



Form No. 3410-990 Rev A

**Count on it.**

# Operator's Manual

## Groundsmaster® 4300-D Traction Unit

Model No. 30853—Serial No. 400000000 and Up



This product complies with all relevant European directives; for details, please see the separate product specific Declaration of Conformity (DOC) sheet.

## WARNING

## CALIFORNIA Proposition 65 Warning

**This product contains a chemical or chemicals known to the State of California to cause cancer, birth defects, or reproductive harm.**

**Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.**

It is a violation of California Public Resource Code Section 4442 or 4443 to use or operate the engine on any forest-covered, brush-covered, or grass-covered land unless the engine is equipped with a spark arrester, as defined in Section 4442, maintained in effective working order or the engine is constructed, equipped, and maintained for the prevention of fire.

Please refer to the engine manufacturer's information included with the machine.

# Introduction

This machine is a ride-on, rotary-blade lawn mower intended to be used by professional, hired operators in commercial applications. It is primarily designed for cutting grass on well-maintained lawns in parks, sports fields, and on commercial grounds. It is not designed for cutting brush, mowing grass and other growth alongside highways, or for agricultural uses.

Read this information carefully to learn how to operate and maintain your product properly and to avoid injury and product damage. You are responsible for operating the product properly and safely.

You may contact Toro directly at [www.Toro.com](http://www.Toro.com) for product safety and operation training materials, accessory information, help finding a dealer, or to register your product.

Whenever you need service, genuine Toro parts, or additional information, contact an Authorized Service Dealer or Toro Customer Service and have the model and serial numbers of your product ready. The model and serial numbers are on a plate mounted on the left side of the frame under the footrest. Write the numbers in the space provided.

**Model No.** \_\_\_\_\_

**Serial No.** \_\_\_\_\_

This manual identifies potential hazards and has safety messages identified by the safety-alert symbol (Figure 1), which signals a hazard that may cause serious injury or death if you do not follow the recommended precautions.



### Figure 1

g000502

1. Safety-alert symbol

This manual uses 2 words to highlight information.

**Important** calls attention to special mechanical information and **Note** emphasizes general information worthy of special attention.

# Contents

|                                                   |    |                                                      |    |
|---------------------------------------------------|----|------------------------------------------------------|----|
| Safety .....                                      | 4  | Lubrication .....                                    | 38 |
| General Safety.....                               | 4  | Greasing the Bearings and Bushings.....              | 38 |
| Slope Indicator .....                             | 5  | Engine Maintenance .....                             | 40 |
| Safety and Instructional Decals .....             | 6  | Engine Safety.....                                   | 40 |
| Setup .....                                       | 11 | Servicing the Air Cleaner .....                      | 40 |
| 1 Adjusting the Control Arm Position.....         | 12 | Servicing the Engine Oil.....                        | 41 |
| 2 Removing the Shipping Blocks and Pins .....     | 12 | Fuel System Maintenance .....                        | 42 |
| 3 Installing Rear Weights .....                   | 13 | Servicing the Fuel System .....                      | 42 |
| 4 Installing the Hood Latch for CE .....          | 14 | Servicing the Water Separator.....                   | 43 |
| Compliance.....                                   | 14 | Servicing the Fuel-Pickup Tube .....                 | 43 |
| 5 Installing the Throttle Stop for CE .....       | 14 | Bleeding Air from the Fuel Injectors.....            | 43 |
| Compliance.....                                   | 14 | Electrical System Maintenance .....                  | 44 |
| 6 Adjusting the Carrier Frame .....               | 14 | Electrical System Safety.....                        | 44 |
| 7 Adjusting the Roller Scraper (Optional) .....   | 15 | Servicing the Battery .....                          | 44 |
| 8 Installing the Mulching Baffle (Optional) ..... | 16 | Replacing the Fuses .....                            | 44 |
| 9 Preparing the Machine.....                      | 16 | Charging the Battery .....                           | 45 |
| Product Overview .....                            | 17 | Drive System Maintenance .....                       | 45 |
| Controls .....                                    | 17 | Adjusting the Traction Drive for Neutral.....        | 45 |
| Specifications .....                              | 22 | Adjusting the Rear Wheel Toe-in .....                | 46 |
| Cutting Unit Specifications .....                 | 23 | Cooling System Maintenance .....                     | 46 |
| Attachments/Accessories.....                      | 23 | Cooling System Safety.....                           | 46 |
| Before Operation .....                            | 24 | Checking the Cooling System .....                    | 46 |
| Before Operation Safety.....                      | 24 | Removing Debris from the Cooling System .....        | 47 |
| Adding Fuel.....                                  | 24 | Brake Maintenance .....                              | 48 |
| Checking the Engine-Oil Level.....                | 25 | Adjusting the Parking Brakes.....                    | 48 |
| Checking the Cooling System.....                  | 25 | Adjusting the Parking-Brake Latch.....               | 49 |
| Checking the Hydraulic System .....               | 25 | Belt Maintenance .....                               | 49 |
| Draining the Water Separator.....                 | 25 | Tensioning the Alternator Belt .....                 | 49 |
| Checking the Tire Pressure .....                  | 25 | Hydraulic System Maintenance .....                   | 50 |
| Checking the Torque of the Wheel-Lug .....        | 25 | Hydraulic System Safety .....                        | 50 |
| Nuts .....                                        | 25 | Checking the Hydraulic-Fluid Level .....             | 50 |
| Adjusting the Height of Cut .....                 | 26 | Changing the Hydraulic Fluid.....                    | 51 |
| Breaking-in the Machine.....                      | 26 | Replacing the Hydraulic Filters .....                | 52 |
| Bleeding the Fuel System.....                     | 27 | Checking the Hydraulic Lines and Hoses.....          | 53 |
| Checking the Safety-Interlock Switches.....       | 28 | Testing the Pressure in the Hydraulic System.....    | 53 |
| Checking the Blade Stopping Time.....             | 28 | Hydraulic Valve Solenoid Functions.....              | 53 |
| Selecting a Blade.....                            | 28 | Cutting Deck Maintenance .....                       | 53 |
| Understanding the Diagnostic Light.....           | 29 | Separating the Cutting Decks from the Traction ..... | 53 |
| Changing the Counterbalance Settings.....         | 29 | Unit .....                                           | 53 |
| Choosing Accessories .....                        | 30 | Mounting the Cutting Decks to the Traction .....     | 54 |
| During Operation .....                            | 31 | Unit .....                                           | 54 |
| During Operation Safety .....                     | 31 | Blade Maintenance .....                              | 54 |
| Starting and Shutting Off the Engine.....         | 31 | Blade Safety .....                                   | 54 |
| Operating Tips .....                              | 32 | Servicing the Blade Plane.....                       | 54 |
| After Operation .....                             | 33 | Removing and Installing a Blade .....                | 55 |
| After Operation Safety .....                      | 33 | Inspecting and Sharpening the Blade .....            | 56 |
| Identifying the Tie-Down Points .....             | 33 | Miscellaneous Maintenance .....                      | 57 |
| Pushing or Towing the Machine.....                | 34 | Servicing the Front Roller.....                      | 57 |
| Hauling the Machine.....                          | 34 | Storage .....                                        | 58 |
| Maintenance .....                                 | 35 | Preparing the Machine for Storage .....              | 58 |
| Recommended Maintenance Schedule(s) .....         | 35 | Storing the Cutting Deck .....                       | 58 |
| Daily Maintenance Checklist .....                 | 36 |                                                      |    |
| Service-Interval Chart.....                       | 37 |                                                      |    |
| Pre-Maintenance Procedures .....                  | 37 |                                                      |    |
| Pre-Maintenance Safety.....                       | 37 |                                                      |    |
| Raising the Machine.....                          | 37 |                                                      |    |

# Safety

This machine has been designed in accordance with EN ISO 5395:2013 and ANSI B71.4-2012.

**Important:** For CE required regulatory data, refer to the Declaration of Conformity supplied with the machine.

## General Safety

This product is capable of amputating hands and feet and of throwing objects. Always follow all safety instructions to avoid serious personal injury.

Using this product for purposes other than its intended use could prove dangerous to you and bystanders.

- Read and understand the contents of this *Operator's Manual* before starting the engine.
- Do not put your hands or feet near moving components of the machine.
- Do not operate the machine without all guards and other safety protective devices in place and working on the machine.
- Keep clear of any discharge opening. Keep bystanders and pets a safe distance away from the machine.
- Keep children out of the operating area. Never allow children to operate the machine.
- Stop the machine and shut off the engine before servicing, fueling, or unclogging the machine.

Improperly using or maintaining this machine can result in injury. To reduce the potential for injury, comply with these safety instructions and always pay attention to the safety-alert symbol, which means Caution, Warning, or Danger—personal safety instruction. Failure to comply with these instructions may result in personal injury or death.

You can find additional safety information where needed throughout this *Operator's Manual*.

# Slope Indicator




**Figure 2**


This page may be copied for personal use.

1. The maximum slope you can safely operate the machine on is **15 degrees**. Use the slope chart to determine the degree of slope of hills before operating. **Do not operate this machine on a slope greater than 15 degrees.** Fold along the appropriate line to match the recommended slope.
2. Align this edge with a vertical surface, a tree, building, fence pole, etc.
3. Example of how to compare slope with folded edge

# Safety and Instructional Decals




Safety decals and instructions are easily visible and are located near any area of potential danger. Replace any decal that is damaged or missing.



**93-6689**

decal93-6689


1. Danger—do not sit on the plastic shroud.



**93-7272**

decal93-7272


1. Cutting/dismemberment hazard; fan—stay away from moving parts.



**93-7818**

decal93-7818


1. Warning—read the *Operator's Manual* for instructions on torquing the blade bolt/nut to 115 to 149 N·m (85 to 110 ft-lb).



**106-6754**

decal106-6754


1. Warning—do not touch the hot surface.
2. Cutting/dismemberment hazard, fan and entanglement hazard, belt—stay away from moving parts.



**106-6755**

decal106-6755


1. Engine coolant under pressure.
2. Explosion hazard—read the *Operator's Manual*.
3. Warning—do not touch the hot surface.
4. Warning—read the *Operator's Manual*.



**110-0986**

decal110-0986


1. Press the brake pedal and parking-brake pedal to engage the parking brake.
2. Press the brake pedal to apply the brake.
3. Press the traction pedal to move the machine forward.
4. PTO enabled mode
5. Transport mode (No PTO)



**110-8921**

decal110-8921

1. Traction unit speed
2. Slow
3. Fast



117-0169

1. Read the *Operator's Manual*.
2. Power point (10 A)
3. Head lights (10 A)
4. Power (10 A)
5. Engine start (15 A)
6. Optional air ride seat suspension (20 A)
7. Engine computer management C (7.5 A)
8. Engine computer management B (7.5 A)
9. Engine computer management A (7.5 A)

decal117-0169


#### CALIFORNIA SPARK ARRESTER WARNING

Operation of this equipment may create sparks that can start fires around dry vegetation. A spark arrester may be required. The operator should contact local fire agencies for laws or regulations relating to fire prevention requirements.

117-2718

117-2718


decal117-2718



117-4764

decal117-4764


1. Thrown object hazard—keep bystanders a safe distance away from the machine.
2. Cutting hazard of hand, mower blade—stay away from moving parts, keep all guards and shields in place.
3. Cutting hazard of foot, mower blade—stay away from moving parts, keep all guards and shields in place.



120-4158

decal120-4158

1. Read the *Operator's Manual*.
2. Engine—start
3. Engine—preheat
4. Engine—stop



121-5644

decal121-5644


- |                   |                                        |
|-------------------|----------------------------------------|
| 1. Light switch   | 6. Slow                                |
| 2. Engage         | 7. Lower                               |
| 3. Power take-off | 8. Raise                               |
| 4. Disengage      | 9. Read the <i>Operator's Manual</i> . |
| 5. Fast           |                                        |



### Battery Symbols

Some or all of these symbols are on your battery

- |                                        |                                                                                 |
|----------------------------------------|---------------------------------------------------------------------------------|
| 1. Explosion hazard                    | 6. Keep bystanders a safe distance away from the battery.                       |
| 2. No fire, open flame, or smoking     | 7. Wear eye protection; explosive gases can cause blindness and other injuries. |
| 3. Caustic liquid/chemical burn hazard | 8. Battery acid can cause blindness or severe burns.                            |
| 4. Wear eye protection.                | 9. Flush eyes immediately with water and get medical help fast.                 |
| 5. Read the <i>Operator's Manual</i> . | 10. Contains lead; do not discard                                               |



104-1086

decal104-1086

1. Height of cut

# REELMASTER 5010-H/ 5410/5510/5610 & GROUNDMASTER 4300 QUICK REFERENCE AID

CHECK/SERVICE (daily)

1. OIL LEVEL, ENGINE
2. OIL LEVEL, HYDRAULIC TANK
3. COOLANT LEVEL, RADIATOR
4. FUEL /WATER SEPARATOR
5. PRECLEANER – AIR CLEANER

6. RADIATOR SCREEN

7. BRAKE FUNCTION

8. TIRE PRESSURE


9. BELTS (FAN, ALT.)

GREASING -- SEE OPERATOR'S MANUAL

## FLUID SPECIFICATIONS/CHANGE INTERVALS

| SEE OPERATOR'S MANUAL FOR INITIAL CHANGES. | FLUID TYPE                  | CAPACITY                        | CHANGE INTERVAL         |                           | FILTER PART NO.                                                    |
|--------------------------------------------|-----------------------------|---------------------------------|-------------------------|---------------------------|--------------------------------------------------------------------|
|                                            |                             |                                 | FLUID                   | FILTER                    |                                                                    |
| A. ENGINE OIL                              | SAE 15W-40CI-4              | 3.5 QTS.* (5010-H)<br>5.5 QTS.* | 150 HRS.                | 150 HRS.                  | 104-5167                                                           |
| B. HYD. CIRCUIT OIL                        | ISO VG 46/68                | 11 GALS.* (5010-H)<br>15 GALS.* | 800 HRS.                | SEE INDICATOR<br>800 HRS. | 94-2621**<br>86-3010                                               |
| C. AIR CLEANER                             |                             |                                 |                         | SEE INDICATOR             | 108-3810 (5010-H)<br>(5410)<br>(5510)<br>108-3812 (5610)<br>(4300) |
| D. WATER SEPARATOR                         |                             |                                 |                         | 400 HRS.                  | 110-9049                                                           |
| E. FUEL TANK                               | NO. 2-DIESEL                | 14 GALS.                        | DRAIN AND FLUSH, 2 YRS. |                           |                                                                    |
| F. COOLANT                                 | 50/50 ETHYLENE GLYCOL/WATER | 5.5 QTS. (5010-H)               | DRAIN AND FLUSH, 2 YRS. |                           |                                                                    |
|                                            |                             | 7.0 QTS. (5410)<br>(5510)       |                         |                           |                                                                    |
|                                            |                             | 10.0 QTS. (5610)<br>(4300)      |                         |                           |                                                                    |

\* INCLUDING FILTER \*\* EXCLUDES 5010-H




125-8753

125-8753

decal125-8753

1. Read the *Operator's Manual* for more maintenance information.



133-2930

decal133-2930

1. Warning—read the *Operator's Manual*; do not operate this machine unless you are trained.
2. Warning—wear hearing protection.
3. Thrown object hazard—keep bystanders a safe distance away from the machine.
4. Tipping hazard—slow the machine before turning; do not turn at high speeds; only drive on slopes with the cutting units lowered; always wear a seatbelt.
5. Warning—do not park on slopes; lock the parking brake, stop the engine and remove the ignition key before leaving the machine.
6. Warning—read the *Operator's Manual*; do not tow the machine.



decal133-2931

### 133-2931

1. Warning—read the *Operator's Manual*; do not operate this machine unless you are trained.
2. Warning—wear hearing protection.
3. Thrown object hazard—keep bystanders a safe distance away from the machine
4. Tipping hazard—do not drive across or down slopes greater than 15 degrees; only drive on slopes with the cutting units lowered; always wear a seatbelt
5. Warning—do not park on slopes; lock the parking brake, stop the engine and remove the ignition key before leaving the machine.
6. Warning—read the *Operator's Manual*; do not tow the machine.

# Setup

## Loose Parts

Use the chart below to verify that all parts have been shipped.

| Procedure | Description                                        | Qty.   | Use                                                      |
|-----------|----------------------------------------------------|--------|----------------------------------------------------------|
| <b>1</b>  | No parts required                                  | –      | Adjust the control arm position.                         |
| <b>2</b>  | No parts required                                  | –      | Remove the shipping blocks and pins.                     |
| <b>3</b>  | Rear weights (quantity varies with configuration). | Varies | Install rear weights (order from your Toro Distributor). |
| <b>4</b>  | Hood-latch assembly<br>Washer                      | 1<br>1 | Install the hood latch for CE compliance.                |
| <b>5</b>  | Throttle stop<br>Set screw                         | 1<br>1 | Install the throttle stop for CE compliance.             |
| <b>6</b>  | No parts required                                  | –      | Adjust the carrier frame.                                |
| <b>7</b>  | No parts required                                  | –      | Adjust the roller scraper (Optional).                    |
| <b>8</b>  | No parts required                                  | –      | Install the mulching baffle (Optional).                  |
| <b>9</b>  | No parts required                                  | –      | Prepare the machine.                                     |

## Media and Additional Parts

| Description                | Qty. | Use                             |
|----------------------------|------|---------------------------------|
| Operator's Manual          | 1    | Review before operating machine |
| Engine Operator's Manual   | 1    |                                 |
| Parts Catalog              | 1    |                                 |
| Declaration of Conformity  | 1    |                                 |
| Operator Training Material | 1    |                                 |

**Note:** Determine the left and right sides of the machine from the normal operating position.

# 1

## Adjusting the Control Arm Position

No Parts Required

### Procedure

The control arm position can be adjusted for your comfort.

1. Loosen the 2 bolts securing the control arm to the retaining bracket (Figure 3).




Figure 3

1. Control arm
2. Retaining brackets
3. Bolts (2)

2. Rotate the control arm to the desired position and tighten the 2 bolts.

# 2

## Removing the Shipping Blocks and Pins

No Parts Required

### Procedure

1. Remove and discard the shipping blocks from the cutting decks.
2. Remove and discard the shipping pins from the cutting-deck suspension arms.

**Important:** The shipping pins stabilize the cutting decks during shipping, remove them before operation.

# 3

## Installing Rear Weights

### Parts needed for this procedure:

|        |                                                    |
|--------|----------------------------------------------------|
| Varies | Rear weights (quantity varies with configuration). |
|--------|----------------------------------------------------|

### Procedure

The Groundsmaster 4300–D Traction Unit complies with EN ISO 5395:2013 and ANSI B71.4-2012 standards when equipped with rear weights and/or 40.8 kg (90 lb) of calcium chloride ballast is added to rear wheels. Use the following charts to determine the combinations of weights required for your configuration. Order parts from your Toro Distributor.

| Weight P/N 110-8985-03                                                |                                               |                                                   |                                         |                                          |
|-----------------------------------------------------------------------|-----------------------------------------------|---------------------------------------------------|-----------------------------------------|------------------------------------------|
| Configuration                                                         | Number of weights to meet ANSI (US) standards | Number of weights to meet CE (European) standards | Fasteners (2 each required) for weights | Weight Location                          |
| Base Unit                                                             | 6                                             | 0                                                 | 3231–34 Carriage Bolt<br>104–8301 Nut   | 3 on top of bumper and<br>3 under bumper |
| With Recycler Kit                                                     | 40.8 kg (90 lb) calcium chloride*             | 0                                                 | N/A                                     | N/A                                      |
| With Sunshade                                                         | 40.8 kg (90 lb) calcium chloride*             | 4                                                 | 3231–7 Carriage Bolt<br>104–8301 Nut    | 1 on top of bumper and<br>3 under bumper |
| With 4 Post ROPS and Sunshade                                         | 40.8 kg (90 lb) calcium chloride*             | 4                                                 | 3231–7 Carriage Bolt<br>104–8301 Nut    | 1 on top of bumper and<br>3 under bumper |
| * Install tubes inside the rear tires before adding calcium chloride. |                                               |                                                   |                                         |                                          |

**Important:** Always install tubes inside the rear tires before calcium chloride is installed. If a puncture occurs in a tire with calcium chloride, remove the machine from the turf area as quickly as possible. To prevent possible damage to the turf, immediately soak the affected area with water.





Figure 4

# 4

## Installing the Hood Latch for CE Compliance

### Parts needed for this procedure:

|   |                     |
|---|---------------------|
| 1 | Hood-latch assembly |
| 1 | Washer              |

### Procedure

1. Unlatch and raise the hood.
2. Remove the rubber grommet from the hole in the left side of the hood (Figure 5).




Figure 5

1. Rubber grommet

3. Remove the nut from the hood-latch assembly (Figure 6).




Figure 6

1. Hood latch
2. Nut
3. Rubber washer
4. Metal washer

4. Outside the hood, insert the hook end of the latch through the hole in the hood and make sure that the rubber-sealing washer remains to the outer side of the hood (Figure 6).
5. Inside the hood, insert the metal washer onto the latch and secure with the nut and make sure that the latch engages the frame catch when it is locked. Use the enclosed hood-latch key to operate the hood latch.

# 5

## Installing the Throttle Stop for CE Compliance

### Parts needed for this procedure:

|   |               |
|---|---------------|
| 1 | Throttle stop |
| 1 | Set screw     |

### Procedure

1. Loosen the set screw on the throttle stop (Figure 7).
2. Slide the throttle stop onto the high-idle stop screw (Figure 7). The chamfered end of the throttle stop is to be positioned outward.




Figure 7

1. Throttle stop
2. Set screw

3. Turn the key in the ignition switch to the ON position and allow the engine to run for 5 to 10 minutes.
4. Adjust the high idle to 2,860 rpm with the cutting decks disengaged.
5. Tighten the set screw.
6. Apply adhesive into the set screw to prevent tampering.

# 6

## Adjusting the Carrier Frame

### No Parts Required

### Adjusting the Front Cutting Decks

The front and rear cutting decks require different mounting positions. The front cutting deck has 2 mounting positions depending on what height of cut and degree of deck rotation you desire.

1. For heights of cut between 2.0 to 7.6 cm (0.75 to 3 inches), mount the front carrier frames in the lower front mounting holes (Figure 8).

**Note:** This position allows more forward positioning of the cutting decks relative to the traction unit when approaching quick uphill changes in terrain. It does however limit the clearance of the chamber to the carrier when cresting sharp knolls.




Figure 8

1. Front deck mounting hole (upper)
2. Front deck mounting hole (lower)
3. Rear deck mounting hole

2. For heights of cut between 6.3 to 10 cm (2.5 to 4 inches), mount the front carrier frames in the upper front mounting holes (Figure 8).

**Note:** This increases the chamber to carrier clearance due to the higher position of the cutting chamber, but will cause the cutting decks to reach their maximum forward travel sooner.

## Adjusting the Rear Cutting Deck

The front and rear cutting decks require different mounting positions. The rear cutting deck has 1 mounting position for proper alignment with the sidewinder under frame.

For all heights of cut, mount the rear cutting deck in the rear-mounting holes (Figure 8).

# 7

## Adjusting the Roller Scraper (Optional)

### No Parts Required

### Procedure

The optional rear roller scraper is designed to work best when there is an even gap of 0.5 to 1 mm (0.020 to 0.040 inch) between the scraper and roller.

1. Loosen the grease fitting and the mounting screw (Figure 9).




Figure 9

1. Roller scraper
2. Mounting screw
3. Grease fitting

2. Slide the scraper up or down until a gap of 0.5 to 1 mm (0.020 to 0.040 inch) is achieved between the rod and the roller.
3. Secure the grease fitting and torque to 41 N·m (30 ft-lb) in an alternating sequence.

# 8

## Installing the Mulching Baffle (Optional)

### No Parts Required

### Procedure

1. Thoroughly clean debris from the mounting holes on the rear wall and left side wall of the chamber.
2. Install the mulching baffle in the rear opening and secure it with 5 flange-head bolts ([Figure 10](#)).




Figure 10

1. Mulching baffle

3. Verify that the mulching baffle does not interfere with the tip of the blade and does not protrude inside the surface of the rear chamber wall.

### **⚠ DANGER**

Do not use the high-lift blade with the mulching baffle. The blade could break, resulting in personal injury or death.

# 9

## Preparing the Machine

### No Parts Required

### Checking the Tire Pressure

Check the tire pressure before use; refer to [Checking the Tire Pressure](#) (page 25).

**Important:** Maintain pressure in all tires to ensure a good quality-of-cut and proper machine performance. *Do not underinflate the tires.*

### Checking the Fluid Levels

1. Check the engine-oil level before starting the engine; refer to [Checking the Engine-Oil Level](#) (page 41).
2. Check the hydraulic-fluid level before starting the engine; refer to [Checking the Hydraulic-Fluid Level](#) (page 50).
3. Check the cooling system before starting the engine; refer to [Checking the Cooling System](#) (page 46).

### Greasing the Machine

Grease the machine before use; refer to [Greasing the Bearings and Bushings](#) (page 38). Failure to properly grease the machine results in premature failure of critical parts.

# Product Overview

## Controls

### Seat Adjusting Knobs

The seat-adjusting lever (Figure 11) allows you to adjust the seat forward and rearward. The weight-adjusting knob adjusts the seat for your weight. The weight gauge indicates when the seat is adjusted to your weight. The height-adjusting knob adjusts the seat for your height.




Figure 11

- |                          |                                           |
|--------------------------|-------------------------------------------|
| 1. Weight gauge          | 3. Height-adjusting knob                  |
| 2. Weight-adjusting knob | 4. Adjusting lever (forward and rearward) |

### Traction Pedal

The traction pedal (Figure 12) controls the forward and reverse operation. Press the top of the pedal to move forward and the bottom to move backward.

To stop, reduce foot pressure on the traction pedal and allow it to return to the center position.

### Mow-Speed Limiter

When the mow-speed limiter (Figure 12) is flipped up it will control the mow speed and allow the cutting decks to be engaged. Each spacer adjusts the mowing speed by 0.8 km/h (0.5 mph). The more spacers you have on the top of the bolt, the slower you will go. For transport, flip back the mow speed limiter for maximum-transport speed.

### Brake Pedal

Press the brake pedal (Figure 12) to stop the machine.

### Parking Brake

To engage the parking brake, (Figure 12) push down the brake pedal and press the top forward to latch. To disengage the parking brake, press the brake pedal until the parking-brake latch retracts.




Figure 12

- |                      |                        |
|----------------------|------------------------|
| 1. Traction pedal    | 4. Brake pedal         |
| 2. Mow-speed limiter | 5. Parking brake       |
| 3. Spacers           | 6. Tilt-steering pedal |

### Tilt-Steering Pedal

To tilt the steering wheel toward you, press the foot pedal (Figure 12) down, and pull the steering tower toward you to the most comfortable position and then release the pedal.

### Headlight Switch

Pivot the switch downward to turn on the headlights (Figure 13).

### Throttle Control

Move the throttle control (Figure 13) forward to increase the engine speed and backward to decrease speed.




Figure 13

- |                                  |                                |
|----------------------------------|--------------------------------|
| 1. Lower mow/raise control lever | 4. Enable/disable switch lever |
| 2. Key switch                    | 5. Throttle control            |
| 3. InfoCenter                    | 6. Headlight switch            |

## Key Switch

The key switch (Figure 13) has 3 positions: OFF, ON/PREHEAT, and START.

## Lower Mow/Raise Control Lever

This lever (Figure 13) raises and lowers the cutting decks and also starts and stops the mowers when the mowers are enabled in the mow mode. When starting the decks in the down position, this lever will turn the decks on if the PTO and the mow speed limiter are engaged.

## Enable/Disable Switch

Use the enable/disable switch (Figure 13) in conjunction with the lower mow/raise control lever to operate the mowers. The mowers cannot be lowered when the mow/transport lever is in the transport position.

## Hydraulic-Filter-Restriction Indicator

With the engine running at normal operating temperature, view the indicator (Figure 14), it should be in the green zone. When the indicator is in the red zone, change the hydraulic filters.




Figure 14

1. Hydraulic-filter-restriction indicator

## Power Point

The power point is a 12 V power supply for electronic devices (Figure 15).




Figure 15

1. Power point

## Using the InfoCenter LCD Display

The InfoCenter LCD display shows the operating status, various diagnostics, and other information about the machine (Figure 16). There is a splash screen and main information screen in the InfoCenter. Press any of the InfoCenter buttons and then select the appropriate directional arrow to switch between the splash screen and the main information screen.




Figure 16

1. Indicator light
2. Right button
3. Middle button
4. Left button

- Left Button, Menu Access/Back Button—press to access the InfoCenter menus. You can use it to back out of any menu you are currently using.
- Middle Button—press to scroll down menus.
- Right Button—press to open a menu where a right arrow indicates additional content.

**Note:** The purpose of each button may change depending on what is required at the time. Each button is labeled with an icon displaying its current function.

## InfoCenter Icon Description

|                                                                                     |                                                      |
|-------------------------------------------------------------------------------------|------------------------------------------------------|
| <b>SERVICE DUE</b>                                                                  | Indicates when scheduled service should be performed |
|    | Hour meter                                           |
|    | Info icon                                            |
|    | Fast                                                 |
|    | Slow                                                 |
|    | Fuel level                                           |
|    | The glow plugs are active                            |
|    | Raise the cutting units                              |
|    | Lower the cutting units                              |
|    | Sit in the seat.                                     |
|   | The parking brake is engaged                         |
| <b>H</b>                                                                            | The range is high (Transport)                        |
| <b>N</b>                                                                            | Neutral                                              |
| <b>L</b>                                                                            | The range is low (Mow)                               |
|  | Coolant Temperature (°C or °F)                       |
|  | Temperature (hot)                                    |
|  | The PTO is engaged                                   |
|  | Not allowed                                          |
|  | Start the engine                                     |
|  | Shut off the engine                                  |
|  | Engine                                               |
|  | Key switch                                           |

## InfoCenter Icon Description (cont'd.)

|                                                                                                                                                                            |                                                  |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------|
|                                                                                           | Cutting units are lowering                       |
|                                                                                           | Cutting units are raising                        |
| <b>PIN</b>                                                                                                                                                                 | PIN passcode                                     |
| <b>CAN</b>                                                                                                                                                                 | CAN bus                                          |
|                                                                                           | InfoCenter                                       |
| <b>Bad</b>                                                                                                                                                                 | Bad or failed                                    |
|                                                                                           | Bulb                                             |
| <b>OUT</b>                                                                                                                                                                 | Output of TEC controller or control wire harness |
|                                                                                           | Switch                                           |
|                                                                                           | Release the switch                               |
|                                                                                           | Change to indicated state.                       |
| Symbols are often combined to form sentences. Some examples are shown below                                                                                                |                                                  |
|  <b>N</b>                                                                               | Put machine into neutral.                        |
|      | Engine start is denied.                          |
|      | Engine shutdown                                  |
|      | Engine coolant is too hot                        |
|  or  | Sit down or engage parking brake                 |

## Using the Menus

To access the InfoCenter menu system, press the menu access button while at the main screen. This brings you to the main menu. Refer to the following tables for a synopsis of the options available from the menus:

| Main Menu   |                                                                                                                                                                                                 |
|-------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Menu Item   | Description                                                                                                                                                                                     |
| Faults      | Contains a list of the recent machine faults. Refer to the <i>Service Manual</i> or your Toro Distributor for more information on the Faults menu and the information contained there.          |
| Service     | Contains information on the machine such as hours of use, counters, and other similar numbers.                                                                                                  |
| Diagnostics | Displays the state of each machine switch, sensor, and control output. You can use this to troubleshoot certain issues as it quickly tells you which machine controls are ON and which are OFF. |
| Settings    | Allows you to customize and modify configuration variables on the InfoCenter display.                                                                                                           |
| About       | Lists the model number, serial number, and software version of your machine.                                                                                                                    |

| Service   |                                                                                                                                                                  |
|-----------|------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Menu Item | Description                                                                                                                                                      |
| Hours     | Lists the total number of hours that the machine, engine, and PTO have been on, as well as the number of hours the machine has been transported and service due. |
| Counts    | Lists numerous counts the machine has experienced.                                                                                                               |

| Diagnostics   |                                                                                           |
|---------------|-------------------------------------------------------------------------------------------|
| Menu Item     | Description                                                                               |
| Cutting Units | Indicates the inputs, qualifiers, and outputs for raising and lowering the cutting units. |
| Hi/Low Range  | Indicates the inputs, qualifiers, and outputs for driving in transport mode.              |
| PTO           | Indicates the inputs, qualifiers, and outputs for enabling the PTO circuit.               |
| Engine Run    | Indicates the inputs, qualifiers, and outputs for starting the engine.                    |

| Settings        |                                                                                       |
|-----------------|---------------------------------------------------------------------------------------|
| Menu Item       | Description                                                                           |
| Units           | Controls the units used on the InfoCenter (English or Metric).                        |
| Language        | Controls the language used on the InfoCenter*.                                        |
| LCD Backlight   | Controls the brightness of the LCD display.                                           |
| LCD Contrast    | Controls the contrast of the LCD display.                                             |
| Protected Menus | Allows the superintendent/mechanic to access protected menus by inputting a passcode. |
| Counterbalance  | Controls the amount of counterbalance applied to the cutting decks.                   |

\*Only operator-faced text is translated. Faults, Service, and Diagnostics screens are service-faced. Titles appear in the selected language, but menu items are in English.

| About                       |                                                       |
|-----------------------------|-------------------------------------------------------|
| Menu Item                   | Description                                           |
| Model                       | Lists the model number of the machine.                |
| SN                          | Lists the serial number of the machine.               |
| Machine Controller Revision | Lists the software revision of the master controller. |
| InfoCenter Revision         | Lists the software revision of the InfoCenter.        |
| CAN Bus                     | Lists the machine communication bus status.           |

## Protected Menus

There is 1 operating configuration setting that is adjustable within the Settings Menu of the InfoCenter: counterbalance. This setting can be locked by using the Protected Menu.

**Note:** At the time of delivery, the initial password code is programmed by your distributor.

## Accessing the Protected Menu Settings

1. From the Main Menu, scroll down to the Settings Menu and press the right button.
2. In the Settings Menu, scroll down to the Protected Menu and press the right button.
3. To enter the passcode, use the center button to set the first digit and then press the right button to move on to the next digit.
4. Use the center button to set the second digit and then press the right button to move on the next digit.
5. Use the center button to set the third digit and then press the right button to move on to the next digit.
6. Use the center button to set the fourth digit and then press the right button.
7. Press the middle button to enter the code.
8. If the code has been accepted and the protected menu has been unlocked, "PIN" will be displayed in the upper right corner of the display screen.

**Note:** If you forget or misplace your passcode, contact your Toro Distributor for assistance.

## Viewing and Changing the Protected Menu Settings

1. In the Protected Menu, scroll down to Protect Settings.
2. To view and change the settings without entering a passcode, use the right button to change the Protect Settings to OFF.
3. To view and change the settings with a passcode, use the left button to change the Protect Settings to ON, set the passcode, and turn the key in the ignition switch to the OFF position and then to the ON position.

## Setting the Counterbalance

1. In the Settings Menu, scroll down to Counterbalance.
2. Press the right button to select counterbalance and change between the low, medium, and high settings.

# Specifications

**Note:** Specifications and design are subject to change without notice.




Figure 17

g193881

| Description                              | Figure 17 reference | Dimension or Weight      |
|------------------------------------------|---------------------|--------------------------|
| Overall height                           | A                   | 217.2 cm (85-1/2 inches) |
| Wheel tread (tire center to center) rear | B                   | 184.5 cm (72.6 inches)   |
| Overall width (transport position)       | C                   | 231 cm (91 inches)       |
| Overall width (mowing position)          | D                   | 246.5 cm (97 inches)     |
| Wheel base                               | E                   | 152.4 cm (60 inches)     |
| Overall length (transport position)      | F                   | 315 cm (124 inches)      |

|                                            |   |                            |
|--------------------------------------------|---|----------------------------|
| Overall length (mowing position)           | G | 315 cm (124 inches)        |
| Fuel-tank capacity                         |   | 53 L (14 US gallons)       |
| Transport speed                            |   | 0 to 16 km/h (0 to 10 mph) |
| Mowing speed                               |   | 0 to 13 km/h (0 to 8 mph)  |
| Net weight (with cutting decks and fluids) |   | 1,412 kg (3,114 lb)        |

## Cutting Unit Specifications

|        |                                                                                                                                                 |
|--------|-------------------------------------------------------------------------------------------------------------------------------------------------|
| Length | 86.4 cm (34 inches)                                                                                                                             |
| Width  | 86.4 cm (34 inches)                                                                                                                             |
| Height | 24.4 cm (9.6 inches) to carrier mount<br>26.7 cm (10-1/2 inches) at 3/4 inch height of cut<br>34.9 cm (13-3/4 inches) at 4 inches height of cut |
| Weight | 88 kg (195 lb)                                                                                                                                  |

## Attachments/Accessories

A selection of Toro approved attachments and accessories is available for use with the machine to enhance and expand its capabilities. Contact your Authorized Service Dealer or Distributor or go to [www.Toro.com](http://www.Toro.com) for a list of all approved attachments and accessories.

To best protect your investment and maintain optimal performance of your Toro equipment, count on Toro genuine parts. When it comes to reliability, Toro delivers replacement parts designed to the exact engineering specification of our equipment. For peace of mind, insist on Toro genuine parts.

# Operation

**Note:** Determine the left and right sides of the machine from the normal operating position.

## Before Operation

### Before Operation Safety

#### General Safety

- Never allow children or untrained people to operate or service the machine. Local regulations may restrict the age of the operator. The owner is responsible for training all operators and mechanics.
- Become familiar with the safe operation of the equipment, operator controls, and safety signs.
- Know how to stop the machine and engine quickly.
- Check that operator-presence controls, safety switches, and shields are attached and functioning properly. Do not operate the machine unless they are functioning properly.
- Before mowing, always inspect the machine to ensure that the blades, blade bolts, and cutting assemblies are in good working condition. Replace worn or damaged blades and bolts in sets to preserve balance.
- Inspect the area where you will use the machine and remove all objects that the machine could throw.
- Avoid sudden starts and stops, holes, dropoffs, and hidden hazards in the terrain.
- For braking, move the traction pedal to the neutral position or to the direction opposite the travel direction.

#### Fuel Safety

- Use extreme care in handling fuel. It is flammable and its vapors are explosive.
- Extinguish all cigarettes, cigars, pipes, and other sources of ignition.
- Use only an approved fuel container.
- Never remove the fuel cap or fill the fuel tank while the engine is running or hot.
- Never refuel the machine in an enclosed space.
- Never store the machine or fuel container where there is an open flame, spark, or pilot light, such as on a water heater or other appliance.
- If you spill fuel, do not attempt to start the engine; avoid creating any source of ignition until the fuel vapors have dissipated.

# Adding Fuel

## Recommended Fuel

Use only clean, fresh diesel fuel with ultra low (<15 ppm) sulfur content meeting ASTM D975 or EN590 specifications. The minimum cetane rating should be 40. Purchase fuel in quantities that can be used within 180 days to ensure that the fuel is fresh.

Use of non-ultra low sulfur fuel will cause damage to the engine emissions system.

**Fuel-tank capacity:** 53 L (14 US gallons).

Use summer-grade diesel fuel (No. 2-D) at temperatures above -7°C (20°F) and winter grade (No. 1-D or No. 1-D/2-D blend) below that temperature. Using winter-grade fuel at lower temperatures provides lower flash point and cold flow characteristics which eases starting and reduces fuel-filter plugging.

Using summer-grade fuel above -7°C (20°F) contributes toward longer fuel-pump life and increased power compared to winter-grade fuel.

**Important: Do not use kerosene or gasoline instead of diesel fuel. Failure to observe this caution will damage the engine.**


## Biodiesel Ready

This machine can also use a biodiesel blended fuel of up to B20 (20% biodiesel, 80% petrodiesel). The petrodiesel portion must be ultra low sulfur. Observe the following precautions:

- The biodiesel portion of the fuel must meet specification ASTM D6751 or EN14214.
- The blended fuel composition should meet ASTM D975 or EN590.
- Painted surfaces may be damaged by biodiesel blends.
- Use B5 (biodiesel content of 5%) or lesser blends in cold weather.
- Monitor seals, hoses, gaskets in contact with fuel as they may be degraded over time.
- Fuel filter plugging may be expected for a time after converting to biodiesel blends.
- Contact your distributor if you wish for more information on biodiesel.

## Filling the Fuel Tank

**Note:** If possible, fill the fuel tank after each use. This minimizes possible buildup of condensation inside the fuel tank.



g194207




Figure 18

g194206

**Note:** Fill the tank until the level is 6 to 13 mm (1/4 to 1/2 inch) below the bottom of the filler neck.

## Checking the Engine-Oil Level

Before you start the engine and use the machine, check the oil level in the engine crankcase; refer to [Checking the Engine-Oil Level](#) (page 41).

## Checking the Cooling System

Before you start the engine and use the machine, check the cooling system; refer to [Checking the Cooling System](#) (page 46).

## Checking the Hydraulic System

Before you start the engine and use the machine, check the hydraulic system; refer to [Checking the Hydraulic Lines and Hoses](#) (page 53).

## Draining the Water Separator

Drain water or other contaminants from the water separator; refer to [Servicing the Water Separator](#) (page 43).


## Checking the Tire Pressure

**Service Interval:** Before each use or daily

The correct air pressure in the front and rear tires is 83 to 103 kPa (12 to 15 psi).

**Important:** Maintain pressure in all tires to ensure a good quality of cut and proper machine performance. *Do not under-inflate the tires.*

Check the air pressure in all the tires before operating the machine.



G001055

Figure 19

g001055

## Checking the Torque of the Wheel-Lug Nuts

**Service Interval:** After the first hour

After the first 10 hours

Every 250 hours

Torque the wheel-lug nuts to 94 to 122 N·m (70 to 90 ft-lb) after **1-4 hours** of operation and again after **10 hours** of operation. Torque every **250 hours** thereafter.

## ⚠ WARNING

Failure to maintain the proper torque of the wheel nuts could result in failure or loss of a wheel, and may result in personal injury.

Torque the front and rear-wheel nuts to 135 to 150 N·m (100 to 110 ft-lb) after 10 hours of operation. Torque the nuts every 250 hours thereafter.

## Adjusting the Height of Cut

**Important:** This cutting deck often cuts approximately 6 mm (1/4 inch) lower than a reel cutting unit with the same bench setting. It may be necessary to have the bench of the rotary cutting deck set 6 mm (1/4 inch) above that of reels cutting in the same area.

**Important:** Access to the rear cutting units is greatly improved by removing the cutting unit from the tractor. If the unit is equipped with a Sidewinder®, sidewind the cutting units to the right, remove the rear cutting unit, and slide it out to the right side.

1. Lower the cutting deck to the ground, shut off the engine, and remove the key from the ignition switch.
2. Loosen the bolt securing each height-of-cut bracket to the height-of-cut plate (front and each side) as shown in [Figure 20](#).
3. Beginning with the front adjustment, remove the bolt.




Figure 20

1. Height-of-cut bracket
2. Height-of-cut plate
3. Spacer

4. While supporting the chamber, remove the spacer ([Figure 20](#)).
5. Move the chamber to the desired height of cut and install a spacer into the designated height-of-cut hole and slot ([Figure 21](#)).




Figure 21

6. Position the tapped plate in-line with the spacer.
7. Install the bolt finger-tight.
8. Repeat steps through for each side adjustment.
9. Torque all 3 bolts to 41 N·m (30 ft-lb). Always tighten the front bolt first.

**Note:** Adjustments of more than 3.8 cm (1-1/2 inches) may require temporary assembly to an intermediate height to prevent binding (e.g., changing from 3.1 to 7 cm (1-1/4 to 2-3/4 inches) height of cut).

## Breaking-in the Machine

To ensure optimum performance of the parking brake system, burnish (break-in) the brakes before use. Set the forward traction speed to 6.4 km/h (4 mph) to match the reverse traction speed. (All 8 spacers moved to the top of the mow speed control.) With the engine at high idle, proceed forward with the mow speed control stop engaged and ride the brake for 15 seconds. Proceed backward at full reverse speed and ride the brake for 15 seconds. Repeat this 5 times waiting 1 minute between each forward and reverse cycle to avoid overheating the brakes. An adjustment to the brakes may be required after break-in; refer to [Adjusting the Parking Brakes](#) (page 48).

# Bleeding the Fuel System


You must bleed the fuel system before starting the engine if any of the following situations have occurred:

- Initial start-up of a new machine.
- Engine has ceased running due to lack of fuel.
- Maintenance has been performed upon fuel system components; i.e., filter replaced, separator serviced, etc.

## **⚠ DANGER**

Under certain conditions, diesel fuel and fuel vapors are highly flammable and explosive. A fire or explosion from fuel can burn you and others and can cause property damage.

- Use a funnel and fill the fuel tank outdoors, in an open area, when the engine is off and is cold. Wipe up any fuel that spills.
  - Do not fill the fuel tank completely full. Add fuel to the fuel tank until the level is 6 to 13 mm (0.25 to 0.50 inch) below the bottom of the filler neck. This empty space in the tank allows the fuel to expand.
  - Never smoke when handling fuel, and stay away from an open flame or where fuel fumes may be ignited by a spark.
  - Store fuel in a clean, safety-approved container and keep the cap in place.
1. Engage the parking brake, turn the key in the ignition switch to the OFF position, park the machine on a level surface, and ensure that the fuel tank is at least half full.
  2. Open the hood.
  3. Open the air-bleed screw on the fuel injection pump (Figure 22) with a 12 mm wrench.



G003993

g003993

**Figure 22**

### 1. Bleed screw

4. Turn the key in the ignition switch to the ON position. The electric fuel pump will begin operation, thereby forcing air out around the air bleed screw. Leave the key in the ON position until a solid stream of fuel flows out around the screw.
5. Tighten the screw and turn the key to the OFF position.

**Note:** Normally, the engine should start after the above bleeding procedures are followed. However, if engine does not start, air may be trapped between injection pump and injectors; refer to [Bleeding Air from the Fuel Injectors \(page 43\)](#).

# Checking the Safety-Interlock Switches

**Service Interval:** Before each use or daily

## ⚠ CAUTION

If safety interlock switches are disconnected or damaged the machine could operate unexpectedly causing personal injury.

- Do not tamper with the interlock switches.
- Check the operation of the interlock switches daily and replace any damaged switches before operating the machine.

The interlock switches stop the machine when you raise from the seat while the traction pedal is pressed. However, the operator may get off the seat while the engine is running and the traction pedal is in the NEUTRAL position. Although the engine continues to run if the PTO switch is disengaged and the traction pedal is released, shut off the before rising from the seat.

1. Park the machine on a level surface, lower the cutting unit, shut off the engine, and engage the parking brake.
2. Press the traction pedal. Turn the key in the ignition switch to the ON position.

**Note:** If the engine cranks, there is a malfunction in the interlock system. Correct this malfunction before operating the machine.

3. Turn the key in the ignition switch to the ON position, start the engine, rise from the seat, and move the PTO switch to the ON position.

**Note:** The PTO should not engage. If the PTO engages, there is a malfunction in the interlock system. Correct this malfunction before operating the machine.

4. Engage the parking brake, turn the key in the ignition switch to the ON position, start the engine, and move the traction pedal out of the NEUTRAL position.

**Note:** The InfoCenter displays "traction denied" and the machine should not move. If the machine does move, there is a malfunction in the interlock system. Correct this malfunction before operating the machine.

5. Start the engine with the PTO engaged.

**Note:** If the engine cranks, there is a malfunction in the interlock system. Correct this malfunction before operating the machine.

# Checking the Blade Stopping Time

**Service Interval:** Before each use or daily

The blades of the cutting deck should come to a complete stop in approximately 5 seconds after you shut down the cutting-deck-engagement switch.

**Note:** Make sure that the decks are lowered onto a clean section of turf or hard surface to avoid thrown dust and debris.

1. Have a second person stand back from the deck at least 6 m (20 feet) and watch the blades on 1 of the cutting decks.
2. Shut the cutting decks down and record the time it takes for the blades to come to a complete stop.

**Note:** If this time is greater than 7 seconds, the braking valve needs adjustment. Call your Toro Distributor for assistance in making this adjustment.

## Selecting a Blade

### Standard Combination Sail

This blade was designed to provide excellent lift and dispersion in almost any condition. If more or less lift and discharge velocity is required, consider a different blade.

Attributes: Excellent lift and dispersion in most conditions.

### Angled Sail

The blade generally performs best in lower heights of cut—1.9 to 6.4 cm (3/4 to 2-1/2 inches).

Attributes:

- Discharge remains more even at lower heights of cut.
- Discharge has less tendency to throw left and thus a cleaner look around bunkers and fairways.
- Lower power requirement at lower heights and dense turf.

### High-Lift Parallel Sail

The blade generally performs better in the higher heights of cut—7 to 10 cm (2 to 4 inches).

Attributes:

- More lift and higher discharge velocity.
- Sparse or limp turf is picked up significantly at higher heights of cut.
- Wet or sticky clippings are discharged more efficiently reducing congestion in the deck.
- Requires more horsepower to run.
- Tends to discharge further left and can tend to windrow at lower heights of cut.

## ⚠ WARNING

Do not use the high-lift blade with the mulching baffle. The blade could break, resulting in personal injury or death.

## Atomic Blade

This blade was designed to provide excellent leaf mulching.

Attribute: Excellent leaf mulching

the new setting. The new counterbalanced setting may change the effective height of cut.

## Understanding the Diagnostic Light

The machine is equipped with a diagnostic, light which indicates if the machine detects a malfunction. The diagnostic light is located on the InfoCenter, above the display screen (Figure 23). When the machine functions properly and the key switch is moved to the ON/RUN position, the diagnostic light turns on briefly to indicate that the light is working properly. When a machine advisory message displays, the light illuminates when the message is present. When a fault message is displayed, the light blinks until the fault is resolved.




**Figure 23**

1. Diagnostic light

## Changing the Counterbalance Settings

During different times of the mowing season or when turf conditions vary, the amount of counterbalance (upward lift) required on the cutting decks can be changed to meet the conditions.

1. Position the machine on a level surface, lower the cutting decks, turn the key in the ignition switch to the OFF position, and engage the parking brake.
2. Turn the key in the ignition switch to the RUN position.
3. In the InfoCenter Settings Menu, scroll down to Counterbalance.
4. Press the right button to select counterbalance and change between the low, medium, and high settings.

**Note:** Once the adjustment has been completed, move the machine to a test area and operate the machine with

# Choosing Accessories

## Optional Equipment Configurations

|                                                                  | Angle Sail Blade                                                                                                                                                                            | High Lift Parallel Sail Blade ( <i>Do not use with the mulching baffle</i> )                                                                      | Mulching Baffle                                                                                                                                                                                                                     | Roller Scraper                                                                                                                                                           |
|------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Grass Cutting: 1.9 to 4.4 cm (3/4 to 1-3/4 inches) height of cut | Recommended in most applications                                                                                                                                                            | May work well in light or sparse turf                                                                                                             | Has been shown to improve dispersion and after cut performance on northern grasses that are cut at least 3 times per week and less than 1/3 of the grass blade is removed. <b>Do not use with the high lift parallel sail blade</b> | Can be used any time that rollers build up with grass or large flat grass clumps of grass are seen. The scrapers may actually increase clumping in certain applications. |
| Grass Cutting: 5 to 6.4 cm (2 to 2-1/2 inches) height of cut     | Recommended for thick or lush turf                                                                                                                                                          | Recommended for light or sparse turf                                                                                                              |                                                                                                                                                                                                                                     |                                                                                                                                                                          |
| Grass Cutting: 7 to 10 cm (2-3/4 to 4 inches) height of cut      | May work well in lush turf                                                                                                                                                                  | Recommended in most applications                                                                                                                  |                                                                                                                                                                                                                                     |                                                                                                                                                                          |
| Leaf Mulching                                                    | Recommended for use with the mulching baffle                                                                                                                                                | <b>Not Allowed</b>                                                                                                                                | Use with combination sail or angle sail blade only                                                                                                                                                                                  |                                                                                                                                                                          |
| Pros                                                             | Even discharge at lower height of cut. Cleaner look around bunkers and fairways Lower power requirements                                                                                    | More lift and higher discharge velocity Sparse or limp turf is picked up at high height of cut Wet or sticky clippings are discharged efficiently | May improve dispersion and appearance in certain grass cutting applications Very good for leaf mulching                                                                                                                             | Reduces roller buildup in certain applications                                                                                                                           |
| Cons                                                             | Does not lift the grass well in high height-of-cut applications Wet or sticky grass has a tendency to build up in the chamber, leading to poor quality of cut and higher power requirements | Requires more power to run in some applications Tends to windrow at lower height of cut in lush grass Do not use with the mulching baffle         | Grass will build up in the chamber if attempting to remove too much grass with baffle in place                                                                                                                                      |                                                                                                                                                                          |

# During Operation

## During Operation Safety

### General Safety

- The owner/operator can prevent and is responsible for accidents that may cause personal injury or property damage.
- Wear appropriate clothing, including eye protection; slip-resistant, substantial foot protection; and hearing protection. Tie back long hair and do not wear jewelry.
- Do not operate the machine while ill, tired, or under the influence of alcohol or drugs.
- Never carry passengers on the machine and keep bystanders and pets away from the machine during operation.
- Operate the machine only in good visibility to avoid holes or hidden hazards.
- Avoid mowing on wet grass. Reduced traction could cause the machine to slide.
- Before you start the engine, ensure that all drives are in neutral, the parking brake is engaged, and you are in the operating position.
- Keep your hands and feet away from the cutting units. Keep clear of the discharge opening at all times.
- Look behind and down before backing up to be sure of a clear path.
- Use care when approaching blind corners, shrubs, trees, or other objects that may obscure your vision.
- Do not mow near drop-offs, ditches, or embankments. The machine could suddenly roll over if a wheel goes over the edge or if the edge gives way.
- Stop the blades whenever you are not mowing.
- Stop the machine and inspect the blades after striking an object or if there is an abnormal vibration in the machine. Make all necessary repairs before resuming operation.
- Slow down and use caution when making turns and crossing roads and sidewalks with the machine. Always yield the right-of-way.
- Disengage the drive to the cutting unit and shut off the engine before adjusting the height of cut (unless you can adjust it from the operating position).
- Never run an engine in an area where exhaust gasses are enclosed.
- Never leave a running machine unattended.
- Before leaving the operating position (including to empty the catchers or to unclog the chute), do the following:
  - Park the machine on level ground.
  - Disengage the power take-off and lower the attachments.
  - Engage the parking brake.
  - Shut off the engine and remove the key.

– Wait for all moving parts to stop.

- Do not operate the machine when there is the risk of lightning.
- Do not use the machine as a towing vehicle.
- Use accessories, attachments, and replacement parts approved by The Toro® Company only.

### Rollover Protection System (ROPS) Safety

- **Do not** remove the ROPS from the machine.
- Ensure that the seat belt is attached and that you can release it quickly in an emergency.
- Check carefully for overhead obstructions and do not contact them.
- Keep the ROPS in safe operating condition by thoroughly inspecting it periodically for damage and keeping all the mounting fasteners tight.
- Replace a damaged ROPS. Do not repair or alter it.

### Machines with a Fixed Roll Bar

- The ROPS is an integral safety device.
- Always wear your seat belt.

### Slope Safety

- Slow down the machine and use extra care on hillsides. Travel up and down on hillsides. Turf conditions can affect the stability of the machine.
- Avoid turning the machine on slopes. If you must turn the machine, turn it slowly and gradually downhill, if possible.
- Do not turn the machine sharply. Use care when reversing the machine.
- Use extra care while operating the machine with attachments; they can affect the stability of the machine.

## Starting and Shutting Off the Engine

**Important:** You must bleed the fuel system before starting the engine if you are starting the engine for the first time, the engine has stopped due to lack of fuel, or you have performed maintenance on the fuel system; refer to [Bleeding Air from the Fuel Injectors \(page 43\)](#).

### Starting the Engine

1. Sit on the seat, keep your foot off the traction pedal so that it is in NEUTRAL, engage the parking brake, set the throttle to the FAST position, and ensure that the Enable/Disable switch is in the DISABLE position.
2. Turn the key in the ignition switch to the ON/PREHEAT position.

**Note:** An automatic timer controls the glow plug preheat for 6 seconds.

3. After preheating the glow plugs, turn the key in the ignition switch to the START position.
4. Crank the engine for no longer than 15 seconds. Release the key when the engine starts.
5. If additional preheating is required, turn the key in the ignition switch to the OFF position and then to the ON/PREHEAT position. Repeat this process as required.
6. Run the engine at low idle speed until it warms up.

## Shutting Off the Engine

1. Move all controls to NEUTRAL, engage the parking brake, move the throttle to the LOW IDLE position, and allow the engine to reach low-idle speed.

**Important:** Allow the engine to idle for 5 minutes before shutting it off after a full load operation. Failure to do so may lead to trouble on a turbo-charged engine.

2. Turn the key in the ignition switch to the OFF position and remove the key.

## Operating Tips

### Becoming Familiarized with the Machine

Before mowing grass, practice operating the machine in an open area. Start and shut off the engine. Operate in forward and reverse. Lower and raise the cutting decks and engage and disengage the mowers. When you feel familiar with the machine, practice operating up and down slopes at different speeds.

### Mowing

Turn the key in the ignition switch to the ON position, start the engine, and move the throttle to the FAST position. Move the Enable/Disable switch to the ENABLE position and use the Lower Mow/Raise lever to control the cutting decks. To move forward and cut grass, press the traction pedal forward.

**Note:** Allow the engine to idle for 5 minutes before shutting it off after a full load operation. Failure to do so may lead to turbo-charger trouble.

### Mowing when the Grass Is Dry

Mow either in the late morning to avoid the dew, which causes grass clumping, or in late afternoon to avoid the damage that may be caused by direct sunlight on the sensitive, freshly mowed grass.

## Selecting the Proper Height-of-Cut Setting to Suit Conditions

Remove approximately 1 inch or no more than 1/3 of the grass blade when cutting. In exceptionally lush and dense grass you may have to raise the height-of-cut setting.

## Mowing with Sharp Blades

A sharp blade cuts cleanly and without tearing or shredding the grass blades like a dull blade. Tearing and shredding causes the grass to turn brown at the edges which impairs growth and increases susceptibility to diseases. Always make sure that the blade is in good condition and a full sail is present.

## Checking the Condition of the Decks

Make sure that the cutting chambers are in good condition. Straighten any bends in the chamber components to ensure that the correct blade tip/chamber clearance.

## Checking the Mower Housing After Operating

To ensure that optimum performance is met, clean the underside of mower housing. If you allow residue to build up in mower housing, cutting performance will decrease.

## Transporting the Machine

Move the Enable/Disable switch to the Disable position and raise the cutting decks to the transport position. Move the Mow/Transport lever to the transport position. Be careful when driving between objects so you do not accidentally damage the machine or cutting decks. Use extra care when operating the machine on slopes. Drive slowly and avoid sharp turns on slopes to prevent rollovers. Lower the cutting decks when going downhill for steering control.

# After Operation

## After Operation Safety

- Clean grass and debris from the cutting units, mufflers, and engine compartment to help prevent fires. Clean up oil or fuel spills.
- If the cutting units are in the transport position, use the positive mechanical lock (if available) before you leave the machine unattended.
- Allow the engine to cool before storing the machine in any enclosure.
- Shut off the fuel before storing or transporting the machine.
- Never store the machine or fuel container where there is an open flame, spark, or pilot light, such as on a water heater or on other appliances.
- Keep all parts of the machine in good working condition and all hardware tightened, especially blade-attachment hardware.
- Replace all worn or damaged decals.

## Identifying the Tie-Down Points

- **Front of the machine**—the hole in the rectangular pad, under the axle tube, inside each front tire (Figure 24).




Figure 24

1. Front tie-down

- **Rear of the machine**—each side of the machine on the rear frame (Figure 25).




Figure 25

1. Rear tie-down

# Pushing or Towing the Machine

In an emergency, the machine can be moved by actuating the bypass valve in the variable displacement hydraulic pump and pushing or towing the machine.

**Important:** Do not push or tow the machine faster than 3 to 4.8 km/h (2 to 3 mph) because internal transmission damage may occur. The bypass valve must be open whenever the machine is pushed or towed.

1. The bypass valve is located on the left side of the hydrostat (Figure 26). Rotate the bolt 1-1/2 turns to open and allow the oil to bypass internally. Because fluid is bypassed, the machine can be moved slowly without damaging the transmission.




Figure 26

1. Bypass valve

- 
2. Close the bypass valve before starting the engine. However, do not exceed 7 to 11 N·m (5 to 8 ft-lb) torque to close the valve.

**Important:** Running the engine with the bypass valve open will cause the transmission to overheat.

## Hauling the Machine

- Use care when loading or unloading the machine into a trailer or a truck.
- Use full-width ramps for loading the machine into a trailer or a truck.
- Tie the machine down securely using straps, chains, cable, or ropes. Both front and rear straps should be directed down and outward from the machine.

# Maintenance

**Note:** Determine the left and right sides of the machine from the normal operating position.

## Recommended Maintenance Schedule(s)

| Maintenance Service Interval | Maintenance Procedure                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| After the first hour         | <ul style="list-style-type: none"> <li>Torque the wheel-lug nuts to 94 to 122 N·m (70 to 90 ft-lb).</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| After the first 8 hours      | <ul style="list-style-type: none"> <li>Check the condition and tension of the alternator belt.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| After the first 10 hours     | <ul style="list-style-type: none"> <li>Torque the wheel-lug nuts to 94 to 122 N·m (70 to 90 ft-lb).</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| After the first 50 hours     | <ul style="list-style-type: none"> <li>Change the engine oil and filter.</li> <li>Check the engine rpm (idle and full throttle).</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| Before each use or daily     | <ul style="list-style-type: none"> <li>Check the tire pressure.</li> <li>Check the operation of the safety-interlock switches.</li> <li>Check the blade stopping time.</li> <li>Check the engine-oil level.</li> <li>Check the level of coolant in the expansion tank and clean debris off the screen, oil cooler, and front of the radiator.</li> <li>Remove debris from the screen, oil coolers, and radiator (more frequently in dirty operating conditions).</li> <li>Check the hydraulic fluid level.</li> <li>Check the hydraulic lines and hoses for leaks, kinked lines, loose mounting supports, wear, loose fittings, weather deterioration, and chemical deterioration.</li> </ul> |
| Every 50 hours               | <ul style="list-style-type: none"> <li>Grease the bearings and bushings. (Grease them immediately after every washing regardless of the interval listed.)</li> <li>Check the condition of and clean the battery.</li> <li>Check the battery cable connections.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                     |
| Every 100 hours              | <ul style="list-style-type: none"> <li>Inspect the cooling-system hoses.</li> <li>Check the condition and tension of the alternator belt.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| Every 150 hours              | <ul style="list-style-type: none"> <li>Change the engine oil and filter.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| Every 200 hours              | <ul style="list-style-type: none"> <li>Drain moisture from the fuel and hydraulic fluid tanks.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| Every 250 hours              | <ul style="list-style-type: none"> <li>Torque the wheel-lug nuts to 94 to 122 N·m (70 to 90 ft-lb).</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| Every 400 hours              | <ul style="list-style-type: none"> <li>Service the air cleaner. (Or earlier if the air-cleaner indicator illuminates red. Service it more frequently in extremely dirty or dusty conditions.)</li> <li>Check the fuel lines and connections for deterioration, damage, or loose connections (or yearly, whichever comes first).</li> <li>Replace the fuel filter canister.</li> <li>Check the engine rpm (idle and full throttle).</li> </ul>                                                                                                                                                                                                                                                 |
| Every 800 hours              | <ul style="list-style-type: none"> <li>Drain and clean the fuel tank.</li> <li>Check the rear wheel toe-in.</li> <li>Change the hydraulic fluid.</li> <li>Change the hydraulic filters (sooner if the service interval indicator is in the red zone).</li> <li>Adjust the engine valves (refer to the engine operator's manual).</li> </ul>                                                                                                                                                                                                                                                                                                                                                   |
| Before storage               | <ul style="list-style-type: none"> <li>Drain and clean the fuel tank.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| Every 2 years                | <ul style="list-style-type: none"> <li>Flush and replace the cooling-system fluid.</li> <li>Drain and flush the hydraulic tank.</li> <li>Replace all moving hoses.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |

Refer to your engine operator's manual for additional maintenance procedures.

# Daily Maintenance Checklist

Duplicate this page for routine use.

| Maintenance Check Item                                                                                                                                                                                                                                   | For the week of: |       |      |        |      |      |      |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------|-------|------|--------|------|------|------|
|                                                                                                                                                                                                                                                          | Mon.             | Tues. | Wed. | Thurs. | Fri. | Sat. | Sun. |
| Check the safety-interlock operation.                                                                                                                                                                                                                    |                  |       |      |        |      |      |      |
| Check the brake operation.                                                                                                                                                                                                                               |                  |       |      |        |      |      |      |
| Check the engine oil and fuel level.                                                                                                                                                                                                                     |                  |       |      |        |      |      |      |
| Drain the water/fuel separator.                                                                                                                                                                                                                          |                  |       |      |        |      |      |      |
| Check the air-filter-restriction indicator.                                                                                                                                                                                                              |                  |       |      |        |      |      |      |
| Check the radiator and screen for debris.                                                                                                                                                                                                                |                  |       |      |        |      |      |      |
| Check unusual engine noises. <sup>1</sup>                                                                                                                                                                                                                |                  |       |      |        |      |      |      |
| Check unusual operating noises.                                                                                                                                                                                                                          |                  |       |      |        |      |      |      |
| Check the hydraulic system fluid level.                                                                                                                                                                                                                  |                  |       |      |        |      |      |      |
| Check the hydraulic-filter indicator. <sup>2</sup>                                                                                                                                                                                                       |                  |       |      |        |      |      |      |
| Check hydraulic hoses for damage.                                                                                                                                                                                                                        |                  |       |      |        |      |      |      |
| Check for fluid leaks.                                                                                                                                                                                                                                   |                  |       |      |        |      |      |      |
| Check the tire pressure.                                                                                                                                                                                                                                 |                  |       |      |        |      |      |      |
| Check the instrument operation.                                                                                                                                                                                                                          |                  |       |      |        |      |      |      |
| Check the height-of-cut adjustment                                                                                                                                                                                                                       |                  |       |      |        |      |      |      |
| Check the condition of the blades                                                                                                                                                                                                                        |                  |       |      |        |      |      |      |
| Check all grease fittings for lubrication <sup>3</sup>                                                                                                                                                                                                   |                  |       |      |        |      |      |      |
| Touch-up damaged paint.                                                                                                                                                                                                                                  |                  |       |      |        |      |      |      |
| 1. Check the glow plug and injector nozzles if hard starting, excess smoke, or rough running is noted.<br>2. Check with the engine running and the oil at operating temperature<br>3. Immediately after every washing, regardless of the interval listed |                  |       |      |        |      |      |      |

## Notation for Areas of Concern

| Inspection performed by: |      |             |
|--------------------------|------|-------------|
| Item                     | Date | Information |
| 1                        |      |             |
| 2                        |      |             |
| 3                        |      |             |
| 4                        |      |             |
| 5                        |      |             |
| 6                        |      |             |
| 7                        |      |             |
| 8                        |      |             |

**Important:** Refer to your engine owner's manual for additional maintenance procedures.

**Note:** Download a free copy of the electrical or hydraulic schematic by visiting [www.Toro.com](http://www.Toro.com) and searching for your machine from the Manuals link on the home page.

# Service-Interval Chart




Figure 27

decal125-8753

## Pre-Maintenance Procedures

### Pre-Maintenance Safety


- Before adjusting, cleaning, repairing, or leaving the machine, do the following:
  - Park the machine on a level surface.
  - Move the throttle switch to the low-idle position.
  - Disengage the cutting units.
  - Lower the cutting units.
  - Ensure that the traction is in neutral.
  - Engage the parking brake.
  - Shut off the engine and remove the key.
  - Wait for all moving parts to stop.
  - Allow machine components to cool before performing maintenance.
- If the cutting units are in the transport position, use the positive mechanical lock (if available) before you leave the machine unattended.
- If possible, do not perform maintenance while the engine is running. Keep away from moving parts.
- Use jack stands to support the machine or components when required.
- Carefully release pressure from components with stored energy.

## Raising the Machine

**Note:** Use jack stands to support the machine when required.

Use the following as points to jack up the machine:

- Front of the machine**—rectangular pad, under the axle tube, inside each front tire (Figure 28).



G031850

g031850

Figure 28

1. Front jacking point

- Rear of the machine**—rectangular axle tube on the rear axle.

# Lubrication

## Greasing the Bearings and Bushings

If you operate the machine under normal conditions, lubricate all grease fittings for the bearings and bushings after **every 50 hours of operation** with No. 2 lithium grease. Lubricate bearings and bushings **immediately** after every washing, regardless of the interval listed.

The grease fitting locations and quantities are as follows:

- Pump driveshaft U-joint (3)—[Figure 29](#)




Figure 29

- Cutting unit lift-arm cylinders (2 each)—[Figure 30](#)




Figure 30

- Lift-arm pivots (1 each)—[Figure 30](#)

- Cutting unit carrier-frame pivot (1 each)—[Figure 31](#)




Figure 31

- Lift-arm pivot shaft (1 each)—[Figure 32](#)




Figure 32

- Rear axle tie rod (2)—[Figure 33](#)






Figure 33


- Axle-steering pivot (1)—[Figure 34](#)



- Steering-cylinder ball joints (2) and rear axle (1)—[Figure 35](#)




- Brake pedal (1)—[Figure 36](#)




- Cutting unit spindle-shaft bearings (2 per cutting unit)—[Figure 37](#)

**Note:** You can use either fitting, whichever is more accessible. Pump grease into the fitting until a small amount appears at bottom of the spindle housing (under the deck).



- Rear-roller bearings (2 per cutting unit)—[Figure 38](#)




**Note:** Make sure that the grease groove in each roller mount aligns with the grease hole in each end of the roller shaft. To help align the groove and hole, there is also an alignment mark on 1 end of the roller shaft.

# Engine Maintenance

## Engine Safety

- Shut off the engine before checking the oil or adding oil to the crankcase.
- Do not change the governor speed or overspeed the engine.




g194209

## Servicing the Air Cleaner

Check the whole intake system for leaks, damage, or loose hose clamps. Do not use a damaged air filter.

Service the air-cleaner filter only when the service indicator requires it. Changing the air filter before it is necessary only increases the chance of dirt entering the engine when the filter is removed.

**Important:** Make sure that the cover is seated correctly, seals with the air-cleaner body, and the rubber outlet valve is in a downward position—between the 5 o'clock and 7 o'clock positions when viewed from the end.



G031351

g031351

Figure 39

# Servicing the Engine Oil

## Checking the Engine-Oil Level

**Service Interval:** Before each use or daily

The engine is shipped with oil in the crankcase; however, the oil level must be checked before and after the engine is first started.

Crankcase capacity is approximately 5.2 L (5.5 US qt) with the filter.

Use high-quality engine oil that meets the following specifications:

- **API Classification Level Required:** CH-4, CI-4 or higher
- **Preferred oil:** SAE 15W-40 (above -17.8°C (0°F))
- **Alternate oil:** SAE 10W-30 or 5W-30 (all temperatures)

Toro Premium Engine oil is available from your distributor in either 15W-40 or 10W-30 viscosity.

1. Park the machine on a level surface, shut off the engine, engage the parking brake, and remove the key from the ignition switch.
2. Check the engine-oil level ([Figure 40](#)).





**Figure 40**

**Important:** Be sure to keep the engine-oil level between the upper and lower limits on the oil gauge. Engine failure may occur as a result of over filling or under filling the engine oil.

## Changing the Engine Oil and Filter



g194203

## Fuel System Maintenance

### Servicing the Fuel System

#### Draining the Fuel Tank


**Service Interval:** Every 800 hours

Before storage

Drain and clean the fuel tank if the fuel system becomes contaminated or if the machine is to be stored for an extended period. Use clean fuel to flush out the tank.

#### Checking the Fuel Lines and Connections

Inspect them for deterioration, damage, or loose connections.



G031853

g031853


Figure 41

**Important:** Do not overtighten the filter.


Add oil to the crankcase; refer to [Servicing the Engine Oil \(page 41\)](#).

# Servicing the Water Separator

Service Interval: Every 400 hours



g194210



G031412

g031412

Figure 42


# Servicing the Fuel-Pickup Tube

The fuel-pickup tube, located inside the fuel tank, is equipped with a screen to help prevent debris from entering the fuel system. Remove the fuel-pickup tube and clean screen as required.

## Bleeding Air from the Fuel Injectors

**Note:** This procedure should be used only if the fuel system has been purged of air through normal priming procedures and the engine does not start; refer to [Bleeding the Fuel System](#) (page 27).

1. Loosen the pipe connection to the No. 1 nozzle and holder assembly ([Figure 43](#)).



G031685

g031685

Figure 43

1. Fuel injectors
2. Turn the key in the ignition switch to the ON position and watch the fuel flow around the connector.
3. When you observe a solid flow of fuel, turn the key in the ignition switch to the OFF position.
4. Tighten the pipe connector securely.
5. Repeat steps 1 through 4 on the remaining nozzles.

# Electrical System Maintenance

## Electrical System Safety

- Disconnect the battery before repairing the machine. Disconnect the negative terminal first and the positive last. Connect the positive terminal first and the negative last.
- Charge the battery in an open, well-ventilated area, away from sparks and flames. Unplug the charger before connecting or disconnecting the battery. Wear protective clothing and use insulated tools.

**WARNING**

**CALIFORNIA**  
**Proposition 65 Warning**

Battery posts, terminals, and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and reproductive harm. Wash hands after handling.

## Servicing the Battery

**Note:** To clean the battery, wash the entire case with a solution of baking soda and water. Rinse it with clear water.

## Replacing the Fuses

There are 8 fuses in the Electrical System. The fuse block (Figure 44) is located behind the control-arm access panel.




**Figure 44**

1. Fuse block




**Figure 45**

# Charging the Battery

## ⚠ WARNING

Charging the battery produces gasses that can explode.

Do not smoke near the battery, and keep sparks and flames away from the battery.

**Important:** Keep the battery fully charged. This is especially important to prevent battery damage when the temperature is below 0°C (32°F).

1. Clean the exterior of the battery case and the battery posts.

**Note:** Connect the leads of the battery charger to battery posts before connecting the charger to the electrical source.

2. Look at the battery and identify the positive and negative battery posts.
3. Connect the positive lead of the battery charger to the positive battery post (Figure 46).




Figure 46

- |                          |                           |
|--------------------------|---------------------------|
| 1. Positive battery post | 3. Red (+) charger lead   |
| 2. Negative battery post | 4. Black (-) charger lead |

4. Connect the negative lead of the battery charger to the negative-battery post (Figure 46).
5. Connect the battery charger to the electrical source, and charge the battery.

**Important:** Do not overcharge the battery.

6. When the battery is fully charged, unplug the charger from the electrical source, then disconnect the charger leads from the battery posts (Figure 46).

# Drive System Maintenance

## Adjusting the Traction Drive for Neutral

The machine must not creep when the traction pedal is released. If it does creep, adjust as follows:

1. Park the machine on a level surface, shut off the engine, and lower the cutting decks to the ground.
2. Jack up the machine until all the tires are off the ground. Support the machine with jack stands to prevent it from falling accidentally.
3. On the right side of the hydrostat, loosen the locknut on the traction adjustment cam (Figure 47).




Figure 47

- |            |                            |
|------------|----------------------------|
| 1. Locknut | 2. Traction-adjustment cam |
|------------|----------------------------|

## ⚠ WARNING

The engine must be running so the final adjustment of the traction adjustment cam can be performed. This could cause personal injury.

Keep your hands, feet, face, and other body parts away from the muffler, other hot parts of the engine, and any rotating parts.

4. Turn the key in the ignition switch to the ON position, start the engine, and rotate the cam hex in either direction until the wheels cease rotation.
5. Tighten the locknut to secure the adjustment.

6. Turn the key in the ignition switch to the OFF position, remove the jack stands, and lower the machine to the ground.
7. Test drive the machine to make sure that it does not creep.

## Adjusting the Rear Wheel Toe-in

1. Rotate the steering wheel so that the rear wheels are straight ahead.
2. Loosen the jam nut on each end of the tie rod (Figure 48).

**Note:** The end of the tie rod with the external groove is a left thread.




Figure 48

1. Wrench slot
2. Tie rod
3. Jam nut

3. Using the wrench slot, rotate the tie rod.
4. Measure the distance at the front and rear of the rear wheels at axle height.

**Note:** The distance at the front of the rear wheels should be less than 6 mm (1/4 inch) of the distance measured at the rear of the wheels.

5. Repeat procedure as required.

# Cooling System Maintenance

## Cooling System Safety

- Swallowing engine coolant can cause poisoning; keep out of reach from children and pets.
- Discharge of hot, pressurized coolant or touching a hot radiator and surrounding parts can cause severe burns.
  - Always allow the engine to cool at least 15 minutes before removing the radiator cap.
  - Use a rag when opening the radiator cap, and open the cap slowly to allow steam to escape.

## Checking the Cooling System

**Service Interval:** Before each use or daily—Check the level of coolant in the expansion tank and clean debris off the screen, oil cooler, and front of the radiator.

The cooling system is filled with a 50/50 solution of water and permanent ethylene glycol antifreeze. The capacity of the cooling system is 9.5 L (10 US qt).

### ⚠ CAUTION

If the engine has been running, the pressurized, hot coolant can escape and cause burns.

- Do not open the radiator cap when the engine is running.
- Use a rag when opening the radiator cap, and open the cap slowly to allow steam to escape.

1. Check the level of coolant in the expansion tank (Figure 49).

**Note:** The coolant level should be between the marks on the side of the tank.




**Figure 49**

1. Expansion tank
- 
2. If the coolant level is low, remove the expansion-tank cap and replenish the system. **Do not overfill.**
  3. Install the expansion-tank cap.

## Removing Debris from the Cooling System

1. Turn the key in the ignition switch to the OFF position and remove the key.
2. Thoroughly clean all debris out of the engine area.
3. Unlatch the clamp and pivot open the rear screen ([Figure 50](#)).




**Figure 50**

1. Rear-screen latch
  2. Rear screen
- 

4. Clean the screen thoroughly with compressed air.
5. Pivot the latches inward to release the oil cooler ([Figure 51](#)).




**Figure 51**

1. Oil-cooler latches
  2. Oil cooler
-

6. Thoroughly clean both sides of the oil cooler and the radiator (Figure 52) with compressed air.




**Figure 52**

1. Radiator

7. Pivot the oil cooler back into position and secure the latches.
8. Close the screen and secure the latch.

## Brake Maintenance

### Adjusting the Parking Brakes

Adjust the brakes when there is more than 2.5 cm (1 inch) of free travel (Figure 53) of the brake pedal, or when more holding force is required. Free travel is the distance the brake pedal moves before you feel braking resistance.




**Figure 53**

1. Free travel

**Note:** Use the wheel motor backlash to rock the drums back and forth to ensure that the drums are free prior to and after adjustment.

1. To reduce free travel of the brake pedals, tighten the brakes by loosening the front nut on the threaded end of the brake cable (Figure 54).




**Figure 54**

1. Brake cables
2. Front nuts

2. Tighten the rear nut to move the cable backward until brake pedals have 6.3 to 12.7 mm (1/4 to 1/2 inch) of free travel (Figure 53), before wheel lock up is achieved.
3. Tighten the front nuts, ensuring that both cables actuate the brakes simultaneously. Ensure that the cable conduit does not rotate during tightening procedure.

# Adjusting the Parking-Brake Latch

If the parking brake fails to engage and latch, an adjustment to the brake pawl is required.

1. Loosen the 2 screws securing the parking brake pawl to the frame (Figure 55).




Figure 55

- |                 |                       |
|-----------------|-----------------------|
| 1. Brake cables | 3. Parking brake pawl |
| 2. Brake detent | 4. Screws (2)         |
- 
2. Press the parking brake pedal forward until the brake detent completely engages on the brake pawl (Figure 55).
  3. Tighten the 2 screws locking the adjustment.
  4. Press the brake pedal to disengage the parking brake.
  5. Check the adjustment and adjust as required.

# Belt Maintenance

## Tensioning the Alternator Belt

1. Open the hood.
2. Check the tension of the alternator belt by depressing it (Figure 56) midway between the alternator and the crankshaft pulleys with 10 kg (22 lb) of force.




Figure 56

- |                    |               |
|--------------------|---------------|
| 1. Brace           | 3. Pivot bolt |
| 2. Alternator belt |               |

**Note:** The belt should deflect 11 mm (0.04 inch).

3. If the deflection is incorrect, proceed to step 4. If correct, continue operation.
4. Loosen the bolt securing the brace to the engine (Figure 56), the bolt securing the alternator to the brace and the pivot bolt.
5. Insert a pry bar between the alternator and the engine and pry out on the alternator.
6. When you achieve the proper tension, tighten the alternator, brace, and pivot bolts to secure the adjustment.

# Hydraulic System Maintenance

## Hydraulic System Safety

- Ensure that all hydraulic-fluid hoses and lines are in good condition and all hydraulic connections and fittings are tight before applying pressure to the hydraulic system.
- Keep your body and hands away from pinhole leaks or nozzles that eject high-pressure hydraulic fluid.
- Use cardboard or paper to find hydraulic leaks.
- Safely relieve all pressure in the hydraulic system before performing any work on the hydraulic system.
- Seek immediate medical attention if fluid is injected into skin. Injected fluid must be surgically removed within a few hours by a doctor.

## Checking the Hydraulic-Fluid Level

**Service Interval:** Before each use or daily

The machine's reservoir is filled at the factory with approximately 56.7 L (15 US gallons) of high quality hydraulic fluid. The recommended replacement fluid is as follows:

**Toro Premium All Season Hydraulic Fluid**(Available in 18.9 L (5 US gallon) pails or 208 L (55 US gallon) drums. See the *Parts Catalog* or your Toro Distributor for part numbers.)

**Alternate fluids:** If the Toro fluid is not available, other fluids may be used provided they meet all the following material properties and industry specifications. We do not recommend the use of synthetic fluid. Consult with your lubricant distributor to identify a satisfactory product.

**Note:** Use products only from reputable manufacturers. Toro does not take responsibility for damage caused by improper substitutions.

### High Viscosity Index/Low Pour Point Anti-wear Hydraulic Fluid, ISO VG 46

Material Properties:

|                            |                                              |
|----------------------------|----------------------------------------------|
| Viscosity, ASTM D445       | cSt @ 40°C 44 to 48cSt<br>@ 100°C 7.9 to 8.5 |
| Viscosity Index ASTM D2270 | 140 to 160                                   |
| Pour Point, ASTM D97       | -34°F to -49°F                               |

Industry Specifications:

Vickers I-286-S (Quality Level), Vickers M-2950-S (Quality Level), Denison HF-0

temperature conditions. For operation in consistently high ambient temperatures, 18°C (65°F) to 49°C (120°F), ISO VG 68 hydraulic fluid may offer improved performance.


Premium Biodegradable Hydraulic Fluid-Mobil EAL EnviroSyn 46H

**Important:** Mobil EAL EnviroSyn 46H is the only synthetic biodegradable fluid approved by Toro. This fluid is compatible with the elastomers used in Toro hydraulic systems and is suitable for a wide-range of temperature conditions. This fluid is compatible with conventional mineral oils, but for maximum biodegradability and performance the hydraulic system should be thoroughly flushed of conventional fluid. The oil is available in 19 L (5 US gallons) containers or 208 L (55 US gallons) drums from your Mobil Distributor.

**Note:** Many hydraulic fluids are almost colorless, making it difficult to spot leaks. A red dye additive for the hydraulic system oil is available in 20 ml (2/3 oz) bottles. 1 bottle is sufficient for 15 to 23 L (4 to 6 US gallons) of hydraulic oil. Order Part No. 44-2500 from your Toro Distributor.

1. Position the machine on a level surface, lower the cutting decks, and turn the key in the ignition switch to the OFF position.
2. Check the hydraulic-fluid level ([Figure 57](#)).

**Important:** The ISO VG 46 Multigrade fluid has been found to offer optimal performance in a wide-range of



g194205




Figure 57

# Changing the Hydraulic Fluid

**Service Interval:** Every 800 hours

If fluid becomes contaminated, contact your Toro Distributor because the system must be flushed. Contaminated fluid looks milky or black when compared to clean oil.

1. Turn the key in the ignition switch to the OFF position and raise the hood.
2. Place a large drain pan under the fitting secured to the bottom of the hydraulic-fluid reservoir (Figure 58).




Figure 58

1. Hose

3. Disconnect the hose from the bottom of the fitting and let the hydraulic fluid flow into the drain pan.
4. Install the hose when hydraulic fluid stops draining.
5. Fill the reservoir with approximately 56.7 L (15 US gallons) of hydraulic fluid; refer to [Changing the Hydraulic Fluid](#) (page 51).

**Important:** Use only hydraulic fluids specified. Other fluids could cause system damage.

6. Install the reservoir cap.
7. Turn the key in the ignition switch to the ON position, start the engine, use all of the hydraulic controls to distribute hydraulic fluid throughout the system, and check for leaks.
8. Turn the key in the ignition switch to the OFF position.
9. Check the level of the hydraulic fluid and add enough to raise level to the Full mark on the dipstick.

**Important:** Do not overfill.

# Replacing the Hydraulic Filters

The hydraulic system is equipped with a service-interval indicator (Figure 59). With the engine running, view the indicator, it should be in the green zone. When the indicator is in the red zone, change the hydraulic filters.




**Figure 59**

1. Hydraulic-filter restriction indicator

**Important:** Use of any other filters may void the warranty on some components.

1. Position the machine on a level surface, lower the cutting decks, turn the key in the ignition switch to the OFF position, engage the parking brake, and remove the key.
2. Replace both of the hydraulic filters (Figure 60).




**Figure 60**

3. Turn the key in the ignition switch to the ON position, start the engine, and let it run for about 2 minutes to purge air from the system.
4. Turn the key in the ignition switch to the OFF position and check for leaks.

# Checking the Hydraulic Lines and Hoses

**Service Interval:** Before each use or daily

Make all necessary repairs before operating.

## ⚠ WARNING

Hydraulic fluid escaping under pressure can penetrate skin and cause injury.

- Make sure that all hydraulic-fluid hoses and lines are in good condition and all hydraulic connections and fittings are tight before applying pressure to the hydraulic system.
- Keep your body and hands away from pinhole leaks or nozzles that eject high-pressure hydraulic fluid.
- Use cardboard or paper to find hydraulic leaks.
- Safely relieve all pressure in the hydraulic system before performing any work on the hydraulic system.
- Get immediate medical help if fluid is injected into skin.

# Testing the Pressure in the Hydraulic System

Use the hydraulic system test ports to test the pressure in the hydraulic circuits. Contact your Toro Distributor for assistance.

# Hydraulic Valve Solenoid Functions

Use the list below to identify and describe the different functions of the solenoids in the hydraulic manifold. Each solenoid must be energized to allow function to occur.

| Solenoid | Function                 |
|----------|--------------------------|
| PRV2     | Front mower circuit      |
| PRV1     | Rear mower circuit       |
| PRV      | Lift/lower cutting decks |
| S1       | Lower cutting decks      |
| S2       | Lower cutting decks      |

# Cutting Deck Maintenance

## Separating the Cutting Decks from the Traction Unit

1. Position the machine on a level surface, lower the cutting decks to the floor, turn the key in the ignition switch to the OFF position, and engage the parking brake.
2. Disconnect and remove the hydraulic motor from the deck (Figure 61). Cover the top of the spindle to prevent contamination.




Figure 61

1. Motor-mounting screws

3. Remove the lynch pin securing the deck-carrier frame to the lift-arm pivot pin (Figure 62).




Figure 62

1. Lynch pin
2. Lift-arm pivot pin

4. Roll the cutting deck away from the traction unit.

## Mounting the Cutting Decks to the Traction Unit

1. Position the machine on a level surface and turn the key in the ignition switch to the OFF position.
2. Move the cutting deck into position in front of the traction unit.
3. Slide the deck-carrier frame onto the lift-arm pivot pin and secure it with the lynch pin (Figure 62).
4. Install the hydraulic motor to the deck (Figure 61). Make sure that the O-ring is in position and not damaged.
5. Grease the spindle.

## Blade Maintenance

### Blade Safety

#### **⚠ DANGER**

**A worn or damaged blade can break, and a piece of the blade could be thrown at you or bystanders, resulting in serious personal injury or death. Trying to repair a damaged blade may result in discontinued safety certification of the product.**

- **Inspect the blade periodically for wear or damage.**
- **Never try to straighten a blade that is bent or weld a broken or cracked blade.**
- **Replace a worn or damaged blade.**
- Use care when checking the blades. Wrap the blades or wear gloves, and use caution when servicing the blades. Only replace the blades; never straighten or weld them.
- On multi-bladed machines, take care as rotating 1 blade can cause other blades to rotate.

### Servicing the Blade Plane

The rotary deck comes from the factory preset at 5 cm (2 inches) height of cut and blade rake of 7.9 mm (0.310 inch). The left and right heights are also preset to within  $\pm 0.7$  mm (0.030 inch) of the other.

The cutting deck is designed to withstand blade impacts without deformation of the chamber. If a solid object is struck, inspect the blade for damage and the blade plane for accuracy.

### Inspecting the Blade Plane

1. Remove the hydraulic motor from the cutting deck and remove the cutting deck from the tractor.
2. Use a hoist (or minimum of 2 people) and place the cutting deck on a flat table.
3. Mark 1 end of the blade with a paint pen or marker. Use this end of the blade to check all heights.
4. Position the cutting edge of the marked end of the blade at 12 o'clock (straight ahead in the direction of mowing) (Figure 63) and measure height from table to cutting edge of blade.




**Figure 63**

g011353

5. Rotate the marked end of the blade to the 3 and 9 o'clock positions ([Figure 63](#)) and measure the heights.
6. Compare the 12 o'clock measured height to the height-of-cut setting. It should be within 0.7 mm (0.030 inch). The 3 and 9 o'clock heights should be 1.6 to 6.0 mm (0.06 to 0.24 inch) higher than the 12 o'clock setting and within 1.6 to 6.0 mm (0.06 to 0.24 inch) of each other.

**Note:** If any of these measurements are not within specification, proceed to [Adjusting the Blade Plane \(page 55\)](#).

## Adjusting the Blade Plane

Start with the front adjustment (change 1 bracket at a time).

1. Remove the height-of-cut bracket (front, left, or right) from the deck frame ([Figure 64](#)).
2. Adjust 1.5 mm (0.060 inch) shims and/or 0.7 mm (0.030 inch) shim between the deck frame and bracket to achieve the desired height setting ([Figure 64](#)).




**Figure 64**

g031692

1. Height-of-cut bracket
2. Shims

3. Install the height-of-cut bracket to the deck frame with the remaining shims assembled below the height-of-cut bracket.
4. Secure the socket-head bolt/spacer and flange nut.

**Note:** Socket-head bolt/spacer are held together with thread-locking adhesive to prevent the spacer from falling inside the deck frame.

5. Verify the 12 o'clock height and adjust if needed.
6. Determine if only 1 or both (right and left) height-of-cut brackets need to be adjusted. If the 3 or 9 o'clock side is 1.6 to 6.0 mm (0.06 to 0.24 inch) higher than the new front height then no adjustment is needed for that side. Adjust the other side to within 1.6 to 6.0 mm (0.06 to 0.24 inch) of the correct side.
7. Adjust the right and/or left height-of-cut brackets by repeating steps 1 through 3.
8. Secure the carriage bolts and flange nuts.
9. Again, verify the 12, 3, and 9 o'clock heights.

## Removing and Installing a Blade

Replace the blade if a solid object is hit, the blade is out of balance, or if the blade is bent. Always use genuine Toro replacement blades to be sure of safety and optimum performance. Never use replacement blades made by other manufacturers because they could be dangerous.

1. Raise the cutting deck to the highest position, turn the key in the ignition switch to the OFF position, and engage the parking brake. Block the cutting deck to prevent it from falling accidentally.
2. Grasp the end of the blade using a rag or thickly padded glove. Remove the blade bolt, anti-scalp cup, and blade from the spindle shaft ([Figure 65](#)).




**Figure 65**

G011355

g011355

1. Blade bolt
2. Anti-scalp cup

3. Install the blade, sail facing toward the cutting deck, with the anti-scalp cup and blade bolt ([Figure 65](#)).

Tighten the blade bolt to 115 to 149 N·m (85 to 110 ft-lb).

## Inspecting and Sharpening the Blade

1. Raise the cutting deck to the highest position, turn the key in the ignition switch to the OFF position, and engage the parking brake.
2. Block the cutting deck to prevent it from falling accidentally.
3. Examine the cutting ends of the blade carefully, especially where the flat and curved parts of the blade meet (Figure 66).

**Note:** Since sand and abrasive material can wear away the metal that connects the flat and curved parts of the blade, check the blade before using the machine.

4. If wear is noticed (Figure 66), replace the blade; refer to [Servicing the Blade Plane](#) (page 54).

### ⚠ DANGER

If the blade is allowed to wear, a slot will form between the sail and flat part of the blade (Figure 65). Eventually a piece of the blade may break off and be thrown from under the housing, possibly resulting in serious injury to yourself or bystanders.

- Inspect the blade periodically for wear or damage.
- Always replace a worn or damaged blade.




Figure 66

1. Cutting edge
2. Sail
3. Wear/slot/crack

**Note:** The blade will remain balanced if the same amount of metal is removed from both cutting edges.




Figure 67

1. Sharpen at this angle only

7. To check the blade for being straight and parallel, lay the blade on a level surface and check its ends.

**Note:** Position the ends of the blade slightly lower than the center, and the cutting edge lower than the heel of the blade. This blade produces a good quality of cut and requires minimal power from the engine. By contrast a blade that is higher at the ends than the center, or if cutting edge is higher than the heel, the blade is bent or warped and must be replaced.

8. Install the blade, sail facing toward cutting deck, with the anti-scalp cup and blade bolt. Torque the blade bolt to 115 to 149 N·m (85 to 110 ft-lb).

5. Inspect the cutting edges of all blades. Sharpen the cutting edges if they are dull or nicked. Sharpen only the top of the cutting edge and maintain the original cutting angle to make sure that it is sharp (Figure 67).
6. If dull or nicked, sharpen only the top cutting edge while maintaining the original cutting angle (Figure 67).

# Miscellaneous Maintenance

## Servicing the Front Roller

Inspect the front roller for wear, excess wobble, or binding. Service or replace the roller or components if any of these conditions exist.

### Disassembling the Front Roller

1. Remove the roller-mounting bolt (Figure 68).
2. Insert a punch through the end of the roller housing and drive the opposite bearing out by alternating taps to the opposite side of inner bearing race. There should be a 1.5 mm (0.060 inch) lip of inner race exposed.




Figure 68

- |                  |                   |
|------------------|-------------------|
| 1. Front roller  | 3. Bearing        |
| 2. Mounting bolt | 4. Bearing spacer |

3. Push the second bearing out in press.
4. Inspect the roller housing, bearings, and bearing spacer for damage (Figure 68).
5. Replace damaged components and assemble.

### Assembling the Front Roller

1. Press the first bearing into the roller housing (Figure 68). Press on the outer race only or equally on the inner and outer race.
2. Insert the spacer (Figure 68).
3. Press the second bearing into the roller housing (Figure 68). Pressing equally on the inner and outer race until the inner race comes in contact with the spacer.
4. Install the roller assembly into the deck frame.
5. Verify that there is no more than a 1.5 mm (0.060 inch) gap between roller assembly and the roller-mount brackets of the deck frame.
6. If there is a gap over 1.5 mm (0.060 inch), install enough 5/8 inch diameter washers to take up the slop.

**Important:** Securing the roller assembly with a gap larger than 1.5 mm (0.060 inch) creates a side load on the bearing and can lead to premature bearing failure.

7. Torque the mounting bolt to 108 N·m (80 ft-lb).

# Storage

## Preparing the Machine for Storage

### Preparing the Traction Unit

1. Thoroughly clean the traction unit, cutting decks, and engine.
2. Check the tire pressure. Inflate all traction unit tires to 83 to 103 kPa (12 to 15 psi).
3. Check all fasteners for looseness and tighten them as necessary.
4. Grease all grease fittings and pivot points. Wipe up any excess lubricant.
5. Lightly sand and use touch-up paint on painted areas that are scratched, chipped, or rusted. Repair any dents in the metal body.
6. Service the battery and cables as follows:
  - A. Remove the battery terminals from the battery posts.

**Note:** Always disconnect the negative terminal first and the positive last. Always connect the positive terminal first and the negative last.
  - B. Clean the battery, terminals, and posts with a wire brush and baking soda solution.
  - C. Coat the cable terminals and battery posts with Grafo 112X skin-over grease (Part Number 505-47) or petroleum jelly to prevent corrosion.
  - D. Slowly recharge the battery every 60 days for 24 hours to prevent lead sulfation of the battery.

### Preparing the Engine

1. Drain the engine oil from the oil pan and replace the drain plug.
2. Remove and discard the oil filter. Install a new oil filter.
3. Refill the oil pan with designated quantity of motor oil.
4. Turn the key in the ignition switch to the ON position, start the engine, and run it at idle speed for approximately 2 minutes.
5. Turn the key in the ignition switch to the OFF position.
6. Thoroughly drain all fuel from the fuel tank, lines, and the fuel filter/water separator assembly.
7. Flush the fuel tank with fresh, clean diesel fuel.
8. Secure all fuel-system fittings.
9. Thoroughly clean and service the air-cleaner assembly.
10. Seal the air-cleaner inlet and the exhaust outlet with weatherproof tape.

11. Check the antifreeze protection and add as needed for expected minimum temperature in your area.

## Storing the Cutting Deck

If the cutting deck is separated from the traction unit for any length of time, install a spindle plug in the top of the spindle to protect the spindle from dust and water.

## **European Privacy Notice**

### **The Information Toro Collects**

Toro Warranty Company (Toro) respects your privacy. In order to process your warranty claim and contact you in the event of a product recall, we ask you to share certain personal information with us, either directly or through your local Toro company or dealer.

The Toro warranty system is hosted on servers located within the United States where privacy law may not provide the same protection as applies in your country.

**BY SHARING YOUR PERSONAL INFORMATION WITH US, YOU ARE CONSENTING TO THE PROCESSING OF YOUR PERSONAL INFORMATION AS DESCRIBED IN THIS PRIVACY NOTICE.**

### **The Way Toro Uses Information**

Toro may use your personal information to process warranty claims, to contact you in the event of a product recall and for any other purpose which we tell you about. Toro may share your information with Toro's affiliates, dealers or other business partners in connection with any of these activities. We will not sell your personal information to any other company. We reserve the right to disclose personal information in order to comply with applicable laws and with requests by the appropriate authorities, to operate our systems properly or for our own protection or that of other users.

### **Retention of your Personal Information**

We will keep your personal information as long as we need it for the purposes for which it was originally collected or for other legitimate purposes (such as regulatory compliance), or as required by applicable law.

### **Toro's Commitment to Security of Your Personal Information**

We take reasonable precautions in order to protect the security of your personal information. We also take steps to maintain the accuracy and current status of personal information.

### **Access and Correction of your Personal Information**

If you would like to review or correct your personal information, please contact us by email at [legal@toro.com](mailto:legal@toro.com).

## **Australian Consumer Law**

Australian customers will find details relating to the Australian Consumer Law either inside the box or at your local Toro Dealer.



## The Toro Warranty

### A Two-Year Limited Warranty

#### Conditions and Products Covered

The Toro Company and its affiliate, Toro Warranty Company, pursuant to an agreement between them, jointly warrant your Toro Commercial product ("Product") to be free from defects in materials or workmanship for two years or 1500 operational hours\*, whichever occurs first. This warranty is applicable to all products with the exception of Aerators (refer to separate warranty statements for these products). Where a warrantable condition exists, we will repair the Product at no cost to you including diagnostics, labor, parts, and transportation. This warranty begins on the date the Product is delivered to the original retail purchaser.

\* Product equipped with an hour meter.

#### Instructions for Obtaining Warranty Service

You are responsible for notifying the Commercial Products Distributor or Authorized Commercial Products Dealer from whom you purchased the Product as soon as you believe a warrantable condition exists. If you need help locating a Commercial Products Distributor or Authorized Dealer, or if you have questions regarding your warranty rights or responsibilities, you may contact us at:

Toro Commercial Products Service Department  
Toro Warranty Company  
8111 Lyndale Avenue South  
Bloomington, MN 55420-1196  
  
952-888-8801 or 800-952-2740  
E-mail: commercial.warranty@toro.com

#### Owner Responsibilities

As the Product owner, you are responsible for required maintenance and adjustments stated in your *Operator's Manual*. Failure to perform required maintenance and adjustments can be grounds for disallowing a warranty claim.

#### Items and Conditions Not Covered

Not all product failures or malfunctions that occur during the warranty period are defects in materials or workmanship. This warranty does not cover the following:

- Product failures which result from the use of non-Toro replacement parts, or from installation and use of add-on, or modified non-Toro branded accessories and products. A separate warranty may be provided by the manufacturer of these items.
- Product failures which result from failure to perform recommended maintenance and/or adjustments. Failure to properly maintain your Toro product per the Recommended Maintenance listed in the *Operator's Manual* can result in claims for warranty being denied.
- Product failures which result from operating the Product in an abusive, negligent, or reckless manner.
- Parts subject to consumption through use unless found to be defective. Examples of parts which are consumed, or used up, during normal Product operation include, but are not limited to, brake pads and linings, clutch linings, blades, reels, rollers and bearings (sealed or greasable), bed knives, spark plugs, castor wheels and bearings, tires, filters, belts, and certain sprayer components such as diaphragms, nozzles, and check valves, etc.
- Failures caused by outside influence. Conditions considered to be outside influence include, but are not limited to, weather, storage practices, contamination, use of unapproved fuels, coolants, lubricants, additives, fertilizers, water, or chemicals, etc.
- Failure or performance issues due to the use of fuels (e.g. gasoline, diesel, or biodiesel) that do not conform to their respective industry standards.

- Normal noise, vibration, wear and tear, and deterioration.
- Normal "wear and tear" includes, but is not limited to, damage to seats due to wear or abrasion, worn painted surfaces, scratched decals or windows, etc.

#### Parts

Parts scheduled for replacement as required maintenance are warranted for the period of time up to the scheduled replacement time for that part. Parts replaced under this warranty are covered for the duration of the original product warranty and become the property of Toro. Toro will make the final decision whether to repair any existing part or assembly or replace it. Toro may use remanufactured parts for warranty repairs.

#### Deep Cycle and Lithium-Ion Battery Warranty:

Deep cycle and Lithium-Ion batteries have a specified total number of kilowatt-hours they can deliver during their lifetime. Operating, recharging, and maintenance techniques can extend or reduce total battery life. As the batteries in this product are consumed, the amount of useful work between charging intervals will slowly decrease until the battery is completely worn out. Replacement of worn out batteries, due to normal consumption, is the responsibility of the product owner. Battery replacement may be required during the normal product warranty period at owner's expense. Note: (Lithium-Ion battery only): A Lithium-Ion battery has a part only prorated warranty beginning year 3 through year 5 based on the time in service and kilowatt hours used. Refer to the *Operator's Manual* for additional information.

#### Maintenance is at Owner's Expense

Engine tune-up, lubrication, cleaning and polishing, replacement of filters, coolant, and completing recommended maintenance are some of the normal services Toro products require that are at the owner's expense.

#### General Conditions

Repair by an Authorized Toro Distributor or Dealer is your sole remedy under this warranty.

**Neither The Toro Company nor Toro Warranty Company is liable for indirect, incidental or consequential damages in connection with the use of the Toro Products covered by this warranty, including any cost or expense of providing substitute equipment or service during reasonable periods of malfunction or non-use pending completion of repairs under this warranty. Except for the Emissions warranty referenced below, if applicable, there is no other express warranty. All implied warranties of merchantability and fitness for use are limited to the duration of this express warranty.**

Some states do not allow exclusions of incidental or consequential damages, or limitations on how long an implied warranty lasts, so the above exclusions and limitations may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

#### Note regarding engine warranty:

The Emissions Control System on your Product may be covered by a separate warranty meeting requirements established by the U.S. Environmental Protection Agency (EPA) and/or the California Air Resources Board (CARB). The hour limitations set forth above do not apply to the Emissions Control System Warranty. Refer to the Engine Emission Control Warranty Statement supplied with your product or contained in the engine manufacturer's documentation for details.

#### Countries Other than the United States or Canada

Customers who have purchased Toro products exported from the United States or Canada should contact their Toro Distributor (Dealer) to obtain guarantee policies for your country, province, or state. If for any reason you are dissatisfied with your Distributor's service or have difficulty obtaining guarantee information, contact the Toro importer.