



Form No. 3420-844 Rev B

Count on it.

Parts Catalog

Hydraulic Switch Kit Sand Pro® 5040 Traction Unit

Model No. 08783—Serial No. 400000000 and Up



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Hydraulic Routing and Couplers Assembly 4


Hydraulic Pump and Manifold Assembly 6

Hydraulic Pump Assembly No. 114-0603..... 8

Hydraulic Manifold Assembly No. 137-3360 10

Control Panel and Wire Harness Assembly 12


Hydraulic Routing and Couplers Assembly



Hydraulic Routing and Couplers Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	137-3366	1	Clamp-Saddle	13:2	237-30	1	O-Ring
2	137-3371	1	Coupler ASM	14	322-12	2	Screw-HH
2:2	110-1303	1	Decal-Coupler	15	3296-29	2	Nut-Lock, NI
3	3256-23	2	Washer-Plain	16	32120-2	1	Ring-Retaining
4	322-10	2	Screw-HH	17	32151-29	2	Ring-Retaining
5	340-101	3	Fitting-HYD, 45 DEG	18	340-104	1	Fitting-HYD, Tee
5:1	237-30	1	O-Ring	18:1	237-30	2	O-Ring
5:2	237-79	1	O-Ring	19	110-1324	1	Tube ASM
6	100-7671	3	Adapter-HYD	20	340-4	2	Fitting-STR
6:1	237-79	1	O-Ring	20:1	237-30	1	O-Ring
7	105-4170	4	Coupler-Male	20:2	237-79	1	O-Ring
8	105-4169	2	Coupler-Female	21	120-3409	1	Fitting-Tee
9	105-7962	2	Plug-Dust	21:1	237-79	1	O-Ring
10	105-7963	4	Cap-Dust	21:2	237-30	1	O-Ring
11	112-7159	1	Coupler ASM	22	119-2074	1	Hose-HYD
11:2	112-7160	1	Decal-Quick Coupler	23	137-3375	1	Hose-HYD
12	108-8464	2	Fitting-Straight	24	2412-36	1	Clamp-Hose
12:2	237-79	1	O-Ring	25	137-3374	1	Hose-HYD
12:3	237-30	1	O-Ring	26	110-8162	1	Dipstick
13	340-98	1	Fitting-Elbow, 90 DEG	27	3290-378	3	Tie-Cable
13:1	237-79	1	O-Ring				


Hydraulic Pump and Manifold Assembly



Hydraulic Pump and Manifold Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	108-2825	1	Hub	15	104-8300	1	Nut-HF, NI
2	5-7280	1	Key	16	137-3360	1	Manifold ASM (On-Off-On)
3	3246-4	4	Screw-Set	17	3234-5	2	Screw-HHF
4	137-3377	1	Bracket W/Bushing ASM	18	119-2074	1	Hose-HYD
4:2	23-2270	1	Bushing-Rubber	19	137-3356	1	Hydraulic Tube ASM
7	114-0603	1	HYD Pump ASM	20	137-3363	1	Hose-Suction
8	137-3365-01	1	Arm-Torque	21	2412-129	2	Clamp-Hose
9	353-987	1	Fitting-Elbow, 90	22	323-7	2	Screw-HH
9:1	237-81	1	O-Ring	23	104-8301	2	Nut-HF, NI
10	340-98	2	Fitting-Elbow, 90 DEG	24	3235-6	2	Screw-HH
10:1	237-79	1	O-Ring	25	87-3990	1	Strainer-Transaxle
10:2	237-30	1	O-Ring	25:1	237-123	1	O-Ring
11	137-3364-01	1	Bracket-Block, Valve	27	340-142	1	Fitting-Elbow-90
12	2412-81	1	Clamp-R	27:1	237-58	1	O-Ring
13	3256-23	3	Washer-Plain	27:2	237-81	1	O-Ring
14	322-12	1	Screw-HH				

Hydraulic Pump Assembly No. 114-0603





Hydraulic Pump Assembly No. 114-0603 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	114-0606	1	Seal Kit
1:1		1	Seal-Lip ●
1:2		2	Seal-Backup ●

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1:3		2	Seal-Channel ●
1:4		2	Seal-Gasket ●

● Not serviced separately

Hydraulic Manifold Assembly No. 137-3360




Hydraulic Manifold Assembly No. 137-3360 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
2	112-9212	5	Plug
3	107-7517	1	Valve-Solenoid
3:1	105-9156	1	Seal Kit
3:2	107-7812	1	Nut-Solenoid
4	107-7516	2	Solenoid Valve ASM

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
4:1	105-9156	1	Seal Kit
4:2	110-2634	1	Nut-Coil
5	120-2553	1	Valve-Relief
5:1	105-9156	1	Seal Kit
6	119-8036	3	Coil

Control Panel and Wire Harness Assembly



Control Panel and Wire Harness Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	108-8460-01	1	Bracket-Valve	6:2	137-3362	1	Decal-Lift
2	99-7430	1	Relay	7	93-9999	1	Switch-PTO, On-On-None
3	32144-11	2	Screw-HWHTF	8	100-8590	1	Switch-Rocker, Dpdt (On-Off-On)
4	321-3	1	Screw-HH	9	122-1080	1	Harness-Wire
5	3296-42	1	Nut-Lock, NI	10	218-578	1	Fuse-Blade, 10 Amp
6	137-3361	1	Lift Panel ASM				

Notes:

Notes:



Count on it.