

TORO[®]

Count on it.

Operator's Manual

**Reelmaster[®] 6700-D 4-Wheel
Drive Traction Unit**

Model No. 03813—Serial No. 403190001 and Up

This product complies with all relevant European directives. For details, please see the separate product specific Declaration of Conformity (DOC) sheet.

It is a violation of California Public Resource Code Section 4442 or 4443 to use or operate the engine on any forest-covered, brush-covered, or grass-covered land unless the engine is equipped with a spark arrester, as defined in Section 4442, maintained in effective working order or the engine is constructed, equipped, and maintained for the prevention of fire.

The enclosed engine owner's manual is supplied for information regarding the US Environmental Protection Agency (EPA) and the California Emission Control Regulation of emission systems, maintenance, and warranty. Replacements may be ordered through the engine manufacturer.

⚠ WARNING

CALIFORNIA Proposition 65 Warning

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.

Battery posts, terminals, and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and reproductive harm. Wash hands after handling.

Use of this product may cause exposure to chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.

Visit www.Toro.com for more information, including safety tips, training materials, accessory information, help finding a dealer, or to register your product.

Whenever you need service, genuine Toro parts, or additional information, contact an Authorized Service Dealer or Toro Customer Service and have the model and serial numbers of your product ready. **Figure 1** identifies the location of the model and serial numbers on the product. Write the numbers in the space provided.

Important: With your mobile device, you can scan the QR code (if equipped) on the serial number decal to access warranty, parts, and other product information.




Figure 1

1. Location of the model and serial numbers

Model No. _____

Serial No. _____

This manual identifies potential hazards and has safety messages identified by the safety-alert symbol (**Figure 2**), which signals a hazard that may cause serious injury or death if you do not follow the recommended precautions.



Figure 2

Safety-alert symbol

Introduction

This machine is a ride-on, reel-blade lawn mower intended to be used by professional operators in commercial applications. It is primarily designed for cutting grass on well-maintained turf. Using this product for purposes other than its intended use could prove dangerous to you and bystanders.

Read this information carefully to learn how to operate and maintain your product properly and to avoid injury and product damage. You are responsible for operating the product properly and safely.

This manual uses 2 words to highlight information. **Important** calls attention to special mechanical information and **Note** emphasizes general information worthy of special attention.

Contents

Safety	4
General Safety.....	4
Safety and Instructional Decals	4
Setup	11
1 Checking Fluid Levels	12
2 Installing the Cutting Units.....	12
3 Making Alternate Cutting Unit Adjustments	17
4 Adding Rear Ballast	18
5 Applying the CE Decals	18
Product Overview	18
Controls	18
Specifications	21
Attachments/Accessories	21
Before Operation	22
Before Operation Safety	22
Performing Daily Maintenance.....	22
Filling the Fuel Tank.....	23
During Operation	23
During Operation Safety	23
Starting the Engine	24
Shutting Off the Engine.....	25
Bleeding the Fuel System	25
Checking the Interlock Switches	25
Fault Memory and Retrieval.....	27
Operating Tips	27
After Operation	28
After Operation Safety	28
Hauling the Machine	28
Identifying the Tie-Down Points	28
Pushing or Towing the Machine	29
Hydraulic Solenoid Valve Functions	29
Maintenance	30
Maintenance Safety.....	30
Recommended Maintenance Schedule(s)	30
Daily Maintenance Checklist.....	31
Lubrication	32
Greasing the Bearings and Bushings	32
Engine Maintenance	34
Engine Safety	34
Servicing the Air Cleaner	34
Checking the Engine Oil	35
Servicing the Engine Oil and Filter	36
Adjusting the Throttle.....	37
Fuel System Maintenance	38
Draining the Fuel Tank	38
Checking the Fuel Lines and Connections.....	38
Servicing the Water Separator	38
Bleeding Air from the Injectors	39

Electrical System Maintenance	39
Electrical System Safety	39
Servicing the Battery.....	39
Checking the Fuses	40
Drive System Maintenance	40
Checking the Tire Pressure.....	40
Checking the Torque of the Wheel Nuts and Bolts.....	40
Checking the Planetary Gear Drive Oil	40
Changing the Planetary Gear Drive Oil	41
Checking the Rear Axle Lubricant.....	41
Changing the Rear Axle Lubricant	42
Checking the Rear Wheel Toe-In	42
Adjusting the Traction Drive for Neutral	42
Cooling System Maintenance	43
Cooling System Safety	43
Removing Debris	43
Checking the Cooling System	44
Maintaining the Cooling System.....	44
Brake Maintenance	45
Adjusting the Service Brakes	45
Belt Maintenance	46
Checking the Alternator Belt	46
Hydraulic System Maintenance	46
Hydraulic System Safety.....	46
Checking the Hydraulic Fluid	46
Hydraulic Fluid Specifications	47
Hydraulic Fluid Capacity	47
Changing the Hydraulic Fluid	47
Replacing the Hydraulic Filter	48
Checking the Hydraulic Lines and Hoses	48
Using the Hydraulic System Test Ports	48
Cutting Unit System Maintenance	50
Blade Safety	50
Checking the Reel-to-Bedknife Contact	50
Backlapping the Cutting Units	50
Adjusting the Cutting Unit Lowering Rate	51
Adjusting the Lifted Height of the Outer Front Cutting Units (Enable Position).....	51
Adjusting the Travel of the Front 3 Cutting Units.....	52
Storage	53
Storage Safety.....	53
Preparing the Traction Unit	53
Preparing the Engine	53

Safety

This machine has been designed in accordance with EN ISO 5395 (when you complete the setup procedures) and ANSI B71.4-2017.

General Safety

This product is capable of amputating hands and feet and of throwing objects.

- Read and understand the contents of this *Operator's Manual* before starting the engine.
- Use your full attention while operating the machine. Do not engage in any activity that causes distractions; otherwise, injury or property damage may occur.
- Do not put your hands or feet near moving components of the machine.


- Do not operate the machine without all guards and other safety protective devices in place and functioning properly on the machine.
- Keep children, bystanders, and pets out of the operating area. Never allow children to operate the machine.
- Shut off the engine, remove the key, wait for all movement to stop before you leave the operator's position. Allow the machine to cool before adjusting, servicing, cleaning, or storing it.

Improperly using or maintaining this machine can result in injury. To reduce the potential for injury, comply with these safety instructions and always pay attention to the safety-alert symbol **▲**, which means Caution, Warning, or Danger—personal safety instruction. Failure to comply with these instructions may result in personal injury or death.

Safety and Instructional Decals




Safety decals and instructions are easily visible to the operator and are located near any area of potential danger. Replace any decal that is damaged or missing.



93-1263

decal93-1263


1. Read the *Operator's Manual*.
2. To engage the parking brake, connect the brake pedals with the locking pin, push down on both pedals, and pull the brake latch out.
3. To release the parking brake, press both pedals until the parking brake latch retracts.
4. Danger—reels enabled.



93-6668

decal93-6668

1. Read the *Operator's Manual* for information on charging the battery; contains lead; do not discard.



93-6681

decal93-6681

1. Cutting/dismemberment hazard, fan—stay away from moving parts.




1. Hydraulic fluid 2. Read the *Operator's Manual*.

decal93-6686




decal93-6687

1. Do not step here.



decal93-6689

1. Warning—do not carry passengers.




decal93-6693

1. Crushing hazard of hand—wait for moving parts to stop.




decal93-6696

1. Stored energy hazard—read the *Operator's Manual*.



decal93-6699

1. Machine speed 3. Continuous variable setting
2. Slow 4. Fast




decal93-9425

1. Warning—read the *Operator's Manual*.
2. High pressure fluid hazard, injection into the body—stay away from moving parts; seek medical attention.



decal104-9298


1. Read the *Operator's Manual*.



105-0123

decal105-0123

1. Throttle—slow
2. Throttle—fast
3. Reels raised and off
4. Reels lowered and on when enabled—forward and backlap
5. Reels—enabled
6. Reels disabled—lift only
7. Reels disabled—lift and lower
8. Headlights
9. Headlights—On
10. Headlights—Off
11. Read the *Operators Manual*.



105-7506

decal105-7506


1. Read the *Operator's Manual*.
2. Engine—stop
3. On
4. Engine—preheat
5. Engine—start



106-6755

decal106-6755


1. Engine coolant under pressure.
2. Explosion hazard—read the *Operator's Manual*.
3. Warning—do not touch the hot surface.
4. Warning—read the *Operator's Manual*.



106-6754

decal106-6754


1. Warning—do not touch the hot surface.
2. Cutting/dismemberment hazard, fan; entanglement hazard, belt—stay away from moving parts.



decal115-2045

115-2045

1. Warning—read the *Operator's Manual*.
2. Cutting hazard of the foot; cutting hazard of the hand—stay away from moving parts; keep all guards and shields in place.
3. Warning—do not operate this machine unless you are trained.
4. Tipping hazard—lower the cutting unit when driving down slopes; drive slowly when turning; do not turn sharply while traveling fast.
5. Warning—wear the seatbelt.
6. Warning—read the *Operator's Manual*; do not tow the machine.
7. Thrown object hazard—keep bystanders away.
8. 1. Stop (⑧) 2. ←




decal115-2046

115-2046

Note: This machine complies with the industry standard stability test in the static lateral and longitudinal tests with the maximum recommended slope indicated on the decal. Review the instructions for operating the machine on slopes in the *Operator's Manual* as well as the conditions in which you would operate the machine to determine whether you can operate the machine in the conditions on that day and at that site. Changes in the terrain can result in a change in slope operation for the machine. If possible, keep the cutting units lowered to the ground while operating the machine on slopes. Raising the cutting units while operating on slopes can cause the machine to become unstable.


1. Warning—read the *Operator's Manual*.
2. Cutting hazard of the foot; cutting hazard of the hand—stay away from moving parts; keep all guards and shields in place.
3. Warning—do not operate this machine unless you are trained.
4. Tipping hazard—lower the cutting unit when driving down slopes; do not mow on slopes greater than 15°.
5. Warning—wear the seatbelt.
6. Warning—read the *Operator's Manual*; do not tow the machine.
7. Thrown object hazard—keep bystanders away.
8. Warning—engage the parking brake, shut off the engine, and remove the key before leaving the machine.



decal115-2047

115-2047

1. Warning—do not touch the hot surface.



decal115-8000

115-8000

1. Height of cut
2. Reel—mow and backlap
3. Read the *Operator's Manual*.
4. Machine speed
5. Rear reels circuit controls
6. Front reels circuit controls

REELMASTERS 6500-D / 6700-D QUICK REFERENCE AID

CHECK/SERVICE (daily)

1. OIL LEVEL, ENGINE
2. OIL LEVEL, HYDRAULIC TANK
3. COOLANT LEVEL, RADIATOR
4. FUEL /WATER SEPARATOR
5. AIR FILTER SERVICE INDICATOR
6. RADIATOR SCREEN
7. BRAKE FUNCTION
8. TIRE PRESSURE (15-20 PSI)



CHECK/SERVICE SEE OPERATOR'S MANUAL

9. BATTERY
10. BELTS (FAN, ALT.)
11. PLANETARY GEAR DRIVE
12. REAR AXLE OIL FILL**
13. REAR AXLE OIL CHECK (2)**

FLUID SPECIFICATIONS/CHANGE INTERVALS

SEE OPERATOR'S MANUAL FOR INITIAL CHANGES.	FLUID TYPE	CAPACITY	CHANGE INTERVAL FLUID	FILTER PART NO.
A. ENGINE OIL	SAE 15W-40	7.5 QTS.	150 HRS.	150 HRS. 108-3841
B. HYD. CIRCUIT OIL	SEE OPERATOR'S MANUAL	9 GALS.*	2000 HRS.	1000 HRS. 94-2621
C. PRIMARY AIR FILTER	---	---	---	SEE SERVICE INDICATOR 108-3812
D. SAFETY AIR FILTER	---	---	---	SEE OPERATOR'S MANUAL 108-3813
E. WATER SEPARATOR			400 HRS.	110-9049
F. FUEL TANK	NO. 2-DIESEL	15 GALS.	DRAIN AND FLUSH, 2 YRS.	
G. COOLANT	50/50 ETHYLENE GLYCOL/WATER	2.5 GALS.	DRAIN AND FLUSH, 2 YRS.	
H. PLANETARY GEAR DRIVE	SAE85W-140	16 OZ.	800 HRS.	---
I. REAR AXLE OIL**	SAE85W-140	80 OZ.	800 HRS.	---

* INCLUDES FILTER, CHECK DIP STICK, DO NOT OVER FILL.

**4WD ONLY

138-6982

decal138-6982

1. Read the *Operator's Manual*.

⚠ WARNING: Cancer and Reproductive Harm - www.P65Warnings.ca.gov. For more information, please visit www.tccoCAProp65.com

CALIFORNIA SPARK ARRESTER WARNING

Operation of this equipment may create sparks that can start fires around dry vegetation. A spark arrester may be required. The operator should contact local fire agencies for laws or regulations relating to fire prevention requirements.

138-6982

133-8062

decal133-8062



Battery Symbols

Some or all of these symbols are on your battery

1. Explosion hazard
2. No fire, open flame, or smoking
3. Caustic liquid/chemical burn hazard
4. Wear eye protection
5. Read the *Operator's Manual*.
6. Keep bystanders a safe distance from the battery.
7. Wear eye protection; explosive gases can cause blindness and other injuries.
8. Battery acid can cause blindness or severe burns.
9. Flush eyes immediately with water and get medical help fast.
10. Contains lead; do not discard.

Setup

Loose Parts

Use the chart below to verify that all parts have been shipped.

Procedure	Description	Qty.	Use
1	No parts required	—	Check the fluid levels.
2	Lift chain Chain bracket U-bolt Nut Screw Washer Nut Large O-ring Kickstand	7 7 7 14 7 7 7 7 1	Install the cutting units.
3	No parts required	—	Make cutting unit adjustments if needed.
4	Calcium chloride (obtain separately) Rear weight kit, part number 104-1478 (obtain separately)	45 kg (100 lb) 1	Add rear ballast (if required).
5	Warning decal CE decal Year of production decal	1 1 1	Apply the CE decals.

Media and Additional Parts

Description	Qty.	Use
Operator's Manual	1	Read the manual before operating the machine.
Engine owner's manual	1	Read the manual before operating the engine.
Declaration of Conformity	1	This document indicates CE compliance.
Diagnostic ACE display overlay	1	The diagnostic ACE display overlay is for diagnosing machine malfunctions.
Key	2	Use the keys to start the machine.
Hood lock key	1	Use the hood lock key to lock and unlock the hood.

Note: Determine the left and right sides of the machine from the normal operating position.

1

Checking Fluid Levels

No Parts Required

Procedure

Before starting the engine for the first time, check the following fluid levels:

- Engine oil
Refer to [Checking the Engine Oil \(page 35\)](#).

- Engine coolant

Refer to [Checking the Cooling System \(page 44\)](#).

- Hydraulic oil

Refer to [Checking the Hydraulic Fluid \(page 46\)](#).

- Rear axle lubricant

Refer to [Checking the Rear Axle Lubricant \(page 41\)](#).

2

Installing the Cutting Units

Parts needed for this procedure:

7	Lift chain
7	Chain bracket
7	U-bolt
14	Nut
7	Screw
7	Washer
7	Nut
7	Large O-ring
1	Kickstand

Removing the Tipper Assemblies

Remove the tipper assemblies (if so equipped) from the number 1, number 2, and number 3 lift arms to avoid interference with the carrier frames of the cutting units.

1. Remove the locknut and the washer securing the pivot rod to the number 2 lift arm ([Figure 3](#)). Remove the pivot rod and spring from the lift arm. Repeat the procedure on the number 1 and number 3 lift arms.




Figure 3

1. Pivot rod
2. Tipper support bracket w/roller

Note: The tipper bracket with the roller and the tipper support brackets are not required when operating the DPA cutting units (Figure 3).

2. Disconnect the lift chains from the cutting units, if attached.

Mounting the Lift Brackets and Chains

Mount a chain bracket to each lift arm with a U-bolt and 2 nuts. Position the brackets as follows:

Note: Refer to Figure 4 to determine the lift arm number being described.




Figure 4

1. Cutting unit 1
2. Cutting unit 2
3. Cutting unit 3
4. Cutting unit 4
5. Cutting unit 5
6. Cutting unit 6
7. Cutting unit 7
8. Reel motor
9. Weight

1. On lift arm numbers 1, 4, and 5, position the chain brackets and U-bolts 38.1 cm (15 inches) behind the center line of the pivot knuckle (Figure 5).
2. On lift arm numbers 1 and 5 the brackets should be rotated to the right 10 degrees from vertical (Figure 5).

3. On lift arm number 4 the bracket should be rotated to the left 10 degrees from vertical (Figure 5).




Figure 5

1. Lift arm number 5 = 38.1 cm (15 inches)
2. Lift arm number 4 = 10 degrees
3. Lift arm numbers 1 and 5 = 10 degrees
4. On lift arm numbers 2 and 3, position the brackets and U-bolts 38.1 cm (15 inches) behind the center line of the pivot knuckle (Figure 6).

Note: Rotate the brackets 45 degrees to the outboard side of the machine.




Figure 6

1. Lift arm number 2 = 38.1 cm (15 inches)

2. Lift arm number 3 = 45 degrees

5. On lift arm number 6 and number 7, position the brackets and U-bolts 36.8 cm (14.5 inches) behind the center line of the pivot knuckle (Figure 7).

Note: Rotate the brackets 10 degrees to the outboard side of the machine.




Figure 7

1. Lift arm number 6 = 36.8 cm (14.5 inches)

2. Lift arm number 7 = 10 degrees

6. Tighten all the U-bolt nuts to 52 to 65 N·m (38 to 48 ft-lb).

7. Mount a lift chain to each chain bracket with a screw, a washer, and a nut, positioning them as shown in Figure 8.




Figure 8

1. Lift chain

2. Chain bracket

Using the Kickstand

Whenever the cutting unit has to be tipped to expose the bedknife/reel, prop up the rear of the cutting unit with the kickstand to make sure that the nuts on the back end of the bedbar adjusting screws are not resting on the work surface (Figure 9).




Figure 9

1. Kickstand

Adjusting the Rear Shield

Under most conditions, best dispersion is attained when the rear shield is closed (front discharge). When conditions are heavy or wet, the rear shield may be opened.

To open the rear shield (Figure 10), loosen the cap screw securing the shield to the left side plate, rotate the shield to the open position, and tighten the cap screw.




Figure 10

1. Rear shield

2. Cap screw

1. On cutting unit numbers 2, 4, and 6, remove the 2 cap screws securing the counterweight to the left end of the cutting unit.

Note: Remove the counterweight (Figure 12).




Figure 12

1. Counterweight

2. On the right end of the cutting unit, remove the plastic plug from the bearing housing (Figure 13).
3. Remove the 2 cap screws from the right side plate (Figure 13).




Figure 13

1. Plastic plug

2. Cap screw (2)

4. Install the counterweight to the right end of the cutting unit with the 2 screws previously removed.
5. Loosely install the 2 reel motor mounting cap screws to the left side plate of the cutting unit (Figure 13).

Mounting the Counterweights

All cutting units are shipped with the counterweight mounted to the left end of the cutting unit. Use the following diagram to determine the position of the counterweights and reel motors.




Figure 11

1. Cutting unit 1
2. Cutting unit 2
3. Cutting unit 3
4. Cutting unit 4
5. Cutting unit 5
6. Cutting unit 6
7. Cutting unit 7
8. Reel motor
9. Weight

Installing the Cutting Units

Figure 14 shows the orientation of the hydraulic drive motor for each of the cutting unit locations. For any of the locations requiring the motor to be mounted on the right end of the cutting unit, install a counter weight on the left end of the cutting unit. For the locations requiring the motor to be mounted on the left end, install a counter weight on the right end of the cutting unit.

Note: The counterweight mounting cap screws are shipped installed on the right bearing housing of the cutting units. The cap screws on the left bearing housing are to be used for securing the hydraulic motor.




Figure 14

1. Cutting unit 1	6. Cutting unit 6
2. Cutting unit 2	7. Cutting unit 7
3. Cutting unit 3	8. Reel motor
4. Cutting unit 4	9. Weight
5. Cutting unit 5	

1. Remove the cutting units from the cartons. Assemble and adjust them per the cutting unit *Operator's Manual*.
2. Remove the protective plugs from each end of the cutting unit.
3. Lubricate and install a large O-ring into bearing housing groove on each end of cutting unit (Figure 15 & Figure 18).




Figure 15

1. Bearing housing	3. Counterweight
2. Large o-ring	

Note: Before installing the cutting unit motors or counterweights, lubricate the internal splines of the cutting unit reel shafts with grease.

4. Install a counter weight onto the appropriate end of each cutting unit with the cap screws provided (Figure 15).
5. Thoroughly grease the cutting unit reel bearings prior to installation on the traction unit. Grease should be evident at the inboard reel seals; refer to the cutting unit *Operator's Manual* for greasing procedure.
6. Insert a thrust washer onto the horizontal shaft of the pivot knuckle as shown in (Figure 16).




Figure 16

1. Carrier frame	4. Lynch pin
2. Pivot knuckle	5. Steering locking pin
3. Lift arm steering plate	

7. Insert the horizontal shaft of the pivot knuckle into the mounting tube of the carrier frame (Figure 16).
8. Secure the pivot knuckle to the carrier frame with a thrust washer, a flat washer, and a flange-head cap screw (Figure 16).
9. Insert a thrust washer onto vertical shaft of pivot knuckle (Figure 16).
10. If removed, insert the vertical shaft of the pivot knuckle into lift arm pivot hub (Figure 16). Guide the pivot knuckle in place between the two rubber centering bumpers in the under side of the lift arm steering plate.
11. Insert the lynch pin into the cross hole on the pivot knuckle shaft (Figure 16).
12. Remove nut securing turf compensation spring mounting bracket to cutting unit stabilizer ear (Figure 17). Install the tipper chain onto the cap screw and secure it with the nut that you previously removed.




Figure 17

1. Lift chain
2. Cutting unit stabilizer ear

13. Mount the motor to the drive end of the cutting unit and secure it with 2 cap screws (Figure 18).




Figure 18

1. Motor
2. O-ring

Note: If fixed cutting unit position is required, insert the steering locking pin into the pivot knuckle mounting hole (Figure 16).

14. Hook the spring wire around the bottom of the steering locking pin (Figure 16).

Turf-Compensation Settings

The turf-compensation spring transfers the weight from the front to the rear roller. This helps to reduce a wave pattern in the turf, also known as marcelling or bobbing.

Important: Make spring adjustments with the cutting unit mounted to the traction unit, pointing straight ahead and lowered to the shop floor.

1. Make sure that the hairpin cotter is installed in the rear hole in the spring rod ([Figure 19](#)).




Figure 19

1. Turf-compensation spring
2. Hairpin cotter
3. Spring rod
4. Hex nuts

2. Tighten the hex nuts on the front end of the spring rod until the compressed length of the spring is 15.9 cm (6.25 inches); refer to [Figure 19](#).

Note: When operating on rough terrain decrease the spring length by 12.7 mm (0.5 inch). Ground following will be slightly shorter.

Note: You must reset the turf-compensation setting if the HOC setting or the aggressiveness-of-cut setting is changed.

3

Making Alternate Cutting Unit Adjustments

No Parts Required

Procedure

The factory sets the tractor appropriately for most fairway mowing applications. Several adjustments for fine-tuning the machine for particular applications are included in the Cutting Unit Maintenance section as follows:

- Adjusting the cutting unit lowering rate
Adjusts the speed at which the cutting units lower.
- Adjusting the lifted height of the outer front cutting units
Adjusts the turnaround height of the outer front cutting units to provide greater clearance on contoured fairways.
- Adjusting the travel of the front three cutting units

Adjusts the downward travel of the front three cutting units to allow for highly contoured fairways.

4

Adding Rear Ballast

Parts needed for this procedure:

45 kg (100 lb)	Calcium chloride (obtain separately)
1	Rear weight kit, part number 104-1478 (obtain separately)

Procedure

To comply with EN ISO 5395 and ANSI B71.4-2017, add 45 kg (100 lb) of calcium chloride ballast to the rear wheels and install the rear weight kit (Part No. 104-1478).

Important: If a puncture occurs in a tire with calcium chloride, remove the machine from the turf area as quickly as possible. To prevent possible damage to turf, immediately soak the affected area with water.

5

Applying the CE Decals

Parts needed for this procedure:

1	Warning decal
1	CE decal
1	Year of production decal

Procedure

On machines requiring CE compliance, apply the year of production decal (Part No. 133-5615) near the serial plate, the CE decal (Part No. 93-7252) near the hood lock, and the CE warning decal (Part No. 115-2046) over the standard warning decal (Part No. 115-2045).

Product Overview

Controls

Traction Pedal

The traction pedal (Figure 20) controls forward and reverse operation. Press the top of the pedal to move the machine forward and the bottom of the pedal to move the machine backward. Ground speed is determined by how far you press the pedal. For maximum ground speed, fully press the pedal while the throttle is in the FAST position.

To stop the machine, reduce your foot pressure on the traction pedal and allow it to return to the center position.




Figure 20

1. Traction pedal	6. Parking brake latch
2. Forward speed limiter	7. Locking pin
3. Red diagnostic light	8. Reverse speed limiter
4. Speedometer	9. Key switch
5. Brake pedals	

Forward Speed Limiter

Preset the forward speed limiter (Figure 20) to limit the amount the traction pedal can be pressed in the forward direction to maintain a constant mowing speed.

Red Diagnostic Light

The red diagnostic light (Figure 20), located on steering tower, is used to convey several different messages. While starting the machine, the light illuminates when the glow plugs are on.

If the light blinks during operation, it may indicate any of the following:

- The machine is being operated faster than the maximum speed value initially programmed into the ECU.
- An electrical malfunction has been detected (open or shorted output).
- A hydraulic leak has been detected (Only if Turfdefender leak detector is installed on machine)
- A communications error has been detected (Only if Turfdefender leak detector is installed on machine)

Key Switch

The key switch (Figure 20) has 3 positions: OFF, ON/PREHEAT, and START.

Speedometer

The speedometer (Figure 20) indicates the ground speed at which the machine is traveling.

Brake Pedals

Two brake pedals (Figure 20) operate individual wheel brakes for turning assistance, parking, and to aid in obtaining better sidehill traction. Locking pin connects the pedals for parking brake operation and transport.

Parking Brake Latch

A knob on the left side of the console actuates the parking brake latch (Figure 20). To engage the parking brake, connect the pedals with the locking pin, push down on both pedals, and pull the parking brake latch out. To release the parking brake, press both pedals until the parking brake latch retracts.

Reverse Speed Limiter

Adjust the screw (Figure 20) to limit the amount that you can press the traction pedal in the rearward direction to limit speed.

Lower Mow/Raise Control Lever


This lever (Figure 21) raises and lowers the cutting units and also starts and stops the reels when you enable the reels in the mow mode. You cannot lower the cutting units when the mow/transport lever is in the transport position.

Fuel Gauge

The fuel gauge (Figure 21) indicates the level of fuel in the tank.

Engine Oil Pressure Warning Light

This light (Figure 21) indicates dangerously low engine oil pressure.



G019448
g019448

Figure 21

1. Throttle control
2. Lower mow/raise control lever
3. Fuel gauge
4. Charge indicator
5. Engine oil pressure warning light
6. Engine coolant temperature gauge
7. Glow plug indicator light
8. Engine coolant temperature gauge
9. Enable/disable switch (#7) right rear
10. Enable/disable switch (Master)
11. Enable/disable switch (#6) left rear

Throttle Control

Move the control (Figure 21) forward to increase engine speed, rearward to decrease speed.

Engine Coolant Temperature Warning Light

The light (Figure 21) illuminates and the engine shuts down when the coolant reaches a dangerously high temperature.

Glow Plug Indicator Light


When the indicator light (Figure 21) is lit, it indicates that the glow plugs are on.

Enable/Disable Switch

Use the enable/disable switch in conjunction with the lower mow/raise control lever to operate the cutting units (Figure 21).

Hour Meter

The hour meter (Figure 22) shows the total hours that the machine has been operated.



G019525
g019525

Figure 22

1. Hour meter

Backlap Knobs

The backlap knobs (Figure 23) are used in conjunction with the lower mow/raise control lever for backlapping the cutting units. Refer to [Backlapping the Cutting Units \(page 50\)](#).




Figure 23

1. Backlap knobs
2. Reel control knobs

Reel Speed Controls

The reel speed controls adjust the speed of the front and rear cutting units (Figure 23). The #1 position is for backlapping. The remaining settings are for

mowing operations. Refer to [Figure 24](#) for the proper settings.




Figure 24

1. Height of cut
2. Reel—mow and backlap
3. Read the *Operator's Manual*.
4. Machine speed
5. Rear reels circuit controls
6. Front reels circuit controls

Seat Controls

The seat-adjusting lever (Figure 25) allows you to adjust the seat forward and rearward. The seat-adjusting knob (Figure 25) adjusts the seat for your weight. To adjust the seat forward and rearward, pull the lever on the left side of the seat assembly outward. After moving the seat to the desired location, release the lever to lock the seat into position. To adjust the seat for your weight, turn the spring tension knob—clockwise to increase the spring tension, counterclockwise to decrease the spring tension.




Figure 25

1. Seat-adjusting knob 2. Seat-adjusting lever

Using the diagnostic display, determine which output is malfunctioning, refer to [Checking the Interlock Switches \(page 25\)](#).

If the diagnostic light is not illuminated when the key switch is in the ON position, this indicates that the electronic controller is not operating. Possible causes include the following:

- Loop-back is not connected.
- The light is burned out.
- Fuses are blown.
- There is no battery power.

Check the electrical connections, input fuses, and diagnostic light bulb to determine the malfunction. Ensure that the loop-back connector is secured to the wire harness connector.

Green Diagnostic Light

The machine is equipped with a diagnostic light that indicates if the electronic controller is functioning correctly. The green diagnostic light ([Figure 26](#)) is located under the control panel, next to the fuse block. When the electronic controller is functioning correctly and the key is moved to the ON position, the controller diagnostic light illuminates. The light blinks if the controller detects a malfunction in the electrical system. The light stops blinking and automatically resets when you turn the key to the OFF position.




Figure 26

1. Green diagnostic light

When the controller diagnostic light blinks, one of the following problems has been detected by the controller:

- One of the outputs has been shorted.
- One of the outputs is open circuited.

Diagnostic ACE Display (Optional)

The machine is equipped with an electronic controller which controls most machine functions. The controller determines what function is required for various input switches (i.e. seat switch, key switch, etc.) and turns on the outputs to actuate solenoids or relays for the requested machine function.

For the electronic controller to control the machine as desired, each of the input switches, output solenoids, and relays must be connected and functioning properly.

The Diagnostic ACE display is a tool to help the user verify correct electrical functions of the machine.

Specifications

Note: Specifications and design are subject to change without notice.

Width of cut	338 cm (133 inches)
Overall width—transport	226 cm (89 inches)
Overall width—operational	279 cm (110 inches)
Overall length	305 cm (120 inches)
Height with ROPS installed	213 cm (84 inches)
Weight*	1792 kg (3,950 lb)

* With 5 blade cutting units and full fluid levels.

Attachments/Accessories

A selection of Toro approved attachments and accessories is available for use with the machine to enhance and expand its capabilities. Contact

your Authorized Service Dealer or authorized Toro distributor or go to www.Toro.com for a list of all approved attachments and accessories.

To ensure optimum performance and continued safety certification of the machine, use only genuine Toro replacement parts and accessories. Replacement parts and accessories made by other manufacturers could be dangerous, and such use could void the product warranty.

Operation

Before Operation

Before Operation Safety

General Safety

- Never allow children or untrained people to operate or service the machine. Local regulations may restrict the age of the operator. The owner is responsible for training all operators and mechanics.
- Become familiar with the safe operation of the equipment, operator controls, and safety signs.
- Always shut off the engine, remove the key, wait for all moving parts to stop, and allow the machine to cool before adjusting, servicing, cleaning, or storing the machine.
- Know how to stop the machine and shut off the engine quickly.
- Do not operate the machine without all guards and other safety protective devices in place and functioning properly on the machine.
- Before mowing, always inspect the machine to ensure that the cutting units are in good working condition.
- Inspect the area where you will use the machine and remove all objects that the machine could throw.

Fuel Safety

- Use extreme care in handling fuel. It is flammable and its vapors are explosive.
- Extinguish all cigarettes, cigars, pipes, and other sources of ignition.
- Use only an approved fuel container.
- Do not remove the fuel cap or fill the fuel tank while the engine is running or hot.
- Do not add or drain fuel in an enclosed space.
- Do not store the machine or fuel container where there is an open flame, spark, or pilot light, such as on a water heater or other appliance.
- If you spill fuel, do not attempt to start the engine; avoid creating any source of ignition until the fuel vapors have dissipated.

Performing Daily Maintenance

Service Interval: Before each use or daily

Before starting the machine each day, perform the Each Use/Daily procedures listed in [Maintenance \(page 30\)](#).

Filling the Fuel Tank

Fuel tank capacity: 57 liters (15 US gallons)

Use only clean, fresh diesel fuel or biodiesel fuels with low (<500 ppm) or ultra low (<15 ppm) sulfur content. The minimum cetane rating should be 40. Purchase fuel in quantities that can be used within 180 days to ensure fuel freshness.

Use summer grade diesel fuel (No. 2-D) at temperatures above -7° C (20° F) and winter grade (No. 1-D or No. 1-D/2-D blend) below that temperature. Use of winter grade fuel at lower temperatures provides lower flash point and cold flow characteristics which will ease starting and reduce fuel filter plugging.

Use of summer grade fuel above -7° C (20° F) will contribute toward longer fuel pump life and increased power compared to winter grade fuel.

Important: Do not use kerosene or gasoline instead of diesel fuel. Failure to observe this caution will damage the engine.

Biodiesel Ready

This machine can also use a biodiesel blended fuel of up to B20 (20% biodiesel, 80% petrodiesel). The petrodiesel portion should be low or ultra low sulfur. Observe the following precautions:

- The biodiesel portion of the fuel must meet specification ASTM D6751 or EN14214.
- The blended fuel composition should meet ASTM D975 or EN590.
- Painted surfaces may be damaged by biodiesel blends.
- Use B5 (biodiesel content of 5%) or lesser blends in cold weather.
- Monitor seals, hoses, gaskets in contact with fuel as they may be degraded over time.
- Fuel filter plugging may be expected for a time after converting to biodiesel blends.
- Contact your distributor if you wish for more information on biodiesel.

1. Park the machine on a level surface, lower the cutting units, shut off the engine, engage the parking brake, and remove the key.
2. Using a clean rag, clean area around the fuel-tank cap.
3. Remove the cap from the fuel tank ([Figure 27](#)).




Figure 27

1. Fuel-tank cap
2. Fuel
3. Filler neck
4. Fill the tank with fuel until the level is to the bottom of the filler neck.
5. Install the fuel-tank cap tightly after filling the tank.

Note: If possible, fill the fuel tank after each use. This minimizes possible buildup of condensation inside the fuel tank.

During Operation

During Operation Safety

General Safety

- The owner/operator can prevent and is responsible for accidents that may cause personal injury or property damage.
- Wear appropriate clothing, including eye protection; long pants; substantial, slip-resistant footwear; and hearing protection. Tie back long hair and do not wear loose clothing or loose jewelry.
- Do not operate the machine while ill, tired, or under the influence of alcohol or drugs.
- Use your full attention while operating the machine. Do not engage in any activity that causes distractions; otherwise, injury or property damage may occur.
- Before you start the engine, ensure that all drives are in neutral, the parking brake is engaged, and you are in the operating position.
- Do not carry passengers on the machine and keep bystanders and pets away from the machine during operation.

- Operate the machine only in good visibility to avoid holes or hidden hazards.
- Avoid mowing on wet grass. Reduced traction could cause the machine to slide.
- Keep your hands and feet away from the cutting units.
- Look behind and down before backing up to be sure of a clear path.
- Use care when approaching blind corners, shrubs, trees, or other objects that may obscure your vision.
- Stop the cutting units whenever you are not mowing.
- Slow down and use caution when making turns and crossing roads and sidewalks with the machine. Always yield the right-of-way.
- Never run an engine in an area where exhaust gasses are enclosed.
- Never leave a running machine unattended.
- Before leaving the operating position (including to empty the catchers or to unclog the cutting units), do the following:
 - Park the machine on level ground.
 - Disengage the cutting units and lower the attachments.
 - Engage the parking brake.
 - Shut off the engine and remove the key.
 - Wait for all moving parts to stop.
- Operate the machine only in good visibility and appropriate weather conditions. Do not operate the machine when there is the risk of lightning.

Rollover Protection System (ROPS) Safety

- Do not remove any of the ROPS components from the machine.
- Ensure that the seat belt is attached and that you can release it quickly in an emergency.
- Always wear your seat belt.
- Check carefully for overhead obstructions and do not contact them.
- Keep the ROPS in safe operating condition by thoroughly inspecting it periodically for damage and keeping all the mounting fasteners tight.
- Replace all damaged ROPS components. Do not repair or alter them.

Slope Safety

- Slopes are a major factor related to loss of control and rollover accidents, which can result in severe injury or death. You are responsible for safe slope

operation. Operating the machine on any slope requires extra caution.

- Evaluate the site conditions to determine if the slope is safe for machine operation, including surveying the site. Always use common sense and good judgment when performing this survey.
- Review the slope instructions, listed below, for operating the machine on slopes. Before you operate the machine, review the site conditions to determine whether you can operate the machine in the conditions on that day and at that site. Changes in the terrain can result in a change in slope operation for the machine.
 - Avoid starting, stopping, or turning the machine on slopes. Avoid making sudden changes in speed or direction. Make turns slowly and gradually.
 - Do not operate a machine under any conditions where traction, steering, or stability is in question.
 - Remove or mark obstructions such as ditches, holes, ruts, bumps, rocks, or other hidden hazards. Tall grass can hide obstructions. Uneven terrain could overturn the machine.
 - Be aware that operating the machine on wet grass, across slopes, or downhill may cause the machine to lose traction.
 - Use extreme caution when operating the machine near drop-offs, ditches, embankments, water hazards, or other hazards. The machine could suddenly roll over if a wheel goes over the edge or the edge caves in. Establish a safety area between the machine and any hazard.
 - Identify hazards at the base of the slope. If there are hazards, mow the slope with a pedestrian-controlled machine.
 - If possible, keep the cutting units lowered to the ground while operating on slopes. Raising the cutting units while operating on slopes can cause the machine to become unstable.

Starting the Engine

1. Sit on the seat, keep your foot off the traction pedal so that it is in NEUTRAL, engage the parking brake, set the engine-speed switch to the SLOW position, and ensure that the Enable/Disable switch is in the DISABLE position.
2. Turn the key to the ON/PREHEAT position. An automatic timer controls the preheat for approximately 6 seconds.
3. When the glow indicator dims, turn the key to the START position. Release the key immediately when the engine starts and allow it to return to

the RUN position. Allow the engine to warm up (without load), then move the throttle control to the desired position.

Crank the engine for no longer than 15 seconds. Release the key when the engine starts. If additional preheat is required, turn the key to the OFF position and then to the ON/PREHEAT position. Repeat the process as required.

Shutting Off the Engine

Move the throttle control to the IDLE position, move the reel drive switch to DISENGAGE, and rotate the key to the OFF position.

Note: Remove the key to prevent accidental starting.

Important: Allow the engine to idle for 5 minutes before shutting it off after a full load operation. Failure to do so may lead to turbocharger trouble.

Note: Lower the cutting units to the ground. This relieves pressure from the lift circuit and eliminates the risk of the cutting units accidentally lowering to the ground.

Bleeding the Fuel System

1. Park the machine on a level surface, lower the cutting units, shut off the engine, engage the parking brake, and remove the key.
2. Ensure that the fuel tank is at least half full.
3. Unlatch and raise the hood.
4. Open the vent plug on the fuel filter/water separator (Figure 28).





Figure 28

1. Fuel filter/water separator 2. Vent plug

5. Turn the key to the ON position. The electric fuel pump will begin operation, thereby forcing air out around the vent plug. Leave the key in the ON position until a solid stream of fuel flows out

around the plug. Tighten the plug and turn the key to the OFF position.

6. Open the air bleed screw on the fuel injection pump (Figure 29).



g019459

g019459

Figure 29

1. Fuel injection pump bleed screw
7. Turn the key to the ON position. The electric fuel pump will begin operation, thereby forcing air out around air bleed screw. Leave the key in the ON position until a solid stream of fuel flows out around the screw. Tighten the screw and turn key to the OFF position.

Note: Normally, the engine should start after you follow the above procedure. However, if the engine does not start, air may be trapped between the injection pump and the injectors; refer to [Bleeding Air from the Injectors \(page 39\)](#).

Checking the Interlock Switches

The purpose of the interlock switches is to prevent the engine from cranking or starting unless the traction pedal is in the NEUTRAL position, the Enable/Disable switch is in the DISABLE position, and the Lower Mow/Raise control is in the NEUTRAL position. In addition, the engine should shut off when you press the traction pedal while you are off the seat or if the parking brake is engaged.

⚠ CAUTION

If the safety-interlock switches are disconnected or damaged, the machine could operate unexpectedly, causing personal injury.

- **Do not tamper with the interlock switches.**
- **Check the operation of the interlock switches daily and replace any damaged switches before operating the machine.**

Verifying the Interlock-Switch Function

Service Interval: Before each use or daily

1. Park the machine on a level surface, lower the cutting units, shut off the engine, engage the parking brake, and remove the key.
2. Open the control panel cover. Locate the wire harness and the loop-back connector. Carefully unplug the loop-back connector from the harness connector (Figure 30).




Figure 30

1. Loop-back connector

3. Connect the Diagnostic ACE display connector to the harness connector (Figure 31). Make sure that the correct overlay decal is positioned on Diagnostic ACE display.




Figure 31

1. Diagnostic ACE

4. Turn the key to the ON position, but do not start the machine.

Note: The red text on the overlay decal refers to input switches and the green text refers to outputs.

5. The “inputs displayed” LED, on lower right column of the Diagnostic ACE, should be illuminated. If “outputs displayed” LED is illuminated, press and release the toggle button

on the Diagnostic ACE to change the LED to “inputs displayed”. Do not hold the button down.

6. The Diagnostic ACE will illuminate the LED associated with each of the inputs when that input switch is closed.

Individually, change each of the switches from open to closed (i.e., sit on seat, engage traction pedal, etc.), and note that the appropriate LED on Diagnostic ACE will blink on and off when corresponding switch is closed. Repeat on each switch that is possible to be changed by hand.

7. If switch is closed and appropriate LED does not turn on, check all wiring and connections to switch and/or check switches with an ohm meter. Replace any damaged switches and repair any damaged wiring.

The Diagnostic ACE also has the ability to detect which output solenoids or relays are turned on. This is a quick way to determine if a machine malfunction is electrical or hydraulic.

Verifying the Output Function

1. Park the machine on a level surface, lower the cutting units, shut off the engine, engage the parking brake, and remove the key.
2. Open the control panel cover. Locate the wire harness and connectors near the controller. Carefully unplug the loop-back connector from the harness connector.
3. Connect the Diagnostic ACE connector to the harness connector. Make sure that the correct overlay decal is positioned on the Diagnostic ACE.
4. Turn the key to the ON position, but do not start the machine.

Note: The red text on the overlay decal refers to input switches and the green text refers to outputs.

5. The “outputs displayed” LED, on lower right column of Diagnostic ACE, should be illuminated. If “inputs displayed”; LED is illuminated, press the toggle button on the Diagnostic ACE to change the LED to “outputs displayed.”

Note: It may be necessary to toggle between “inputs displayed” and “outputs displayed” several times to do the following step. To toggle back and forth, press toggle button once. This may be done as often as required. Do not hold the button.

6. Sit on the seat and attempt to operate the desired function of the machine. The appropriate

output LEDs should illuminate to indicate that the ECU is turning on that function. (Refer to [Hydraulic Solenoid Valve Functions \(page 29\)](#) to be certain of the specified output LEDs.)

Note: If any output LED is blinking, this indicates an electrical problem with that OUTPUT. Repair/replace defective electrical parts immediately. To reset a blinking LED, turn the key switch "Off", then back "On" and clear the controllers fault memory; refer to [Fault Memory and Retrieval \(page 27\)](#).

If no output LEDs are blinking, but the correct output LEDs do not illuminate, verify that the required input switches are in the necessary positions to allow that function to occur. Verify correct switch function.

If the output LEDs are on as specified, but the machine does not function properly, this indicates a non-electrical problem. Repair as necessary.

Note: Due to electrical system constraints, the output LEDs for "Start", "Preheat" and "ETR/ALT" may not blink even though an electrical problem may exist for those functions. If the machine problem appears to be with one of these functions, be certain to check the electrical circuit with a volt/ohm meter to verify that no electrical problem exists to these functions.

If each input switch is in the correct position and functioning correctly, but the output LEDs are not correctly illuminated, this indicates an ECU problem. If this occurs, contact your authorized Toro distributor for assistance.

4. Rotate the key to the ON position, and continue to hold the lower mow/raise control lever in the RAISE position until the top left Diagnostic Tool light comes on (approximately 2 seconds).
5. Release the lower mow/raise control lever to the center position.
6. The Handheld Tool will now play back the fault retained in the Controller memory.

Important: The display will show eight (8) individual records with the fault displayed on the 8th record. Each record will be displayed for 10 seconds. Be sure to have the Diagnostic Tool display on Outputs to see fault. The Problem circuit will be flashing. Records will repeat until the key is turned off. The machine will not start in this mode.

Clearing the Fault Memory (Diagnostic Tool not required)

7. Rotate the key to the OFF position.
8. Turn Backlap Switch to the Front or Rear Backlap position.
9. Turn the Reel Control Switch to Enable position.
10. Move the lower mow/raise control lever to the Raise position and hold.
11. Turn the key to On, and continue to hold the lower mow/raise control lever in the RAISE position until the Reel Control Lamp starts to flash (approximately 2 seconds).
12. Release the lower mow/raise control lever and turn the key to the OFF position. The memory is now cleared.
13. Turn the Backlap Switch to the OFF position and the Enable Switch to the DISABLE position.

Important: Do not leave the Diagnostic ACE display connected to the machine. It is not designed to withstand the environment of the machine's everyday use. When you are finished using the Diagnostic ACE, disconnect it from the machine and connect the loop-back connector to the harness connector. The machine will not operate without the loop-back connector installed on the harness. Store the Diagnostic ACE in a dry, secure location indoors, not on the machine.

Fault Memory and Retrieval

If the Controller senses a **fault** on one of the **output solenoids**, it will flash the machines diagnostic Lamp (Reel Diagnostic Lamp on console or Green Diagnostic Lamp under console) and store the fault into the Controller's (ECU) memory. The fault can then be retrieved and viewed with the Diagnostic ACE handheld tool or a laptop/PC at anytime. The Controller will store 1 fault at a time and will not store another different fault until the first fault is cleared.

Retrieving Fault Information

Retrieving Stored Faults (Do not sit in seat)

1. Rotate the key to the OFF position.
2. Connect the Handheld Diagnostic Tool to the desired Controller Loop-back Connector (use the proper overlay).
3. Move the lower mow/raise control lever to the RAISE position and hold it there.

Operating Tips

Becoming Familiarized with the Machine

Before mowing grass, practice operating the machine in an open area. Start and shut off the engine.

Operate in forward and reverse. Lower and raise the cutting units and engage and disengage the reels. When you feel familiar with the machine, practice operating up and down slopes at different speeds.

Warning System

If a warning light comes on during operation, stop the machine immediately and correct the problem before continuing operation. Serious damage could occur if you operate the machine when there is a malfunction.

Important: The Red Diagnostic Light on the steering tower indicates when the glow plugs are on. Do not start the engine until the glow plug cycle is complete.

Mowing

Start the engine and move the throttle to FAST so that the engine is running at maximum speed. Move the Enable/Disable switch to Enable and use the Lower Mow/Raise lever to control the cutting units (the front cutting units are timed to lower before the rear cutting units). To move forward and cut grass, press the traction pedal forward. Maintain a speed that does not result in the Reel Control Light being illuminated. Gradually increase or decrease the traction speed to maintain the proper clip.

Transporting the Machine

Move the Enable/Disable switch to lower mow/raise control lever Disable (mid position), lock the brake pedals together, and raise the cutting units to the transport position. Be careful when driving between objects so that you do not accidentally damage the machine or the cutting units. Use extra care when operating the machine on slopes. Drive slowly and avoid sharp turns on slopes to prevent rollovers. Lower the cutting units when going downhill for steering control.

After Operation

After Operation Safety

General Safety

- Shut off the engine, remove the key, wait for all movement to stop before you leave the operator's position. Allow the machine to cool before adjusting, servicing, cleaning, or storing it.
- Clean grass and debris from the cutting units, drives, mufflers, cooling screens, and engine

compartment to help prevent fires. Clean up oil or fuel spills.

- Shut off the fuel while storing or transporting the machine.
- Disengage the drive to the attachment whenever you are transporting or not using the machine.
- Maintain and clean the seat belt(s) as necessary.
- Do not store the machine or fuel container where there is an open flame, spark, or pilot light, such as on a water heater or on other appliances.

Hauling the Machine

- Use full-width ramps for loading the machine onto a trailer or truck.
- Tie the machine down securely.

Identifying the Tie-Down Points

- Front—the hole in the rectangular pad, under the axle tube, inside each front tire ([Figure 32](#))




Figure 32

g031851

1. Front tie-down

- Rear—each side of the machine on the rear frame ([Figure 33](#))




Figure 33

1. Rear tie-down


Pushing or Towing the Machine

In an emergency, you can move the machine by actuating the bypass valve in the variable displacement hydraulic pump, and then pushing or towing the machine.

Important: Do not push or tow the machine faster than 3 to 4.8 km/h (2 to 3 mph) because internal transmission damage may occur. The bypass valve must be open whenever you push or tow the machine.

1. The bypass valve is located on top of variable displacement pump (Figure 34). Rotate the valve 90°, in either direction, to open and allow oil to bypass internally.

Note: You can now move the machine slowly without damaging the transmission.



1. Bypass valve

2. Close the bypass valve before starting the engine.

Important: Running the engine with the bypass valve open will cause the transmission to overheat.

Note: Do not exceed 7 to 11 N·m (5 to 8 ft-lb) torque to close the valve.

Hydraulic Solenoid Valve Functions

Use the list below to identify and describe the different functions of the solenoids in the hydraulic manifold. Each solenoid must be energized to allow function to occur.

Solenoid	Function
MSV1	Front reel circuit
MSV2	Rear reel circuit
SV4	Lift front wing cutting units
SV3	Lift front center cutting unit
SV5	Lift rear cutting units
SV1	Pressurize raise/lower hydraulic circuit
SV2	Direction: ON = Raise, OFF = Lower
SV 6	Left rear wing cutting unit
SV 7	Right rear wing cutting unit
SV8	Load holding

Maintenance

Note: Determine the left and right sides of the machine from the normal operating position.

Maintenance Safety

- Before adjusting, cleaning, servicing, or leaving the machine, do the following:
 - Park the machine on a level surface.
 - Move the throttle switch to the low-idle position.
 - Disengage the cutting units.
 - Lower the cutting units.
 - Ensure that the traction is in neutral.
 - Engage the parking brake.
 - Shut off the engine and remove the key.
 - Wait for all moving parts to stop.
 - Allow machine components to cool before performing maintenance.

- If possible, do not perform maintenance while the engine is running. Keep away from moving parts.
- Use jack stands to support the machine or components when required.
- Carefully release pressure from components with stored energy.
- Keep all parts of the machine in good working condition and all hardware tightened.
- Replace all worn or damaged decals.
- To ensure safe, optimal performance of the machine, use only genuine Toro replacement parts. Replacement parts made by other manufacturers could be dangerous, and such use could void the product warranty.

Recommended Maintenance Schedule(s)

Maintenance Service Interval	Maintenance Procedure
After the first 8 hours	<ul style="list-style-type: none">Check the torque of the wheel nuts and bolts (after the first 1 to 4 hours of operation and then after 10 hours of operation).
After the first 50 hours	<ul style="list-style-type: none">Change the engine oil and oil filter.
After the first 200 hours	<ul style="list-style-type: none">Change the planetary gear drive oil.Change the rear axle lubricant.
Before each use or daily	<ul style="list-style-type: none">Inspect the seat belt(s) for wear, cuts, and other damage. Replace the seat belt(s) if any component does not operate properly.Check the operation of the interlock switches.Check the engine oil level.Drain water or other contaminants from the water separator.Check the tire pressure.Remove debris from the rear screen, oil cooler, and radiator (more frequently in dirty conditions).Check and clean the cooling system.Check the hydraulic fluid level.Check the hydraulic lines and hoses.Check the reel-to-bedknife contact.
Every 25 hours	<ul style="list-style-type: none">Check the electrolyte level (if the machine is in storage, check it every 30 days).
Every 50 hours	<ul style="list-style-type: none">Grease the bearings and bushings (and immediately after every washing).
Every 100 hours	<ul style="list-style-type: none">Inspect and tighten the cooling system hoses and connections.Check the condition and tension of the alternator belt.
Every 150 hours	<ul style="list-style-type: none">Change the engine oil and oil filter.
Every 200 hours	<ul style="list-style-type: none">Check the torque of the wheel nuts and bolts.

Maintenance Service Interval	Maintenance Procedure
Every 400 hours	<ul style="list-style-type: none"> Service the air cleaner. (more frequently in extremely dirty or dusty conditions). Service the air cleaner earlier if the air-cleaner indicator shows red. Check the fuel lines and connections for deterioration, damage, or loose connections (or yearly, whichever comes first). Replace the fuel-filter canister. Check the planetary gear drive oil (also, check if external leakage is observed). Check the rear axle lubricant level.
Every 800 hours	<ul style="list-style-type: none"> Change the planetary gear drive oil (or yearly, whichever comes first). Change the rear axle lubricant. Check the rear wheel toe-in. If you are not using the recommended hydraulic fluid or have ever filled the reservoir with an alternative fluid, change the hydraulic fluid. If you are not using the recommended hydraulic fluid or have ever filled the reservoir with an alternative fluid, replace the hydraulic filter.
Every 1,000 hours	<ul style="list-style-type: none"> If you are using the recommended hydraulic fluid, replace the hydraulic filter.
Every 2,000 hours	<ul style="list-style-type: none"> If you are using the recommended hydraulic fluid, change the hydraulic fluid.
Every 2 years	<ul style="list-style-type: none"> Drain and clean the fuel tank. Drain and flush the cooling system.

Daily Maintenance Checklist

Duplicate this page for routine use.

Maintenance Check Item	For the week of:						
	Mon.	Tues.	Wed.	Thurs.	Fri.	Sat.	Sun.
Check the safety-interlock operation.							
Check the brake operation.							
Check the engine oil and fuel level.							
Drain the water/fuel separator.							
Check the air-filter-restriction indicator.							
Check the radiator and screen for debris.							
Check unusual engine noises. ¹							
Check unusual operating noises.							
Check the hydraulic-fluid level.							
Check the hydraulic-filter indicator. ²							
Check hydraulic hoses for damage.							
Check for fluid leaks.							
Check the tire pressure.							
Check the instrument operation.							
Check the reel-to-bedknife adjustment.							
Check the height-of-cut adjustment.							
Check all grease fittings for lubrication. ³							
Touch-up damaged paint.							

1. Check the glow plug and injector nozzles if hard starting, excess smoking, or rough running is noted.

2. Check with the engine running and the oil at operating temperature.

3. Immediately after every washing, regardless of the interval listed

Notation for Areas of Concern

Inspection performed by:

Item	Date	Information
1		
2		
3		
4		
5		
6		
7		
8		

Important: Refer to your engine owner's manual for additional maintenance procedures.

Note: To obtain an electrical schematic or a hydraulic schematic for your machine, visit www.Toro.com.

Lubrication

Greasing the Bearings and Bushings

Service Interval: Every 50 hours (and immediately after every washing).

Lubricate all grease fittings for the bearings and bushings with No. 2 lithium grease.

The grease fitting locations and quantities are as follows:

- Cutting unit carrier frame and pivot (2) (Figure 35)





Figure 35



g019486

Figure 36

1. Top fitting on king pin
- Front lift cylinders (3) (Figure 37 and Figure 38)

- Rear axle tie rod (2) (Figure 36)
- Steering cylinder ball joints (2) (Figure 36)
- King pin bushings (2) (Figure 36) — **The top fitting on the king pin should only be lubricated annually (2 pumps).**




Figure 37

- Rear lift cylinder pivot (2) (Figure 39)




Figure 39




Figure 38

- Lift arm pivot (3) (Figure 40)




Figure 40

- Rear axle pivot (Figure 41)




Figure 41

- Rear lift arm pivots (2) (Figure 42)




Figure 42

g019492

- Brake pedal shaft (1) (Figure 43)




Figure 43

G019493

g019493

Engine Maintenance

Engine Safety

- Shut off the engine before checking the oil or adding oil to the crankcase.
- Do not change the governor speed or overspeed the engine.

Servicing the Air Cleaner

Service Interval: Every 400 hours (more frequently in extremely dirty or dusty conditions). Service the air cleaner earlier if the air-cleaner indicator shows red.

Check the air-cleaner body for damage which could cause an air leak. Replace it if it is damaged. Check the whole intake system for leaks, damage, or loose hose clamps.

Service the air-cleaner filter only when the service indicator (Figure 44) requires it. Changing the air filter before it is necessary only increases the chance of dirt entering the engine when you remove the filter.




Figure 44

g009709

1. Service indicator

Important: Ensure that the cover is seated correctly and seals with the air cleaner body.

1. Pull the latch outward and rotate the air cleaner cover counterclockwise (Figure 45).




Figure 45

- 1. Service indicator
- 2. Latch
- 3. Cover

2. Remove the cover from the air cleaner body. Before removing the filter, use low pressure air (275 kPa [40 psi], clean and dry) to help remove large accumulations of debris packed between outside of primary filter and the canister. **Avoid using high pressure air which could force dirt through the filter into the intake tract.**

This cleaning process prevents debris from migrating into the intake when the primary filter is removed.

3. Remove and replace the primary filter (Figure 46).

Cleaning of the used element is not recommended due to the possibility of damage to the filter media. Inspect the new filter for shipping damage, checking the sealing end of the filter and the body. **Do not use a damaged element.** Insert the new filter by applying pressure to the outer rim of the element to seat it in the canister. **Do not apply pressure to the flexible center of the filter.**




Figure 46

- 1. Air cleaner primary filter

Important: Never attempt to clean the safety filter (Figure 47). Replace the safety filter with a new one after every three primary filter services.




Figure 47

1. Air cleaner safety filter
4. Clean the dirt ejection port located in the removable cover. Remove the rubber outlet valve from the cover, clean the cavity and replace the outlet valve.
5. Install the cover orienting the rubber outlet valve in a downward position—between approximately 5:00 to 7:00 when viewed from the end.
6. Reset the indicator (Figure 44) if it shows red.

Checking the Engine Oil

Service Interval: Before each use or daily

The engine is shipped with oil in the crankcase; however, check the oil level before and after the engine is first started.

Use high-quality engine oil that meets the following specifications:

- API Classification Level Required: CH-4, CI-4 or higher.
- Preferred oil: SAE 15W-40: above -18°C (0°F)
- Alternate oil: SAE 10W-30 or 5W-30 (all temperatures)

Note: Toro Premium Engine oil is available from your distributor in either 15W-40 or 10W-30 viscosity. See the *Parts Catalog* for part numbers.

Note: The best time to check the engine oil is when the engine is cool before it has been started for the day. If it has already been run, allow the oil to drain back down to the sump for at least 10 minutes before checking. If the oil level is at or below the Add mark on the dipstick, add oil to bring the oil level to the Full mark. **Do not overfill the engine.** If the oil level is between the Full and Add marks, no oil addition is required.

1. Park the machine on a level surface, lower the cutting units, shut off the engine, engage the parking brake, and remove the key.
2. Release the hood latch and open the hood (Figure 48).




Figure 48

1. Hood latch

3. Remove the dipstick (Figure 49), wipe it clean, install the dipstick into the tube, and pull it out again.

Check the oil level on the dipstick; the oil level should be up to the Full mark on the dipstick.




Figure 49

1. Dipstick

4. If the oil is below the safe range, remove the fill cap (Figure 50) and add oil until the level reaches the Full mark.

Important: Do not overfill the engine.




Figure 50

1. Fill cap
5. Install the oil fill cap and dipstick.
6. Close the hood and secure it with the latches.

Servicing the Engine Oil and Filter

Service Interval: After the first 50 hours

Every 150 hours

Capacity: 7.0 L (7.5 US qt) with filter

Change the oil and filter initially after the first 50 hours of operation, thereafter change oil and filter every 150 hours.

1. Remove the drain plug (Figure 51) and let oil flow into a drain pan. When the oil stops, install the drain plug.




Figure 51

1. Drain plugs
2. Remove the oil filter (Figure 52). Apply a light coat of clean oil to the new filter seal before screwing it on. Do not overtighten the filter.




Figure 52

1. Oil filter

3. Add oil to the crankcase.

Adjusting the Throttle

1. Position the throttle lever forward so that it stops against the seat base slot.
2. Loosen the throttle cable connector on the lever arm at the injection pump (Figure 53).




Figure 53

1. Injection pump lever arm
2. Connector

3. Hold the injection pump lever arm against the high idle stop and tighten the cable connector.

Note: When tightened, the cable connector must be free to swivel.

4. Torque the locknut, used to set the friction device on the throttle lever, to 4 to 6 N·m (40 to 55 in-lb). The maximum force required to operate the throttle lever should be 80 N (20 lb).

Fuel System Maintenance

Draining the Fuel Tank

Service Interval: Every 2 years

Park the machine on a level surface, lower the cutting units, engage the parking brake, shut off the engine, and remove the key.

Drain and clean the fuel tank every 2 years. Also, drain and clean the tank if the fuel system becomes contaminated or if the machine is to be stored for an extended period. Use clean fuel to flush out the tank.




Figure 54

1. Fuel tank drain

Checking the Fuel Lines and Connections

Service Interval: Every 400 hours (or yearly, whichever comes first).

Check the fuel lines and connections for deterioration, damage, or loose connections.

Servicing the Water Separator

Service Interval: Before each use or daily—Drain water or other contaminants from the water separator.

Every 400 hours—Replace the fuel-filter canister.

1. Park the machine on a level surface, lower the cutting units, engage the parking brake, shut off the engine, and remove the key.
2. Place a clean container under the fuel filter.

3. Loosen the drain plug on the bottom of the filter canister and open the vent on the top of the canister mount.




Figure 55

1. Water separator filter canister
4. Clean the area where the filter canister mounts.
5. Remove the filter canister and clean the mounting surface.
6. Lubricate the gasket on the filter canister with clean oil.
7. Install the filter canister by hand until the gasket contacts the mounting surface, then rotate it an additional 1/2 turn.
8. Tighten the drain plug on the bottom of the filter canister and close the vent on the top of the canister mount.

Bleeding Air from the Injectors

Note: Perform this procedure only when the fuel system has been purged of air through normal priming procedures and the engine does not start; refer to [Bleeding the Fuel System \(page 25\)](#).

1. Loosen the pipe connection to the No. 1 nozzle and holder assembly.




Figure 56

1. Fuel injectors (4)
2. Move the throttle to the FAST position.
3. Turn the key to the RUN position and watch for fuel to flow around the connector. Turn the key to the OFF position when you see a steady flow of fuel.
4. Tighten the pipe connector securely.
5. Repeat steps 1 through 4 on the remaining nozzles.

Note: You can remove the fan shroud from the machine to simplify cleaning.

6. Install the rear screen and secure the latches.

Important: Do not use water to clean the engine, as damage may occur.

Electrical System Maintenance

Electrical System Safety

- Disconnect the battery before repairing the machine. Disconnect the negative terminal first and the positive last. Connect the positive terminal first and the negative last.
- Charge the battery in an open, well-ventilated area, away from sparks and flames. Unplug the charger before connecting or disconnecting the battery. Wear protective clothing and use insulated tools.

Servicing the Battery

Service Interval: Every 25 hours—Check the electrolyte level (if the machine is in storage, check it every 30 days).

The battery electrolyte level must be properly maintained and the top of the battery kept clean. If the machine is stored in a location where temperatures are extremely high, the battery will run down more rapidly than if the machine is stored in a location where temperatures are cool.

⚠ DANGER

Battery electrolyte contains sulfuric acid which is a deadly poison and causes severe burns.

- **Do not drink electrolyte and avoid contact with skin, eyes or clothing. Wear safety glasses to shield your eyes and rubber gloves to protect your hands.**
- **Fill the battery where clean water is always available for flushing the skin.**
- **Charge the battery in a well-ventilated place so that the gasses produced while charging can dissipate.**
- **Since the gases are explosive, keep open flames and electrical sparks away from the battery; do not smoke.**
- **Nausea may result if the gases are inhaled.**
- **Unplug the charger from the electrical outlet before connecting to or disconnecting the charger leads from the battery posts.**

Maintain the cell level with distilled or demineralized water. Do not fill the cells above the bottom of the split

ring inside each cell. Install the filler caps with the vents pointing to the rear (toward the fuel tank).


Keep the top of the battery clean by washing it periodically with a brush dipped in ammonia or bicarbonate of soda solution. Flush the top surface with water after cleaning. Do not remove the filler caps while cleaning.

The battery cables must be tight on the terminals to provide good electrical contact.


If corrosion occurs at the terminals, disconnect the cables, negative (–) cable first, and scrape the clamps and terminals separately. Connect the cables, positive (+) cable first, and coat the terminals with petroleum jelly.

Checking the Fuses

There are 7 fuses in the electrical system. They are located below the control panel (Figure 57 and Figure 58).



1. Fuses



Drive System Maintenance

Checking the Tire Pressure

Service Interval: Before each use or daily

The tires are over-inflated for shipping. Therefore, release some of the air to reduce the pressure. Correct air pressure in the front and rear tires is 103 to 138 kPa (15 to 20 psi).

DANGER

Low tire pressure decreases machine side hill stability. This could cause a rollover, which may result in personal injury or death.

Do not under-inflate the tires.

Checking the Torque of the Wheel Nuts and Bolts

Service Interval: After the first 8 hours

Every 200 hours

Torque the wheel nuts and bolts to 115 to 135 N·m (85 to 100 ft-lb).

WARNING

Failure to maintain proper torque of the wheel nuts and bolts could result in personal injury.

Maintain the proper torque on the wheel nuts and bolts.

Checking the Planetary Gear Drive Oil

Service Interval: Every 400 hours (also, check if external leakage is observed).

Check the oil level every 400 hours of operation. Use high quality SAE 85W-140 gear oil as a replacement.

1. With the machine on a level surface, position the wheel so that 1 check plug (Figure 59) is at the 12 o'clock position and the other is at the 3 o'clock position.




Figure 59

g019500




Figure 61

g019501

1. Check plug (2)
2. Remove the plug at the 3 o'clock position (Figure 59). The oil level should be at the bottom of the check plug hole.
3. If the oil level is low, remove the plug at the 12 o'clock position and add oil until it begins to flow out of the hole at the 3 o'clock position.
4. Install both plugs.
5. Repeat steps 1 through 4 on the opposite planetary gear assembly.

Changing the Planetary Gear Drive Oil

Service Interval: After the first 200 hours

Every 800 hours (or yearly, whichever comes first).

Change the oil initially after 200 hours operation. Thereafter, change the oil every 800 hours. Use high quality SAE 85W-140 gear oil as replacement.

1. With the machine on level surface, position a wheel so that one of the check/drain plugs is at the lowest (6 o'clock) position (Figure 60).




Figure 60

G008862

g008862

1. Check/drain plug
2. Place a drain pan under the planetary hub, remove the plug, and allow the oil to drain.
3. Place a drain pan under the brake housing, remove the drain plug, and allow the oil to drain (Figure 61).

Checking the Rear Axle Lubricant

Service Interval: Every 400 hours

The rear axle is shipped from the factory filled with SAE 85W-140 gear oil. Check the level before first starting the engine and every 400 hours thereafter. Capacity is 2.3 L (80 fl oz). Visually inspect for leaks daily.

1. Park the machine on a level surface, lower the cutting units, shut off the engine, engage the parking brake, and remove the key.
2. Remove a check plug (Figure 62) from 1 end of axle and make sure lubricant is up to the bottom of the hole. If the level is low, remove the fill plug (Figure 62) and add enough oil to bring the level up to the bottom of the check plug holes.




Figure 62

1. Check plug 2. Fill plug

Changing the Rear Axle Lubricant

Service Interval: After the first 200 hours

Every 800 hours

Change the oil initially after the first 200 hours of operation and every 800 hours of operation thereafter.

1. Park the machine on a level surface, lower the cutting units, shut off the engine, engage the parking brake, and remove the key.
2. Clean the area around the 3 drain plugs: 1 on each end and 1 in the center (Figure 63).




Figure 63

1. Drain plug location

3. Remove the 3 oil level check plugs and the main axle vent cap to ease in draining of the oil.
4. Remove the drain plugs and allow the oil to drain into the pans.
5. Install the plugs.
6. Remove a check plug and fill the axle with approximately 2.3 L (80 fl oz) of 85W-140 gear oil or until oil is up to the bottom of the hole.
7. Install the check plug.

Checking the Rear Wheel Toe-In

Service Interval: Every 800 hours

After every 800 operating hours or annually, check the rear wheel toe-in.

1. Measure the center-to-center distance (at axle height) at the front and rear of the steering tires. The front measurement must be 3 mm (1/8 inch) less than the rear measurement.
2. To adjust the distance, remove the cotter pin and nut from either tie rod ball joint. Remove the tie rod ball joint from the axle case support (Figure 64).
3. Loosen the clamps at both ends of the tie rods (Figure 64).




Figure 64

1. Tie rod clamp 2. Tie rod ball joint

4. Rotate the detached ball joint inward or outward 1 complete revolution. Tighten the clamp at the loose end of the tie rod.
5. Rotate the entire tie rod assembly the same direction (inward or outward) 1 complete revolution. Tighten the clamp at the connected end of the tie rod.
6. Install the ball joint in the axle case support and tighten the nut finger tight. Measure the toe-in.
7. Repeat the procedure if necessary.
8. Tighten the nut and install a new cotter pin when the adjustment is correct.

Adjusting the Traction Drive for Neutral

The machine must not creep when you release the traction pedal. If it does creep, an adjustment is required.

1. Park the machine on a level surface, lower the cutting units, shut off the engine, press only the right brake pedal and engage the parking brake.

2. Jack up left side of machine until the front tire and the rear tire are off the shop floor. Support the machine with jack stands to prevent it from falling accidentally.
3. Start the engine and allow it to run at low idle.
4. Adjust the jam nuts on the pump rod end to move the pump control tube forward to eliminate forward creep or rearward to eliminate rearward creep ([Figure 65](#)).




Figure 65

1. Pump rod
2. Pump control tube
5. After wheel rotation ceases, tighten the jam nuts to secure the adjustment.
6. Shut off the engine and release the right brake. Remove the jack stands and lower the machine to the shop floor. Test drive the machine to ensure that it does not creep.

Cooling System Maintenance

Cooling System Safety

- Swallowing engine coolant can cause poisoning; keep out of reach from children and pets.
- Discharge of hot, pressurized coolant or touching a hot radiator and surrounding parts can cause severe burns.
 - Always allow the engine to cool at least 15 minutes before removing the radiator cap.
 - Use a rag when opening the radiator cap, and open the cap slowly to allow steam to escape.

Removing Debris

Service Interval: Before each use or daily

Remove debris from the rear screen, oil cooler, and radiator daily (more frequently in dirty conditions).

Important: Never spray water onto a hot engine as damage to the engine may occur.

1. Park the machine on a level surface, lower the cutting units, shut off the engine, engage the parking brake, and remove the key.
2. Open the hood.
3. Clean the engine area thoroughly of all debris.
4. Close the hood.
5. Unlatch and remove the rear screen ([Figure 66](#)).




Figure 66

1. Rear screen
6. Clean the screen thoroughly.
7. Unscrew the knobs and pivot the oil cooler rearward ([Figure 67](#)).




Figure 67

1. Oil cooler 2. Radiator

8. Clean both sides of the oil cooler and radiator area thoroughly with compressed air. Do not use water.
9. Open the hood and blow the debris out toward the back of the machine.
10. Pivot the oil cooler back into position and tighten the knobs.

Checking the Cooling System

Service Interval: Before each use or daily

The capacity of the cooling system is 9.4 L (10 US qt).

1. Clean the debris off the screen, the oil cooler, and the front of the radiator daily (more often if conditions are extremely dusty and dirty); refer to [Removing Debris \(page 43\)](#).

The cooling system is filled with a 50/50 solution of water and permanent ethylene glycol antifreeze. Check the level of the coolant in the radiator and the expansion tank at the beginning of each day before starting the engine.

Carefully remove the radiator cap and the expansion tank cap ([Figure 68](#)).

2. Check the level of coolant in the radiator and in the expansion tank ([Figure 68](#)).

The radiator should be filled to the top of the filler neck and the expansion tank filled to the Full mark.




Figure 68

1. Expansion tank

3. Fill the expansion tank to the Full mark and the radiator to the top of the filler neck. **Do not overfill the expansion tank.**

Note: If air is trapped in the system, remove the vent plug ([Figure 69](#)) from the top of the radiator side tank to allow trapped air to escape. Install the vent plug using PTFE thread sealant.




Figure 69

1. Vent plug

4. Install the radiator cap and the expansion tank cap.
5. Close the hood and secure the latches.

Maintaining the Cooling System

Service Interval: Every 100 hours

Every 2 years

Capacity: 9.4 L (10 US qt)

Protect the cooling system with a 50/50 solution of water and permanent ethylene glycol anti-freeze. Do not use only water in the cooling system.


- After every 100 operating hours, inspect and tighten the hose connections. Replace any deteriorated hoses.
- After every 2 years, drain and flush the cooling system. Add anti-freeze; refer to [Checking the Cooling System \(page 44\)](#).

Brake Maintenance

Adjusting the Service Brakes

Adjust the service brakes when there is more than 2.5 cm (1 inch) of free travel of the brake pedal, or when the brakes do not work effectively. Free travel is the distance the brake pedal moves before braking resistance is felt.

1. Disengage the locking pin from the brake pedals so that both pedals work independently of each other.
2. To reduce the amount of free travel of the brake pedals, tighten the brakes by loosening the front nut on the threaded end of the brake cable ([Figure 70](#)). Then tighten rear nut to move cable backward until brake pedals have 1.2 to 2.5 cm (1/2 to 1 inch) of free travel. Tighten the front nuts after the brakes are adjusted correctly.



G019480
g019480

Figure 70

1. Brake cables

Belt Maintenance

Checking the Alternator Belt

Service Interval: Every 100 hours

Check condition and tension of alternator belt after every 100 hours of operation (Figure 71). Replace belt as required. Check the tension as follows:

1. Open the hood.
2. Check the tension by pressing the belt midway between the alternator and the crankshaft pulleys with 97 N (22 lb) of force. The belt should deflect 1.1 cm (7/16 inch). If the deflection is incorrect, proceed to step 3. If it is correct, continue operation.




Figure 71

1. Alternator belt
2. Brace
3. Loosen the bolt securing the brace to the engine and the bolt securing the alternator to the brace.
4. Insert a pry bar between the alternator and the engine and pry out on the alternator.
5. When proper tension is achieved, tighten the alternator and brace bolts to secure the adjustment.
6. Tighten the locknut to secure the adjustment.

Hydraulic System Maintenance

Hydraulic System Safety

- Seek immediate medical attention if fluid is injected into skin. Injected fluid must be surgically removed within a few hours by a doctor.
- Ensure that all hydraulic-fluid hoses and lines are in good condition and all hydraulic connections and fittings are tight before applying pressure to the hydraulic system.
- Keep your body and hands away from pinhole leaks or nozzles that eject high-pressure hydraulic fluid.
- Use cardboard or paper to find hydraulic leaks.
- Safely relieve all pressure in the hydraulic system before performing any work on the hydraulic system.

Checking the Hydraulic Fluid

Service Interval: Before each use or daily

1. Park the machine on a level surface, lower the cutting units, shut off the engine, engage the parking brake, and remove the key.
2. Clean the area around the filler neck and cap of the hydraulic tank (Figure 72). Remove the cap from the filler neck.




Figure 72

1. Hydraulic tank cap
3. Remove the dipstick from the filler neck and wipe it with a clean rag. Insert the dipstick into the filler neck, then remove it and check the

level of the fluid. The fluid level should be within 6 mm (1/4 inch) of the mark on the dipstick.

4. If the level is low, add the appropriate fluid to raise the level to the full mark.
5. Install the dipstick and cap onto the filler neck.

Hydraulic Fluid Specifications

The reservoir is filled at the factory with high-quality hydraulic fluid. Check the level of the hydraulic fluid before you first start the engine and daily thereafter; refer to [Checking the Hydraulic Fluid \(page 46\)](#).

Recommended hydraulic fluid: Toro PX Extended Life Hydraulic Fluid; available in 19 L (5 US gallon) pails or 208 L (55 US gallon) drums.

Note: A machine using the recommended replacement fluid requires less frequent fluid and filter changes.

Alternative hydraulic fluids: If Toro PX Extended Life Hydraulic Fluid is not available, you may use another conventional, petroleum-based hydraulic fluid having specifications that fall within the listed range for all the following material properties and that it meets industry standards. Do not use synthetic fluid. Consult with your lubricant distributor to identify a satisfactory product.

Note: Toro does not assume responsibility for damage caused by improper substitutions, so use products only from reputable manufacturers who will stand behind their recommendation.

High Viscosity Index/Low Pour Point Anti-wear Hydraulic Fluid, ISO VG 46

Material Properties:

Viscosity, ASTM D445	cSt @ 40°C (104°F) 44 to 48
Viscosity Index ASTM D2270	140 or higher
Pour Point, ASTM D97	-37°C to -45°C (-34°F to -49°F)

Industry Specifications:	Eaton Vickers 694 (I-286-S, M-2950-S/35VQ25 or M-2952-S)
--------------------------	--

Note: Many hydraulic fluids are almost colorless, making it difficult to spot leaks. A red dye additive for the hydraulic fluid is available in 20 ml (0.67 fl oz) bottles. A bottle is sufficient for 15 to 22 L (4 to 6 US gallons) of hydraulic fluid. Order Part No. 44-2500 from your authorized Toro distributor.

Important: Toro Premium Synthetic Biodegradable Hydraulic Fluid is the only

synthetic biodegradable fluid approved by Toro. This fluid is compatible with the elastomers used in Toro hydraulic systems and is suitable for a wide-range of temperature conditions. This fluid is compatible with conventional mineral oils, but for maximum biodegradability and performance, the hydraulic system should be thoroughly flushed of conventional fluid. The oil is available in 19 L (5 US gallons) pails or 208 L (55 US gallons) from your authorized Toro distributor.

Hydraulic Fluid Capacity

32 L (8.5 US gallons); refer to [Hydraulic Fluid Specifications \(page 47\)](#)

Changing the Hydraulic Fluid

Service Interval: Every 2,000 hours—if you are using the recommended hydraulic fluid, change the hydraulic fluid.

Every 800 hours—if you are not using the recommended hydraulic fluid or have ever filled the reservoir with an alternative fluid, change the hydraulic fluid.

If the fluid becomes contaminated, contact a Toro distributor to flush the hydraulic system. Contaminated hydraulic fluid looks milky or black when compared to clean fluid.

1. Park the machine on a level surface, lower the cutting units, shut off the engine, engage the parking brake, and remove the key.
2. Open the hood.
3. Remove the drain plug from the bottom of the reservoir ([Figure 73](#)) and let the hydraulic fluid flow into a drain pan.




Figure 73

1. Hydraulic reservoir
4. Install and tighten the plug when the hydraulic fluid stops draining.
5. Fill the reservoir with hydraulic fluid; refer to [Hydraulic Fluid Specifications \(page 47\)](#) and [Hydraulic Fluid Capacity \(page 47\)](#).

Important: Use only the hydraulic fluids specified. Other fluids could cause system damage.

6. Install the reservoir cap. Start the engine and use all the hydraulic controls to distribute the hydraulic fluid throughout the system.
7. Check for leaks.
8. Shut off the engine.
9. Check the level of the fluid and add enough to raise the level to the full mark on the dipstick.

Important: Do not overfill the reservoir.

Replacing the Hydraulic Filter

Service Interval: Every 1,000 hours—If you are using the recommended hydraulic fluid, replace the hydraulic filter.

Every 800 hours—If you are not using the recommended hydraulic fluid or have ever filled the reservoir with an alternative fluid, replace the hydraulic filter.

The hydraulic system filter head is equipped with a service interval indicator. With the engine running, view the indicator—it should be in the green zone. When the indicator is in the red zone, change the filter element.

Use the Toro replacement filter (Part No. 94-2621).

Important: Use of any other filter may void the warranty on some components.

1. Park the machine on a level surface, lower the cutting units, shut off the engine, engage the parking brake, and remove the key.
2. Clean the area around the filter mounting area. Place a drain pan under the filter and remove the filter ([Figure 74](#)).




Figure 74

1. Hydraulic filter
2. Service interval indicator
3. Lubricate the new filter gasket and fill the filter with hydraulic fluid.
4. Ensure that the filter mounting area is clean. Screw the filter on until the gasket contacts the mounting plate. Then, tighten the filter 1/2 turn.
5. Start the engine and let it run for about 2 minutes to purge air from the system.
6. Shut off the engine and remove the key, and check for leaks.

Checking the Hydraulic Lines and Hoses

Service Interval: Before each use or daily

Check the hydraulic lines and hoses for leaks, kinked lines, loose mounting supports, wear, loose fittings, weather deterioration, and chemical deterioration. Make all necessary repairs before operating.

Using the Hydraulic System Test Ports

The test ports are used to test pressure in the hydraulic circuits. Contact your authorized Toro distributor for assistance.

1. Test Port A ([Figure 75](#)) is used to assist in troubleshooting the hydraulic circuit for the lift cylinders.




Figure 75

G007908




Figure 77

g000791

1. Test port A (lift cylinders)
2. Test Port B (Figure 76) is used to assist in troubleshooting the hydraulic circuit for the front cutting units.
3. Test Port C (Figure 76) is used to assist in troubleshooting the hydraulic circuit for the rear cutting units.




Figure 76

g005019

1. Test port B (front cutting units)
2. Test port C (rear cutting units)
4. Test Port D is located on the bottom of the hydrostatic transmission (Figure 77) and is used to measure the charge pressure of the transmission.
5. Test Port E is used to measure traction forward pressure (Figure 77).
6. Test Port F is used to measure traction reverse pressure (Figure 77).
7. Test Port G is used to measure steering circuit pressure (Figure 77).

Cutting Unit System Maintenance

Blade Safety

- A worn or damaged blade or bedknife can break, and a piece could be thrown toward you or bystanders, resulting in serious personal injury or death.
- Inspect the cutting units periodically for excessive wear or damage.
- Use care when checking the cutting units. Wrap the blades or wear gloves, and use caution when servicing the reels and bedknives. Only replace or sharpen the reels and bedknives; never straighten or weld them.
- On machines with multiple cutting units, take care when rotating a reel; it can cause the reels in the other cutting units to rotate.

Checking the Reel-to-Bedknife Contact


Service Interval: Before each use or daily

Check the reel-to-bedknife contact even if the quality of cut had been acceptable previously. There must be light contact across the full length of the reel and bedknife; refer to Adjusting Reel to Bedknife in the cutting unit operator's manual.

Backlapping the Cutting Units

Note: When backlapping, the front units all operate together, and the rear units operate together.

1. Park the machine on a level surface, lower the cutting units, shut off the engine, engage the parking brake, and move the Enable/Disable switch to disable position.
2. Unlock and raise the seat to expose the controls.
3. Locate the reel speed selector knobs and backlap knobs (Figure 78). Rotate the desired backlap knob(s) to the backlap position and the desired reel speed selector knob(s) to position 1.



g005018

Figure 78

1. Backlap knobs
2. Reel speed selector knobs

Note: Backlapping speed may be increased by moving the reel speed selector knob toward 13. Each position increases the speed approximately 100 rpm. After changing the selector, wait 30 seconds for the system to stabilize at the new speed.

4. Make initial reel to bedknife adjustments appropriate for backlapping on all cutting units which are to be backlapped.
5. Start the engine and run it at idle speed.
6. Select either front, rear, or both backlap knobs to determine which reels will be backlapped.
7. Move the Enable/Disable switch to the Enable position. Move the Lower Mow/Lift control forward to start the backlapping operation on the designated reels.
8. Apply lapping compound with a long-handled brush (Toro Part No. 29-9100). Never use a short-handled brush.
9. If the reels stall or become erratic while backlapping, stop backlapping by moving the Lower Mow/Lift control lever rearward. Once the reels have stopped, move the desired reel speed selector knob(s) one position closer to 13. Resume backlapping by moving the Lower Mow/Lift control lever forward.
10. To make an adjustment to the cutting units while backlapping, stop the cutting units by moving the Lower Mow/Raise lever rearward; move the Enable/Disable switch to Disable and shut off the engine. After adjustments have been completed, repeat steps 5 through 9.
11. When the cutting unit is adequately sharpened, a burr will form on the front edge of the knife.

Using a file, carefully remove the burr without dulling the cutting edge.

12. Repeat the procedure for all cutting units to be backlapped.

When you are finished with the backlap operation, return the backlap knobs to the forward flow position, lower the seat, and wash all lapping compound off the cutting units. Adjust the reel-to-bedknife contact as needed.

Note: If you do not return the backlap knobs to the forward flow position after backlapping, the cutting units will not raise or function properly.




Figure 79

1. Adjustment valve for #1 (front center) cutting unit
2. Adjustment valve for #4 and #5 (front wings) cutting units
3. Adjustment valves for #2 and #3 (rear) cutting units
4. Adjustment valve for #6 (rear left) cutting unit
5. Adjustment valve for #7 (rear right) cutting unit

3. Loosen the locking nuts on the valves.
4. Using a hex key, rotate the appropriate valve clockwise to slow down the drop rate of the cutting units.
5. Verify the lift rate adjustment by raising and lowering cutting units several times. Adjust it as required.
6. Tighten the locking nut to secure the adjustment.

Adjusting the Lifted Height of the Outer Front Cutting Units (Enable Position)

You can increase the turnaround height of the front outer cutting units (#4 and #5) and rear cutting units (#6 and #7) to provide additional ground clearance on contoured fairways.

Note: The RM CONFIG time delay should not be changed from the original setting of 0 when using this method to adjust the turnaround height.

To increase/adjust the turn around height of the cutting units proceed as follows:

1. Park the machine on a level surface, lower the cutting units, shut off the engine, engage the parking brake, and remove the key.
2. Loosen the carriage bolt nut securing the lift arm switch bracket to the #4, 6, or 7 lift arms (Figure 80).




Figure 80
#4 shown

1. Lift arm switch	3. Lift arm flag
2. Carriage bolt nut	

3. Move the lift switch bracket up in the slot to the desired position.
4. Set the distance between the lift arm switch and the flag on the lift arm to approximately 1.6 mm (0.062 inch).
5. Tighten carriage bolt nut.

Adjusting the Travel of the Front 3 Cutting Units

Additional downward travel of the front 3 cutting units may be desirable in highly contoured locations. If any of the front 3 cutting units lift off the ground when cresting a hill, you can lower the front carrier frame by removing the mounting bolts and positioning frame in the bottom set of holes in the main frame (Figure 81). Contact your authorized Toro distributor for assistance.

Note: Moving the carrier frame down decreases the amount of clearance between the cutting units and the ground in turnaround and transport positions and may require adjusting the lift chain length on the cutting unit.




Figure 81

1. Carrier frame mounting bolts

Storage

Storage Safety

- Shut off the engine, remove the key, wait for all movement to stop before you leave the operator's position. Allow the machine to cool before adjusting, servicing, cleaning, or storing it.
- Do not store the machine or fuel container where there is an open flame, spark, or pilot light, such as on a water heater or on other appliances.

5. Shut off the engine and remove the key.
6. Flush the fuel tank with fresh, clean fuel.
7. Secure all of the fuel-system fittings.
8. Thoroughly clean and service the air-cleaner assembly.
9. Seal the air-cleaner inlet and the exhaust outlet with weatherproof tape.
10. Check the antifreeze protection and add a 50/50 solution of water and ethylene glycol antifreeze as needed for the expected minimum temperature in your area.

Preparing the Traction Unit

1. Park the machine on a level surface, lower the cutting units, engage the parking brake, shut off the engine, and remove the key.
2. Thoroughly clean the traction unit, cutting units, and the engine.
3. Check the tire pressure; refer to [Checking the Tire Pressure \(page 40\)](#).
4. Check all fasteners for looseness; tighten them as necessary.
5. Grease or oil all grease fittings and pivot points. Wipe up any excess lubricant.
6. Lightly sand and use touch-up paint on painted areas that are scratched, chipped, or rusted. Repair any dents in the metal body.
7. Service the battery and cables as follows; refer to [Electrical System Safety \(page 39\)](#):
 - A. Remove the battery terminals from the battery posts.
 - B. Clean the battery, terminals, and posts with a wire brush and baking-soda solution.
 - C. Coat the cable terminals and battery posts with Grafo 112X skin-over grease (Toro Part No. 505-47) or petroleum jelly to prevent corrosion.
 - D. Slowly charge the battery every 60 days for 24 hours to prevent lead sulfation of the battery.

Preparing the Engine

1. Drain the engine oil from the oil pan and install the drain plug.
2. Remove and discard the oil filter. Install a new oil filter.
3. Fill the engine with specified motor oil.
4. Start the engine and run it at idle speed for approximately 2 minutes.

EEA/UK Privacy Notice

Toro's Use of Your Personal Information

The Toro Company ("Toro") respects your privacy. When you purchase our products, we may collect certain personal information about you, either directly from you or through your local Toro company or dealer. Toro uses this information to fulfil contractual obligations - such as to register your warranty, process your warranty claim or to contact you in the event of a product recall - and for legitimate business purposes - such as to gauge customer satisfaction, improve our products or provide you with product information which may be of interest. Toro may share your information with our subsidiaries, affiliates, dealers or other business partners in connection with these activities. We may also disclose personal information when required by law or in connection with the sale, purchase or merger of a business. We will never sell your personal information to any other company for marketing purposes.

Retention of your Personal Information

Toro will keep your personal information as long as it is relevant for the above purposes and in accordance with legal requirements. For more information about applicable retention periods please contact legal@toro.com.

Toro's Commitment to Security

Your personal information may be processed in the US or another country which may have less strict data protection laws than your country of residence. Whenever we transfer your information outside of your country of residence, we will take legally required steps to ensure that appropriate safeguards are in place to protect your information and to make sure it is treated securely.

Access and Correction

You may have the right to correct or review your personal data, or object to or restrict the processing of your data. To do so, please contact us by email at legal@toro.com. If you have concerns about the way in which Toro has handled your information, we encourage you to raise this directly with us. Please note that European residents have the right to complain to your Data Protection Authority.

California Proposition 65 Warning Information

What is this warning?

You may see a product for sale that has a warning label like the following:



What is Prop 65?

Prop 65 applies to any company operating in California, selling products in California, or manufacturing products that may be sold in or brought into California. It mandates that the Governor of California maintain and publish a list of chemicals known to cause cancer, birth defects, and/or other reproductive harm. The list, which is updated annually, includes hundreds of chemicals found in many everyday items. The purpose of Prop 65 is to inform the public about exposure to these chemicals.

Prop 65 does not ban the sale of products containing these chemicals but instead requires warnings on any product, product packaging, or literature with the product. Moreover, a Prop 65 warning does not mean that a product is in violation of any product safety standards or requirements. In fact, the California government has clarified that a Prop 65 warning “is not the same as a regulatory decision that a product is ‘safe’ or ‘unsafe.’” Many of these chemicals have been used in everyday products for years without documented harm. For more information, go to <https://oag.ca.gov/prop65/faqs-view-all>.

A Prop 65 warning means that a company has either (1) evaluated the exposure and has concluded that it exceeds the “no significant risk level”; or (2) has chosen to provide a warning based on its understanding about the presence of a listed chemical without attempting to evaluate the exposure.

Does this law apply everywhere?

Prop 65 warnings are required under California law only. These warnings are seen throughout California in a wide range of settings, including but not limited to restaurants, grocery stores, hotels, schools, and hospitals, and on a wide variety of products. Additionally, some online and mail order retailers provide Prop 65 warnings on their websites or in catalogs.

How do the California warnings compare to federal limits?

Prop 65 standards are often more stringent than federal and international standards. There are various substances that require a Prop 65 warning at levels that are far lower than federal action limits. For example, the Prop 65 standard for warnings for lead is 0.5 µg/day, which is well below the federal and international standards.

Why don't all similar products carry the warning?

- Products sold in California require Prop 65 labelling while similar products sold elsewhere do not.
- A company involved in a Prop 65 lawsuit reaching a settlement may be required to use Prop 65 warnings for its products, but other companies making similar products may have no such requirement.
- The enforcement of Prop 65 is inconsistent.
- Companies may elect not to provide warnings because they conclude that they are not required to do so under Prop 65; a lack of warnings for a product does not mean that the product is free of listed chemicals at similar levels.

Why does Toro include this warning?

Toro has chosen to provide consumers with as much information as possible so that they can make informed decisions about the products they buy and use. Toro provides warnings in certain cases based on its knowledge of the presence of one or more listed chemicals without evaluating the level of exposure, as not all the listed chemicals provide exposure limit requirements. While the exposure from Toro products may be negligible or well within the “no significant risk” range, out of an abundance of caution, Toro has elected to provide the Prop 65 warnings. Moreover, if Toro does not provide these warnings, it could be sued by the State of California or by private parties seeking to enforce Prop 65 and subject to substantial penalties.



The Toro Warranty

Two-Year or 1,500 Hours Limited Warranty

Conditions and Products Covered

The Toro Company and its affiliate, Toro Warranty Company, pursuant to an agreement between them, jointly warrant your Toro Commercial product ("Product") to be free from defects in materials or workmanship for 2 years or 1,500 operational hours*, whichever occurs first. This warranty is applicable to all products with the exception of Aerators (refer to separate warranty statements for these products). Where a warrantable condition exists, we will repair the Product at no cost to you including diagnostics, labor, parts, and transportation. This warranty begins on the date the Product is delivered to the original retail purchaser.

* Product equipped with an hour meter.

Instructions for Obtaining Warranty Service

You are responsible for notifying the Commercial Products Distributor or Authorized Commercial Products Dealer from whom you purchased the Product as soon as you believe a warrantable condition exists. If you need help locating a Commercial Products Distributor or Authorized Dealer, or if you have questions regarding your warranty rights or responsibilities, you may contact us at:

Toro Commercial Products Service Department

Toro Warranty Company

8111 Lyndale Avenue South

Bloomington, MN 55420-1196

952-888-8801 or 800-952-2740

E-mail: commercial.warranty@toro.com

Owner Responsibilities

As the product owner, you are responsible for required maintenance and adjustments stated in your *Operator's Manual*. Repairs for product issues caused by failure to perform required maintenance and adjustments are not covered under this warranty.

Items and Conditions Not Covered

Not all product failures or malfunctions that occur during the warranty period are defects in materials or workmanship. This warranty does not cover the following:

- Product failures which result from the use of non-Toro replacement parts, or from installation and use of add-on, or modified non-Toro branded accessories and products.
- Product failures which result from failure to perform recommended maintenance and/or adjustments.
- Product failures which result from operating the Product in an abusive, negligent, or reckless manner.
- Parts consumed through use that are not defective. Examples of parts which are consumed, or used up, during normal Product operation include, but are not limited to, brake pads and linings, clutch linings, blades, reels, rollers and bearings (sealed or greasable), bed knives, spark plugs, castor wheels and bearings, tires, filters, belts, and certain sprayer components such as diaphragms, nozzles, and check valves.
- Failures caused by outside influence, including, but not limited to, weather, storage practices, contamination, use of unapproved fuels, coolants, lubricants, additives, fertilizers, water, or chemicals.

Countries Other than the United States or Canada

Customers who have purchased Toro products exported from the United States or Canada should contact their Toro Distributor (Dealer) to obtain guarantee policies for your country, province, or state. If for any reason you are dissatisfied with your Distributor's service or have difficulty obtaining guarantee information, contact your Authorized Toro Service Center.

- Failure or performance issues due to the use of fuels (e.g. gasoline, diesel, or biodiesel) that do not conform to their respective industry standards.
- Normal noise, vibration, wear and tear, and deterioration. Normal "wear and tear" includes, but is not limited to, damage to seats due to wear or abrasion, worn painted surfaces, scratched decals or windows.

Parts

Parts scheduled for replacement as required maintenance are warranted for the period of time up to the scheduled replacement time for that part. Parts replaced under this warranty are covered for the duration of the original product warranty and become the property of Toro. Toro will make the final decision whether to repair any existing part or assembly or replace it. Toro may use remanufactured parts for warranty repairs.

Deep Cycle and Lithium-Ion Battery Warranty

Deep cycle and Lithium-Ion batteries have a specified total number of kilowatt-hours they can deliver during their lifetime. Operating, recharging, and maintenance techniques can extend or reduce total battery life. As the batteries in this product are consumed, the amount of useful work between charging intervals will slowly decrease until the battery is completely worn out. Replacement of worn out batteries, due to normal consumption, is the responsibility of the product owner. Note: (Lithium-Ion battery only): Pro-rated after 2 years. Refer to the battery warranty for additional information.

Maintenance is at Owner's Expense

Engine tune-up, lubrication, cleaning and polishing, replacement of filters, coolant, and completing recommended maintenance are some of the normal services Toro products require that are at the owner's expense.

General Conditions

Repair by an Authorized Toro Distributor or Dealer is your sole remedy under this warranty.

Neither The Toro Company nor Toro Warranty Company is liable for indirect, incidental or consequential damages in connection with the use of the Toro Products covered by this warranty, including any cost or expense of providing substitute equipment or service during reasonable periods of malfunction or non-use pending completion of repairs under this warranty. Except for the Emissions warranty referenced below, if applicable, there is no other express warranty. All implied warranties of merchantability and fitness for use are limited to the duration of this express warranty.

Some states do not allow exclusions of incidental or consequential damages, or limitations on how long an implied warranty lasts, so the above exclusions and limitations may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Note Regarding Emissions Warranty

The Emissions Control System on your Product may be covered by a separate warranty meeting requirements established by the U.S. Environmental Protection Agency (EPA) and/or the California Air Resources Board (CARB). The hour limitations set forth above do not apply to the Emissions Control System Warranty. Refer to the Engine Emission Control Warranty Statement supplied with your product or contained in the engine manufacturer's documentation.