



Count on it.

Form No. 3428-684 Rev A

Operator's Manual

8-Blade or 11-Blade DPA Cutting Unit

Reelmaster® 6000-D Series Traction Unit

Model No. 03698—Serial No. 403420001 and Up

Model No. 03699—Serial No. 403420001 and Up



This cutting unit is designed for cutting grass on well-maintained lawns in golf courses, parks, sports fields, and on commercial grounds. Using this product for purposes other than its intended use could prove dangerous to you and bystanders.

Visit www.Toro.com for product safety and operation training materials, accessory information, help finding a dealer, or to register your product.

Important: With your mobile device, you can scan the QR code on the serial number plate (if equipped) to access warranty, parts, and other product information.

Figure 1

1. Location of the model and serial numbers

Model No. _____	
Serial No. _____	

This manual identifies potential hazards and has safety messages identified by the safety-alert symbol (Figure 2), which signals a hazard that may cause serious injury or death if you do not follow the recommended precautions.



Figure 2
Safety-alert symbol

This manual uses 2 words to highlight information. **Important** calls attention to special mechanical information and **Note** emphasizes general information worthy of special attention.

Contents

Safety	3
General Safety	3
Cutting Unit Safety	3
Blade Safety	4
Safety and Instructional Decals	4
Setup	5
1 Removing the Tipper Assemblies	5
2 Mounting the Lift Brackets and Chains	6
3 Adjusting the Cutting Unit	7
4 Mounting the Counterweights	7
5 Installing the Cutting Units	8
Product Overview	10
Specifications	10
Attachments/Accessories	10
Operation	10
Adjusting the Cutting Unit	10
Adjusting the Height of Cut (HOC)	13
Height-of-Cut Chart Terms	16
Maintenance	18
Using the Kickstand When Tipping the Cutting Unit	18
Lubricating the Cutting Unit	18
Adjusting the Reel Bearings	18
Servicing the Bedknife	20
Servicing the Bedbar	21
Servicing the Roller	24

Safety

This machine has been designed in accordance with EN ISO 5395 and ANSI B71.4–2017.

General Safety

This product is capable of amputating hands and feet. Always follow all safety instructions to avoid serious personal injury.

- Read and understand the contents of this *Operator's Manual* before starting the machine.
- Use your full attention while operating the machine. Do not engage in any activity that causes distractions; otherwise, injury or property damage may occur.
- Do not put your hands or feet near moving components of the machine.
- Do not operate the machine without all guards and other safety protective devices in place and functioning properly on the machine.
- Keep clear of any discharge opening.
- Keep bystanders and children out of the operating area. Never allow children to operate the machine.
- Before you leave the operator's position, do the following:
 - Park the machine on a level surface.
 - Lower the cutting unit(s).
 - Disengage the drives.
 - Engage the parking brake (if equipped).
 - Shut off the engine and remove the key (if equipped).
 - Wait for all movement to stop.

Improperly using or maintaining this machine can result in injury. To reduce the potential for injury, comply with these safety instructions and always pay attention to the safety-alert symbol▲, which means Caution, Warning, or Danger—personal safety instruction. Failure to comply with these instructions may result in personal injury or death.

Cutting Unit Safety

- The cutting unit is only a complete machine when installed on a traction unit. Read the traction unit *Operator's Manual* carefully for complete instructions on the safe use of the machine.
- Stop the machine, remove the key (if equipped), and wait for all movement to stop before inspecting the attachment after striking an object or if there is an abnormal vibration in the machine. Make all necessary repairs before resuming operation.

- Keep all parts in good working condition and all hardware tightened. Replace all worn or damaged decals.
- Use only accessories, attachments, and replacement parts approved by Toro.
- Inspect the blade periodically for wear or damage.
- Use care when checking the blades. Wrap the blades or wear gloves, and use caution when servicing the blades. Only replace or sharpen the blades; never straighten or weld them.
- On multi-bladed machines, take care as rotating 1 blade can cause other blades to rotate.

Blade Safety

A worn or damaged blade can break, and a piece of the blade could be thrown toward you or bystanders, resulting in serious personal injury or death.

Safety and Instructional Decals



Safety decals and instructions are easily visible to the operator and are located near any area of potential danger. Replace any decal that is damaged or missing.



decal93-6688

93-6688

1. Warning—read the instructions before servicing or performing maintenance.
2. Cutting hazard of the hand or foot—shut off the engine and wait for moving parts to stop.

Setup

Loose Parts

Use the chart below to verify that all parts have been shipped.

Procedure	Description	Qty.	Use
1	No parts required	–	Remove the tipper assemblies.
2	Lift chain Chain bracket U-bolt Nut Screw Washer Nut	5/7 5/7 5/7 10/14 5/7 5/7 5/7	Mount the lift brackets and chains.
3	No parts required	–	Adjust the cutting unit
4	No parts required	–	Mount the counterweights.
5	Large O-ring Screw	5/7 2	Install the cutting units.

Media and Additional Parts

Description	Qty.	Use
Operator's Manual	1	Review the material and save it in an appropriate place.
Parts Catalog (not included)—refer to the included postcard for information on obtaining the Parts Catalog	–	

Note: Determine the left and right sides of the machine from the normal operating position.

1

Removing the Tipper Assemblies

No Parts Required

Procedure

Remove the tipper assemblies (if so equipped) from the number 1, number 2, and number 3 lift arms to avoid interference with the carrier frames of the cutting units.

1. Remove the locknut and the washer securing the pivot rod to the number 2 lift arm (Figure 3). Remove the pivot rod and spring from the

lift arm. Repeat the procedure on the number 1 and number 3 lift arms.




Figure 3

1. Pivot rod
2. Tipper support bracket w/roller

Note: The tipper bracket with the roller and the tipper support brackets are not required when operating the DPA cutting units (Figure 3).

- Disconnect the lift chains from the cutting units, if attached.

2

Mounting the Lift Brackets and Chains

Parts needed for this procedure:

5/7	Lift chain
5/7	Chain bracket
5/7	U-bolt
10/14	Nut
5/7	Screw
5/7	Washer
5/7	Nut

Procedure

Mount a chain bracket to each lift arm with a U-bolt and 2 nuts. Position the brackets as follows:

Note: Refer to [Figure 4](#) to determine the lift arm number being described.




Figure 4

- Cutting unit 1
 - Cutting unit 2
 - Cutting unit 3
 - Cutting unit 4
 - Cutting unit 5
 - Cutting unit 6
 - Cutting unit 7
 - Reel motor
 - Weight
- On lift arm numbers 1, 4, and 5, position the chain brackets and U-bolts 38.1 cm (15 inches) behind the center line of the pivot knuckle ([Figure 5](#)).
 - On lift arm numbers 1 and 5 the brackets should be rotated to the right 10 degrees from vertical ([Figure 5](#)).
 - On lift arm number 4 the bracket should be rotated to the left 10 degrees from vertical ([Figure 5](#)).




Figure 5

- Lift arm number 5 = 38.1 cm (15 inches)
- Lift arm number 4 = 10 degrees
- Lift arm numbers 1 and 5 = 10 degrees

- On lift arm numbers 2 and 3, position the brackets and U-bolts 38.1 cm (15 inches) behind the center line of the pivot knuckle ([Figure 6](#)).

Note: Rotate the brackets 45 degrees to the outboard side of the machine.




Figure 6

- Lift arm number 2 = 38.1 cm (15 inches)
- Lift arm number 3 = 45 degrees

5. On lift arm number 6 and number 7, position the brackets and U-bolts 36.8 cm (14.5 inches) behind the center line of the pivot knuckle ([Figure 7](#)).

Note: Rotate the brackets 10 degrees to the outboard side of the machine.




Figure 7

1. Lift arm number 6 = 36.8 cm (14.5 inches)
2. Lift arm number 7 = 10 degrees

6. Tighten all the U-bolt nuts to 52 to 65 N·m (38 to 48 ft-lb).
7. Mount a lift chain to each chain bracket with a screw, a washer, and a nut, positioning them as shown in [Figure 8](#).




Figure 8

1. Lift chain
2. Chain bracket

3

Adjusting the Cutting Unit

No Parts Required

Procedure

1. Adjust the bedknife to the reel.
2. Adjust the rear roller for your height-of-cut requirements.
3. Set the height of cut.
4. Adjust the rear shield if necessary.

Refer to [Adjusting the Cutting Unit \(page 10\)](#) for complete instructions for performing these adjustments

4

Mounting the Counterweights

No Parts Required

Procedure

All cutting units are shipped with the counterweight mounted to the left end of the cutting unit. Use the following diagram to determine the position of the counterweights and reel motors.

Note: Some traction units have only 5 cutting units.




Figure 9

1. Cutting unit 1
2. Cutting unit 2
3. Cutting unit 3
4. Cutting unit 4
5. Cutting unit 5
6. Cutting unit 6
7. Cutting unit 7
8. Reel motor
9. Weight

1. On cutting unit numbers 2, 4, and 6, remove the 2 cap screws securing the counterweight to the left end of the cutting unit.

Note: Remove the counterweight (Figure 10).




Figure 10

1. Counterweight

2. On the right end of the cutting unit, remove the plastic plug from the bearing housing (Figure 11).
3. Remove the 2 cap screws from the right side plate (Figure 11).




Figure 11

1. Plastic plug
2. Cap screw (2)

4. Install the counterweight to the right end of the cutting unit with the 2 screws previously removed.
5. Loosely install the 2 reel motor mounting cap screws to the left side plate of the cutting unit (Figure 11).

5

Installing the Cutting Units

Parts needed for this procedure:

5/7	Large O-ring
2	Screw

Procedure

1. Insert a thrust washer onto the horizontal shaft of the pivot knuckle as shown in Figure 12.




Figure 12

1. Carrier frame
2. Pivot knuckle
3. Lift-arm steering plate
4. Lynch pin
5. Steering locking pin

2. Insert the horizontal shaft of the pivot knuckle into the mounting tube of the carrier frame (Figure 12).
3. Secure pivot knuckle to carrier frame with a thrust washer, a flat washer, and a flange-head cap screw (Figure 12).
4. Insert a thrust washer onto the vertical shaft of the pivot knuckle (Figure 12).
5. If removed, insert the vertical shaft of the pivot knuckle into the lift-arm pivot hub (Figure 12).
6. Guide the pivot knuckle in place between the 2 rubber centering bumpers in the underside of the lift-arm steering plate.
7. Insert the lynch pin into the cross hole on the pivot-knuckle shaft (Figure 12).
8. Secure the lift arm chain to the cutting unit chain bracket (Figure 13) with the snapper pin as follows:

- On cutting unit numbers 1, 4, 5, 6, and 7, use only 6 of the chain links.
- On cutting unit numbers 2 and 3, use all 7 of the chain links.




Figure 13

1. Lift chain
2. Snapper pin




Figure 14

1. Reel motor
2. Cap screw

Note: If a fixed cutting unit position is required, insert the steering locking pin into the pivot knuckle mounting hole (Figure 12).

9. Coat the spline of the reel motor with clean grease.
10. Oil the reel motor O-ring and install it onto the motor flange.
11. Install the motor by rotating it clockwise so that the motor flanges clear the cap screws (Figure 14).
12. Rotate the motor counterclockwise until the flanges encircle the cap screws and then tighten the cap screws.

13. Hook the spring wire around the bottom of the steering locking pin (Figure 12).

Important: Make sure that the reel motor hoses are not twisted, kinked, or at risk of being pinched.

Product Overview

Specifications

Cutting Unit	Weight
8 blade	67 kg (147 lb)
11 blade	69 kg (151 lb)

Attachments/Accessories

A selection of Toro approved attachments and accessories is available for use with the machine to enhance and expand its capabilities. Contact your Authorized Service Dealer or authorized Toro distributor or go to www.Toro.com for a list of all approved attachments and accessories.

To ensure optimum performance and continued safety certification of the machine, use only genuine Toro replacement parts and accessories. Replacement parts and accessories made by other manufacturers could be dangerous, and such use could void the product warranty.

Operation

Note: Determine the left and right sides of the machine from the normal operating position.

Adjusting the Cutting Unit

Adjusting the Rear Shield

Under most conditions, best dispersion is attained when the rear shield is closed (front discharge). When conditions are heavy or wet, the rear shield may be opened.

To open the rear shield ([Figure 15](#)), loosen the cap screw securing the shield to the left side plate, rotate the shield to the open position, and tighten the cap screw.




Figure 15

1. Rear shield

2. Cap screw

Checking the Cutting Unit

The dual knob bedknife-to-reel adjustment system incorporated in this cutting unit simplifies the adjustment procedure needed to deliver optimum mowing performance. The precise adjustment possible with the dual knob/bedbar design gives the necessary control to provide a continual self-sharpening action—thus maintaining sharp cutting edges, ensuring good quality of cut, and greatly reducing the need for routine backlapping.

Prior to mowing each day, or as required, check each cutting unit to verify proper bedknife-to-reel contact.

This must be performed regardless of whether the quality of cut is acceptable.

1. Lower the cutting units onto a hard surface, shut off the engine, and remove the ignition key.
2. Slowly rotate the reel in a reverse direction, listening for reel-to-bedknife contact. If no contact is evident, turn the bedknife adjusting knobs clockwise, 1 click at a time, until you feel and hear light contact.

Note: The reel must cut one sheet of paper, when inserted at a right angle to the bedknife, at both ends and the center of the reel.

Note: The adjustment knobs have detents corresponding to 0.023 mm (0.0009 inch) bedknife movement for each indexed position.

3. If excessive contact/reel drag is evident, either backlap, reface the front of the bedknife, or grind the cutting unit to achieve the sharp edges needed for precision cutting; refer to the *Toro Manual for Sharpening Reel and Rotary Mowers*, Form No. 09168SL.

Important: Light contact is preferred at all times. If light contact is not maintained, the bedknife/reel edges will not sufficiently self-sharpen and dull cutting edges will result after a period of operation. If excessive contact is maintained, bedknife/reel wear will be accelerated, uneven wear can result, and quality of cut may be adversely affected.

Note: As the reel blades continue to run against the bedknife, a slight burr will appear on the front cutting edge surface along the full length of the bedknife. To improve the cutting performance, occasionally run a file across the front edge to remove this burr.

After extended running, a ridge will eventually develop at both ends of the bedknife. You must round off these notches or file them flush with the cutting edge of the bedknife to ensure smooth operation.

Note: Over time, the chamfer (Figure 16) will need to be ground as it is only designed to last 40% of the bedknife life.




Figure 16

1. Lead-in chamfer on right end of bedknife
2. 6 mm (0.25 inch)
3. 1.5 mm (0.060 inch)

Note: Do not make lead-in chamfer too large as it may cause turf tufting.

Adjusting the Bedknife to the Reel

Use this procedure to set the bedknife to the reel and to check the condition of the reel and bedknife and their interaction. After completing this procedure, always test the cutting unit performance under your field conditions. You may need to make further adjustments to obtain optimal cutting performance.

Important: Do not overtighten the bedknife to the reel or you will damage it.

- After backlapping the cutting unit or grinding the reel, you may need to mow with the cutting unit for a few minutes and then perform this procedure to adjust the bedknife to the reel as the reel and bedknife adjust to each other.
- You may need additional adjustments if the turf is extremely dense or your cutting height is very low.

You will need the following tools to complete this procedure:

- Shim, 0.05 mm (0.002 inch)—Part No. 125-5611
 - Cutting performance paper—Part No. 125-5610
1. Position the cutting unit on a flat, level work surface. Turn the bedbar-adjusting screws counterclockwise to ensure that the bedbar does not contact the reel (Figure 17).




Figure 17

1. Bedbar-adjusting screw

2. Tip the mower to expose the bedknife and the reel; refer to [Using the Kickstand When Tipping the Cutting Unit](#) (page 18).
3. Rotate the reel so that a blade crosses the bedknife approximately 25 mm (1 inch) in from the end of the bedknife on the right hand side of the cutting unit. Putting an identifying mark on this blade makes subsequent adjustments easier. Insert the 0.05 mm (0.002 inch) shim between the marked reel blade and the bedknife at the point where the blade crosses the bedknife.

4. Turn the right bedbar adjuster clockwise until you feel **light** pressure (i.e., drag) on the shim, then back off the bedbar adjuster 2 clicks and remove the shim.

Note: Because adjusting 1 side of the cutting unit affects the other side, the 2 clicks provide clearance for when the other side is adjusted.

Note: If starting with a large gap, both sides should initially be drawn closer by alternately tightening the right and left sides.

5. **Slowly** rotate the reel so that the same blade that you checked on the right side is crossing the bedknife approximately 25 mm (1 inch) in from the end of the bedknife on the left side of the cutting unit.
6. Turn the left bedbar adjuster clockwise until the shim can be slid through the reel to bedknife gap with light drag.
7. Return to the right side and adjust as necessary to get light drag on the shim between the same blade and bedknife.
8. Repeat steps 6 and 7 until the shim can be slid through both gaps with slight drag, but 1 click in on each side prevents the shim from passing through on both sides. The bedknife is now parallel to the reel.

Note: This procedure should not be needed on daily adjustments, but should be done after grinding or disassembly.

9. From this position (i.e., 1 click in and shim not passing through) turn the bedbar adjusters clockwise 1 click each.

Note: Each click turned moves the bedknife 0.022 (0.0009 inches). **Do not overtighten the adjusting screws.**

10. Test the cutting performance by inserting a long strip of cutting performance paper (Toro part number 125-5610) between reel and bedknife, perpendicular to the bedknife ([Figure 18](#)). **Slowly** rotate the reel forward; it should cut the paper.




Figure 18

Note: If excessive reel drag occurs either backlap or grind the cutting unit to achieve the sharp edges needed for precision cutting.

Adjusting the Rear Roller

1. Adjust the rear roller brackets ([Figure 19](#)) to the desired height-of-cut range by positioning the required amount of spacers below the side-plate mounting flange ([Figure 19](#)) per the HOC Chart.




Figure 19

1. Spacer
2. Roller bracket
3. Side-plate mounting flange

2. Raise the rear of the cutting unit and place a block under the bedknife.
3. Remove the 2 nuts securing each roller bracket and spacer to each side-plate mounting flange.
4. Lower the roller and screws from the side-plate mounting flanges and spacers.
5. Place the spacers onto the screws on the roller brackets.
6. Secure the roller bracket and spacers to the underside of the side-plate mounting flanges with the nuts previously removed.
7. Verify that the bedknife-to-reel contact is correct. Tip the mower to expose the front and rear rollers and the bedknife.

Note: The position of the rear roller to the reel is controlled by the machining tolerances of the assembled components and paralleling is not required. A limited amount of adjustment is possible by setting the cutting unit on a surface plate and loosening the side-plate mounting cap screws (Figure 20).




Figure 20

1. Side-plate mounting cap screws

8. Adjust and tighten the cap screws and torque the cap screws to 27 to 36 N·m (240 to 320 in-lb).

Adjusting the Turf-Compensation Settings

The turf-compensation spring transfers the weight from the front to the rear roller. This helps to reduce a wave pattern in the turf, also known as marcelling or bobbing.

Important: Make spring adjustments with the cutting unit mounted to the traction unit, pointing straight ahead and lowered to the shop floor.

1. Make sure that the hairpin cotter is installed in the rear hole in the spring rod (Figure 21).




Figure 21

1. Turf-compensation spring
2. Hairpin cotter
3. Spring rod
4. Hex nuts

2. Tighten the hex nuts on the front end of the spring rod until the compressed length of the spring is 15.9 cm (6.25 inches); refer to Figure 21.

Note: When operating on rough terrain decrease the spring length by 12.7 mm (0.5 inch). Ground following will be slightly shorter.

Note: You must reset the turf-compensation setting if the HOC setting or the aggressiveness-of-cut setting is changed.

Adjusting the Height of Cut (HOC)

Note: For heights of cut greater than 2.54 cm (1.00 inch) install the High Height-of-Cut Kit.

1. Loosen the locknuts securing the height-of-cut arms to the cutting-unit side plates (Figure 22).




Figure 22

1. Adjusting screw
2. Locknut
3. Height-of-cut arm

- Loosen the nut on the gauge bar (Figure 23) and set the adjusting screw to the desired height of cut.




Figure 23

- | | |
|---------------------------|---------------------------------------|
| 1. Gauge bar | 4. Holes used for setting Groomer HOC |
| 2. Height-adjusting screw | 5. Hole not used |
| 3. Nut | |

- Measure the distance between the bottom of the screw head and the face of the bar to get the height of cut.
- Hook the screw head on the cutting edge of the bedknife and rest the rear end of the bar on the rear roller (Figure 24).
- Rotate the adjusting screw until the front roller contacts the gauge bar (Figure 24). Adjust both ends of roller until the entire roller is parallel to the bedknife.




Figure 24

- Tighten the nuts to secure the adjustment.

Note: Do not overtighten the nuts. Tighten them just enough to remove play from the washer.

Important: When set properly, the rear and front rollers will contact the gauge bar and the screw will be snug against the bedknife. This ensures that the height of cut is identical at both ends of the bedknife.

Height-of-Cut Chart

HOC Setting	Aggressiveness of Cut	No. of Rear Spacers	With Groomer Kits Installed
0.64 cm (0.250 inches)	Less	0	Y
	Normal	0	Y
	More	1	-
0.95 cm (0.375 inches)	Less	0	Y
	Normal	1	Y
	More	2	-
1.27 cm (0.500 inches)	Less	0	Y
	Normal	1	Y
	More	2	Y
1.56 cm (0.625 inches)	Less	1	Y
	Normal	2	Y
	More	3	-
1.91 cm (0.750 inches)	Less	2	Y
	Normal	3	Y
	More	4	-
2.22 cm (0.875 inches)	Less	2	Y
	Normal	3	Y
	More	4	-
2.54 cm (1.000 inches)	Less	3	Y
	Normal	4	Y
	More	5	-
2.86 cm (1.125 inches)	Less	4	-
	Normal	5	-
	More	6	-
3.18 cm (1.250 inches)*+	Less	4	-
	Normal	5	-
	More	6	-
3.49 cm (1.375 inches)*+	Less	4	-
	Normal	5	-
	More	6	-
3.81 cm (1.500 inches)*+	Less	5	-
	Normal	6	-
	More	7	-
4.13 cm (1.625 inches)*+	Less	6	-
	Normal	7	-
	More	8	-
4.44 cm (1.750 inches)*+	Less	6	-
	Normal	7	-
	More	8	-
4.76 cm (1.875 inches)*+	Less	7	-
	Normal	8	-
	More	9	-
5.08 cm (2.000 inches)*+	Less	7	-
	Normal	8	-
	More	9	-

* The High HOC Kit (Part No. 110-9600) must be installed. Front HOC bracket must be positioned in the top side-plate hole.

+ When the Height of Cut is above 2.54 cm (1 inch) and a rear roller brush is used, the High Height-of-Cut Brush is required and the optional Steering Cylinder, Part No. 105-9275 should be installed to prevent contact between the rear tire and the brush when making extreme turns.

Use the following chart to determine which bedknife is best suited for the desired height of cut.

Bedknife/Height of Cut Chart			
Bedknife	Part No.	Bedknife Lip Height	Height of Cut
Low HOC (Optional)	110-4084	5.6 mm (0.220 inch)	6.4 to 12.7 mm (0.250 to 0.500 inch)
EdgeMax® Low HOC (Optional)	137-0832	5.6 mm (0.220 inch)	6.4 to 12.7 mm (0.250 to 0.500 inch)
Extended Low HOC (Optional)	120-1640	5.6 mm (0.220 inch)	6.4 to 12.7 mm (0.250 to 0.500 inch)
Extended EdgeMax® Low HOC (Optional)	119-4280	5.6 mm (0.220 inch)	6.4 to 12.7 mm (0.250 to 0.500 inch)
EdgeMax® (Models 03698 and 03699)	137-0833	6.9 mm (0.270 inch)	9.5 to 38.1 mm (0.375 to 1.50 inches)*
Standard (Optional)	108-9096	6.9 mm (0.270 inch)	9.5 to 38.1 mm (0.375 to 1.50 inches)*
Heavy Duty (Optional)	110-4074	9.3 mm (0.370 inch)	12.7 to 38.1 mm (0.500 to 1.50 inches)

* Warm-season grasses may require the Low HOC bedknife for 12.7 mm (0.500 inch) and below.




Figure 25

1. Bedknife lip height

Aggressiveness of Cut

Aggressiveness of cut has a significant impact on the performance of the cutting unit. Aggressiveness of cut refers to the angle of the bedknife relative to the ground (Figure 26).

The best cutting unit setup is dependent on your turf conditions and desired results. Experience with the cutting unit on your turf will determine the best setting to use. Aggressiveness of cut may be adjusted throughout the cutting season to allow for various turf conditions.

In general, less to normal aggressive settings are more appropriate for warm-season grasses (Bermuda, paspalum, zoysia) while cool-season grasses (bent, bluegrass, rye) may require normal to more aggressive setups. More aggressive setups cut more grass off by allowing the spinning reel to pull more grass up into the bedknife.

Height-of-Cut Chart Terms

Height-of-Cut Setting (HOC)

This corresponds to the desired height of cut.

Bench-Set Height of Cut

This is the height at which the top edge of the bedknife is set above a flat level surface that contacts the bottom of both the front and rear rollers.

Effective Height of Cut

This is the actual height that the grass has been cut. For a given bench set height of cut, the actual height of cut will vary depending on the type of grass, time of year, turf, and soil conditions. The cutting unit setup (aggressiveness of cut, rollers, bedknives, attachments installed, turf compensation settings, etc.) will also affect the effective height of cut. Check the effective height of cut using the Turf Evaluator (Model 04399) regularly to determine the desired bench set height of cut.




Figure 26

- 1. Rear spacers
- 2. Side-plate mounting flange
- 3. Aggressiveness of cut

Rear Spacers

The number of rear spacers determines the aggressiveness of cut for the cutting unit. For a given height of cut, adding spacers, below the side-plate mounting flange, increases the aggressiveness of the cutting unit. All cutting units on a given machine must be set to the same aggressiveness of cut (number of rear spacers, Part No. 119-0626), otherwise the after-cut appearance could be negatively affected ([Figure 26](#)).

Groomer

These are the recommended height-of-cut settings when a groomer kit is installed on the cutting unit.

Maintenance

Using the Kickstand When Tipping the Cutting Unit

Whenever you have to tip the cutting unit to expose the bedknife and the reel, prop up the rear of the cutting unit with the kickstand (supplied with the traction unit) to make sure that the nuts on the back end of the bedbar adjusting screws are not resting on the work surface ([Figure 27](#)).




Figure 27

1. Kickstand

Lubricating the Cutting Unit

Each cutting unit has 6 grease fittings ([Figure 28](#)) that must be lubricated regularly with No. 2 lithium grease.

The lubrication points include the front roller (2), the rear roller (2), and the reel bearing (2).

1. Wipe each grease fitting with a clean rag.
2. Apply grease until clean grease comes out of the roller seals and the bearing relief valve.
3. Wipe any excess grease away.




Figure 28

1. Relief valve

Adjusting the Reel Bearings

To ensure long life of the reel bearings, periodically check if reel end play exists. You can check and adjust the reel bearings as follows:

1. Loosen the reel-to-bedknife contact by turning the bedknife adjusting knobs ([Figure 29](#)) counterclockwise until no contact exists.




Figure 29

1. Bedknife-adjuster knob
2. Using a rag or a thickly padded glove, hold on to the reel blade and try to move the reel assembly side to side ([Figure 30](#)).




Figure 30

g020697

3. If end play exists, proceed as follows:

- A. Loosen the external setscrew securing the bearing adjuster nut to bearing housing located on the left side of the cutting unit (Figure 31).




Figure 31

g003332

1. Setscrew
2. Adjuster nut

- B. Using a 1-3/8 inch socket wrench, slowly tighten the reel-bearing adjustment nut until no end play of the reel exists. If adjusting the nut does not eliminate reel end play, replace the reel bearings.

Note: The reel bearings do not require preload. Overtightening the reel-bearing adjuster nut will damage the reel bearings.

4. Tighten the setscrew securing the bearing adjuster nut to the bearing housing.

Note: Torque the nut to 1.4 to 1.7 N·m (12 to 15 in-lb).

Servicing the Bedknife

The bedknife service limits are listed in the following chart.

Important: Operating the cutting unit with the bedknife below the service limit may result in poor after-cut appearance and reduce the structural integrity of the bedknife for impacts.

Bedknife Service Limit Chart				
Bedknife	Part	Bedknife Lip Height*	Service Limit*	Grind Angles Top/Front Angles
EdgeMax® Low HOC (Optional)	137-0832	5.6 mm (0.220 inch)	6.4 to 12.7 mm (0.250 to 0.500 inch)	10/5 degrees
Low HOC (Optional)	110-4084	5.6 mm (0.220 inch)	4.8 mm (0.190 inch)	10/5 degrees
Extended EdgeMax® Low HOC (Optional)	119-4280	5.6 mm (0.220 inch)	4.8 mm (0.190 inch)	10/10 degrees
Extended Low HOC (Optional)	120-1640	5.6 mm (0.220 inch)	4.8 mm (0.190 inch)	10/10 degrees
EdgeMax® (Models 03698 and 03699)	137-0833	6.9 mm (0.270 inch)	4.8 mm (0.190 inch)	10/5 degrees
Standard (Optional)	108-9096	6.9 mm (0.270 inch)	4.8 mm (0.190 inch)	10/5 degrees
Heavy Duty (Optional)	110-4074	9.3 mm (0.370 inch)	4.8 mm (0.190 inch)	10/5 degrees




Figure 32

Recommended Top and Front Bedknife Grind Angles

1. Bedknife service limit*
2. Top grind angle
3. Front grind angle




Figure 33

Note: All bedknife service limit measurements relate to the bottom of the bedknife (Figure 33).

Checking the Top Grind Angle

The angle that you use to grind your bedknives is very important.

Use the angle indicator (Toro Part No. 131-6828) and the angle-indicator mount (Toro Part No. 131-6829) to check the angle that your grinder produces and then correct for any grinder inaccuracy.

1. Place the angle indicator on the bottom side of the bedknife as shown in [Figure 34](#).




Figure 34

1. Bedknife (vertical)
 2. Angle indicator
-
2. Press the Alt Zero button on the angle indicator.
 3. Place the angle-indicator mount on the edge of the bedknife so that the edge of the magnet is mated with the edge of the bedknife ([Figure 35](#)).

Note: The digital display should be visible from the same side during this step as it was in step 1.




Figure 35

1. Angle-indicator mount
2. Edge of the magnet mated with the edge of the bedknife
3. Bedknife
4. Angle indicator

-
4. Place the angle indicator on the mount as shown in [Figure 35](#).

Note: This is the angle that your grinder produces; it should be within 2 degrees of the recommended top grind angle.

Servicing the Bedbar

Removing the Bedbar

1. Turn the bedbar-adjusting screws counterclockwise to back the bedknife away from the reel ([Figure 36](#)).




Figure 36

1. Bedbar-adjusting screw
2. Spring-tension nut
3. Bedbar
4. Washer

-
2. Back out the spring-tension nut until the washer is no longer tensioned against the bedbar ([Figure 36](#)).
 3. On each side of the machine, loosen the locknut securing the bedbar bolt ([Figure 37](#)).




Figure 37

1. Bedbar bolt
2. Locknut

-
4. Remove each bedbar bolt, allowing the bedbar to be pulled downward and removed from the machine bolt ([Figure 37](#)). Account for 2 nylon washers and 1 stamped steel washer on each end of the bedbar ([Figure 38](#)).




Figure 38

- | | |
|----------------|-----------------|
| 1. Bedbar bolt | 3. Steel washer |
| 2. Nut | 4. Nylon washer |

Assembling the Bedbar

1. Install the bedbar, positioning the mounting ears between the washer and the bedbar adjuster.
2. Secure the bedbar to each side plate with the bedbar bolts (nuts on bolts) and 6 washers.

Note: Position a nylon washer on each side of side-plate boss. Place a steel washer outside each of the nylon washers (Figure 38).

3. Torque the bedbar bolts to 27 to 36 N·m (240 to 320 in-lb).

Note: Tighten the locknuts until the outside steel washer stops rotating and end play is removed, but do not overtighten or deflect the side plates. The washers on the inside may have a gap.

4. Tighten the spring-tension nut until the spring is collapsed, then back off 1/2 turn (Figure 39).




Figure 39

- | | |
|-----------------------|-----------|
| 1. Spring-tension nut | 2. Spring |
|-----------------------|-----------|

Installing the Bedknife

1. Remove the rust, scale, and corrosion from the bedbar surface and apply a thin layer of oil to the bedbar surface.
2. Clean the screw threads.
3. Apply anti-seize compound to the screws and install the bedknife to the bedbar as follows (Figure 40):




Figure 40

- | | |
|-------------|----------|
| 1. Bedbar | 3. Screw |
| 2. Bedknife | |

- A. Torque the 2 outer screws to 1 N·m (10 in-lb); refer to Figure 40.
- B. Working from the center of the bedknife, torque the screws to 23 to 28 N·m (200 to 250 in-lb); refer to Figure 40.




Figure 41

1. Bedknife screw tool
 2. Install and torque these first to 1 N·m (10 in-lb).
 3. Torque to 23 to 28 N·m (200 to 250 in-lb).
-
4. Grind the bedknife.

Servicing the Roller

The Roller Rebuild Kit (Part No. 114-5430) and the Roller Rebuild Tool Kit (Part No. 115-0803) (Figure 42) are available for servicing the roller. The Roller Rebuild Kit includes all the bearings, bearing nuts,

inner seals, and outer seals to rebuild a roller. The Roller Rebuild Tool Kit includes all the tools and the installation instructions required to rebuild a roller with the roller rebuild kit. Refer to your parts catalog or contact your authorized Toro distributor for assistance.




Figure 42

- | | |
|--|----------------------------|
| 1. Roller Rebuild Kit (Part No. 114-5430) | 6. Bearing nut |
| 2. Roller Rebuild Tool kit (Part No. 115-0803) | 7. Inner seal tool |
| 3. Inner seal | 8. Washer |
| 4. Bearing | 9. Bearing/outer-seal tool |
| 5. Outer seal | |

Notes:

Declaration of Incorporation

The Toro Company, 8111 Lyndale Ave. South, Bloomington, MN, USA declares that the following unit(s) conform(s) to the directives listed, when installed in accordance with the accompanying instructions onto certain Toro models as indicated on the relevant Declarations of Conformity.

Model No.	Serial No.	Product Description	Invoice Description	General Description	Directive
03698	403420001 and Up	8-blade DPA Cutting Unit for Reelmaster 6000 Series Traction Unit	7" 8 BLADE DPA (RADIAL) CU-RM6500/6700	Cutting Unit	2000/14/EC 2006/42/EC
03699	403420001 and Up	11-blade DPA Cutting Unit for Reelmaster 6000 Series Traction Unit	7" 11 BLADE DPA (RADIAL) CU-RM6500/6700	Cutting Unit	2000/14/EC 2006/42/EC

Relevant technical documentation has been compiled as required per Part B of Annex VII of 2006/42/EC.

We will undertake to transmit, in response to requests by national authorities, relevant information on this partly completed machinery. The method of transmission shall be electronic transmittal.

This machinery shall not be put into service until incorporated into approved Toro models as indicated on the associated Declaration of Conformity and in accordance with all instructions, whereby it can be declared in conformity with all relevant Directives.

Certified:



John Heckel
Sr. Engineering Manager
8111 Lyndale Ave. South
Bloomington, MN 55420, USA
December 26, 2018

Authorized Representative:

Marcel Dutrieux
Manager European Product Integrity
Toro Europe NV
Nijverheidsstraat 5
2260 Oevel
Belgium

Tel. +32 16 386 659

EEA/UK Privacy Notice

Toro's Use of Your Personal Information

The Toro Company ("Toro") respects your privacy. When you purchase our products, we may collect certain personal information about you, either directly from you or through your local Toro company or dealer. Toro uses this information to fulfil contractual obligations - such as to register your warranty, process your warranty claim or to contact you in the event of a product recall - and for legitimate business purposes - such as to gauge customer satisfaction, improve our products or provide you with product information which may be of interest. Toro may share your information with our subsidiaries, affiliates, dealers or other business partners in connection these activities. We may also disclose personal information when required by law or in connection with the sale, purchase or merger of a business. We will never sell your personal information to any other company for marketing purposes.

Retention of your Personal Information

Toro will keep your personal information as long as it is relevant for the above purposes and in accordance with legal requirements. For more information about applicable retention periods please contact legal@toro.com.

Toro's Commitment to Security

Your personal information may be processed in the US or another country which may have less strict data protection laws than your country of residence. Whenever we transfer your information outside of your country of residence, we will take legally required steps to ensure that appropriate safeguards are in place to protect your information and to make sure it is treated securely.

Access and Correction

You may have the right to correct or review your personal data, or object to or restrict the processing of your data. To do so, please contact us by email at legal@toro.com. If you have concerns about the way in which Toro has handled your information, we encourage you to raise this directly with us. Please note that European residents have the right to complain to your Data Protection Authority.



The Toro Warranty

Two-Year or 1,500 Hours Limited Warranty

Conditions and Products Covered

The Toro Company and its affiliate, Toro Warranty Company, pursuant to an agreement between them, jointly warrant your Toro Commercial product ("Product") to be free from defects in materials or workmanship for 2 years or 1,500 operational hours*, whichever occurs first. This warranty is applicable to all products with the exception of Aerators (refer to separate warranty statements for these products). Where a warrantable condition exists, we will repair the Product at no cost to you including diagnostics, labor, parts, and transportation. This warranty begins on the date the Product is delivered to the original retail purchaser.

* Product equipped with an hour meter.

Instructions for Obtaining Warranty Service

You are responsible for notifying the Commercial Products Distributor or Authorized Commercial Products Dealer from whom you purchased the Product as soon as you believe a warrantable condition exists. If you need help locating a Commercial Products Distributor or Authorized Dealer, or if you have questions regarding your warranty rights or responsibilities, you may contact us at:

Toro Commercial Products Service Department
Toro Warranty Company
8111 Lyndale Avenue South
Bloomington, MN 55420-1196

952-888-8801 or 800-952-2740
E-mail: commercial.warranty@toro.com

Owner Responsibilities

As the product owner, you are responsible for required maintenance and adjustments stated in your *Operator's Manual*. Repairs for product issues caused by failure to perform required maintenance and adjustments are not covered under this warranty.

Items and Conditions Not Covered

Not all product failures or malfunctions that occur during the warranty period are defects in materials or workmanship. This warranty does not cover the following:

- Product failures which result from the use of non-Toro replacement parts, or from installation and use of add-on, or modified non-Toro branded accessories and products.
- Product failures which result from failure to perform recommended maintenance and/or adjustments.
- Product failures which result from operating the Product in an abusive, negligent, or reckless manner.
- Parts consumed through use that are not defective. Examples of parts which are consumed, or used up, during normal Product operation include, but are not limited to, brake pads and linings, clutch linings, blades, reels, rollers and bearings (sealed or greasable), bed knives, spark plugs, castor wheels and bearings, tires, filters, belts, and certain sprayer components such as diaphragms, nozzles, and check valves.
- Failures caused by outside influence, including, but not limited to, weather, storage practices, contamination, use of unapproved fuels, coolants, lubricants, additives, fertilizers, water, or chemicals.
- Failure or performance issues due to the use of fuels (e.g. gasoline, diesel, or biodiesel) that do not conform to their respective industry standards.
- Normal noise, vibration, wear and tear, and deterioration. Normal "wear and tear" includes, but is not limited to, damage to seats due to wear or abrasion, worn painted surfaces, scratched decals or windows.

Countries Other than the United States or Canada

Customers who have purchased Toro products exported from the United States or Canada should contact their Toro Distributor (Dealer) to obtain guarantee policies for your country, province, or state. If for any reason you are dissatisfied with your Distributor's service or have difficulty obtaining guarantee information, contact your Authorized Toro Service Center.

Parts

Parts scheduled for replacement as required maintenance are warranted for the period of time up to the scheduled replacement time for that part. Parts replaced under this warranty are covered for the duration of the original product warranty and become the property of Toro. Toro will make the final decision whether to repair any existing part or assembly or replace it. Toro may use remanufactured parts for warranty repairs.

Deep Cycle and Lithium-Ion Battery Warranty

Deep cycle and Lithium-Ion batteries have a specified total number of kilowatt-hours they can deliver during their lifetime. Operating, recharging, and maintenance techniques can extend or reduce total battery life. As the batteries in this product are consumed, the amount of useful work between charging intervals will slowly decrease until the battery is completely worn out. Replacement of worn out batteries, due to normal consumption, is the responsibility of the product owner. Note: (Lithium-Ion battery only): Pro-rated after 2 years. Refer to the battery warranty for additional information.

Lifetime Crankshaft Warranty (ProStripe 02657 Model Only)

The ProStripe which is fitted with a genuine Toro Friction Disc and Crank-Safe Blade Brake Clutch (integrated Blade Brake Clutch (BBC) + Friction Disc assembly) as original equipment and used by the original purchaser in accordance with recommended operating and maintenance procedures, are covered by a Lifetime Warranty against engine crankshaft bending. Machines fitted with friction washers, Blade Brake Clutch (BBC) units and other such devices are not covered by the Lifetime Crankshaft Warranty.

Maintenance is at Owner's Expense

Engine tune-up, lubrication, cleaning and polishing, replacement of filters, coolant, and completing recommended maintenance are some of the normal services Toro products require that are at the owner's expense.

General Conditions

Repair by an Authorized Toro Distributor or Dealer is your sole remedy under this warranty.

Neither The Toro Company nor Toro Warranty Company is liable for indirect, incidental or consequential damages in connection with the use of the Toro Products covered by this warranty, including any cost or expense of providing substitute equipment or service during reasonable periods of malfunction or non-use pending completion of repairs under this warranty. Except for the Emissions warranty referenced below, if applicable, there is no other express warranty. All implied warranties of merchantability and fitness for use are limited to the duration of this express warranty.

Some states do not allow exclusions of incidental or consequential damages, or limitations on how long an implied warranty lasts, so the above exclusions and limitations may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Note Regarding Emissions Warranty

The Emissions Control System on your Product may be covered by a separate warranty meeting requirements established by the U.S. Environmental Protection Agency (EPA) and/or the California Air Resources Board (CARB). The hour limitations set forth above do not apply to the Emissions Control System Warranty. Refer to the Engine Emission Control Warranty Statement supplied with your product or contained in the engine manufacturer's documentation.