




Count on it.

Operator's Manual

4050 Directional Drill

Model No. 23898—Serial No. 31500001 and Up

Model No. 23899—Serial No. 31500001 and Up



It is a violation of California Public Resource Code Section 4442 or 4443 to use or operate the engine on any forest-covered, brush-covered, or grass-covered land unless the engine is equipped with a spark arrester, as defined in Section 4442, maintained in effective working order or the engine is constructed, equipped, and maintained for the prevention of fire.

⚠ WARNING

**CALIFORNIA
Proposition 65 Warning**

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.

Use of this product may cause exposure to chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.

Introduction

This machine is a directional drill intended for underground drilling and pullback operation for utility lines including: electrical, gas, communication, water, etc. It is designed to operate a wide variety of attachments each of which perform a specialized function. This machine is to be used in temperatures of 17 to 37°C (0 to 100°F). Using this product for purposes other than its intended use could prove dangerous to you and bystanders.

Read this information carefully to learn how to operate and maintain your product properly and to avoid injury and product damage. You are responsible for operating the product properly and safely.

Visit www.Toro.com for product safety and operation training materials, accessory information, help finding a dealer, or to register your product.

Whenever you need service, genuine Toro parts, or additional information, contact an Authorized Service Dealer or Toro Customer Service and have the model and serial numbers of your product ready. [Figure 1](#) identifies the location of the model and serial numbers on the product. Write the numbers in the space provided.

The enclosed engine owner's manual is supplied for information regarding the US Environmental Protection Agency (EPA) and the California Emission Control Regulation of emission systems, maintenance,

and warranty. Replacements may be ordered through the engine manufacturer.

With your mobile device, you can scan the QR code (if equipped) on the serial number plate to access warranty, parts, and other product information.




Figure 1

1. Model and serial number location

Model No. _____
Serial No. _____

This manual identifies potential hazards and has safety messages identified by the safety alert symbol ([Figure 2](#)), which signals a hazard that may cause serious injury or death if you do not follow the recommended precautions.



Figure 2

1. Safety alert symbol

This manual uses 2 words to highlight information. **Important** calls attention to special mechanical information and **Note** emphasizes general information worthy of special attention.

Contents

Safety	4	Replacing the Pipe Holder	69
General Safety	4	Maintenance	70
Tramming Safety	5	Recommended Maintenance Schedule(s)	70
Drilling Safety	6	Pre-Maintenance Procedures	72
Safety and Instructional Decals	8	Pre-Maintenance Safety	72
Product Overview	23	Opening the Front Hood	72
Controls	26	Opening the Rear-Access Door	72
Control Panel	27	Using the Cylinder Lock	73
4-Button Joysticks	28	Lubrication	74
7 or 8-Button Joysticks	30	Greasing the Machine	74
Rear Control Panel	33	Engine Maintenance	76
Drill Frame and Stabilizer Controls	34	Engine Safety	76
Drive Pendant	34	Cleaning the Crankcase-Vent Tube	76
Drill Pendant	35	Servicing the Air-Cleaning System	76
Stake-Down Levers	37	Servicing the Engine Oil and Filter	79
Specifications	37	Adjusting the Valve Clearance	81
Before Operation	38	Fuel System Maintenance	81
Before Operation Safety	38	Draining Water from the Fuel Filter	81
Understanding Horizontal Directional		Draining Water from the Fuel Tank	82
Drilling	38	Priming the Fuel System	82
Gathering Site Information	39	Replacing the Fuel Filters	83
Planning the Bore Path	42	Checking the Fuel Lines and Connections	
Preparing the Job Site and the Machine		84
.....	47	Draining and Cleaning the Fuel Tank	84
Marking and Preparing the Bore Path	47	Electrical System Maintenance	84
Checking the Safety-Interlock Switches	47	Battery Safety	84
Testing the Zap-Alert System	48	Servicing the Battery	84
Mounting a Fire Extinguisher	49	Charging the Battery	85
Loading Drill Pipes into the Pipe Holder		Jump-Starting the Machine	86
.....	50	Drive System Maintenance	87
Filling the Fuel Tank	51	Checking the Oil Level for the Stakedown	
Performing Daily Maintenance	52	Planetary Drive	87
Starting and Stopping the Engine	52	Checking the Oil Level for the Tracks	
Driving the Machine	52	Planetary Drive	87
Loading and Unloading the Machine	52	Changing the Oil for the Tracks Planetary	
Setting up the Machine for Drilling	53	Drive	88
Deploying the Zap-Alert System	54	Checking the Oil Level for the Rotary Motor	
Lowering the Stakes	55	Planetary Drive	89
Connecting to a Drilling-Fluid Source	56	Checking the Oil for the Thrust Motor	
Positioning the Cab (Model with Cab		Planetary Drive	89
only)	57	Checking the Oil for the Gearbox Drive	
Opening the Door (Model with Cab		90
only)	58	Changing the Oil for the Gearbox	
Operating the Air Conditioning and Heating		Drive	90
(Model with Cab only)	58	Servicing the Tracks	91
Operating the Windshield Wipers (Model		Cooling System Maintenance	92
with Cab only)	59	Cooling System Safety	93
During Operation	59	Checking the Coolant Level in the	
During Operation Safety	59	Radiator	93
Drilling the Bore	60	Checking the Condition of Cooling-System	
Backreaming and Pullback	64	Components	94
After Operation	66	Checking the Concentration of the	
After Operation Safety	66	Coolant	94
Finishing the Job	66	Cleaning the Cooling System	94
Using the TJC Applicator	67	Belt Maintenance	97
Moving a Disabled Machine	68	Servicing the Engine-Drive Belt	97
		Hydraulic System Maintenance	98
		Hydraulic System Safety	98

Safety

Important: This machine was manufactured according to the appropriate regulatory standards. Modifying this machine in any way may cause it to be out of compliance with those standards and with the instructions in this *Operator's Manual*. Modifications to this machine should only be made by only the manufacturer or an Authorized Service Dealer.

Important: Before operating in an area with high-voltage lines or cables, contact a "One-Call System Directory" service. In the USA, call 811 or your local utility company. If you do not know your local utility company's phone number, call the national number (USA and Canada only) at 1-888-258-0808. In Australia, call 1100 for the nationwide marking service. Also, contact any utility companies that are not participants of the "One-Call System Directory" service. Please refer to [Drilling Near Utility Lines \(page 6\)](#) for more information.

General Safety

This product is capable of causing personal injury. Always follow all safety instructions to avoid serious personal injury.

- Read and understand the contents of this *Operator's Manual* before starting the engine.
- Use your full attention while operating the machine. Do not engage in any activity that causes distractions; otherwise, injury or property damage may occur.
- Do not put your hands or feet near moving components of the machine.
- Do not operate the machine without all guards and other safety protective devices in place and functioning properly on the machine.
- Keep bystanders and children out of the operating area. Never allow children to operate the machine.
- Shut off the machine, turn off the battery-disconnect switch, and wait for all movement to stop before you leave the operator's position. Allow the machine to cool before adjusting, servicing, cleaning, or storing it.

Improperly using or maintaining this machine can result in injury. To reduce the potential for injury, comply with these safety instructions and always pay attention to the safety-alert symbol, which means Caution, Warning, or Danger—personal safety instruction. Failure to comply with these instructions may result in personal injury or death.

Servicing the Hydraulic Fluid	98
Drilling-Fluid Pump Maintenance	102
Servicing the Drilling-Fluid-Pump Oil	102
Preparing the Drilling-Fluid System for Cold Weather	104
Cab Maintenance	106
Changing the Cab Air Filter	106
Filling the Windshield-Washer Fluid Tank	106
Cleaning	107
Cleaning with the Spray-Hose Attachment.....	107
Cleaning Plastic and Resin Parts	107
Storage	108
Troubleshooting	109
Index	112

Tramming Safety

You move the machine to and from the work site with the use of a travel pendant. When tramming (moving the machine with the pendant), observe the following safety precautions:

- Operate the travel pendant alongside the machine outside of the danger zone (Figure 3).
- Keep all bystanders away while tramming the machine.
- Do not carry passengers on the machine.
- Watch for the turning-radius sweep of the drill frame, as the center of the turning radius is the end of the track.

- Move slowly when using the pendant for tramming.
- Use care when loading or unloading the machine onto a trailer.
- Watch for traffic when crossing roadways.
- Check for overhead clearances (i.e., doorways, branches, electrical wires) before tramming under any objects and do not contact them.
- When tramming on a slope, you should be uphill from the machine.

Use the following illustration to ensure that bystanders do not enter the danger zone while you are tramming the machine.




Figure 3
Driving Danger Zone

- | | |
|---------------------------------|--------------------------------|
| 1. 1.8 m (6 ft) safety distance | 3. Turning-radius center |
| 2. Operator | 4. 3 m (10 ft) safety distance |

Drilling Safety

- Always lower the pipe loading guard before drilling (Figure 4).
- Always engage the exit side lockout before operating.
- Keep bystanders and children out of the operating area.
- Stop operating the machine if anyone enters the drilling danger zone.
- Ensure that no one approaches a pipe while it is spinning.

Drilling Danger Zone

The danger zone is the area within and around the machine where a person is exposed to the risk of injury.

The danger zone defines the amount of space needed for safe drilling operation, including movement of the carriage.

Use the following illustration to ensure that bystanders and children do not enter the danger zone while you are drilling.




Figure 4
Drilling Danger Zone

- 1. 3 m (10 ft) safety distance
- 2. Pedestrian safety bar

- 3. 1.8 m (6 ft) safety distance

Drilling Near Utility Lines

Important: Before operating in an area with high-voltage lines or cables, contact a “One-Call System Directory” service. In the USA, call 811 or your local utility company. If you do not know your local utility company’s phone number, call the national number (USA and Canada only) at 1-888-258-0808. Also, contact any utility companies that are not participants of the “One-Call System Directory” service.

Utility Line Color

Refer to the following table for the proper utility line and the corresponding utility line color (USA and Canada).

Utility Line	Utility Line Color
Electric	Red
Telecommunication, alarm or signal, cables, or conduit	Orange
Natural gas, oil, steam, petroleum, or other gaseous or flammable material	Yellow
Sewer and drain	Green
Drinking water	Blue

Reclaimed water, irrigation, and slurry lines	Purple
Temporary survey markings	Pink
Proposed excavation limits	White

Electrical and Communication Line Safety

⚠ WARNING

If you leave the seat of the machine or touch any part of the machine when it is charged with electricity, serious injury or death could result.

Do not leave the seat of the machine if the machine is charged with electricity.

⚠ CAUTION

If you damage the fiber-optic cable and look into the exposed highly-intense light, you may harm your eyes.

- Shut off the machine and turn off the battery-disconnect switch.
- Remove all individuals from the work area.
- Immediately contact the proper emergency and utility authorities to secure the area.

In the event of an electric strike that charges the machine, the Zap-Alert alarm system will sound for as long as the machine is charged with power.

Note: Immediately contact the proper emergency and utility authorities to secure the area in case the machine is charged and you cannot leave the seat of the machine.

Note: It is possible to strike a utility line without the machine becoming charged.

- The alarm will sound if the drill contacts an electrical power source.
- Do not attempt to leave the machine.

Note: You will be safe as long as you do not leave the seat of the machine.

- Touching any part of the machine may ground you.
- Do not allow another individual to touch or approach the machine when charged.
- The alarm may sound if a communication line is broken, but until you are certain, you must consider the alarm to be an electric strike.

Gas Line Safety

⚠ WARNING

If you damage a gas line, an immediate explosion and fire hazard could occur. Leaking gas is both flammable and explosive and may cause serious injury or death.

- Do not smoke while operating the machine.
- Shut off the machine and remove the key.
- Remove all individuals from the work area.
- Immediately contact the proper emergency and utility authorities to secure the area.

Water Line Safety

If you damage a water line, a potential flood hazard could occur.

- Shut off the machine and remove the key.
- Remove all individuals from the work area.
- Immediately contact the proper emergency and utility authorities to secure the area.

Safety and Instructional Decals



Safety decals and instructions are easily visible to the operator and are located near any area of potential danger. Replace any decal that is damaged or missing.




Battery Symbols

Some or all of these symbols are on your battery

- | | |
|--|--|
| 1. Explosion hazard | 6. Keep bystanders a safe distance from the battery. |
| 2. No fire, open flame, or smoking. | 7. Wear eye protection; explosive gases can cause blindness and other injuries |
| 3. Caustic liquid/chemical burn hazard | 8. Battery acid can cause blindness or severe burns. |
| 4. Wear eye protection | 9. Flush eyes immediately with water and get medical help fast. |
| 5. Read the <i>Operator's Manual</i> . | 10. Contains lead; do not discard. |




117-2718




125-1621

1. Press the operator presence switch to enable machine movement.




125-1622

1. Pull up to start the engine.
2. Push down to shut off the engine.



125-1641

- | | |
|-----------------|-------------------|
| 1. Forward left | 6. Forward right |
| 2. Increase rpm | 7. High |
| 3. Engine speed | 8. Track speed |
| 4. Decrease rpm | 9. Low |
| 5. Reverse left | 10. Reverse right |



125-1623

decal125-1623

- | | |
|--|---|
| <ol style="list-style-type: none"> 1. Forward left track/forward rotary 2. Reverse left track/reverse rotary 3. Drilling fluid pump on 4. Forward right track/forward carriage 5. Reverse right track/reverse carriage 6. Tighten lower wrench (stationary wrench) 7. Loosen lower wrench (stationary wrench) 8. Tighten upper wrench (makeup/breakout wrench) 9. Loosen upper wrench 10. Wrench breakout (for upper wrench) | <ol style="list-style-type: none"> 11. Wrench makeup (for upper wrench) 12. Raise pipe elevator 13. Lower pipe elevator 14. Reverse cam rotation 15. Forward (toward operator) cam rotation 16. Tighten pipe grip 17. Loosen pipe grip 18. Reverse drill spindle 19. Forward (toward operator) drill spindle |
|--|---|



125-6107

decal125-6107


1. Crushing hazard of hand and foot—keep hands and feet away.



125-6109

decal125-6109

1. Electrical shock hazard—when the Zap-Alert system is activated, do not leave the operator's position or touch the ground and the machine at the same time.



125-6108

decal125-6108


1. Thrown object hazard—read the *Operator's Manual*.



125-6110

decal125-6110


1. Crushing hazard—do not stand under any part of the machine.



125-6111
decal125-6111

125-6111

- | | |
|--------------------------------|--------------------------------|
| 1. Stake up | 6. Stake up |
| 2. Stake down | 7. Stake spin counterclockwise |
| 3. Stake spin counterclockwise | 8. Stake down |
| 4. Stake spin clockwise | 9. Stake spin clockwise |
| 5. Left stake | 10. Right stake |



125-6115
decal125-6115

125-6115


- Crushing hazard—deploy cylinder locks before performing maintenance.



125-6114
decal125-6114

125-6114

- Stored energy hazard—do not use tools; read the *Operator's Manual*.



125-6113
decal125-6113

125-6113


- | | |
|--|---|
| 1. Warning—read the <i>Operator's Manual</i> . | 4. Warning—stay away from moving parts; keep all guards and shields in place. |
| 2. Warning—all operators should be trained before operating the machine. | 5. Warning—wear hearing protection. |
| 3. Warning—keep bystanders away. | 6. Explosion hazard; electrical shock hazard—do not dig; call your local utility company. |



125-6116

decal125-6116

1. Falling hazard—do not move the machine when someone is in the operator's position.



125-6118

decal125-6118


1. Crushing hazard, machine movement—read the *Operator's Manual*.



125-6117

decal125-6117


1. Falling hazard—do not stand on the machine while it is moving.



125-6119

decal125-6119


1. Entanglement hazard—stay away from moving objects.



125-6124

decal125-6124


1. Center the pipe joint between the upper and lower wrenches.



125-6120

decal125-6120


1. Lower drill carriage
2. Raise drill carriage
3. Raise left stabilizer
4. Lower left stabilizer
5. Raise right stabilizer
6. Lower right stabilizer



125-6123

decal125-6123


1. Load pipes from the back row first.



125-6125

decal125-6125

1. Warning—read the *Operator's Manual*.
2. Explosion hazard; electrical shock hazard—do not dig before calling local services.
3. Press to apply thread-joint compound.
4. Press and hold for maximum drilling fluid pressure; release to stop the flow.
5. Press to turn the drilling-fluid pump on or off.
6. Press and hold to move the drill carriage at high speed up or down the drill frame.
7. Mode I—spin drill spindle clockwise. Mode II—left trigger pressed, open the lower wrench (stationary wrench); left trigger released, raise the pipe elevator.
8. Mode I—spin drill spindle counterclockwise. Mode II—left trigger pressed, close the lower wrench (stationary wrench); left trigger released, lower the pipe elevator.
9. Thrust the drill carriage forward.
10. Pull the drill carriage rearward.



138-7085

decal138-7085


- | | |
|---|---|
| 1. Warning—read the <i>Operator's Manual</i> . | 9. Rotate the drill spindle clockwise (drill mode I) |
| 2. Explosion hazard; electrical shock hazard—do not dig; call your local utility company. | 10. Rotate the drill spindle counter clockwise (drill mode I) |
| 3. Drilling-fluid pump—On/Off | 11. Cruise Control—set/release |
| 4. Drilling fluid—increase | 12. Carriage thrust speed—high |
| 5. Drilling fluid—decrease | 13. Drilling-fluid flow—high |
| 6. Upper wrench—open/close | 14. Thrust the carriage forward. |
| 7. Lower wrench—open/close | 15. Pull the carriage back. |
| 8. Rotate the wrench clockwise and counter clockwise (make and break rotation) | |



125-6126

decal125-6126


1. Entanglement hazard—stay away from moving parts.



125-6127

decal125-6127


1. Cutting/dismemberment hazard, fan—stay away from moving parts.



125-6128

decal125-6128


1. High pressure fluid hazard, injection into the body—read the *Operator's Manual* before performing maintenance.



125-6129

decal125-6129

1. Hot surface—stay away from hot surfaces.



125-6135

decal125-6135



125-6131


decal125-6131

1. Warning—stay away from the area shown (at least 3 m or 10 ft away) while in operation.



125-6137


decal125-6137



125-6130

decal125-6130


1. Warning—read the *Operator's Manual*; stay away from the area shown (at least 3 m or 10 ft away from the front and rear of the machine and 1.8 m or 6 ft away from the side of the machine) while in operation.



125-6139

decal125-6139


1. Lift point and tie-down point



125-6140

decal125-6140


1. Rotate the chair.



125-6141

decal125-6141


- | | |
|-------------------------|-----------------------------|
| 1. Engine—heating light | 4. Engine—start |
| 2. Engine—stop | 5. Drill-pendant receptacle |
| 3. Engine—run | 6. Drive-pendant receptacle |



125-6142

decal125-6142


1. Exit-side lockout—reset light
2. Exit-side lockout—drill-enabled light
3. Transmitter-battery-status light
4. Engine—start
5. Press down to shut off the engine; pull up to start the engine.
6. Reset Zap-Alert system
7. Zap-Alert system triggered
8. Unlock exit-side lockout
9. Reset exit-side lockout
10. Engage drive movement and setup functions
11. Engage drill carriage movement and other drill functions
12. Work lights—On
13. Work lights
14. Work lights—Off
15. Press and hold to increase the engine speed.
16. Engine speed
17. Press and hold to decrease the engine speed.
18. Mode I—with the left trigger released, extend the pipe gripper toward the drill frame; with the left trigger pressed, open the lower wrench (stationary wrench). Mode II—spin the drill spindle clockwise.
19. Mode I—with the left trigger released, extend the pipe gripper toward the pipe holder; with the left trigger pressed, close the lower wrench (stationary wrench). Mode II—spin the drill spindle counterclockwise.
20. Mode I—with the left trigger released, lower the pipe elevator; with the left trigger pressed, open the upper wrench (makeup/breakout wrench). Mode II—with the left trigger released, extend the pipe gripper toward the drill frame; with the left trigger pressed, open the upper wrench (makeup/breakout wrench).
21. Mode I—with the left trigger released, raise the pipe elevator; with the left trigger pressed, close the upper wrench (makeup/breakout wrench). Mode II—with the left trigger released, extend the pipe gripper toward the pipe holder; with the left trigger pressed, close the upper wrench (makeup/breakout wrench).
22. With the trigger released, rock forward to rotate the basket toward the pipe cam,; rock backwards to rotate the basket toward the drill frame.
23. With the trigger released, the upper button closes the pipe gripper; the lower button opens the pipe gripper.
24. With the trigger pressed, rock forward to rotate the upper wrench (makeup/breakout wrench) counterclockwise to loosen a joint; rock backwards to rotate the upper wrench (makeup/breakout wrench) clockwise to tighten a joint.
25. With the trigger pressed, press the front or rear button to resume the previously set auto-drill speed; press and hold the front button to increase the auto-drill speed; press and hold the rear button to decrease the auto-drill speed.



138-7084

decal138-7084

- | | |
|--|--|
| 1. Exit-side lockout—reset light | 15. Rotate the cam forward or backward (drill mode II). |
| 2. Press down to shut off the engine. | 16. Rotate the cam forward or backward (drill mode I). |
| 3. Pull up to start the engine. | 17. Move to the next or previous step in SmartTouch™ mode. |
| 4. Rotate the drill spindle counter clockwise (drill mode II). | 18. Retract the pipe gripper arm. |
| 5. Exit-side lockout—drill-enabled light | 19. Extend the pipe gripper arm. |
| 6. Reset Zap-Alert system | 20. Apply thread-joint compound. |
| 7. Zap-Alert system triggered | 21. Engine—start |
| 8. Rotate the drill spindle clockwise (drill mode II). | 22. Engage drive movement and setup functions |
| 9. Transmitter-battery-status light | 23. Engage drill carriage movement and other drill functions |
| 10. Unlock exit-side lockout | 24. Work lights—On |
| 11. Reset exit-side lockout | 25. Work lights—Off |
| 12. Raise the pipe elevator. | 26. Press and hold to increase the engine speed. |
| 13. Lower the pipe elevator. | 27. Press and hold to decrease the engine speed. |
| 14. Tighten or loosen the pipe grip. | |



125-6151

decal125-6151


1. Do not exceed loads of 2,268 kg (5,000 lb).



125-6152

decal125-6152


1. Move the seat forward and backwards.



125-6179

decal125-6179


1. Warning—stay away from the area shown (at least 3 m or 10 ft away) while in operation.



125-6157

decal125-6157

1. Disconnect the battery power.
 2. Off/Stop
 3. On/Start
 4. Read the *Operator's Manual*.
-



decal138-7086

138-7086


- | | |
|---|--|
| 1. Engine—start | 16. Zap-Alert system triggered |
| 2. Raise the pipe elevator. | 17. Unlock exit-side lockout |
| 3. Lower the pipe elevator. | 18. Reset exit-side lockout |
| 4. Tighten or loosen the pipe grip. | 19. Exit-side lockout—unlock/reset light |
| 5. Rotate the cam forward or backward (drill mode II). | 20. Engage drive movement and setup functions |
| 6. Rotate the cam forward or backward (drill mode I). | 21. Engage drill carriage movement and other drill functions |
| 7. Move to the next or previous step in SmartTouch™ mode. | 22. Exit-side lockout—drill-enabled light |
| 8. Retract the pipe gripper arm. | 23. Transmitter-battery-status light |
| 9. Apply thread-joint compound. | 24. Work light—On |
| 10. Extend the pipe gripper arm. | 25. Work light—Off |
| 11. Press down to shut off the engine. | 26. Engine speed—Fast |
| 12. Pull up to start the engine. | 27. Engine speed—Slow |
| 13. Rotate the drill spindle counter clockwise (drill mode II). | 28. Swing the cab in or out. |
| 14. Rotate the drill spindle clockwise (drill mode II). | 29. Rotate the cab clockwise or counterclockwise. |
| 15. Reset Zap-Alert system | 30. Windshield-wiper control |



125-6180

decal125-6180


1. Entanglement hazard—stay away from moving parts.



125-6183

decal125-6183

1. Press the operator presence switch to enable machine movement.



125-6694

decal125-6694


1. Tie down location



125-8473

decal125-8473

1. Explosion hazard—wear eye protection.
2. Caustic liquid/chemical burn hazard—rinse affected area and seek medical assistance.
3. Fire hazard—keep open flames away.
4. Poison hazard—do not tamper with the battery.



125-8483

decal125-8483

1. Hydraulic fluid; read the *Operator's Manual*.

Product Overview




Figure 5

- | | |
|---------------------|---------------------|
| 1. Drill carriage | 6. Rear hood |
| 2. Zap-alert strobe | 7. Rear-access door |
| 3. Cab | 8. Right stabilizer |
| 4. Monitor | 9. Front hood |
| 5. Thrust frame | 10. Track |




Figure 6

- 1. Pipe holder
- 2. Pedestrian safety bar
- 3. Stake-down plate
- 4. Left stabilizer
- 5. Rear-control panel
- 6. Drilling-fluid-pump inlet




Figure 7

- 1. Drill carriage
- 2. Drill spindle
- 3. Thrust frame
- 4. Pipe wiper
- 5. Cab
- 6. Upper wrench (makeup/breakout wrench)
- 7. Lower wrench (stationary wrench)

Controls

Refer to the following sections for the appropriate machine controls:

- The Software Guide for this machine.
- Operator Platform
- Control Panel
- Left Joystick
- Right Joystick
- Exit-Side Lockout System
- Rear Control Panel
- Drill Frame and Stabilizer Controls
- Drive Pendant
- Drill Pendant
- Stake-Down Levers
- Battery-Disconnect Switch

Operator Platform

The operator platform, located on the right, front corner of the machine, contains most of the controls that you use to operate the drilling functions of the machine.




Figure 8

1. Operator display
2. Left control panel and joystick
3. Right joystick

Operator-Controls Covers

The covers protect the operator controls from adverse weather conditions, such as rain, wind, sunlight, etc. Remove them before using the machine and replace them before leaving the machine for the day. Each cover is secured with 2 screws as shown in [Figure 9](#).




Figure 9

1. Screws
2. Covers

Operator-Platform Latch

The operator platform swings out away from the machine, making room for you to sit. It has 4 positions: travel (swung all the way into the machine), full-out, and 2 intermediate positions. Return the platform to the TRAVEL position before moving the machine.

To release the platform and swing it out or in, press down on the rear platform latch ([Figure 10](#)).




Figure 10

1. Rear platform latch

To release the platform and swing it out or in, press on the front platform latch ([Figure 11](#)).




Figure 11

1. Front platform latch

Control Panel




Figure 12

- | | |
|--|-----------------------------------|
| 1. Engine-stop button | 6. Ground-strike-reset switch |
| 2. Exit-side lockout—reset light | 7. Exit-side-lockout—reset switch |
| 3. Exit-side lockout—drill-enabled light | 8. Drive/drill switch |
| 4. Receiver-battery-status light | 9. Lights switch |
| 5. Engine-start button | 10. Engine-speed switch |

Exit-Side Lockout—Reset Light

This light (Figure 12) illuminates yellow when the exit-side lockout function is turned off on exit-side-lockout transmitter, indicating that you may reset the system.

Exit-Side Lockout—Drill-enabled Light

This light (Figure 12) illuminates green when the exit-side-lockout feature has been turned off and reset and the machine is ready to drill.

Exit-Side Lockout—Reset Switch

Press this switch (Figure 12) to enable drilling operation when the reset light illuminates.

Transmitter-Battery-Status Light

This light (Figure 12) illuminates red when the battery on the exit-side-lockout transmitter is too low to transmit. Stop drilling operations and fix the problem with the transmitter before continuing.

Engine-Start Button

Press this button (Figure 12) to start the engine. The key switch on the rear, control panel must be in the ON position.

Engine-Stop Button

Press this button (Figure 12) to immediately stop the engine and all drilling operations. You must pull this button out before you can start the engine again.

Ground-Strike-Reset Switch

Press this switch (Figure 12) to reset the Zap-Alert system after a ground strike has occurred and been fixed; refer to [Deploying the Zap-Alert System \(page 54\)](#).

Drive/Drill Switch

Press the top of this switch (Figure 12) to enable the drive and setup controls or the bottom to enable drill and pipe-loader functions.

Lights Switch

Press the top of this switch (Figure 12) to turn the machine lights on or the bottom of this switch to turn them off.

Engine-Speed Switch

- Press and hold the top of this switch to increase the engine speed.
- Press and hold the bottom of this switch to decrease the engine speed.
- Release the switch to maintain the current engine speed.

4-Button Joysticks

Left Joystick

Note: The joystick controls vary depending on the control mode you select. There are 2 control modes: Mode I and Mode II; refer to the *Software Guide* for this machine to set the control mode.




Figure 13

- | | |
|---------------------------|-----------------|
| 1. Joystick—move left | 6. Front button |
| 2. Joystick—move forward | 7. Rear button |
| 3. Joystick—move rearward | 8. Lower button |
| 4. Joystick—move right | 9. Trigger |
| 5. Toggle switch | |

Trigger

The trigger changes the other joystick controls from pipe-loader controls to wrench-operation controls.

	Mode I	Mode II
Forward	<ul style="list-style-type: none"> Left trigger pressed—closes the lower wrench (stationary wrench). Left trigger released—retracts the pipe gripper toward the pipe holder. 	Push the joystick forward to spin the drill spindle counterclockwise.
Rearward	<ul style="list-style-type: none"> Left trigger pressed—opens the lower wrench (stationary wrench). Left trigger released—extends the pipe gripper toward the pipe holder. 	Pull the joystick rearward to spin the drill spindle clockwise.
Left	<ul style="list-style-type: none"> Left trigger pressed—opens the upper wrench (makeup/breakout wrench). Left trigger released—lowers the pipe elevator. 	<ul style="list-style-type: none"> Left trigger pressed—opens the upper wrench (makeup/breakout wrench). Left trigger released—extends the pipe gripper toward the drill frame.
Right	<ul style="list-style-type: none"> Left trigger pressed—closes the upper wrench (makeup/breakout wrench). Left trigger released—raises the pipe elevator. 	<ul style="list-style-type: none"> Left trigger pressed—closes the upper wrench (makeup/breakout wrench). Left trigger released—retracts the pipe gripper toward the pipe holder.

- Press the trigger to enable the wrench controls.
- Release the trigger to enable the pipe-loader controls.

Toggle Switch

- Left trigger pressed—rock the switch forward to rotate the upper wrench (makeup/breakout wrench) clockwise to loosen a joint; rock the switch rearward to rotate the upper wrench (makeup/breakout wrench) counterclockwise to tighten a joint.
- Left trigger released—rock the switch forward to rotate the pipe cam out toward the basket; rock the switch rearward to rotate the pipe cam toward the drill frame.

Front Button

- Left trigger pressed—press this button to resume the previously set auto-drill speed. Press and hold this button to increase the auto-drill speed.
- Left trigger released—press this button to close the pipe gripper.

Rear Button

- Left trigger pressed—press this button to set the auto drill speed. Press and hold this button to decrease the auto-drill speed.
- Left trigger released—press this button to open the pipe gripper.

Lower Button

If a sensor fails, use this button to override the pipe cam presets and manually move the cam. Operate in this mode only when necessary; you could damage the pipe cam or pipes if you do not align them correctly. If the sensor fails, contact your Authorized Service Dealer for repair.

Right Joystick

Note: The joystick controls vary depending on the control mode you select. There are 2 control modes: Mode I and Mode II; refer to the *Software Guide* for this machine to set the control mode.




Figure 14

- | | |
|---------------------------|-----------------|
| 1. Joystick—move left | 6. Front button |
| 2. Joystick—move forward | 7. Rear button |
| 3. Joystick—move rearward | 8. Lower button |
| 4. Joystick—move right | 9. Trigger |
| 5. Toggle switch | |

Trigger

Press and hold the trigger to move the drill carriage at high speed up or down the drill frame.

Toggle Switch

Rock the switch forward to increase the flow rate of the drilling fluid; rock the switch rearward to decrease the flow rate of the drilling fluid.

Note: Before using this feature you must first turn on the drilling-fluid pump using the lower button on the right joystick.

Front Button

Press this button to apply thread-joint compound.

Rear Button

Press and hold this button for maximum drilling fluid pressure; use this to quickly fill the pipe with drilling fluid after adding or removing a pipe. Release the button to stop the flow or return to the previously set flow rate.

Lower Button

Press this button to turn the drilling-fluid pump on or off.

Forward

Push the joystick forward to thrust the drill carriage forward.

Rearward

Pull the joystick rearward to pull the drill carriage rearward.

	Mode I	Mode II
Left	Push the joystick left to spin the drill spindle clockwise.	<ul style="list-style-type: none"> Left trigger pressed—opens the lower wrench (stationary wrench). Left trigger released—raises the pipe elevator.
Right	Push the joystick right to spin the drill spindle counterclockwise.	<ul style="list-style-type: none"> Left trigger pressed—closes the lower wrench (stationary wrench). Left trigger released—lowers the pipe elevator.

7 or 8-Button Joysticks

Joysticks in Setup Mode

The machine must be in setup mode (Figure 12) and you must be in the seat to use these functions.





Figure 15
Joysticks – Setup Mode

g225942

- | | |
|--|---|
| 1. Lower the left stake down | 5. Lower the right stake down |
| 2. Rotate the left stake clockwise | 6. Rotate the right stake clockwise |
| 3. Raise the left stake up | 7. Raise the right stake up |
| 4. Rotate the left stake counter clockwise | 8. Rotate the right stake counter clockwise |

	Left Joystick	Right Joystick
Forward	Push the joystick forward to lower the left stake down.	Push the joystick forward to lower the right stake down.
Rearward	Pull the joystick rearward to raise the left stake down.	Pull the joystick rearward to raise the right stake down.
Left	Move the joystick to the left to rotate the left stake counter clockwise.	Move the joystick to the left to rotate the right stake counter clockwise.
Right	Move the joystick to the right to rotate the left stake clockwise.	Move the joystick to the right to rotate the right stake clockwise.



Left Joystick



g226145

Figure 16
Left Joystick in DRILL mode

1. Raise the elevator
2. Lower the elevator
3. Open / Close the pipe gripper
4. Rotate the cam assembly
5. Go to the previous step in SmartTouch™ mode
6. Go to the next step in SmartTouch™ mode
7. Retract the pipe gripper arm
8. Extend the pipe gripper arm
9. Apply tread-joint compound



g226143

Figure 17
Left Joystick — Directional Controls

1. Rotate the drill spindle counter clockwise (Drill Mode II)
2. No action
3. Rotate the drill spindle clockwise (Drill Mode II)
4. No action

Push the joystick left and hold the cam rocker switch at the same time to use the cam override function.


Important: This overrides the anti-crash prevention warning and could cause damage to the machine.

Push the cam rocker switch forward to rotate the cam assembly out.

Push the cam rocker switch backward to rotate the cam assembly in.

Right Joystick


The joystick controls vary depending on the control mode you select when powering up the machine. There are 2 control modes: Drill Mode I and Drill Mode II; refer to the Control-Select Screen in the *Software Guide* for information on setting the control modes.



g226146

Figure 18
Right Joystick

- | | | |
|--------------------------------------|--|--|
| 1. Turn the mud on or off | 4. Open and Close the rear wrench | 7. Set the cruise or carve functions on or off |
| 2. Increase the mud flow momentarily | 5. Open and close the front wrench | 8. Set the carriage to high speed |
| 3. Decrease the mud flow momentarily | 6. Rotate the wrench clockwise and counter clockwise (make and break rotation) | 9. Max flow of mud |



g226144

Figure 19

Mode I	Mode II
1. Thrust the carriage forward	1. Thrust the carriage forward
2. Rotate the drill spindle counter clockwise	2. No Action
3. Pull the carriage back	3. Pull the carriage back
4. Rotate the drill spindle clockwise	4. No action

Exit-Side-Lockout System

The exit-side-lockout system provides the individuals working around the machine with a means to disable the drill pipe from rotating and thrusting.

For more information and instructions, refer to the *Operator's Manual* for the Exit-side-lockout system.

Rear Control Panel




Figure 20

- | | |
|-------------------------|-----------------------------|
| 1. Engine-heating light | 4. Drill-pendant receptacle |
| 2. Engine, key switch | 5. Drive-pendant receptacle |
| 3. Fluid-pump switch | |

Engine-Heating Light

When the engine is cold, the heater warms the intake air to enable easier starting. This light illuminates while the heater is on. Wait until this light turns off before starting the engine.

Engine Key Switch

The key switch has 3 positions as follows (Figure 21):




Figure 21

- | | |
|------------------------|--------------------------|
| 1. Engine-off position | 3. Engine-start position |
| 2. Engine-run position | |

- Engine-off position—turn the key to this position to stop the engine. You cannot start the engine from the operator platform when the key is in this position.
- Engine-run position—turn the key to this position after starting the engine. Turning the key to this position also enables the engine start button from the operator platform.
- Engine-start position—turn the key to this position to start the engine. Release the key to the RUN position once the engine has started.

Fluid-Pump Switch

Use this switch to turn on the fluid pump to use the spray gun when cleaning the machine (Figure 20).

Drill-Pendant Receptacle

Plug the drill pendant into this receptacle to attach it to the machine (Figure 20).

Drive-Pendant Receptacle

Plug the drive pendant into this receptacle to attach it to the machine (Figure 20).

Drill Frame and Stabilizer Controls

Drive Pendant

Refer to [Figure 20](#) for the location of the drive pendant.




Figure 22

- 1. Drill-frame tilt lever
- 2. Left-stabilizer lever
- 3. Right-stabilizer lever

Stabilizer Levers

Use the stabilizer levers to raise and lower the stabilizers.

Note: The Drive/Drill switch on the operator panel must be switched to the DRIVE position for this function to work.

Drill-Frame Tilt Lever

Use the drill-frame tilt lever to tilt the drill frame to place the stake-down plate on the ground or to return the frame to the TRAVEL position.

Note: The DRIVE/DRILL switch on the operator panel must be switched to the DRIVE position for this function to work.




Figure 23

- 1. Engine-speed switch
- 2. Drive-direction joystick
- 3. Engine-stop button
- 4. Drive-speed switch
- 5. Operator-presence switch

Engine-Stop Button

Press this button to immediately stop the engine and all movement/drilling operations. You must pull this button out before you can start the engine again.

Engine-Speed Switch

- Press and hold the top of this switch to increase the engine speed.
- Press and hold the bottom of this switch to decrease the engine speed.
- Release the switch to maintain the current engine speed.

Drive-Direction Joystick

Use the joystick to control the direction of the machine. The machine will travel in the direction that you move the joystick.

Drive-Speed Switch

The switch sets the speed at which the machine will travel. Move the switch up for high speed or down for low speed.

Operator-Presence Switch

Press and hold this button to enable the other controls on the drive pendant. The machine will stop moving if you release this button.

Drill Pendant

⚠ WARNING

Only an authorized person(s) should operate the drill pendant. Personal injury, harm to others, or damage to the machine could occur if this pendant is misused.

The drill pendant (also referred to as the life-jacket pendant) is designed to allow you rudimentary control over the drilling features when connected to the front receptacle, should the operator platform controls become non-responsive. You can also plug this pendant into the drive-pendant receptacle at the rear control panel, in the event that the drive pendant malfunctions to obtain basic movement functions at slow speed.

Refer to [Figure 20](#) for the location of the drill pendant.




Figure 24

- | | |
|---|---|
| 1. Left-track-control switch/rotary-control switch | 6. Pipe-grip-control switch |
| 2. Drilling fluid and wrench-control switch | 7. Pipe-clamp-control switch |
| 3. Right-track-control switch/carriage-control switch | 8. Cam-rotation-control switch |
| 4. Breakout-wrench-control switch (upper wrench) | 9. Pipe-elevator-control switch |
| 5. Drill-spindle-control switch | 10. Stationary (for lower wrench) pipe-clamp-control switch |

Left-Track-Control Switch/Rotary-Control Switch

When this switch is connected to the drive-pendant receptacle, move it to control the movement of the left track.

- Move the switch forward to move the left track forward.
- Move the switch backward to move the left track backward.

When this switch is connected to the front drill-pendant receptacle, move it to control the rotation of the pipe.

- Move the switch forward to rotate the pipe clockwise.
- Move the switch backward to rotate the pipe counterclockwise.

Drilling Fluid and Wrench-Control Switch

When this switch is connected to the front drill-pendant receptacle, move it to control the drilling-fluid flow or the wrench operation.

- Move the switch to the left to turn the drilling fluid to the ON position.
- Move the switch to the right to turn wrench operation to the ON position.

Right-Track-Control Switch/Carriage-Control Switch

When this switch is connected to the drive-pendant receptacle, move it to control the movement of the right track.

- Move the switch forward to move the right track forward.
- Move the switch backward to move the right track backward.

When this switch is connected to the front drill-pendant receptacle, move it to control the movement of the carriage.

- Move the switch forward to move the carriage forward.
- Move the switch backward to move the carriage backward.

Breakout-Wrench-Control Switch

When this switch is connected to the front drill-pendant receptacle, move it to control the wrench breakout and makeup.

- Move the switch forward for wrench breakout (for upper wrench).
- Move the switch backward for wrench makeup (for upper wrench).

Drill-Spindle-Control Switch

When this switch is connected to the front drill-pendant receptacle, move it to control the movement of the drill spindle.

- Move the switch forward to rotate the drill spindle backward toward the pipe holder.
- Move the switch backward to rotate the drill spindle forward toward the operator.

Pipe-Grip-Control Switch

When this switch is connected to the front drill-pendant receptacle, move it to control the pipe grip.

- Move the switch forward to tighten the grip on the pipe.
- Move the switch backward to loosen the grip on the pipe.

Pipe-Clamp-Control Switch

When this switch is connected to the front drill-pendant receptacle, move it to control the pipe clamp.

- Move the switch forward to tighten the clamp on the pipe.
- Move the switch backward to loosen the clamp on the pipe.

Cam-Rotation-Control Switch

When this switch is connected to the front drill-pendant receptacle, move it to control the movement of the cam.

- Move the switch forward to rotate the cam backward toward the pipe holder.
- Move the switch backward to rotate the cam forward toward the operator.

Pipe-Elevator-Control Switch

When this switch is connected to the front drill-pendant receptacle, move it to control the pipe elevator.

- Move the switch forward to raise the pipe elevator.
- Move the switch backward to lower the pipe elevator.

Stationary Pipe-Clamp-Control Switch

When this switch is connected to the front drill-pendant receptacle, move it to control the stationary-pipe clamp.

- Move this switch forward to tighten the stationary-pipe clamp (for lower wrench).
- Move this switch backward to loosen the stationary-pipe clamp (for lower wrench).

Stake-Down Levers




Figure 25

g021835
g021835

- | | |
|---------------------------------|----------------------------------|
| 1. Left-stake-raise/lower lever | 3. Right-stake-raise/lower lever |
| 2. Left-stake-spin lever | 4. Right-stake-spin lever |

Stake-Raise/Lower Levers

Push down on these levers to lower the stakes into the ground. Pull up on these levers to raise the stakes out of the ground.

Note: The DRIVE/DRILL switch on the operator panel must be switched to the DRIVE position for this function to work.

Stake-Spin Levers

Push down on these levers to spin the stakes clockwise. Pull up on these levers to spin the stakes counterclockwise.

Note: The DRIVE/DRILL switch on the operator panel must be switched to the DRIVE position for this function to work.

Battery-Disconnect Switch

Open the rear compartment to access the BATTERY-DISCONNECT switch.

Turn the BATTERY-DISCONNECT switch to the ON or OFF position to perform the following:

- To energize the machine electrically, rotate the BATTERY-DISCONNECT switch clockwise to the ON position (Figure 26).
- To de-energize the machine electrically, rotate the BATTERY-DISCONNECT switch counterclockwise to the OFF position (Figure 26).




Figure 26

- | | |
|--|---|
| 1. Battery-disconnect switch (On position) | 2. Battery-disconnect switch (Off position) |
|--|---|

Specifications

Note: Specifications and design are subject to change without notice.

Machine

Width	2.2 m (7.2 ft)
Length	6 m (19.7 ft)
Height	2.5 m (8.2 ft)
Weight	9,806 kg (21,620 lbs)

Operation

Determine the left and right sides of the machine from the normal operating position.

Before Operation

Before Operation Safety

General Safety

- Always shut off the engine, and remove the key. Wait for all movement to stop and allow the machine to cool before adjusting, cleaning, or repairing it.
- The owner must ensure that all operators are well trained and competent to safely operate the machine.
- Never allow children or untrained people to operate or service the machine. Local regulations may restrict the age of the operator.
- Become familiar with the safe operation of the equipment, operator controls, and safety signs.
- Shut off the engine, remove the key (if equipped), and wait for all movement to stop before you leave the operator's position. Allow the machine to cool before adjusting, servicing, cleaning, or storing it.
- Know how to shut off the machine quickly.
- Check that operator-presence controls, safety switches, and shields are attached and functioning properly. Do not operate the machine unless they are functioning properly.
- Inspect the area where you will use the machine and remove all objects that the machine could throw.
- Keep the manual(s) with the machine. Go to www.Toro.com for a replacement manual.

Fuel Safety

- Use extreme care in handling fuel. It is flammable and its vapors are explosive.
- Extinguish all cigarettes, cigars, pipes, and other sources of ignition.
- Use only an approved fuel container.
- Do not remove the fuel cap or fill the fuel tank while the engine is running or hot.
- Do not add or drain fuel in an enclosed space.

- Do not store the machine or fuel container where there is an open flame, spark, or pilot light, such as on a water heater or other appliance.
- If you spill fuel, do not attempt to start the engine; avoid creating any source of ignition until the fuel vapors have dissipated.

Understanding Horizontal Directional Drilling

Horizontal directional drilling is a process used for drilling a horizontal bore through the soil and under obstructions such as roads, buildings, bodies of water, etc. Once you drill the bore, you pull back the utility lines or pipes through the bore and connect them as needed. Because it does not greatly disturb the surface, installing utilities using directional drilling preserves the environment and saves both time and money over traditional installation methods such as trenching.

Installing cabling or pipe using a directional drill involves the following steps:

1. Gather site information.

Before operating in an area with high-voltage lines or cables, contact a One-Call System Directory service. In the USA, call 811 or your local utility company. If you do not know your local utility company's phone number, call the national number (USA and Canada only) at 1-888-258-0808. Also, contact any utility companies that are not participants of the One-Call System Directory service. Please refer to [Drilling Near Utility Lines \(page 6\)](#) for more information.

Before fully planning the bore, gather information about the job site, such as the location of other utilities, obstacles at the site, and the permits you will need to complete the job; refer to [Gathering Site Information \(page 39\)](#).

2. Plan the bore.

Before you drill, plan the bore path based on the information that you gathered; refer to [Planning the Bore Path \(page 42\)](#).

3. Prepare the job site and the machine.

Before drilling, prepare the job site with an entry point, a depth-gauge hole (optional), and an exit hole. You also need to drive the unit to the site, set it up for drilling, and connect it to a drilling-fluid mixer.

Note: When drilling, you connect the machine to a drilling-fluid mixer that mixes water with bentonite clay and other ingredients. The machine pumps this mixture, referred to as

drilling fluid or “mud”, through the drill pipe and out the drill bit. The drilling fluid lubricates the bit, helps to hold the bore open while drilling, and mixes with the spoils, flushing them out of the bore through the entry point.

Refer to [Preparing the Job Site and the Machine \(page 47\)](#) for instructions on preparing the job site and the machine.

4. **Drill the bore.**

You drill the bore in 3 stages:

A. Entry

In the entry phase of the bore, you push the drill bit and head into the ground at an angle of up to 16 degrees. After pushing in one or more pipes, you begin drilling down and forward until you reach the desired depth or depth-gauge hole (if used).

B. Horizontal Reach

After reaching the desired depth, you push the bit forward, steering the bit to a horizontal depth. The drill bit emits a radio signal from the sonde housing, which allows a crew member on the surface to track the location and depth of the head using the sonde receiver as you drill and steer it along a planned route.

C. Exit

Once you have attained the planned horizontal reach, you steer the head up at an angle similar to your entry angle bringing the bit into the exit hole or trench.

Refer to [Drilling the Bore \(page 60\)](#).

5. **Backream the bore and pull back cabling or pipe.**

After entering the exit hole, the end crew detaches the drill bit and sonde housing from the drill pipe. In its place, they attach a reaming bit and the end of the cable or pipe to be pulled through the bore. The reaming bit is designed to enlarge the bore as you pull it back. As before, you pump drilling fluid through the pipe to the reaming bit as you pull the cable or pipe back through the bore to lubricate the reamer and allow the cable or pipe to slide easily through the bore. You continue pulling the pipe back until the reamer reaches the depth-gauge hole or exits at the entry point. There you remove the reamer and product from the drill pipe, pulling the pipe the rest of the way back to the machine.

Refer to [Backreaming and Pullback \(page 64\)](#) for instructions on backreaming and pulling cable or pipe.

6. **Finish the bore and leave the job site.**

After completing the operation, you need to disconnect and clean the machine and load it on the trailer; refer to [Finishing the Job \(page 66\)](#).

Gathering Site Information

Planning the Initial Route

Before you can begin boring, you need to plan the route that you will bore and prepare as follows:

- Create a basic plan for the bore, mapping out the proposed route.
 - Note any obstacles which may affect the bore, such as large trees, bodies of water, buildings, etc.
 - Plan the route of the bore to avoid as many obstacles as possible.
 - Determine the depth of any bodies of water to be crossed to ensure that you can get deep enough under them.
- Determine the depth that you need to install the material at and the minimum bend radius both of the drill pipe and of the material being installed. This will seriously affect how long the bore needs to be and at what angle that you can begin and end; refer to [Planning the Bore Path \(page 42\)](#).
- Have the area of the bore marked for utility lines (in the US call 811). Ensure that all lines are marked on your blueprints/bore plan as well.
- Contact the local authorities to arrange for any permits and traffic control that you will need to conduct the job.

Inspecting the Proposed Job Site

Physically inspect the site as follows:

- Note the terrain, slopes, valleys, hills, and any features not planned for previously.
 - Determine the degree of slope at both the proposed entry point and exit point.
- Determine what the soil types are in the area and, if possible, at the depth that you will be boring. You may need to dig test holes at intervals along the bore path to fully determine this.
- Walk the area of the bore, looking for any possible unmarked obstructions. Look for manholes, pedestals, old foundations, etc.
- Identify all the hazards that you will pass within 3 m (10 ft).

⚠ DANGER

Contacting underground hazards with the machine while drilling or reaming can cause explosion, electrocution, breathing problems, severe trauma, and death to you or bystanders.

- Ensure that all personnel at the job site wear personal protective equipment including a hard hat, eye protection, electrically insulated safety boots and gloves, and hearing protection.
- Keep bystanders and spectators away from the job site, including the complete bore path.
- Locate and expose all electric and gas lines that you will be crossing by careful hand digging.
- Ensure that you use the Zap-Alert system whenever you operate the machine.

Common hazards include the following:

- Gas lines

⚠ DANGER

Drilling into a gas line can cause an explosion or fire, burning, injuring, or killing you or others in the vicinity of the break.

- ◇ Do not smoke or have any source of flame near gas lines or at either end of a bore that will be crossing a gas line.
- ◇ Keep bystanders and spectators away from the job site, including the complete bore path.
- ◇ Locate and expose all gas lines that you will be crossing by careful hand digging.
- ◇ Have the gas company turn off the gas to any lines you will be crossing before drilling.
- ◇ Use the receiver to track the exact position of the drill head when approaching gas lines.

- Electrical power lines

⚠ DANGER

Drilling into an electric power line will cause the machine to become electrified and may electrocute you or any bystanders.

- ◇ Keep bystanders and spectators away from the job site, including the complete bore path.
- ◇ Locate and expose all electric lines that you will be crossing by careful hand digging.
- ◇ Have the electric company turn off the power to any lines you will be crossing before drilling.
- ◇ Use the receiver to track the exact position of the drill head when approaching electric lines.
- ◇ Before drilling, setup and use the Zap-alert system which is designed to notify in the case of an electric strike and electrically isolate the machine operator from the machine. If the Zap-alert alarm triggers, stop what you are doing and do not leave the operator's position. Refer to [Deploying the Zap-Alert System \(page 54\)](#) for detailed instructions on using the Zap-alert system.

– **Crystalline silica and other dust**

If you will be drilling through or cutting concrete, sand, or other substances that create dusts or fumes, you need to ensure that you and all workers wear breathing protection to protect your lungs from the dust.

⚠ WARNING

Machining or handling stone, masonry, concrete, metal, and other materials can generate dust, mists, and fumes containing chemicals, such as silica, known to cause serious or fatal injury or illness, such as respiratory disease, silicosis, cancer, birth defects, or other reproductive harm.

- ◇ **Control dust, mist, and fumes at the source where possible. Water should be used for dust suppression when feasible.**
- ◇ **Use good work practices and follow the recommendations of the manufacturer or suppliers, OSHA, and other occupational and trade associations.**
- ◇ **When the hazards from inhalation cannot be eliminated, the operator and any bystanders should wear a respirator approved by OSHA for the material being handled.**

⚠ WARNING

***Silicosis Warning:* Grinding, cutting, or drilling stone, masonry, concrete, metal, and other materials with silica in their composition may give off dust or mist containing crystalline silica. Silica is a basic component of sand, quartz, brick, clay, granite, and numerous other minerals and rocks. Repeated and/or substantial inhalation of airborne crystalline silica can cause fatal respiratory diseases, including silicosis. In addition, some other authorities have listed respirable crystalline silica as a substance known to cause cancer. When cutting such materials, follow respiratory precautions.**

Planning the Bore Path

Before setting up the job site, you need to plan the bore path, including the following:




Figure 27

1. Bore entry
2. Beginning-of-bore-at-depth point
3. Bore depth
4. Obstacle
5. End-of-bore-at-depth point and bore exit

- **Bore entry**

This is where you setup the machine and the drill bit enters the ground. Depending on conditions, this will typically be set back 9 to 15 m (30 to 50 ft) from the beginning-of-the-bore-at-depth point.

- **Beginning-of-bore-at-depth point**

This is the point where you want the utility line or pipe to end after installation is complete. It is typically the point at which the bore levels out and begins to bore horizontally. This may be the same as the entry point, or you may dig a separate depth-gauge hole at this point (Figure 27).

- **Bore depth**

This the depth at which you want to install the utility line or pipe. This machine is designed primarily for installations between 1 and 3 m (3.5 to 10 ft).

- **Obstacles in the path**

It is important to know where the known obstacles are that you will need to steer around or under before starting so that you can plan where to begin steering prior to reaching the obstacle.

- **End-of-bore-at-depth point**

This is the point where you want the utility line or pipe to begin after installation is complete. Often, this will also be the bore exit.

- **Bore exit**

This is the location where the drill head will exit the ground and the point at which you will pull the utility lines or pipe into the bore. If this point will be at the surface instead of at installation depth,

you will need to determine the distance from the end-of-bore-at-depth location needed for steering the drill to the surface, typically 9 to 15 m (30 to 50 ft) from the end-of-the-bore-at-depth point.

Determining the Bore-Entry Point

One of the more challenging aspects of planning the bore path is to determine the entry point of the bore. You need to take the following traits into account when determining the location of the entry point:

- **Bore depth**

This is the depth at which you want to install the utility line or pipe. This machine is designed primarily for installations between 1 and 3 m (3.5 to 10 ft).

- **Pipe and material flexibility**

The 3 m (10 ft) pipes used on this machine can flex to an 8% pitch over the length of the pipe; this equates to a bend of no more than 20 cm (8 inches) off a straight path (Figure 28).

Important: If you steer the pipe to bend sharper than 20 cm (8 inches) per pipe, you may damage the pipes and their connections. You must also make steering changes gradually over the entire length of each pipe. If you steer the whole 20 cm (8 inches) in only 25 to 50 cm (1 to 2 ft) of travel, you will permanently damage the pipes.




Figure 28

1. 20 cm (8 inches)

This flexibility is often rated in materials as a minimum bend radius, which is the radius of the circle formed if the material or pipes, connected together, were bent to form a giant circle. The minimum radius of a circle made with the pipe used with this machine is 33 m (108.2 ft).

• **Entry pitch**

The entry pitch is the angle at which the machine enters the ground. With the tracks on level ground, the stabilizers down, and the stake-down plate on the ground, the drill frame angle is about 15 degrees or a 27% pitch. This pitch will change depending on the slope of the ground and other factors of the job site. You can also reduce this pitch a bit by building up the ground under the stake-down plate before positioning the machine. You can determine the actual pitch of the drill frame by placing the drill bit and sonde housing on the frame and then use the receiver to display the pitch.

The steeper the entry pitch is, the deeper the bore will have to be due to the limitations of the pipe flexibility. Typically you need to insert the drill and at least 1/3 of a pipe into the ground before you can start steering toward the beginning of the bore point. [Figure 29](#), [Figure 30](#), and the following table illustrate the relationship between entry pitch and depth.




Figure 30

1. 18% pitch
2. 3 m (10 ft)
3. 53 cm (21 inches)




Figure 29

1. 26% pitch
2. 3 m (10 ft)
3. 76 cm (30 inches)

Note: The depths given in the following table are for 3 m (10 ft) of combined drill head and pipe. As you steer up, the pitch of the steered section will change and can be monitored with the receiver. Use the following table to identify how many lengths of pipe will be necessary to insert and steer to the beginning point and help you choose an entry point.

Pitch	Depth Change per 10 feet	Pitch	Depth Change per 10 feet
1%	2 cm (1 inch)	26%	76 cm (30 inches)
2%	5 cm (2 inches)	27%	79 cm (31 inches)
3%	10 cm (4 inches)	28%	81 cm (32 inches)
4%	13 cm (5 inches)	29%	84 cm (33 inches)
5%	15 cm (6 inches)	30%	86 cm (34 inches)
6%	18 cm (7 inches)	31%	91 cm (36 inches)
7%	20 cm (8 inches)	32%	94 cm (37 inches)
8%	25 cm (10 inches)	33%	97 cm (38 inches)
9%	28 cm (11 inches)	34%	99 cm (39 inches)
10%	30 cm (12 inches)	35%	102 cm (40 inches)
11%	33 cm (13 inches)	36%	104 cm (41 inches)
12%	36 cm (14 inches)	37%	107 cm (42 inches)
13%	39 cm (15 inches)	38%	109 cm (43 inches)
14%	43 cm (17 inches)	39%	112 cm (44 inches)
15%	46 cm (18 inches)	40%	114 cm (45 inches)
16%	48 cm (19 inches)	41%	117 cm (46 inches)
17%	51 cm (20 inches)	42%	117 cm (46 inches)
18%	53 cm (21 inches)	43%	119 cm (47 inches)
19%	56 cm (22 inches)	44%	122 cm (48 inches)
20%	61 cm (24 inches)	45%	124 cm (49 inches)
21%	64 cm (25 inches)	46%	127 cm (50 inches)
22%	66 cm (26 inches)	47%	130 cm (51 inches)
23%	69 cm (27 inches)	48%	133 cm (52 inches)
24%	71 cm (28 inches)	49%	135 cm (53 inches)
25%	74 cm (29 inches)	50%	137 cm (54 inches)

All measurements are approximate and will vary depending on soil conditions.

Note: These values and more can be found in the *Driller's Handbook & Daily Log* by Digital Control Incorporated.

Given the above information, you can calculate the number of rods required to reach your beginning point at the appropriate depth. Toro recommends that you start the entry point the same distance back from your beginning-at-depth point as the length of pipes you will need to reach that point. This will ensure that you have enough extra space so you will not need to over-steer and damage the pipes.

The following example illustrates the process given an installation using the maximum entry pitch of the machine (26%) on level ground:

- Insert the first 3 m (10 ft) of drill bit/pipe into the ground with no steering. The end of the drill bit will be 76 cm (30 inches) deep (Figure 28).




Figure 31

- | | | |
|-----------------------|-----------------------|-------------------|
| 1. 26% pitch | 4. 185 cm (73 inches) | 7. 14.7 m (45 ft) |
| 2. 76 cm (30 inches) | 5. 203 cm (80 inches) | |
| 3. 142 cm (56 inches) | 6. 208 cm (82 inches) | |

- Begin steering up for the next 3 m (10 ft), pushing the pipes in at the maximum pitch change of 8%. This results in a change of pitch from 26% at the beginning of the 3 m (10 ft) to 18% at the end of the 3 m (10 ft) for an average pitch of 22%. Given that, the drill head lowers another 66 cm (26 inches) and is now 142 cm (56 inches) deep.
- Continuing steering up for the next 3 m (10 ft) at an 8% pitch change, your pitch will change from 18% to 10% for an average pitch of 14%. Given that, the drill head lowers another 43 cm (17 inches) and is now 185 cm (73 inches) deep.
- Continuing steering up for the next 3 m (10 ft) at an 8% pitch change, your pitch will change from 10% to 2% for an average pitch of 6%. Given that, the drill head lowers another 18 cm (7 inches) and is now 203 cm (80 inches) deep.
- Leveling the drill head from 2% to 0% takes less than 1.5 m (5 ft) more for a final depth of 208 cm (82 inches). Reaching this final point took 4-1/2 pipes 3 m (10 ft) long. So for this example, your entry point should be 14.7 m (45 ft) back from the beginning-at-depth point of your installation.

The following example illustrates the process given an installation using the machine at an 18% pitch on level ground:

- Insert the first 3 m (10 ft) of drill bit/pipe into the ground with no steering. The end of the drill bit will be 53 cm (21 inches) deep (Figure 32).




Figure 32

- | | | |
|----------------------|-----------------------|-----------------------|
| 1. 18% pitch | 3. 96 cm (38 inches) | 5. 119 cm (47 inches) |
| 2. 53 cm (21 inches) | 4. 114 cm (45 inches) | 6. 10.6 m (35 ft) |

- Begin steering up for the next 3 m (10 ft), pushing the pipes in at the maximum pitch change of 8%. This results in a change of pitch from 18% at the beginning of the 3 m (10 ft) to 10% at the end of the 3 m (10 ft) for an average pitch of 14%. Given that, the drill head lowers another 43 cm (17 inches) and is now 96 cm (38 inches) deep.
- Continuing steering up for the next 3 m (10 ft) at an 8% pitch change, your pitch will change from 10% to 2% for an average pitch of 6%. Given that, the drill head lowers another 18 cm (7 inches) and is now 114 cm (45 inches) deep.
- Leveling the drill head from 2% to 0% takes less than 1.5 m (5 ft) more for a final depth of 119 cm (47 inches). Reaching this final point took 3-1/2 pipes 3 m (10 ft) long. So for this example your entry point should be 10.6 m (35 ft) back from the beginning-at-depth point of your installation.

Important: You can use the information contained in this section to determine both the space needed to steer up to the exit point if needed and also to steer around obstacles.

Mapping the Bore

With the information you gathered previously, map out the route of the bore, identifying the following so that you can mark the site later:

- Entry point
- Location of the machine and supporting equipment
- Beginning of bore at depth
- Any obstacles that you need to steer around and the locations where you need to start steering to get around or under them
- Any utility lines that you will need to cross
- Slope and soil changes along the path that will affect the bore
- End of the bore at depth
- Exit location if different than the end of the bore

Preparing the Job Site and the Machine

Before drilling, prepare the job site and the machine as follows:

- Mark and prepare the bore path [Marking and Preparing the Bore Path \(page 47\)](#).
- Test the Zap-Alert system; refer to [Testing the Zap-Alert System \(page 48\)](#).
- Load the drill pipes into the pipe holder if needed; refer to [Loading Drill Pipes into the Pipe Holder \(page 50\)](#).
- Add fuel to the machine; refer to [Adding Fuel \(page 51\)](#).
- Perform daily maintenance; refer to [Performing Daily Maintenance \(page 52\)](#).
- Load/unload the machine; refer to [Loading and Unloading the Machine \(page 52\)](#).
- Drive the machine to the entry point; refer to [Driving the Machine \(page 52\)](#).
- Connect the machine to a drilling-fluid source; refer to [Connecting to a Drilling-Fluid Source \(page 56\)](#).
- Setup the machine for drilling; refer to [Setting up the Machine for Drilling \(page 53\)](#).
- Deploy the Zap-Alert system; refer to [Deploying the Zap-Alert System \(page 54\)](#).

Marking and Preparing the Bore Path

1. Walk the bore path, marking it on the ground with marking paint so that the receiver operator will be able to follow the plan.
2. Hand dig to expose any buried utility lines marked previously that the bore path will be crossing. This will allow the receiver operator to know exactly where they are.
3. If you are exiting the bore at ground level and not in an existing trench, dig an angled hole into which the bit will enter at the end of the bore.
4. If desired, dig a hole to the beginning-of-the-bore point where you can disconnect the pipe or lines after pulling them back.

Checking the Safety-Interlock Switches

Checking the Operator Presence Safety-Interlock Functions on the Operator Platform

1. Start the engine.
2. With the engine running, rise from the seat and press a joystick function.

Note: The drill functions should not engage. If they do engage, there is a malfunction in the interlock system that you should correct before resuming operation.

Checking the Operator Presence Safety-Interlock Functions on the Drive Pendant

You will need 2 people for this procedure.

1. Start the engine.
2. With the engine running, have 1 person sit in the seat.
3. Using the travel pendant, press the controls to tram the machine.

Note: The tramping functions should not engage. If they do engage, there is a malfunction in the interlock system that you should correct before resuming operation.

4. With the engine running, use the travel pendant and press the controls to lower the stabilizer feet while **not** holding the operator presence button.

Note: The stabilizer feet functions should not engage. If they do engage, there is a malfunction in the interlock system that you should correct before resuming operation.

5. With the engine running, use the travel pendant and press the controls to tram the machine while **not** holding the operator presence button.

Note: The tramping functions should not engage. If they do engage, there is a malfunction in the interlock system that you should correct before resuming operation.

Testing the Zap-Alert System

The Zap-Alert system is an electric strike sensing device on the machine that triggers a strobe light and audible alarm in the event that the drill bit, reamer, or stake breaks into an energized power line. In the event of an electric strike, the machine will become energized, setting off the alarm.

⚠ DANGER

If the Zap-alert system activates while drilling, the machine, except for the operator platform, will become energized. If you step off the operator platform or if someone touches the machine or wet ground near the machine or in the bore, you or the one who touched the machine could be electrocuted, causing serious injury or death.

- Test the Zap-alert system before drilling.
- Deploy the grounding stake before drilling. Ensure that the stake is fully inserted into moist soil.
- If the Zap-alert is triggered:
 - Stay in the seat and do not touch the ground or any other part of the machine until the power has been turned off. Do not pour liquids or urinate from the operator platform onto the ground.
 - Stop drilling, stop the drilling-fluid flow, and retract the drill out of the ground.
 - Keep everyone away from the machine.
 - Keep standing or running water and drilling fluid contained close to the machine. Keep water and drilling fluid sources away from the broken line.
 - Contact the utility company to have power shut off to the broken line. Do not reset the Zap-alert system until the power has been turned off.

Test the Zap-alert system before using the drill each day, as follows:

1. Open the front hood.
2. Lay the grounding stake flat on the ground away from the machine. Do not drive the stake into the ground.

Important: Do not allow the stake to touch any part of the machine.

3. Connect an alligator clip from the Zap-alert tester to the grounding stud on the Zap-alert system (Figure 33).




Figure 33

- | | |
|------------------------------------|----------------------------|
| 1. Test button | 5. Reset button |
| 2. Zap-alert tester | 6. Alligator clips |
| 3. Zap-alert system | 7. Machine grounding point |
| 4. Zap-alert system grounding stud | |

4. Connect the other alligator clip to a metal component of the machine frame.
5. Press the TEST button on the Zap-alert tester (Figure 33).

The Zap-alert alarm should sound, and the strobe on top of the front hood should flash.
6. Press the ZAP-ALERT RESET button to stop the alarm (Figure 33).

7. Disconnect the alligator clips from the grounding stud and the machine.
8. Store the grounding stake in the holder on the operator platform as shown in [Figure 34](#).




Figure 34

1. Grounding stake

If either the audible alarm or the strobe light fail to trigger when you pressed the TEST button, have them repaired before drilling with the machine.

Mounting a Fire Extinguisher

Mount your fire extinguisher below the operator seat ([Figure 35](#)).

Note: A fire extinguisher is not provided with the machine.

The recommended fire extinguisher is a dry chemical fire extinguisher approved for class B and C fires.




Figure 35

1. Mounting location

Filling the Fuel Tank

Fuel Tank Capacity

208 L (55 U.S. gallons)

Fuel Specification

Use only clean, fresh diesel fuel or biodiesel fuels with ultra low (<15 ppm) sulfur content. The minimum cetane rating should be 40. Purchase fuel in quantities that can be used within 180 days to ensure fuel freshness.

Use summer grade diesel fuel (No. 2-D) at temperatures above -7° C (20° F) and winter grade (No. 1-D or No. 1-D/2-D blend) below that temperature. Using winter grade fuel at lower temperatures provides lower flash point and cold flow characteristics which will ease starting and reduce fuel filter plugging.

Using summer grade fuel above -7° C (20° F) will contribute toward longer fuel pump life and increased power compared to winter grade fuel.

Important: Do not use kerosene or gasoline instead of diesel fuel. Failure to observe this caution will damage the engine.

⚠ DANGER

In certain conditions, fuel is extremely flammable and highly explosive. A fire or explosion from fuel can burn you and others and can damage property.

- **Fill the fuel tank outdoors, in an open area, when the engine is cold. Wipe up any fuel that spills.**
- **Do not fill the fuel tank inside an enclosed trailer.**
- **Do not smoke when handling fuel, and stay away from an open flame or where fuel fumes may be ignited by a spark.**
- **Store fuel in an approved container and keep it out of the reach of children. Do not buy more than a 30-day supply of fuel.**
- **Do not operate without entire exhaust system in place and in proper working condition.**

⚠ WARNING

Fuel is harmful or fatal if swallowed. Long-term exposure to vapors can cause serious injury and illness.

- **Avoid prolonged breathing of vapors.**
- **Keep face away from nozzle and gas tank or conditioner opening.**
- **Keep fuel away from eyes and skin.**

Using Biodiesel Fuel

This machine can also use a biodiesel blended fuel of up to B20 (20% biodiesel, 80% petrodiesel). The petrodiesel portion must be ultra low sulfur. Observe the following precautions:

- The biodiesel portion of the fuel must meet specification ASTM D6751 or EN14214.
- The blended fuel composition should meet ASTM D975 or EN590.
- Painted surfaces may be damaged by biodiesel blends.
- Use B5 (biodiesel content of 5%) or lesser blends in cold weather.
- Monitor seals, hoses, gaskets in contact with fuel as they may be degraded over time.
- Fuel filter plugging may be expected for a time after converting to biodiesel blended.
- Contact your dealer for more information about biodiesel.

Adding Fuel

In certain conditions during fueling, static electricity can be released, causing a spark which can ignite the fuel vapors. A fire or explosion from fuel can burn you and others and can damage property.

- Place fuel containers on the ground away from your vehicle before filling.
- Do not fill fuel containers inside a vehicle or on a truck or trailer bed because interior carpets or plastic truck bed liners may insulate the container and slow the loss of any static charge.
- When practical, remove equipment from the truck or trailer, and refuel the equipment with its tracks on the ground.
- If this is not possible, then refuel such equipment on a truck or trailer from a portable container rather than from a fuel dispenser nozzle.
- If you are using a fuel dispenser nozzle, keep the nozzle in contact with the rim of the fuel tank or container opening at all times until fueling is complete.

1. Park the machine on a level surface.

- Using a clean rag, clean the area around fuel-tank cap.
- Remove the cap from the fuel tank (Figure 37).




Figure 37

- Fuel-tank cap
-
- Fill the tank until the level is to the bottom of the filler neck with diesel fuel.
 - Install fuel tank cap tightly.
- Note:** If possible, fill the fuel tank after each use. This will minimize possible buildup of condensation inside the fuel tank.

Performing Daily Maintenance

Before starting the machine each day, perform the Each Use/Daily procedures listed in the [Maintenance \(page 70\)](#).

Starting and Stopping the Engine

To start the engine, complete the following:

- Open the front hood; refer to [Opening the Front Hood \(page 72\)](#).
- Turn the BATTERY-DISCONNECT switch to the ON position; refer to [Battery-Disconnect Switch \(page 37\)](#).
- Close and latch the hood.
- Open the door on the rear control panel.
- Turn the ignition key to the RUN position.

Note: If the Wait-to-Start light illuminates, wait until it turns off before proceeding.

- Turn the ignition key to the START position until the engine starts, then release it.

To stop the engine, turn the ignition key to the OFF position. In an emergency, you can also stop the engine and all processes by pressing the ENGINE-STOP button on either the drive pendant or the control panel.

Driving the Machine

- Start the machine, and ensure that the stake-down augers are removed from the ground.
- Ensure that the rear stabilizers are retracted and that the thrust frame is raised off the ground in the horizontal position.
- Walk around the machine to ensure that no one is near it.

Note: Ensure that all bystanders are clear of the area where you will be moving the machine.

- Connect the drive pendant to the right receptacle on the bottom of the rear control panel.
- With the pendant in hand, walk at least 6 feet to the side of the machine.

Note: Be sure to keep this safe distance whenever moving the machine.

- Press and hold the OPERATOR PRESENCE button on the drive pendant.
- Use the SPEED switch on the pendant to increase or decrease the engine speed as desired.
- Set the desired travel speed using the SPEED switch.
- Use the joystick to move the machine as desired.

Note: For more information on the drive pendant, refer to [Drive-Pendant Receptacle \(page 33\)](#).

Loading and Unloading the Machine

⚠ WARNING

Moving a machine of this size on a trailer over public roads carries risks to those around the machine if it should come loose, be involved in an accident, hit a low hanging structure, etc.

- Follow the tie-down procedures described in this section when moving the machine.
- Follow all local traffic regulations governing the hauling of large equipment. This manual cannot adequately cover all laws and safety regulations; it is your responsibility to know and follow the laws and regulations that pertain to you.

⚠ WARNING

The machine can slip and fall from a trailer or ramp, crushing anyone caught beneath it and causing serious injury or death.

- Keep all bystanders away from the machine and trailer.
- Ensure that the trailer and ramp are not slippery and are free of ice, grease, oil, etc.
- Move the machine onto the ramp at slow speed with the engine at slow speed.
- Ensure that you have the machine centered on the ramp and trailer.

1. Ensure that the ramp and the trailer or truck bed can support the weight of the machine.
2. Ensure that the upper front and rear pipe-holder pins and the lower front and rear pipe-holder pins are installed (Figure 38).




Figure 38

1. Upper transport pin
2. Pipe-box mounting pin
3. Lower transport pin

3. Ensure that the pins securing the pipe holder to the thrust frame are installed.
4. Place a block at the front and rear of the trailer and/or truck tires.
5. Using the drive pendant, set the engine speed to slow and the drive speed to slow.
6. Using the drive pendant, carefully drive the machine forward or rearward up the ramp and into position on the trailer.
7. Lower the stake-down plate to the deck of the trailer.
8. Turn off the engine.
9. Use appropriately rated chains and binders to secure the rings on the left and right track

frames and the stake-down plate to the trailer (Figure 39).




Figure 39

1. Tie-down points (only right side shown)

10. Measure and note the distance from the ground to the highest point on the machine to ensure that you do not collide with low hanging obstacles.
11. Remove the block from the trailer tires, and stow them with the machine for use when unloading it.
12. After driving a few miles, pull over and check to ensure that all chains are still tight and that the machine has not moved.

Note: To unload the machine, reverse the above procedure.

Setting up the Machine for Drilling

1. Using the drive pendant, drive the machine to the location that you have prepared for it, ensuring that the front of the machine is the proper distance back from entry point and the drill frame is in line with the bore path.
2. Drive up to the location and make sure that all utilities are located and marked prior to drilling.
3. Loosen the 4 screws that secure the covers over the operator consoles and remove the covers (Figure 40).

Note: Store them someplace safe for the day.




Figure 40

g034674
g034674

1. Screw
2. Cover

4. Lower the pedestrian safety bar and secure it in place (Figure 41).




Figure 41

g034683
g034683

1. Pedestrian safety bar (lowered position shown)

5. Push down on the rear platform latch securing the operator platform, and swing it out to the desired position, ensuring that it locks in place (Figure 42).

Note: The operator platform has 4 positions: travel (swung all the way into the machine), full-out, and 2 intermediate positions.




Figure 42

g025651

g025651

1. Rear platform latch

Deploying the Zap-Alert System

The Zap-alert system is an electric strike-sensing device on the machine that triggers a strobe light and an audible alarm whenever the drill bit, reamer, or stake breaks into an energized power line. In the event of an electric strike, the machine will become energized, setting off the alarm. The operator's platform is electrically isolated from the rest of the machine to protect you.

⚠ DANGER

If the Zap-alert system activates while drilling, the machine, except for the operator platform, will become energized. If you step off the operator platform or if someone touches the machine or wet ground near the machine or in the bore, you or the one who touched the machine could be electrocuted, causing serious injury or death.

- Test the Zap-alert system before drilling.
- Deploy the grounding stake before drilling. Ensure that the stake is fully inserted into moist soil.
- If the Zap-alert is triggered:
 - Stay in the seat and do not touch the ground or any other part of the machine until the power has been turned off. Do not pour liquids or urinate from the operator platform onto the ground.
 - Stop drilling, stop the drilling-fluid flow, and retract the drill out of the ground.
 - Keep everyone away from the machine, wet ground near the machine or running from the machine, and any open sources of water/mud that is in the bore and contacting the broken line.
 - Contact the utility company to have the power shut off to the broken line. Do not reset the Zap-alert system until the power has been turned off.

1. Remove the grounding stake from the holder on the side of the operator platform (Figure 43).




Figure 43

1. Grounding stake

2. Move the stake directly away from the machine, perpendicular to the drill frame, and drive it into the ground until the handle touches the ground.

3. If the ground is dry where you put the stake, soak the ground with water before using the machine to ensure good electrical contact.

Lowering the Stakes

1. Move the operator station to the desired angle, switch the DRILL/DRIVE switch to the DRILL position, and raise the pipe elevators, so that the pipe is resting on the elevators; refer to [Starting the First Pipe \(page 60\)](#).

Note: Remove the front and rear pipe-holder pins if necessary (Figure 44).




Figure 44

1. Front pin
2. Rear pin

2. Load the first pipe and install the sonde and the drill head; refer to [Loading Drill Pipes into the Pipe Holder \(page 50\)](#).
3. Place the drill head on the drill frame, and take a pitch reading using the receiver; refer to the *Tracking System Operator's Manual*.
4. Lower the thrust frame, tilting the drill frame until the plate contacts the ground (Figure 45).




Figure 45

1. Thrust frame
2. Stake-down plate

- Lower the rear stabilizers until they contact the ground firmly, or until the desired entry angle is achieved (Figure 46).

Note: The rear of the tracks should just start to lift off the ground.

Note: If the ground is soft, place timber below the stabilizers, and lower the stabilizers.




Figure 46

- Rear stabilizers

- Press the 2 right stake levers in to lower and spin the right stake auger until it seats fully (Figure 47).




Figure 47

- | | |
|---------------------------------|----------------------------------|
| 1. Left-stake-raise/lower lever | 3. Right-stake-raise/lower lever |
| 2. Left-stake-spin lever | 4. Right-stake-spin lever |

- Repeat step 6 for the left-side stake.

Connecting to a Drilling-Fluid Source

When drilling and reaming, you pump a mixture of bentonite clay, water, and sometimes other ingredients, collectively called drilling fluid or “mud”, through the pipe and into the bore. This drilling fluid, or “mud”, does the following for your bore:

- Lubricates the drill head
- Loosens the soil into which the drill is cutting
- Penetrates and binds loose soil to keep it from collapsing on the bore pipe.

Important: Do not operate the drilling-fluid pump without a pressurized supply of drilling fluid, or damage to the pumping system will result.

The specific mixture you need will vary depending on your soil type and the operation that you are performing. Refer to your mixing system *Operator’s Manual* for details.

Conversely, for some jobs (depending on the soil type and distance), you can pump screened water from a natural water source, such as a lake or river, through the drill instead of mixed drilling fluid.

- To connect the machine to a mixing system, refer to [Setting up the Mixing System](#) (page 56).
- To connect the machine to a natural water source, refer to [Setting up the Pump to Use a Natural Water Source](#) (page 57).

Setting up the Mixing System

Set up your mixing system near the directional drill location, preferably downwind, so that fumes from the mixing system engine will not bother you while you are drilling. Follow the instructions provided in the mixing system *Operator’s Manual* for setting it up and using it.

Complete the steps following to connect the exit hose from the mixing system to the drilling-fluid pump on the machine:

1. Raise the cam-lock levers on the pump-inlet cap, and remove the cap (Figure 48).




Figure 48

1. Cam-lock levers
2. Pump-inlet cap

2. Insert the hose from the mixing system over the pump inlet, and secure it with the cam-lock levers.

Setting up the Pump to Use a Natural Water Source

To set up a pump to use a natural water source, you must ensure that you use the Y-screen to filter all materials other than water.

1. Remove the pump-inlet cap (Figure 49).




Figure 49

1. Pump threads
2. Pump-inlet cap
3. Y-screen

2. Align the Y-screen with the threads on the pump (Figure 49).
3. Rotate and tighten the Y-screen onto the pump.
4. Attach the hose to the Y-screen, and begin pumping from the natural water source.

Positioning the Cab (Model with Cab only)

Positioning the Cab for Drilling Operation

1. Push back on the SWING-ROCKER switch (until the cab stops) to swing the cab to the DRILL position (Figure 50).




Figure 50

1. Swing rocker switch
2. Rotate rocker switch

Important: Ensure that you swing the cab out completely before rotating, or you may contact the machine, causing damage to the cab.

2. Push back on the ROTATE-ROCKER switch to rotate the cab to the desired drill position (Figure 50).

Positioning the Cab into Transport Mode

1. Push forward on the ROTATE-ROCKER switch (until the cab stops) to rotate the cab to the TRANSPORT position (Figure 50).

Important: Ensure that you completely rotate the cab to the TRANSPORT position (clockwise) before swinging, or you may contact the machine, causing damage to the cab.

2. Push forward on the SWING-ROCKER switch (until the cab stops) to swing the cab to the TRANSPORT position (Figure 50).

Opening the Door (Model with Cab only)

Open the door from the outside by pulling on the handle, and swing the door to the left (Figure 51).




Figure 51

1. Door handle

Open the door from the inside by pulling the knob backward and pushing the door to the outside (Figure 52).




Figure 52

1. Door knob

Operating the Air Conditioning and Heating (Model with Cab only)

Air Conditioning the Cab

1. Push the AIR-CONDITIONING switch to the right to turn the air conditioning to the ON position (Figure 53).




Figure 53

- | | |
|---|-------------------------------------|
| 1. Cool/Cold temperature | 6. Temperature knob |
| 2. Air-conditioning switch Off position | 7. Fan speed (low, medium, or high) |
| 3. Air-conditioning switch | 8. Fan-speed knob |
| 4. Air-condition switch On position | 9. Fan Off position |
| 5. Warm/Hot temperature | |

2. Open the vents to increase or decrease the air flow.
3. Turn the TEMPERATURE knob to the left until you reach the desired temperature (Figure 53).
4. Turn the FAN-SPEED knob to either low, medium, or high (Figure 53).

Heating the Cab

1. Push the AIR-CONDITIONING switch to the left to turn the air conditioning to the OFF position (Figure 53).
2. Open the vents to increase or decrease the air flow.
3. Turn the TEMPERATURE knob to the right until you reach the desired temperature (Figure 53).
4. Turn the FAN-SPEED knob to either low, medium, or high (Figure 53).

Operating the Windshield Wipers (Model with Cab only)

Changing the Windshield-Wiper Speed

Turn the WINDSHIELD-WIPER knob (Figure 54) to the right increase the speed of the windshield wipers, or turn the knob to the left to decrease the speed.




Figure 54

1. Windshield-wiper knob

Dispersing the Windshield-Washer Fluid

Push down on the WINDSHIELD-WIPER knob (Figure 54) to disperse the desired amount of windshield washer fluid.

During Operation

During Operation Safety

General Safety

- The owner/operator can prevent and is responsible for accidents that may cause personal injury or property damage.
- Wear appropriate clothing, including eye protection; long pants; substantial, slip-resistant footwear; hearing protection; and a hard hat. Tie back long hair and do not wear loose clothing or loose jewelry.
- Do not operate the machine while ill, tired, or under the influence of alcohol or drugs.
- Never carry passengers on the machine and keep bystanders and children out of the operating area.
- Operate the machine only in good visibility to avoid holes or hidden hazards.
- Keep your hands and feet away from moving parts.
- Look behind and down before backing up to be sure of a clear path.
- Use care when approaching blind corners, shrubs, trees, or other objects that may obscure your vision.
- Do not operate near drop-offs, ditches, or embankments.
- Stop the machine whenever you are not operating it.
- Stop the machine and inspect the after striking an object or if there is an abnormal vibration in the machine. Make all necessary repairs before resuming operation.
- Slow down and use caution when making turns and crossing roads and sidewalks with the machine. Always yield the right-of-way.
- Never run an engine in an area where exhaust gasses are enclosed.
- Never leave a running machine unattended.
- Before leaving the operating position, do the following:
 - Shut off the machine, remove the key, and turn the battery-disconnect switch to the off position.
 - Wait for all moving parts to stop.
- Do not operate the machine when there is the risk of lightning.
- Do not use the machine as a towing vehicle.
- Use accessories, attachments, and replacement parts approved by The Toro® Company only.

Slope Safety

When operating the machine on a slope, the operator must account for many variables, such as the amount, distribution, and height of the load; the stability of the ground; uneven terrain and obstacles; and the condition of the brakes. These and other variables make it impractical to designate the maximum angle at which the operator can safely use the machine for all slopes and situations.

Slopes are a major factor related to loss of control and rollover accidents, which can result in severe injury or death. The operator is responsible for safe slope operation. Operating the machine on any slope requires extra caution. Before using the machine on a slope, the operator must do the following:

- Review and understand the slope instructions in the manual and on the machine.
- Evaluate the site conditions of the day to determine if the slope is safe for machine operation. Use common sense and good judgment when performing this evaluation. Changes in the terrain, such as moisture, can quickly affect the operation of the machine on a slope.
- Walk beside the machine when tramming up and down slopes.
- Identify hazards at the base of the slope. Do not operate the machine near drop offs, ditches, embankments, water or other hazards. The machine could suddenly roll over if a track goes over the edge or the edge collapses. Keep a safe distance (twice the width of the machine) between the machine and any hazard.
- Avoid starting, stopping or turning the machine on slopes. Avoid making sudden changes in speed or direction; turn slowly and gradually.
- Do not operate a machine under any conditions where traction, steering or stability is in question. Be aware that operating the machine on wet terrain, across slopes or downhill may cause the machine to slide even if the tracks are stopped.
- Remove or mark obstacles such as ditches, holes, ruts, bumps, rocks, or other hidden hazards. Uneven terrain could overturn the machine.

Drilling the Bore

Starting the First Pipe

1. Ensure that all bystanders are away from the machine and that the exit-side lockout is ON.
2. Move the drive carriage fully down the drill frame and spray the spindle threads with thread joint compound, then return the drive carriage to the upper end of the frame (Figure 43).




Figure 55

1. Drill spindle
2. TJC-applicator nozzle

3. Rotate the cam until the cam automatically stops at the first row of pipes in the pipe holder.
4. Lower the elevators to load a pipe into the cam.
5. Rotate the cam with the pipe facing toward the operator until the cam stops.
6. Rotate the pipe-gripper cam forward until the pipe is in the grippers.
7. Grip the pipe with the pipe grippers.
8. Continue to rotate the pipe-gripper cam toward the operator, until the pipe is aligned with the drill spindle.
9. Rotate the drill spindle clockwise, and move the carriage slowly forward to insert the spindle into the female end of the pipe (Figure 56).




Figure 56

1. Drill spindle
2. Pipe

Setting up the Drill Head and the Tracking System

The drill head consists of 2 parts, the drill bit and the sonde housing (Figure 57).




Figure 57

1. Sonde housing
2. Drill bit

10. Move the drive carriage slowly down the frame until the male threads on the pipe are under the thread-joint-compound applicator, and apply thread-joint compound to the threads.
11. Continue to rotate the drill spindle clockwise, until the male pipe thread is fully seated into the sonde housing or lead bar.
12. Release and retract the pipe-gripper cam to the HOME position.

Important: Ensure that you fully retract the pipe gripper and rotate it all the way out or the carriage may collide with the gripper, damaging the machine.

13. Raise the pipe elevator.
14. Retract the cam to the HOME position (past the fourth row of pipes).

Drill bits vary in size and type to meet the various soil conditions that you may need to drill through. Some of the possibilities are as follows:

- **Straight blade**—Used in a wide range of medium density soils.
- **Bent blade**—Used in medium to soft soils. This bit has an added 20 degree bend to increase steering performance in soft soils.
- **Triangle point blade**—Use in hard and rocky soils. This bit has carbide edges to reduce wear.

All of the above bits come in varying widths. A wider blade increases your ability to steer in soft soils. A narrower blade moves through hard soils better. Contact your Authorized Toro Dealer for a complete list of available blades.

The sondes and receivers are essential to track the position of the drill head throughout the drilling operation. The sonde housing on the drill head opens up to accept the sonde beacon which works with the receiver to track the location, pitch, direction, head orientation, and more of the drill head. Refer to the *Tracking System Operator's Manual* for instructions on using the system.

To install the sonde beacon into the sonde housing on the drill head, complete the following:

1. Replace the batteries in the sonde beacon as described in the *Tracking System Operator's Manual*.
2. Loosen the screws securing the housing cover to the housing and remove the cover (Figure 58).




Figure 58

- | | |
|------------------|----------------|
| 1. Sonde housing | 4. Cover holes |
| 2. Bolts | 5. Cover |
| 3. Drill bit | |

3. Insert the sonde beacon with the forward end toward the drill bit into the sonde housing (Figure 59).




Figure 59

- | | |
|------------------|--------------|
| 1. Sonde housing | 3. Drill bit |
| 2. Sonde beacon | |

4. Install the housing cover and secure it with the screws (Figure 58).

Installing the Drill Head

1. Using the exit-side-lockout transmitter, activate the exit-side lockout to disable the thrust and rotation of the carriage.

⚠ WARNING

If the drill rotates or extends while you or others are manually working on the drill bit or pipe in front of the machine, the worker could get caught in the bit or pipe, causing serious injury, amputation, or death.

- Activate the exit-side lockout on the exit-side-lockout transmitter before approaching the drill bit or pipe when attached to the machine. This will disable the drill carriage.
- Do not wear loose clothing or jewelry when working on a drill bit or pipe attached to the machine. Tie long hair up and out of the way.

2. Place the lead bar through the lower wrench (stationary wrench) as shown in Figure 60.

Important: Do not clamp the wrench on the body of a pipe, or it may damage the pipe. Grip the pipes on the thickened area near the joint.




Figure 60

- | | |
|--|-------------------------------------|
| 1. Drill pipe | 3. Lower wrench (stationary wrench) |
| 2. Upper wrench (makeup/breakout wrench) | 4. Lead bar |

3. Hand thread the lead bar onto the drill spindle pipe threads, then move away from the front of the machine.
4. When the area is clear of people, activate the exit-side lockout using the exit-side-lockout

transmitter (the OK-to-Drill light on the control panel should illuminate); press the exit-side-lockout, RESET switch on the control panel.

5. Using the lower wrench (stationary wrench), clamp the lead bar, and tighten the drill spindle to full-seat threads.
6. Double check the drill head and bit to ensure that the fluid ports are clean and free from obstructions.
7. Install the drill head onto the end of the lead bar as directed by the drill head manufacturer, then move away from the front of the machine.

Important: Do not pull the drill head into the pipe guide, or you may damage the machine or the drill head.

Boring the Entry Shaft

The first step in boring is to create the entry shaft. In this step, you push and bore the drill bit and first few pipes into the ground at an angle from 0 to 16 degrees (with the tracks flat on the ground) until you reach the desired depth of installation.

Important: Drill and ream in a clockwise rotation. If you use a counterclockwise rotation, the pipes will disconnect from each other and may be disconnected underground.

1. When the area is clear of people, activate the exit-side lockout using the exit-side-lockout transmitter (the OK-to-Drill light on the control panel should illuminate); press the exit-side-lockout, RESET switch on the control panel.
2. Turn on the drilling-fluid-pump switch, and allow the fluid pressure to build to 1,379 to 2,068 kPa (200 to 300 psi).
3. Rotate the drill head until the bit is at the 6 o'clock position.
4. Move the carriage forward, driving the bit straight into the ground until the entire drill housing is underground.
5. Continue pushing forward, and begin rotating the drill spindle clockwise to initiate the drilling action.
6. Drill forward until the carriage reaches the end of the frame, then retract it about 6 mm (1/4 inch).

Adding Drill Pipes

1. Align the pipe joint in the wrench assembly.
2. Close the lower wrench (stationary wrench) onto the first pipe.

Note: The drilling fluid will automatically shut off when you activate the upper wrench (makeup/breakout wrench).

3. Pull back the carriage approximately 12.7 mm (0.5 inch).

Note: This will allow the carriage to float, and will not damage the pipe threads.

4. Rotate the drill head counterclockwise until the spindle is completely removed from the pipe.
5. Spray the spindle with thread joint compound, then return the drive carriage to the upper end of the frame.
6. Rotate the pipe-gripper cam to the closest row of pipes in the pipe holder.
7. Lower a pipe into the pipe-gripper cam, and grip it in place.
8. Rotate the pipe gripper until the pipe is centered in front of the spindle on the drive carriage.
9. Rotate the drill spindle clockwise and move the carriage slowly forward to insert the spindle into the female end of the pipe (Figure 56).

Note: Tighten the joint until the pipe is rotating with the spindle.

10. Move the drive carriage slowly down the frame until the male threads on the pipe are under the thread-joint-compound applicator, and apply thread-joint compound to the threads.
11. Rotate the drill spindle clockwise and move the carriage slowly forward to insert the male end of the pipe into the female end of the previous pipe.

Note: Tighten the joint until you reach no more than 2,304 N-m (1,700 ft-lb).

12. Release and rotate the pipe-gripper cam clockwise to the HOME position.

Important: Ensure that you fully rotate the pipe-gripper cam, or the carriage may collide with the gripper, damaging the machine.

13. Rotate the main cam past the fourth row of pipe to the HOME position.

Software version K or newer: After loading the first pipe the software will skip the certain proximity switches to improve operator productivity. The grippers will also function when the pipe loading cam is extended and retracted without operator input.

Steering the Drill Head

The drill bit is shaped like a wedge, angled from one side of the bit to the other. When you push the bit through the soil without rotating it, it will veer toward the direction the wedge is pointing. When you rotate the pipe and drill head, it bores through the soil in a straight path.




Figure 61

1. Drill bit

When drilling, the receiver operator follows the drill head as it progresses. The receiver receives signals from the sonde in the drill head identifying its position, depth, pitch, direction, transmitter temperature, and orientation in the soil. The remote console is a screen that remains near you (the drill operator) to show you the information from the receiver while drilling so that you can make steering decisions.

For detailed information on using the receiver and remote console to guide the drill head, refer to the *Operator's Manual* that came with your receiver.

Important: Do not steer the drill head more than 20 cm (8 inches) off center for every 3 m (10 ft) of forward travel. If you steer more than this, you will damage the drill pipes.

Boring the Horizontal Shaft

After creating the entry shaft, you gradually steer the drill head up while pushing forward, following the planned bore path. When you reach the desired depth, level out the drill head and bore the horizontal shaft, adding pipes as you go. While boring, pay close attention to the information relayed back to you by the receiver operator about the status and location of the drill head to ensure that you are following the planned path.

Important: While drilling, watch the sonde temperature. All sondes have a maximum temperature, above which they will be damaged. Friction between the drill head and the soil will cause the temperature to raise. To reduce the temperature, slow down, decrease forward pressure, and increase the drilling-fluid flow. If the drill head is entering a soil type other than what it is designed for, that can also raise the temperature. Assess the situation and pull out the drill head and change it if necessary.

If you run into an obstruction, do the following:

1. Increase the flow of the drilling fluid for a few seconds without drilling, then attempt to continue drilling forward.
2. If the obstruction persists, try one or more of the following options:

- If the obstruction is in an area where you can dig, stop the drill head with the Exit Side Lockout and dig down to the obstruction to identify it and remove it if possible.
- Pull the drill head back 15 m (50 ft) or more and steer the drill head to the side, marking a new drill path around the obstacle.

Important: Do not steer the drill head more than 20 cm (8 inches) off center for every 3 m (10 ft) of forward travel. If you steer more than this, you will damage the drill pipes.

- If the obstruction is actually a change in soil type, such as a zone of rocky soil, pull the drill head all the way back and change to a drill bit appropriate for drilling through the new soil type.

Exiting the Ground

As you approach the end of the bore, steer the drill head to the exit point, keeping the steering limits in mind as you do so. Before exiting the ground, ensure that everyone is away from the exit point. As soon as you break through, stop the drilling-fluid flow. Extend the drill forward until the entire drill head is out of the ground.

Backreaming and Pullback

After drilling the initial bore, you attach a reamer to the pipe, which is then connected to a the product that you are installing. The reamer is designed to widen the bore, pack the walls, and lubricate the passage of the product into the bore.

The following reamers are available from your Authorized Toro Dealer in various sizes to meet your needs and soil conditions:

- **Carbide step-wing cutter**—Use this reamer in sandy and medium clay soil conditions to mix the drilling fluid with the soil, making a mixture that flows easily around the product being pulled.
- **Cast cone packer**—Use this reamer in soils that pack easily, such as soft clay, peat, and loam, to

pack the sides of the bore, maintaining the bore opening.

- **Fluted reamer**—Use this reamer in hard clay and rocky soils; it combines the features of the other 2 reamers.

Connecting the Reamer and Product

⚠ WARNING

If the drill rotates or extends while you or others are manually working on the drill bit or pipe in front of the machine, the worker could get caught in the bit or pipe, causing serious injury, amputation, or death.

- **Enable the exit-side lockout on the exit-side-lockout transmitter before approaching the drill bit or pipe when attached to the machine. This will disable the drill carriage.**
- **Do not wear loose clothing or jewelry when working on a drill bit or pipe attached to the machine. Tie long hair up and out of the way.**

1. Using the exit-side-lockout transmitter, enable the exit side lockout.
2. Remove the drill head from the lead bar.
3. Double check the reamer to ensure that the fluid ports are clean and free from obstructions.
4. Install the reamer and swivel onto the end of the lead bar as directed by the reamer manufacturer.
5. Connect the product to the reamer using an appropriate pulling connection; refer to your Authorized Toro Dealer to acquire the appropriate puller to meet your requirements.

Removing Drill Pipes

1. Using the exit-side-lockout transmitter, enable the exit side lockout.
2. Install a drill-pipe wiper around the pipe and into the retaining bracket on the front of the machine.

Note: This will remove most of the dirt and mud from the pipe as you pull it back into the machine, keeping the machine clean. Contact your Authorized Toro Dealer to purchase drill-pipe wipers.




Figure 62

1. Drill-pipe wiper
2. Drill pipe

3. Disengage the exit-side lockout and reset the system.
 4. Begin rotating the drill spindle clockwise and slowly retract the drive carriage to pull the pipe back into the machine.
 5. When the joint between the pipes is centered between the 2 wrenches, the drive carriage will stop, and a green light will illuminate below the spray valve.
 6. Close the lower wrench (stationary wrench) onto the pipe joint.
- Note:** The drilling fluid will automatically shut off when you close the lower wrench (stationary wrench).
7. Rotate the pipe cam to the drill frame, extend pipe-gripper arms to the pipe, and grip the pipe to support it.
 8. Close the upper wrench (makeup/breakout wrench) onto the pipe joint.
 9. Rotate the upper wrench (makeup/breakout wrench) counterclockwise until the joint is loosened.

10. Release the upper wrench (makeup/breakout wrench).
11. Pull back the carriage approximately 12.7 mm (0.5 inch).
Note: This will allow the carriage to float, and will not damage the pipe threads.
12. Rotate the drill spindle counterclockwise, moving rearward slowly until the pipes are separated.
13. Move the drill carriage back until the male, pipe threads just clear the female end of the lower pipe, then close the upper wrench (makeup/breakout wrench) onto the pipe end, but not on the threads.
14. Rotate the drill spindle counterclockwise until the upper-pipe joint is loose but not separated.
15. Release the upper wrench (makeup/breakout wrench).
16. Move the drill carriage back until the pipe is lined up with the pipe holder.
17. Rotate the drill spindle counterclockwise, moving rearward slowly until the spindle fully separates from the pipe.
18. Rotate the pipe-gripper arms until the pipe rests inside the pipe-gripper cam.
19. Rotate the pipe cam to the desired row.
Note: Fill the outside rows first.
20. Release the pipe gripper, and raise the pipe into the holder row with the pipe elevator.
21. Rotate the pipe cam past the fourth row of pipes to the HOME position.

Important: Ensure that you fully retract the pipe gripper, or the carriage may collide with the gripper, damaging the machine.

22. Move the drill spindle down the frame under the thread-joint-compound applicator, and spray the spindle with thread joint compound.
23. Rotate the drill spindle clockwise, and move the carriage slowly forward to insert the spindle into the female end of the pipe secured in the lower wrench (stationary wrench).
24. Tighten the joint until you reach the full machine torque.
25. Release the wrench and continue reaming/retraction as needed.

Removing the Last Pipe and the Reamer

Important: Do not pull the drill head into the pipe guide, or you may damage the machine or the drill head.

1. Using the exit-side-lockout transmitter, enable the exit side lockout.
2. After the reamer has cleared the ground, if you have not already done so, disconnect the product being installed from the reamer.
3. Connect the drilling fluid pump to a source of clean water.
4. Turn the pump on to flush clean water through the pump, spindle, and reamer until the water runs clear.
5. Remove and store the last pipe; refer to [Removing Drill Pipes \(page 65\)](#).
6. Leave the lead bar clamped in the lower wrench (stationary wrench), but do not connect the drill spindle to the lead bar.
7. Remove the reamer from the end of the lead bar as directed by the reamer manufacturer.
8. Release the lower wrench (stationary wrench) and pull the lead bar out of the pipe guide.

After Operation

After Operation Safety

General Safety

- Shut off the engine, remove the key (if equipped), and wait for all movement to stop before you leave the operator's position. Allow the machine to cool before adjusting, servicing, cleaning, or storing it.
- Clean up any oil or fuel spills.
- Allow the engine to cool before storing the machine in any enclosure.
- Never store the machine or fuel container where there is an open flame, spark, or pilot light, such as on a water heater or on other appliances.

Finishing the Job

Complete the following after each day of use:

- Connect the hand spray gun to the quick disconnect located at the rear compartment, and clean the machine with clean water; refer to [Cleaning with the Spray-Hose Attachment \(page 107\)](#).
- Add grease to the grease fittings; refer to [Greasing the Machine \(page 74\)](#).
- If the air temperature is below freezing or will be before the next use, refer to [Preparing the Drilling-Fluid System for Cold Weather \(page 104\)](#).

- Install the controls covers; refer to [Operator Platform \(page 26\)](#).
- Flush the drilling fluid out of the drilling-fluid pump with water or antifreeze.

Important: The drilling-fluid pump may be damaged if the drilling-fluid dries up in the pump.

Using the TJC Applicator

Adjusting the Applicator Nozzle

You can adjust the applicator nozzle to spray thread-joint compound (TJC) either in a fan-shaped spray or as a stream.

- For fan-shaped spray, turn the spray valve on the side of the nozzle horizontal ([Figure 63](#)).
- For a stream, turn the spray valve on the side of the nozzle vertical ([Figure 63](#)).




Figure 63

1. Spray valve—fan-shaped spray (horizontal)
2. Spray valve—stream (vertical)

Adjusting the TJC-Spray Volume

1. Loosen the jam nut on the adjustment bolt located on top of the TJC-applicator piston ([Figure 64](#)).




Figure 64

1. Adjustment bolt
2. Jam nut
3. TJC-applicator piston

2. Adjust the bolts as follows:

- To increase the applied volume of compound, thread the bolt out (up).
- To decrease the applied volume of compound, thread the bolt in (down).

3. When you have attained the desired application volume, tighten the jam nut to secure the adjustment.

Filling the TJC Applicator

1. Stop the machine and stop the engine.
2. Open the stake-down-guard door.
3. Loosen the wing nuts securing the cover straps to the machine (Figure 65).




Figure 65

- | | |
|--------------------------|---------------|
| 1. TJC-applicator piston | 4. Wingnut |
| 2. Cover | 5. TJC bucket |
| 3. Strap | |

4. Rotate the cover and pull the cover straps off the retaining bolts (Figure 65).
5. Lift the cover assembly off and out of the empty thread-joint-compound bucket (Figure 65).
6. Replace the empty bucket with a new full bucket.
7. Place the plunger into the new bucket and lower the cover assembly onto the bucket (Figure 65).
8. Slide the cover straps over the retaining bolts, and rotate the cover to seat the straps on the bolts (Figure 65).
9. Tighten the wing nuts.

Moving a Disabled Machine

Whenever the machine is stopped and the engine is not running, the hydrostatic brakes automatically engage. Do not attempt to tow the machine if it cannot move under its own power. If possible, repair the machine at the site. If this is not possible, use a crane and a spreader bar to lift the machine onto a trailer, using the lift points shown in Figure 66.




Figure 66

Repeat lift points on other side

- | | |
|---------------|-----------------|
| 1. Lift point | 2. Spreader bar |
|---------------|-----------------|

Replacing the Pipe Holder

1. Ensure that the 2 upper pins and the 2 lower pins are installed to secure the pipe inside the pipe holder (Figure 67).




Figure 67

1. Upper pins
2. Lower pins

-
2. Remove the lower, outer pins on the pipe holder (Figure 68).
 3. With a hoist capable of lifting 2,260 kg (5,000 lb), remove the pipe holder.




Figure 68

1. Front pin
2. Rear pin

Maintenance

▲ WARNING

Failure to properly maintain the machine could result in premature failure of machine systems, causing possible harm to you or bystanders.

Keep the machine well maintained and in good working order as indicated in these instructions.

Note: Determine the left and right sides of the machine from the normal operating position. Place a service tag on the machine when maintenance procedures are being performed.

Replace all covers and guards after you service or clean the machine. Do not operate the machine without the covers or guards in place.

Note: Download a free copy of the electrical or hydraulic schematic by visiting www.Toro.com and searching for your machine from the Manuals link on the home page.

Important: Refer to your engine owner's manual for additional maintenance procedures.

Recommended Maintenance Schedule(s)

Maintenance Service Interval	Maintenance Procedure
After the first 100 hours	<ul style="list-style-type: none"> • Check the stakedown planetary-drive oil level (Also, check if external leakage is observed). • Check the rotary motor planetary-drive oil level (Also, check if external leakage is observed). • Check the thrust motor planetary-drive oil. • Check the gearbox drive oil. • Change the gearbox-drive oil.
After the first 250 hours	<ul style="list-style-type: none"> • Adjust the valve clearance. • Change the planetary-drive oil.
Before each use or daily	<ul style="list-style-type: none"> • Grease the machine. (Grease immediately after every washing). • Check the crankcase-vent tube and clean it if necessary. • Check the indicator on the display screen for a restricted air filter. • Check the engine oil level. • Check the track tension. • Check the coolant level in the radiator. • Check the hydraulic fluid level. • Check the drilling-fluid pump oil level. • Clean the machine with the spray-hose attachment.
Every 50 hours	<ul style="list-style-type: none"> • Check and clean the dust valve. • Remove air cleaner cover and clean out debris. Do not remove the filter. • Check the fuel-water separator for water and sediment. • Check the battery condition. • Check the tracks rotary motor planetary-drive oil level (Also, check if external leakage is observed).
Every 250 hours	<ul style="list-style-type: none"> • Clean or replace the air-cleaner filter. • Change the engine oil filter. • Change the engine oil. • Replace the primary and secondary fuel filters. • Check the condition of the engine-drive belt.
Every 300 hours	<ul style="list-style-type: none"> • Check the condition of the coolant system components. Clean dirt and debris from them and repair or replace the components as necessary.

Maintenance Service Interval	Maintenance Procedure
Every 500 hours	<ul style="list-style-type: none"> • Inspect the fuel lines and connections. • Check the stakedown planetary-drive oil level (Also, check if external leakage is observed). • Check the rotary motor planetary-drive oil level (Also, check if external leakage is observed). • Check the thrust motor planetary-drive oil (or yearly, whichever comes first). • Check the gearbox drive oil (or yearly, whichever comes first). • Change the gearbox-drive oil (or yearly, whichever comes first). • Change the hydrostatic-charge filter. • Change the drilling-fluid pump oil.
Every 800 hours	<ul style="list-style-type: none"> • Change the planetary-drive oil (or yearly, whichever comes first).
Every 1,000 hours	<ul style="list-style-type: none"> • Drain and clean the fuel tank. • Check the concentration of the coolant before the winter season. • Clean the cooling system. (Clean the cooling system if the coolant becomes dirty or rust colored.) • Check the tension on the engine drive belt. • Change the hydraulic fluid. • Change the high-pressure hydraulic filter (and as needed per the service indicator) • Changing the hydraulic-return filter (and as needed per the service indicator)
Every 2,000 hours	<ul style="list-style-type: none"> • Adjust the valve clearance.
Yearly or before storage	<ul style="list-style-type: none"> • Touch up chipped paint.
Every 2 years	<ul style="list-style-type: none"> • Replace moving hoses.

▲ WARNING

Improperly servicing or repairing the machine may cause injury or death.

If you do not understand the service procedures for this machine, contact your Authorized Service Dealer or see the service manual for this machine.

▲ WARNING

Operating the machine without covers and guards in place may cause personal injury or death.

Replace all covers and guards after you service or clean the machine. Do not operate the machine without the covers or guards in place.

Pre-Maintenance Procedures

Pre-Maintenance Safety

- Before adjusting, cleaning, repairing, or leaving the machine, do the following:
 - Move the machine on a level surface.
 - Shut off the machine.
 - Turn the battery-disconnect switch to the OFF position.
 - Wait for all moving parts to stop.
 - Allow machine components to cool before performing maintenance.
- If possible, do not perform maintenance while the engine is running. Keep away from moving parts.
- Use adequate support to support the machine or components when required.
- Carefully release pressure from components with stored energy.

Opening the Front Hood

1. Park the machine on a level surface, stop the engine, and remove the ignition key.
2. Lift up on the latch as shown in [Figure 69](#).

Note: Ensure that the key is in the OPEN (horizontal) position as shown in [Figure 69](#).




Figure 69

1. Key in the open (horizontal) position
2. Hood latch




Figure 70

1. Hood latch

4. Keep the hood latch ([Figure 70](#)) pulled up, and lift up on the handle as shown in [Figure 71](#).




Figure 71

1. Hood handle

Opening the Rear-Access Door

1. Park the machine on a level surface, stop the engine, and remove the ignition key.
2. Push on the left side of the panel handle, and pull the panel open when the handle is released ([Figure 72](#)).

3. Pull up on the hood latch as shown in [Figure 70](#).




Figure 72

1. Rear-access door handle




Figure 73

- | | |
|----------------------|------------------|
| 1. Cotter pin | 4. Clevis pin |
| 2. Cylinder lock | 5. Lift cylinder |
| 3. Lift cylinder rod | |

Using the Cylinder Lock

⚠ WARNING

The thrust frame may lower when it is in the raised position, causing serious injury or death.

Install the cylinder lock before performing maintenance that requires the thrust frame to be raised.

Installing the Cylinder Lock

1. Start the engine.
2. Lower the thrust frame to the fully-lowered position.
3. Stop the engine.
4. Position the cylinder lock over the cylinder rod (Figure 73).
5. Secure the cylinder lock with the cotter pin and clevis pin (Figure 73).
6. Turn the engine to the ON position, and raise the thrust frame until it rests on the cylinder lock.

Removing and Storing the Cylinder Lock

1. Start the engine.
2. Lower the thrust frame to the fully lowered position.
3. Stop the engine.
4. Remove the cotter pin and the clevis pin that secure the cylinder lock (Figure 73).
5. Remove the cylinder lock.
6. Turn the engine to the ON position, and raise the thrust frame.
7. Store the cylinder lock at the rear of the pipe holder (Figure 74).




Figure 74

1. Location behind the rear of the pipe holder

Lubrication

Greasing the Machine

Service Interval: Before each use or daily (Grease immediately after every washing).

Grease type: General-purpose grease.

1. Park the machine on a level surface, stop the engine, and remove the ignition key.
2. Clean the grease fittings with a rag.
3. Connect a grease gun to each fitting.
4. Pump grease into the fittings until grease begins to ooze out of the bearings (approximately 3 pumps).
5. Wipe up any excess grease.




Figure 75

Cylinder assembly (view from under machine, near stabilizer foot)




Figure 76

Track frame (repeat on other side)




Figure 77

Front elevator assembly (top view)






Figure 78

Rear elevator assembly (top view)




g034475
g034475

Figure 79
Front pipe-loader cam area (6 fittings)




g034479
g034479

Figure 82
Stabilizer cylinder and foot (repeat on other side)




g034474
g034474

Figure 80
Rear pipe-loader cam area (6 fittings)




g023617
g023617

Figure 83
Carriage-roller bearings (operator's side shown; repeat on other side)




g034473
g034473

Figure 81
Hydraulic cylinder and wrench assembly



g023610
g023610

Figure 84
Gearbox float (operator's side shown; repeat on other side)



g023611
g023611

Figure 85

Stakedown shaft (left side shown; repeat on right side)

Engine Maintenance


Engine Safety

- Shut off the engine before checking the oil or adding oil to the crankcase.
- Do not change the governor speed or overspeed the engine.

Cleaning the Crankcase-Vent Tube

Service Interval: Before each use or daily—Check the crankcase-vent tube and clean it if necessary.

1. Park the machine on a level surface, stop the engine, and remove the ignition key.
2. Open the front hood.
3. Gently pull the crankcase-vent tube out ([Figure 86](#)).
4. Clean the end of the crankcase-vent tube ([Figure 86](#)).



g023621

g023621

Figure 86

1. Crankcase vent tube

Servicing the Air-Cleaning System

Important: Do not remove the elements from the machine to check for dirty filters; use the following procedure instead.

Important: Do not replace the old air-cleaner filter with a filter that is more than 5 years old; check the date of manufacture on the end cap of the element.

Note: Every time you service the air-cleaner system, ensure that all hose connections and flanges are air tight. Replace all damaged parts.

- Check the air-cleaner body for damage which could cause an air leak. Replace it if it is damaged. Check the whole intake system for leaks, damage or loose hose clamps. Also, inspect the rubber intake hose connections at the air cleaner and the turbo to make sure that the connections are complete.
- Service the air-cleaner filter only when “Check Air Filter” is displayed on the screen. Changing the air filter before it is necessary only increases the chance of dirt entering the engine when the filter is removed.
- Be sure that the cover is seated correctly and seals with the air-cleaner body.

Checking the Air-Cleaner Indicator

Service Interval: Before each use or daily

1. Start the engine.
2. Check the restricted, air-cleaner indicator on the display screen; refer to the Air-Cleaner Indicator Screen in the *Software Guide* for this machine.
3. Replace the air-filter element(s) as follows:
 - A. Replace the primary, air-cleaner filter; refer to [Servicing the Air-Cleaner Filter \(page 78\)](#).
 - B. Repeat steps 1 and 2; if the restricted air-cleaner indicator is still shown on the display screen, replace the secondary, air-cleaner filter; refer to [Servicing the Air-Cleaner Filter \(page 78\)](#).

Cleaning the Dust Valve

Service Interval: Every 50 hours

1. Park the machine on a level surface, stop the engine, and remove the ignition key.
2. Open the rear-access door; refer to [Opening the Rear-Access Door \(page 72\)](#).
3. Squeeze the sides of the dust valve on the air-cleaner cover to release any collected water, dust, or dirt from the valve. ([Figure 87](#)).

Note: Ensure that there are no obstructions inside the dust valve.




Figure 87

1. Dust valve
2. Air-cleaner cover

Servicing the Air-Cleaner Cover

Service Interval: Every 50 hours—Remove air cleaner cover and clean out debris. Do not remove the filter.

Removing the Air-Cleaner Cover

1. Park the machine on a level surface, stop the engine, and remove the ignition key.
2. Open the rear-access door; refer to [Opening the Rear-Access Door \(page 72\)](#).
3. Clean the outside of the air-cleaner canister with a clean, damp cloth.
4. Check the air-cleaner cover for damage which could cause an air leak. Replace a damaged air-cleaner body.

Important: Service the air-cleaner filter only when “Check Air Filter” is displayed on the screen. Changing the air filter before it is necessary only increases the chance of dirt entering the engine when the filter is removed.

- Pull the 4 latches for the air-cleaner cover outward (Figure 88).




Figure 88

- Air-cleaner cover latches

- Pull the air-cleaner cover away from the filter housing and remove the cover.
- Clean any debris from inside the cover.

Important: If “Check Air Filter” is not displayed on the screen, do not remove the air filter.

Installing the Air-Cleaner Cover

- Park the machine on a level surface, stop the engine, and remove the ignition key.
- Align the dust cap on the air cleaner filter cover.
- Align the air-cleaner cover with the filter housing.
- Place air-cleaner cover inward until it is fully seated, and secure it with the latches (Figure 88).

Servicing the Air-Cleaner Filter

Service Interval: Every 250 hours

Replace the filters only when the “Check Air Filter” indicator appears on the display screen; refer to [Checking the Air-Cleaner Indicator \(page 77\)](#).

Note: Contact your Authorized Toro Dealer to order replacement filters.

- Park the machine on a level surface, stop the engine, and remove the ignition key.
- Open the rear-access door.
- Before removing the filter, clean out all debris from the inside of the filter body using low-pressure air at 275 kPa (40 psi).

Important: Avoid using high pressure air which could force dirt through the filter

into the intake tract. This cleaning process prevents debris from migrating into the intake when the primary filter is removed.

- Using the air-filter handles, remove the primary filter from the air-cleaner cover (Figure 89).

Important: Do not clean the used filter.




Figure 89

- Top of primary filter
- Air-filter handles
- Bottom of primary filter
- Air-filter cover

- Inspect the new filter for shipping damage, checking the sealing end of the filter and the body.

Note: Do not use a damaged element.

- Insert the new primary filter by applying pressure to the outer rim of the filter to seat it in the air-cleaner cover.
- Remove the rubber outlet valve from the cover, clean the cavity, and replace the outlet valve; refer to [Cleaning the Dust Valve \(page 77\)](#).
- Install the cover; refer to [Installing the Air-Cleaner Cover \(page 78\)](#).

Servicing the Engine Oil and Filter

The engine is shipped with oil in the crankcase; however, check the oil level before and after you first start the engine.

Crankcase capacity: 7.5 L (7.9 US qt) with the filter.

Use only high-quality low ash SAE 15W-40 heavy-duty engine oil with an API classification of CJ-4 (ACEA E9) or higher.

While low ash SAE 15W-40 oil with an API classification of CJ-4 (ACEA E9) or higher is recommended for most climates, refer to [Figure 90](#) for oil viscosity recommendations for extreme climates.




Figure 90

Note: Limited use of low-viscosity oils such as SAE 10W-30 with an API classification of CJ-4 (ACEA E9) or higher can be used for easier starting and providing sufficient oil flow at ambient temperatures below -5°C (23°F). However, continuous use of low viscosity oil can decrease engine life because of wear ([Figure 90](#)).

Toro Premium Engine Oil is available from an Authorized Toro Service Dealer in either 15W-40 or 10W-30 viscosity with API classification CJ-4 (ACEA E9) or higher. See the parts catalog for part numbers.

Checking the Engine-Oil Level

Service Interval: Before each use or daily—Check the engine oil level.

1. Park the machine on a level surface, stop the engine, and remove the ignition key.
2. Open the front hood.
3. Remove the dipstick ([Figure 91](#)), and wipe it clean.




Figure 91


Operator's side

1. Dipstick
4. Insert the dipstick into the oil fill tube, pull the dipstick out again, and read the oil level on the dipstick.

Note: The oil level on the dipstick should be at the High mark or between the Low and High marks. If the oil is below the Low mark, complete the following procedure:

- A. Remove the fill cap ([Figure 92](#)) and add oil until the level reaches the High mark. **Do not overfill.**

Important: Use an oil canister with a bendable hose or a funnel to fill the machine with oil.



g034691

g034691

Figure 92


1. Oil-fill cap

B. Install the oil-fill cap and the dipstick.

Changing the Engine-Oil Filter

Service Interval: Every 250 hours

1. Park the machine on a level surface, stop the engine, and remove the ignition key.
2. Open the front hood.
3. Align a drain pan or several rags under the oil filter and the oil-filter adapter (Figure 93).



g023629

g023629

Figure 93

1. Oil filter
2. Oil-filter adapter

4. Rotate the oil filter counterclockwise and remove the oil filter (Figure 93).

Note: Discard the oil filter.

5. Using a clean rag, wipe clean the surface of the oil-filter adapter where the oil filter seats with a clean rag.

6. Fill the new oil filter with the specified engine oil.
7. Apply a thin layer of the specified engine oil to the seal of the oil filter.
8. Align the oil filter to the oil-filter adapter, and rotate it clockwise until the seal of the oil filter contacts the oil-filter adapter (Figure 93).

Important: Do not use an oil filter strap wrench to install the new oil filter. The wrench can dent an oil filter and therefore cause a leak.

9. Hand tighten the oil filter an additional 1/2 turn (Figure 93).
10. Remove the oil pan or rags you placed in step 3 and dispose of the used oil according to local codes.

Changing the Engine Oil


Service Interval: Every 250 hours

1. Park the machine on a level surface, stop the engine, and remove the ignition key.

⚠ WARNING

Allow the engine and oil to cool before draining the oil. Hot oil may cause serious injury.

2. Ensure that the drain hose (Figure 94) is carefully pulled up and the end of the hose is placed in a drain pan.



g034692

g034692

Figure 94

1. Drain hose
2. Drain valve

3. Open the drain valve (Figure 94).
4. Drain the oil into the drain pan.
5. When the oil stops, close the drain valve (Figure 94).

6. Place the drain hose back into the original position (Figure 94).
7. Change the engine oil filter; refer to [Changing the Engine-Oil Filter \(page 80\)](#).
8. Remove the oil-fill cap from the filler neck by pulling the cap upward.




Figure 95

1. Filler neck
2. Oil-fill cap
3. Funnel

Note: Use a funnel with a flexible, attached hose to direct the engine oil into the engine.

9. Fill the crankcase with approximately 7.5 L (7.9 US qt) of the specified engine oil; refer to [Servicing the Engine Oil and Filter \(page 79\)](#).
10. Install the oil-fill cap.
11. Start the engine, run it at idle for about 2 minutes, and check for oil leaks.
12. Stop the engine and remove the key.
13. Wait for 2 or 3 minutes and check the oil level; refer to [Checking the Engine-Oil Level \(page 79\)](#).

Adjusting the Valve Clearance

Service Interval: After the first 250 hours
Every 2,000 hours

Refer to the engine owner's manual, which is included with the machine, for the adjustment procedure.

If you cannot adjust the valve clearance, contact your Authorized Toro Service Dealer.

Fuel System Maintenance

⚠ DANGER

Under certain conditions, diesel fuel and fuel vapors are highly flammable and explosive. A fire or explosion from fuel can burn you and others and can cause property damage.

- Use a funnel and fill the fuel tank outdoors, in an open area, when the engine is off and cold. Wipe up any fuel that spills.
- Do not fill the fuel tank completely full. Add fuel to the fuel tank until the level is 25 mm (1 inch) below the bottom of the filler neck. This empty space in the tank allows the fuel to expand.
- Never smoke when handling fuel, and stay away from an open flame or where fuel fumes may be ignited by a spark.
- Store fuel in a clean, safety-approved container and keep the cap in place.

Draining Water from the Fuel Filter

Service Interval: Every 50 hours—Check the fuel-water separator for water and sediment.

1. Park the machine on a level surface, stop the engine, and remove the ignition key.
2. Open the front hood.
3. Align a drain pan under the primary fuel filter (Figure 96).




Figure 96

1. Drain valve
2. Primary fuel filter

4. Rotate the drain valve at the bottom of the primary fuel filter 2 or 3 turns counterclockwise, and drain any water and sediment from the fuel filter (Figure 96).

Note: If the fuel-water separator has any water or sediment, also drain the water and sediment from the fuel tank; refer to [Draining Water from the Fuel Tank \(page 82\)](#).

- When clean fuel appears, rotate the drain valve clockwise until it is closed.

Note: Do not overtighten the drain valve.

- Prime the fuel system; refer to [Priming the Fuel System \(page 82\)](#).

Draining Water from the Fuel Tank

- Park the machine on a level surface, stop the engine, and remove the ignition key.
- Place a drain pan under the drain plug in the fuel tank.
- Loosen the drain plug until the water and sediment drain out ([Figure 97](#)).




Figure 97

- | | |
|--------------------|--------------|
| 1. Drain-plug hole | 3. Drain pan |
| 2. Drain plug | 4. Fuel tank |

- Clean the threads on the drain plug and apply 3 layers of PTFE sealing tape.
- Clean the O-ring if it comes out.
- When clean fuel appears, install the O-ring and drain plug, and tighten the plug securely.
- Check the fuel-tank drain plug for leaks.

Priming the Fuel System

Note: Prime the fuel system whenever any of the following occurs:

- You drained water from the fuel filter.
 - You replaced the fuel filter.
 - You ran the engine until the fuel tank is empty or drained the fuel tank.
- Park the machine on a level surface, stop the engine, and remove the ignition key.
 - Open the front hood.
 - Ensure that the engine and the exhaust system are cool.
 - Ensure that the fuel tank is at least 1/4 full.
 - Rotate the BATTERY-DISCONNECT switch clockwise to the ON position.
 - Locate the PRIMING button on the top of the filter adapter for the primary fuel filter ([Figure 98](#)).




Figure 98

- | | |
|--------------------------------|-------------------|
| 1. Primary fuel-filter adapter | 2. Priming button |
|--------------------------------|-------------------|

- Press down and release the PRIMING button repeatedly until you feel resistance when pressing the PRIMING button ([Figure 98](#)).
- If the engine does not start after priming the fuel system and making several attempts to start the engine, bleed the high-pressure fuel lines; refer to your engine owner's manual or contact your Authorized Toro Service Dealer.

⚠ WARNING

The fuel system is under high pressure. Bleeding the system without proper precautions and training could result in injury to you from injected fluid or fire or explosion.

Read the engine owner's manual for the proper bleeding procedure or contact your Authorized Toro Dealer.

Replacing the Fuel Filters

Service Interval: Every 250 hours—Replace the primary and secondary fuel filters.

Replacing the Primary Fuel Filter

1. Park the machine on a level surface, stop the engine, and remove the ignition key.
2. Open the front hood; refer to [Opening the Front Hood \(page 72\)](#).
3. Place clean rags under the primary fuel filter ([Figure 98](#)).
4. Loosen the hose clamps and separate the primary fuel filter from the fuel hoses ([Figure 98](#)).


Note: Do not remove the hose clamps from the hoses.

Note: Discard the fuel filter.

5. Align the new primary fuel filter to the hoses with the arrow printed on the filter pointing forward.
6. Slip the hoses over the hose fitting of the primary fuel filter, and tighten the hose clamps ([Figure 98](#)).
7. Replace the secondary fuel filter; refer to [Replacing the Secondary Fuel Filter \(page 83\)](#).

Replacing the Secondary Fuel Filter

1. Park the machine on a level surface, stop the engine, and remove the ignition key.
2. Open the front hood; refer to [Opening the Front Hood \(page 72\)](#).
3. Align a drain pan or several rags under the secondary fuel filter and the fuel-filter adapter ([Figure 99](#)).



g023821
g023821
Figure 99

1. Secondary fuel filter
2. Filter adapter

4. Rotate the fuel filter counterclockwise and remove the fuel filter ([Figure 99](#)).

Note: Discard the fuel filter.

5. Using a clean rag, wipe clean the surface of the fuel-filter adapter where the fuel filter seats with a clean rag.
6. Fill the new fuel filter with the specified fuel.
7. Align the fuel filter to the fuel-filter adapter, and rotate it clockwise until the seal of the fuel filter contacts the fuel-filter adapter ([Figure 99](#)).

Important: Do not use a fuel filter strap wrench to install the new oil filter. The wrench can dent a fuel filter and therefore cause a leak.

8. Hand tighten the fuel filter and additional 1/2 turn ([Figure 99](#)).
9. Remove the drain pan or rags you placed in step 3 and dispose of the used fuel according to local codes.

Checking the Fuel Lines and Connections

Service Interval: Every 500 hours/Yearly (whichever comes first)—Inspect the fuel lines and connections.

Inspect the fuel lines and connections for deterioration, damage, or loose connections.

Draining and Cleaning the Fuel Tank

Service Interval: Every 1,000 hours/Yearly (whichever comes first)—Drain and clean the fuel tank.

Drain and clean the tank if the fuel system becomes contaminated or if the machine will be stored for an extended period of time. Use clean fuel to flush out the tank. Refer to [Draining Water from the Fuel Tank \(page 82\)](#) for draining instructions.

Note: Perform this procedure when the fuel level is low, to avoid draining a large volume of fuel.

Electrical System Maintenance

Battery Safety

- Turn off the battery-disconnect switch before repairing the machine.
- Charge the battery in an open, well-ventilated area, away from sparks and flames. Unplug the charger before connecting or disconnecting the battery. Wear protective clothing and use insulated tools.

Servicing the Battery

Service Interval: Every 50 hours—Check the battery condition.

Important: Before welding on the machine, disconnect the negative cable from the battery to prevent damage to the electrical system. Also, disconnect the engine and machine controller before welding on the machine.

Note: Check the battery condition weekly or after every 50 hours of operation. Keep the terminals and the entire battery case clean because a dirty battery discharges slowly. To clean the battery, wash the entire case with a solution of baking soda and water. Rinse with clear water. Coat the battery posts and cable connectors with Grafo 112X (skin-over) grease (Toro Part No. 505-47) or petroleum jelly to prevent corrosion.

WARNING

Exposure to battery acid or a battery explosion can cause serious personal injury.

Before you service a battery, wear face protection, protective gloves, and protective clothing.

⚠ WARNING

A battery contains sulfuric acid, which can cause serious burns; and it can produce explosive gases.

- Avoid contact with skin, eyes, or clothing; flush affected areas with water.
- If taken internally, drink large quantities of water or milk. *Do not* induce vomiting. Seek medical attention immediately.
- Keep sparks, flames, and lit cigarettes and cigars away from the battery.
- Ventilate the battery when you are charging it or using it in an enclosed area.
- Wear eye protection when working near a battery.
- Wash your hands after handling a battery.
- Keep the battery out of the reach of children.

⚠ WARNING

If you try to charge or jump start a frozen battery, it could be explosive, causing personal injury to you or others in the area.

To prevent the battery electrolyte from freezing, keep the battery fully charged.

⚠ WARNING

- Sparks or a flame can cause hydrogen gas in a battery to explode.
- When you disconnect the battery cables, disconnect the negative (-) cable first.
- When you connect the battery cables, connect the negative (-) cable last.
- Do not short-circuit the battery posts with a metal object.
- Do not weld, grind, or smoke near a battery.

Note: The electrical system in this machine is 12 volts.

Charging the Battery

⚠ WARNING

Charging the battery produces gasses that can explode.

Do not smoke near the battery, and keep sparks and flames away from the battery.

Important: Keep the battery fully charged. This is especially important to prevent battery damage when the temperature is below 32°F (0°C).

1. Park the machine on a level surface, stop the engine, and remove the ignition key.
2. Open the front hood.
3. Clean the exterior of the battery case and the battery posts.

Note: Connect the leads of the battery charger to battery posts before connecting the charger to the electrical source.

4. Look at the battery and identify the positive and negative battery posts.
5. Connect the positive lead of the battery charger to the positive battery post (Figure 100).




Figure 100

- | | |
|--------------------------|---------------------------|
| 1. Positive battery post | 3. Red (+) charger lead |
| 2. Negative battery post | 4. Black (-) charger lead |

6. Connect the negative lead of the battery charger to the negative-battery post (Figure 100).
7. Connect the battery charger to the electrical source, and charge the battery according to the Battery-charging Table that follows.

Important: Do not overcharge the battery.

Battery-charger Table

Charger setting	Charging time
4 to 6 amperes	30 minutes
25 to 30 amperes	10 to 15 minutes

- When the battery is fully charged, unplug the charger from the electrical source, then disconnect the charger leads from the battery posts (Figure 100).

Jump-Starting the Machine

⚠ WARNING

Jump-starting the battery can produce gasses that can explode.

Do not smoke near the battery, and keep sparks and flames away from battery.

Note: This procedure requires 2 people to perform. Ensure that the person making the connections wears the proper face protection, protective gloves, and clothing.

- Park the machine on a level surface, stop the engine, and remove the ignition key.
- Open the front hood.
- Ensure that all controls are in the NEUTRAL position.
- Sit in the operator seat and have the other person make the connections.

Note: Ensure that the jumper battery is a 12-volt battery.

Important: If you are using another machine for power, ensure that the 2 machines are not touching each other.

- Prepare to start the engine; refer to [Starting and Stopping the Engine \(page 52\)](#).
- Remove the cover from the jump post (Figure 101).




Figure 101

- Ground point (unpainted bolt)
 - Jumper-cable clamp (negative)
 - Jump post
 - Cover
 - Jumper-cable clamp (positive)
- Connect the positive (+) jumper cable to the jump post (Figure 101).
 - Connect the negative (-) jumper cable to a ground point, such as an unpainted bolt or chassis member (Figure 101).
 - Start the engine; refer to [Starting and Stopping the Engine \(page 52\)](#).
- Important:** If the engine starts and then stops, *do not* operate the starter motor until the starter motor stops turning. *Do not* operate the starter motor for more than 30 seconds at one time. Wait 30 seconds before operating the starter motor to cool the motor and to build up the charge in the battery.
- When the engine starts, have the other person disconnect the negative (-) jumper cable from the frame and then disconnect the positive (+) jumper cable (Figure 101).

Drive System Maintenance

Checking the Oil Level for the Stakedown Planetary Drive

Service Interval: After the first 100 hours—Check the stakedown planetary-drive oil level (Also, check if external leakage is observed).

Every 500 hours—Check the stakedown planetary-drive oil level (Also, check if external leakage is observed).

Oil specification: SAE 85W-140 API classification level GL4

Planetary-drive oil capacity: approximately 1.2 L (2.5 US pt)

Toro Premium Gear Oil is available from an Authorized Toro Service Dealer. See the parts catalog for part numbers.

1. Check the oil level on the sight-glass on each stakedown planetary drive (Figure 102).

Note: The oil level should cover half of the sight-glass.




Figure 102

1. Sight-glass
2. Breather cap

2. Remove the breather cap and add the oil into the planetary drive until the oil level on the sight-glass is at least half full (Figure 102).
3. Repeat for the other stakedown planetary.

Checking the Oil Level for the Tracks Planetary Drive

Service Interval: Every 50 hours—Check the tracks rotary motor planetary-drive oil level (Also, check if external leakage is observed).

Oil specification: SAE 85W-140 API classification level GL4

Planetary-drive oil capacity: approximately 1.4 L (1.5 US pt)

Toro Premium Gear Oil is available from an Authorized Toro Service Dealer. See the parts catalog for part numbers.

1. Park the machine on a level surface, stop the engine, and remove the ignition key.
2. Clean the area around the oil-level plug with a cleaning solvent (Figure 103).




Figure 103

1. Oil-level plug
2. Oil-drain plug (6 o'clock position)

3. Remove the oil-level plug (Figure 103).

Note: The oil level is correct when it is up to the bottom of the oil-level plug hole.

4. If the oil is below the bottom of the hole, add the specified oil until the oil is level with the bottom of the hole.
5. Install and tighten the oil-level plug.

Changing the Oil for the Tracks Planetary Drive

Service Interval: After the first 250 hours—Change the planetary-drive oil.

Every 800 hours—Change the planetary-drive oil (or yearly, whichever comes first).

Note: Change the oil when it is warm, if possible.

1. Park the machine on a level surface.
2. Clean the area around the oil-level plug (Figure 103).
3. Rotate the planetary drive until the oil-drain plug is directly below the oil-level plug (Figure 103).
4. Stop the engine and remove the key.
5. Place a drain pan under the oil-drain plug.
6. Remove the oil-level plug and the oil-drain plug.
7. Install the oil-drain plug.
8. Fill the chain drive planetary with oil until the oil is even with the bottom of the oil-level plug hole.
9. Install the oil-level plug.
10. Repeat steps 1 through 9 to change the planetary-drive oil on the other side of the machine.

Checking the Oil Level for the Rotary Motor Planetary Drive

Service Interval: After the first 100 hours—Check the rotary motor planetary-drive oil level (Also, check if external leakage is observed).

Every 500 hours—Check the rotary motor planetary-drive oil level (Also, check if external leakage is observed).

Oil specification: SAE 85W-140 API classification level GL4

Planetary-drive oil capacity: approximately 0.24 L (0.5 US pt)

Toro Premium Gear Oil is available from an Authorized Toro Service Dealer. See the parts catalog for part numbers.

1. Park the machine on a level surface, stop the engine, and remove the ignition key.
2. Check the oil level on the sight-glass on the rotary motor planetary drive (Figure 104).

Note: The oil level should be 3/4 full in the sight-glass.




Figure 104

1. Rotary motor oil cap
2. Sight-glass

3. If the oil level is low, remove the oil-level plug (Figure 104).
4. Install and tighten the oil-level plug.

Checking the Oil for the Thrust Motor Planetary Drive

Service Interval: After the first 100 hours—Check the thrust motor planetary-drive oil.

Every 500 hours—Check the thrust motor planetary-drive oil (or yearly, whichever comes first).

Oil specification: SAE 85W-140 API classification level GL4

Planetary-drive oil capacity: approximately 0.24 L (0.5 US pt)

1. Park the machine on a level surface, stop the engine, and remove the ignition key.
2. Check the oil level on the sight-glass on each thrust motor planetary drive (Figure 106).

Note: The oil level should cover half of the sight-glass.




Figure 105

1. Breather cap
2. Sight-glass

3. Remove the breather cap and add the oil into the planetary drive until the oil level on the sight-glass is at least half full (Figure 106).
4. Repeat for all 4 thrust motor planetary drives.

Checking the Oil for the Gearbox Drive

Service Interval: After the first 100 hours—Check the gearbox drive oil.

Every 500 hours—Check the gearbox drive oil (or yearly, whichever comes first).

Oil specification: SAE 85W-140 API classification level GL4

Planetary-drive oil capacity: approximately 2.7 L (5.75 US pt)

1. Park the machine on a level surface, stop the engine, and remove the ignition key.
2. Check the oil level on the sight-glass on the gearbox drive (Figure 106).

Note: The oil level should cover half of the sight-glass.




Figure 106

1. Sight-glass

3. Remove the breather cap and add the oil into the gearbox drive until the oil level on the sight-glass is at least half full (Figure 106).

Changing the Oil for the Gearbox Drive

Service Interval: After the first 100 hours—Change the gearbox-drive oil.

Every 500 hours—Change the gearbox-drive oil (or yearly, whichever comes first).

Note: Change the oil when it is warm, if possible.

1. Park the machine on a level surface and move the carriage all the way to the rear stop.




Figure 107

2. Stop the engine and remove the ignition key.

3. Remove the 2 bolts and nuts on the carriage guard (Box B of [Figure 107](#)).
4. Remove the 2 bolts and nuts on the side of the carriage guard (Box C of [Figure 107](#)).
5. Slide the carriage guard forward (Box D of [Figure 107](#)).
6. Remove the 6 bolts on the gearbox (Box E of [Figure 107](#)).
7. Remove the cover on the gearbox and syphon the oil out (Box F of [Figure 107](#)).
8. Fill the gearbox with oil until the oil level in the sight glass is more than half full ([Figure 106](#)).
9. Clean the sealant off of the gearbox box and cover ([Figure 108](#)).




Figure 108

10. Put new automotive-grade RTV sealant around the edge of the cover (Box B of [Figure 108](#)).
11. Slide the cover back onto the gearbox and loosely install the 6 bolts (Box E of [Figure 107](#)).
12. Place the carriage guard back into place and loosely install the 2 bolts (Box C of [Figure 107](#)).
13. Install the 2 bolts securing the carriage guard onto the gearbox (Box B of [Figure 107](#)).
14. Tighten the 6 bolts on the gearbox and the 2 bolts on the side of the carriage guard.

Servicing the Tracks

Service Interval: Before each use or daily—Check the track tension.

⚠ WARNING

Grease in the hydraulic track is highly pressurized; ensure that the track-tension grease valve is not loosened more than 1 revolution at a time.

If you remove the track-tension grease valve (found in the hydraulic-track tensioner) or loosen it too much, grease can be released and may cause serious injury or death.

Tightening the Track Tension

If the track seems loose, tighten the track tension as follows:

1. Park the machine on a level surface, stop the engine, and remove the ignition key.
2. Remove dirt and debris found around the track-tension grease valve ([Figure 109](#)).

Important: Ensure that the area surrounding the track-tension grease valve is clean before beginning to adjust the track tension.

3. Remove the retaining bolts and cover that house the track-tension grease valve.
4. Apply grease to the fitting until the tension reaches 31,026 kPa (4,500 psi) as shown in [Figure 109](#).




Figure 109

Track-tension grease valve shown

5. Remove excess grease from around the valve.
6. Install the cover and retaining bolts.
7. Repeat steps [2](#) through [6](#) to tighten the track tension on the other side.

Loosening the Track Tension

If the track seems tight, loosen the track tension as follows:

1. Park the machine on a level surface, stop the engine, and remove the ignition key.
2. Remove dirt and debris found around the track-tension grease valve (Figure 109).

Important: Ensure that the entire area surrounding the track-tension grease valve is clean before beginning to adjust the track tension.

3. Remove the retaining bolts and the cover that house the track-tension grease valve.
4. Turn the track-tension grease valve counterclockwise **no more than 1 revolution** (Figure 109).
Note: A 1-revolution turn will release grease and loosen the track.
5. When the tension reaches 31,026 kPa (4,500 psi), turn the track-tension grease valve clockwise to tighten it.
6. Remove excess grease from around the valve.
7. Install the cover and retaining bolts.
8. Repeat steps 2 through 7 to loosen the track tension on the other side.

Cooling System Maintenance

Coolant specification: 50/50 solution of ethylene-glycol antifreeze and water or equivalent

Engine and Radiator coolant capacity: 16.8 L (17.7 US qt)

⚠ WARNING

If you remove the radiator cap from a hot engine, hot coolant could spray, causing scalding.

- Wear face protection when opening the radiator cap.
- Allow the cooling system to cool down to below 50°C (120°F) before removing the radiator cap.
- Follow the instructions for checking and maintaining the engine cooling system.

⚠ WARNING

Coolant is toxic.

- Keep coolant away from children and pets.
- If you are not using the same coolant again, dispose of it according to local environmental regulations.

Cooling System Safety

- Swallowing engine coolant can cause poisoning; keep it out of reach of children and pets.
- Discharge of hot, pressurized coolant or touching a hot radiator and surrounding parts can cause severe burns.
 - Always allow the engine to cool at least 15 minutes before removing the radiator cap.
 - Use a rag when opening the radiator cap, and open the cap slowly to allow steam to escape.




Figure 110

1. Coolant tank sight gauge 2. End of the radiator tank

Checking the Coolant Level in the Radiator

Service Interval: Before each use or daily

⚠ WARNING

If the engine has been running, the radiator will be pressurized and the coolant inside will be hot. If you remove the cap, coolant may spray out, causing severe burns.

Do not remove the radiator cap when the engine is hot. Allow the engine to cool for at least 15 minutes or until the radiator cap is cool enough to touch without burning your hand.

Note: The cooling system is filled with a 50/50 solution of water and ethylene-glycol antifreeze.

1. Park the machine on a level surface, stop the engine, and remove the ignition key.
2. Allow the engine to cool.
3. Open the rear-access door.
4. Check the coolant level by looking at the sight gauge at the end of the radiator tank ([Figure 110](#)).

- If the coolant level is low, add coolant until the level is up to the bottom of the filler neck; refer to [Filling the System with Coolant \(page 96\)](#).

Important: Do not overfill the radiator.

- If the coolant level is normal, close the rear-access door.

Checking the Condition of Cooling-System Components

Service Interval: Every 300 hours/Yearly (whichever comes first)

Check the condition of the cooling system for leaks, damage, dirt, and loose hoses and clamps. Clean, repair, tighten, and replace the components as necessary.

Checking the Concentration of the Coolant

Service Interval: Every 1,000 hours/Yearly (whichever comes first)—Check the concentration of the coolant before the winter season.

Test the concentration of ethylene glycol-based antifreeze in the coolant. Ensure that the coolant has a 50% ethylene glycol and 50% water mixture or equivalent.

Note: A 50% ethylene glycol and 50% water mixture will protect the engine to -37° C (-34° F) throughout the year.

Using a concentration tester, check the concentration of the coolant mixture to ensure that it is 50% ethylene glycol and 50% water or equivalent; refer to the manufacturer's instructions for testing.

Cleaning the Cooling System

Service Interval: Every 1,000 hours/Yearly (whichever comes first) (Clean the cooling system if the coolant becomes dirty or rust colored.)

Draining the Coolant from the System

Important: Do not pour coolant onto the ground or into an unapproved container that can leak.

1. Park the machine on a level surface, stop the engine, and remove the ignition key.
2. Allow the engine to cool.
3. Open the rear-access door.

Note: Look to the left when you open the rear-access door, and you will find the drain plug tucked away in the back-left corner.

4. Place a drain pan under the drain plug (Figure 111).

Note: The coolant capacity of both the engine and the radiator is 16.8 L (17.7 US qt).




Figure 111

1. Radiator drain plug

5. Open the drain plug for the radiator and allow the coolant system to drain completely.

Note: Dispose of the used coolant properly according to local codes.

6. Clean the threads on the drain plug and apply 3 layers of PTFE sealing tape.
7. Close the drain plug (Figure 111).

Flushing the Cooling System

Engine and radiator coolant capacity: 16.8 L (17.7 US qt)

1. Park the machine on a level surface, stop the engine, and remove the ignition key.
2. Condition the cooling system as follows:
 - A. Ensure that the coolant is drained from the radiator and that the drain plug is closed; refer to [Draining the Coolant from the System](#) (page 94).
 - B. Add a cooling system cleaning solution to the radiator through the filler neck (Figure 112).

Note: Use cleaning solution of 21 g (12 oz dry) of sodium carbonate for every 17 L (18 US qt) of water; otherwise, use a commercially available equivalent. Follow the directions that come with the cleaning solution.




Figure 112

1. Filler neck (radiator)
2. Funnel
3. Coolant-system cleaning solution

- C. Close the drain plug (Figure 111).

Important: Do not install the radiator cap.

- D. Operate the engine for 5 minutes or until the coolant temperature indicates 82° C (180° F), and then stop the engine.

⚠ CAUTION

The cleaning solution is hot and can cause burns.

Stay away from the discharge end of the coolant drain plug.

- E. Open the drain plug for the radiator, and drain the cleaning solution into a drain pan.

- F. Clean the threads on the drain plug and apply 3 layers of PTFE sealing tape.

- G. Close the drain plug.

3. Flush the cooling system as follows:

- A. Open the filler-neck cap.

- B. Fill the radiator with clean water (Figure 113).




Figure 113

1. Filler neck
2. Funnel
3. Clean water

- C. Close the filler-neck cap.

- D. Operate the engine for 5 minutes or until the coolant temperature indicates 82° C (180° F), and then stop the engine.

⚠ CAUTION

The water is hot and can cause burns.

Stay away from the discharge end of the coolant drain plug.

- E. Open the drain plug and drain the water into a drain pan.

- F. Clean the threads on the drain plug and apply 3 layers of PTFE sealing tape.

- G. If the water drained from the radiator is dirty, perform steps 3-A through 3-E until the water drained from the radiator is clean.

- H. Close the drain plug (Figure 111).

Filling the System with Coolant

Important: You must fill the cooling system properly to prevent air locks in the cooling passages. Failing to vent the cooling system properly can severely damage the cooling system and engine.

Important: Use a mixture of 50% ethylene glycol and 50% water mixture or equivalent in the machine. The lowest ambient operating temperature for this mixture is above -37° C (-34° F). If the ambient temperature is lower, adjust the mixture. Use a mixture of ethylene glycol and water or equivalent in the machine all year.

1. Park the machine on a level surface, stop the engine, and remove the ignition key.
2. Remove the bolts from the coolant-access cover between the front hood and the rear cover.




Figure 114

1. Coolant-access cover
2. Bolts

3. Remove the radiator cap (Figure 115).




Figure 115

1. Radiator cap

4. Fill the radiator with coolant until the fluid level is up to the bottom of the filler neck (Figure 116).

Note: The coolant capacity of both the engine and the radiator is 16.8 L (17.7 US qt).




Figure 116

1. Coolant level (at the bottom of the filler neck)
2. Filler neck
3. Coolant (50/50 ethylene glycol and water or equivalent)

5. Install the radiator filler cap, ensuring that it is tightly sealed (Figure 115).
6. Start the engine and run it at half throttle for 5 minutes.
7. Stop the engine and remove the key.
8. Wait 30 minutes, then check the fluid level in the radiator sight gauge; refer to [Checking the Coolant Level in the Radiator](#) (page 93).

Note: If it is low, add coolant.

Belt Maintenance

Servicing the Engine-Drive Belt

⚠ WARNING

Contacting a rotating belt can cause serious injury or death.

Stop the engine and remove the ignition key before working near belts.

Checking the Condition of the Belt

Service Interval: Every 250 hours

1. Park the machine on a level surface, stop the engine, and remove the ignition key.
2. Open the front hood.
3. Inspect the belt for cuts, cracks, loose cords, grease, oil, twisting, or signs of abnormal wear ([Figure 117](#)).

Note: Replace the belt if it is excessively worn or damaged.

Checking the Tension of the Belt

Service Interval: Every 1,000 hours

1. Park the machine on a level surface, stop the engine, and remove the ignition key.
2. Open the front hood.
3. Align a straight edge over the drive belt and across the pulleys as shown in [Figure 117](#).




Figure 117

4. Press the belt down at the midway point between the fan pulley and the alternator pulley as shown in [Figure 117](#).

Note: The range of belt deflection between the straight edge and the belt should be 7 to 9 mm (9/32 to 11/32 in), under a load of 10 kg (22 lb).

5. If the tension of the belt is above or below the specified range, adjust the drive belt tension; refer to [Adjusting the Tension of the Belt](#) (page 98).

Adjusting the Tension of the Belt

1. Park the machine on a level surface, stop the engine, and remove the ignition key.
2. Open the front hood.
3. Loosen the nut and bolt at the pivot point for the alternator (Figure 118).




Figure 118

1. Adjustment bolt
2. Nut (alternator pivot point)
3. Alternator
4. Bolt (alternator pivot point)

4. Loosen the adjustment bolt on the alternator (Figure 118).
5. Move the alternator away from the engine to increase the belt tension; move the alternator toward the engine to decrease the belt tension (Figure 118).
6. Tighten the alternator adjustment bolt (Figure 118).
7. Check the tension of the belt; refer to [Checking the Tension of the Belt](#) (page 97).
8. If the belt tension is correct, tighten the nut and bolt at the pivot point for the alternator (Figure 118); otherwise, repeat steps 4 through 7.

Hydraulic System Maintenance

Hydraulic System Safety

- Seek immediate medical attention if fluid is injected into skin. Injected fluid must be surgically removed within a few hours by a doctor.
- Ensure that all hydraulic-fluid hoses and lines are in good condition and all hydraulic connections and fittings are tight before applying pressure to the hydraulic system.
- Keep your body and hands away from pinhole leaks or nozzles that eject high-pressure hydraulic fluid.
- Use cardboard or paper to find hydraulic leaks.
- Safely relieve all pressure in the hydraulic system before performing any work on the hydraulic system.

Servicing the Hydraulic Fluid

The hydraulic reservoir is filled at the factory with approximately 170 L (45 US gallons) of high-quality hydraulic fluid. **Check the level of the hydraulic fluid before the engine is first started and daily thereafter.** The recommended replacement fluid as follows:

Toro Premium All Season Hydraulic Fluid

(Available in 5 gallon pails or 55 gallon drums. Contact your Authorized Toro Dealer for part numbers.)

Alternate fluids: If the Toro fluid is not available, other fluids may be used provided they meet all the following material properties and industry specifications. We do not recommend the use of synthetic fluid. Consult with your lubricant dealer to identify a satisfactory product.

Note: Toro will not assume responsibility for damage caused by improper substitutions, so use only products from reputable manufacturers who will stand behind their recommendation.

High Viscosity Index/Low Pour Point Anti-wear Hydraulic Fluid, ISO VG 46

Material Properties:

Viscosity, ASTM D445	42.2 cSt at 40° C (104° F)
	7.8 cSt at 100° C (212° F)

Viscosity Index ASTM D2270	158
----------------------------	-----

High Viscosity Index/Low Pour Point Anti-wear Hydraulic Fluid, ISO VG 46 (cont'd.)

Pour Point, ASTM D97

-6° C (-42° F)

Industry Specifications: Vickers I-286-S (Quality Level),
Vickers M-2950-S (Quality Level), Denison HF-0

Note: Many hydraulic fluids are almost colorless, making it difficult to spot leaks. A red dye additive for the hydraulic system oil is available in 20 mL (2/3 oz) bottles. One bottle is sufficient for 15-22 L (4-6 gal) of hydraulic oil. Order hydraulic oil from your Authorized Toro Dealer.

Note: If ambient operating temperatures exceed 43° C (110° F), contact Toro for fluid recommendations.

Checking the Hydraulic Fluid

Service Interval: Before each use or daily

Check the hydraulic fluid as follows:

1. Park the machine on a level surface, stop the engine, and remove the ignition key.
2. Wait 10 minutes to allow the engine to cool and the hydraulic oil to stabilize.
3. Open the rear-access door.
4. Look at the sight gauge on the hydraulic tank and check the level of the oil (Figure 119).




Figure 119

1. Full oil level
2. Low oil level

5. If the level is low, open the hydraulic-tank cap (Figure 120), add a small amount of oil and wait 2 minutes for the oil level to stabilize in the sight gauge (Figure 119).

Note: The oil level is between 1/2 to 2/3 full in the sight gauge when the oil is at ambient

temperature or if the engine has not yet been started for the day.




Figure 120

1. Hydraulic-tank cap
6. Continue to add the appropriate fluid in small increments until it reaches Full on the sight gauge.
7. Install cap onto the filler neck.

Changing the Hydraulic Fluid

Service Interval: Every 1,000 hours/Yearly
(whichever comes first)

Important: If the fluid becomes contaminated, contact your Authorized Toro Dealer, because the system must be flushed. Contaminated fluid looks milky or black when compared to clean oil.

Important: Use of any other filter may void the warranty on some components.

1. Park the machine on a level surface, stop the engine, and remove the ignition key.
2. Open the rear-access door.
3. Raise the machine using proper equipment.

▲ WARNING

Raising the unit relying solely on mechanical or hydraulic jacks could be dangerous. The mechanical or hydraulic jacks may not be enough support or may malfunction allowing the unit to fall, which could cause injury or death.

Do not rely solely on mechanical or hydraulic jacks for support.

Use adequate jack stands or equivalent support.

4. Place a large draining container under the hydraulic fluid tank.

5. Remove the drain plug from the bottom of the tank.
6. Clean the threads on the drain plug and apply 3 layers of PTFE sealing tape.
7. Drain the hydraulic fluid flow into the container.

Important: The capacity of the hydraulic-fluid tank is 170 L (45 US gal), so ensure that you have a container of at least 182 L (48 US gal) to drain the fluid into.

8. Install the drain plug when the hydraulic fluid stops draining.
9. Fill the reservoir with hydraulic fluid.

Important: Use only the hydraulic fluids specified. Other fluids could cause system damage.

10. Install the reservoir cap.
11. Start the engine and use all of the hydraulic controls to distribute hydraulic fluid throughout the system.
12. Check for leaks, then stop the engine.
13. Check the fluid level and add enough to raise level the level to the Full mark on the dipstick.

Note: Do not overfill.

4. Rotate the hydrostatic-charge filter counterclockwise and remove the filter (Figure 121).

Note: Discard the hydrostatic-charge filter.

5. Using a clean rag, wipe clean the surface where the hydrostatic-charge filter seats with a clean rag.
6. Align the hydrostatic-charge filter to where it seats, and rotate it clockwise until the seal of the filter contacts the adapter (Figure 121).

Changing the Hydrostatic-Charge Filter

Service Interval: Every 500 hours/Every 6 months (whichever comes first)

1. Park the machine on a level surface, stop the engine, and remove the ignition key.
2. Open the front hood.
3. Align a drain pan or several rags under the hydrostatic-charge filter (Figure 121).




Figure 121

1. Hydrostatic-charge filter

Changing the High-Pressure Hydraulic Filter

Service Interval: Every 1,000 hours

⚠ WARNING

Ensure that the engine is in the OFF position before removing the high-pressure hydraulic filter. The high-pressure hydraulic filter contains very high pressure that could cause serious injury, or cause damage to the machine if released while the engine is running.

1. Park the machine on a level surface, stop the engine, and remove the ignition key.
2. Open the front hood.
3. Align a drain pan or several rags under the charge filter (Figure 122).




Figure 122

1. High-pressure hydraulic filter
-
4. Rotate the high-pressure hydraulic filter counterclockwise and remove the filter (Figure 122).
 5. Using a clean rag, wipe clean the surface where the high-pressure hydraulic filter seats with a clean rag.
 6. Align the high-pressure hydraulic filter to where it seats, and rotate it clockwise until the torque reaches 61 N-m (45 ft-lb) as shown in Figure 122.

Changing the Hydraulic-Return Filter

Service Interval: Every 1,000 hours

1. Park the machine on a level surface, stop the engine, and remove the ignition key.
2. Open the rear-access door.
3. Align a drain pan or several rags under the charge filter (Figure 123).




Figure 123

Front-side bolts shown

1. Hydraulic-return filter
 2. Bolts
-
4. With one hand under the hydraulic-return filter, remove the 4 bolts as shown in Figure 123.
- Note:** There are 2 other bolts on the back side that need to be removed.
5. Pull down and remove the filter.
 6. Using a clean rag, wipe clean the surface where the hydraulic-return filter seats with a clean rag.
 7. Align the new hydraulic return filter to where it seats, and tighten the 4 bolts (Figure 123).

Checking the Hydraulic Lines and Hoses

Service Interval: Every 2 years—Replace moving hoses.

Inspect the hydraulic lines and hoses daily for leaks, kinked lines, loose mounting supports, wear, loose fittings, weather deterioration, and chemical deterioration. Make all necessary repairs before operating.

▲ WARNING

Hydraulic fluid escaping under pressure can penetrate skin and cause injury.

- **Make sure that all hydraulic fluid hoses and lines are in good condition and all hydraulic connections and fittings are tight before applying pressure to the hydraulic system.**
- **Keep your body and hands away from pin hole leaks or nozzles that eject high-pressure hydraulic fluid.**
- **Use cardboard or paper to find hydraulic leaks.**
- **Safely relieve all pressure in the hydraulic system before performing any work on the hydraulic system.**
- **Seek immediate medical attention if fluid is injected into skin.**

Checking the Hydraulic System Test Ports

The test ports are used to test the pressure in the hydraulic circuits. Contact your Authorized Toro Dealer for assistance.

Drilling-Fluid Pump Maintenance

Servicing the Drilling-Fluid-Pump Oil

The drilling-fluid pump is shipped with oil in the crankcase; however, check the oil level before and after you first start the engine.

The crankcase capacity is 3.8 L (4 US qt).

Use only high-quality engine oil that meets the following specifications:

- **API Classification Level Required:** CH-4, CI-4 or higher
- **Oil:**SAE 80W-90, non-detergent oil above 0° C (32° F)

Toro Premium Engine Oil is available from your dealer. See the parts catalog for part numbers. Also, refer to the *Engine Operator's Manual*, included with the machine, for further recommendations.

Checking the Drilling-Fluid-Pump Oil Level

Service Interval: Before each use or daily—Check the drilling-fluid pump oil level.

1. Park the machine on a level surface, stop the engine, and remove the ignition key.
 2. Remove the oil-level plug on the crankcase (Figure 124).
 - If oil drains from the oil-level hole, insert the oil-level plug.
- Note:** The oil level is sufficient if oil drains from the opening, or is at least at the level of the oil-level plug.
- If oil does not drain from the oil-level, or is not at the level of the oil-level plug, insert the oil-level plug, and open the oil-filler cap to add the specified oil.




Figure 124

1. Oil-filler cap
 2. Oil-level plug
-
3. Ensure that the oil is at the oil-fill line as shown in Figure 124.

Note: If the oil is below the oil-fill line, refer to step 8 of [Changing the Drilling-Fluid-Pump Oil](#) (page 103) and add the necessary amount of oil.

Changing the Drilling-Fluid-Pump Oil

Service Interval: Every 500 hours—Change the drilling-fluid pump oil.

1. Park the machine on a level surface, stop the engine, and remove the ignition key.
2. Allow the engine to cool.
3. Lower the thrust frame, and ensure that the cylinder lock is installed; refer to [Using the Cylinder Lock](#) (page 73).
4. Remove the drain plug and place a drain pan under the drain-plug hole (Figure 125).




Figure 125

1. Oil-filler cap
 2. Drain plug
 3. Drain pan
-
5. Clean the threads on the drain plug and apply 3 layers of PTFE sealing tape.
 6. Allow all of the oil to drain from drain plug into the oil pan (Figure 125).
 7. Install the drain plug.
 8. Remove the oil-filler cap (Figure 125) and add approximately 1.8 L (4 US qt) of oil, or until the oil reaches the level of the oil-level plug as shown in Figure 124.

Changing the Drilling-Fluid-Pump, Charge Filter

1. Park the machine on a level surface, stop the engine, and remove the ignition key.
2. Open the front hood.
3. Align a drain pan or several rags under the charge filter ([Figure 126](#)).




Figure 126

1. Charge filter

4. Rotate the charge filter counterclockwise and remove the filter ([Figure 126](#)).
- Note:** Discard the charge filter.
5. Using a clean rag, wipe clean the surface where the charge filter seats with a clean rag.
 6. Align the charge filter to where it seats, and rotate it clockwise until the seal of the filter contacts the adapter ([Figure 126](#)).

Preparing the Drilling-Fluid System for Cold Weather

Prepare the machine as follows after drilling if the temperature will be below 0° C (32° F).

1. Park the machine on a level surface, stop the engine, and remove the ignition key.
2. Prepare the machine to circulate the antifreeze as follows:
 - A. Place a drain pan under the drill spindle for the leaked antifreeze ([Figure 127](#)).




Figure 127

1. Drill spindle
2. Drain pan

- B. Ensure that the cap is installed on the drilling-fluid pump inlet ([Figure 128](#)).




Figure 128

1. Drilling-fluid pump inlet

- C. Remove the cap from the antifreeze tank for the drilling-fluid pump ([Figure 129](#)).




Figure 129

1. Antifreeze-tank cap
2. Antifreeze tank

D. Ensure that the tank is full of antifreeze (Figure 129).

3. Circulate the antifreeze as follows:

A. Open the antifreeze valve inside of the rear compartment (Figure 130).




Figure 130

1. Antifreeze valve

B. Open the valve near the rear compartment (Figure 131).




Figure 131

1. Valve (open position)

C. Start the machine and turn On the drilling-fluid pump.

D. Add antifreeze to the tank as needed (Figure 129).

E. When the antifreeze comes out of the drill spindle (Figure 127), turn the pump off.

4. Turn the machine off.

5. Install the cap onto the antifreeze tank (Figure 129).

6. Close the antifreeze valve (Figure 130).

Cab Maintenance

Changing the Cab Air Filter

1. Open the cab door; refer to [Opening the Door \(Model with Cab only\)](#) (page 58).
2. Park the machine on a level surface, stop the engine, and remove the ignition key.
3. Remove the screw and the cover that house the air filter ([Figure 132](#)).




Figure 132

1. Screw
2. Air-filter cover

4. Remove the air filter from the housing, and replace the filter element ([Figure 133](#)).




Figure 133

1. Air filter
2. Air-filter cover
3. Screw

Filling the Windshield-Washer Fluid Tank

1. Open the cab door; refer to [Opening the Door \(Model with Cab only\)](#) (page 58).
2. Open the cap of the windshield-washer-fluid tank ([Figure 134](#)).




Figure 134

1. Windshield-washer-fluid tank
2. Windshield washer fluid-tank cap

3. Fill the windshield-washer-fluid tank until it is full ([Figure 134](#)).
4. Close the windshield-washer-fluid-tank cap ([Figure 134](#)).

Cleaning

Cleaning with the Spray-Hose Attachment

Service Interval: Before each use or daily

The machine comes with a spray-hose attachment that you can use to clean the machine and pipes.

Important: Do not spray any electronic component of the machine and ensure that the hood is down before cleaning the machine with the spray-hose attachment.

Important: If the outside temperature is below freezing, refer to [Preparing the Drilling-Fluid System for Cold Weather \(page 104\)](#) before cleaning the machine.

To use the spray-hose attachment, perform the following procedure:

1. Park the machine on a level surface.
2. Using the right joystick, turn the drilling-fluid pump to the OFF position; refer to the [Right Joystick \(page 29\)](#).
3. Ensure that there is a clean water source to attach to the drilling-fluid pump.
4. Ensure that the valve near the rear compartment is in the CLOSED position ([Figure 135](#)).




Figure 135

1. Valve

5. Connect the spray-hose attachment to the fitting ([Figure 136](#)).




Figure 136

1. Fitting for the spray-hose attachment

6. Using the right joystick, turn the drilling-fluid pump to the ON position.
 7. Adjust the drilling-fluid flow rate using the toggle switch to change the desired water pressure.
- Note:** Refer to [Right Joystick \(page 29\)](#) or [Right Joystick \(page 32\)](#) to increase or decrease the drilling-fluid flow rate.
8. Using the spray-hose attachment, hold down the lever and spray down the machine and pipes.

Cleaning Plastic and Resin Parts

Avoid using gasoline, kerosene, paint thinner, etc., when cleaning plastic windows, the console, the instrument cluster, the monitor, gauges, etc. Use only water, mild soap, and a soft cloth when you clean these parts.

Using gasoline, kerosene, paint thinner, etc., to clean a plastic or resin part will cause it to discolor, crack, or deform.

Storage

1. Stop the engine and remove the key.
2. Remove dirt and grime from the entire machine; refer to [Cleaning with the Spray-Hose Attachment \(page 107\)](#).
3. Service the air cleaner; refer to [Servicing the Air-Cleaning System \(page 76\)](#).
4. Grease the machine; refer to [Greasing the Machine \(page 74\)](#).
5. Charge the battery; refer to [Charging the Battery \(page 85\)](#).
6. Check and adjust the track tension; refer to [Servicing the Tracks \(page 91\)](#).
7. Check the coolant before winter storage; refer to [Preparing the Drilling-Fluid System for Cold Weather \(page 104\)](#).
8. Prepare the drilling-fluid pump for cold weather; refer to [Preparing the Drilling-Fluid System for Cold Weather \(page 104\)](#).
9. Check and tighten all bolts, nuts, and screws. Repair or replace any part that is damaged.
10. Paint all scratched or bare metal surfaces. Paint is available from your Authorized Service Dealer.
11. Store the machine in a clean, dry garage or storage area. Remove the key from the ignition switch and keep it in a memorable place.
12. Cover the machine to protect it and keep it clean.

Troubleshooting

Problem	Possible Cause	Corrective Action
The starter does not crank.	<ol style="list-style-type: none"> 1. The BATTERY-DISCONNECT switch is in the OFF position. 2. The electrical connections are corroded or loose. 3. A fuse is blown or loose. 4. The battery is discharged. 5. The relay or switch is damaged. 6. A starter or starter solenoid is damaged. 7. The internal engine components have seized. 	<ol style="list-style-type: none"> 1. Turn the BATTERY-DISCONNECT switch to the ON position. 2. Check the electrical connections for good contact. 3. Correct or replace the fuse. 4. Charge the battery or replace it. 5. Contact your Authorized Service Dealer. 6. Contact your Authorized Service Dealer. 7. Contact your Authorized Service Dealer.
The engine cranks, but does not start.	<ol style="list-style-type: none"> 1. An incorrect starting procedure was used. 2. The fuel tank is empty. 3. The fuel shut-off valve is closed. 4. Dirt, water, stale fuel, or incorrect fuel is in the fuel system. 5. The fuel line is clogged. 6. There is air in the fuel. 7. The glow plugs are inoperative. 8. The cranking speed is slow. 9. The air cleaner filters are dirty. 10. The fuel filter is clogged. 11. The fuel grade is improper for cold weather use. 12. There is low compression. 13. The injection nozzles or pump are malfunctioning. 14. The ETR solenoid is broken. 	<ol style="list-style-type: none"> 1. Refer to Starting and Stopping the Engine. 2. Fill the tank with fresh fuel. 3. Open the fuel shut-off valve. 4. Drain and flush the fuel system, then add fresh fuel. 5. Clean or replace the fuel line. 6. Bleed the nozzles and check for air leaks at the fuel hose connections and fittings between the fuel tank and the engine. 7. Check the fuse, glow plugs, and wiring. 8. Check the battery, oil viscosity, and starting motor (contact your Authorized Service Dealer). 9. Service the air filters. 10. Replace the fuel filter. 11. Drain the fuel system and replace the fuel filter. Add fresh fuel of the proper grade for ambient temperature conditions. You may need to warm the entire machine. 12. Contact your Authorized Service Dealer. 13. Contact your Authorized Service Dealer. 14. Contact your Authorized Service Dealer.

Problem	Possible Cause	Corrective Action
The engine starts, but does not keep running.	<ol style="list-style-type: none"> 1. The fuel tank vent is restricted. 2. Dirt or water is in the fuel system. 3. The fuel filter is clogged. 4. There is air in the fuel. 5. The fuel grade is improper for cold weather use. 6. The spark arrestor screen is clogged. 7. The fuel pump is damaged. 	<ol style="list-style-type: none"> 1. Loosen the cap. If the engine runs with the cap loosened, replace the cap. 2. Drain and flush the fuel system; add fresh fuel. 3. Replace the fuel filter. 4. Bleed the nozzles and check for air leaks at fuel hose connections and fittings between the fuel tank and engine. 5. Drain the fuel system and replace the fuel filter. Add fresh fuel of proper grade for ambient temperature conditions. 6. Clean or replace the spark arrestor screen. 7. Contact your Authorized Service Dealer.
The engine runs, but knocks or misses.	<ol style="list-style-type: none"> 1. Dirt, water, stale fuel, or incorrect fuel is in the fuel system. 2. There is air in the fuel. 3. The injection nozzles are damaged. 4. There is low compression. 5. The injection pump timing is incorrect. 6. There is excessive carbon buildup. 7. There is internal wear or damage. 	<ol style="list-style-type: none"> 1. Drain and flush the fuel system; add fresh fuel. 2. Bleed nozzles and check for air leaks at the fuel hose connections and fittings between the fuel tank and engine. 3. Contact your Authorized Service Dealer. 4. Contact your Authorized Service Dealer. 5. Contact your Authorized Service Dealer. 6. Contact your Authorized Service Dealer. 7. Contact your Authorized Service Dealer.
The engine does not idle.	<ol style="list-style-type: none"> 1. The fuel tank vent is restricted. 2. Dirt, water, stale fuel, or incorrect fuel is in the fuel system. 3. The air cleaner filters are dirty. 4. The fuel filter is clogged. 5. There is air in the fuel. 6. The fuel pump is damaged. 7. There is low compression. 	<ol style="list-style-type: none"> 1. Loosen the cap. If the engine runs with the cap loosened, replace the cap. 2. Drain and flush the fuel system; add fresh fuel. 3. Service the air filters. 4. Replace the fuel filter. 5. Bleed the nozzles and check for air leaks at fuel hose connections and fittings between the fuel tank and engine. 6. Contact your Authorized Service Dealer. 7. Contact your Authorized Service Dealer.

Problem	Possible Cause	Corrective Action
The engine overheats.	<ol style="list-style-type: none"> 1. More coolant is needed. 2. There is restricted air flow to the radiator. 3. The crankcase oil level is incorrect. 4. There is excessive loading. 5. The incorrect fuel is in the fuel system. 6. The thermostat is damaged. 7. The fan belt is loose or broken. 8. Injection timing is incorrect. 9. The coolant pump is damaged. 	<ol style="list-style-type: none"> 1. Check and add coolant. 2. Inspect and clean the side panel screens with every use. 3. Fill or drain to the full mark. 4. Reduce the load and use a lower ground speed. 5. Drain and flush the fuel system; add fresh fuel. 6. Contact your Authorized Service Dealer. 7. Contact your Authorized Service Dealer. 8. Contact your Authorized Service Dealer. 9. Contact your Authorized Service Dealer.
There is excessive black smoke in the exhaust.	<ol style="list-style-type: none"> 1. There is excessive loading. 2. The air cleaner filters are dirty. 3. Incorrect fuel is in the fuel system. 4. The injection pump timing is incorrect. 5. The injection pump is damaged. 6. The injection nozzles are damaged. 	<ol style="list-style-type: none"> 1. Reduce the load and use a lower ground speed. 2. Service the air filters. 3. Drain the fuel system and refill with specified fuel. 4. Contact your Authorized Service Dealer. 5. Contact your Authorized Service Dealer. 6. Contact your Authorized Service Dealer.
There is excessive white smoke in the exhaust.	<ol style="list-style-type: none"> 1. The engine temperature is low. 2. The glow plugs are inoperative. 3. The injection pump timing is incorrect. 4. The injection nozzles are damaged. 5. There is low compression. 	<ol style="list-style-type: none"> 1. Check the thermostat. 2. Check the fuse, glow plugs, and wiring. 3. Contact your Authorized Service Dealer. 4. Contact your Authorized Service Dealer. 5. Contact your Authorized Service Dealer.
The engine loses power.	<ol style="list-style-type: none"> 1. The engine load is excessive. 2. The crankcase oil level is incorrect. 3. The air cleaner filters are dirty. 4. Dirt, water, stale fuel, or incorrect fuel is in the fuel system. 5. The spark arrestor screen is clogged. 6. There is air in the fuel. 7. There is low compression. 8. The fuel tank vent is restricted. 9. The injection pump timing is incorrect. 10. The injection pump is damaged. 	<ol style="list-style-type: none"> 1. Reduce ground speed. 2. Fill or drain to the full mark. 3. Service the air filters. 4. Drain and flush the fuel system; add fresh fuel. 5. Clean or replace the spark arrestor screen. 6. Bleed the nozzles and check for air leaks at fuel hose connections and fittings between the fuel tank and engine. 7. Contact your Authorized Service Dealer. 8. Contact your Authorized Service Dealer. 9. Contact your Authorized Service Dealer. 10. Contact your Authorized Service Dealer.

Index

811 4, 38–39

A

Accessories 37
Adding drill pipes 63
Adding fuel 51
After Operation Safety 66
Air conditioning the cab 58
Air filter
 Cab
 Changing 106
Air-cleaning system
 Checking the air-cleaner indicator 78
 Cleaning the dust valve 78
 Cover latch 77
 Installing the cover 78
 Removing the cover 77
 Servicing 108
 Servicing the air-cleaner cover 77
 Servicing the filters 78
Antifreeze tank
 Drilling-fluid system 105
Attachments 37
Auto-drill-speed controls 28

B

Backreaming 64
Battery
 Charging 108
 Disconnect switch 52
 Jump-starting 86
 Safety 84
 Servicing 84
Battery-disconnect switch 52
Before operation safety 38
Beginning-of-bore-at-depth point 42
Belt
 Engine-drive
 Adjusting tension 98
 Checking condition 97
 Checking tension 98
Bent blade 61
Bentonite clay 56
Biodiesel fuel
 (See Fuel)
Bits
 Drill 61
Blade
 bent 61
 Straight 61
 Triangle point (rock) 61
Bleeding the fuel system
 (See Priming the fuel system)
Bore
 Adding drill pipes 63
 Beginning-of, at-depth point 42
 Depth 42
 Depth table 42
 Drilling 60
 End-of, at-depth point 42
 Entry 42
 Determining 42
 Entry pitch 42
 Entry shaft 63
 Exit 42
 Exiting 64

Horizontal shaft 64
Mapping 46
Marking and preparing 47
Obstacles 42
Planning 39, 42
Starting the first pipe 60
Steering 64
Boring the entry shaft 63
Breakout-wrench-control switch 36
Button
 Engine-start 27
 Engine-stop 27, 34, 86
 Front
 Left joystick 28
 Right joystick 29
 Lower
 Left joystick 28
 Right joystick 29
 Rear
 Left joystick 28
 Right joystick 29

C

Cab
 Air filter
 Changing 106
 Airconditioning 58
 Heating 58
 Location 23, 25
 Opening the door 106
 Windshield wipers 59
 Windshield-washer fluid 59
Cam
 (See Pipe cam)
Cam-rotation-control switch 36
Carbide step-wing cutter 64
Carriage
 (See Drill carriage)
Carriage-control switch 36
Cast cone packer 64
Changing the cab air filter 106
Changing the high-pressure hydraulic
 filter 101
Changing the hydraulic-return filter 101
Changing the hydrostatic-charge filter 100
Charging the battery 108
Cleaning 107
Cleaning the crankcase-vent tube 76
Cold weather
 Preparation 108
Communication lines
 Safety precautions 7
Connecting the reamer and product 65
Control panel 27
 Location 23, 26
 Rear 33
Controls
 Auto-drill speed 28
 Drill frame 34
 Drill pendant 35
 Drilling fluid 29
 Drive pendant 34, 52
 Section contents 26
 Stabilizer 34
 Stake-down levers 37, 55
Coolant
 Capacity 92
 Checking the concentration 94

Checking the level in the radiator 96
Draining 95
Filling 96
Flushing 95
Specification 92
Cooling system
 Checking the condition of components 94
 Cleaning 94
 Coolant concentration
 Checking 94
 Coolant level in the radiator
 Checking 96
 Draining 95
 Filling 96
 Flushing 95
Crystalline silica
 Safety precautions 39
Cylinder lock 103
 Installing 73
 Removing 73

D

Danger zone
 Drilling 6
 Driving 5
Decals 8
Deploying the Zap-alert system 54
Depth table 42
Determining the bore-entry point 42
Diesel fuel
 (See Fuel)
Directional Drilling
 Concept 38
Disabled machine
 Moving 68
Door
 Opening 77
 Rear-access
 Location 23
Draining the fuel tank 84
Draining water
 Fuel filter 81
 Fuel tank 84
Drill bits 61
Drill carriage
 Location 23, 25
 Pull rearward 29
 Thrust forward 29
Drill frame
 Controls 34
Drill head
 Installing 62
 Setup 61
 Steering 64
Drill pendant 35
Drill pipe
 Adding 63
 Loading into the pipe holder 55
 Removing 66
 Starting the first 60
 Wiper 65
Drill spindle
 Location 25
Drill-frame tilt lever 34
Drill-pendant receptacle 33, 35
Drill-spindle-control switch 36
Drilling
 Adding drill pipes 63

Directional		Reset switch	27	High-pressure hydraulic filter	
Concept	38	System	33	Changing	101
Entry shaft	63	Transmitter	33	Hood	
Horizontal shaft	64	Exiting the ground	64	Front	
Setting up	53	F		Location	23
Starting the first pipe	60	Filter		Opening	83
Steering	64	Air-cleaner	78	Rear	
Drilling danger zone	6	Charge (for the drilling fluid pump)	104	Location	23
Drilling fluid		Changing	104	Horizontal Directional Drilling	
Pump		Fuel		(See Directional Drilling)	
Changing the charge filter	104	Draining water	81	Horizontal shaft	
Changing the oil	103	High-pressure hydraulic		Boring	64
Checking the oil level	103	Changing	101	Hydraulic fluid	
Connecting to a fluid source	56	Hydraulic-return		Changing	99
Connecting to a natural water		Changing	101	Checking	99
source	57	Hydrostatic-charge		Servicing	98
Connecting to mixing system	56	Changing	100	Specifications	98
Servicing the oil	102	Fluid		Hydraulic system	
Drilling Fluid and Wrench-control switch	36	Hydraulic		Lines and hoses	
Drilling fluid controls	29	Changing	99	Checking	102
Drilling safety	6	Checking	99	Test ports	102
Drilling-fluid system		Servicing	98	Hydraulic-return filter	
Cold weather preparation	108	Specifications	98	Changing	101
Drilling-fluid-pump inlet		Windshield-washer		Hydrostatic-charge filter	
Location	24	Dispersing	59	Changing	100
Drive pendant	34, 52	Filling the tank	106	I	
Drive-direction joystick	34	Fluid-pump switch	33	Indicator	
Drive/drill switch	27	Flushing the cooling system	95	Air-cleaner	78
Drive-pendant receptacle	33–35, 52	Fluted reamer	64	Ignition switch	33
Drive-speed switch	34–35	Frame		Initial planning	39
Driving danger zone	5	Location	23, 25	Inspecting the job site	39
Driving the machine	52	Front button		Installing the drill head	62
During operation safety	59	Left joystick	28	J	
Dust valve		Right joystick	29	Job site	
Cleaning	78	Front hood		Inspecting	39
E		Location	23	Preparation	47
Electric strike alarm		Opening	83	Joystick	
(See Zap-Alert system)		Fuel		Drive-direction	34
Electrical lines		Adding	51	Left	31
Safety precautions	7, 39	Checking lines and connections	84	Location	26
End-of-bore-at-depth point	42	Filter		Setup	30
Engine		Draining water	81	Right	107
Cooling system	92	Fuel filters		Location	26
Drive belt		Replacing	83	Setup	30, 107
Servicing	97	Priming	82	Joysticks	
Jump-starting	86	Safety precautions	51	Setup	30
Key Switch	33	Tank		Joysticks in Setup Mode	
Oil		Draining and cleaning	84	Joystick	30
Changing	80	Draining water	84	Jump-starting the machine	86
Checking the level	81	Tank capacity	51	L	
Oil filter		G		Labels	
Changing	81	Gas lines		(See Decals)	
Servicing the Air-cleaning system	108	Safety precautions	7, 39	Latch	
Servicing the Oil and Filter	81	Gearbox drive		Operator-platform	26
Speed switch	27, 34	Changing the oil	90	Lead bar	
Start button	27	Checking the oil	90	Installing	62
Starting	86	Greasing the machine	74	Removing	66
Stop button	27, 34	Gripper		Left joystick	
Stopping	86	(See Pipe gripper)		Location	26
Valve clearance	81	(See Piper gripper)		Left Joystick	31
Vent tube		Ground-strike-reset switch	27	Setup Mode	30
(See Cleaning)		Grounding stake		Left-stabilizer lever	34
Engine-heating light	33	Storage	49	Left-track-control switch	35
Entry pitch	42	H		Length	37
Entry shaft		Heating the cab	58	Lever	
Boring	63	Height	37	Drill-frame tilt	34
Exit-side lockout					
Drill-enabled light	27				
Receiver	33				
Reset light	27				

Left-stabilizer.....	34	Changing	90	Location.....	24
Right-stabilizer	34	Checking.....	90	Platform	
Stake-down	37, 55	Planetary drive		Operator	67
Life jacket pendant		Changing	88	Latch	26
(See Drill pendant)		Rotary motor planetary drive		Pre-Maintenance Safety	72
Lifting the machine	68	Checking the level	89	Preparing for drilling.....	53
Light		Stakedown planetary drive		Preparing the job site and machine.....	47
Drill-enabled		Checking the level	87	Priming the fuel system.....	82
Exit-side lockout.....	27	Thrust motor planetary drive		Product	
Engine-heating.....	33	Checking.....	89	Connecting to a reamer	65
Exit-side-lockout	27	Tracks planetary drive		Product overview illustration	
Receiver-battery-status	27	Checking the level	87	Left side	24
Reset		Oil Filter		Right side.....	23
Exit-side lockout.....	27	Changing	81	Top view	25
Lights switch.....	27	One-Call System Directory	4, 38–39	Product safety decals	8
Loading drill pipes.....	55	Opening the cab door.....	106	Pullback.....	64, 66
Loading the machine		Opening the front hood	83	Pump	
Unloading the machine.....	52	Opening the rear-access door.....	77	Drilling fluid	
Lower button		Operator platform	67	Connecting to a fluid source.....	56
Left joystick.....	28	Location	23	Connecting to a natural water	
Lower Button		Operator seat		source.....	57
Right joystick.....	29	Location	23	Connecting to mixing system.....	56
Lower wrench		Operator-platform latch	26	Drilling-fluid	
Location	25	Operator-presence switch	34–35	Changing the charge filter	104
Lubrication	74			Changing the oil.....	103
				Checking the oil level	103
				Servicing the oil	102
				Inlet	
				Location.....	24
M		P		R	
Magazine		Pedestrian safety bar		Reamer	
(See Pipe holder)		Lowering.....	53	Carbide step-wing cutter	64
Maintenance.....	52, 70, 72	Pendant		Cast cone packer	64
Battery.....	84	Drill.....	35	Connecting	65
Belt.....	97	Drive	34, 52	Fluted	64
Cooling system	92	Performing Daily Maintenance	52	Removing	66
Daily	52	Pipe		Rear button	
Drilling-fluid pump	102	Adding	63	Left joystick.....	28
Electrical system.....	84	Flexibility	42	Right joystick	29
Engine.....	76	Removing	66	Rear control panel.....	33
Fuel system	81	Starting the first	60	Rear hood	
Hydraulic system	98	Utility product		Location	23
Lubrication	74	Connecting to a reamer.....	65	Rear-access door	
Premaintenance procedures.....	72	Wiper	65	Location	23
Schedule	70	Pipe cam		Opening	77
Tracks	108	Rotate	28	Receiver-battery-status light.....	27
Mapping the bore.....	46	Sensor-failure override	28	Receptacle	
Mixing system	56	Pipe gripper		Drill-pendant	33, 35
Model and Serial Plate		Close	28	Drive-pendant.....	33–35, 52
Location	2	Open.....	28	Removing drill pipes	66
Model Number		Pipe holder		Removing the last pipe	66
Location	2	Loading.....	55	Removing the reamer	66
Monitor		Location	24	Replacing the fuel filters	83
Location	26	Pipe loader		Replacing the pipe holder	69
Moving a disabled machine	68	Enable controls	28	Right joystick	107
Moving the machine.....	52	Pipe magazine		Location	26
Mud		(See Pipe holder)		Right Joystick.....	107
(See Drilling fluid)		Pipe wiper		Setup Mode	30
		Location	25	Right-stabilizer lever	34
		Pipe-clamp-control switch	36	Right-track-control switch.....	36
		Pipe-elevator-control switch	36	Rock blade	
		Pipe-grip-control switch.....	36	(See Triangle point blade)	
N		Pipes		Rotary motor planetary drive	
Number		Loading into the pipe holder	55	Checking the oil level.....	89
Model and Serial		Pipr holder		Oil specification and capacity.....	89
Location.....	2	Replacing.....	69	Rotary-control switch.....	35
		Pitch			
		Setting the thrust frame	55	S	
		Planetary drive		Safety	38, 66, 72
		Changing the oil	88		
		Planning			
		Initial	39		
		Planning the bore path.....	42		
		Plate			
		Stake-down			

After operation	66	Carriage-control	36	Right joystick	29
Battery	84	Drill-spindle-control	36	Troubleshooting	109
Before operation	38	Drilling Fluid and Wrench-control	36	U	
Checking		Drive/drill	27	Upper wrench	
Testing	47	Drive-speed	34–35	Location	25
Communication lines	7	Engine, key	33	Rotate	28
Crystalline silica	39	Engine-speed	27, 34	Using the TJC applicator	67
Decals	8	Fluid-pump	33	Utility lines	
Drilling	6	Ground-strike-reset	27	Connecting to a reamer	65
Drilling danger zone	6	Left-track-control	35	Safety precautions	38
Drive pendant	47	Lights	27	Utility Lines	
Driving		Operator-presence	34–35	Marking	
Tramming	5	Pipe-clamp-control	36	811	4, 38–39
Driving danger zone	5	Pipe-elevator-control	36	Color codes (US and Canada)	6
During	59	Pipe-grip-control	36	One-Call System Directory ...	4, 38–39
During operation	59	Reset		V	
Electrical lines	7, 39	Exit-side lockout	27	Valve clearance	81
Fuel	38, 51	Right-track-control	36	Vent tube	
Gas lines	7, 39	Rotary-control	35	Cleaning	76
General	4, 38	Stationary Pipe-clamp-control	36	W	
Operator platform	47	Toggle		Water as drilling fluid	57
Operator presence	47	Left joystick	28	Water lines	
Pre-Maintenance	72	Right joystick	29	Safety precautions	7
Utility lines	38	Symbol		Weight	37
Water lines	7	Safety Alert	2, 4	Width	37
Zap-alert system		T		Windshield wiper	
Deploying	54	Temperature		Changing speed	59
Safety Alert Symbol	2, 4	Sonde	64	Windshield-washer fluid	
Safety bar		Testing the Zap-alert system	48	Dispersing	59
Location	24	Thread joint compound		Filling the tank	106
Seat		Applicator	67	Wiper	
Location	23	Applicator nozzle		Pipe	65
Serial Number		Adjusting	67	Location	25
Location	2	Filling	68	Windshield	59
Servicing the tracks	108	Spray volume		Wire	
Setting up for drilling	53	Adjusting	67	Connecting to a reamer	65
Sonde	61	Thread-joint compound		Wrench	
Temperature	64	Application controls	29	Enable controls	28
Sonde housing	61	Thrust frame		Lower	
Specifications	37	Location	23, 25	Location	25
Spindle		Lowering	55	Upper	
(See Drill spindle)		Setting the pitch	55	Location	25
Spray-hose attachment		Thrust motor planetary drive		Rotate	28
Cleaning with	107	Checking the oil	89	Z	
Spreader bar		Tie-down points	53	Zap-alert system	
Lifting the machine	68	TJC		Deploying	54
Stabilizer		Thread joint compound	67	Grounding stake	
Location	23–24	Toggle switch		Storage	49
Stabilizer controls	34	Left joystick	28	Tester	48
Stabilizer levers	34	Right joystick	29	Testing	48
Stabilizers		Track		Zap-Alert system	7, 39
Lowering	55	Location	23	Ground-strike-reset switch	27
Stake-down cage		Tracking system	61	Strobe	
Location	24	Tracks		Location	23
Stake-down levers	37	Servicing	108		
Stake-down plate	55	Tension			
Location	24	Loosening	92		
Stakedown planetary drive		Tightening	91		
Checking the oil level	87	Tracks planetary drive			
Oil specification and capacity	87	Checking the oil level	87		
Starting the engine	86	Oil specification and capacity	87		
Starting the first pipe	60	Trailing the machine	52		
Stationary Pipe-clamp-control switch	36	Tramming			
Steering the drill head	64	(See Driving the machine)			
Stopping the engine	86	Transmitter			
Storage	108	(See Sonde)			
Straight blade	61	Transmitter-battery-status Light	27		
Switch		Triangle point blade	61		
Battery-disconnect	52	Trigger			
Breakout-wrench-control	36	Left joystick	28		
Cam-rotation-control	36				



Count on it.