

TORO[®]

Count on it.

Operator's Manual

Workman[®] HDX-Auto Utility Vehicle

Model No. 07390—Serial No. 403430001 and Up

Model No. 07390TC—Serial No. 403430001 and Up

This product complies with all relevant European directives; for details, please see the separate product specific Declaration of Conformity (DOC) sheet.

It is a violation of California Public Resource Code Section 4442 or 4443 to use or operate the engine on any forest-covered, brush-covered, or grass-covered land unless the engine is equipped with a spark arrester, as defined in Section 4442, maintained in effective working order or the engine is constructed, equipped, and maintained for the prevention of fire.

The enclosed engine owner's manual is supplied for information regarding the US Environmental Protection Agency (EPA) and the California Emission Control Regulation of emission systems, maintenance, and warranty. Replacements may be ordered through the engine manufacturer.

⚠ WARNING

CALIFORNIA Proposition 65 Warning

The engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.

Battery posts, terminals, and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and reproductive harm. Wash hands after handling.

Introduction

This utility vehicle is intended to be primarily used off-highway to transport people and material loads. Using this product for purposes other than its intended use could prove dangerous to you and bystanders.


Read this information carefully to learn how to operate and maintain your product properly and to avoid injury and product damage. You are responsible for operating the product properly and safely.

Visit www.Toro.com for product safety and operation training materials, accessory information, help finding a dealer, or to register your product.

Whenever you need service, genuine Toro parts, or additional information, contact an Authorized Service Distributor or Toro Customer Service and have the model and serial numbers of your product ready.

Figure 1 identifies the location of the model and serial numbers on the product. Write the numbers in the space provided.

Important: With your mobile device, you can scan the QR code on the serial number decal (if equipped) to access warranty, parts, and other product information.



g239323

Figure 1

1. Model and serial number location

Model No. _____

Serial No. _____

This manual identifies potential hazards and has safety messages identified by the safety-alert symbol (**Figure 2**), which signals a hazard that may cause serious injury or death if you do not follow the recommended precautions.



Figure 2

Safety-alert symbol

g000502

This manual uses 2 words to highlight information. **Important** calls attention to special mechanical information and **Note** emphasizes general information worthy of special attention.

Contents

Safety	4
General Safety	4
Safety and Instructional Decals	5
Setup	11
1 Installing the Steering Wheel.....	12
2 Connecting the Battery	12
3 Checking the Fluid Levels and Tire Pressure	13
4 Installing the Roll Bar	13
5 Connecting the CVT-Intake Duct.....	13
6 Burnishing the Brakes	14
Product Overview	15
Controls	15
Control Panel	17
Instrument Cluster.....	17
Specifications	20
Attachments/Accessories	20
Before Operation	21
Before Operation Safety	21
Performing Daily Maintenance.....	21
Checking the Tire Pressure.....	21
Adding Fuel	22
Breaking in a New Machine	22
Checking the Safety-Interlock System	23
During Operation	24
During Operation Safety	24
Operating the Cargo Bed	25
Starting the Engine	26
Driving the Machine.....	27
Stopping the Machine	27
Shutting Off the Engine.....	27
Using the Speed-Range Control	27
Using the Differential Lock	28
Using the Hydraulic Control	28
After Operation	30
After Operation Safety	30
Hauling the Machine	31
Towing the Machine.....	31
Towing a Trailer	31
Maintenance	32
Maintenance Safety.....	32
Recommended Maintenance Schedule(s)	32
Maintaining the Machine under Special Operating Conditions	34
Pre-Maintenance Procedures	35
Preparing the Machine for Maintenance.....	35
Using the Bed Support.....	35
Removing the Full Bed.....	36
Installing the Full Bed.....	36
Raising the Machine	37
Removing and Installing the Hood	38
Lubrication	39
Greasing the Bearings and the Bushings	39
Engine Maintenance	40
Engine Safety	40
Servicing the Air Filter.....	40
Servicing the Engine Oil.....	41
Checking the Oil-Pressure-Warning Light.....	43
Servicing the Spark Plugs.....	43
Fuel System Maintenance	44
Inspecting the Carbon Canister Air Filter.....	44
Replacing the Fuel Filter	44
Inspecting Fuel Lines and Connections.....	44
Electrical System Maintenance	45
Electrical System Safety	45
Servicing the Fuses	45
Jump-Starting the Machine.....	46
Servicing the Battery.....	47
Drive System Maintenance	47
Inspecting the Tires	47
Checking the Torque of the Wheel Nuts	48
Checking the Front Wheel Alignment.....	48
Maintaining the Transmission	49
Maintaining the Differential and Axles	52
Cooling System Maintenance	53
Cooling System Safety	53
Checking the Engine-Coolant Level.....	53
Removing Debris from the Cooling System	54
Changing the Engine Coolant	55
Brake Maintenance	56
Checking the Brake-Fluid Level	56
Adjusting the Parking Brake.....	56
Adjusting the Brake Pedal.....	57
Controls System Maintenance	58
Converting the Speedometer	58
Hydraulic System Maintenance	59
Hydraulic System Safety.....	59
Servicing the Hydraulic System	59
Raising the Cargo Bed in an Emergency	62
Cleaning	64
Washing the Machine	64
Storage	65
Storage Safety.....	65
Storing the Machine	65
Troubleshooting	66

Safety

This machine has been designed in accordance with the requirements of SAE J2258 (Nov 2016).

General Safety

This product is capable of causing personal injury. Always follow all safety instructions to avoid serious personal injury.

- Read and understand the contents of this *Operator's Manual* before you start the machine. Ensure that everyone using this product knows how to use it and understands the warnings.
- Use your full attention while operating the machine. Do not engage in any activity that causes distractions; otherwise, injury or property damage may occur.
- Do not put your hands or feet near moving components of the machine.
- Do not operate the machine without all guards and other safety protective devices in place and working on the machine.
- Keep bystanders and children out of the operating area. Never allow children to operate the machine.
- Stop and shut off the machine and remove the key before servicing or fueling.

Improperly using or maintaining this machine can result in injury. To reduce the potential for injury, comply with these safety instructions and always pay attention to the safety-alert symbol , which means Caution, Warning, or Danger—personal safety instruction. Failure to comply with these instructions may result in personal injury or death.

Safety and Instructional Decals



Safety decals and instructions are easily visible to the operator and are located near any area of potential danger. Replace any decal that is damaged or missing.



Battery Symbols

Some or all of these symbols are on your battery.

1. Explosion hazard
2. No fire, open flame, or smoking
3. Caustic liquid/chemical burn hazard
4. Wear eye protection.
5. Read the *Operator's Manual*.
6. Keep bystanders away from the battery.
7. Wear eye protection; explosive gases can cause blindness and other injuries.
8. Battery acid can cause blindness or severe burns.
9. Flush eyes immediately with water and get medical help fast.
10. Contains lead; do not discard



93-9850

decal93-9850


1. Do not repair or revise—read the *Operator's Manual*.



93-9852

decal93-9852


1. Warning—read the *Operator's Manual*.
2. Crushing hazard—install the cylinder lock.



93-9868

decal93-9868

1. Crushing hazard of hand—read the *Operator's Manual*.



93-9879

decal93-9879

1. Stored energy hazard—read the *Operator's Manual*.



93-9899

decal93-9899


1. Crushing hazard—install the cylinder lock.



105-4215

decal105-4215

- ## 1. Warning—avoid pinch points.



106-2353

decal106-2353

- ## 1. Electrical power point



106-6755

decal106-6755

1. Engine coolant under pressure.
 2. Explosion hazard—read the *Operator's Manual*.
 3. Warning—do not touch the hot surface.
 4. Warning—read the *Operator's Manual*.



106-7767

decal106-7767

1. Warning—read the *Operator's Manual*; avoid tipping the machine; wear the seat belt; lean away from the direction the machine is tipping.



115-2047

decal115-2047


1. Warning—do not touch the hot surface.




115-2282

decal115 3383

1. Warning—read the *Operator's Manual*.
 2. Warning—stay away from moving parts; keep all guards and shields in place.
 3. Crushing hazard—keep bystanders out of the operating area; do not carry passengers in the cargo bed; keep arms and legs inside of the vehicle at all times; use seat belts and handholds.



115-7723



decal115-7739

115-7739

1. Falling, crushing hazard—do not carry passengers.



decal115-7756

115-7756


1. High-flow hydraulics—engaged



decal121-9776

121-9776


1. Warning—read the *Operator's Manual* and receive proper training before operating the machine.
2. Warning—wear hearing protection.
3. Fire hazard—shut off the engine before refueling the machine.
4. Warning—engage the parking brake, shut off the engine, and remove the key from the key switch before walking away from the machine.
5. Tipping hazard—take turns slowly; drive slowly up and across cliffs; with no load, do not exceed 32 kph (20 mph); while carrying a load or when driving on uneven terrain, drive slowly.



decal121-9890

121-9890


- | | | |
|----------------------------|---------------------|---------|
| 1. Parking brake | 4. Cylinder retract | 7. Fast |
| 2. Hydraulic system—unlock | 5. Cylinder extend | 8. Slow |
| 3. Hydraulic system—lock | 6. Transport | |



decal127-8620


127-8620

- | | | |
|-----------------------------|--------------------|-----------------|
| 1. Head lights | 4. Horn | 7. Engine—start |
| 2. Differential lock—lock | 5. Engine—shut off | 8. Brake |
| 3. Differential lock—unlock | 6. Engine—run | |



127-8626

decal127-8626a




138-3371

decal138-3371

1. Power takeoff (15 A)
2. Start engine (10 A)
3. Hazard lights (10 A)
4. Engine ignition (10 A)
5. Differential lock (15 A)
6. Speedometer (10 A)
7. Headlights and rear lights (15 A)
8. Horn (30 A)


1. Park
2. Reverse
3. Neutral
4. Low
5. Drive
6. Attention—read the *Operator's Manual*; stop the machine before changing gears.



136-1163

decal136-1163

1. Do not exceed a transport load of 1591 kg (3,500 lb).
2. Do not exceed a tongue weight of 273 kg (600 lb).



decal139-3341

139-3341

- | | |
|---|-------------|
| 1. Tank | 3. Pressure |
| 2. Warning—the
hydraulic-fluid pressure is
138 bar (2,000 psi). | |

Setup

Loose Parts

Use the chart below to verify that all parts have been shipped.

Procedure	Description	Qty.	Use
1	Steering wheel Cover Washer (5/8 inch)	1 1 1	Install the steering wheel (TC models only).
2	No parts required	–	Connect the battery (TC models only).
3	No parts required	–	Check the fluid levels and tire pressure.
4	Roll bar Flange-head bolt (1/2 x 1-1/4 inches)	1 6	Install the roll bar.
5	No parts required	–	Connect the continuously-variable transmission intake duct.
6	No parts required	–	Burnish the brakes.

Media and Additional Parts

Description	Qty.	Use
Operator's Manual	1	Read before operating the machine.
Operator Training Material	1	View before operating the machine.
CVT Kit 121-9853	1	Connect the CVT Intake Duct (TC Models Only)
CVT Adapter 127-8750	1	Connect the CVT Intake Duct (TC Models Only)

Note: Determine the left and right side of the machine from the normal operating position.

1

Installing the Steering Wheel

TC Models Only

Parts needed for this procedure:

1	Steering wheel
1	Cover
1	Washer (5/8 inch)

Procedure

1. If the cover is installed, remove it from the hub of the steering wheel (Figure 3).
2. Remove the nut from the steering shaft (Figure 3).
3. Slide the steering wheel and washer onto the steering shaft (Figure 3).
4. Secure the steering wheel to the shaft with the nut and tighten it to 27 to 34 N·m (20 to 25 ft-lb).
5. Install the cover on the steering wheel (Figure 3).




Figure 3

1. Cover
2. Nut
3. Washer (5/8 inch)
4. Steering wheel
5. Steering shaft

2

Connecting the Battery TC Models Only

No Parts Required

Procedure

⚠ WARNING

Incorrectly routing the battery cable could damage the machine and cables, causing sparks. Sparks can cause the battery gasses to explode, resulting in personal injury.

- Always disconnect the negative battery cable (black) before disconnecting the positive battery cable (red).
 - Always connect the positive battery cable (red) first.
1. Squeeze the battery cover to release the tabs from the battery base (Figure 4).




Figure 4

1. Battery cover
2. Remove the battery cover from the battery base (Figure 4).
3. Connect the positive battery cable (red) to the positive (+) terminal of the battery and secure the cable with the bolts and nuts (Figure 5).




Figure 5

1. Insulator boot (positive battery cable)
2. Negative battery cable (black)
3. Negative battery post

4. Slide the insulator boot over the positive terminal.

Note: The insulator boot prevents a possible short-to-ground from occurring.

5. Connect the negative battery cable (black) to the negative (–) terminal of the battery and secure the cable with bolts and nuts.
6. Align the battery cover to the battery base (Figure 4).
7. Squeeze the battery cover, align the tabs to the battery base, and release the battery cover (Figure 4).

3

Checking the Fluid Levels and Tire Pressure

No Parts Required

Procedure

1. Check the engine-oil level before and after you first start the engine; refer to [Checking the Engine-Oil Level \(page 41\)](#).
2. Check the transmission-fluid level before you first start the engine; refer to [Checking the Transmission-Fluid Level \(page 49\)](#).
3. Check the engine-coolant level before you first start the engine; refer to [Checking the Engine-Coolant Level \(page 53\)](#).

4. Check the brake-fluid level before you first start the engine; refer to [Checking the Brake-Fluid Level \(page 56\)](#).
5. Check the air pressure in the tires; refer to [Checking the Tire Pressure \(page 21\)](#).

4

Installing the Roll Bar

Parts needed for this procedure:

1	Roll bar
6	Flange-head bolt (1/2 x 1-1/4 inches)

Procedure

1. Apply medium-grade (service-removable) thread-locking compound to the threads of the 6 flange-head bolts (1/2 x 1-1/4 inches).
2. Align each side of the roll bar with the mounting holes on each side of the machine frame (Figure 6).




Figure 6

1. Roll bar mounting bracket
2. Flange-head bolt (1/2 x 1-1/4 inches)
3. Secure the roll bar mounting bracket to the machine frame using 3 flange-head bolts (1/2 x 1-1/4 inches) on each side (Figure 6).
4. Torque the flange-head bolts (1/2 x 1-1/4 inches) to 115 N·m (85 ft-lb).

5

Connecting the CVT-Intake Duct

No Parts Required

Procedure

Important: Remove the plastic bag covering the end of the CVT duct before starting the engine.

The CVT Kit (Part No. 121-9853) and Adapter Kit (Part No. 127-8750) are required for this procedure.

1. Loosen the hose clamp securing the plastic bag at the end of the CVT-intake hose and remove the bag.
2. Raise the cargo bed by performing the following:
 - A. Engage the parking brake.
 - B. Start the engine.
 - C. Move the hydraulic-lift lever rearward to raise the cargo box.
 - D. Shut off the engine.
 - E. Remove the bed support from the storage brackets on the back of the ROPS panel and install the support onto the cylinder rod of the bed-lift cylinder; refer to [Using the Bed Support \(page 35\)](#).
3. Align the CVT-intake hose onto the intake-tube connector at the back side of the ROPS panel and tighten the hose clamp ([Figure 7](#)).




Figure 7

1. CVT-intake hose
2. Hose clamp
3. Intake-tube connector

4. Remove the bed support, lower the bed, shut off the engine, and remove the key.

6

Burnishing the Brakes

No Parts Required

Procedure

To ensure optimum performance of the brake system, burnish the brakes before use.

1. Bring the machine up to full speed, apply the brakes to rapidly stop the machine without locking up the tires.
2. Repeat this procedure 10 times, waiting 1 minute between stops, to avoid overheating the brakes.

Important: This procedure is most effective if the machine is loaded with 454 kg (1,000 lb).

Product Overview

Controls

Become familiar with all the controls before you start the engine and operate the machine.

Accelerator Pedal

Use the accelerator pedal (Figure 8) to vary the ground speed of the machine when the transmission is in gear. Pressing down the accelerator pedal increases the engine speed and ground speed. Releasing the pedal decreases the engine speed and ground speed.




Figure 8

1. Brake pedal

2. Accelerator pedal

Transmission Lever

Use the transmission lever (Figure 9) to shift the transmission between **P** (PARK), **R** (REVERSE), **N** (NEUTRAL), **L** (LOW FORWARD), and **D** (DRIVE) ground operation.

Important: Do not shift the transmission to the REVERSE, Low, or DRIVE gear unless the machine is motionless and the engine is at low idle; otherwise, you could damage the transmission.




Figure 9

- | | |
|-----------------------|---------------------------|
| 1. Transmission lever | 4. N (neutral) |
| 2. P (park) | 5. L (low forward) |
| 3. R (reverse) | 6. D (drive) |

Brake Pedal

Use the brake pedal to stop or slow the machine (Figure 8).

⚠ CAUTION

Operating a machine with worn or incorrectly adjusted brakes can may result in personal injury.

If the brake pedal travels to within 25 mm (1 inch) of the machine floor board, adjust or repair the brakes.

Parking-Brake Lever

Whenever you shut off the engine, engage the parking brake (Figure 10) to prevent the machine from accidentally moving. If the machine is parked on a steep grade, ensure that you engage the parking brake.

- To engage the parking brake, pull back on the parking-brake lever.
 - To disengage the parking brake, push the parking-brake lever forward.
- Note:** Disengage the parking brake before moving the machine.
- If you park the machine on a steep uphill or downhill grade, shift the transmission into **P** (PARK) and engage the parking brake. Place chocks at the downhill side of the wheels.




Figure 10

1. Parking-brake lever

Hydraulic-Lift Lever

The hydraulic lift raises and lowers the bed. Move the hydraulic-lift lever rearward to raise the bed, and forward to lower it (Figure 11).

Important: When lowering the bed, hold the lever in the forward position for 1 to 2 seconds after the bed contacts the frame to secure it in the lowered position. Do not hold the hydraulic lift in the raise or lower position for more than 5 seconds, once the cylinders reach the end of their travel.




Figure 11

1. Lower the bed
2. Raise the bed
3. Locked
4. Unlocked
5. Hydraulic-lift lock
6. Hydraulic-lift lever

Hydraulic-Lift Lock

The hydraulic-lift lock secures the lift lever, so that the hydraulic cylinders do not operate when the machine is not equipped with a bed (Figure 11). It also locks the lift lever in the ON position when using the hydraulics for attachments.

Speed-Range Lever

Use the speed-range lever (Figure 12) to select 1 of the 4 work-speed ranges for precise control of the maximum ground speed or a transport speed range for moving the machine between job sites.




Figure 12

1. Speed-range lever
2. T (transport range)
3. D (high range)
4. C (mid-high range)
5. B (mid-low range)
6. A (low range)

Control Panel




Figure 13

- | | |
|---|----------------|
| 1. High-flow hydraulics switch (TC models only) | 6. Off |
| 2. Light switch | 7. On |
| 3. Differential switch | 8. Start |
| 4. Horn button (TC models only) | 9. Power point |
| 5. Key switch | |

High-Flow Hydraulics Switch

TC Models Only

Push the switch down to start the high-flow hydraulics and push the switch up to shut off the hydraulics (Figure 13).

Note: You must set the high-flow hydraulics switch to the OFF position to start the engine.

Light Switch

Push the light switch (Figure 13) to toggle the headlights on or off.

Differential-Lock Switch

The differential-lock switch allows you to lock the rear axle for increased traction. Push the differential-lock switch (Figure 13) to toggle the differential lock on or off.

Note: You may lock and unlock the differential while the machine is in motion.

Horn Button

International Models Only

The horn button is located on the control panel (Figure 13). Press the horn button to sound the horn.

Key Switch

Use the key switch (Figure 13) to start and shut off the engine. To shut off the engine, rotate the key switch counterclockwise to the OFF position.

The key switch has 3 positions: OFF, RUN, and START. Rotate the key switch clockwise to the START position to engage the starter motor. Release the key switch when the engine starts. The key switch moves automatically to the ON position.

Power Point

Use the power point (Figure 13) to power optional 12 V electrical accessories.

Instrument Cluster




Figure 14

- | | |
|----------------|------------------------------|
| 1. Tachometer | 5. Charge-indicator light |
| 2. Hour meter | 6. Check-engine light |
| 3. Speedometer | 7. Low-oil pressure light |
| 4. Fuel gauge | 8. Coolant-temperature gauge |

Tachometer

The tachometer displays the speed of the engine (Figure 14).

Note: The white triangle indicates the desired engine speed for 540 rpm PTO operation.




Figure 15

1. Engine speed (rpm) 2. 3,300 rpm for 540 rpm PTO operation

G024371 g024371

Note: The oil-pressure light should glow red. If the light does not function, either a bulb is burned out or there is a malfunction in the system that you must repair.

Note: If engine was just shut off, it may take 1 to 2 minutes for the light to come on.

Coolant-Temperature Gauge and Light

The coolant-temperature gauge and light registers the coolant temperature in the engine and operates only when the key switch is in ON position (Figure 14). The indicator light blinks red if the engine overheats.

Fuel Gauge

The fuel gauge shows the amount of fuel in the tank. It displays only when key switch is in the ON position (Figure 14). The red segment of the display indicates a low-fuel level and the flashing red light indicates that the fuel in the tank is near empty.

Hour Meter

The hour meter indicates the total hours of machine operation. The hour meter (Figure 14) starts to function whenever you rotate the key switch to the ON position or if the engine is running.

Speedometer

The speedometer registers the ground speed of the machine (Figure 14). The speedometer is in mph, but you can easily convert it to km/h; refer to [Converting the Speedometer \(page 58\)](#).

Check-Engine Light

The check-engine light (Figure 14) illuminates to notify the operator of an engine malfunction.

Contact your authorized Toro distributor.

Oil-Pressure-Warning Light

The oil-pressure-warning light (Figure 14) illuminates if the engine-oil pressure drops below a safe level while the engine is running.

Important: If the light flickers or remains on, stop the machine, shut off the engine, and check the oil level. If the oil level is low, but adding oil does not cause the light to go out when the engine is started, shut off the engine immediately, and contact your Authorized Service Dealer for assistance.

Check the operation of the warning lights as follows:

1. Engage the parking brake.
2. Turn the key switch to the ON/PREHEAT position, but do not start the engine.

Passenger Handhold

The passenger handhold is located on the dashboard (Figure 16).




Figure 16

1. Passenger handhold 2. Storage compartment

Seat-Adjustment Lever

You can adjust the seat forward and rearward for your comfort (Figure 17).




Figure 17

1. Seat-adjustment lever

Specifications

Note: Specifications and design are subject to change without notice.

Overall width	165.1 cm (65 inches)
Overall length	Without bed: 326 cm (128 inches) With full bed: 331 cm (130 inches) With 2/3 bed in rear-mounting location: 346 cm (136 inches)
Base weight (dry)	Model 07390: 866 kg (1,905 lb) Model 07390TC: 887 kg (1,951 lb)
Rated capacity (includes 91 kg (200 lb) operator, 91 kg (200 lb) passenger, and loaded attachment)	Model 07390: 1498 kg (3,295 lb) Model 07390TC: 1477 kg (3,249 lb)
Maximum gross vehicle weight (GVW)	2363 kg (5,210 lb)
Tow capacity	Tongue weight: 272 kg (600 lb) Maximum trailer weight: 1587 kg (3,500 lb)
Ground clearance	18 cm (7 inches) with no load
Wheel base	118 cm (70 inches)
Wheel tread (center line to center line)	Front: 117 cm (46 inches) Rear: 121 cm (48 inches)
Height	192.5 cm (75-13/16 inches) to top of ROPS

Attachments/Accessories

A selection of Toro approved attachments and accessories is available for use with the machine to enhance and expand its capabilities. Contact your Authorized Service Dealer or authorized Toro distributor or go to www.Toro.com for a list of all approved attachments and accessories.

To ensure optimum performance and continued safety certification of the machine, use only genuine Toro replacement parts and accessories. Replacement parts and accessories made by other manufacturers could be dangerous, and such use could void the product warranty.

Operation

Before Operation

Before Operation Safety

General Safety

- Never allow children or people who are not trained or physically capable to safely operate or service the machine. Local regulations may restrict the age of the operator. The owner is responsible for training all operators and mechanics.
- Become familiar with the safe operation of the equipment, operator controls, and safety signs.
- Shut off the engine, remove the key (if equipped), and wait for all movement to stop before you leave the operator's position. Allow the machine to cool before adjusting, servicing, cleaning, or storing it.
- Know how to stop and shut off the machine quickly.
- Ensure that there are not more occupants (you and your passenger(s)) than the number of handholds equipped on the machine.
- Check that all safety devices and decals are in place. Repair or replace all safety devices and replace all illegible or missing decals. Do not operate the machine unless they are present and functioning properly.

Fuel Safety

- Use extreme care in handling fuel. It is flammable and its vapors are explosive.
- Extinguish all cigarettes, cigars, pipes, and other sources of ignition.
- Use only an approved fuel container.
- Do not remove the fuel cap or fill the fuel tank while the engine is running or hot.
- Do not add or drain fuel in an enclosed space.
- Do not store the machine or fuel container where there is an open flame, spark, or pilot light, such as on a water heater or other appliance.
- If you spill fuel, do not attempt to start the engine; avoid creating any source of ignition until the fuel vapors have dissipated.

Performing Daily Maintenance

Service Interval: Before each use or daily

Before starting the machine each day, perform the Each Use/Daily procedures listed in [Maintenance \(page 32\)](#).

Checking the Tire Pressure

Service Interval: Before each use or daily

Front tires air pressure specification: 220 kPa (32 psi)

Tear tires air pressure specification: 124 kPa (18 psi)

Important: Check the tire pressure frequently to ensure proper inflation. If the tires are not inflated to the correct pressure, the tires will wear prematurely and may cause the 4-wheel drive to bind.

[Figure 18](#) shows an example of tire wear caused by under-inflation.




Figure 18

1. Under-inflated tire

[Figure 19](#) shows an example of tire wear caused by over-inflation.




Figure 19

1. Over-inflated tire

Adding Fuel

- For best results, use only clean, fresh (less than 30 days old), unleaded gasoline with an cetane rating of 87 or higher ((R+M)/2 rating method).
- **Ethanol:** Gasoline with up to 10% ethanol (gasohol) or 15% MTBE (methyl tertiary butyl ether) by volume is acceptable. Ethanol and MTBE are not the same. Gasoline with 15% ethanol (E15) by volume is not approved for use. **Never use gasoline that contains more than 10% ethanol by volume**, such as E15 (contains 15% ethanol), E20 (contains 20% ethanol), or E85 (contains up to 85% ethanol). Using unapproved gasoline may cause performance problems and/or engine damage which may not be covered under warranty.
- **Do not** use gasoline containing methanol.
- **Do not** store fuel either in the fuel tank or fuel containers over the winter unless you use a fuel stabilizer.
- **Do not** add oil to gasoline.

Using Stabilizer/Conditioner

Use fuel stabilizer/conditioner in the machine to keep the fuel fresh longer when used as directed by the fuel-stabilizer manufacturer.

Important: Do not use fuel additives containing methanol or ethanol.

Add the amount of fuel stabilizer/conditioner to fresh fuel as directed by the fuel-stabilizer manufacturer.

Filling the Fuel Tank

Fuel-tank capacity: 25 L (6.5 US gallons).

1. Clean the area around the fuel-tank cap.
2. Remove the fuel-tank cap ([Figure 20](#)).




Figure 20

1. Fuel-tank cap
3. Fill the tank to approximately 25 mm (1 inch) below the bottom of the filler neck, and install the cap.

Note: Do not overfill the fuel tank.

4. Wipe up any spilled fuel to prevent a fire hazard.

Breaking in a New Machine

Service Interval: After the first 100 hours—Perform the guidelines for breaking in a new machine.

Perform the following to provide proper performance for the machine:

- Ensure that the brakes are burnished; refer to [6 Burnishing the Brakes \(page 14\)](#).
- Check the fluid and engine-oil levels regularly. Remain alert for signs that the machine or its components are overheating.
- After starting a cold engine, let it warm up for about 15 seconds before using the machine.

Note: Allow more time for the engine to warm up when operating in cold temperatures.

- Vary the machine speed during operation. Avoid fast starts and quick stops.
- A break-in oil for the engine is not required. Original engine oil is the same type specified for regular oil changes.
- Refer to [Maintenance \(page 32\)](#) for any special, low-hour checks.

Checking the Safety-Interlock System

Service Interval: Before each use or daily

The purpose of the safety-interlock system is to prevent the engine from cranking or starting, unless you press the brake pedal and have the hydraulic-lift lever in the NEUTRAL position.

⚠ CAUTION

If the safety-interlock switches are disconnected or damaged, the machine could operate unexpectedly, causing personal injury.

- **Do not tamper with the safety-interlock switches.**
- **Check the operation of the safety-interlock switches daily, and replace any damaged switches before operating the machine.**

Note: Refer to the attachment *Operator's Manual* for procedures on checking the attachment interlock system.

Verifying the Hydraulic-Lift Lever Safety-Interlock Switch

1. Sit on the operator's seat and engage the parking brake.
2. Move the shift lever to the NEUTRAL position and ensure that the hydraulic-lift lever is in the center position.
3. If you have a non-TC model with the High-Flow Hydraulic Kit (optional) or TC model, set the high-flow hydraulic switch to the OFF position.
4. Press the brake pedal.
5. Move the hydraulic-lift lever forward and rotate the key switch clockwise to the START position.

Note: If the engine cranks or starts, there is a malfunction in the interlock system that you must repair before operating the machine.

Verifying the Brake Pedal Safety-Interlock Switch

1. Sit on the operator's seat and engage the parking brake.
2. Move the shift lever to the NEUTRAL position and ensure that the hydraulic-lift lever is in the center position.
3. If you have a non-TC model with the High-Flow Hydraulic Kit (optional) or TC model, set the high-flow hydraulic switch to the OFF position.
4. Rotate the key switch clockwise to the START position.

Note: Do not press the brake pedal.

Note: If the engine cranks or starts, there is a malfunction in the interlock system that you must repair before operating the machine.

Verifying the High-Flow Hydraulic Safety-Interlock Switch

Note: This procedure is for a non-TC model with the High-Flow Hydraulic Kit (optional) or a TC model

1. Sit on the operator's seat and engage the parking brake.
2. Move the shift lever to the NEUTRAL position and ensure that the hydraulic-lift lever is in the center position.
3. Set the high-flow hydraulic switch to the ON position.
4. Press the brake pedal.
5. Rotate the key switch clockwise to the START position.

Note: If the engine cranks or starts, there is a malfunction in the interlock system that you must repair before operating the machine.

During Operation

During Operation Safety

General Safety

- The owner/operator can prevent and is responsible for accidents that may cause personal injury or property damage.
- Passengers should sit in the designated seating positions only. Do not carry passengers in the cargo bed. Keep bystanders and children out of the operating area.
- Wear appropriate clothing, including eye protection; long pants; substantial, slip-resistant footwear; and hearing protection. Tie back long hair and do not wear loose clothing or loose jewelry.
- Use your full attention while operating the machine. Do not engage in any activity that causes distractions; otherwise, injury or property damage may occur.
- Do not operate the machine while ill, tired, or under the influence of alcohol or drugs.
- Operate the machine outdoors or in a well-ventilated area only.
- Do not exceed the maximum gross vehicle weight (GVW) of the machine.
- Use extra caution when operating braking or turning the machine with a heavy load in the cargo bed.
- Carrying oversized loads in the cargo bed reduces the stability of the machine. Do not exceed the carrying capacity of the bed.
- Carrying material that cannot be bound to the machine, such as a large tank of liquid, adversely affects the steering, braking, and stability of the machine. When you carry material that cannot be bound to the machine, use caution when steering or braking.
- Carry a reduced load and reduce the ground speed of the machine when operating on rough, uneven terrain, and near curbs, holes, and other sudden changes in terrain. Loads may shift, causing the machine to become unstable.
- Before you start the machine, ensure that the transmission is in neutral, the parking brake is engaged, and you are in the operating position.
- You and your passengers should remain seated whenever the machine is moving. Keep your hands on the steering wheel; your passengers should use the handholds provided. Keep your arms and legs within the machine body at all times.

- Operate the machine only in good visibility. Watch for holes, ruts, bumps, rocks, or other hidden objects. Uneven terrain could overturn the machine. Tall grass can hide obstacles. Use care when approaching blind corners, shrubs, trees, or other objects that may obscure your vision.
- Do not drive the machine near drop-offs, ditches, or embankments. The machine could suddenly roll over if a wheel goes over the edge or if the edge gives way.
- Always watch out for and avoid low overhangs such as tree limbs, door jambs, overhead walkways, etc.
- Look behind and down before reversing the machine to be sure of a clear path.
- When using the machine on public roads, follow all traffic regulations and use any additional accessories that may be required by law, such as lights, turn signals, slow-moving vehicle (SMV) signs, and others as required.
- If the machine ever vibrates abnormally, stop and shut off the machine immediately, wait for all movement to stop, and inspect for damage. Repair all damage to the machine before resuming operation.
- It can take longer to stop the machine on wet surfaces than on dry surfaces. To dry out wet brakes, drive slowly on a level surface while putting light pressure on the brake pedal.
- Operating the machine at high speed and then quickly stopping may cause the rear wheels to lock up, which impairs your control of the machine.
- Do not touch the engine, transmission, muffler, or muffler manifold while the engine is running, or soon after you shut off the engine, because these areas may be hot enough to cause burns.
- Do not leave a running machine unattended.
- Before you leave the operating position, do the following:
 - Park the machine on a level surface.
 - Shift the transmission to the NEUTRAL position.
 - Engage the parking brake.
 - Lower the cargo bed.
 - Shut off the machine and remove the key (if equipped).
 - Wait for all movement to stop
- Do not operate the machine when there is the risk of lightning.
- Use accessories and attachments approved by The Toro® Company only.

Rollover Protection System (ROPS) Safety

- The ROPS is an integral safety device.
- **Do not** remove the ROPS from the machine.
- Always wear your seat belt; ensure that it is attached and that you can release it quickly in an emergency.
- Check carefully for overhead obstructions and do not contact them.
- Keep the ROPS in safe operating condition by thoroughly inspecting it periodically for damage and keeping all the mounting fasteners tight.
- Replace damaged ROPS components. Do not repair or alter them.

Slope Safety

Slopes are a major factor related to loss-of-control and tip-over accidents, which can result in severe injury or death.

- Survey the site to determine which slopes are safe for operating the machine and establish your own procedures and rules for operating on those slopes. Always use common sense and good judgment when performing this survey.
- If you feel uneasy operating the machine on a slope, do not do it.
- Keep all movement on slopes slow and gradual. Do not suddenly change the speed or direction of the machine.
- Avoid operating the machine on wet terrain. Tires may lose traction. A rollover can occur before the tires lose traction.
- Travel straight up and down a slope.
- If you begin to lose momentum while climbing a slope, gradually engage the brakes and slowly reverse the machine straight down the slope.
- Turning while going up or down a slope can be dangerous. If you must turn on a slope, do it slowly and cautiously.
- Heavy loads affect stability on a slope. Carry a reduced load and reduce your ground speed when operating on a slope or if the load has a high center of gravity. Secure the load to the cargo bed of the machine to prevent the load from shifting. Take extra care when hauling loads that shift easily (e.g., liquids, rock, sand, etc.).
- Avoid starting, stopping, or turning the machine on a slope, especially with a load. Stopping while going down a slope takes longer than stopping on level ground. If you must stop the machine,

avoid sudden speed changes, which can cause the machine to tip or roll over. Do not engage the brakes suddenly when rolling rearward, as this may cause the machine to overturn.

Loading and Dumping Safety

- Do not exceed the gross vehicle weight (GVW) of the machine when operating it with a load in the cargo bed and/or towing a trailer; refer to [Specifications \(page 20\)](#).
- Distribute the load in the cargo bed evenly to improve the stability and control of the machine.
- Before dumping, ensure that there is no one behind the machine.
- Do not dump a loaded cargo bed while the machine is sideways on a slope. The change in weight distribution may cause the machine to overturn.

Operating the Cargo Bed

Raising the Cargo Bed

⚠ WARNING

A raised bed could fall and injure persons that are working beneath it.

- **Always use the prop rod to hold the bed up before working under the bed.**
- **Remove any load material from the bed before raising it.**

⚠ WARNING

Driving the machine with the cargo bed raised could cause the machine to tip or roll easier. You could damage the structure of the cargo bed if you operate the machine with the bed raised.

- **Operate the machine when the cargo bed is down.**
- **After emptying the cargo bed, lower it.**

⚠ CAUTION

If a load is concentrated near the back of the cargo bed when you release the latches, the bed may unexpectedly tip open, injuring you or bystanders.

- Center loads in the cargo bed, if possible.
- Hold the cargo bed down and ensure that no one is leaning over the bed or standing behind it when releasing the latches.
- Remove all cargo from the bed before lifting the bed up to service the machine.

Move the lever rearward to raise the cargo bed (Figure 21).




Figure 21

1. Cargo bed lever




Figure 22

1. Latch handle
2. Latch gate
3. Latch pin

Starting the Engine

Important: Do not attempt to push or tow the machine to get it started. Damage to the drive train could result.

1. Sit on the operator seat and engage the parking brake.
2. Disengage the PTO and the high-flow hydraulics (if equipped) and move the hand-throttle lever to the OFF position (if equipped).
3. Move the transmission lever to the P (PARK) position.
4. Ensure that the hydraulic-lift lever is in the OFF position (center).
5. Press the brake pedal.

Note: Keep your foot off the accelerator pedal.

6. Insert the key into the key switch and rotate it clockwise to start the engine.

Note: Release the key switch when the engine starts.

Note: The oil-pressure warning light should turn off.

Important: To prevent overheating of the starter motor, do not engage starter longer than 15 seconds. After 15 seconds of

Lowering the Cargo Bed

⚠ WARNING

The weight of the bed may be heavy. Hands or other body parts could be crushed.

Keep your hands and other body parts away when lowering the bed.

Move the lever forward to lower the cargo bed (Figure 21).

Opening the Tailgate

1. Ensure that the cargo bed is down and latched.
2. Open the latches on the left and right side of the cargo bed and lower the tailgate (Figure 22).

continuous cranking, wait 60 seconds before engaging starter motor again.

Driving the Machine

1. Press the brake pedal.
2. Disengage the parking brake.
3. Move the transmission lever to the desired gear.
4. Release the service brake and gradually press in the accelerator pedal.

Important: Always stop the machine before shifting to reverse a forward gear or to a forward gear from reverse.

Use the chart below to determine the ground speed of each gear when operating the machine with the speed-range control in the **T** (TRANSPORT) position.

Gear	Speed (km/h)	Speed (mph)
R (REVERSE)	0 to 21	0 to 13
L (LOW FORWARD)	0 to 18	0 to 11
D (DRIVE)	0 to 32	0 to 20

Note: Avoid idling the engine for long periods of time.

Note: Leaving the key switch in the ON position for long periods of time without starting the engine discharges the battery.

Stopping the Machine

To stop the machine, remove your foot from the accelerator pedal, then press the brake pedal.

Shutting Off the Engine

1. Stop the machine.
2. Move the transmission lever to the **P** (PARK) position.
3. Engage the parking brake.
4. Rotate the key switch to the OFF position and remove the key.

Using the Speed-Range Control

Use the lever of the speed-range control to limit the maximum ground speed of the machine for operations that require a constant speed like spraying and top dressing. The speed-range lever (Figure 23) is used to select 1 of the 4 work-speed ranges that are used to limit maximum ground speed or a transport-speed range that is used when you move the machine between job sites.

Note: You must release the accelerator pedal in order to shift between speed ranges, but you do not need to stop the machine in order to shift.

- Move the speed-range lever into the detent for speed ranges A, B, C, and D when precise control of maximum-ground speed is desired.
- Move the speed-range lever to the **T** (TRANSPORT) position by moving the speed-range lever out of the detent for range A, B, C, or D, then forward to the **T** (TRANSPORT) position.

Note: Use the speed-range control to limit the maximum ground speed in each range by 4 to 18 km/h (2.5 to 11 mph) with the transmission lever in the **L** (Low FORWARD) position or 8 to 32 km/h (5 to 20 mph) with the transmission lever in the **D** (DRIVE) position.




Figure 23

- | | |
|-------------------------------|------------------------------|
| 1. Speed-range lever | 4. C (mid-high range) |
| 2. T (transport range) | 5. B (mid-low range) |
| 3. D (high range) | 6. A (low range) |

Using the Differential Lock

⚠ WARNING

Tipping or rolling the machine on a hill can cause a serious injury.

- The extra traction available with the differential lock can be enough to get you into dangerous situations such as climbing slopes that are too steep to turn around. Be extra careful when operating with the differential lock on, especially on steeper slopes.
- If the differential lock is on when making a sharp turn at a higher speed and the inside rear wheel lifts off the ground, there may be a loss of control, which could cause the machine to skid. Use the differential lock only at slower speeds.

⚠ CAUTION

Turning with the differential lock on can result in loss of machine control. Do not operate with differential lock on when making sharp turns or at high speeds.

The differential lock increases the traction of the machine by locking the rear wheels so that a wheel does not spin out. This can help when you have heavy loads to haul, on wet turf or slippery areas, going up hills, and on sandy surfaces. It is important to remember that this extra traction is only for temporary, limited use. Its use does not replace the safe operation already discussed concerning steep hills and heavy loads.

The differential lock causes the rear wheels to spin at the same speed. When using the differential lock, your ability to make sharp turns is somewhat restricted and may scuff the turf. Use the differential lock only when needed and at slower speeds.

Note: Machine motion plus a slight turn is required to engage or disengage differential lock.

- Press the differential-lock switch up to lock the differential ([Figure 24](#)).

Note: The light in the differential-lock switch illuminates when the switch is in the lock position.

- Press the differential-lock switch up to unlock the differential ([Figure 24](#)).




Figure 24

1. Lock position (differential-lock switch)
2. Unlock position (differential-lock switch)

Using the Hydraulic Control

The hydraulic control supplies hydraulic power from the machine pump whenever the engine runs. You can use the power through the quick couplers at the rear of the machine.

⚠ WARNING

Hydraulic fluid escaping under pressure can have sufficient force to penetrate skin and can cause serious injury.

Use care when connecting or disconnecting hydraulic quick couplers. Shut off the engine, engage the parking brake, lower the attachment, and place the remote hydraulic valve in the float detent position to relieve the hydraulic pressure before connecting or disconnecting the quick couplers.

Important: If multiple machines use the same attachment, cross-contamination of the transmission fluid may occur. Change the transmission fluid more frequently.

Using the Hydraulic Bed-Lift Lever to Control Hydraulic Attachments

• OFF Position

This is the normal position for the control valve when it is not in use. In this position, the work ports of the control valve are blocked and any load is held by the check valves in both directions.

• RAISE (Quick Coupler A) Position

This position lifts the bed and rear hitch attachment, or applies pressure to quick coupler A. This position also allows hydraulic fluid to return from quick coupler B to flow back into the valve and then out to the reservoir. This is a momentary position, and when you release the lever, it spring-returns to the center, OFF position.




Figure 25

1. Quick coupler A position 2. Quick coupler B position

• LOWER (Quick Coupler B) Position

This position lowers the bed, rear hitch attachment, or applies pressure to quick coupler B. This also allows hydraulic fluid to return from quick coupler A to flow back into the valve and then out to the reservoir. This is a momentary position, and when you release the lever, it spring-returns to the center, OFF position. Momentarily holding and then releasing the control lever in this position provides hydraulic-fluid flow to quick coupler B, which provides power down on the rear hitch. When you release it, it holds the down-pressure on the hitch.

Important: If you use it with a hydraulic cylinder, holding the control lever in the lower position causes the hydraulic-fluid flow to go over a relief valve, which can damage the hydraulic system.

• ON Position

This position is similar to the LOWER (QUICK COUPLER B POSITION). It also directs hydraulic fluid to quick coupler B, except that the lever is held in this position by a detent lever in the control panel. This allows hydraulic fluid to flow continuously to equipment that use a hydraulic motor.

Use this position only on attachments with a hydraulic motor attached.

Important: If you use it with a hydraulic cylinder or no attachment, the ON position causes the hydraulic-fluid flow to go over a relief valve, which can damage the hydraulic system. Use this position only momentarily or with a motor attached.

Important: Check the hydraulic-fluid level after installation of an attachment. Check the operation of the attachment by cycling the attachment several times to purge air from the system, then check hydraulic-fluid level again. The attachment cylinder slightly affects the fluid level in the transaxle. Operating the machine with a low hydraulic-fluid level can damage the pump, remote hydraulics, power steering, and machine transaxle.

Connecting the Quick Couplers

Important: Clean dirt from the quick couplers before connecting them. Dirty couplers can introduce contamination into the hydraulic system.

1. Pull back the locking ring on the coupler.
2. Insert the hose nipple into the coupler until it snaps into position.

Note: When attaching remote equipment to the quick couplers, determine which side requires pressure, then attach that hose to quick coupler B, which has pressure when you push the control lever forward or locked in the ON position.

Disconnecting the Quick Couplers

Note: With both the machine and attachment shut off, move the lift lever back and forth to remove the system pressure and ease the disconnection of the quick couplers.

1. Pull back the locking ring on the coupler.
2. Pull the hose firmly from the coupler.

Important: Clean and install the dust plug and dust covers to the quick coupler ends when not in use.

Troubleshooting the Hydraulic Control

- **Difficulty in connecting or disconnecting quick couplers.**
The pressure is not relieved (the quick coupler is under pressure).
- **The power steering is turning with great difficulty or it is not turning at all.**
 - The hydraulic-fluid level is low.
 - The hydraulic-fluid temperature is too hot.
 - The pump is not operating.
- **There are hydraulic leaks.**
 - The fittings are loose.
 - The fitting is missing the O-ring.
- **An attachment does not function.**
 - The quick couplers are not fully engaged.
 - The quick couplers are interchanged.
- **There is a squealing noise.**
 - Remove the valve left in the ON position detent, causing hydraulic fluid to flow over the relief valve.
 - The belt is loose.
- **The engine does not start.**

The hydraulic lever is locked in the FORWARD position.

After Operation

After Operation Safety

General Safety

- Before you leave the operating position, do the following:
 - Park the machine on a level surface.
 - Shift the transmission to the NEUTRAL position.
 - Engage the parking brake.
 - Lower the cargo bed.
 - Shut off the machine and remove the key (if equipped).
 - Wait for all movement to stop
- Allow the machine to cool before adjusting, servicing, cleaning, or storing it.
- Do not store the machine where there is an open flame, spark, or pilot light, such as on a water heater or other appliance.
- Keep all parts of the machine in good working condition and all hardware tightened.
- Maintain and clean the seat belt(s) as necessary.
- Replace all worn, damaged, or missing decals.

Hauling the Machine

- Use care when loading or unloading the machine into a trailer or a truck.
- Use full-width ramps for loading the machine into a trailer or a truck.
- Tie the machine down securely.

Refer to [Figure 26](#) and [Figure 27](#) for the tie-down locations on the machine.

Note: Load the machine on the trailer with the front of the machine facing forward. If that is not possible, secure the machine hood to the frame with a strap, or remove the hood and transport and secure it separately; otherwise, the hood may blow off during transport.




Figure 26

1. Eye hole in the frame (each side)




Figure 27

1. Axle
2. Hitch plate

Towing the Machine

In case of an emergency, you can tow the machine for a short distance; however, this is not the standard operating procedure.

WARNING

Towing at excessive speeds could cause a loss of steering control, resulting in personal injury.

Never tow the machine at faster than 8 km/h (5 mph).

Note: The power steering does not function, making it difficult to steer.

Towing the machine is a 2-person job. If you must move the machine a considerable distance, transport it on a truck or trailer.

1. Affix a tow line to the tongue at the front of the frame of the machine ([Figure 26](#)).
2. Move the transmission to the NEUTRAL position and disengage the parking brake.

Towing a Trailer

The machine is capable of pulling trailers and attachments of greater weight than the machine itself. Several types of tow hitches are available for the machine, depending on your application. Contact your Authorized Service Dealer for details.

When equipped with a tow hitch bolted onto the rear axle tube, your machine can tow trailers or attachments with a maximum gross trailer weight (GTW) up to 1587 kg (3,500 lb).

Always load a trailer with 60% of the cargo weight in the front of the trailer. This places approximately 10% (272 kg (600 lb) maximum) of the gross trailer weight (GTW) on the tow hitch of the machine.

When hauling cargo or towing a trailer (attachment), do not overload the machine or trailer. Overloading can cause poor performance or damage to the brakes, axle, engine, transaxle, steering, suspension, body structure, or tires.

Important: To reduce potential for drive line damage, use low range.

When towing fifth-wheel attachments, like a fairway aerator, always install the wheel bar (included with the fifth wheel kit) to prevent the front wheels from lifting off the ground if the towed attachments movement is suddenly impaired.

Maintenance

Maintenance Safety

- Do not allow untrained personnel to service the machine.
- Before you leave the operating position, do the following:
 - Park the machine on a level surface.
 - Shift the transmission to the NEUTRAL position.
 - Engage the parking brake.
 - Lower the cargo bed.
 - Shut off the machine and remove the key (if equipped).
 - Wait for all movement to stop
- Allow the machine to cool before adjusting, servicing, cleaning, or storing it.
- Support the machine with jack stands whenever you work under the machine.
- Do not work under a raised bed without the proper bed safety support in place.
- Ensure that all hydraulic-line connectors are tight and that all the hydraulic hoses and lines are in good condition before applying pressure to the system.
- Before disconnecting or performing any work on the hydraulic system, relieve all pressure in the system by shutting off the motor, cycling the dump valve from raise to lower, and/or lowering the cargo bed and attachments. Place the remote hydraulics lever in the float position. If the bed must be in raised position, secure it with the safety support.
- Carefully release pressure from components with stored energy.

- Do not charge the batteries while servicing the machine.
- To ensure that the entire machine is in good condition, keep all hardware properly tightened.
- To reduce the potential fire hazard, keep the machine area free of excessive grease, grass, leaves, and accumulation of dirt.
- If possible, do not perform maintenance while the machine is running. Keep away from moving parts.
- If you must run the machine to perform a maintenance adjustment, keep your hands, feet, clothing, and any parts of the body away from any moving parts. Keep bystanders away from the machine.
- Clean up oil and fuel spills.
- Check the parking brake operation as recommended in the maintenance schedule and adjust and service it as required.
- Keep all parts of the machine in good working condition and all the hardware properly tightened. Replace all worn or damaged decals.
- Never interfere with the intended function of a safety device or reduce the protection provided by a safety device.
- Do not overspeed the engine by changing the governor settings. To ensure safety and accuracy, have an Authorized Service Dealer check the maximum engine speed with a tachometer.
- If major repairs are ever necessary or assistance is required, contact an Authorized Service Dealer.
- Altering this machine in any manner may affect the operation of the machine, performance, durability, or its use may result in injury or death. Such use could void the product warranty of The Toro® Company.

Recommended Maintenance Schedule(s)

Maintenance Service Interval	Maintenance Procedure
After the first 2 hours	<ul style="list-style-type: none">• Torque the front and rear wheel nuts.
After the first 10 hours	<ul style="list-style-type: none">• Torque the front and rear wheel nuts.• Check the adjustment of the parking brake.
After the first 50 hours	<ul style="list-style-type: none">• Change the engine oil and filter.• Inspect the opening on the filter.• Check the transmission-fluid level.
After the first 100 hours	<ul style="list-style-type: none">• Perform the guidelines for breaking in a new machine.

Maintenance Service Interval	Maintenance Procedure
Before each use or daily	<ul style="list-style-type: none"> Inspect the seat belt(s) for wear, cuts, and other damage. Replace the seat belt(s) if any component does not operate properly. Check the tire pressure. Check the operation of the safety-interlock system. Check the engine-oil level. (Check the oil level before and after the engine is first started and daily thereafter.) Check the oil-pressure-warning light. Check the level of the coolant. Check the Coolant level at the overflow reservoir only. Do not remove the radiator cap. (Check the coolant level before the engine is first started and daily thereafter.) Remove debris from the engine area and radiator. (Clean it more frequently in dirty conditions.) Check the brake-fluid level. (Check the level before the engine is first started and daily thereafter.) Check the hydraulic-fluid level. (Check the level of hydraulic fluid before the engine is first started and daily thereafter.) Wash the machine.
Every 25 hours	<ul style="list-style-type: none"> Remove the air-cleaner cover and clean out the debris.
Every 50 hours	<ul style="list-style-type: none"> Check the battery-fluid level (every 30 days if in storage). Check the battery cable connections.
Every 100 hours	<ul style="list-style-type: none"> Grease the bearings and bushings (lubricate more frequently in heavy-duty applications). Change the air-cleaner filter (more frequently in dusty or dirty conditions). Check the spark plugs. Inspect the condition of the tires. Check the constant-velocity boots for damage and leaking lubricant.
Every 200 hours	<ul style="list-style-type: none"> Change the engine oil and filter. Change the carbon canister air filter. Torque the front and rear wheel nuts Check the fluid level in the reservoir for the speed-control cylinder. Check the adjustment of the parking brake. Check the adjustment of the brake pedal. Inspect the service and parking brakes.
Every 400 hours	<ul style="list-style-type: none"> Replace the fuel filter. Inspect the fuel lines and connections. Check the front wheel alignment. Check the transmission-fluid level. Check the condition of the drive belt. Clean the clutches. Visually inspect the brakes for worn brake shoes.
Every 800 hours	<ul style="list-style-type: none"> If you are not using the recommended hydraulic fluid or have ever filled the reservoir with an alternative fluid, replace the hydraulic fluid and filter.
Every 1,000 hours	<ul style="list-style-type: none"> Flush/replace the coolant system fluid. Change the brake fluid. If you are using the recommended hydraulic fluid, replace the hydraulic filter.
Every 2,000 hours	<ul style="list-style-type: none"> If you are using the recommended hydraulic fluid, change the hydraulic fluid.
Yearly	<ul style="list-style-type: none"> Complete all of the yearly maintenance procedures specified in the engine owner's manual.

Note: Download a free copy of the electrical schematic by visiting www.Toro.com and searching for your machine from the Manuals link on the home page.

Important: Refer to your engine owner's manual for additional maintenance procedures.

⚠ WARNING

Failing to properly maintain the machine could result in premature failure of machine systems, causing possible harm to you or bystanders.

Keep the machine well maintained and in good working order as indicated in these instructions.

⚠ CAUTION

Only qualified and authorized personnel should maintain, repair, adjust, or inspect the machine.

- Avoid fire hazards and have fire-protection equipment present in the work area. Do not use an open flame to check fluid levels or leakage of fuel, battery electrolyte, or coolant.
- Do not use open pans of fuel or flammable cleaning fluids for cleaning parts.

⚠ CAUTION

If you leave the key in the switch, someone could accidentally start the engine and seriously injure you or other bystanders.

Shut off the engine and remove the key from the switch before you perform any maintenance.

Maintaining the Machine under Special Operating Conditions

Important: If the machine is subjected to any of the conditions listed below, perform maintenance twice as frequently:

- Desert operation
- Cold climate operation—below 10°C (50°F)
- Trailer towing
- Frequent operation in dusty conditions
- Construction work
- After extended operation in mud, sand, water, or similar dirty conditions, do the following:
 - Have your brakes inspected and cleaned as soon as possible. This prevents any abrasive material from causing excessive wear.
 - Wash the machine using water alone or with a mild detergent.

Important: Do not use brackish or reclaimed water to clean the machine.

Pre-Maintenance Procedures

Preparing the Machine for Maintenance

1. Park the machine on a level surface.
2. Engage the parking brake.
3. Empty and raise the cargo bed; refer to [Raising the Cargo Bed \(page 25\)](#).
4. Shut off the engine and remove the key.
5. Allow the machine to cool before performing maintenance.

Using the Bed Support

Important: Always install or remove the bed support from the outside of the bed.

1. Raise the bed until the lift cylinders are fully extended.
2. Remove the bed support from the storage brackets on the back of the ROPS panel ([Figure 28](#)).




Figure 28

1. Bed support
3. Push the bed support onto the cylinder rod, and ensure that the support-end tabs rest on the

end of the cylinder barrel and cylinder-rod end ([Figure 29](#)).




Figure 29

1. Bed support
2. Cylinder barrel
3. Bed
4. Remove the bed support from the cylinder, and insert it into the brackets on the back of the ROPS panel.

Important: Do not try to lower the bed with the bed-safety support on the cylinder.

Removing the Full Bed

1. Start the engine, engage the hydraulic-lift lever, and lower the bed until the cylinders are loose in the slots.
2. Release the lift lever and shut off the engine.
3. Remove the lynch pins from the outer ends of the cylinder rod clevis pins (Figure 30).




Figure 30

- | | |
|-----------------------|-------------------------------|
| 1. Cylinder rod end | 4. Lynch pin |
| 2. Bed-mounting plate | 5. Rear slots (full bed) |
| 3. Clevis pin | 6. Front slots (2/3 full bed) |

4. Remove the clevis pins securing the cylinder rod ends to the bed-mounting plates by pushing the pins toward the inside (Figure 30).
5. Remove the lynch pins and clevis pins securing the pivot brackets to the frame channels (Figure 30).
6. Lift the bed off the machine.

⚠ CAUTION

The full bed weighs approximately 148 kg (325 lb), so do not try to install or remove it by yourself.

Use an overhead hoist or get the help of 2 or 3 other people.

7. Store the cylinders in the storage clips.
8. Engage the hydraulic lift-lock lever on the machine to prevent accidental extension of the lift cylinders.

Installing the Full Bed

Note: If you are installing the bed sides on the flat bed, it is easier to install them before installing the bed on the machine.

Ensure that the rear pivot plates are bolted to the bed frame/channel so that the lower end angles to the rear (Figure 31).




Figure 31

- | | |
|-----------------------------|---------------|
| 1. Left, rear corner of bed | 4. Clevis pin |
| 2. Machine frame channel | 5. Lynch pin |
| 3. Pivot plate | |

⚠ CAUTION

The full bed weighs approximately 148 kg (325 lb), so do not try to install or remove it by yourself.

Use an overhead hoist or get the help of 2 or 3 other people.

Ensure that the spacer brackets and wear blocks (Figure 32) are installed with the carriage-bolt heads positioned inside the machine.




Figure 32

- 1. Wear block
- 2. Spacer bracket
- 3. Carriage bolt

1. Ensure that the lift cylinders are fully retracted.
2. Carefully set the bed onto the machine frame, aligning the rear bed pivot-plate holes with the holes in the rear frame channel, and install the 2 clevis pins and lynch pins (Figure 32).
3. With the bed lowered, secure each cylinder rod end to the appropriate slots in the bed-mounting plates with a clevis pin and lynch pin.
4. Insert the clevis pin from outside of the bed with the lynch pin oriented toward the outside (Figure 32).

Note: The rear slots are for a full bed installation; the front slots are for a 2/3-full bed installation.

Note: You may need to start the engine to extend or retract the cylinders for alignment with the holes.

- Note:** You can plug the unused slot with a bolt and nut to prevent assembly errors.
5. Start the engine and engage the hydraulic-lift lever to raise the bed.
 6. Release the lift lever and shut off the engine.
 7. Install the bed-safety support to prevent accidentally lowering the bed; refer to [Using the Bed Support \(page 35\)](#).
 8. Install the lynch pins to the inside ends of the clevis pins.

Note: If the automatic tailgate release is installed on the bed, ensure that the front dump link rod is placed on the inside of the left clevis pin before you install the lynch pin.

Raising the Machine

▲ DANGER

A machine on a jack may be unstable and slip off the jack, injuring anyone beneath it.

- Do not start the machine while the machine is on a jack, as the engine vibration or wheel movement could cause the machine to slip off the jack.
- Always remove the key from the key switch before getting off the machine.
- Block the tires when the machine is on a jack.

When jacking up the front of the machine, always place a wooden block (or similar material) between the jack and the machine frame.

The jacking point at the front of the machine is located under the front, center frame support (Figure 33).




Figure 33

- 1. Front jacking points

The jacking point at the rear of the machine is located under the axle (Figure 34).




Figure 34

G009824
g009824

1. Rear jacking points

Removing and Installing the Hood

Removing the Hood

1. While grasping the hood in the headlight openings, lift up the hood to release the lower mounting tabs from the frame slots (Figure 35).




Figure 35

1. Hood
2. Pivot the bottom of the hood upward until you can pull the top mounting tabs from the frame slots (Figure 35).

3. Pivot the top of the hood forward and unplug the wire connectors from the headlights (Figure 35).
4. Remove the hood.

Installing the Hood

1. Connect the lights.
2. Insert the top mounting tabs into the frame slots (Figure 35).
3. Insert the lower mounting tabs into the frame slots (Figure 35).
4. Ensure that the hood is fully engaged in the top, sides, and bottom grooves.

Lubrication

Greasing the Bearings and the Bushings

Service Interval: Every 100 hours (lubricate more frequently in heavy-duty applications).

Grease Type: No. 2 lithium grease

Important: When greasing the drive shaft universal shaft bearing crosses, pump grease until it comes out of all 4 cups at each cross.

1. Use a rag to wipe the grease fitting clean so that foreign matter cannot be forced into the bearing or bushing.
2. With a grease gun, apply grease into the grease fittings on the machine.
3. Wipe any excess grease off the machine.

The grease fitting locations and quantities are as follows:

- **Ball joints (4);** refer to [Figure 36](#)
- **Pivot mounts (2);** refer to [Figure 36](#)
- **Steering cylinder (2);** refer to [Figure 36](#)
- **Tie rods (2);** refer to [Figure 36](#)




Figure 36

- **Spring tower (2);** refer to [Figure 37](#)




Figure 37

- **Brake (1);** refer to [Figure 38](#)
- **Throttle (1);** refer to [Figure 38](#)




Figure 38

- Drive shaft U-joints (2); refer to Figure 39
- Sliding yolk (1); refer to Figure 39




Figure 39

Engine Maintenance

Engine Safety

- Shut off the engine, remove the key, and wait for all moving parts to stop before checking the oil or adding oil to the crankcase.
- Keep your hands, feet, face, clothing, and other body parts away from the muffler and other hot surfaces.

Servicing the Air Filter

Service Interval: Every 25 hours—Remove the air-cleaner cover and clean out the debris.

Every 100 hours—Change the air-cleaner filter (more frequently in dusty or dirty conditions).

Inspect the air filter and hoses periodically to maintain maximum engine protection and to ensure maximum service life. Check the air-filter cover and housing for damage, which could cause an air leak. Replace any damaged air-filter components.

1. Pull the latch outward and rotate the air-filter cover counterclockwise (Figure 40).




Figure 40

- | | |
|---------------------|-----------------------|
| 1. Latch | 4. Dust valve |
| 2. Air-filter cover | 5. Air-filter housing |
| 3. Air filter | |

2. Before removing the filter, use low-pressure air (40 psi, clean and dry) to remove large accumulations of debris packed between the outside of the air filter and the air-filter housing.

Important: Avoid using high-pressure air, which could force dirt through the filter into the intake tract. This cleaning process prevents debris from migrating into the intake when the primary filter is removed.

- Remove the air filter from the housing (Figure 40).
- Note:** Do not clean a used filter element because you may damage the filter media.
- Wipe clean the interior of the air-filter cover and housing (Figure 40).
- Remove the rubber dust valve from the cover (Figure 40).
- Clean the dirt-ejection port located in the air-cleaner cover, the dust-valve cavity, and replace the dust valve (Figure 40).
- Inspect the new air filter for shipping damage, checking the sealing end of the filter and the body.

Important: Do not use a damaged element.

- Insert the new air filter by applying light pressure to the outer rim of the filter to seat it in the air-filter housing (Figure 40).
- Align the air-filter cover with the dust valve at the 6 o'clock position when viewed from the left end of the cover (Figure 40).
- Secure the latch of the air-filter cover (Figure 40).

Note: Reset the indicator if it shows red (if equipped).

Servicing the Engine Oil

Note: Change the oil more frequently when operating conditions are extremely dusty or sandy.

Note: Dispose of the used engine oil and oil filter at a certified recycling center.


Engine-Oil Specifications

Oil Type: Detergent engine oil (API SJ or higher)

Crankcase Capacity: 2.0 L (2.1 US qt) when the filter is changed

Viscosity: See the table below.

USE THESE SAE VISCOSITY OILS




* A synthetic 5W-30 oil may be used.

Checking the Engine-Oil Level

Service Interval: Before each use or daily—Check the engine-oil level. (Check the oil level before and after the engine is first started and daily thereafter.)

Note: The best time to check the engine oil is when the engine is cool before it has been started for the day. If the engine has already ran, shut it off and wait for at least 10 minutes before checking the oil level.

- Park the machine on a level surface.
- Engage the parking brake.
- Shut off the engine and remove the key.
- Remove the dipstick and wipe it with a clean rag (Figure 42).



G025526

g025526

Figure 42

- Dipstick tube
- Filler neck
- Filler cap
- Dipstick

- Insert the dipstick into the tube and ensure that it seats fully.
- Remove dipstick and check the oil level (Figure 42).
- If the oil level is low, remove the filler cap (Figure 42) and add enough oil to raise the level to the Full mark on the dipstick.

Note: When adding oil, remove dipstick to allow proper venting. Slowly pour the oil into the filler neck, and check the level often during this process. **Do not overfill the engine with oil.**

Figure 41




Figure 43

1. Note the clearance between the fill device and the oil-fill neck.

Important: When adding engine oil or filling oil, there must be clearance between the oil fill device and the oil fill neck in the valve cover as shown in Figure 43. This clearance is necessary to permit venting when adding oil.

2. Install the filler cap onto the filler neck (Figure 42).
3. Firmly install the dipstick (Figure 42).

Changing the Engine Oil and Filter

Service Interval: After the first 50 hours

Every 200 hours

1. Raise the bed and place the safety support on the extended lift cylinder to hold up the bed.
2. Align a large drain pan under the oil-drain plug (Figure 44).




Figure 44

1. Drain plug
2. Forward
3. Remove the drain plug and let the oil flow into a drain pan (Figure 44).
4. When the oil stops draining, install the drain plug.
5. Remove the oil filter from the filter adapter (Figure 45).




Figure 45

1. Forward
2. Oil filter
3. Filter adapter
6. Wipe clean the sealing base of the filter adapter (Figure 45).
7. Apply a light coat of clean oil to the seal of the new filter.
8. Install the filter until the gasket contacts the sealing base of the filter adapter, then tighten the filter clockwise and additional 1/2 to 2/3 of a turn (Figure 45).

Note: Do not overtighten the engine-oil filter.

- Add the specified oil to the crankcase of the engine.

Checking the Oil-Pressure-Warning Light

Service Interval: Before each use or daily

Note: If you just shut off the engine, it may take 1 to 2 minutes for the light to come on.

- Engage the parking brake.
- Turn the key switch to the ON position, but do not start the engine.

Note: The oil-pressure light should glow red.

Note: If the light does not function, either a bulb is burned out, or there is a malfunction in the system that you must repair.

Servicing the Spark Plugs

Service Interval: Every 100 hours/Yearly (whichever comes first) Replace the spark plugs if necessary.

Type: Champion RN14YC (or equivalent)


Air Gap: 0.762 mm (0.03 inch)

Important: A cracked, fouled, dirty, or malfunctioning spark plug must be replaced. Do not sand-blast, scrape, or clean electrodes by using a wire brush because grit may eventually release from the plug and fall into the cylinder. The result is usually a damaged engine.

Note: The plug should be removed and checked whenever the engine malfunctions.

- Clean the area around the spark plug so that foreign matter cannot fall into the cylinder when you remove the spark plug.
- Pull the wire off the terminal of the spark plug.
- Remove the plug from the cylinder head.
- Check the condition of the side electrode, center electrode, and center electrode insulator to ensure that there is no damage (Figure 46).

Note: Do not use a damaged or worn spark plug. Replace it with a new spark plug of the specified type.



g238425

Figure 46

- | | |
|-------------------------------|---------------------------|
| 1. Side electrode | 3. Air gap (not to scale) |
| 2. Center electrode insulator | |
-
- Set the air gap between the center and side of the electrodes at 0.762 mm (0.030 inch) as shown in Figure 46.
 - Install the spark plug into the cylinder head, and torque the plug to 20 N·m (14.7 ft-lb).
 - Install the spark-plug wire.
 - Repeat steps 1 through 7 for the other spark plug.

Fuel System Maintenance

Inspecting the Carbon Canister Air Filter

Service Interval: After the first 50 hours—Inspect the opening on the filter.

Every 200 hours—Change the carbon canister air filter.

1. Locate the air filter on the bottom of the carbon canister (Figure 47).




Figure 47

1. Filter opening
2. Ensure that the opening on the bottom of the filter is clear and open.
3. Remove and install the new filter (if necessary).

Replacing the Fuel Filter

Service Interval: Every 400 hours

1. Raise the bed and place the safety support on the extended-lift cylinder to hold up the bed.
2. Unplug the wire-harness connectors from the fuel pump (Figure 48).
3. Loosen the hose clamp and disconnect the fuel line from the fuel-pump cap (Figure 48).




Figure 48

1. Fuel pump
2. Hose clamp
3. Fuel line/fuel filter

4. Remove the fuel-pump cap from the top of the fuel tank (Figure 48).

Important: Do not allow the fuel-pump assembly to rotate in the tank while removing the fuel pump. Damage to the float assembly can occur if the fuel pump rotates inside the fuel tank.

5. Remove the fuel-pump assembly and the fuel filter from the tank (Figure 48).
6. Remove the clamp securing the fuel filter hose to the fuel-pump fitting.
7. Remove the hose from the fitting (Figure 48).
8. Insert the new hose clamp onto the new fuel-filter hose.
9. Insert the hose onto the fuel pump and secure the clamp.
10. Insert the assembly into the fuel tank, and tighten the cap to 20 to 22 N·m (175 to 200 in-lb).
11. Connect the wires and secure the hose with the hose clamp.

Inspecting Fuel Lines and Connections

Service Interval: Every 400 hours/Yearly (whichever comes first)

Inspect the fuel lines, fittings, and clamps for signs of leaking, deterioration, damage, or loose connections.

Note: Repair any damaged or leaking fuel system component before using the machine.

Electrical System Maintenance

Electrical System Safety

- Disconnect the battery before repairing the machine. Disconnect the negative terminal first and the positive last. Connect the positive terminal first and the negative last.
- Charge the battery in an open, well-ventilated area, away from sparks and flames. Unplug the charger before connecting or disconnecting the battery. Wear protective clothing and use insulated tools.

Servicing the Fuses

The fuses for the electrical system are located under the center of the dash panel (Figure 49 and Figure 50).




Figure 49

1. Fuses




Figure 50

- | | |
|---------------------------|--------------------------------------|
| 1. Power takeoff (15 A) | 5. Differential lock (15 A) |
| 2. Engine start (10 A) | 6. Speedometer (10 A) |
| 3. Hazards (10 A) | 7. Headlights and rear lights (15 A) |
| 4. Engine ignition (10 A) | 8. Horn (30 A) |

Jump-Starting the Machine

⚠ WARNING

Jump-starting can be dangerous. To avoid personal injury or damage to electrical components in machine, observe the following warnings:

- Never jump-start with a voltage source greater than 15 V DC; this damages the electrical system.
- Never attempt to jump-start a discharged battery that is frozen. It could rupture or explode during jump-starting.
- Observe all battery warnings while jump-starting your machine.
- Be sure your machine is not touching the jump-start machine.
- Connecting cables to the wrong post could result in personal injury and/or damage to the electrical system.

1. Squeeze the battery cover to release the tabs from the battery base and remove the battery cover from the battery base (Figure 51).




Figure 51

1. Battery cover

2. Connect a jumper cable between the positive posts of the 2 batteries (Figure 52).

Note: The positive post may be identified by a + sign on top of the battery cover.

3. Connect 1 end of the other jumper cable to the negative terminal of the battery in the other machine.

Note: The negative terminal has “NEG” on the battery cover.

Note: Do not connect the other end of the jumper cable to the negative post of the discharged battery. Connect the jumper cable to the engine or frame. Do not connect the jumper cable to the fuel system.




Figure 52

1. Battery
4. Start the engine in the machine providing the jump-start.

Note: Let it run for a few minutes, then start your engine.

5. Remove the negative jumper cable first from your engine, then the battery in the other machine.
6. Install the battery cover to the battery base.

Servicing the Battery

Service Interval: Every 50 hours—Check the battery-fluid level (every 30 days if in storage).

Every 50 hours—Check the battery cable connections.

⚠ DANGER

Battery electrolyte contains sulfuric acid, which is fatal if consumed and causes severe burns.

- **Do not drink electrolyte or allow it to contact your skin, eyes or clothing. Wear safety glasses to shield your eyes and rubber gloves to protect your hands.**
- **Fill the battery where clean water is always available for flushing the skin.**
- Always keep the battery clean and fully charged.
- If the battery terminals are corroded, clean them with a solution of 4 parts water and 1 part baking soda.
- Apply a light coating of grease to the battery terminals to prevent corrosion.
- Maintain the battery electrolyte level.
- Keep the top of the battery clean by washing it periodically with a brush dipped in ammonia or bicarbonate of soda solution. Flush the top surface with water after cleaning. Do not remove the fill cap while cleaning.
- Ensure that the battery cables are kept tight on the terminals to provide good electrical contact.
- Maintain the cell electrolyte level with distilled or demineralized water. Do not fill the cells above the bottom of the fill ring inside each cell.
- If you store the machine in a location where temperatures are extremely high, the battery runs down more rapidly than if the machine is stored in a location where temperatures are cool.

Drive System Maintenance

Inspecting the Tires

Service Interval: Every 100 hours

Front tires air pressure specification: 220 kPa (32 psi)

Rear tires air pressure specification: 124 kPa (18 psi)

Operating accidents, such as hitting curbs, can damage a tire or rim and also disrupt wheel alignment, so inspect the tire condition after an accident.

Important: Check the tire pressure frequently to ensure proper inflation. If the tires are not inflated to the correct pressure, the tires will wear prematurely and may cause 4-wheel drive to bind.

[Figure 53](#) is an example of tire wear caused by under-inflation.




Figure 53

1. Under-inflated tire

[Figure 54](#) is an example of tire wear caused by over-inflation.




Figure 54

1. Over-inflated tire

Checking the Torque of the Wheel Nuts

Service Interval: After the first 2 hours

After the first 10 hours

Every 200 hours

⚠ WARNING

Failure to maintain proper torque of the wheel nuts could result in failure or loss of a wheel and may result in personal injury.

Torque the front and rear wheel nuts to 109 to 122 N·m (80 to 90 ft-lb) after 1 to 4 hours of operation and again after 10 hours of operation. Torque the wheel nuts every 200 hours thereafter.

Checking the Front Wheel Alignment

Service Interval: Every 400 hours/Yearly (whichever comes first)

1. Ensure that the tires are facing straight ahead.
2. Measure the center-to-center distance (at axle height) at the front and rear of the steering tires (Figure 55).

Note: The measurement must be within 0 ± 3 mm (0 ± 0.12 inch) at the front of the tire then at the rear of the tire. Rotate the tire 90° and check the measurement.

Important: Check the measurements at consistent locations on the tire. The machine should be on a flat surface with the tires facing straight ahead.





Figure 55

1. Front of the machine
2. 0 ± 3 mm (0 ± 0.12 inch)
front to rear of the tire
3. Center to center distance

3. Adjust the center-to-center distance as follows:

- A. Loosen the jam nut at the center of the tie rod (Figure 56).



g010329

Figure 56

1. Tie rods
2. Jam nuts
- B. Rotate the tie rod to move the front of the tire inward or outward to achieve the center to center distances from front to back.
- C. Tighten the tie rod jam nut when the adjustment is correct.
- D. Check to ensure that the tires turn an equal amount to the right and to the left.

Note: If the tires do not turn equally, refer to the *Service Manual* for the adjustment procedure.

Maintaining the Transmission

Checking the Transmission-Fluid Level

Service Interval: After the first 50 hours

Every 400 hours

Transmission-fluid type: Dexron VI

1. Locate the fill plug at the lower-inboard area at the back of the transmission (Figure 57).




Figure 57

1. Fill port (transmission)
2. Fill plug

2. Align a drain pan below the fill plug.
3. Rotate the plug counterclockwise and remove the plug from the fill port in the transmission (Figure 57).

Note: When the transmission fluid level is correct, the fluid should be level with the bottom of the threads in the fill port.

4. If the transmission-fluid level is low, add transmission fluid of the specified type into the transmission through the fill port until the fluid level is flush with the bottom of the threads in the port (Figure 57).

Note: Use a funnel with a flexible hose when filling the transmission.

5. Check the condition of the O-ring at the fill plug.

Note: Replace the O-ring if it is worn or damaged.

6. Install the fill plug into the transmission and tighten it by hand (Figure 57).

Changing the Transmission Fluid

Transmission-fluid type: Dexron VI

Transmission-fluid capacity: 700 ml (23.7 fl oz)

1. Park the machine to a level surface.
2. Locate the fill plug at the back inboard area of the transmission case and the locate the drain plug at the front outboard side of the transmission (Figure 58 and Figure 59).




Figure 58

1. Fill plug
2. Transmission case (back inboard location)
3. Forward




Figure 59

1. Forward
2. Drain plug
3. Remove the fill plug from the fill port by rotating the plug counterclockwise and removing it from the transmission (Figure 58).
4. Align a drain pan below the drain plug (Figure 59).

- Remove the drain plug from the drain port by rotating the plug counterclockwise and removing it from the transmission (Figure 59).

Note: Allow the transmission fluid to drain completely.

- Install the drain plug (Figure 59).
- Add 700 ml (23.7 fl oz) of Dexron VI transmission fluid into the transmission through the fill port (Figure 58).

Note: Use a funnel with a flexible hose when filling the transmission.

Note: When the transmission fluid level is correct, the fluid should be level with the bottom of the threads in the fill port.

- Install the fill plug (Figure 58).




Figure 61

- Cap
- Max mark (reservoir)
- Min mark (reservoir)
- DOT 3 brake fluid

- If the fluid level is low, perform the following:
 - Wipe clean the area around the cap for the reservoir (Figure 61).
 - Remove the cap from the reservoir (Figure 61).
 - Add the specified fluid to raise the level midway between the Min and Max marks on the side of the reservoir (Figure 61).
 - Install the cap hand tight (Figure 61).
- Align the holes in the control-cover plate to the holes in the seat base (Figure 60).
- Secure the plate to the base with the 6 hex-washer screws (Figure 60) that you removed in step 2.
- Thread the knobs onto the rods for the hydraulic-lift lever and the speed-range lever (Figure 60).




Figure 60

- Knob (speed-range lever)
- Rod (hydraulic-lift lever)
- Rod (speed-range lever)
- Control-cover plate
- Knob (hydraulic-lift lever)
- Hex-washer screws (#10 x 3/4 inch)

- Remove the 6 hex-washer screws (#10 x 3/4 inch) that secure the control-cover plate to the seat base, and remove the cover plate (Figure 60).
- Move the speed-range lever to the TRANSPORT position; refer to [Using the Speed-Range Control \(page 27\)](#).
- Check the fluid level in the reservoir for the speed-control cylinder (Figure 61).

Note: The normal fluid level is between the Min and Max marks on the side of the reservoir.

Adjusting the Speed Control

Important: The minimum controlled speed for the machine is 4.0 kph (2.5 mph) at full engine speed. Controlling the machine speed slower than 4.0 kph (2.5 mph) results in excessive belt and clutch wear.

- Drive the machine in speed range A (low range), B (mid-low range), C (mid-high range), or D (high range) in order to determine which speed range includes the maximum ground speed that you want to set; refer to [Using the Speed-Range Control \(page 27\)](#).

Note: Use the speedometer to determine the speed that the machine is traveling.

- Remove the knobs from the hydraulic-lift lever and the speed-range lever (Figure 60).

3. Remove the 6 hex-washer screws (#10 x 3/4 inch) that secure the control-cover plate to the seat base, and remove the cover plate (Figure 60).
4. Move the speed-range lever to the **T** (TRANSPORT) position (Figure 62).
5. Loosen the 2 hex-socket screws (5/16 x 3/4 inch) that secure the detent plate to the lever-support bracket (Figure 62).




Figure 62

- | | |
|--------------------------|-----------------|
| 1. Lever-support bracket | 3. Detent plate |
| 2. Hex-socket screws | |

6. Move the detent plate in one of the following directions:
 - Move the detent plate **forward** to increase the maximum ground speed limit (Figure 62).
 - Move the detent plate **rearward** to decrease the maximum ground speed limit (Figure 62).
7. Tighten the 2 hex-socket screws (5/16 x 3/4 inch) to 19.8 to 25.4 N·m (14.6 to 18.7 ft-lb).
8. Drive the machine with the speed control set to speed range for which you are setting the maximum ground speed limit. If the maximum ground speed limit is too fast or too slow, repeat steps 1 through 8 until the correct maximum ground speed limit is attained.
9. Align the holes in the control-cover plate to the holes in the seat base (Figure 60).
10. Secure the plate to the base with the 6 hex-washer screws (Figure 60) that you removed in step 3.
11. Thread the knobs onto the rods for the hydraulic-lift lever and the speed-range lever (Figure 60).

Checking the Drive Belt

Service Interval: Every 400 hours

1. Remove the 9 hex-washer bolts (1/4 x 1 inch) that secure the transmission cover to the mounting plate of the transmission (Figure 63).




Figure 63

- | | |
|------------------------------------|--|
| 1. Hex-washer bolts (1/4 x 1 inch) | 4. Mounting plate |
| 2. Transmission cover | 5. Tapered faces (primary clutch) |
| 3. Drive belt | 6. Belt width—replace at 29.5 mm (1.16 inches) or less |

2. Move the cover forward until you can see the drive belt (Figure 63).
3. Check the tapered faces of the primary clutch for signs of damage (Figure 63).

Note: If the faces of the primary clutch are damaged, replace the primary clutch; contact your Authorized Service Dealer.

4. Check the drive belt for missing or damaged cogs (Figure 63).

Note: If the cogs of the drive belt are missing or damaged, replace the drive belt.

5. Measure across the belt and record the belt width (Figure 63).

Note: If the width of the belt is 29.5 mm (1.16 inches) or less, replace the belt (Figure 63).

6. Align the holes in the transmission cover with the holes in the mounting plate (Figure 63).
7. Secure the cover to the mounting plate (Figure 63) with the 9 hex-washer bolts (1/4 x 1 inch).

that you removed in step 1, and torque the bolts to 10.2 to 12.4 N·m (90 to 110 in-lb).

Cleaning the Clutches

Service Interval: Every 400 hours

1. Remove the 9 hex-washer bolts (1/4 x 1 inch) that secure the transmission cover to the mounting plate of the transmission (Figure 64).




Figure 64

- | | |
|------------------------------------|---------------------|
| 1. Hex-washer bolts (1/4 x 1 inch) | 4. Mounting plate |
| 2. Transmission cover | 5. Secondary clutch |
| 3. Primary clutch | |

2. At the primary and secondary clutches, Remove dirt and mud buildup with water and dry immediately with compressed air to remove excess water and debris.
3. Remove any remaining debris using a fast-drying contact cleaner or brake cleaner.

Note: Note: Remove the debris in and around moving parts.

4. If debris or buildup exists around the belt or along the clutch shaft, use a fine abrasive pad or a similar product to remove it.
5. Align the holes in the transmission cover with the holes in the mounting plate (Figure 64).
6. Secure the cover to the mounting plate (Figure 64) with the 9 hex-washer bolts (1/4 x 1 inch) that you removed in step 1, and torque the bolts to 10.2 to 12.4 N·m (90 to 110 in-lb).

Maintaining the Differential and Axles

Changing the Differential Oil

Oil type: 80W90 API GL-5

Oil capacity: 550 ml (18.6 fl oz)

1. Align a drain pan under the drain plug (Figure 65).




Figure 65

- | | |
|--------------|---------------|
| 1. Fill plug | 3. Drain port |
| 2. Fill port | 4. Drain plug |
2. Remove the fill plug from the fill port and the drain plug from the drain port of the differential (Figure 65).

Note: Allow the differential to completely drain.

3. Check the condition of the O-rings on the plugs.

Note: Replace damaged or worn O-rings.

4. Install the drain plug into the drain port (Figure 65), and tighten the plug to 14 to 19 N·m (10 to 14 ft-lb).

Note: The drain plug is magnetic. It is normal to see small amounts of ferrous-metal particles around magnet—expect more particles around the magnet after the initial break-in.

5. Add 550 ml (18.6 fl oz) of the specified oil into the fill port of the differential (Figure 65).

Note: Use a funnel with a flexible hose to add oil to the differential.

6. Install the fill plug into the fill port (Figure 65), and tighten the plug to 14 to 19 N·m (10 to 14 ft-lb).

Checking the Constant-Velocity Boots

Service Interval: Every 100 hours

1. Jack up the back end of the machine and support it with jack stands; refer to [Raising the Machine \(page 37\)](#).
2. Check the CV (constant velocity) boots at the rear axles for damage and leaking lubricant ([Figure 66](#)).

Note: Replace any damaged or leaking CV boot before operating the machine.




Figure 66

3. Remove the jack stands and lower the machine to the ground.

Cooling System Maintenance

Cooling System Safety

- Swallowing engine coolant can cause poisoning; keep out of reach from children and pets.
- Discharge of hot, pressurized coolant or touching a hot radiator and surrounding parts can cause severe burns.
 - Always allow the engine to cool at least 15 minutes before removing the radiator cap.
 - Use a rag when opening the radiator cap, and open the cap slowly to allow steam to escape.
- Do not operate the machine without the covers in place.
- Keep your fingers, hands and clothing clear of rotating fan and drive belt.
- Shut off the engine and remove the key before performing maintenance.

Checking the Engine-Coolant Level

Service Interval: Before each use or daily—Check the level of the coolant. Check the Coolant level at the overflow reservoir only. Do not remove the radiator cap. (Check the coolant level before the engine is first started and daily thereafter.)

Coolant type: a 50/50 solution of water and permanent ethylene-glycol antifreeze

⚠ CAUTION

If the engine has been running, the pressurized, hot coolant can escape and cause burns.

- Do not open the radiator cap.
- Allow the engine to cool for at least 15 minutes or until the radiator cap is cool enough to touch without burning your hand.
- Use a rag when opening the reserve-tank cap, and open the cap slowly to allow steam to escape.
- Do not check the coolant level at the radiator; check the coolant level at the reserve tank only.

1. Park the machine on a level surface.

2. Engage the parking brake.
3. Shut off the engine and remove the key.
4. Check the coolant level at the reserve tank (Figure 67).

Note: The coolant should be up to the bottom of the filler neck.




Figure 67

1. Coolant-reserve tank
5. If coolant is low, remove the reserve- tank cap and add a 50/50 mixture of water and permanent ethylene-glycol antifreeze.

Note: Do not overfill.

6. Install the reserve-tank cap.

Removing Debris from the Cooling System

Service Interval: Before each use or daily—Remove debris from the engine area and radiator. (Clean it more frequently in dirty conditions.)

1. Park the machine on a level surface.
2. Engage the parking brake.
3. Shut off the engine and remove the key.
4. Clean the engine area thoroughly of all debris.
5. Unlatch and remove the radiator screen from the front of the radiator (Figure 68).




Figure 68

1. Radiator screen
2. Latch

6. If equipped, rotate the latches and pivot the oil cooler away from the radiator (Figure 69).




Figure 69

1. Radiator housing
2. Oil cooler
3. Latches

7. Clean the radiator, oil cooler, and screen with compressed air.

Note: Blow debris away from the radiator.

8. Install the cooler and screen to the radiator.

Changing the Engine Coolant

Service Interval: Every 1,000 hours/Every 2 years (whichever comes first)

Cooling-system capacity: 3.7 L (4 US qt)

Coolant type: a 50/50 solution of water and permanent ethylene-glycol antifreeze

1. Park the machine on a level surface.
2. Raise the bed and install the bed safety support on the extended lift cylinder to secure the bed.

⚠ CAUTION

If the engine has been running, the cooling system pressurizes with hot coolant that can escape and cause burns.

- Do not open the radiator cap when the engine is running.
 - Allow the engine to cool for at least 15 minutes or until the radiator cap is cool enough to touch without burning your hand.
 - Use a rag to open the radiator cap. Open the cap slowly to allow the steam to escape.
3. Remove the radiator cap ([Figure 70](#)).




Figure 70

1. Radiator cap

4. Remove the reserve-tank cap ([Figure 70](#)).




Figure 71

1. Reserve tank-cap
2. Reserve tank

5. Disconnect the lower radiator hose and allow the coolant to flow into a drain pan.

Note: When the coolant stops flowing, connect the lower radiator hose.

6. Slowly fill the radiator with a 50/50 mixture of water and permanent ethylene-glycol antifreeze
7. Top off the radiator and install the cap ([Figure 70](#)).
8. Slowly fill the coolant-reserve tank until level reaches the bottom of the filler neck ([Figure 71](#)).
9. Install the reserve-tank cap ([Figure 71](#)).
10. Start the engine and operate it until it is warm.
11. Shut off the engine, check the coolant level, and replenish the coolant, if necessary.

Brake Maintenance

Checking the Brake-Fluid Level

Service Interval: Before each use or daily—Check the brake-fluid level. (Check the level before the engine is first started and daily thereafter.)

Every 1,000 hours/Every 2 years (whichever comes first)—Change the brake fluid.

Brake-fluid type: DOT 3 brake fluid

Note: The brake-fluid reservoir ships from the factory filled with DOT 3 brake fluid.

1. Park the machine on a level surface.
2. Engage the parking brake.
3. Shut off the engine and remove the key.
4. Remove the hood.
5. Check the fluid level in the brake-fluid reservoir ([Figure 72](#) and [Figure 73](#)).

Note: The fluid level should be up to the Full line on the reservoir.




Figure 72

1. Brake-fluid reservoir




Figure 73

1. Brake-fluid reservoir
6. If the fluid level is low, perform the following:
 - A. Clean the area around the cap for the reservoir ([Figure 73](#)).
 - B. Remove the reservoir cap ([Figure 73](#)).
 - C. Add the specified brake fluid to the Full line on the reservoir ([Figure 73](#)).
 - Important: Do not overfill the brake-fluid reservoir.**
 - D. Install the cap ([Figure 73](#)).
7. Install the hood.

Adjusting the Parking Brake

Service Interval: After the first 10 hours

Every 200 hours

1. Remove the rubber grip from the parking-brake lever ([Figure 74](#)).




Figure 74

1. Grip
2. Parking-brake lever

2. Loosen the set screw securing the knob to the parking-brake lever (Figure 75).




Figure 75

1. Knob
2. Set screw
3. Parking-brake lever

3. Rotate the knob (Figure 75) until a force of 20 to 22 kg (45 to 50 lb) is required to actuate the lever.
4. Tighten the set screw when finished (Figure 75).

Note: If you can no longer make a parking-brake adjustment by adjusting the parking-brake lever, loosen the handle to the middle of the adjustment and adjust the cable at the rear, then repeat step 3.

5. Install the rubber grip onto the parking-brake lever (Figure 74).

Adjusting the Brake Pedal

Service Interval: Every 200 hours

1. Remove the hood.
2. Remove the cotter pin and clevis pin securing the master cylinder yoke to the brake-pedal pivot (Figure 76).




Figure 76

1. Cotter pin
2. Brake-pedal pivot
3. Clevis pin
4. Master cylinder yoke
5. Jam nut

3. Lift up on the brake pedal (Figure 77) until it contacts the frame.




Figure 77

1. Brake pedal
2. Accelerator pedal

4. Loosen the jam nuts securing the yoke to the master cylinder shaft (Figure 76).
5. Adjust the yoke until its holes align with the hole in the brake-pedal pivot (Figure 76).
6. Secure the yoke to the pedal pivot with the clevis pin and cotter pin (Figure 76).
7. Tighten the jam nut securing the yoke to the master cylinder shaft (Figure 76).

Note: The brake master cylinder must relieve the pressure from the service brake when it is properly adjusted.

8. Install the hood.

Controls System Maintenance

Converting the Speedometer

You can convert the speedometer from mph to kpm or kph to mph.

1. Position the machine on a level surface, shut off the engine, engage the parking brake, and remove the key.
2. Remove the hood.
3. Locate the 2 loose wires next to the meter (Figure 78).




Figure 78

1. Meter (forward face)
 2. Plug
 3. Speedometer wires
-
4. Remove the connector plug from the harness wire and connect the wires together (Figure 78).
- Note:** The meter switches from mph to kph. Retain the plug in order to convert the speedometer to mph.
5. Install the hood.

Hydraulic System Maintenance

Hydraulic System Safety

- Seek immediate medical attention if fluid is injected into skin. Injected fluid must be surgically removed within a few hours by a doctor.
- Before disconnecting or performing any work on the hydraulic system, relieve all pressure in the system by shutting off the engine, cycling the dump valve from raise to lower, and/or lowering the cargo bed and attachments. Place the remote hydraulics lever in the float position. Do not work under a raised bed without the proper bed safety support in place.
- Ensure that all hydraulic-fluid hoses and lines are in good condition and that all hydraulic connections and fittings are tight before applying pressure to the hydraulic system.
- Keep your hands and body away from pinhole leaks or nozzles that eject high-pressure hydraulic fluid.
- Use cardboard or paper to find hydraulic leaks.

Servicing the Hydraulic System

Hydraulic Fluid Specifications

The reservoir is filled at the factory with high-quality hydraulic fluid. Check the level of the hydraulic fluid before you first start the engine and daily thereafter; refer to [Checking the Hydraulic-Fluid Level \(page 59\)](#).

Recommended replacement fluid: Toro PX Extended Life Hydraulic Fluid; available in 19 L (5 US gallon) pails or 208 L (55 US gallon) drums.

Note: A machine using the recommended replacement fluid requires less frequent fluid and filter changes.

Alternative fluids: If Toro PX Extended Life Hydraulic Fluid is not available, you may use another conventional, petroleum-based hydraulic fluid having specifications that fall within the listed range for all the following material properties and that it meets industry standards. Do not use synthetic fluid. Consult with your lubricant distributor to identify a satisfactory product.

Note: Toro does not assume responsibility for damage caused by improper substitutions, so use

products only from reputable manufacturers who will stand behind their recommendation.

High Viscosity Index/Low Pour Point Anti-wear Hydraulic Fluid, ISO VG 46

Material Properties:

Viscosity, ASTM D445	cSt @ 40°C (104°F) 44 to 48
----------------------	--------------------------------

Viscosity Index ASTM D2270	140 or higher
----------------------------	---------------

Pour Point, ASTM D97	-37°C to -45°C (-34°F to -49°F)
----------------------	---------------------------------

Industry Specifications:	Eaton Vickers 694 (I-286-S, M-2950-S/35VQ25 or M-2952-S)
--------------------------	--

Note: Many hydraulic fluids are almost colorless, making it difficult to spot leaks. A red dye additive for the hydraulic fluid is available in 20 ml (0.67 fl oz) bottles. A bottle is sufficient for 15 to 22 L (4 to 6 US gallons) of hydraulic fluid. Order Part No. 44-2500 from your authorized Toro distributor.

Checking the Hydraulic-Fluid Level

Service Interval: Before each use or daily—Check the hydraulic-fluid level. (Check the level of hydraulic fluid before the engine is first started and daily thereafter.)

Hydraulic-fluid capacity for Non-TC model: 7.5 L (2 US gallons)

Hydraulic-fluid capacity for Non-TC model with the High Flow Hydraulic Kit (optional) or TC model: 15.1 L (4 US gallons)

1. Park the machine on a level surface.
2. Engage the parking brake.
3. Shut off the engine and remove the key.
4. Clean the area around the filler neck and the cap of the hydraulic reservoir ([Figure 79](#) and [Figure 80](#)).




Figure 79
Hydraulic-fluid level (non-TC models)

1. Cap 2. Dipstick 3. Filler neck

5. Remove the cap and dipstick from the filler neck of the reservoir and wipe the dipstick clean with a rag (Figure 79 and Figure 80).
6. Insert the dipstick into the filler neck; then remove it and check the fluid level (Figure 79 and Figure 80).
 - **Non-TC model:** The hydraulic-fluid level should be between the lower indented area on the dipstick.
 - **Non-TC model with the High-Flow-Hydraulic Kit (option) or TC model:** The hydraulic-fluid level should be between the upper indented area on the dipstick.
7. If the level is low, add the specified hydraulic fluid into the reservoir to raise the level to the middle of the indented area on the dipstick (Figure 79 and Figure 80).
8. Install the dipstick and cap to the filler neck of the reservoir (Figure 79 and Figure 80).




Figure 80
Hydraulic-fluid level (non-TC model with the High Flow Hydraulic Kit (optional kit) or TC model)

1. Cap 2. Dipstick 3. Filler neck

Replacing the Hydraulic Filter

Service Interval: Every 1,000 hours—if you are **using** the recommended hydraulic fluid, replace the hydraulic filter.

Important: Use of any other filter may void the warranty on some components.

1. Park the machine on a level surface, shut off the engine, engage the parking brake, and remove the key.
2. Clean the area around filter-mounting area (Figure 81).




Figure 81

1. Filter adapter
2. Hydraulic filter
3. Place a drain pan under the filter (Figure 81).
4. Remove the filter by rotating it counterclockwise (Figure 81).
5. Clean the filter-seating surface of the filter adapter (Figure 81).
6. Lubricate the gasket on the new filter with the specified hydraulic fluid.
7. Thread the filter onto the filter adapter until the gasket of the filter contacts the seating surface of the adapter (Figure 81), and then tighten the filter an additional 1/2 turn (Figure 81).
8. Start the engine and let it run for about 2 minutes to purge air from the system.
9. Shut off the engine and check the hydraulic-fluid level in the hydraulic tank and the filter area for leaks.

Changing the Hydraulic Fluid

Service Interval: Every 2,000 hours—if you are **using** the recommended hydraulic fluid, change the hydraulic fluid.

Every 800 hours—if you are **not using** the recommended hydraulic fluid or have ever filled the reservoir with an alternative fluid, replace the hydraulic fluid and filter.

Hydraulic-fluid capacity for Non-TC model: 7.5 L (2 US gallons)

Hydraulic-fluid capacity for Non-TC model with the High Flow Hydraulic Kit (optional) or TC model: 15.1 L (4 US gallons)

1. Park the machine on a level surface, shut off the engine, engage the parking brake, and remove the key.
2. Raise the cargo bed.
3. Remove the cap and dipstick from the filler neck of the hydraulic tank (Figure 82).




Figure 82

1. Cap
2. Dipstick
3. Filler neck (hydraulic tank)
4. Siphon equipment
5. Collection container
4. Route the intake hose of the siphoning equipment through the filler neck of the hydraulic tank and to the bottom of the tank (Figure 82).
5. Direct the discharge hose of the siphoning equipment into a collection container (Figure 82) with a 11.4 L (3 US gallon) capacity—Non-TC model or 18.9 L (5 US gallon) capacity—Non-TC

model with the High Flow Hydraulic Kit (option) or TC model.

6. Siphon the hydraulic fluid from the hydraulic tank.
7. Remove the siphoning equipment from the hydraulic tank (Figure 82).
8. Add 7.5 L (2 US gallons)—Non-TC model or 15.1 L (4 US gallons)—Non-TC model with the High Flow Hydraulic Kit (option) or TC model of the specified hydraulic fluid into the hydraulic tank (Figure 82).

Important: Use only the hydraulic fluids specified. Other fluids could cause system damage.

9. Install the dipstick and cap to the filler neck of the hydraulic tank (Figure 82).
10. Start the engine and operate the machine to fill the hydraulic system.
11. Check the hydraulic-fluid level and replenish it, if required.

Raising the Cargo Bed in an Emergency

The cargo bed can be raised in an emergency without starting the engine by cranking starter or by jumping the hydraulic system.

Raising the Cargo Bed using the Starter

Crank the starter while holding the lift lever in the Raise position. Run the starter for 10 seconds, then wait 60 seconds before engaging the starter again. If the engine does not crank, you must remove the load and bed (attachment) to service the engine or transaxle.

Raising the Cargo Bed by Jumping the Hydraulic System

⚠ CAUTION

A raised bed full of material without the proper safety support rod may lower unexpectedly. Working under an unsupported raised bed may cause injury to you or others.

- Before servicing or making adjustments to the machine, park the machine on a level surface, engage the parking brake, shut off the engine, and remove the key.
- Remove any load material from the bed or other attachment and insert the safety support on a fully extended cylinder rod before working under a raised bed.

You will need 2 hydraulic hoses, each with a male and female quick coupler, that fit the machine couplers, to perform this operation.

1. Back another machine up to the rear of the disabled machine.

Important: The machine hydraulic system uses Dexron III ATF. To avoid system contamination, make sure that the machine used to jump the hydraulic system uses an equivalent fluid.

2. On both machine, disconnect the 2 quick-coupler hoses from the hoses secured to the coupler bracket (Figure 83).




Figure 83

1. Quick-coupler hose A
2. Quick-coupler hose B

3. On the disabled machine, connect the 2 jumper hoses to the hoses that were disconnected (Figure 84).
4. Cap the unused fittings.




Figure 84

1. Disconnected hoses
2. Jumper hoses
5. On the other machine, connect the 2 hoses to the coupler still in the coupler bracket (connect the top hose to the top coupler and the bottom hose to the bottom coupler) (Figure 85).
6. Cap the unused fittings.




Figure 85

1. Jumper hoses
7. Keep all bystanders away from the machines.
8. Start the second machine and move the lift lever to the raise position, which raises the disabled cargo bed.
9. Move the hydraulic-lift lever to the NEUTRAL position, and engage the lift-lever lock.
10. Install the bed support onto the extended lift cylinder; refer to [Using the Bed Support \(page 35\)](#).

Note: With both the machine turned off, move the lift lever back and forth to remove the system pressure and ease the disconnection of the quick couplers.

11. After completing the operation, remove the jumper hoses and connect the hydraulic hoses to both machines.

Important: Check the hydraulic fluid levels, in both machines, before resuming operation.

Cleaning

Washing the Machine

Service Interval: Before each use or daily—Wash the machine.

Wash the machine as needed using water alone or with a mild detergent. You may use a rag when washing the machine.

Important: Do not use brackish or reclaimed water to clean the machine.

Important: Do not use power-washing equipment to wash the machine. Power-washing equipment may damage the electrical system, loosen important decals, or wash away necessary grease at friction points. Avoid excessive use of water near the control panel, engine, and battery.

Important: Do not wash the machine with the engine running. Washing the machine with the engine running may result in internal engine damage.

Storage

Storage Safety

- Shut off the machine, remove the key (if equipped), and wait for all movement to stop before you leave the operator's position. Allow the machine to cool before adjusting, servicing, cleaning, or storing it.
- Do not store the machine or fuel container where there is an open flame, spark, or pilot light, such as on a water heater or other appliance.

Storing the Machine

Service Interval: Every 200 hours—Inspect the service and parking brakes.

Every 400 hours—Visually inspect the brakes for worn brake shoes.

Yearly

1. Position the machine on a level surface, engage the parking brake, shut off the engine, and remove the key from the key switch.
2. Clean dirt and grime from the entire machine, including the outside of the engine cylinder head fins and blower housing.

Important: You can wash the machine with mild detergent and water. Do not use high-pressure water to wash the machine. Pressure washing the machine may damage the electrical system or wash away necessary grease at friction points. Avoid excessive use of water, especially near the control panel, lights, engine, and battery.

3. Check and adjust the brake pedal and parking brake, if necessary; refer to [Adjusting the Brake Pedal \(page 57\)](#) and [Adjusting the Parking Brake \(page 56\)](#).
4. Service the air cleaner; refer to [Servicing the Air Filter \(page 40\)](#).
5. Grease the machine; refer to [Greasing the Bearings and the Bushings \(page 39\)](#).
6. Change the engine oil and filter; refer to [Servicing the Engine Oil \(page 41\)](#).
7. Check the tire pressure; refer to [Checking the Tire Pressure \(page 21\)](#).
8. For storage over 30 days, prepare the fuel system as follows:

A. Add a petroleum based stabilizer/conditioner to the fuel in the tank. Do not use an alcohol-based stabilizer (ethanol or methanol).

Important: Do not store fuel containing stabilizer/conditioner longer than the

duration recommended by the fuel stabilizer manufacturer.

- B. Run the engine to distribute conditioned fuel through the fuel system for 5 minutes.
- C. Shut off the engine, allow it to cool, and drain the fuel tank.
- D. Start the engine and run it until it stops.
- E. Start and run the engine again until it does not start again.
- F. Dispose of drained fuel properly. Recycle as per local codes.

9. Remove the spark plugs and check their condition; refer to [Servicing the Spark Plugs \(page 43\)](#).
10. With the spark plugs removed from the engine, pour 15 ml (2 tablespoons) of engine oil into the spark-plug hole.
11. Use the starter to crank the engine and distribute the oil inside the cylinder.
12. Install the spark plugs and tighten each one to the recommended torque; refer to [Servicing the Spark Plugs \(page 43\)](#).

Note: Do not install the spark-plug wires on the spark plugs.

13. Check the anti freeze protection and add a 50/50 solution of water and anti freeze as needed for expected minimum temperature in your area.
14. Remove the battery from the chassis, and charge it fully; refer to [Servicing the Battery \(page 47\)](#).

Note: Do not connect the battery cables to the battery posts during storage.

Important: The battery must be fully charged to prevent it from freezing and being damaged at temperatures below 0°C (32°F). A fully charged battery maintains its charge for about 50 days at temperatures lower than 4°C (40°F). If the temperatures will be above 4°C (40°F), check the water level in the battery and charge it every 30 days.

15. Check and tighten all fasteners. Repair or replace any part that is damaged.
16. Paint all scratched or bare metal surfaces with paint available from your authorized Toro distributor.
17. Store the machine in a clean, dry garage or storage area.
18. Remove the key from the key switch and put it in a safe place that is out of the reach of children.
19. Cover the machine to protect it and keep it clean.

Troubleshooting

Problem	Possible Cause	Corrective Action
The quick couplers are difficult to connector disconnect.	1. The hydraulic pressure not relieved (the quick coupler is under pressure).	1. Shut off the engine, move the hydraulic-lift lever forward and backward several times, and connect the quick couplers for the fittings in the auxiliary hydraulic panel.
The power steering moves hard.	1. The hydraulic-fluid level is low. 2. The hydraulic fluid is hot. 3. The hydraulic pump not operating.	1. Service the hydraulic reservoir. 2. Check the hydraulic-fluid level and service if it is low. Contact an Authorized Service Dealer. 3. Contact an Authorized Service Dealer.
The hydraulic fitting leaks.	1. The fitting is loose. 2. The hydraulic fitting is missing an O-ring.	1. Tighten the fitting. 2. Install the missing O-ring.
An attachment does not function.	1. The quick couplers are not fully connected. 2. The quick couplers are interchanged.	1. Disconnect the quick couplings, remove and debris from the couplings, connect the couplings. Replace any damaged couplings. 2. Disconnect the quick couplings, align the couplings to the correct ports on the auxiliary hydraulic panel, connect the couplings.
A squealing noise is heard.	1. The Hydraulic-lift lever is locked in the ON position (causing hydraulic fluid to flow over the relief valve).	1. Set the hydraulic-lift lock to the UNLOCK position and move the hydraulic-lift lever to NEUTRAL.
The engine does not start.	1. The hydraulic-lift lever is locked in the ON position.	1. Set the hydraulic-lift lock to the UNLOCK position, move the hydraulic-lift lever to NEUTRAL, and start the engine.
The transmission is hard to shift.	1. The engine-idle rpm is set too fast. 2. The clutches are dirty.	1. Adjust the engine low idle to 1,250 to 1,350 rpm. 2. Clean the clutches.
The clutch engagement is abrupt.	1. The engine idle is too slow. 2. The belt is new. 3. The accelerator pedal free play is too large. 4. The clutched are dirty.	1. Adjust the engine low idle to 1,250 to 1,350 rpm. 2. Allow 10 hours of normal operation for the belt break-in period. 3. Adjust the accelerator pedal. 4. Clean the clutches.

Notes:

Notes:

Notes:

California Proposition 65 Warning Information

What is this warning?

You may see a product for sale that has a warning label like the following:



What is Prop 65?

Prop 65 applies to any company operating in California, selling products in California, or manufacturing products that may be sold in or brought into California. It mandates that the Governor of California maintain and publish a list of chemicals known to cause cancer, birth defects, and/or other reproductive harm. The list, which is updated annually, includes hundreds of chemicals found in many everyday items. The purpose of Prop 65 is to inform the public about exposure to these chemicals.

Prop 65 does not ban the sale of products containing these chemicals but instead requires warnings on any product, product packaging, or literature with the product. Moreover, a Prop 65 warning does not mean that a product is in violation of any product safety standards or requirements. In fact, the California government has clarified that a Prop 65 warning “is not the same as a regulatory decision that a product is ‘safe’ or ‘unsafe.’” Many of these chemicals have been used in everyday products for years without documented harm. For more information, go to <https://oag.ca.gov/prop65/faqs-view-all>.

A Prop 65 warning means that a company has either (1) evaluated the exposure and has concluded that it exceeds the “no significant risk level”; or (2) has chosen to provide a warning based on its understanding about the presence of a listed chemical without attempting to evaluate the exposure.

Does this law apply everywhere?

Prop 65 warnings are required under California law only. These warnings are seen throughout California in a wide range of settings, including but not limited to restaurants, grocery stores, hotels, schools, and hospitals, and on a wide variety of products. Additionally, some online and mail order retailers provide Prop 65 warnings on their websites or in catalogs.

How do the California warnings compare to federal limits?

Prop 65 standards are often more stringent than federal and international standards. There are various substances that require a Prop 65 warning at levels that are far lower than federal action limits. For example, the Prop 65 standard for warnings for lead is 0.5 µg/day, which is well below the federal and international standards.

Why don't all similar products carry the warning?

- Products sold in California require Prop 65 labelling while similar products sold elsewhere do not.
- A company involved in a Prop 65 lawsuit reaching a settlement may be required to use Prop 65 warnings for its products, but other companies making similar products may have no such requirement.
- The enforcement of Prop 65 is inconsistent.
- Companies may elect not to provide warnings because they conclude that they are not required to do so under Prop 65; a lack of warnings for a product does not mean that the product is free of listed chemicals at similar levels.

Why does Toro include this warning?

Toro has chosen to provide consumers with as much information as possible so that they can make informed decisions about the products they buy and use. Toro provides warnings in certain cases based on its knowledge of the presence of one or more listed chemicals without evaluating the level of exposure, as not all the listed chemicals provide exposure limit requirements. While the exposure from Toro products may be negligible or well within the “no significant risk” range, out of an abundance of caution, Toro has elected to provide the Prop 65 warnings. Moreover, if Toro does not provide these warnings, it could be sued by the State of California or by private parties seeking to enforce Prop 65 and subject to substantial penalties.

EEA/UK Privacy Notice

Toro's Use of Your Personal Information

The Toro Company ("Toro") respects your privacy. When you purchase our products, we may collect certain personal information about you, either directly from you or through your local Toro company or dealer. Toro uses this information to fulfil contractual obligations - such as to register your warranty, process your warranty claim or to contact you in the event of a product recall - and for legitimate business purposes - such as to gauge customer satisfaction, improve our products or provide you with product information which may be of interest. Toro may share your information with our subsidiaries, affiliates, dealers or other business partners in connection with these activities. We may also disclose personal information when required by law or in connection with the sale, purchase or merger of a business. We will never sell your personal information to any other company for marketing purposes.

Retention of your Personal Information

Toro will keep your personal information as long as it is relevant for the above purposes and in accordance with legal requirements. For more information about applicable retention periods please contact legal@toro.com.

Toro's Commitment to Security

Your personal information may be processed in the US or another country which may have less strict data protection laws than your country of residence. Whenever we transfer your information outside of your country of residence, we will take legally required steps to ensure that appropriate safeguards are in place to protect your information and to make sure it is treated securely.

Access and Correction

You may have the right to correct or review your personal data, or object to or restrict the processing of your data. To do so, please contact us by email at legal@toro.com. If you have concerns about the way in which Toro has handled your information, we encourage you to raise this directly with us. Please note that European residents have the right to complain to your Data Protection Authority.



The Toro Warranty

Two-Year or 1,500 Hours Limited Warranty

Conditions and Products Covered

The Toro Company and its affiliate, Toro Warranty Company, pursuant to an agreement between them, jointly warrant your Toro Commercial product ("Product") to be free from defects in materials or workmanship for 2 years or 1,500 operational hours*, whichever occurs first. This warranty is applicable to all products with the exception of Aerators (refer to separate warranty statements for these products). Where a warrantable condition exists, we will repair the Product at no cost to you including diagnostics, labor, parts, and transportation. This warranty begins on the date the Product is delivered to the original retail purchaser.

* Product equipped with an hour meter.

Instructions for Obtaining Warranty Service

You are responsible for notifying the Commercial Products Distributor or Authorized Commercial Products Dealer from whom you purchased the Product as soon as you believe a warrantable condition exists. If you need help locating a Commercial Products Distributor or Authorized Dealer, or if you have questions regarding your warranty rights or responsibilities, you may contact us at:

Toro Commercial Products Service Department
Toro Warranty Company
8111 Lyndale Avenue South
Bloomington, MN 55420-1196
952-888-8801 or 800-952-2740
E-mail: commercial.warranty@toro.com

Owner Responsibilities

As the product owner, you are responsible for required maintenance and adjustments stated in your *Operator's Manual*. Repairs for product issues caused by failure to perform required maintenance and adjustments are not covered under this warranty.

Items and Conditions Not Covered

Not all product failures or malfunctions that occur during the warranty period are defects in materials or workmanship. This warranty does not cover the following:

- Product failures which result from the use of non-Toro replacement parts, or from installation and use of add-on, or modified non-Toro branded accessories and products.
- Product failures which result from failure to perform recommended maintenance and/or adjustments.
- Product failures which result from operating the Product in an abusive, negligent, or reckless manner.
- Parts consumed through use that are not defective. Examples of parts which are consumed, or used up, during normal Product operation include, but are not limited to, brake pads and linings, clutch linings, blades, reels, rollers and bearings (sealed or greasable), bed knives, spark plugs, castor wheels and bearings, tires, filters, belts, and certain sprayer components such as diaphragms, nozzles, and check valves.
- Failures caused by outside influence, including, but not limited to, weather, storage practices, contamination, use of unapproved fuels, coolants, lubricants, additives, fertilizers, water, or chemicals.
- Failure or performance issues due to the use of fuels (e.g. gasoline, diesel, or biodiesel) that do not conform to their respective industry standards.
- Normal noise, vibration, wear and tear, and deterioration. Normal "wear and tear" includes, but is not limited to, damage to seats due to wear or abrasion, worn painted surfaces, scratched decals or windows.

Parts

Parts scheduled for replacement as required maintenance are warranted for the period of time up to the scheduled replacement time for that part. Parts replaced under this warranty are covered for the duration of the original product warranty and become the property of Toro. Toro will make the final decision whether to repair any existing part or assembly or replace it. Toro may use remanufactured parts for warranty repairs.

Deep Cycle and Lithium-Ion Battery Warranty

Deep cycle and Lithium-Ion batteries have a specified total number of kilowatt-hours they can deliver during their lifetime. Operating, recharging, and maintenance techniques can extend or reduce total battery life. As the batteries in this product are consumed, the amount of useful work between charging intervals will slowly decrease until the battery is completely worn out. Replacement of worn out batteries, due to normal consumption, is the responsibility of the product owner. Note: (Lithium-Ion battery only): Pro-rated after 2 years. Refer to the battery warranty for additional information.

Lifetime Crankshaft Warranty (ProStripe 02657 Model Only)

The Prostripe which is fitted with a genuine Toro Friction Disc and Crank-Safe Blade Brake Clutch (integrated Blade Brake Clutch (BBC) + Friction Disc assembly) as original equipment and used by the original purchaser in accordance with recommended operating and maintenance procedures, are covered by a Lifetime Warranty against engine crankshaft bending. Machines fitted with friction washers, Blade Brake Clutch (BBC) units and other such devices are not covered by the Lifetime Crankshaft Warranty.

Maintenance is at Owner's Expense

Engine tune-up, lubrication, cleaning and polishing, replacement of filters, coolant, and completing recommended maintenance are some of the normal services Toro products require that are at the owner's expense.

General Conditions

Repair by an Authorized Toro Distributor or Dealer is your sole remedy under this warranty.

Neither The Toro Company nor Toro Warranty Company is liable for indirect, incidental or consequential damages in connection with the use of the Toro Products covered by this warranty, including any cost or expense of providing substitute equipment or service during reasonable periods of malfunction or non-use pending completion of repairs under this warranty. Except for the Emissions warranty referenced below, if applicable, there is no other express warranty. All implied warranties of merchantability and fitness for use are limited to the duration of this express warranty.

Some states do not allow exclusions of incidental or consequential damages, or limitations on how long an implied warranty lasts, so the above exclusions and limitations may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Note Regarding Emissions Warranty

The Emissions Control System on your Product may be covered by a separate warranty meeting requirements established by the U.S. Environmental Protection Agency (EPA) and/or the California Air Resources Board (CARB). The hour limitations set forth above do not apply to the Emissions Control System Warranty. Refer to the Engine Emission Control Warranty Statement supplied with your product or contained in the engine manufacturer's documentation.

Countries Other than the United States or Canada

Customers who have purchased Toro products exported from the United States or Canada should contact their Toro Distributor (Dealer) to obtain guarantee policies for your country, province, or state. If for any reason you are dissatisfied with your Distributor's service or have difficulty obtaining guarantee information, contact your Authorized Toro Service Center.