



Vibratory Plow
Sitework Systems Attachment
Model No. 22437—990001 & Up

PROTOTYPE

Operator's Manual



Contents

	Page
Introduction	2
Safety	2
Vibration Level	3
Safety Decals	3
Specifications	4
Stability Ratings	4
Installation	5
Loose Parts	5
Installing the Plow on the Traction Unit	5
Assembling the Plow	5
Removing the Plow from the Traction Unit	5
Operation	6
Plowing	6
Transporting the Plow	7
Gaging Plow Depth	8
Tips for Plowing	8
Maintenance	9
Service Interval Chart	9
Greasing	9
Lubrication	10
Storage	11
Troubleshooting	11

Introduction

We want you to be completely satisfied with your new product, so feel free to contact your local Authorized Service Dealer for help with service, genuine replacement parts, or other information you may require.

Whenever you contact your Authorized Service Dealer or the factory, always know the model and serial numbers of your product. These numbers will help the Service Dealer or Service Representative provide exact information about your specific product. You will find the model and serial number on a plate located on the attachment receiver plate.

For your convenience, write the product model and serial numbers in the space below.

Model No:	_____
Serial No.	_____

The warning system in this manual identifies potential hazards and has special safety messages that help you and others avoid personal injury, even death. DANGER, WARNING and CAUTION are signal words used to identify the level of hazard. However, regardless of the hazard, be extremely careful.

DANGER signals an extreme hazard that will cause serious injury or death if the recommended precautions are not followed.

WARNING signals a hazard that may cause serious injury or death if the recommended precautions are not followed.

CAUTION signals a hazard that may cause minor or moderate injury if the recommended precautions are not followed.

Two other words are also used to highlight information. “Important” calls attention to special mechanical information and “Note” emphasizes general information worthy of special attention.

The left and right side of the machine is determined by standing in the normal operator’s position.

Safety

Improper use or maintenance by the operator or owner can result in injury. To reduce the potential for injury, comply with the safety instructions in the traction unit operator’s manual and always pay attention to the safety alert symbol, which means CAUTION, WARNING, or DANGER—“personal safety instruction.” Failure to comply with the instruction may result in personal injury or death.

! DANGER !

POTENTIAL HAZARD

- There may be buried power, gas, and/or telephone lines in the area being plowed.

WHAT CAN HAPPEN

- Shock or explosion may occur.

HOW TO AVOID THE HAZARD

- Have the property or area to be plowed marked for buried lines and do not plow in marked areas.

! DANGER !

POTENTIAL HAZARD

- Contact with moving plow may cause injury.

WHAT CAN HAPPEN

- The moving plow can cut hands, feet, or other body parts.

HOW TO AVOID THE HAZARD

- Keep your hands, feet, and any other part of your body or clothing away from moving parts.
- Before adjusting, cleaning, repairing, and inspecting the plow, lower it to the ground, stop the engine, remove the key, and wait for all moving parts to stop.

! WARNING !

POTENTIAL HAZARD

- When the engine is off, attachments in the raised position can gradually lower.

WHAT CAN HAPPEN

- Someone nearby may be pinned or injured by the attachment as it lowers.

HOW TO AVOID THE HAZARD

- Always lower the attachment lift each time you shut off the traction unit.

! WARNING !

POTENTIAL HAZARD

- When the plow is out of the ground, bystanders could be injured by the swinging plow.
- The traction unit could be overturned by the inertia of the swinging plow.

WHAT CAN HAPPEN

- You or bystanders could be crushed by the traction unit or plow.

HOW TO AVOID THE HAZARD

- Keep the plow low at all times.
- Use caution when turning and do not turn quickly.
- Keep all bystanders at least 6 ft. (2 meters) away while operating.

Vibration Level

This unit has a maximum hand-arm vibration level of 7 m/s² and whole body vibration level of 0.2 m/s² based on measurements of identical machines per EN 1033 and EN 1032.

Safety Decals




Figure 1

- | | |
|----------------------------------|---|
| 1. Explosion hazard | 4. Pinching/crushing hazard—foot |
| 2. Shock hazard | 5. Do not dig-in areas with underground utility lines |
| 3. Pinching/crushing hazard—hand | 6. Keep bystanders away |

Specifications

Note: Specifications and design are subject to change without notice.

Width	29 inches (73.6 cm)
Length	35 inches (89 cm)
Height	24 inches (60 cm)
Weight (without blade)	400 lbs (181.5 Kg)
Hydraulic motor displacement	1.27 in ³ /rev (20.8 cc)
Plow cycles	1,528 VPM

⚠
WARNING
⚠

POTENTIAL HAZARD

- Exceeding the maximum recommended slope can cause the traction unit to tip.

WHAT CAN HAPPEN




- If the traction unit tips, you or bystanders could be crushed.

HOW TO AVOID THE HAZARD

- Do not drive the traction unit on a slope steeper than the maximum recommended slope, as determined in the previous table and the traction unit operator's manual.

Stability Ratings

To determine the maximum degree of slope you can traverse with the plow installed on a traction unit, find the stability rating for the hill orientation you want to travel in the table below, then find the degree of slope for the same rating and orientation in the Stability Data section of the traction unit operator's manual.

Orientation	Stability Rating
Front Uphill 	C
Rear Uphill 	D
Side Uphill 	C

PROTOTYPE

IMPORTANT: If your traction unit has a rear operator's platform, the counterweight must be used on the platform while using the plow, or the traction unit will become unstable.

Installation

Loose Parts

DESCRIPTION	QTY.	USE
Vibratory plow	1	Assemble the plow
Blade	1	
Coulter	1	

Installing the Plow on the Traction Unit

Refer to your traction unit operator's manual for complete instructions on installing attachments onto the traction unit and connecting hydraulic hoses.




Figure 3

1. Couler pin screw

Assembling the Plow

Installing the Blade

1. Raise the plow about 36 in. (1 m) off of the ground and install the cylinder locks.
2. Stop the engine and remove the key.
3. Remove the two click pins from the clevis pins in the blade bracket, then remove the clevis pins (Fig. 2).
4. Slide the blade into the blade bracket and secure it at the desired depth (a change in mounting holes will change the depth by 3 in. (7.6 cm)), using the clevis pins and click pins removed previously (Fig. 2).




Figure 2

1. Click pin
2. Clevis pin
3. Blade

Installing the Coulter

1. Back out the couler pin screw about 0.5 in. (1.3 cm), then strike it several times with a hammer to loosen the pin (Fig. 3).

2. Completely remove the couler pin screw, washer, and couler pin (Fig. 4).
3. Put the couler into the couler bracket (Fig. 4).
4. Slide the couler pin through the bracket and couler and secure it with the couler pin screw and washer (Fig. 4).




Figure 4

1. Couler pin
 2. Couler
 3. Couler bracket
 4. Washer
 5. Couler pin screw
5. Torque the screw to 45 ft. lbs (61 N·m).

Removing the Plow from the Traction Unit

Refer to your traction unit operator's manual for complete instructions on removing attachments from the traction unit and disconnecting hydraulic hoses.

1. With the plow raised above the ground, stop the engine.

- Remove the lower click pin and clevis pin securing the blade to the plow (to completely remove the blade, remove both the upper and lower click and clevis pins) (Fig. 2).
- Swing the blade up and secure it as illustrated in Figure 5.

! **CAUTION** !

POTENTIAL HAZARD

- When you swing the blade up, you could drop it.

WHAT CAN HAPPEN

- The blade could swing down a severely injure you.

HOW TO AVOID THE HAZARD

- Always hold the blade securely when moving it and wear work boots.

- Tilt the plow forward and lower it to the ground or trailer, with the stand and coulter supporting the weight of the plow (Fig. 5).




Figure 5

- Stand
- Coulter

- Stop the engine and remove the plow as directed in your traction unit operator's manual.

Operation

Note: Always use the traction unit to lift and move the attachment.

Plowing

- Move the lynch pins to the outside holes on the spring rods to allow the plow to move from side to side (Fig. 6).




Figure 6

- Outer hole
- Lynch pin (in inner hole)
- Spring rod

! **CAUTION** !

POTENTIAL HAZARD

- When you remove the lynch pin, the plow is free to swing.

WHAT CAN HAPPEN

- The plow could swing into you or a bystander, or cause the traction unit to become unstable.

HOW TO AVOID THE HAZARD

- Hold the plow in the neutral position when moving the lynch pins.

- Thread the tapered end of the tubing bullet into the end of the tubing to be installed, ensuring that you achieve a tight bond (Fig. 7).






Figure 7

- Tubing bullet
- Tubing

 **WARNING** 

POTENTIAL HAZARD

- The threads on the bullet are sharp.
- If you are using a basket grip, the wires could be frayed.

WHAT CAN HAPPEN

- The threads could cut you or others.
- The wires on a basket grip can cause puncture wounds.

HOW TO AVOID THE HAZARD

- Keep away from the threads, holding the bullet only by the faceted end above the threads.
- Replace a frayed basket grip.
- Wear leather gloves when handling either the bullet or a basket grip.

3. If your traction unit has a speed selector, move it to the slow (turtle) position.
4. Start the engine.
5. Tilt the attachment plate completely back so that the top of the plow is parallel to the ground (Fig. 9)
6. Lower the plow so that it is resting on the ground.



IMPORTANT: Always ensure that the plow is on or in the ground before engaging the auxiliary hydraulics lever. Failure to do so will cause excessive vibration of the traction unit, possibly resulting in damage.

Note: If you dig a hole to lower the blade into before starting, it will reduce the risk of bending the blade.

7. Pull the auxiliary hydraulics lever to the operator grip to engage the plow.
8. Slowly lower the plow into the ground to the desired depth, while moving the traction unit backward.

IMPORTANT: If you need to raise the bullet out of the ground during operation, release the auxiliary hydraulics lever to stop the plow before breaking through the surface. If you will continue plowing after breaking the surface, retighten the bullet into the tubing.

9. When finished, release the auxiliary hydraulics lever to stop the plow.

 **CAUTION** 

POTENTIAL HAZARD

- When plowing on a hill, the plow can swing down hill when raised out of the soil.

WHAT CAN HAPPEN

- Due to the weight of the plow, if it swings too fast, the force could tip the traction unit injuring you or others.



HOW TO AVOID THE HAZARD

- When plowing on a hill, raise the plow out of the ground slowly, letting it swing while the bullet is still in the soil.

10. Raise the plow out of the ground far enough to pull the bullet out of the soil.
11. Move the traction unit rearward to pull out a working length of pipe, then move forward slightly to create some slack in the line.
12. Stop the engine.
13. Remove the tubing from the tubing bullet.

Transporting the Plow

1. Move the lynch pins to the inside holes on the spring rods to prevent side to side movement (Fig. 6).

 **CAUTION** 

POTENTIAL HAZARD

- Failure to secure the plow will allow it to swing side to side and unbalance the plow.

WHAT CAN HAPPEN

- Due to the weight of the plow, if it swings too fast, the force could tip the traction unit injuring you or others.

HOW TO AVOID THE HAZARD

- Always secure the plow with the lynch pins in the inner holes of the spring rods before transporting the plow.

2. Raise the loader arms just enough to ensure that the blade clears the ground.

IMPORTANT: Never transport the plow with the arms fully raised.

Gaging Plow Depth

Normally, you will be plowing at the maximum depth set by the blade; however, the plow is also equipped with a gage to allow you to lift the plow and determine how high above maximum depth you are plowing.

The gage is located on the left side of the plow facing the traction unit. A rod assembly runs from the gage to the ground. When the plow is lifted, the indicator on the gage moves down. Marks on the gage show the number of inches lower or higher than the maximum depth that you are plowing. The gage reads from +2 to -3 inches (+5 to -7.6 cm), with zero being the maximum depth on bare ground and -3 being 3 inches (7.6 cm) above maximum depth. Figures 8 and 9 illustrate the gage.




Figure 8

- 1. Depth gage
- 2. Gage locking lever




Figure 9

- 1. Gage rod assembly
- 2. Parallel to the ground

When plowing bare ground, maximum depth is indicated on the gage as the zero mark. You can plow down to the +1 mark, but in this case you will be contacting the ground with the coulters axle. Plowing any lower may damage the coulters.

When plowing grass covered ground, the gage will read about an inch lower than the actual depth because of the grass. In this case, lower the plow to the desired coulters depth and note the reading on the gage.

If you are transporting the plow or are plowing extremely rough terrain, you can lock the gage at the +2 position to keep it from being damaged. To lock the gage, manually raise it to the +2 position and move the locking lever to the left.

Tips for Plowing

- When plowing long runs it is advisable to install two hairpin cotters through the spring and quick attach pins on the mount plate (Fig. 10). This will ensure that the vibration of the plow will not cause the pins to come loose.

Note: If your quick attach pins do not have holes in them for the hairpin cotters, contact your dealer to obtain new quick attach pins.




Figure 10

- 1. Hairpin cotters

- To reduce wear on the traction unit drive chain (if your model has one), tighten the chain so there is only 2 in. (5 cm) of slack on the upper span (refer to your traction unit Operator's Manual for instructions).
- Clean the area of trash, branches and rocks before plowing to prevent equipment damage.
- Always begin plowing with the slowest ground speed possible. Increase speed if conditions permit.
- Always use full throttle (maximum engine speed) when plowing.
- Always plow backwards (i.e., in reverse).
- If your traction unit has a speed selector and a flow divider, move the speed selector to slow (turtle) and the flow divider to the 10 o'clock position.

- Avoid sharp turns when plowing to increase productivity and minimize ground disturbance.
- If your traction unit has tires and you have the agricultural or Sitework Systems tires installed on the traction unit, remove the tires and move the right side

tires to the left and the left side tires to the right. This will ensure that the tire tread points to the rear to give you the most traction when using the vibratory plow.

Maintenance

Service Interval Chart

Service Operation	Each Use	5 Hours	25 Hours	200 Hours	Storage Service	Notes
Grease pivot pin fittings		X			X	
Gear lube oil—check level			X			
Gear lube oil—change				X		
Chipped surfaces—paint					X	

! **CAUTION** !

POTENTIAL HAZARD

- If you leave the key in the ignition switch, someone could start the engine.

WHAT CAN HAPPEN

- Accidental starting of the engine could seriously injure you or other bystanders.

HOW TO AVOID THE HAZARD

- Remove the key from the ignition switch before you do any maintenance.


Greasing

Service Interval/Specification

Grease 6 fittings, as shown in Figures 11 through 14, every 8 operating hours. Grease all fittings immediately after every washing.

Grease Type: General-purpose grease.

Fitting Locations



m-4146

Figure 11




Figure 12

m-4148




Figure 13

m-4150




Figure 14

m-4151

How to Grease

1. Lower the plow/loader arms, stop the engine, and remove the key.
2. Clean the grease fittings with a rag.
3. Connect a grease gun to the fittings.
4. Pump grease into the fittings until grease begins to ooze out of the bearings.
5. Wipe up any excess grease.

Lubrication

Service Interval/Specification

Check the gear lubrication oil level in the gear case every 25 operating hours and change it every 200 operating hours or once a year, whichever occurs first.

Gear lube type: SAE 90–140 API service GL–4 or GL–5

Refill capacity: 3 pints.

Checking Gear Lube

1. Position the traction unit and plow on a level surface and lower the attachment lift so that the plow is on the ground.
2. Stop the engine and remove the key.
3. Check the clear glass gage on the side of the gear case (Fig. 15). The gear lube should be at the level of the red dot in the center of the gage.
4. If the gear lube level is low, remove the fill plug (Fig. 15) and fill the case with gear lube until it is level with the red dot in the gage.




Figure 15

m-4147

1. Glass gage
2. Drain plug
3. Fill plug

5. Replace the fill plug.

Changing Gear Lube

1. Position the traction unit and plow on a level surface and lower the attachment lift so that the plow is on the ground.
2. Stop the engine and remove the key.
3. Prepare an appropriate container to catch the used oil under the plow.
4. Remove the drain plug (Fig. 15), allowing the oil to spill out into the container.

5. When finished, replace the drain plug, ensuring that it is tight.
6. Remove the fill plug (Fig. 15) and fill the case with gear lube until it is level with the red dot in the gage.
7. Replace the fill plug.

Storage

1. Before long term storage, wash the attachment with mild detergent and water to remove dirt and grime.
2. Grease the plow.

3. Check gear case lubrication.
4. Check and tighten all bolts, nuts, and screws. Repair or replace any part that is damaged or worn.
5. Ensure that all hydraulic couplers are connected together to prevent contamination of the hydraulic system.
6. Paint all scratched or bare metal surfaces. Paint is available from your Authorized Service Dealer.
7. Store the attachment in a clean, dry garage or storage area. Cover it to protect it and keep it clean.

Troubleshooting

PROBLEM	POSSIBLE CAUSES	CORRECTIVE ACTION
The plow does not operate.	<ol style="list-style-type: none"> 1. Hydraulic coupler not completely connected 2. Defective hydraulic coupler 3. An obstruction in a hydraulic hose 4. Auxiliary valve on the traction unit is not opening. 	<ol style="list-style-type: none"> 1. Check and tighten all couplers. 2. Check couplers and replace any that are defective. 3. Find and remove the obstruction. 4. Repair the valve.

PROTOTYPE



PROTOTYPE