



520Lxi Garden Tractor

Model No. 73580-200000001 & Up

Setup
Instructions

Loose Parts

Note: Use the chart below to identify parts for assembly.

DESCRIPTION	QTY.	USE
Rear Wheel	2	
Wheel Bolt	10	Installing the rear wheels
R.H. Wheel Spindle	1	
L.H. Wheel Spindle	1	
Unplated Thrust Washer - 1.56" O.D x .06" Thick	2	
Plated Wheel Washer - 1.50" O.D x .05" Thick	4	
Bolt - 5/16"-18 x 2.25" Long	2	
Hex Nut - 5/16"-18	2	Installing the front wheels
Spindle Cap	2	
Front Wheel	2	
Hubcap Washer - 2.50" O.D x .05" Thick	2	
Cotter Pin - .156" x 1.50" Long	2	
Shim Washer - 1.50" O.D x .015" Thick	2	
Hubcap	2	
Steering Wheel	1	
Boot Washer	1	
Nut	1	Installing the steering wheel
Lock Washer	1	
Trim Cover	1	
Seat Assembly	1	
Shoulder Bolt - 5/16"	2	Installing the seat
Locknut - 5/16"	2	

DESCRIPTION	QTY.	USE
Bolt - 1/4"-20 x .88" Long	2	
Washer - 1/4"	2	Attaching the battery cables
Hex Nut - 1/4"-20	2	
Grill Screw - #8 x .50" Long	2	
Grill Washer - .75" O.D.	2	Securing the grill
Hitch Pin	1	
Hairpin Cotter	1	Installing the drawbar hitch pin
Flat Washer - .50" I.D.	1	
Key	2	Use in ignition and "Key Choice" switches
Operator's Manual	1	
Engine Operator's Manual	1	Read before operating the tractor

Installing the Rear Wheels

1. Remove the four wheel bolts holding the rear shipping brackets to the rear hubs.
2. Using a jack or suitable hoist, raise the rear of the tractor only high enough to install the rear wheels.
3. Install the wheels onto the hubs with the valve stems facing inward (Fig. 1).
4. Tighten the wheel bolts to 75-80 ft-lb (105-112 N·m).




Figure 1

1. Hub
2. Rear wheel
3. Wheel bolt (5)

m-1278

Installing the Front Wheels

IMPORTANT: Never raise the front of the tractor by placing a jack under the bumper or front axle because the tractor may be damaged.

1. The front hood support braces have two slots (Fig. 2) that may be used to lift the tractor to install the front wheel spindles. To access these slots, remove the front grill and raise the hood.




Figure 2

1. Slots
2. Grill Grommets

m-3454

Note: Remove, or be careful not to damage, the two upper grill grommets (Fig. 2).

- Using a suitable hoist, raise the front of the tractor only high enough to install the front wheel spindles.

IMPORTANT: Do not pivot the weight of the tractor onto the rear drawbar hitch because the hitch will be damaged.

- Install a 1.56" O.D. x .06" thick unplated thrust washer onto the splined shaft of the R.H. wheel spindle (Fig. 4).
- Install the splined end of the R.H. spindle through the R.H. end of the front axle and into the steering arm (Fig. 4).

Note: The L.H. and R.H. spindles are different. Assemble the spindles as shown in figure 3.

Note: The outside edge of the spindle must be parallel to the end of the steering arm (Fig. 3).




Figure 3

- R.H. Spindle
- L.H. Spindle
- Steering arm
- Parallel relationship

- Secure the spindle shaft to the steering arm with a 5/16"-18 x 2.25" bolt and 5/16" nut (Fig. 4). Torque the nut to 230 \pm 25 in-lbs.
- Insert a 1.50" O.D x .05" thick plated wheel washer onto the R.H. spindle (Fig. 4).

- Install a front wheel onto the R.H. spindle with the valve stem facing inward (Fig 4).
- Insert another 1.50" O.D x .05" thick plated wheel washer onto the R.H. spindle (Fig. 4).
- Install a 2.50" O.D x .05" thick hub cap washer onto the spindle. Now insert a .156 x 1.50" long cotter pin into the hole in the spindle (Fig. 4).
- Check the front wheel end play. Install shim washers inside the hubcap washer as necessary so there is minimum end play.




Figure 4

1. Wheel spindle	8. Plated wheel washer 1.50" O.D. x .05" thick
2. Unplated thrust washer 1.56" x .06" thick	9. Hub cap washer 2.50" O.D. x .05" thick
3. Front axle	10. Shim washer 1.50" O.D. x .015" thick
4. Steering arm	11. Cotter pin .056" x 1.50"
5. Bolt 5/16"-18 x 2.25"	12. Hubcap
6. Nut 5/16"	
7. Spindle cap	

- Secure the wheel to the spindle with a cotter pin. Bend the ends of the cotter pin completely around the spindle.
- Install a hubcap onto the hubcap washer until it snaps in place (Fig. 4).

13. Look at the end of the steering arm and the inside edge of the tire. The end of the steering arm and the inside edge of the tire must be parallel (Fig. 5). Adjust the steering arm if required.




Figure 5

1. Wheel
2. Steering arm
3. Parallel relationship

14. Insert a spindle cap into the steering arm (Fig. 4).

15. Repeat the procedure on the opposite end of the front axle.

16. Lubricate both spindles and the front axle pivot until grease begins to come out of the bearings.

17. After servicing the battery, replace the front grill of the tractor and secure the grill with two #8 x .50" long grill screws and .75" O.D. grill washers in the upper two grill mounting holes (Fig. 6).





Figure 6

1. Grill screw (1 of 2)
2. Grill washer (1 of 2)

Installing the Seat

1. Mount the seat to the seat base using two 5/16" shoulder bolts and lock nuts (Fig. 7).
2. Insert the seat switch wire through the center opening in the seat base (Fig 7).
3. Push the seat switch wire connector into the wire harness connector.



m-3453


Figure 7

1. Seat	5. Seat switch wire connector
2. Seat base	6. Opening for seat switch wire
3. 5/16" shoulder bolt (2)	
4. 5/16" Locknut (4)	

3. Install the steering wheel onto the shaft, carefully aligning the splines (Fig. 8).

Note: There is no fixed straight ahead position on power steering models.

4. Secure the steering wheel to the shaft with a lock washer and nut (Fig. 8). Tighten the retaining nut to 45-50 ft-lbs.
5. Install the trim cover on the steering wheel.



m-2482

Figure 8

1. Boot washer	4. Lock washer
2. Steering shaft	5. Nut
3. Steering wheel	6. Trim cover

Installing the Steering Wheel

1. Install the boot washer onto the steering shaft (Fig. 8).
2. Remove the plastic trim cover from the steering wheel (Fig. 8)

Checking Front Wheel Toe-In

With the tractor on a level surface, check to make sure the front wheel toe-in is between 1/8" and 1/4". For instructions on adjusting toe-in, refer to the Maintenance section in Operator's Manual.

Ensuring that the Steering Linkage is Centered

1. With the tractor on a level surface, turn the steering wheel fully to the left and check the clearance of the left hand spindle stop to the stop on the front axle. There should be a slight clearance between the stops (Fig. 9).




Figure 9

1. Left hand spindle stop 3. Clearance
2. Axle stop

2. Repeat for the right front tire in a right turn.
3. If the stops on one side hit, and on the other side have clearance, shorten the tie rod on the side that hits, and equally lengthen the tie rod on the opposite side until both sides have clearance. Recheck the toe in.

Checking Tire Pressure

Check front and rear tire pressure. The correct front and rear tire pressure is 20 psi (138 kPa).

Activating the Battery

DANGER

POTENTIAL HAZARD

- Battery electrolyte contains sulfuric acid which is a deadly poison and it causes severe burns.

WHAT CAN HAPPEN

- If you carelessly drink electrolyte you could die or if it gets onto your skin you will be burned.


HOW TO AVOID THE HAZARD

- Do not drink electrolyte and avoid contact with skin, eyes or clothing. Wear safety glasses to shield your eyes and rubber gloves to protect your hands.
- Fill the battery where clean water is always available for flushing the skin.
- Follow all instructions and comply with all safety messages on the electrolyte container.

1. Remove the battery from the tractor (refer to Removing the Battery in your tractor Operator's Manual).

Note: Never fill the battery electrolyte with the battery installed in the tractor.


2. Remove the filler caps from the battery. Slowly pour electrolyte into each cell until the electrolyte level is up to the lower part of the tube (Fig. 10). Use an electrolyte with a specific gravity of 1.265.



1262

Figure 10

1. Filler caps
2. Electrolyte
3. Lower part of tube



1254

Figure 11

1. Positive battery post
2. Negative battery post
3. Red (+) charger lead
4. Black (-) charger lead

POTENTIAL HAZARD

- Charging battery produces gasses.

WHAT CAN HAPPEN

- Battery gasses can explode.

HOW TO AVOID THE HAZARD

- Keep cigarettes, sparks and flames away from battery.


3. Leave the filler caps off and connect a 3-4 amp battery charger to the battery posts (Fig. 11). Charge the battery at a rate of 4 amperes or less for 4 hours (12 volts).
4. When the battery is fully charged, unplug the charger from electrical outlet, then disconnect the charger leads from the battery posts (Fig. 11).

5. Slowly pour electrolyte into each cell until the level is once again up to "UPPER" line on the battery case (Fig. 10), then install the filler caps.
6. Install the battery in the tractor and connect the battery cables (refer to Installing the Battery in your tractor Operator's Manual).

Note: Do not run the tractor with the battery disconnected.

Installing the Drawbar Hitch Pin

Insert the drawbar hitch pin into the drawbar hitch and secure it with a .50" I.D. flat washer and hairpin cotter (Fig. 12).



m-2481

Figure 12

1. Drawbar hitch pin	3. .50" Flat washer
2. Drawbar hitch	4. Hairpin cotter

Checking the Wiring and Fasteners

- Inspect the tractor for any loose electrical connections and secure them as required. Check the wire routing to make sure moving parts do not interfere with wires and cause a short.
- Assure all fasteners are tight.

Burnishing the Clutch

The following break-in procedure must be performed as part of pre-delivery service or when a new clutch is installed.

Note: There must be a PTO driven attachment installed to provide a load in order to burnish the clutch facings properly.

1. Run the engine at full throttle and engage the clutch bringing the load to full speed. Then disengage the clutch.
2. Let the load come to a full stop, then engage again.

3. Repeat these procedures (1 and 2) 5 times.

Test Driving the Tractor

1. Check the oil level in the crankcase (refer to Engine Oil in your tractor Operator's Manual for oil type, viscosity and crankcase capacity).
2. Check the oil level in the transaxle (refer to Transaxle Fluid in your tractor Operator's Manual for oil type, viscosity and capacity).
3. Check the coolant level in the coolant recovery tank.
4. Check to make sure all lubrication points have been greased as shown in the Maintenance section of tractor Operator's Manual.
5. Fill the tank with unleaded regular gasoline with an octane rating of at least 85. Open the fuel shutoff valve and check the fuel hose and fittings for leaks.
6. As applicable, check and test the operation of the following:
 - Engine, choke and throttle controls
 - Gauges
 - Headlights and taillights
 - Indicator lights
 - PTO clutch and brake
 - Lift system
 - Service and parking brakes
 - Transmission controls
 - Steering
 - Tractor operation in forward and reverse
7. Test the operation of the safety interlock system (refer to the tractor Operator's Manual for the correct procedure).