




Count on it.

Operator's Manual

Greensmaster® Flex™ 2120 Traction Unit

Model No. 04044—Serial No. 405500001 and Up

Model No. 04045—Serial No. 405500001 and Up



G032415



This product complies with all relevant European directives; for details, please see the separate product specific Declaration of Conformity (DOC) sheet.

It is a violation of California Public Resource Code Section 4442 or 4443 to use or operate the engine on any forest-covered, brush-covered, or grass-covered land unless the engine is equipped with a spark arrester, as defined in Section 4442, maintained in effective working order, or the engine is constructed, equipped, and maintained for the prevention of fire.

The enclosed engine owner's manual is supplied for information regarding the US Environmental Protection Agency (EPA) and the California Emission Control Regulation of emission systems, maintenance, and warranty. Replacements may be ordered through the engine manufacturer.

Operating this machine between 1,500 and 2,400 m (5,000 to 8,000 ft) above sea level requires the high-altitude kit. See your authorized Toro distributor.

⚠ WARNING

**CALIFORNIA
Proposition 65 Warning**

The engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.

Use of this product may cause exposure to chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.

Introduction

This machine is a walk-behind, reel-blade lawn mower intended to be used by professional, hired operators in commercial applications. It is primarily designed for cutting grass on well-maintained turf. Using this product for purposes other than its intended use could prove dangerous to you and bystanders

Read this information carefully to learn how to operate and maintain your product properly and to avoid injury and product damage. You are responsible for operating the product properly and safely.

Visit www.Toro.com for product safety and operation training materials, accessory information, help finding a dealer, or to register your product.

Whenever you need service, genuine Toro parts, or additional information, contact an authorized Toro distributor and have the model and serial numbers of your product ready. The model and serial numbers are located on a plate on the rear frame. Write the numbers in the space provided.

Important: With your mobile device, you can scan the QR code (if equipped) on the serial number decal to access warranty, parts, and other product information.




Figure 1

1. Model and serial number location

Model No. _____

Serial No. _____

This manual identifies potential hazards and has safety messages identified by the safety-alert symbol (Figure 2), which signals a hazard that may cause serious injury or death if you do not follow the recommended precautions.



Figure 2
Safety-alert symbol

This manual uses 2 words to highlight information. **Important** calls attention to special mechanical information and **Note** emphasizes general information worthy of special attention.

Contents

Safety	4	Servicing the Traction-Interlock Switch	32
General Safety	4	Servicing the Brake-Interlock Switch.....	32
Safety and Instructional Decals	4	Brake Maintenance	33
Setup	7	Adjusting the Service/Parking Brake	33
1 Preparing the Traction Unit	8	Belt Maintenance	33
2 Installing the Cutting Unit to the Traction Unit	8	Inspecting the Reel-Drive Belt.....	33
3 Installing the Handle Retainers	9	Visually Inspecting the Reel Clutch	34
4 Installing the Transport Wheels	9	Engaging/Disengaging the Transmission-Belt Tensioner.....	34
5 Checking the Engine-Oil Level.....	10	Controls System Maintenance	35
6 Installing the Production-Year Decal.....	10	Adding Fluid to the Clutch Assembly	35
7 Installing the Grass Basket.....	11	Adjusting the Traction Control	35
8 Breaking in the Machine.....	11	Adjusting the Reel Control	36
Product Overview	12	Storage	36
Controls	12	Storage Safety.....	36
Specifications	16	Storing the Machine.....	36
Attachments/Accessories	16		
Before Operation	17		
Before Operation Safety	17		
Performing Daily Maintenance.....	17		
Checking the Engine-Oil Level.....	17		
Fuel Specifications	17		
Filling the Fuel Tank.....	18		
Setting the Machine to Match Turf Conditions.....	19		
Adjusting the Handle Height	20		
Adjusting the Handle Angle.....	20		
Adjusting the Throttle Control	20		
Checking the Operation of the Interlock Switches	21		
Transporting the Machine to a Job Site.....	22		
During Operation	22		
During Operation Safety	22		
Starting the Engine	23		
Shutting Off the Engine.....	24		
Releasing the Transmission.....	24		
Operating Tips	24		
After Operation	25		
After Operation Safety	25		
Transporting the Machine	25		
Maintenance	26		
Maintenance Safety.....	26		
Recommended Maintenance Schedule(s)	27		
Daily Maintenance Checklist.....	28		
Engine Maintenance	29		
Engine Safety	29		
Servicing the Engine Oil.....	29		
Servicing the Air Cleaner	30		
Servicing the Spark Plug.....	31		
Fuel System Maintenance	31		
Cleaning the Fuel-Tank Screen.....	31		
Replacing the Fuel Line	31		
Replacing the Breather Hose	31		
Electrical System Maintenance	32		

Safety

This machine has been designed in accordance with EN ISO 5395 and ANSI B71.4-2017 and meets these standards when you add the required decals.

General Safety

This product is capable of amputating hands and feet and of throwing objects.

- Read and understand the contents of this *Operator's Manual* before starting the machine.
- Use your full attention while operating the machine. Do not engage in any activity that causes distractions; otherwise, injury or property damage may occur.
- Do not put your hands or feet near moving components of the machine.


- Do not operate the machine without all guards and other safety protective devices in place and functioning properly on the machine.
- Keep bystanders and children out of the operating area. Never allow children to operate the machine.
- Shut off the engine, remove the key (if equipped), and wait for all movement to stop before you leave the operator's position. Allow the machine to cool before adjusting, servicing, cleaning, or storing it.

Improperly using or maintaining this machine can result in injury. To reduce the potential for injury, comply with these safety instructions and always pay attention to the safety-alert symbol , which means Caution, Warning, or Danger—personal safety instruction. Failure to comply with these instructions may result in personal injury or death.

Safety and Instructional Decals



Safety decals and instructions are easily visible to the operator and are located near any area of potential danger. Replace any decal that is damaged or missing.



115-7271

decal115-7271

- | | |
|----------------------|-------------------------|
| 1. Engage the reel. | 3. Disengage the reel. |
| 2. Engage the lever. | 4. Disengage the lever. |



decal120-2769

120-2769


- | | |
|--|---|
| 1. Toxic gas inhalation hazard—do not operate indoors. | 4. Warning—disconnect the spark plug wire and read the <i>Operator's Manual</i> before servicing or performing maintenance. |
| 2. Explosion hazard—shut off the engine and keep away from open flames when refueling. | 5. Hot surface/burn hazard—do not touch hot surfaces. |
| 3. Warning—shut off the engine and turn off the fuel before leaving the machine. | 6. Warning—read the <i>Operator's Manual</i> ; when adding fuel to the tank, only fill to the bottom of the fill tube. |



decal120-9570

120-9570


1. Warning—stay away from moving parts, keep all guards and shields in place.



120-9571

decal120-9571


1. Lower the lever to disengage the traction.



120-9598

decal120-9598


- | | |
|---|--|
| 1. Brake | 4. Parking brake |
| 2. Release handle to disengage the brake. | 5. Rotate the latch to lock the parking brake; compress the handle to release the latch. |
| 3. Compress the handle to engage the brake. | |



130-8322

decal130-8322

- | | |
|---|---|
| 1. Use only gasoline that contains 10% ethanol by volume (E10) or less. | 3. Do not use gasoline that contains more than 10% ethanol by volume (E10). |
| 2. Read the <i>Operator's Manual</i> . | |



131-3111


decal131-3111

- | | |
|---------|---------|
| 1. Fast | 2. Slow |
|---------|---------|



133-8062

decal133-8062



decal115-7274

115-7274

- | | |
|----------------------|--------------------|
| 1. Lights (optional) | 3. Engine—start |
| 2. Hour meter | 4. Engine—shut off |



decal133-2335

133-2335

- | | | |
|--|---|----------------------------|
| 1. Warning—read the <i>Operator's Manual</i> ; all operators should be trained before operating the machine. | 3. Thrown object hazard—keep bystanders away. | 5. Do not tow the machine. |
| 2. Warning—wear hearing protection. | 4. Warning—stay away from moving parts; keep all guards and shields in place. | |

Setup

Loose Parts

Use the chart below to verify that all parts have been shipped.

Procedure	Description	Qty.	Use
1	No parts required	–	Prepare the traction unit (optional).
2	Bolt (3/8 x 3/4 inch)	2	Install the cutting unit to the traction unit.
3	Handle retainer Hairpin cotter	2 2	Install the handle retainers.
4	Transport wheels—Transport Wheel Kit (Model No. 04123 [Optional])	2	Install the transport wheels.
5	No parts required	–	Check the engine-oil level.
6	Production-year decal	1	Install the production-year decal
7	Grass basket	1	Install the grass basket.
8	No parts required	–	Break in the machine.

Media and Additional Parts

Description	Qty.	Use
Operator's Manual	1	Read or view these materials before operating the machine.
Engine Owner's Manual	1	
Certificate of Compliance	1	

Note: Determine the left and right sides of the machine from the normal operating position.

1

Preparing the Traction Unit

Optional—Cutting Unit Models
04251, 04252, 04253, or 04254

No Parts Required

Procedure

If you are installing cutting unit Model No. 04251, 04252, 04253, or 04254 on this traction unit, complete the following steps:

1. Position the cutting unit on a flat, level surface.
2. On both pitch arms (Figure 3), measure 2.3 mm (0.09 inch) in on the tabs and grind down the corner as shown in Figure 4.




Figure 3

g034505

1. Pitch arms




Figure 4

g034506

3. Paint the bare metal to prevent corrosion.

2

Installing the Cutting Unit to the Traction Unit

Parts needed for this procedure:

2	Bolt (3/8 x 3/4 inch)
---	-----------------------

Procedure

Note: To install the weight rod onto your machine, refer to the installation instructions in your cutting unit *Operator's Manual*.

1. Place the mower on its drums on a level surface.
2. Lower the kickstand and push in the locking pin to lock the kickstand in the SERVICE position (Figure 5). Allow the machine to rest on the locked kickstand.

Note: Place the kickstand in the SERVICE position whenever you remove the cutting unit. This kickstand position keeps the machine from tipping backward onto the handle.




Figure 5

g018142

1. Kickstand—STORAGE position
2. Locking pin
3. Kickstand—SERVICE position

3. Push the cutting unit under the traction unit and to the left to engage the transmission coupling (Figure 6).




Figure 6

1. Transmission coupling

4. Maneuver the machine frame forward until it engages the cutting unit pivot arms [Figure 7](#).




Figure 7

1. Telescoping coupler
2. Cutting-unit hex shaft
3. Bolt

5. Secure the machine frame to the cutting unit pivot arms with the 2 bolts (3/8 x 3/4 inch) ([Figure 7](#)).
6. Move the kickstand to the STORAGE position by releasing the locking pin and allowing the kickstand to rotate up.
7. Set the cutting-unit height of cut; refer to your cutting unit *Operator's Manual*.

3

Installing the Handle Retainers

Parts needed for this procedure:

2	Handle retainer
2	Hairpin cotter

Procedure

1. While supporting the handle, remove the cable ties that secure the handle clamps to the side plates ([Figure 8](#)).




Figure 8

1. Hairpin cotter
2. Handle retainer

2. Pivot the handle to the desired operating position and insert a handle retainer over the handle clamp and into the matching holes in the side plate ([Figure 8](#)).
3. Secure the clamp in position with a hairpin cotter ([Figure 8](#)).
4. Repeat the procedure on the opposite side of the handle.
5. Adjust the handle height to the desired position; refer to [Adjusting the Handle Height \(page 20\)](#).

Note: The machine is shipped with the handle adjusted to the lowest position. The machine is traditionally operated with the handle telescoped out to its maximum height.

4

Installing the Transport Wheels

Optional

Parts needed for this procedure:

2	Transport wheels—Transport Wheel Kit (Model No. 04123 [Optional])
---	---

Procedure

1. Use your foot to push the center of the kickstand down and pull up on the lower handle support until the kickstand has rotated forward and over center ([Figure 9](#)).




Figure 9

1. Kickstand

2. Press the wheel locking clip toward the center of wheel and slide the wheel onto the hex shaft ([Figure 10](#)).




Figure 10

1. Locking clip

3. Rotate the wheel back and forth until it fits onto the axle and the locking clip is secured in the groove on the axle shaft.
4. Repeat the procedure on the opposite side of the machine.
5. Inflate the tires to 83 to 103 kPa (12 to 15 psi).
6. Carefully lower the machine off of the kickstand by pushing forward slowly or by lifting the lower handle support, allowing the kickstand to spring back to the STORAGE position.

5

Checking the Engine-Oil Level

No Parts Required

Procedure

Check the engine-oil level; refer to [Checking the Engine-Oil Level \(page 29\)](#).

6

Installing the Production-Year Decal

CE Machines Only

Parts needed for this procedure:

1	Production-year decal
---	-----------------------

Procedure

If you use this machine in a country that complies to CE standards, apply the production-year decal near the serial plate; refer to [Figure 11](#).




Figure 11

g233866

1. Serial plate
2. Production-year decal

7


Installing the Grass Basket

Parts needed for this procedure:

1	Grass basket
---	--------------

Procedure

1. Grasp the basket by the handle.
2. Guide the basket lip between the cutting unit side plates and over the front roller ([Figure 12](#)).



G032407

g032407


Figure 12

1. Basket hooks

3. Install the basket hooks over the frame loop ([Figure 12](#)).

Important: If you ever drop the basket, examine the pitch-arm contact points near the lower lip of the basket for damage ([Figure 13](#)). Straighten them before using the basket.

Using the basket with bent pitch-arm contact points may cause contact between the basket and cutting unit, causing undesired noise and/or damage to the basket and cutting unit.



G032408

g032408

Figure 13

1. Pitch-arm contact point

8

Breaking in the Machine

No Parts Required

Procedure

Only 8 hours of mowing operation is required for the break-in period.

The first several hours of operation are critical to future dependability of the machine. You must monitor the machine performance closely so that minor difficulties, which could lead to major problems, are noted and can be corrected. During the first few hours of operation, inspect the machine frequently for signs of oil leakage, loose fasteners, or any other malfunction.

Refer to the engine owner's manual for the recommended break-in-period oil change and maintenance procedures.

Product Overview




Figure 14

- | | |
|---|-------------------------|
| 1. Traction and reel-drive engagement lever | 6. Fuel tank |
| 2. Operator-presence control | 7. Grass basket |
| 3. Handle | 8. Cutting unit |
| 4. Service brake | 9. Transport-wheel axle |
| 5. Control panel | |

Controls




Figure 15

- | | |
|-----------------------------------|---|
| 1. Open space for optional lights | 5. Operator-presence control lights |
| 2. Parking-brake latch | 6. On/Off switch |
| 3. Service brake | 7. Throttle control |
| 4. Handle | 8. Traction and reel-drive engagement lever |

Throttle Control

The throttle control (Figure 15 and Figure 16) is located on the right, rear side of the control panel. Rotate the throttle to regulate the engine speed.




Figure 16

1. Full speed
2. Slow speed




Figure 17

1. NEUTRAL
2. Traction—NEUTRAL and reel drive—DISENGAGE
3. Traction—FORWARD (transport)
4. Traction—FORWARD and reel drive—ENGAGE

Traction and Reel-Drive Engagement Lever

The traction and reel-drive engagement lever (Figure 17) is located on the front right side of the control panel.

To transport the machine, the lever has 2 positions: NEUTRAL and FORWARD. Pushing the lever to the traction—FORWARD (transport) position or the traction—FORWARD and reel drive—ENGAGE position engages the traction drive (Figure 17).

Note: To move the lever, you must first engage the operator-presence control.

To operate the reel, the lever has 2 positions: ENGAGE and DISENGAGE. Move the top of the lever to the left, then forward to the traction—FORWARD and reel drive—ENGAGE position to engage the reel and begin mowing. Push the lever to the right to the traction—FORWARD (transport) position to disengage the reel and continue forward motion or pull back on it to the traction—NEUTRAL and reel drive—DISENGAGE position to disengage both the reel and the traction drive (Figure 17).

Note: If you release the operator-presence control, the lever returns to neutral and the machine stops.

Service Brake

The service brake (Figure 18) is located on the left front side of the handle. Pulling back the lever applies the service brake.

You must disengage the brake before you engage the traction drive. If you operate the machine with the brake engaged, the machine moves, but with a high resistance and increased power consumption.




Figure 18

1. Parking-brake latch
2. Service brake

Parking-Brake Latch

Use the parking-brake latch (Figure 18) with the service brake. Rotate the parking-brake latch toward the brake handle to hold the service brake in place. Pull the brake lever to release.

Note: You cannot move the traction-control lever while the latch is engaged.

On/Off Switch

The On/Off switch (Figure 15) is located on the top of the control panel. Move the switch to the ON position to start the engine and the OFF position to shut off the engine.

Operator-Presence Control (OPC)

You must engage the operator-presence control (Figure 15) before you engage the traction lever. If you release the OPC during operation, the traction lever returns to neutral and the engine continues to run.

Choke Lever

The choke lever (Figure 19) is located on the left front of the engine. The lever has 2 positions: RUN and CHOKE. Move the lever to the CHOKE position when starting a cold engine. After the engine starts, move the lever to the RUN position.




Figure 19

1. Choke lever
2. Fuel-shutoff valve

Fuel-Shutoff Valve

The fuel-shutoff valve (Figure 19 and Figure 20) is located on the left front of the engine near the choke lever. The valve has 2 positions: CLOSED and OPEN. Move the lever up to the CLOSED position when you store or transport the machine. Open the valve before you start the engine by rotating the lever down.




Figure 20

1. Fuel-shutoff valve—CLOSED position

Recoil-Starter Handle

Pull the recoil-starter handle (Figure 21) to start the engine.




Figure 21

1. Recoil-starter handle




Figure 22

1. Lower-center handle
2. Kickstand loop

Kickstand

The kickstand (Figure 23) is mounted to the rear of the machine. Use the kickstand when you install or remove the transport wheels or the cutting unit.

- To use the kickstand to install the transport wheels, lower the kickstand to the ground and step down on the loop while pulling up and back on the lower-center handle (Figure 22).

⚠ CAUTION

The machine is heavy and can cause back strain if lifted improperly.

Put your foot pressure down on the kickstand loop and use only the lower-center handle to raise the machine. Attempting to raise the machine onto the kickstand any other way can cause injury.




Figure 23

1. Kickstand
2. Kickstand loop

- To prevent the machine from tipping backward when removing the reel, lower the kickstand and push in the locking pin to lock it in the SERVICE position (Figure 24).




Figure 24

- | | |
|-------------------------------|-------------------------------|
| 1. Kickstand—STORAGE position | 3. Kickstand—SERVICE position |
| 2. Locking pin | |

Specifications

1820 Traction Unit

Width	82.5 cm (32-1/2 inches)
Height	104.8 cm (41-1/4 inches)
Length with basket	152.4 cm (60 inches)
Net Weight (with 11-blade cutting unit and grass basket installed)	117 kg (258 lb)
Width of cut	46 cm (18 inches)
Height of cut	1.5 to 7.5 mm (1/16 to 19/64 inch) with Micro-Cut bedknife
Clip frequency	Adjustable (refer to your cutting unit <i>Operator's Manual</i>)

2120 Traction Unit

Width	90.1 cm (35-1/2 inches)
Height	104.8 cm (41-1/4 inches)
Length with basket	152.4 cm (60 inches)
Net Weight (with 11-blade cutting unit and grass basket installed)	117.9 kg (260 lb)
Width of cut	53.3 cm (21 inches)
Height of cut	1.5 to 7.5 mm (1/16 to 19/64 inch) with Micro-Cut bedknife
Clip frequency	Adjustable (refer to your cutting unit <i>Operator's Manual</i>)

Attachments/Accessories

A selection of Toro approved attachments and accessories is available for use with the machine to enhance and expand its capabilities. Contact your Authorized Service Dealer or authorized Toro distributor or go to www.Toro.com for a list of all approved attachments and accessories.

To ensure optimum performance and continued safety certification of the machine, use only genuine Toro replacement parts and accessories. Replacement parts and accessories made by other manufacturers could be dangerous, and such use could void the product warranty.

Operation

Before Operation

Note: Determine the left and right sides of the machine from the normal operating position.

Before Operation Safety

General Safety

- Never allow children or untrained people to operate or service the machine. Local regulations may restrict the age of the operator. The owner is responsible for training all operators and mechanics.
- Become familiar with the safe operation of the equipment, operator controls, and safety signs.
- Shut off the machine, remove the key (if equipped), and wait for all movement to stop before you leave the operator's position. Allow the machine to cool before adjusting, servicing, cleaning, or storing it.
- Know how to stop the machine and shut off the machine quickly.
- Check that operator-presence controls, safety switches, and safety protective devices are attached and functioning properly. Do not operate the machine unless they are functioning properly.
- Inspect the area where you will use the machine and remove all objects that the machine could throw.

Fuel Safety

- Use extreme care in handling fuel. It is flammable and its vapors are explosive.
- Extinguish all cigarettes, cigars, pipes, and other sources of ignition.
- Use only an approved fuel container.
- Do not remove the fuel cap or add fuel to the tank while the engine is running or hot.
- Do not add or drain fuel in an enclosed space.
- Do not store the machine or fuel container where there is an open flame, spark, or pilot light, such as on a water heater or other appliance.
- If you spill fuel, do not attempt to start the engine; avoid creating a source of ignition until the fuel vapors have dissipated.
- Do not fill containers inside a vehicle or on a truck or trailer bed with a plastic liner. Always place

containers on the ground, away from the vehicle before filling.

- Remove equipment from the truck or trailer and refuel it on the ground. If this is not possible, refuel such equipment with a portable container rather than from a fuel-dispenser nozzle.
- Keep the nozzle in contact with the rim of the fuel tank or container operating at all times until fueling is complete.

Performing Daily Maintenance

Perform the daily maintenance procedures; refer to [Daily Maintenance Checklist \(page 28\)](#).

Checking the Engine-Oil Level

Check the engine-oil level before each use or every 8 operating hours, refer to [Checking the Engine-Oil Level \(page 29\)](#).

Fuel Specifications

Fuel tank capacity: 3.0 L (0.79 US gallons)

Recommended fuel: Unleaded gasoline with an octane rating of 87 or higher ((R+M)/2 rating method)

Ethanol: Gasoline with up to 10% ethanol (gasohol) or 15% MTBE (methyl tertiary butyl ether) by volume is acceptable. Ethanol and MTBE are not the same. Gasoline with 15% ethanol (E15) by volume is not approved for use.

- **Never use gasoline that contains more than 10% ethanol by volume**, such as E15 (contains 15% ethanol), E20 (contains 20% ethanol), or E85 (contains up to 85% ethanol).
- **Do not** use gasoline containing methanol.
- **Do not** store fuel either in the fuel tank or fuel containers over the winter unless a fuel stabilizer is used.
- **Do not** add oil to gasoline.
- For best results, use only clean, fresh (less than 30 days old) fuel.
- Using unapproved gasoline may cause performance problems and/or engine damage, which may not be covered under the warranty

Filling the Fuel Tank

⚠ DANGER

In certain conditions, fuel is extremely flammable and highly explosive. A fire or explosion from fuel can burn you and others and can damage property.

- Fill the fuel tank outdoors, in an open area, when the engine is cold. Wipe up any fuel that spills.
- Never fill the fuel tank inside an enclosed trailer.
- Do not fill the fuel tank completely full. Add fuel to the fuel tank until the level is 6 to 13 mm (1/4 to 1/2 inch) below the bottom of the filler neck. This empty space in the tank allows fuel to expand.
- Never smoke when handling fuel, and stay away from an open flame or where fuel fumes may be ignited by a spark.
- Store fuel in an approved container and keep it out of the reach of children. Never buy more than a 30-day supply of fuel.
- Do not operate without entire exhaust system in place and in proper working condition.

⚠ DANGER

In certain conditions during fueling, static electricity can be released, causing a spark which can ignite the fuel vapors. A fire or explosion from fuel can burn you and others and can damage property.

- Always place fuel containers on the ground away from your vehicle before filling.
- Do not fill fuel containers inside a vehicle or on a truck or trailer bed because interior carpets or plastic truck-bed liners may insulate the container and slow the loss of any static charge.
- When practical, remove equipment from the truck or trailer and fuel it on the ground. If this is not possible, then fuel such equipment with a portable container rather than from a fuel-dispenser nozzle.
- If you must use a fuel-dispenser nozzle, keep the nozzle in contact with the rim of the fuel tank or container opening at all times until fueling is complete.

⚠ WARNING

Fuel is harmful or fatal if swallowed. Long-term exposure to vapors can cause serious injury and illness.

- Avoid prolonged breathing of vapors.
- Keep your face away from the nozzle and fuel tank or conditioner bottle opening.
- Avoid contact with skin; wash off spills with soap and water.

1. Clean around the fuel-tank cap and remove the cap from the tank (Figure 25). Fill the fuel tank no higher than to the bottom of the filter screen.

Important: Do not overfill the tank with fuel.




Figure 25

1. Fuel-tank cap

2. Install the fuel-tank cap and wipe up any spilled fuel.

Setting the Machine to Match Turf Conditions

Use the following table to set the machine to match turf conditions.

Bedbars: Standard and Optional (Flex/eFlex 2120 Machines)			
Part Number	Description	Aggressiveness	Comments
106-2468-01	Non-Aggressive	Less	Red, Standard
99-3794-03	Aggressive	More	Black

Bedbars: Standard and Optional (Flex/eFlex 1820 Machines)			
Part Number	Description	Aggressiveness	Comments
110-2282-01	Non-Aggressive	Less	Red, Standard
110-2281-03	Aggressive	More	Black

Bedknives: Standard and Optional (Flex/eFlex 2120 Machines)			
Part Number	Description	Height-of-cut Range	Comments
115-1880	Microcut-EdgeMax	1.6 to 3.2 mm (0.062 to 0.125 inch)	Standard
93-4262	Microcut	1.6 to 3.2 mm (0.062 to 0.125 inch)	
108-4303	Extended Microcut	1.6 to 3.2 mm (0.062 to 0.125 inch)	Less aggressive
115-1881	Tournament- EdgeMax	3.2 to 6.4 mm (0.125 to 0.25 inch)	
93-4263	Tournament	3.2 to 6.4 mm (0.125 to 0.25 inch)	
108-4302	Extended Tournament	3.2 to 6.4 mm (0.125 to 0.25 inch)	Less aggressive
93-4264	Low Cut	6.4 mm (0.25 inch) and up	

Bedknives: Standard and Optional (Flex/eFlex 1820 Machines)			
Part Number	Description	Height-of-cut Range	Comments
117-1530	Microcut-EdgeMax	1.6 to 3.2 mm (0.062 to 0.125 inch)	Standard
98-7261	Microcut	1.6 to 3.2 mm (0.062 to 0.125 inch)	
110-2300	Extended Microcut	1.6 to 3.2 mm (0.062 to 0.125 inch)	Less aggressive
98-7260	Tournament	3.2 to 6.4 mm (0.125 to 0.25 inch)	
117-1532	Tournament- EdgeMax	3.2 to 6.4 mm (0.125 to 0.25 inch)	
110-2301	Low Cut	6.4 mm (0.25 inch) and up	

Rollers (Flex/eFlex 2120 Machines)			
Part Number	Description	Diameter/Material	Comments
04255	Narrow Wiehle	6.4 cm (2.5 inches)/Aluminum	Narrow spaced grooves
04256	Wide Wiehle	6.4 cm (2.5 inches)/Aluminum	More penetration, wide spaced grooves
04257	Full Roller	6.4 cm (2.5 inches)/Steel	Least penetration
04258	Narrow Wiehle—Long	6.4 cm (2.5 inches)/Aluminum	More edge support; 4.3 cm (1.7 inches) longer
04267	Paspalum	6.4 cm (2.5 inches)/Aluminum	Less penetration, softened narrow spaced grooves
115-7356	Rear Roller	5.1 cm (2.0 inches)/Aluminum	Standard rear
120-9595	Rear Roller	5.1 cm (2.0 inches)/Steel	Steel rear

Rollers (Flex/eFlex 1820 Machines)			
Part Number	Description	Diameter/Material	Comments
120-9607	Narrow Wiehle	6.4 cm (2.5 inches)/Aluminum	Narrow spaced grooves
120-9609	Wide Wiehle	6.4 cm (2.5 inches)/Aluminum	More penetration, wide spaced grooves
120-9611	Full Roller	6.4 cm (2.5 inches)/Steel	Least penetration
121-4681	Narrow Wiehle—Long	6.4 cm (2.5 inches)/Aluminum	More edge support; 4.3 cm (1.7 inches) longer
120-9605	Rear Roller	5.1 cm (2.0 inches)/Aluminum	Standard rear

Adjusting the Handle Height

Note: The machine is shipped with the handle adjusted to the lowest position. The machine is normally operated with the handle telescoped out to its maximum height.

1. Loosen the 3 carriage bolts and nuts securing each side of the handle in the handle clamps (Figure 26).




Figure 26

1. Handle clamp
2. Nut
3. Carriage bolts

2. Pull up on the handle slowly and evenly on each side until it is in the desired operating position.
3. Tighten the carriage bolts and nuts to lock the adjustment.

Adjusting the Handle Angle

1. Remove the hairpin cotters from the handle retainers on each side of the machine (Figure 27).




Figure 27

1. Hairpin cotter
2. Handle retainer

2. While supporting the handle, remove the hairpin cotters from each side and pivot the handle to the desired operating position (Figure 27).
3. Install the handle retainers and hairpin cotters.

Adjusting the Throttle Control

1. Remove the console cover.
2. Loosen the 2 fasteners securing the throttle control (Figure 28).




Figure 28

1. Fasteners
2. Throttle control

3. Adjust the throttle control to the desired position.
4. Tighten the throttle-control fasteners.
5. Install the previously removed console cover.

Checking the Operation of the Interlock Switches

Service Interval: Before each use or daily

⚠ CAUTION

If the safety interlock switches are disconnected or damaged, the machine could operate unexpectedly, causing personal injury.

- Do not tamper with the interlock switches.
- Check the operation of the interlock switches daily and replace any damaged switches before operating the machine.

Checking the Operator-Presence-Control (OPC) Interlock Switch

1. Push the kickstand down with your foot and pull up on the handle support until the kickstand has rotated forward, over center.
2. Start the engine.
3. With the OPC released, attempt to engage the traction lever (Figure 29). The traction lever **should not** engage. If the traction lever engages, the interlock system needs service. Correct the problem before operating the machine; refer to [Servicing the Traction-Interlock Switch \(page 32\)](#).




Figure 29

1. Operator-presence control (OPC)
2. Traction lever
3. Brake lever

4. With the OPC pressed and the traction lever engaged, release the OPC (Figure 29). The

traction lever **should** disengage. If the traction lever does not disengage, the interlock system needs service. Correct the problem before operating the machine; refer to [Servicing the Traction-Interlock Switch \(page 32\)](#).

5. With the OPC pressed and the shift lever moved to the left, engage the traction and reel drive and release the OPC (Figure 29). The traction lever **should** disengage. If the traction lever does not disengage, the interlock system needs service. Correct the problem before operating the machine; refer to [Servicing the Traction-Interlock Switch \(page 32\)](#) or [Servicing the Traction-Interlock Switch \(page 32\)](#).
6. With the OPC pressed and the shift lever moved to the left to engage the traction and reel drive, move the shift lever to the right to disengage the reel drive (Figure 29). The reel drive **should** disengage. If the reel drive does not disengage, the interlock system needs service. Correct the problem before operating the machine; refer to [Servicing the Traction-Interlock Switch \(page 32\)](#).
7. Carefully lower the machine off the kickstand.

Checking the Traction-Interlock Switch

1. Push the kickstand down with your foot and pull up on the handle support until the kickstand has rotated forward, over center.
2. With the OPC pressed, the traction lever engaged, and the engine controls in the starting position (Figure 29), attempt to start the engine. The engine **should not** start. If the engine starts, the interlock switch needs service. Correct the problem before operating the machine; refer to [Servicing the Traction-Interlock Switch \(page 32\)](#).
3. Carefully lower the machine off the kickstand.

Checking the Brake-Interlock Switch

1. Push the kickstand down with your foot and pull up on the handle support until the kickstand has rotated forward, over center.
2. With the traction lever disengaged, the service brake engaged, and the engine controls in the starting position (Figure 29), attempt to start the engine. The engine **should** start. If the engine does not start, the interlock switch needs service. Correct the problem before operating the machine; refer to [Servicing the Brake-Interlock Switch \(page 32\)](#).

3. With the engine running, engage the service brake (not the parking-brake latch), press the OPC, and engage the traction lever (Figure 29). The engine should labor to overcome the brake but should not shut off. If the engine shuts off immediately, the interlock switch needs service. Correct the problem before operating the machine; refer to [Servicing the Brake-Interlock Switch \(page 32\)](#).
4. With the engine running, engage the parking-brake latch, press the OPC, and engage the traction lever (Figure 29). The engine **should** shut off. If the engine does not shut off, the interlock switch needs service. Correct the problem before operating the machine; refer to [Servicing the Brake-Interlock Switch \(page 32\)](#).
5. Carefully lower the machine off the kickstand.

Transporting the Machine to a Job Site

Transporting the Machine Using Transport Wheels

Use the transport wheels to transport the machine a shorter distance.

1. Install the transport wheels; refer to [4 Installing the Transport Wheels \(page 9\)](#).
2. Ensure that the traction and reel-drive controls are in the NEUTRAL position.
3. Start the engine; refer to [Starting the Engine \(page 23\)](#).
4. Set the throttle control to SLOW, tip the front of the machine up, gradually engage the traction drive, and slowly increase the engine speed.
5. Adjust the throttle to operate the mower at the desired ground speed and transport the machine to the desired destination.

Transporting the Machine Using a Trailer

Use a trailer to transport the machine a considerable distance. Use caution while loading and unloading the machine onto the trailer.

1. Carefully drive the machine onto the trailer.
2. Shut off the engine, engage the parking brake, and turn the fuel valve to the OFF position.
3. Use a full-width ramp for loading the machine into a trailer or truck.
4. Securely fasten the machine to the trailer.

Note: You can use the Toro Trans Pro trailer to transport the machine. For instructions on loading the trailer, refer to your trailer *Operator's Manual*.

Important: Do not run the engine while transporting it on a trailer because damage can occur to the machine.

During Operation

During Operation Safety

General Safety

- The owner/operator can prevent and is responsible for accidents that may cause personal injury or property damage.
- Wear appropriate clothing, including eye protection; long pants; substantial, slip-resistant footwear; and hearing protection. Tie back long hair and do not wear loose clothing or loose jewelry.
- Do not operate the machine while ill, tired, or under the influence of alcohol or drugs.
- Use your full attention while operating the machine. Do not engage in any activity that causes distractions; otherwise, injury or property damage may occur.
- Before you start the machine, ensure that all drives are in neutral, the parking brake is engaged, and you are in the operating position.
- Keep bystanders and children out of the operating area. If co-workers must be present, use caution and ensure that the grass basket is installed on the machine.
- Operate the machine only in good visibility to avoid holes or hidden hazards.
- Do not operate the machine when there is the risk of lightning.
- Use care when mowing on wet grass. Poor footing could cause a slip-and-fall accident.
- Keep your hands and feet away from the cutting unit.
- Look behind and down before backing up to be sure of a clear path.
- Use care when approaching blind corners, shrubs, trees, or other objects that may obscure your vision.
- Stop the cutting unit whenever you are not mowing.
- Disengage the drive to the cutting unit and shut off the machine before adjusting the height of cut.

- Never run an engine in an area where exhaust gasses are enclosed.
- Never leave a running machine unattended.
- Before you leave the operator's position, do the following:
 - Park the machine on a level surface.
 - Disengage the cutting unit(s).
 - Engage the parking brake.
 - Shut off the machine and remove the key (if equipped).
 - Wait for all movement to stop.
- Shut off the machine before emptying the basket.
- Do not touch the engine, muffler, or exhaust pipe while the engine is running or soon after it has shut off because these areas could be hot enough to cause burns.
- Shut off the machine and disengage the drive to the cutting unit in the following situations:
 - Before fueling
 - Before clearing blockages
 - Before removing the grass basket
 - Before checking, cleaning, or maintaining the cutting unit
 - After striking a foreign object or if an abnormal vibration occurs. Inspect the cutting unit for damage and make repairs before starting and operating the machine
 - Before leaving the operating position
- Use only accessories and attachments approved by The Toro® Company.

Slope Safety

- Slopes are a major factor related to loss of control and rollover accidents, which can result in severe injury or death. You are responsible for safe slope operation. Operating the machine on any slope requires extra caution. Before using the machine on a slope, do the following:
 - Review and understand the slope instructions in the manual and on the machine.
 - Evaluate the site conditions of the day to determine if the slope is safe for machine operation. Use common sense and good judgment when performing this evaluation. Changes in the terrain, such as moisture, can quickly affect the operation of the machine on a slope.
- Operate across slopes, never up and down. Avoid operation on excessively steep or wet slopes. Poor footing could cause a slip-and-fall accident.
- Identify hazards at the base of the slope. Do not operate the machine near drop-offs, ditches,

embankments, water, or other hazards. The machine could suddenly roll over if a wheel goes over the edge or the edge collapses. Keep a safe distance between the machine and any hazard. Use a handheld tool to operate in these areas.

- Avoid starting, stopping, or turning the machine on slopes. Avoid making sudden changes in speed or direction; turn slowly and gradually.
- Do not operate a machine under any conditions where traction, steering, or stability is in question. Be aware that operating the machine on wet grass, across slopes, or downhill may cause the machine to lose traction. Loss of traction to the drive may result in sliding and a loss of braking and steering. The machine can slide even if you stop the drive.
- Remove or mark obstacles such as ditches, holes, ruts, bumps, rocks, or other hidden hazards. Tall grass can hide obstacles. Uneven terrain could overturn the machine.
- If you lose control of the machine, step away from the direction of travel of the machine.
- Always keep the machine in gear when going down slopes. Do not coast downhill (applicable only to gear-drive units).

Starting the Engine

Note: For illustrations and descriptions of the controls referenced in this section, refer to [Controls \(page 12\)](#).

Note: Ensure that the spark-plug wire is installed on the spark plug.

1. Ensure that the traction and reel drive levers are in the DISENGAGED position.

Note: The engine will not start if the traction lever is in the ENGAGED position.

2. Ensure that the fuel-shutoff valve is open.
3. Move the On/Off switch to the ON position.
4. Move the throttle control to the FAST position.
5. Move the choke lever halfway between the CHOKE and RUN positions when starting a cold engine.

Note: The choke may not be required when starting a warm engine.

6. Pull the recoil-start handle out until positive engagement results, then pull it vigorously to start the engine.

Important: Do not pull the recoil rope to its limit or let go of the starter handle when the rope is pulled out; the rope may break or the recoil assembly may be damaged.

7. Move the choke lever to the RUN position as the engine warms up.

Shutting Off the Engine

1. Move the traction and reel drive controls to the **DISENGAGED** position.
2. Move the throttle control to the **SLOW** position.
3. Move the On/Off switch to the **OFF** position.
4. Close the fuel-shutoff valve before you store or transport the machine

Releasing the Transmission

If the machine becomes disabled with the motor brake on, you can disengage the drum from the transmission to allow the machine to be maneuvered.

1. On the right rear corner of the machine, locate the traction engage/disengage lever next to the drive housing drum (**Figure 30**).




Figure 30

- | | |
|--|---|
| 1. Traction engage/disengage lever-engaged | 2. Traction engage/disengage lever-disengaged |
|--|---|

2. Rotate the lever rearward to disengage the transmission from the drum.

Important: Push the lever from the front to prevent your hand from being struck by the spring loaded lever.

3. Move the machine as needed

Important: If possible, do not tow the machine. If it is absolutely necessary, do not tow at any speed greater than 4.8 kph (3 mph); always disengage the transmission from the drum. Failing to do so will likely cause damage to the machine, especially the electrical components.

4. When finished, rotate the lever forward to engage the transmission to the drum.

Note: The service brake is still operational with the transmission disengaged from the drum.

Operating Tips

Important: Grass clippings act as a lubricant when mowing. Operating the cutting unit excessively without grass clippings can damage the cutting unit.

- Mow the greens in a straight back-and-forth direction across the green.
- Avoid circular mowing or turning the machine on the greens areas to prevent scuffing.
- Turn the machine off the green by raising the cutting reel (pushing the handle down) and turning on the traction drum.
- Mow at a normal walking pace. Fast speeds saves little time and results in an inferior mowing job.
- To assist in maintaining a straight line across the green and to keep the machine an equal distance from the edge of the previous cut, use the alignment stripes on the basket (**Figure 31**).




Figure 31

1. Alignment stripes

Operating the Machine in Low Light Conditions

Use the LED Light Kit when you operate the machine in low light conditions; contact your authorized Toro distributor.

Important: Do not use other light systems with this machine, as they will not operate properly with the engine AC output.

Operating the Controls while Mowing

1. Start the engine, set the throttle to a reduced speed, push down on the handle to raise the cutting unit, press the operator-presence control, move the traction and reel-drive engagement lever to the FORWARD (transport) position, and transport the machine onto the collar of the green (Figure 32).
2. Move the lever to the NEUTRAL position (Figure 32).




Figure 32

Traction and Reel-Drive Lever Positions

- | | |
|--|---|
| 1. NEUTRAL | 3. Traction—FORWARD (transport) |
| 2. Traction—NEUTRAL and reel drive—DISENGAGE | 4. Traction—FORWARD and reel drive—ENGAGE |

3. Move the lever to the traction—NEUTRAL and reel drive—DISENGAGE position (Figure 32).
4. Move the lever to the traction—FORWARD and reel drive—ENGAGE position (Figure 32), increase the throttle speed until the machine is traveling at the desired ground speed, drive the machine onto the green, lower the cutting unit to the ground, and begin mowing.

Operating the Controls after Mowing

1. Drive off the green, move the reel drive and traction control levers to the DISENGAGED position, and shut off the engine.
2. Empty the grass basket of clippings, install the grass basket on the mower, and transport the machine to storage.

After Operation

After Operation Safety

General Safety

- Shut off the machine, remove the key (if equipped), and wait for all movement to stop before you leave the operator's position. Allow the machine to cool before adjusting, servicing, cleaning, or storing it.
- Clean grass and debris from the machine to help prevent fires. Clean up oil or fuel spills.
- Allow the machine to cool before storing the machine in any enclosure.
- Do not store the machine or fuel container where there is an open flame, spark, or pilot light, such as on a water heater or on other appliances.
- Reduce the throttle setting before shutting off the engine and turn off the fuel-shutoff valve (if equipped) after mowing.

Transporting the Machine

After mowing, transport the machine away from the job site; refer to [Transporting the Machine Using Transport Wheels \(page 22\)](#) or [Transporting the Machine Using a Trailer \(page 22\)](#).

Maintenance

⚠ WARNING

Failing to properly maintain the machine could result in premature failure of machine systems, causing possible harm to you or bystanders.

Keep the machine well maintained and in good working order as indicated in these instructions.

Note: Determine the left and right sides of the machine from the normal operating position.

Important: Do not tip the machine at an angle greater than 25°. Tipping beyond 25° leads to oil leaking into the combustion chamber and/or fuel leaking out of the fuel-tank cap.

Important: Refer to your engine owner's manual for additional maintenance procedures.

Note: Download a free copy of the electrical or hydraulic schematic by visiting www.Toro.com and searching for your machine from the Manuals link on the home page.

⚠ CAUTION

If you leave the key in the ignition switch, someone could accidentally start the engine and seriously injure you or other bystanders.

Remove the key from the ignition and disconnect the wires from the spark plugs before you do any maintenance. Set the wires aside so that they do not accidentally contact the spark plugs.

Maintenance Safety

- Before you leave the operator's position, do the following:
 - Park the machine on a level surface.
 - Move the throttle to the low-idle position.
 - Disengage the cutting unit(s).
 - Ensure that the traction is in neutral.
 - Engage the parking brake.
 - Shut off the machine and remove the key (if equipped).
 - Wait for all movement to stop.
- Allow machine components to cool before performing maintenance.
- If possible, do not perform maintenance while the machine is running. Keep away from moving parts.
- If the engine must be running to perform a maintenance adjustment, keep your hands, feet, clothing, and any parts of the body away from the cutting unit, attachments, and any moving parts. Keep bystanders away.
- Clean grass and debris from the cutting unit, drive, muffler, cooling screen, and the engine to help prevent fires. Clean up oil or fuel spills.
- Keep all parts in good working condition. Replace all worn, damaged, or missing parts and decals. Keep all hardware tight to ensure that the machine is in safe working condition.
- Check the grass catcher components frequently and replace them when necessary.
- To ensure safe, optimal performance of the machine, use only genuine Toro replacement parts. Replacement parts made by other manufacturers could be dangerous, and such use could void the product warranty.
- If major repairs are ever needed or if assistance is desired, contact an authorized Toro distributor.

Recommended Maintenance Schedule(s)

Maintenance Service Interval	Maintenance Procedure
After the first 20 hours	<ul style="list-style-type: none"> • Change the engine oil. • Clean the fuel-tank screen.
Before each use or daily	<ul style="list-style-type: none"> • Check the operation of the interlock switches. • Check the engine-oil level.
Every 50 hours	<ul style="list-style-type: none"> • Change the engine oil (more frequently in dusty or dirty conditions). • Clean the air cleaner (more often in dirty or dusty conditions).
Every 100 hours	<ul style="list-style-type: none"> • Replace the paper air filter element (more often in dirty or dusty conditions). • Check the spark plug. • Clean the fuel-tank screen.
Every 500 hours	<ul style="list-style-type: none"> • Replace the clutch oil with ATF D/M Automatic Transmission Fluid (Toro Part No. 505-136).
Every 1,000 hours	<ul style="list-style-type: none"> • Replace the fuel line. • Replace the breather hose. • Inspect the reel-drive belt. • Check the transmission-drive belts. • Check the transmission bearings.

Daily Maintenance Checklist

Important: Duplicate this page for routine use.

Maintenance Check Item	For the week of:						
	Mon.	Tues.	Wed.	Thurs.	Fri.	Sat.	Sun.
Check the safety interlock operation.							
Check the parking brake operation.							
Check that pivot joints operate freely.							
Check the fuel level.							
Check the engine oil level.							
Check the air filter.							
Clean the engine cooling fins.							
Check for unusual engine noises.							
Check for unusual operating noises.							
Check the reel-to-bedknife adjustment.							
Check the height-of-cut adjustment.							
Touch up damaged paint.							

Notation for Areas of Concern		
Inspection performed by:		
Item	Date	Information

Engine Maintenance

Engine Safety

- Do not change the governor speed or overspeed the engine.
- Run the engine dry or remove the fuel with a hand pump; never siphon the fuel. If you must drain the fuel tank, do it outdoors.

Servicing the Engine Oil

Fill the crankcase with approximately 0.6 L (20 fl oz) of the proper viscosity oil before starting. The engine uses a high-quality oil that has the American Petroleum Institute (API) service classification of SE or higher. Select the proper oil viscosity (weight) based on the ambient temperature. Figure 33 illustrates the temperature/viscosity recommendations.




Figure 33

Note: Multi-grade oils (5W-20, 10W-30 and 10W-40) increase oil consumption. Check the engine-oil level more frequently when you use these oils.

Checking the Engine-Oil Level

Service Interval: Before each use or daily

The ideal time to check the engine-oil level is when the engine is cool or before you have started the engine for the day. If you have already ran the engine, allow the oil to drain back down to the sump for at least 10 minutes before you check the engine-oil level.

1. Remove the transport wheels (if installed).
2. Position the machine so that the engine is level, and clean the area around the oil-level gauge (Figure 34).




Figure 34

1. Oil-level dipstick
2. Drain plug

3. Remove the oil-level dipstick by rotating it counterclockwise (Figure 34).
4. Wipe the dipstick and insert it into the filler port, but do not screw the dipstick into the port.
5. Remove the dipstick and check the level of the oil.
6. If the level is low, add only enough oil to raise the level until it is between the "H" and "L" marks on the dipstick (Figure 35). Check the level of the oil.

Important: Do not overfill the crankcase.




Figure 35

7. Install the dipstick and wipe up any oil that may have spilled.

Changing the Engine Oil

Service Interval: After the first 20 hours

Every 50 hours

1. Start and run the engine for a few minutes to warm the engine oil.
2. At the rear of the machine, place a drain pan under the drain plug (Figure 34). Loosen the drain plug.

3. Push down on the handle to tip the machine and engine backward, allowing all the oil to run into the drain pan.

Important: Do not tip the machine at an angle greater than 25°. Tipping the machine beyond 25° leads to oil leaking into the combustion chamber and/or fuel leaking out of the fuel-tank cap.

4. Install the drain plug and refill the crankcase with the specified oil.
5. Torque the drain plug to 20 to 23 N·m (15 to 17 ft-lbs).
6. Wipe up any spilled oil.
7. Dispose of the used oil properly. Recycle according to local codes.

Servicing the Air Cleaner

Service Interval: Every 50 hours

1. Ensure that the wire is off the spark plug.
2. Remove the wing nut that secures the air-cleaner cover to the air cleaner and remove the cover.
3. Clean the cover (Figure 36 and Figure 37).




Figure 36

1. Air-cleaner cover

4. If the foam element is dirty, remove it from the paper element (Figure 37). Clean it as follows.
 - A. Wash the foam element in a solution of liquid soap and warm water. Squeeze the element to remove the dirt, but do not twist it, as the foam may tear.
 - B. Dry the foam element by wrapping it in a clean rag. Squeeze the rag and element to dry it, but do not twist it, as the foam may tear.
 - C. Saturate the element with clean engine oil. Squeeze the element to remove the excess oil and to distribute the oil.

Note: A foam element that is damp with oil is desirable.




Figure 37

- | | |
|----------------------|---------------------|
| 1. Wing nut | 4. Foam element |
| 2. Air-cleaner cover | 5. Paper element |
| 3. Wing nut | 6. Air-cleaner base |

5. Check the condition of the paper element. Clean it by gently tapping or replace it as necessary.

Important: Do not use compressed air to clean the paper element.

6. Install the foam element, paper element, and air-cleaner cover.

Important: Do not operate the engine without the air-cleaner element, as extreme wear and damage can likely occur to the engine.

Servicing the Spark Plug

Service Interval: Every 100 hours

Use an NGK BR6HS spark plug or equivalent. The correct air gap is 0.6 to 0.7 mm (0.024 to 0.028 inch).

1. Pull the molded wire off the spark plug (Figure 38).




Figure 38

1. Spark-plug wire

2. Clean around the spark plug and remove the plug from the cylinder head.

Important: Replace a cracked, fouled, or dirty spark plug. Do not sand blast, scrape, or clean the electrodes because engine damage could result from grit entering the cylinder.

3. Set the air gap at 0.6 to 0.7 mm (0.024 to 0.028 inch) as shown in Figure 39. Install the correctly gapped spark plug and tighten it firmly to 23 N·m (17 ft-lb).




Figure 39

1. Center-electrode insulator
2. Side electrode
3. Air gap—0.6 to 0.7 mm (0.024 to 0.028 inch)

Fuel System Maintenance

Cleaning the Fuel-Tank Screen

Service Interval: After the first 20 hours

Every 100 hours/Monthly (whichever comes first)

1. Unscrew and remove the fuel-tank cap from the fuel tank (Figure 40).




Figure 40

1. Fuel-tank cap
2. Fuel-tank screen

2. Remove the fuel-tank screen from inside the fuel tank.
3. Clean the screen in clean fuel and install it in the tank.
4. Install the fuel-tank cap to the fuel tank.

Replacing the Fuel Line

Service Interval: Every 1,000 hours

If fuel leaks from the fuel line, replace the line immediately.

Replacing the Breather Hose

If the breather hose is damaged, replace it immediately.

Electrical System Maintenance

Servicing the Traction-Interlock Switch

Use the following procedure if the traction-interlock switch needs adjustment or replacement.

1. Ensure that the engine is off.
2. Remove the control panel.
3. Engage the traction lever.




Figure 41

1. Traction lever
2. Interlock switch

4. Loosen the interlock switch mounting fasteners (Figure 41).
5. Place a 1.6 mm (0.062 inch) thick shim between the traction lever and the interlock switch (Figure 41).
6. Tighten the interlock switch mounting fasteners.
7. Engage the traction lever and check the gap. The normal operating range is between 0.76 to 3.05 mm (0.03 to 0.12 inch). With the traction lever engaged, verify that the switch loses continuity. Replace the switch if necessary.

Servicing the Brake-Interlock Switch

1. Ensure that the engine is off.
2. Remove the control panel.
3. Engage the service-brake lever and engage the parking-brake latch.
4. Loosen and remove the interlock-switch mounting fasteners (Figure 42).




Figure 42

1. Parking-brake latch
2. Interlock switch
3. Service-brake lever

5. Place a 1.6 mm (0.062 inch) thick shim between the parking-brake latch and the interlock switch (Figure 42).
6. Install and tighten the interlock switch mounting fasteners. Check the gap. The latch must not contact the switch.
7. Engage the brake lever and rotate the latch. Verify that the switch loses continuity. Replace the switch if necessary.

Brake Maintenance

Adjusting the Service/Parking Brake

If the service/parking brake slips when operated, adjust the cable as follows:

1. Move the service/parking brake lever to the OFF position.
2. Remove the control panel.
3. To increase the cable tension, loosen the upper cable jam nut and tighten the lower cable jam nut (Figure 43) until a force of 156 N (35 lb) applied to the brake-lever handle is required to release the parking-brake latch.

Important: Do not over adjust the brake, as the brake band may drag.




Figure 43

1. Jam nuts
2. Service-brake cable

Belt Maintenance

Inspecting the Reel-Drive Belt

Service Interval: Every 1,000 hours

1. Shut off the engine and remove the key.
2. Loosen the flange bolt that secures the belt cover and remove the belt cover to expose the belt (Figure 44).




Figure 44

1. Belt cover

3. Perform the following steps to adjust the belt tension:
 - A. Loosen the bearing-housing mounting nut (Figure 45).




Figure 45

1. Bearing-housing mounting nut
2. Reel-drive belt
3. Compression spring

- B. Using a 16 mm (5/8 inch) wrench, rotate the bearing housing to ensure that it operates freely.

- C. Clean any debris from inside the belt compartment and from around the compression spring (Figure 45).
- D. Ensure that the compression spring is applying the proper tension on the belt.
- E. Tighten the bearing housing mounting nut.
- F. Install the belt cover.

Visually Inspecting the Reel Clutch

Remove the rubber plug (Figure 46) from the hole in the front of the transmission to visually inspect the reel clutch when making adjustments.

Important: Replace the plug when finished to prevent water and debris from contaminating the clutch.




Figure 46

- 1. Rubber-hole plug
- 2. Engage/disengage shaft

Engaging/Disengaging the Transmission-Belt Tensioner

The transmission belt is tensioned by a spring-loaded idler pulley. If you must engage or disengage the belt tension, use a 3/8-inch wrench to rotate the engage/disengage shaft (Figure 46) to the desired position. Rotating the shaft 1/4-turn (90°) clockwise disengages the idler from the belt (Figure 47).

Note: You must disengage the belt tension before removing the transmission cover

Note: The transmission belt is properly tensioned when the alignment marks on the transmission cover and the engagement shaft are aligned.




Figure 47

- 1. ENGAGED
- 2. DISENGAGED

Controls System Maintenance

Adding Fluid to the Clutch Assembly

Fluid specification: ATF D/M Automatic Transmission Fluid (Toro Part No. 505-136)

1. Remove the vent from the breather from the transmission assembly (Figure 48).




Figure 48

g295805

1. Breather
 2. Vent
 3. Level plug
 4. Drain plug
2. Remove the drain plug (Figure 48) and allow the transmission fluid to drain from the transmission housing.
 3. Add the specified fluid (296 ml or 10 fl oz) through the breather opening.
 4. Apply a light coating of clean motor oil (SAE 30) onto the rubber portion of the seals and O-rings (breather and level plug) prior to assembly.
 5. Install drain plug to the clutch assembly and torque it to 14 N·m (10 ft-lbs).
 6. Remove the level plug (Figure 48) to confirm fluid fill level.
 7. Install the level plug and torque it to 14 N·m (10 ft-lbs).
 8. Install the vent to the breather. Tighten until gasket contacts and then tighten an additional 80°.

Adjusting the Traction Control Control

If the traction control does not engage or if it slips during operation, an adjustment is necessary.

1. Move the traction control to the ENGAGED position.
2. Measure the distance from the pin on either end of the traction-control spring (Figure 49); if it is not within 7.3 to 7.6 cm (2-7/8 to 3 inches), adjust the clutch according to the steps below.




Figure 49

G032417

g032417

1. Measure this distance (should be 7.3 to 7.6 cm (2-7/8 to 3 inches).
 2. Traction-control spring
 3. Clevis pin
 4. Turnbuckle
 5. Jam nut
- A. Disengage the traction-control lever.
 - B. Loosen the jam nut on the turnbuckle and remove the clevis pin, disconnecting the spring from the turnbuckle (Figure 49).
 - C. Turn the turnbuckle in or out to adjust the length as necessary.
 - D. Install the turnbuckle to the spring with the clevis pin.
 - E. Move the traction control to the ENGAGED position.
 - F. Measure the distance from the pin on either end of the traction-control spring (Figure 49); repeat steps A through F until it is within 7.3 to 7.6 cm (2-7/8 to 3 inches).

Adjusting the Reel Control

If the reel control does not properly engage, an adjustment is necessary.

1. Ensure that the reel control is disengaged.
2. At the control-handle bulkhead, loosen the reel-control cable until there is slack in the cable (Figure 50).




Figure 50

g295537

- | | |
|---------------------------|-----------------------|
| 1. Jam nuts | 3. Reel-control cable |
| 2. Traction-control cable | |

3. At the control-handle bulkhead, tighten the reel-control cable enough to remove the slack from the cable without extending the spring.
4. Check the operation as follows:
 - Verify that the reel-clutch teeth disengage when the clutch is released and the reel-clutch teeth do not bottom out when engaged.

Note: Remove the rubber plug (Figure 46) from the hole in the front of the transmission to view the reel clutch.

 - The reel stopping time must be less than 7 seconds with the reel to bedknife backed off.
 - Refer to the *Service Manual* or contact your authorized Toro distributor for further assistance.

Storage

Storage Safety

- Shut off the engine, remove the key (if equipped), and wait for all movement to stop before you leave the operator's position. Allow the machine to cool before adjusting, servicing, cleaning, or storing it.
- Do not store the machine or fuel container where there is an open flame, spark, or pilot light, such as on a water heater or other appliance.

Storing the Machine

1. Remove any grass clippings, dirt, and grime from the external parts of the entire machine, especially the engine. Clean the dirt and chaff from the outside of the engine cylinder-head fins and the blower housing.

Important: You can wash the machine with mild detergent and water. Do not pressure-wash the machine. Avoid excessive use of water, especially near the shift-lever plate and the engine.

2. For long-term storage (more than 30 days) add stabilizer/conditioner additive to the fuel in the tank.
 - A. Run the engine to distribute conditioned fuel through the fuel system (5 minutes).
 - B. Either shut off the engine, allow it to cool, and drain the fuel tank, or operate the engine until it shuts off.
 - C. Start the engine and run it until it shuts off. Start the engine again, with the choke closed, until the engine does not start.
 - D. Disconnect the spark-plug wire from the spark plug.
 - E. Dispose of the fuel properly. Recycle it according to local codes.

Note: Do not store fuel containing stabilizer/conditioner longer than the duration recommended by the fuel-stabilizer manufacturer.

3. Check and tighten all bolts, nuts, and screws. Repair or replace any part that is worn or damaged.
4. Paint all scratched or bare metal surfaces. Paint is available from your authorized Toro distributor.
5. Store the machine on a level surface in a clean, dry garage or storage area. Cover the machine to protect it and keep it clean.

Notes:

EEA/UK Privacy Notice

Toro's Use of Your Personal Information

The Toro Company ("Toro") respects your privacy. When you purchase our products, we may collect certain personal information about you, either directly from you or through your local Toro company or dealer. Toro uses this information to fulfil contractual obligations - such as to register your warranty, process your warranty claim or to contact you in the event of a product recall - and for legitimate business purposes - such as to gauge customer satisfaction, improve our products or provide you with product information which may be of interest. Toro may share your information with our subsidiaries, affiliates, dealers or other business partners in connection these activities. We may also disclose personal information when required by law or in connection with the sale, purchase or merger of a business. We will never sell your personal information to any other company for marketing purposes.

Retention of your Personal Information

Toro will keep your personal information as long as it is relevant for the above purposes and in accordance with legal requirements. For more information about applicable retention periods please contact legal@toro.com.

Toro's Commitment to Security

Your personal information may be processed in the US or another country which may have less strict data protection laws than your country of residence. Whenever we transfer your information outside of your country of residence, we will take legally required steps to ensure that appropriate safeguards are in place to protect your information and to make sure it is treated securely.

Access and Correction

You may have the right to correct or review your personal data, or object to or restrict the processing of your data. To do so, please contact us by email at legal@toro.com. If you have concerns about the way in which Toro has handled your information, we encourage you to raise this directly with us. Please note that European residents have the right to complain to your Data Protection Authority.

California Proposition 65 Warning Information

What is this warning?

You may see a product for sale that has a warning label like the following:



WARNING: Cancer and Reproductive Harm—www.p65Warnings.ca.gov.

What is Prop 65?

Prop 65 applies to any company operating in California, selling products in California, or manufacturing products that may be sold in or brought into California. It mandates that the Governor of California maintain and publish a list of chemicals known to cause cancer, birth defects, and/or other reproductive harm. The list, which is updated annually, includes hundreds of chemicals found in many everyday items. The purpose of Prop 65 is to inform the public about exposure to these chemicals.

Prop 65 does not ban the sale of products containing these chemicals but instead requires warnings on any product, product packaging, or literature with the product. Moreover, a Prop 65 warning does not mean that a product is in violation of any product safety standards or requirements. In fact, the California government has clarified that a Prop 65 warning "is not the same as a regulatory decision that a product is 'safe' or 'unsafe.'" Many of these chemicals have been used in everyday products for years without documented harm. For more information, go to <https://oag.ca.gov/prop65/faqs-view-all>.

A Prop 65 warning means that a company has either (1) evaluated the exposure and has concluded that it exceeds the "no significant risk level"; or (2) has chosen to provide a warning based on its understanding about the presence of a listed chemical without attempting to evaluate the exposure.

Does this law apply everywhere?

Prop 65 warnings are required under California law only. These warnings are seen throughout California in a wide range of settings, including but not limited to restaurants, grocery stores, hotels, schools, and hospitals, and on a wide variety of products. Additionally, some online and mail order retailers provide Prop 65 warnings on their websites or in catalogs.

How do the California warnings compare to federal limits?

Prop 65 standards are often more stringent than federal and international standards. There are various substances that require a Prop 65 warning at levels that are far lower than federal action limits. For example, the Prop 65 standard for warnings for lead is 0.5 µg/day, which is well below the federal and international standards.

Why don't all similar products carry the warning?

- Products sold in California require Prop 65 labelling while similar products sold elsewhere do not.
- A company involved in a Prop 65 lawsuit reaching a settlement may be required to use Prop 65 warnings for its products, but other companies making similar products may have no such requirement.
- The enforcement of Prop 65 is inconsistent.
- Companies may elect not to provide warnings because they conclude that they are not required to do so under Prop 65; a lack of warnings for a product does not mean that the product is free of listed chemicals at similar levels.

Why does Toro include this warning?

Toro has chosen to provide consumers with as much information as possible so that they can make informed decisions about the products they buy and use. Toro provides warnings in certain cases based on its knowledge of the presence of one or more listed chemicals without evaluating the level of exposure, as not all the listed chemicals provide exposure limit requirements. While the exposure from Toro products may be negligible or well within the "no significant risk" range, out of an abundance of caution, Toro has elected to provide the Prop 65 warnings. Moreover, if Toro does not provide these warnings, it could be sued by the State of California or by private parties seeking to enforce Prop 65 and subject to substantial penalties.



The Toro Warranty

Two-Year or 1,500 Hours Limited Warranty

Conditions and Products Covered

The Toro Company and its affiliate, Toro Warranty Company, pursuant to an agreement between them, jointly warrant your Toro Commercial product ("Product") to be free from defects in materials or workmanship for 2 years or 1,500 operational hours*, whichever occurs first. This warranty is applicable to all products with the exception of Aerators (refer to separate warranty statements for these products). Where a warrantable condition exists, we will repair the Product at no cost to you including diagnostics, labor, parts, and transportation. This warranty begins on the date the Product is delivered to the original retail purchaser.

* Product equipped with an hour meter.

Instructions for Obtaining Warranty Service

You are responsible for notifying the Commercial Products Distributor or Authorized Commercial Products Dealer from whom you purchased the Product as soon as you believe a warrantable condition exists. If you need help locating a Commercial Products Distributor or Authorized Dealer, or if you have questions regarding your warranty rights or responsibilities, you may contact us at:

Toro Commercial Products Service Department
Toro Warranty Company
8111 Lyndale Avenue South
Bloomington, MN 55420-1196
952-888-8801 or 800-952-2740
E-mail: commercial.warranty@toro.com

Owner Responsibilities

As the product owner, you are responsible for required maintenance and adjustments stated in your *Operator's Manual*. Repairs for product issues caused by failure to perform required maintenance and adjustments are not covered under this warranty.

Items and Conditions Not Covered

Not all product failures or malfunctions that occur during the warranty period are defects in materials or workmanship. This warranty does not cover the following:

- Product failures which result from the use of non-Toro replacement parts, or from installation and use of add-on, or modified non-Toro branded accessories and products.
- Product failures which result from failure to perform recommended maintenance and/or adjustments.
- Product failures which result from operating the Product in an abusive, negligent, or reckless manner.
- Parts consumed through use that are not defective. Examples of parts which are consumed, or used up, during normal Product operation include, but are not limited to, brake pads and linings, clutch linings, blades, reels, rollers and bearings (sealed or greasable), bed knives, spark plugs, castor wheels and bearings, tires, filters, belts, and certain sprayer components such as diaphragms, nozzles, and check valves.
- Failures caused by outside influence, including, but not limited to, weather, storage practices, contamination, use of unapproved fuels, coolants, lubricants, additives, fertilizers, water, or chemicals.
- Failure or performance issues due to the use of fuels (e.g. gasoline, diesel, or biodiesel) that do not conform to their respective industry standards.
- Normal noise, vibration, wear and tear, and deterioration. Normal "wear and tear" includes, but is not limited to, damage to seats due to wear or abrasion, worn painted surfaces, scratched decals or windows.

Countries Other than the United States or Canada

Customers who have purchased Toro products exported from the United States or Canada should contact their Toro Distributor (Dealer) to obtain guarantee policies for your country, province, or state. If for any reason you are dissatisfied with your Distributor's service or have difficulty obtaining guarantee information, contact your Authorized Toro Service Center.

Parts

Parts scheduled for replacement as required maintenance are warranted for the period of time up to the scheduled replacement time for that part. Parts replaced under this warranty are covered for the duration of the original product warranty and become the property of Toro. Toro will make the final decision whether to repair any existing part or assembly or replace it. Toro may use remanufactured parts for warranty repairs.

Deep Cycle and Lithium-Ion Battery Warranty

Deep cycle and Lithium-Ion batteries have a specified total number of kilowatt-hours they can deliver during their lifetime. Operating, recharging, and maintenance techniques can extend or reduce total battery life. As the batteries in this product are consumed, the amount of useful work between charging intervals will slowly decrease until the battery is completely worn out. Replacement of worn out batteries, due to normal consumption, is the responsibility of the product owner. Note: (Lithium-Ion battery only): Pro-rated after 2 years. Refer to the battery warranty for additional information.

Lifetime Crankshaft Warranty (ProStripe 02657 Model Only)

The Prostripe which is fitted with a genuine Toro Friction Disc and Crank-Safe Blade Brake Clutch (integrated Blade Brake Clutch (BBC) + Friction Disc assembly) as original equipment and used by the original purchaser in accordance with recommended operating and maintenance procedures, are covered by a Lifetime Warranty against engine crankshaft bending. Machines fitted with friction washers, Blade Brake Clutch (BBC) units and other such devices are not covered by the Lifetime Crankshaft Warranty.

Maintenance is at Owner's Expense

Engine tune-up, lubrication, cleaning and polishing, replacement of filters, coolant, and completing recommended maintenance are some of the normal services Toro products require that are at the owner's expense.

General Conditions

Repair by an Authorized Toro Distributor or Dealer is your sole remedy under this warranty.

Neither The Toro Company nor Toro Warranty Company is liable for indirect, incidental or consequential damages in connection with the use of the Toro Products covered by this warranty, including any cost or expense of providing substitute equipment or service during reasonable periods of malfunction or non-use pending completion of repairs under this warranty. Except for the Emissions warranty referenced below, if applicable, there is no other express warranty. All implied warranties of merchantability and fitness for use are limited to the duration of this express warranty.

Some states do not allow exclusions of incidental or consequential damages, or limitations on how long an implied warranty lasts, so the above exclusions and limitations may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Note Regarding Emissions Warranty

The Emissions Control System on your Product may be covered by a separate warranty meeting requirements established by the U.S. Environmental Protection Agency (EPA) and/or the California Air Resources Board (CARB). The hour limitations set forth above do not apply to the Emissions Control System Warranty. Refer to the Engine Emission Control Warranty Statement supplied with your product or contained in the engine manufacturer's documentation.