



Broom

Dingo[®] Attachment

Model No. 22415—200000001 & Up

Operator's Manual



English (CE)

Contents

	Page
Introduction	2
Safety	2
Safety Decals	3
Specifications	3
Stability Ratings	4
Installation	5
Loose Parts	5
Assembling the Broom	5
Configuring the Broom for Use with the Dingo TX	6
Greasing the Broom	6
Checking Castor Tire Pressure	6
Installing the Broom on the Traction Unit	6
Removing the Broom from the Traction Unit	8
Adjusting the Downward Pressure of the Broom	8
Operation	9
Tips for Sweeping	9
Maintenance	9
Service Interval Chart	9
Greasing and Lubrication	10
Changing Brushes	11
Replacing the Castor Fork Bushings	12
Servicing a Castor Wheel	12
Storage	12
Troubleshooting	13

Introduction

We want you to be completely satisfied with your new product, so feel free to contact your local Authorized Service Dealer for help with service, genuine replacement parts, or other information you may require.

Whenever you contact your Authorized Service Dealer or the factory, always know the model and serial numbers of your product. These numbers will help the Service Dealer or Service Representative provide exact information about your specific product. You will find the model and serial number on a plate located on the product. For your convenience, write the product model and serial numbers in the space below.

Model No: _____

Serial No. _____

The warning system in this manual identifies potential hazards and has special safety messages that help you and others avoid personal injury, even death. **DANGER**, **WARNING** and **CAUTION** are signal words used to identify the level of hazard. However, regardless of the hazard, be extremely careful.

DANGER signals an extreme hazard that will cause serious injury or death if the recommended precautions are not followed.

WARNING signals a hazard that may cause serious injury or death if the recommended precautions are not followed.

CAUTION signals a hazard that may cause minor or moderate injury if the recommended precautions are not followed.

Two other words are also used to highlight information. “Important” calls attention to special mechanical information and “Note” emphasizes general information worthy of special attention.

The left and right side of the machine is determined by standing in the normal operator’s position.

Safety

Improper use or maintenance by the operator or owner can result in injury. To reduce the potential for injury, comply with the safety instructions in the traction unit operator’s manual and always pay attention to the safety alert  symbol, which means CAUTION, WARNING, or DANGER—“personal safety instruction.” Failure to comply with the instruction may result in personal injury or death.

! **WARNING** !

POTENTIAL HAZARD

- Contact with rotating bristles may cause injury.

WHAT CAN HAPPEN

- Rotating bristles can injure hands, feet or other body parts.

HOW TO AVOID THE HAZARD

- Keep your hands, feet, and any other part of your body or clothing away from rotating parts.
- Before adjusting, cleaning, repairing and inspecting the broom, lower the broom to the ground and stop the engine. Remove the key.

! **WARNING** !

POTENTIAL HAZARD

- Small stones, dirt clumps, or other debris may be thrown during sweeping.

WHAT CAN HAPPEN

- Serious injury may result.

HOW TO AVOID THE HAZARD

- Keep children and bystanders out of the work area.
- Always wear safety glasses or goggles when operating the broom.

! **WARNING** !

POTENTIAL HAZARD

- When the engine is off, attachments in the raised position can gradually lower.

WHAT CAN HAPPEN

- Someone nearby may be pinned or injured by the attachment as it lowers.

HOW TO AVOID THE HAZARD

- Always lower the attachment lift each time you shut off the traction unit.

Safety Decals




Figure 1

- | | |
|----------------------------------|--------------------------------------|
| 1. Pinching/crushing hazard—hand | 6. Thrown object hazard—face |
| 2. Pinching/crushing hazard—foot | 7. Wear eye and breathing protection |
| 3. Keep bystanders away | 8. Thrown object hazard—whole body |
| 4. Safety alert symbol | |
| 5. Read operator's manual | |

Specifications


Note: Specifications and design are subject to change without notice.

Width	53 inches (135 cm)
Length	40 inches (102 cm)
Height	50 inches (127 cm)
Weight	476 lbs (216 Kg)

Maximum swing angle	25 degrees
Sweeping width with no swing rotation With 25 degree swing rotation	48 inches (122 cm) 42 inches (106.6 cm)
Broom diameter	24 inches (51 cm)
Number of brushes	27
Brush material	Polypropylene and/or steel
Brush rotation speed	150 rpm
Hydraulic drive	Direct drive, 11.9 cu. in. (195 cc) geroler motor
Castor wheels	Two 8.5 in. (21.5 cm) x 3.5 in. (8.9) pneumatic tires

Stability Ratings

To determine the degree of slope you can traverse with the broom installed on a traction unit, find the stability rating for the hill position you want to travel in the table below, then find the degree of slope for the same rating and hill position in the Stability Data section of the traction unit operator's manual.

Orientation	Stability Rating
Front Uphill 	C
Rear Uphill 	C
Side Uphill 	C

Note: On traction units other than the Dingo TX, the broom is rated for use without the counterweight. If you use the counterweight with the broom, the traction unit will be less stable in the front and side uphill positions.

!
WARNING
!

POTENTIAL HAZARD

- Exceeding the maximum recommended slope can cause the traction unit to tip.

WHAT CAN HAPPEN

- If the traction unit tips, you or bystanders could be crushed.

HOW TO AVOID THE HAZARD

- Do not drive the traction unit on a slope steeper than the maximum recommended slope, as determined in the previous table and the traction unit operator's manual.

Installation

Loose Parts

Note: Use the chart below to identify parts for assembly.

DESCRIPTION	QTY.	USE
Pivot frame	1	Assemble broom
Broom head	1	
Attachment frame	1	
Swing arm	1	
Bolt, 3/4 in. (1.9 cm) x 10 1/2 in. (26.7 cm)	1	
Nut, 3/4 in. (1.9 cm)	4	
Thrust washer, large	1	
Pivot cap	2	
Bolt, 3/4 in. (1.9 cm) x 4 in. (10 cm)	2	
Spacer	4	

Assembling the Broom

1. Slide the thrust washer and the pivot frame onto the shaft on the back of the broom head (Fig. 2)
2. Secure the pivot frame with a pivot cap, 3/4 in. (1.9 cm) x 10 1/2 in. (26.7 cm) bolt, and 3/4 in. (1.9 cm) nut (Fig. 2).

Note: Ensure that the pivot frame rotates around the shaft. If it cannot, the bolt and nut are too tight.




Figure 2

- | | |
|------------------|--|
| 1. Pivot frame | 5. Bolt, 3/4 in. (1.9 cm) x 10 1/2 in. (26.7 cm) |
| 2. Shaft | 6. Nut, 3/4 in. (1.9 cm) |
| 3. Pivot cap | |
| 4. Thrust washer | |

3. Lubricate the shaft on the top of the pivot frame (Fig. 3) with a corrosion resistant, calcium-sulphonate based grease.
4. Slide the attachment frame onto the shaft on the top of the pivot frame (Fig. 3).
5. Secure the attachment frame with a pivot cap and 3/4 in. (1.9 cm) nut (Fig. 3).




Figure 3

- | | |
|-------------------|--------------------------|
| 1. Assembly frame | 3. Pivot cap |
| 2. Shaft | 4. Nut, 3/4 in. (1.9 cm) |

6. Torque the nut to 265 ft·lbs (359 Nm).
7. Connect the swing arm to the swing bracket on the pivot frame with two spacers, a 3/4 in. (1.9 cm) x 4 in. (10 cm) bolt, and a 3/4 in. (1.9 cm) nut (Fig. 4). Torque to 265 ft·lbs (359 Nm).

8. Route the hydraulic hoses through the ring on the back of the pivot frame (Fig. 4)




Figure 4

- | | |
|---|--------------------------|
| 1. Swing bracket | 4. Nut, 3/4 in. (1.9 cm) |
| 2. Swing arm | 5. Spacer |
| 3. Bolt, 3/4 in. (1.9 cm) x 4 in. (10 cm) | 6. Ring |

9. Thread the clamp levers into the clamp bases until they are approximately 1/4 in. (0.6 cm) from the rubber springs (Fig. 5)




Figure 5

- | | |
|------------------|---------------------|
| 1. Clamp lever | 3. 1/4 in. (0.6 cm) |
| 2. Rubber spring | |

Configuring the Broom for Use with the Dingo TX

The broom is shipped for use with any of the wheeled traction units. To use it with the Dingo TX, you must move the rear crossbar on the broom, as follows:

1. Remove the four bolts securing the crossbar (Fig. 6).
2. Reposition the cross bar at the upper holes (Fig. 6).




Figure 6

- | | |
|------------------|------------------------|
| 1. Rear crossbar | 3. Move to these holes |
| 2. Bolts | |

3. Secure the crossbar with the four bolts.
4. Torque the bolts to 265 ft-lbs (359.2 N·m).

Greasing the Broom


Before using the broom for the first time, grease all of the fittings and the loader arm clamps; refer to Greasing and Lubrication, page 10.

Checking Castor Tire Pressure

Before using the broom, ensure that the castor tires are filled to 50 psi (344.75 kPa).

Installing the Broom on the Traction Unit

1. Position the broom on a level surface with enough space behind it to accommodate the traction unit.
2. Start the engine.
3. Tilt the attachment mount plate forward.
4. Lift the loader arms so the mount plate is above the rear crossbar on the broom.
5. Connect the traction unit to the broom mount plate; refer to your traction unit manual for more information.
6. Raise the broom about 6 in. (15 cm) off the ground.
7. Remove the front legs/clamp levers (Fig. 7).




m-4139

Figure 7

1. Front leg/clamp lever

8. Install the clamp levers on the loader arm clamps and secure them with latch pins (Fig. 8).



m-4130

Figure 8

1. Loader arm clamp
2. Clamp lever
3. Latch pin

9. If necessary, release the loader arm clamps by swinging the clamp levers up and over the clamps.

! **WARNING** !

POTENTIAL HAZARD

- The loader arm clamps are spring loaded and can propel the clamp levers up and forward at great speeds when released.

WHAT CAN HAPPEN


- The clamp lever could strike you or a bystander causing severe injury.

HOW TO AVOID THE HAZARD

- Ensure that you do not stand in the path of the clamp lever and that all bystanders are clear of the area.

10. Swing the loader arm clamps over the loader arms and secure them by pulling the clamp levers down and back (Fig. 9).

Note: Ensure that the rubber spring is compressed approximately 1/4 in. (0.6 cm) when the clamp is secured.



m-4131

Figure 9

1. Loader arm clamp
2. Loader arm
3. Clamp lever
4. Rubber spring

11. Connect the hydraulic hoses; refer to you traction unit manual for more information.

Removing the Broom from the Traction Unit

1. Start the engine and lower the broom to the ground or onto a trailer.
2. Disconnect the hydraulic hoses; refer to you traction unit manual for more information.
3. Swing the clamp levers up to release the loader arm clamps.

**WARNING**

POTENTIAL HAZARD

- The loader arm clamps are spring loaded and can propel the front legs up and forward at great speeds when released.

WHAT CAN HAPPEN

- The front leg could strike you or a bystander causing severe injury.

HOW TO AVOID THE HAZARD

- Ensure that you do not stand in the path of the front leg and that all bystanders are clear of the area.

4. Swing the clamps off of the loader arms.
5. Remove the front legs/clamp levers from the loader arms.
6. Raise the broom about 6 in. (15 cm) off of the ground, and install the front legs in front of the broom.
7. Lower the broom to the ground.
8. Disconnect the traction unit to the broom mount plate; refer to you traction unit manual for more information.

Adjusting the Downward Pressure of the Broom

Improper downward pressure can decrease broom life up to 95% (depending on the incorrect amount of pressure).

A broom sweeps with the tips of its bristles. When too much down pressure is applied, the broom is no longer using it's tips; the broom is now working with the sides of the bristles. This limits the flicking action of the bristles and limits it's sweeping effectiveness.

To check for correct downward pressure, operate the broom on the ground, rotating at normal operating speed with traction unit remaining stationary. Stop and raise the broom. Measure the width of swept area (Fig. 10). A properly adjusted broom will have a sweeping path width of 2 to 4 inches (5 to 10 cm).




Figure 10

1. 2 to 4 inches (5 to 10 cm)

Adjust castor height for proper broom ground pressure. The castor wheel height is adjustable from 4 to 7 inches (10 to 18 cm) in 1/2 inch (1.2 cm) increments by adding or removing an equal amount of spacers from each castor wheel.

1. Start the engine and raise the broom.
2. Stop the engine.
3. Remove the cap securing the castor spindle to the frame bracket (Fig. 11).
4. Move desired amount of spacers to the top or bottom of the bracket (Fig. 11). Ensure that the spacers are equal on both castor wheels and that a thrust washer is positioned on each side of the frame bracket.
5. Install the cap and lower the broom (Fig. 11).




Figure 11

- | | |
|-------------------|------------------|
| 1. Castor spindle | 4. Frame bracket |
| 2. Spacers | 5. Cap |
| 3. Thrust washer | |

To operate the broom, pull the auxiliary hydraulics lever to the operator grip and hold it there.

Tips for Sweeping

- If ground speed is too fast, debris will pile up in front of the broom, causing it to bulldoze instead of sweep. This can damage the broom.
- More pressure will not give a better sweep, but it will wear out the broom faster.
- A level broom lasts longer.
- When sweeping, try to keep the flange on the top of the pivot pin level with the gage plate (Fig. 12). This will allow you adequate room for movement if you run over bumps or low areas.




Figure 12

- | | |
|--------------|---------------|
| 1. Pivot pin | 2. Gage plate |
|--------------|---------------|

Operation

Note: Always use the traction unit to lift and move the attachment.

Maintenance

Service Interval Chart

Service Operation	Each Use	8 Hours	200 Hours	Storage Service	Notes
Main pivot shaft-lubricate	X			X	
Grease fittings		X		X	
Change brushes					As required
Replace castor fork bushings			X		
Replace castor wheel bearings					When the castor wheel is wobbly.
Chipped surfaces-paint				X	



CAUTION



POTENTIAL HAZARD

- If you leave the key in the ignition switch, someone could start the engine.

WHAT CAN HAPPEN

- Accidental starting of the engine could seriously injure you or other bystanders.

HOW TO AVOID THE HAZARD

- Remove the key from the ignition switch before you do any maintenance.


Greasing and Lubrication

Service Interval/Specification

Grease one fitting on the broom pivot shaft (Fig. 13) with a corrosion resistant, calcium-sulphonate based grease before each use. Grease 8 other fittings, located on each castor shaft (Fig. 14, only one side shown), on the right of the the axle (Fig. 15), on the motor/axle linkage (Fig. 16), on the right and left arms (Fig. 17, only one side shown), and on the loader arm clamps (Fig. 8, only one side shown), every 8 operating hours. Grease all fittings immediately after every washing.

Grease Type: corrosion resistant, calcium-sulphonate based grease (pivot shaft only) and general-purpose grease (all other fittings).

Fitting Locations



m-4132

Figure 13






Figure 14



m-4134


Figure 15



m-4180


Figure 16

1. Knuckle joint inside the broom axle



m-4133

Figure 17



m-4130

Figure 18

How to Grease

1. Lower the broom/loader arms and stop the engine. Remove the key.

2. Clean the grease fittings with a rag.
3. Connect a grease gun to the fittings.
4. Pump grease into the fittings until grease begins to ooze out of the bearings.
5. Wipe up any excess grease.

Changing Brushes

The axle of the broom holds 27 removable brushes. In Summer, install all polypropylene brushes. In the Winter, alternate polypropylene and steel brushes to aid in removing hard packed snow and ice.

1. Remove the two bolts securing the side guard plate and remove the plate (Fig. 19).
2. Remove the two bolts securing the hydraulic motor housing (Fig. 19)




Figure 19

1. Side guard plate
2. Hydraulic motor and motor housing
3. Remove

3. Carefully remove the hydraulic motor and motor housing with the axle attached.
4. Loosen the two bolts securing the axle locking collar. (Fig. 20).




Figure 20

1. Axle locking collar
2. Loosen

5. Remove the three bolts and washers securing the axle plate on the axle and remove the plate (Fig. 21)
6. Slide the brushes off of the axle assembly (Fig. 21).
7. Slide a new brush onto the axle assembly so the alignment pins of the brush ride over **the bottom** bar of the axle assembly (Fig. 21).
8. Rotate the next brush 180° from side to side and top to bottom and slide it onto the axle assembly so the alignment pins of the brush ride over **top** bar of axle assembly (Fig. 21).




Figure 21

1. Axle
2. Axle plate
3. Bolt (3)
4. Washer (3)
5. Brushes

9. Repeat steps 7 and 8 until all brushes are installed.
10. Replace the axle plate and secure it with the bolts and washers removed in step 5.
11. Secure the axle locking collar.

12. Slide the hydraulic motor and motor housing into position and secure it with the bolts removed in step 2.
13. Install the side guard and secure it with the bolts removed in step 1.

Replacing the Castor Fork Bushings

After many hours of operation, the bushings pressed into the top and bottom of the frame bracket will wear. To check the bushings, move the castor fork fore and aft and from side to side. If the castor spindle is loose in the bushings, the bushings are worn and must be replaced.

1. Start the engine and raise the broom to highest possible position.
2. Install the cylinder locks then stop the engine.
3. Remove the cap and thrust washers from top of castor spindle.
4. Pull the castor spindle out of the bracket, allowing the thrust washers to remain on the bottom of the spindle.
5. Using a pin punch, drive the bushings out of the bracket (Fig. 22).




Figure 22

1. Frame bracket
2. Bushing

6. Clean inside of the bracket to remove any dirt.
7. Apply grease to the inside and outside of the new bushings.
8. Using a hammer and a flat plate, drive the bushings into the bracket (Fig. 22)
9. Inspect the castor shaft for wear and replace it if necessary.
10. Install the castor spindle into the bracket, place the thrust washers onto the spindle, and secure it with the cap.

Servicing a Castor Wheel

When a castor wheel becomes wobbly, it usually indicates that the wheel bearings are worn. Perform this procedure to fix a wobbly castor wheel.

1. Start the engine and raise the broom to highest possible position.
2. Install the cylinder locks then stop the engine.
3. Remove locknut and capscrew that secure the castor wheel assembly in the castor fork (Fig. 23).
4. Remove the castor wheel from the fork (Fig. 23).
5. Remove the outer bearing from wheel hub and allow the bearing spacer to fall out (Fig. 23).
6. Remove the other outer bearing (Fig. 23).




Figure 23

1. Castor fork
2. Castor wheel
3. Capscrew
4. Locknut
5. Outer bearing
6. Bearing spacer

7. Check the bearings, spacer, and inside of wheel hub for wear. Replace any defective parts.
8. Push an outer bearing into the wheel hub.
9. Slide the bearing spacer into the wheel hub.
10. Push other bearing into the open side of the wheel hub to captivate the spacer inside.
11. Install castor wheel assembly in the castor fork and secure it in place with a capscrew and locknut.

Storage

1. Before long term storage wash the attachment with mild detergent and water to remove dirt and grime.
2. Check the condition of the brushes and replace if necessary.
3. Apply grease to all grease fittings.

4. Check and tighten all bolts, nuts, and screws. Repair or replace any part that are damaged or worn.
5. Paint all scratched or bare metal surfaces. Paint is available from your Authorized Service Dealer.
6. Store the broom in a clean, dry garage or storage area. Cover it to protect it and keep it clean.

Troubleshooting

PROBLEM	POSSIBLE CAUSES	CORRECTIVE ACTION
Broom does not rotate.	1. Hydraulic coupler not completely connected 2. Defective hydraulic coupler 3. An obstruction in a hydraulic hose 4. Auxiliary valve on the traction unit is not opening.	1. Check and tighten all couplers. 2. Check couplers and replace any that are defective. 3. Find and remove the obstruction. 4. Repair the valve.

