



**Count on it.**

**Service Manual**

**30 Inch TurfMaster® HDX WPM**



Published June 2020

# Revision History

# Preface

This service manual was written expressly for Toro service technicians. The Toro Company has made every effort to make the information in this manual complete and correct.

Basic shop safety knowledge and mechanical/electrical skills are assumed. The Table of Contents lists the systems and the related topics covered in this manual.

We are hopeful that you will find this manual a valuable addition to your service shop. If you have any questions or comments regarding this manual, please contact us at the following address:

**The Toro Company**  
**RLC/SWS Customer Care Department**  
**8111 Lyndale Avenue South**  
**Bloomington, MN 55420**

The Toro Company reserves the right to change product specifications or make changes to this manual without notice.

# Service Procedure Icons

The following icons appear throughout this Service Manual to bring attention to specific important details of a service procedure.



## Critical Process

This icon is used to highlight:

- Installing safety equipment (shields, guards, seat belts, brakes, and R.O.P.S. components) that may have been removed
- Dimensions or settings that must be maintained for proper machine operation
- A specific fastener tightening sequence
- Component orientation that may not be obvious



## Critical Torque

This icon is used to highlight an assembly torque requirement that is different than what is recommended in the Standard Torque Tables.



## Fluid Specifications

This icon is used to highlight fluid specifications and capacities that are less common, and may not appear on the machine service decal or in the machine *Operator's Manual*.

**Note:** Refer to the service decal on the machine and the machine *Operator's Manual* for commonly used fluid specifications and capacities.

# Table of Contents

Preface .....	3
Chapter 1: Safety .....	1-1
Safety Instructions .....	1-2
Chapter 2: Specifications and Maintenance .....	2-1
Specifications .....	2-2
Torque Specifications .....	2-3
Chapter 3: Troubleshooting .....	3-1
General Troubleshooting .....	3-3
Chapter 4: Engine .....	4-1
General Information .....	4-2
Service and Repairs .....	4-3
Chapter 5: Controls .....	5-1
General Information .....	5-2
Service and Repairs .....	5-3
Chapter 6: Belts.....	6-1
General Information .....	6-2
Service and Repairs .....	6-3
Chapter 7: Deck .....	7-1
General Information .....	7-2
Service and Repairs .....	7-3
Chapter 8: Drive System .....	8-1
General Information .....	8-2
Service and Repairs .....	8-3





## Table of Contents

Safety Instructions ..... 1-2  
Think Safety First ..... 1-2

# Safety Instructions



## DANGER



This safety symbol means danger. When you see this symbol, carefully read the instructions that follow. Failure to obey the instructions could cause serious permanent injury, disability, or death.

---



## WARNING



This safety symbol means warning. When you see this symbol, carefully read the instructions that follow. Failure to obey the instructions can result in serious injury.

---



## CAUTION



This safety symbol means caution. When you see this symbol, carefully read the instructions that follow. Failure to obey the instructions can result in minor to moderate injury and/or damage to property or equipment.

---

## Think Safety First

### **Avoid unexpected starting of engine...**

Always turn off the engine, remove the ignition key and disconnect the spark plug wire(s) before cleaning, adjusting, or repair.

### **Avoid lacerations and amputations...**

Stay clear of all moving parts whenever the engine is running. Treat all normally moving parts as if they were moving whenever the engine is running or has the potential to start.

### **Avoid burns...**

Do not touch the engine, muffler, or other components, which may be hot during operation, while the unit is running or shortly after it has been running.

### **Avoid fires and explosions...**

Use extreme care in handling fuel. It is flammable and its vapors are explosive. Extinguish all cigarettes, cigars, pipes, and other sources of ignition. Avoid spilling fuel and never smoke while working with any type of fuel or lubricant. Wipe up any spilled fuel or oil immediately. Never remove the fuel cap or add fuel when the engine is running. Always use approved, labeled containers for storing or transporting fuel and lubricants. Do not add or drain fuel in an enclosed space. Do not store the machine or fuel container where there is an open flame, spark, or pilot light, such as on a water heater or other appliance.

### **Avoid asphyxiation...**

Do not operate an engine in a confined area without proper ventilation.

### **Avoid injury from batteries...**

## Think Safety First (continued)

Battery acid is poisonous and can cause burns. Avoid contact with skin, eyes and clothing. Battery gases can explode. Keep cigarettes, sparks and flames away from the battery.

### **Avoid injury due to inferior parts...**

Use only original equipment parts to ensure that important safety criteria are met.

### **Avoid injury to bystanders...**

Always clear the area of bystanders before starting or testing powered equipment.

### **Avoid injury due to projectiles...**

Always clear the area of sticks, rocks or any other debris that could be picked up and thrown by the powered equipment.

### **Avoid modifications...**

Never alter or modify any part unless it is a factory approved procedure.

### **Avoid unsafe operation...**

Always test the safety interlock system after making adjustments or repairs on the machine. Refer to the Electrical section in this manual for more information.

### **Avoid electrical shock...**

Never touch electrical wires or components while the engine is running. They can be sources of shock. De-energize the system if you are having to do repairs. If testing electrical components ensure you are working in a dry environment.

### **Hydraulic System...**

Release all pressure in the hydraulic system before performing any work on the system. Keep your body and hands away from pin-hole leaks or nozzles that eject hydraulic fluid under high pressure. Do not use your hands to search for leaks. Hydraulic fluid escaping under pressure can have sufficient force to penetrate under the skin and cause serious injury. Seek medical attention right away if hydraulic fluid gets in the skin.

### **Personal Protective Equipment...**

Tie back long hair, and do not wear loose clothing or jewelry. Use appropriate personal protective equipment (PPE) for protecting yourself from potential hazards in the environment in which you will work. Each process outlined in this manual may need different PPE to protect the service person. Use the proper PPE for the task at hand.

### **Tools...**

All tools should be in proper working order. Do not use tools that are broken or in disrepair. Use the proper tool for the proper application.

### **Lifts, Hoists, and Jacks...**

All lifts, hoists, and jacks should be used in accordance with the manufacturer information. Inspect lifts, hoists, and jacks prior to use. Do not overload lifts, hoists, and jacks. Do not work under a suspended load. Ensure chock blocks are used on equipment that can move. Use lifts or jacks and jack stands that are rated to support the total weight of the machine and any attachments. Do not rely on jacks to support the machine. If you are unsure of the operation of any lifts, hoists, and jacks do not use.

### **Fire Extinguishers...**

## Think Safety First (continued)

The proper class of fire extinguisher should be used in case of fire.

**Class A** extinguishers are for ordinary combustible materials such as paper, wood, cardboard, and most plastics. The numerical rating on these types of extinguishers indicates the amount of water it holds and the amount of fire it can extinguish. Geometric symbol (green triangle).

**Class B** fires involve flammable or combustible liquids such as gasoline, kerosene, grease and oil. The numerical rating for class B extinguishers indicates the approximate number of square feet of fire it can extinguish. Geometric symbol (red square).

**Class C** fires involve electrical equipment, such as appliances, wiring, circuit breakers and outlets. Never use water to extinguish class C fires - the risk of electrical shock is far too great! Class C extinguishers do not have a numerical rating. The C classification means the extinguishing agent is non-conductive. Geometric symbol (blue circle).

**ABC** fire extinguishers are a dry chemical type used for multiple purposes. See above information for description. Ensure fire extinguishers are serviceable and replace any that are discharged or out of inspection dates



# Specifications and Maintenance

## Table of Contents

Specifications .....	2-2
Torque Specifications .....	2-3
Equivalents and Conversions.....	2-8
U.S. to Metric Conversions .....	2-9

# Specifications

Model	22207	22215	22225
Engine	Kawasaki		Kohler
Engine Oil Capacity	22 oz (0.65 L) without filter, 29 oz (0.85 L) with filter		24 oz (0.70 L) with and without filter
Engine Oil	SAE 30 or SAE 10W-30/API SJ or higher		
Fuel Tank	1 gallon		
Cut Width	30 inch		
Transmission	Single Speed		
High Idle (No Load)	3500 RPM		
Front Wheel	9 inch		
Rear Wheel	10.5 inch		

# Torque Specifications

The recommended fastener torque values are listed in the following tables. For critical applications, as determined by Toro, either the recommended torque or a torque that is unique to the application is clearly identified and specified in the service manual.


These torque specifications for the installation and tightening of fasteners shall apply for all fasteners which do not have a specific requirement identified in the service manual. The following factors shall be considered when applying torque: cleanliness of the fastener, use of a thread sealant (Loctite), degree of lubrication on the fastener, presence of a prevailing torque feature, hardness of the surface underneath of the fastener's head, or similar condition which affects the installation.

As noted in the following tables, torque values should be reduced by 25% for lubricated fasteners to achieve the similar stress as a dry fastener. Torque values may also have to be reduced when the fastener is threaded into aluminum or brass. The specific torque value should be determined based on the aluminum or brass material strength, fastener size, length of thread engagement, etc.

The standard method of verifying torque shall be performed by marking a line on the fastener (head or nut) and mating part, then back off fastener 1/4 of a turn. Measure the torque required to tighten the fastener until the lines match up.

## Fastener Identification

### Inch Series Bolts and Screws




g272208

**Figure 1**

- |            |            |
|------------|------------|
| 1. Grade 1 | 3. Grade 8 |
| 2. Grade 5 |            |

Metric Bolts and Screws



g272209

Figure 2

1. Class 8.8

2. Class 10.9

**Standard Torque for Dry, Zinc Plated, and Steel Fasteners (Inch Series)**

Thread Size	Grade 1, 5, & 8 Fasteners with Thin Height Nuts	SAE Grade 1 Bolts, Screws, Studs & Sems with Regular Height Nuts (SAE Grade 2 or Better Nut)		SAE Grade 5 Bolts, Screws, Studs & Sems with Regular Height Nuts (SAE Grade 5 or Better Nut)		SAE Grade 8 Bolts, Screws, Studs & Sems with Regular Height Nuts (SAE Grade 8 or Better Nut)	
		in-lb	in-lb	N • cm	in-lb	N • cm	in-lb
#6-32 UNC	10 ± 2	13 ± 2	147 ± 23	15 ± 2	169 ± 23	23 ± 3	260 ± 34
#6-40 UNF				17 ± 2	192 ± 23	25 ± 3	282 ± 34
#8-32 UNC	13 ± 2	25 ± 5	282 ± 30	29 ± 3	328 ± 34	41 ± 5	463 ± 56
#8-36 UNF				31 ± 4	350 ± 45	43 ± 5	486 ± 56
#10-24 UNC	18 ± 2	30 ± 5	339 ± 56	42 ± 5	475 ± 56	60 ± 6	678 ± 68
#10-32 UNF				48 ± 5	542 ± 56	68 ± 7	768 ± 79
1/4-20 UNC	48 ± 7	53 ± 7	599 ± 79	100 ± 10	1130 ± 113	140 ± 15	1582 ± 169
1/4-28 UNF	53 ± 7	65 ± 10	734 ± 113	115 ± 12	1299 ± 136	160 ± 17	1808 ± 192
5/16-18 UNC	115 ± 15	105 ± 15	1186 ± 169	200 ± 25	2260 ± 282	300 ± 30	3390 ± 339
5/16-24 UNF	138 ± 17	128 ± 17	1446 ± 192	225 ± 25	2542 ± 282	325 ± 33	3672 ± 373
	ft-lb	ft-lb	N • m	ft-lb	N • m	ft-lb	N • m
3/8-16 UNC	16 ± 2	16 ± 2	22 ± 3	30 ± 3	41 ± 4	43 ± 5	58 ± 7
3/8-24 UNF	17 ± 2	18 ± 2	24 ± 3	35 ± 4	47 ± 5	50 ± 6	68 ± 8
7/16-14 UNC	27 ± 3	27 ± 3	37 ± 4	50 ± 5	68 ± 7	70 ± 7	95 ± 9
7/16-20 UNF	29 ± 3	29 ± 3	39 ± 4	55 ± 6	75 ± 8	77 ± 8	104 ± 11
1/2-13 UNC	30 ± 3	48 ± 7	65 ± 9	75 ± 8	102 ± 11	105 ± 11	142 ± 15
1/2-20 UNF	32 ± 4	53 ± 7	72 ± 9	85 ± 9	115 ± 12	120 ± 12	163 ± 16
5/8-11 UNC	65 ± 10	88 ± 12	119 ± 16	150 ± 15	203 ± 20	210 ± 21	285 ± 28
5/8-18 UNF	75 ± 10	95 ± 15	129 ± 20	170 ± 18	230 ± 24	240 ± 24	325 ± 33
3/4-10 UNC	93 ± 12	140 ± 20	190 ± 27	265 ± 27	359 ± 37	375 ± 38	508 ± 52
3/4-16 UNF	115 ± 15	165 ± 25	224 ± 34	300 ± 30	407 ± 41	420 ± 43	569 ± 58
7/8-9 UNC	140 ± 20	225 ± 25	305 ± 34	430 ± 45	583 ± 61	600 ± 60	813 ± 81
7/8-14 UNF	155 ± 25	260 ± 30	353 ± 41	475 ± 48	644 ± 65	667 ± 66	904 ± 89

**Note:** Reduce torque values listed in the table above by 25% for lubricated fasteners. Lubricated fasteners are defined as threads coated with a lubricant such as oil, graphite, or thread sealant such as Loctite.

Torque values may have to be reduced when installing fasteners into threaded aluminum or brass. The specific torque value should be determined based on the fastener size, the aluminum or base material strength, length of thread engagement, etc.

The nominal torque values listed above for Grade 5 and 8 fasteners are based on 75% of the minimum proof load specified in SAE J429. The tolerance is approximately ± 10% of the nominal torque value. Thin nuts include jam nuts.

## Standard Torque for Dry, Zinc Plated, and Steel Fasteners (Metric Series)

Thread Size	Class 8.8 Bolts, Screws, Studs with Regular Height Nuts (Class 8 or Stronger Nuts)		Class 10.9 Bolts, Screws, Studs with Regular Height Nuts (Class 10 or stronger Nuts)	
	in-lb	N • cm	in-lb	N • cm
<b>M5 X 0.8</b>	57 ± 6	644 ± 68	78 ± 8	881 ± 90
<b>M6 X 1.0</b>	96 ± 10	1085 ± 113	133 ± 14	1503 ± 158
	ft-lb	N • m	ft-lb	N • m
<b>M8 X 1.25</b>	19 ± 2	26 ± 3	28 ± 3	38 ± 4
<b>M10 X 1.5</b>	38 ± 4	52 ± 5	54 ± 6	73 ± 8
<b>M12 X 1.75</b>	66 ± 7	90 ± 10	93 ± 10	126 ± 14
<b>M16 X 2.0</b>	166 ± 17	255 ± 23	229 ± 23	310 ± 31
<b>M20 X 2.5</b>	325 ± 33	440 ± 45	450 ± 46	610 ± 62

**Note:** Reduce torque values listed in the table above by 25% for lubricated fasteners. Lubricated fasteners are defined as threads coated with a lubricant such as oil, graphite, or thread sealant such as Loctite.

Torque values may have to be reduced when installing fasteners into threaded aluminum or brass. The specific torque value should be determined based on the fastener size, the aluminum or base material strength, length of thread engagement, etc.

The nominal torque values listed above are based on 75% of the minimum proof load specified in SAE J1199. The tolerance is approximately ± 10% of the nominal torque value. Thin height nuts include jam nuts.

## SAE Grade 8 Steel Set Screws

Thread Size	Recommended Torque	
	Square Head	Hex Socket
1/4 - 20 UNC	140 ± 20 in-lb	73 ± 12 in-lb
5/16 - 18 UNC	215 ± 35 in-lb	145 ± 20 in-lb
1/2 - 13 UNC	75 ± 15 ft-lb	50 ± 10 ft-lb
3/8 - 16 UNC	35 ± 10 ft-lb	18 ± 3 ft-lb

## Wheel Bolts and Lug Nuts

Thread Size	Recommended Torque**	
7/16 - 20 UNF Grade 5	65 ± 10 ft-lb	88 ± 14 N • m
1/2 - 20 UNF Grade 5	80 ± 10 ft-lb	108 ± 14 N • m
M12 X 1.25 Class 8.8	80 ± 10 ft-lb	108 ± 14 N • m
M12 X 1.5 Class 8.8	80 ± 10 ft-lb	108 ± 14 N • m

\*\*For steel wheels and non-lubricated fasteners.

## Thread Cutting Screws (Zinc Plated Steel)

Type 1, Type 23, or Type F	
Thread Size	Baseline Torque*
No. 6 - 32 UNC	20 ± 5 in-lb
No. 8 - 32 UNC	30 ± 5 in-lb
No. 10 - 24 UNC	38 ± 7 in-lb
1/4 - 20 UNC	85 ± 15 in-lb
5/16 - 18 UNC	110 ± 20 in-lb
3/8 - 16 UNC	200 ± 100 in-lb

\*Hole size, material strength, material thickness and finish must be considered when determining specific torque values. All torque values are based on non-lubricated fasteners.

### Conversion Factors

$$\text{in-lb} \times 11.2985 = \text{N} \cdot \text{cm}$$

$$\text{ft-lb} \times 1.3558 = \text{N} \cdot \text{m}$$

$$\text{N} \cdot \text{cm} \times 0.08851 = \text{in-lb}$$

$$\text{N} \cdot \text{cm} \times 0.73776 = \text{ft-lb}$$

## Thread Cutting Screws (Zinc Plated Steel)

Threads Size	Threads per Inch		Baseline Torque*
	Type A	Type B	
No. 6	18	20	20 ± 5 in-lb
No. 8	15	18	30 ± 5 in-lb
No. 10	12	16	38 ± 7 in-lb
No. 12	11	14	85 ± 15 in-lb

\*Hole size, material strength, material thickness and finish must be considered when determining specific torque values. All torque values are based on non-lubricated fasteners.

# Equivalents and Conversions

## Decimal and Millimeter Equivalents

Fractions	Decimals	mm	Fractions	Decimals	mm
1/64	0.015625	0.397	33/64	0.515625	13.097
1/32	0.03125	0.794	16/32	0.53125	13.484
3/64	0.046875	1.191	35/64	0.546875	13.891
1/16	0.0625	1.588	9/16	0.5625	14.288
5/64	0.078125	1.984	37/64	0.578125	14.684
3/32	0.09375	2.381	19/32	0.59375	15.081
1/8	0.1250	3.175	5/8	0.6250	15.875
9/64	0.140625	3.572	41/64	0.640625	16.272
5/32	0.15625	3.969	21/32	0.65625	16.669
11/64	0.171875	4.366	43/64	0.671875	17.066
3/16	0.1875	4.762	11/64	0.6875	17.462
13/64	0.203125	5.159	45/64	0.703125	17.859
7/32	0.21875	5.556	23/32	0.71875	18.256
15/64	0.234375	5.953	47/64	0.734375	18.653
1/4	0.2500	6.350	3/4	0.7500	19.050
17/64	0.265625	6.747	49/64	0.765625	19.447
9/32	0.28125	7.144	25/32	0.78125	19.844
19/64	0.296875	7.541	51/64	0.796875	20.241
5/16	0.3125	7.541	13/16	0.8125	20.638
21/64	0.328125	8.334	53/64	0.828125	21.034
11/32	0.34375	8.731	27/32	0.84375	21.431
23/64	0.359375	9.128	55/64	0.859375	21.828
3/8	0.3750	9.525	7/8	0.8750	22.225
25/64	0.390625	9.922	57/64	0.890625	22.622
13/32	0.40625	10.319	29/32	0.90625	23.019
27/64	0.421875	10.716	59/64	0.921875	23.416
7/16	0.4375	11.112	15/16	0.9375	23.812
29/64	0.453125	11.509	61/64	0.953125	24.209
15/32	0.46875	11.906	31/32	0.96875	24.606
31/64	0.484375	12.303	63/64	0.984375	25.003
1/2	0.5000	12.700	1	1.000	25.400
<b>1 mm = 0.03937 in.</b>			<b>0.001 in. = 0.0254 mm</b>		

# U.S. to Metric Conversions

	To Convert	Into	Multiply By
<b>Linear Measurement</b>	Miles	Kilometers	1.609
	Yards	Meters	0.9144
	Feet	Meters	0.3048
	Feet	Centimeters	30.48
	Inches	Meters	0.0254
	Inches	Centimeters	2.54
	Inches	Millimeters	25.4
<b>Area</b>	Square Miles	Square Kilometers	2.59
	Square Feet	Square Meters	0.0929
	Square Inches	Square Centimeters	6.452
	Acre	Hectare	0.4047
<b>Volume</b>	Cubic Yards	Cubic Meters	0.7646
	Cubic Feet	Cubic Meters	0.02832
	Cubic Inches	Cubic Centimeters	16.39
<b>Weight</b>	Tons (Short)	Metric Tons	0.9078
	Pounds	Kilograms	0.4536
	Ounces	Grams	28.3495
<b>Pressure</b>	Pounds/Square Inch	Kilopascal	6.895
<b>Work</b>	Foot-Pounds	Newton-Meters	1.356
	Foot-Pounds	Kilogram-Meters	0.1383
	Inch-Pounds	Kilogram-Centimeters	1.152144
<b>Liquid Volume</b>	Quarts	Liters	0.9463
	Gallons	Liters	3.785
<b>Liquid Flows</b>	Gallons/Minute	Liters/Minute	3.785
<b>Temperature</b>	Fahrenheit	Celsius	1. Subtract by 32°
			2. Multiply by 5/9





## Table of Contents

General Troubleshooting ..... 3-3

## GEARS

The Systematic approach to defining, diagnosing and solving problems.



# G

### Gather Information

- Information reported by the customer
- Information observed by you
- Establish the what, where and when of the issue



# E

### Evaluate Potential Causes

- Consider possible causes of the problem to develop a hypothesis
- Narrow down the focus of the problem



# A

### Assess Performance

- Ensure you have all the necessary tools for testing
- Test all potential causes of the failure
- Reevaluate and create new hypotheses if necessary



# R

### Repair

- Return the unit to service by repairing, rebuilding or replacing



# S

### Solution Confirmation

- Did the issue go away
- Was the root cause of the issue correctly repaired
- Are there any other new symptoms

# General Troubleshooting

Problem	Possible Cause	Corrective Action
<b>Bent, crooked handle frame</b>	Shipping damage, improper securing while transporting	Replace damaged components.
<b>Cracked or broken frame</b>	Damage from improper securing while transporting the unit.	Replace the frame.
	Vibration from the bent crank, damaged or unbalanced blades.	Replace the frame.
	Loose engine mounting bolts.	Replace the frame. Inspect the engine for damage.
	Operation with the engine guard.	Unit needs to be operated with the engine guard in place or may cause cracked or broken frame.
<b>Broken Bolts</b>	Corrosion	Extract broken portion of bolt, and repair threads when needed.
	Improper assembly torque	Extract broken portion of bolt, and repair threads when needed.
<b>Cracked blade spindle mounts on deck</b>	Striking debris while mowing	Replace the deck, correct vibration.
<b>Broken spindle mounting bolts</b>	Striking debris while mowing	Replace damaged components and check for spindle bearing damage.
<b>Engine has poor running, no start</b>	Fuel contamination, no fuel	Consult the Operator's Manual for basic troubleshooting. Engine support through the engine manufacturer.
<b>Weak drive</b>	Worn belt or pulley	Replace the belt or pulley.
	Improper traction cable adjustment	Adjust the cable properly.
	Low engine RPM	Adjust engine RPM to proper engine speed.
<b>No drive</b>	Broken traction cable	Replace the cable.
	Broken drive belt	Replace the belt.
	Damaged pinion or wheel gears	Replace the pinion gear and wheel assembly.
	Internal failure of transmission	Replace the transmission.





## Table of Contents


General Information .....	4-2
Service and Repairs .....	4-3
Engine Replacement.....	4-5
Fuel Tank Replacement .....	4-13
Throttle Control Replacement .....	4-17

# General Information

This unit comes with 2 different engines, model 22215 with Kawasaki FJ180V and model 22225 with Kohler CV200. These are lubricated engines with a spin on filter and use a fuel tank that is separate from the engine assembly.

# Service and Repairs


## Engine Assembly 1



g299318

**Figure 3**

- |                       |                            |
|-----------------------|----------------------------|
| 1. Fuel Cap           | 9. Fuel Hose               |
| 2. Fuel Tank          | 10. Throttle Mount Bracket |
| 3. Canister Vent Hose | 11. Control Wire           |
| 4. Kawasaki Engine    | 12. Throttle Control       |
| 5. Tank Mount         | 13. BBC Belt               |
| 6. Fuel Hose          | 14. Engine Pulley          |
| 7. Fuel Valve         | 15. Transmission Belt      |
| 8. Fuel Filter        | 16. Belt Guide Rod         |



g298335

**Figure 4**

- |                       |                       |
|-----------------------|-----------------------|
| 1. Fuel Cap           | 9. Link Wire          |
| 2. Canister Vent Hose | 10. Throttle Bracket  |
| 3. Fuel Tank          | 11. Oil Drain Hose    |
| 4. Tank Mount Asm.    | 12. BBC Belt          |
| 5. Kohler Engine      | 13. Engine Pulley     |
| 6. Fuel Hose          | 14. Transmission Belt |
| 7. Fuel Valve         | 15. Belt Guide Rod    |
| 8. Throttle Control   |                       |

# Engine Replacement

## Engine Removal

1. Park the machine on a level surface and engage the parking brake. Stop the engine and wait for all moving parts to stop. Shut the fuel off.
2. Remove the grass bagger assembly if attached.
3. Using an appropriate lifting device, raise the rear of the machine off the ground.
4. Open and secure the rear cover.
5. Remove the 1/4–20 inch taptite screw securing the frame cover to the frame.



g296174

**Figure 5**

- 
6. Remove the 4 (1/4–20 inch) taptite screws securing the belt cover to the frame.



g296175

**Figure 6**

## Engine Removal (continued)

7. Rotate the belt tensioner arm by turning the 7/16 inch nut on the bottom side of the transmission clockwise.



g302330

Figure 7

- 
8. Remove the belt tension by aligning the idler pulley with the access hole on the bottom side of the transmission. Insert a quarter inch screw driver.

**Note:** Screw driver needs to fit through access hole and the idler pulley slot securing the pulley into position.




g296176

Figure 8

- 
9. Remove the transmission belt from the engine pulley.

**Note:** Access belt from the front of the mower.

## Engine Removal (continued)




g302331

**Figure 9**

---

10. Remove the belt from the rear of the mower.



g296178

**Figure 10**

---

11. Remove the 2 (1/4–20 inch) taptite screws securing the front BBC belt guide to the bosses on the frame. Remove the belt guide.

## Engine Removal (continued)



g296179

**Figure 11**

- 
12. Loosen the  $\frac{1}{2}$  inch nylock nut from BBC idler arm pivot until flush with bottom bolt. Secure the topside of the bolt with a  $\frac{1}{2}$  inch wrench.

**Note:** Access bottom bolt through the bottom of the deck, see image.




g296180

**Figure 12**

- 
13. Move the brake arm downwards to release from pulley.

**Note:** Releases pulley pressure from the belt.


## Engine Removal (continued)



g302385

Figure 13

- 
14. Remove the BBC belt from the pulley.



g296181

Figure 14

- 
15. Remove the BBC belt from rear of mower.
  16. Remove the 3 (1/2 inch) bolts securing the engine to the frame.  
**Note:** To remove the front bolt, go through the access hole in the deck with a 10 inch (3/8 inch) drive extension and a 1/2 inch socket with a universal joint.
  17. Remove the engine.

## Engine Installation



1. Install the engine onto the machine.
2. Install the 3 (1/2 inch) bolts securing the engine to the frame. Torque 500 ± 50 in-lbs. (56 ± 5 Nm).

## Engine Installation (continued)

**Note:** To install the front bolt, go through the access hole in the deck with a 10 inch (3/8 inch) drive extension and a 1/2 inch socket with a universal joint.


3. Install the BBC belt through the rear of the mower.
4. Install the BBC belt to the engine pulley.
5. Install the BBC belt to the brake pulley.



g296181

**Figure 15**

- 
6. Move the brake arm upwards to align with the pulley.



g302385


**Figure 16**



7. Tighten the 1/2 inch nylock nut from the BBC idler arm pivot until flush with the bottom bolt. Secure the topside of the bolt with a 1/2 inch wrench.

**Note:** Access through the front side of the frame.

## Engine Installation (continued)



g305213

Figure 17



8. Install the belt guide. Install the 2 (1/4–20 inch) taprite screws securing the front BBC belt guide to the bosses on the frame. Torque screws to  $110 \pm 11$  in-lbs. ( $12 \pm 2$  Nm).




g296179

Figure 18

9. Install the transmission belt through the rear of the mower.
10. Install the transmission belt to the engine pulley.

**Note:** Access belt engine pulley from the front of the mower.

## Engine Installation (continued)



g302331

**Figure 19**

11. Install the transmission belt to the transmission pulley.
12. Using a 7/16 inch nut on the bottom of the transmission, release pressure on the quarter inch screw driver. Remove the quarter inch screw driver, allowing idler arm to put tension on the belt.
13. Install the 4 (1/4–20 inch) taptite screws securing the belt cover to the frame. Torque screws to  $55 \pm 5$  in-lbs. ( $6 \pm 1$  Nm).



g296175

**Figure 20**

14. Install the 1/4–20 inch taptite screw securing the frame cover to the frame. Torque screw to  $110 \pm 11$  in -lbs. ( $12 \pm 2$  Nm).



## Engine Installation (continued)



g296174

**Figure 21**

- 
15. Lower the rear cover.
  16. Using an appropriate lifting device, lower the rear of the machine to the ground.

## Fuel Tank Replacement

### Fuel Tank Removal

1. Park the machine on a level surface and engage the parking brake. Stop the engine and wait for all moving parts to stop. Shut the fuel off.
2. Remove the grass bagger assembly if attached.
3. Shut the fuel off.
4. Move the hose clamp away from the fuel shut-off valve.
5. Remove the fuel hose from the fuel shut-off valve.

**Note:** Kawasaki engine shown.

## Fuel Tank Removal (continued)



g296195

**Figure 22**

6. Remove the 2 (1/4–10 inch) screws mounting the tank to the fuel tank bracket.
7. Lift fuel tank away from the machine.



g296196

**Figure 23**

8. Remove the 3 (M6x1) screws on the Kawasaki engine securing the fuel tank mounting bracket to the engine assembly. On Kohler engine, remove the 1 (M6x1) and 2 (3/8–16x3/4) screws.

**Note:** Removing the bottom left bolt last allows bracket rotation for easier access on Kawasaki engine.

## Fuel Tank Removal (continued)



g296197

**Figure 24**

- 
9. Remove the fuel tank mounting from the engine.

## Fuel Tank Inspection

Shake or tap the fuel tank to listen for audible rattle of the check ball in the tank vent.

## Fuel Tank Installation

1. Install the fuel tank mounting to the engine.



2. Install the 3 (M6x1) screws on the Kawasaki engine securing the fuel tank mounting bracket to the engine assembly. Torque screws to 65 ± 5 in-lbs. (7 ± 1 Nm). For the Kohler engine install the 1 (M6x1) and 2 (3/8–16x3/4) screws. Torque M6x1 screw to 65 ± 5 in-lbs. (7 ± 1 Nm). Torque 3/8–16x3/4 screws to 200 ± 20 in-lbs. (22 ± 2 Nm).

## Fuel Tank Installation (continued)



g296197

**Figure 25**

3. Install the fuel tank onto the machine.



g296196

**Figure 26**



4. Install the 2 (1/4–20 inch) taptite screws mounting the tank to the fuel tank bracket. Torque screws to  $33 \pm 3$  in-lbs. ( $4 \pm 1$  Nm).
5. Install the fuel hose to the fuel shut-off valve. Secure with a hose clamp.

**Note:** Kawasaki engine shown.

## Fuel Tank Installation (continued)



g296195

Figure 27


---

## Throttle Control Replacement

### Throttle Control Removal

1. Park the machine on a level surface and engage the parking brake. Stop the engine and wait for all moving parts to stop. Shut the fuel off.
2. Remove the grass bagger assembly if attached.
3. Loosen the 2 (1/4–20 inch) screws securing the throttle control to the engine shroud.

**Note:** Mounting bolts are in different locations for Kawasaki and Kohler engines, same function applies.




g296938

Figure 28

## Throttle Control Removal (continued)

4. Tip the rear of the control upwards then out slightly to remove the throttle control from the engine.

**Note:** Kawasaki engine shown.



g296939

Figure 29

---

## Throttle Control Adjustment

Full forward should adjust the full throttle detent that does not apply choke. Move forward for choke to engage the choke linkage. Full backwards should engage the engine stop switch.

**Note:** Kawasaki engine shown.



g296940

Figure 30


---

## Throttle Control Installation

1. Install the throttle control to the engine.

## Throttle Control Installation (continued)

**Note:** Kawasaki engine shown.



g296939

**Figure 31**



2. Tighten the 2 (1/4–20 inch) screws securing the throttle control to the engine shroud. Torque bolts to  $55 \pm 5$  in-lbs. ( $6 \pm 1$  Nm).

**Note:** Kawasaki engine shown. Kohler has different mounting locations.



g296938

**Figure 32**





## Table of Contents

General Information .....	5-2
Service and Repairs .....	5-3
BBC Bail Replacement.....	5-4
BBC Cable Replacement .....	5-6
Traction Bail Replacement.....	5-11
Traction Cable Replacement.....	5-12
Brake Cable Replacement .....	5-37
Parking Brake Lever Assembly Replacement .....	5-41
Handle Replacement .....	5-43

# General Information

Controls for this unit are Blade Brake Clutch (BBC) bail, traction bail and park brake. All controls are operated by cables. All cables should be routed, not kinked or put in a bind. BBC cable is adjusted on the idler arm and the anchor point is on the frame. Traction and park brake are adjusted at the bail.


BBC bail and cable must be adjusted to fully disengage for proper function of the blade brake. When the bail is engaged for the clutching belt it must travel enough to fully tension the belt. The spring on the BBC cable will slightly extend.

Traction cable and bail should be adjusted for full engagement of the transmission arm when the bail touches the handle. Over tensioning the transmission cable will cause the unit to drive when the bail is released.

Brake is adjusted to prevent the unit from rolling once the brake lever is set. Do not over adjust the brake cable this will put excessive wear on the brake.

# Service and Repairs

## Controls Assembly 1



g299363

**Figure 33**

- |                         |                       |
|-------------------------|-----------------------|
| 1. Parking Brake Cable  | 9. Curved Washer      |
| 2. Brake Lever          | 10. Brake Lever Mount |
| 3. Stepped Washer       | 11. BBC Lever Spring  |
| 4. Brake Actuation Link | 12. Stepped Bushing   |
| 5. Coated BBC Bail      | 13. BBC Lever         |
| 6. Traction Cable       | 14. Handle            |
| 7. Coated Traction Bail | 15. BBC Cable         |
| 8. Cable Anchor         | 16. Handle Support    |

# BBC Bail Replacement

## BBC Bail Removal


1. Park the machine on a level surface. Stop the engine and wait for all moving parts to stop. Shut the fuel off.
2. Remove the grass bagger assembly if attached.
3. Loosen the 1/4–20 inch nylock nut to carriage bolt. Pull the cable housing towards the bail to release tension on the cable.



g296942

**Figure 34**

- 
4. Remove the 1/4–20 inch shoulder bolt and nut securing the cable to the BBC bail. Remove the cable.



g302395

**Figure 35**

- 
5. Remove BBC bail by pushing inward on one side and lifting away from the handle assembly.

## BBC Bail Removal (continued)




g296943

Figure 36

---

## BBC Bail Installation

1. Install the BBC bail onto the handle assembly.



g296943

Figure 37



2. Install the cable. Install the 1/4–20 shoulder bolt and nut securing the cable to the BBC bail. Torque bolt and nut to  $75 \pm 5$  in-lbs. ( $8 \pm 1$  Nm).

## BBC Bail Installation (continued)



g302395

Figure 38



3. Tighten the 1/4–20 inch nylock nut to carriage bolt securing the cable guide clamp to the handle. Adjust the housing cable so that there is no slack in the cable. Torque nut to carriage bolt to  $40 \pm 7$  in-lbs. ( $4 \pm 1$  Nm).



g296942

Figure 39

## BBC Cable Replacement

### BBC Cable Removal

1. Park the machine on a level surface. Stop the engine and wait for all moving parts to stop. Shut the fuel off.
2. Remove the grass bagger assembly if attached.
3. Cut both zip ties on the handle.

## BBC Cable Removal (continued)

4. Loosen the 1/4–20 inch nylock nut to carriage bolt. Pull the cable housing towards the bail to release tension on the cable.



g296942

**Figure 40**

- 
5. Remove the 1/4–20 inch bolt and nut securing the cable to the BBC bail. Remove the cable.



g302395

**Figure 41**

- 
6. Remove the 4 (1/4–20 inch) taptite screws securing the front belt cover to the frame.
  7. Remove the 1/4–20 inch taptite screw securing the cable clamp to the main frame.


## BBC Cable Removal (continued)



g302425

**Figure 42**

- 
8. Remove the cable from the main frame.
  9. Unhook the spring from the BBC brake arm.



g305213


**Figure 43**

---

## BBC Cable Installation

1. Install the cable spring to the BBC brake arm.

## BBC Cable Installation (continued)



g305213

**Figure 44**

- 
2. Loosely install the 1/4–20 inch screw securing the cable to the main frame.



3. Install the cable. Install the 1/4–20 inch shoulder bolt and nut securing the cable to the BBC bail. Torque bolt and nut to  $75 \pm 5$  in-lbs. ( $8 \pm 1$  Nm).



g302395

**Figure 45**



4. Tighten the 1/4–20 inch nylock nut to carriage bolt securing the cable guide clamp to the handle. Adjust the housing cable so there is no slack in the cable. Torque nut to carriage bolt to  $40 \pm 7$  in-lbs. ( $4 \pm 1$  Nm).

## BBC Cable Installation (continued)



g296942

**Figure 46**

- 
5. Install zip ties securing the cable to the handle assembly.
  6. Install the cable to the main frame.
  7. Install the 1/4–20 inch taptite screw securing the cable clamp to the main frame. Torque screw to  $110 \pm 11$  in-lbs. ( $12 \pm 1$  Nm).



**Note:** Cable adjustment should be 1/4–3/8 spring stretch.



g302425

**Figure 47**


- 
8. Install the 4 (1/4–20 inch) taptite screws securing the belt cover to the frame. Torque bolts to  $110 \pm 11$  in-lbs. ( $12 \pm 1$  Nm).



# Traction Bail Replacement

## Traction Bail Removal

1. Park the machine on a level surface. Stop the engine and wait for all moving parts to stop. Shut the fuel off.
2. Remove the grass bagger assembly if attached.
3. Remove the 1/4–20 shoulder bolt and nut securing the cable to the traction bail.



g302449

**Figure 48**

- 
4. Remove traction bail by pushing inward on one side and lifting away from the handle assembly.



g302451

**Figure 49**

---

## Traction Bail Installation

1. Install the traction bail to the top hole of the handle assembly.

## Traction Bail Installation (continued)



g302451

Figure 50



2. Install the cable. Install the shoulder bolt and nut securing the cable to the traction bail. Torque shoulder bolt and nut to  $75 \pm 5$  in-lbs. ( $8 \pm 1$  Nm).



g302449

Figure 51

## Traction Cable Replacement

### Traction Cable Removal

1. Park the machine on a level surface and engage the parking brake. Stop the engine and wait for all moving parts to stop. Shut the fuel off.
2. Remove the grass bagger assembly if attached.
3. Using an appropriate lifting device, raise the rear of the machine off the ground.
4. Open and secure the rear cover.
5. Remove the 1/4–20 inch tap-tite screw securing the cover to the frame.

## Traction Cable Removal (continued)



g296174

**Figure 52**

- 
6. Remove the 4 (1/4–20 inch) taptite screws securing the front belt cover to the frame.




g296175

**Figure 53**

- 
7. Remove the 1/4–20 inch shoulder bolt and nut securing the cable to the traction bail.

## Traction Cable Removal (continued)



g302449

**Figure 54**

- 
8. Open the clamp, remove the cable from the clamp lock.



g302450

**Figure 55**

- 
9. Rotate the belt tensioner arm clockwise from the bottom side of the transmission.

## Traction Cable Removal (continued)



g302330

**Figure 56**

- 
- To remove belt tension, align the idler pulley with the access hole on the bottom side of the transmission. Insert a quarter inch screw driver.

**Note:** Screw driver needs to fit through access hole and the idler pulley slot securing the pulley into position.




g296176

**Figure 57**

- 
- Remove the transmission belt from the engine pulley.

**Note:** Access belt from the front of the mower.


## Traction Cable Removal (continued)



g302331

**Figure 58**

- 
12. Remove the belt from the rear of the mower.



g296178

**Figure 59**

- 
13. Using an appropriate lifting device, raise the rear of the machine off the ground.
  14. Set the rear height-of-cut to 5 inch.
  15. Using a 9/16 inch socket, remove the 2 nuts securing the wheels to the rear axles.
  16. Remove the T-30 screw securing the dust cover to the axle assembly.


## Traction Cable Removal (continued)



g297057

**Figure 60**

- 
17. Remove the mulch plug from the rear discharge.
  18. Remove the 5/16–18 inch nut on carriage bolt securing the spring bracket to the frame.




g297058

**Figure 61**

- 
19. Using snap ring pillars, remove the snap ring retaining the pinion gear from axle shaft.
- Note:** Inspect the pinion gear to wheel gear mesh for abnormal wear, broken teeth, and uneven wear. Replace pinion gear and wheel gear, if needed.


## Traction Cable Removal (continued)



g297059

**Figure 62**

- 
20. Remove the 5/16–18 inch bolt securing the axle bearing housing to the axle height-of-cut plate.




g297060

**Figure 63**

- 
21. While holding up the spring loaded height-of-cut handle, apply pressure to the back of the axle bearing housing assembly, separating from axle weldment.

## Traction Cable Removal (continued)



g297061

**Figure 64**

- 
22. Remove the 1–4–20 taptite screw securing the transmission cable guide mounting bolt to the frame.




g297062

**Figure 65**

- 
23. Remove the 1/4–20 inch bolt securing the parking brake to the transmission.

## Traction Cable Removal (continued)



g297064

**Figure 66**

- 
24. Move the parking brake caliper out of the way and secure.
  25. Remove the 2 Phillip head screws from the trailing shield to the main frame.



g297065

**Figure 67**


- 
26. Remove the 5/16–18 inch nut to carriage bolt on the LH side. Remove the RH 5/16–18 inch taptite screw to main frame securing the transmission assembly to the main housing.

## Traction Cable Removal (continued)



g297066

**Figure 68**  
Side



g297531

**Figure 69**  
Vertical

---

27. Slide transmission to the right. Line up RH side height-of-cut notch with bolt.

## Traction Cable Removal (continued)



g297894

**Figure 70**

- 
28. Remove the height-of-cut weldment from the chassis. Slide the LH side of the height-of-cut weldment first before the RH side.




g297895

**Figure 71**

- 
29. Center the transmission. Pinch the traction cable towards the transmission and rotate the front transmission and cable downward.


## Traction Cable Removal (continued)



g297896

**Figure 72**

- 
30. To remove the transmission from the frame, rotate the transmission upside down and slide the transmission to the right. Remove the transmission from the frame with the traction cable attached.




g298181

**Figure 73**

- 
31. Remove the torsion spring from the RH side axle shaft.

## Traction Cable Removal (continued)



g298182

**Figure 74**

- 
32. Using needle a nose plier, squeeze the cable anchor and remove cable anchor from the cable mount.



g298183

**Figure 75**

- 
33. Pull the cable and remove from the cable anchor mount.

## Traction Cable Removal (continued)



g298184

**Figure 76**

---

34. Remove the spring hook from the transmission clutch lever.



g298185

**Figure 77**


---

35. Cable should now be free from the chassis.

## Traction Cable Installation

1. Install the spring hook to the transmission clutch lever.

## Traction Cable Installation (continued)



g298185

**Figure 78**

- 
2. Install the cable to the cable anchor mount.



g298184

**Figure 79**

- 
3. Install the cable anchor to the cable mount.


## Traction Cable Installation (continued)



g298183

**Figure 80**

- 
4. Install the height-of-cut spring to the RH side axle shaft.



g298182

**Figure 81**

- 
5. Install the transmission to the frame with the traction cable attached.

## Traction Cable Installation (continued)




g298181

**Figure 82**

6. Rotate the front transmission and cable upward. Pinch the traction cable towards the transmission.

**Note:** Cable should lay on top of the deck and not be pinched between the transmission and deck housing.



g297896

**Figure 83**

7. Slide the RH side of the height-of-cut weldment first before the LH side. Install the height-of-cut weldment to the chassis.

## Traction Cable Installation (continued)



g297895

**Figure 84**

- 
8. Line up the RH side height-of-cut notch with bolt. Slide the transmission to the left.




g297894

**Figure 85**



9. Put anti-seize inside the axle bearing before sliding over the shaft. Install the axle bearing housing assembly over the axle. Line up the mounting hole on the bearing housing assembly to the weldment hole. Install the bearing retainers in the rear axle weldment and rear height-of-cut plate for alignment purposes before securing the transmission to the frame. Install the 5/16–18 inch bolt to the axle weldment. Torque bolt to  $160 \pm 16$  in-lbs. ( $18 \pm 2$  Nm).

## Traction Cable Installation (continued)




g297061

**Figure 86**



10. Install the LH 5/16–18 inch nut to carriage bolt and the RH 1/2 inch taptite screw to the main frame securing the transmission assembly to the main housing. Torque nut to Hcarriage bolt to  $140 \pm 5$  in-lbs. ( $16 \pm 0.5$  Nm).



g297531

**Figure 87**



11. Install the 2 Phillip head screws securing the trailing shield to the main frame. Torque screws to  $9 \pm 1$  in-lbs. (1 Nm).

## Traction Cable Installation (continued)




g297065

**Figure 88**



12. Install the 3/8 inch bolt securing the parking brake to the transmission. Torque bolt to  $85 \pm 15$  in-lbs. ( $9 \pm 2$  Nm).



g297064

**Figure 89**

13. Install the 1/4–20 taptite screw securing the transmission cable guard to the frame.

## Traction Cable Installation (continued)



g297062

**Figure 90**



14. Install the 5/16–18 inch bolt securing the axle bearing housing to the axle height-of-cut plate. Torque bolt to  $160 \pm 16$  in-lbs. ( $18 \pm 2$  Nm).

15. Using snap ring pillars, install the snap ring retaining the pinion gear to axle shaft.



g297059

**Figure 91**



16. Install the 5/16–18 inch nut on carriage bolt securing the spring bracket to the frame. Torque nut to  $115 \pm 15$  in-lbs. ( $13 \pm 2$  Nm).

## Traction Cable Installation (continued)



g297058

**Figure 92**

---

17. Install the mulch plug to the rear discharge.



18. Install the T-30 screw securing the dust cover to the axle assembly. Torque screw to  $55 \pm 5$  in-lbs. ( $6 \pm 1$  Nm).



g297057


**Figure 93**



19. Using a socket, install the 2 ( $3/8-16$ ) nylock nuts securing the wheels to the rear axles. Torque nuts to  $180 \pm 20$  in-lbs. ( $20 \pm 2$  Nm).

20. Install the belt trough the rear of the mower.

## Traction Cable Installation (continued)




g296178

**Figure 94**

- 
21. Install the transmission belt to the engine pulley.

**Note:** Access belt from the front of the mower.



g302331

**Figure 95**


- 
22. Install the transmission belt to the transmission pulley.

23. Using a 7/16 inch nut on the bottom of the transmission, release pressure on the quarter inch screw driver. Remove the quarter inch screw driver, allowing idler arm to put tension on the belt.



24. Install the cable. Install the shoulder bolt and nut securing the cable to the traction bail. Torque shoulder bolt and nut to  $75 \pm 5$  in-lbs. ( $8 \pm 1$  Nm).

## Traction Cable Installation (continued)



g302449

**Figure 96**



25. Tighten the 1/4–20 inch nylock nut to carriage bolt securing the cable guide clamp to the handle. Adjust the housing cable so there is no slack in the cable. Torque nut to carriage bolt to  $40 \pm 7$  in-lbs. ( $4 \pm 1$  Nm).



g296942

**Figure 97**



## Traction Cable Installation (continued)

26. Install the 4 (1/4–20 inch) taptite screws securing the belt cover to the frame. Torque bolts to  $110 \pm 11$  in-lbs. ( $12 \pm 2$  Nm).



g296175

**Figure 98**

- 
27. Install the 1/4–20 inch taptite screw securing the frame cover to the frame. Torque bolt to  $110 \pm 11$  in-lbs. ( $12 \pm 1$  Nm).



g296174

**Figure 99**

- 
28. Lower the rear cover.
  29. Using an appropriate lifting device, lower the rear of the machine to the ground.
  30. Turn the fuel on.

# Brake Cable Replacement

## Brake Cable Removal

1. Park the machine on a level surface. Stop the engine and wait for all moving parts to stop. Shut the fuel off.
2. Remove the grass bagger assembly if attached.
3. Cut the zip tie.
4. Loosen the 1/4–20 inch nut to the carriage bolt securing the cable to the bracket.



g298346

**Figure 100**

- 
5. Remove the carriage bolt and 1/4–20 inch nut securing the cable to the parking brake lever.



g298347

**Figure 101**

- 
6. Remove the 1/4–20 taptite screw securing the transmission cable guide to the frame.


## Brake Cable Removal (continued)



g297062

**Figure 102**

- 
7. Remove the 3/8 inch bolt securing the parking brake to the transmission.



g297064

**Figure 103**

- 
8. Remove the brake caliper from the frame.
  9. Remove the 5 mm Allen head bolt securing the cable to the caliper.

## Brake Cable Removal (continued)



g302936

**Figure 104**

- 
10. Remove the brake cable up through the main frame access hole.

## Brake Cable Installation



1. Thread brake cable through the main frame access hole.
2. Set cable length to 7–1/8 inch from cable clamp to end cable. Install the 5 mm Allen head bolt securing the cable to the caliper. Torque bolt to 43 in-lbs. ( $5 \pm 1$  Nm).



g302936

**Figure 105**



3. Install the brake caliper.
4. Install the 1/4–20 inch screw securing the parking brake to the transmission. Torque bolt to  $85 \pm 15$  ft-lbs. ( $10 \pm 2$  Nm).

## Brake Cable Installation (continued)

5. Install the 1/4–20 taptite screw securing the transmission cable guide to the frame.



g297062

**Figure 106**



6. Install the 1/4–20 inch shoulder bolt and 1/4–20 inch nylock nut securing the cable to the parking brake lever. Torque bolt and nut to  $75 \pm 5$  in-lbs. ( $8 \pm 1$  Nm).



g298347

**Figure 107**



7. Tighten the 1/4–20 inch nut to the carriage bolt securing the cable to the bracket. Torque bolt to  $40 \pm 7$  ft-lbs. ( $4 \pm 1$  Nm). Adjust housing cable so the machine rolls freely when parking brake is disengaged but stop machine from rolling when engaged.

## Brake Cable Installation (continued)



g298346

**Figure 108**

- 
8. Install zip ties securing the cable to the handle assembly.

## Parking Brake Lever Assembly Replacement

### Parking Brake Lever Assembly Removal

1. Park the machine on a level surface. Stop the engine and wait for all moving parts to stop. Shut the fuel off.
2. Remove the grass bagger assembly if attached.
3. Remove the 1/4–20 inch nylock nut to 1/4–20 inch carriage bolt securing the parking brake assembly to the handle.



g298358

**Figure 109**

- 
4. Remove the 5/16–18 inch nylock nut to 5/16–18 inch carriage bolt securing the parking brake assembly to the handle.

## Parking Brake Lever Assembly Removal (continued)



g298359

Figure 110

- 
5. Remove the parking brake assembly from the handle.



g298360

Figure 111

---

## Parking Brake Lever Assembly Installation



1. Install the parking brake assembly to the handle.
2. Install the 5/16–18 inch bolt/nut to carriage bolt securing the parking brake assembly to the handle. Torque nut to  $80 \pm 10$  in-lbs. ( $9 \pm 1$  Nm).

## Parking Brake Lever Assembly Installation (continued)



g298359

Figure 112



3. Install the 1/4–20 inch nylock nut to 1/4–20 carriage bolt securing the parking brake assembly to the handle. Torque nut to carriage bolt to  $40 \pm 7$  in-lbs. ( $4 \pm 1$  Nm).



g298358

Figure 113

## Handle Replacement

### Handle Removal

1. Park the machine on a level surface. Stop the engine and wait for all moving parts to stop. Shut the fuel off.
2. Remove the grass bagger assembly if attached.
3. Cut the zip tie.

## Handle Removal (continued)

4. Loosen the 1/4–20 inch nylock nut to 1/4–20 inch carriage bolt securing the brake cable to the bracket.



g298346

**Figure 114**

- 
5. Remove the carriage bolt and 1/4–20 inch nut securing the cable to the parking brake lever.



g298347

**Figure 115**

- 
6. Remove the 1/4–20 inch nylock nut to 1/4–20 carriage bolt securing the parking brake assembly to the handle.

## Handle Removal (continued)



g298358

**Figure 116**

- 
7. Remove the 5/16–18 inch nylock nut to 5/16–18 carriage bolt securing the parking brake assembly to the handle.



g298359

**Figure 117**

- 
8. Remove the parking brake assembly from the handle.

## Handle Removal (continued)



g298360

**Figure 118**

- 
9. Remove the 1/4–20 inch nylock nut to carriage bolt. Pull cable housing towards bail to gain slack in cable to release cable tension. Remove the cable clamp assembly from the handle.



g298489

**Figure 119**

- 
10. Remove the 1/4–20 inch shoulder bolt and nut securing the cable to the BBC bail. Remove the cable.

## Handle Removal (continued)



g302395

**Figure 120**

- 
11. Remove BBC bail by pushing inward on one side and lifting away from the handle assembly.



g296943

**Figure 121**

- 
12. Remove traction bail by pushing inward on one side and lifting away from the handle assembly.
  13. Remove the 5/16–18 inch nuts to 5/16–18 inch carriage bolt and 4 (2 per side) bolts with captured nuts securing the handle to the main frame.

## Handle Removal (continued)



g298491

Figure 122

- 
14. Remove handle assembly from the machine.



g298492

Figure 123

---

## Handle Installation



1. Install the handle assembly to the machine.
2. Install the 5/16–18 inch bolt/nuts to carriage bolt and 4 (2 per side) bolts with captured nuts. Torque nuts to  $80 \pm 10$  in-lbs. ( $9 \pm 1$  Nm). Torque bolt to frame to  $300 \pm 30$  in-lbs. ( $34 \pm 3$  Nm).

## Handle Installation (continued)



g298491

**Figure 124**

- 
3. Install the traction bail to the handle assembly.



g302451

**Figure 125**



- 
4. Install the cable. Install the bolt and nut securing the cable to the traction bail. Torque shoulder bolt and nut to  $75 \pm 5$  in-lbs. ( $9 \pm 1$  Nm).

## Handle Installation (continued)



g298490

**Figure 126**

- 
5. Install the BBC bail onto the handle assembly.



6. Install the cable. Install the 1/4–20 inch shoulder bolt and nut securing the cable to the BBC bail. Torque bolt and nut to  $75 \pm 5$  in-lbs. ( $9 \pm 1$  Nm).



g302395

**Figure 127**



7. Install the 1/4–20 inch nylock nut to carriage bolt securing the cable guide clamp to the handle. Torque nut to carriage bolt to  $40 \pm 7$  in-lbs. ( $4 \pm 1$  Nm). adjust housing cable.

## Handle Installation (continued)



g298489

**Figure 128**

- 
8. Install zip ties securing the cable to the handle assembly.
  9. Install the parking brake assembly to the handle.
  10. Install the 5/16–18 inch bolt/nut to carriage bolt securing the parking brake assembly to the handle. Torque bolt/nut to  $80 \pm 10$  in-lbs. ( $9 \pm 1$  Nm).



g298359

**Figure 129**

- 
11. Install the 1/4–20 inch nylock nut to 1/4–20 inch carriage bolt securing the parking brake assembly to the handle. Torque nut to carriage bolt to  $40 \pm 7$  in-lbs. ( $4 \pm 1$  Nm).



## Handle Installation (continued)



g298358

**Figure 130**



12. Install the 1/4–20 inch shoulder bolt and 1/4–20 inch nylock nut securing the cable to the parking brake lever. Torque bolt and nut to  $75 \pm 5$  in-lbs. ( $8 \pm 1$  Nm).



g298347

**Figure 131**



13. Tighten the 1/4–20 inch nut to the carriage bolt securing the cable to the bracket. Torque bolt to  $40 \pm 7$  in-lbs. ( $4 \pm 1$  Nm). Adjust housing cable so the machine rolls freely when the parking brake is disengaged but stop machine from rolling when engaged.

## Handle Installation (continued)



g298346

**Figure 132**

- 
14. Install zip ties securing the cable to the handle assembly.





## Table of Contents

General Information .....	6-2
Service and Repairs .....	6-3
BBC Belt Replacement .....	6-4
Transmission Belt Replacement.....	6-12
Engine Pulley Belt Guide Replacement.....	6-17

# General Information

There are 3 belts on this unit that will need minimal maintenance for proper function, 2 belts are for the blade drive and 1 is the transmission drive belt. Blade drive has a timing belt on the cutting deck and clutching belt from the engine to the deck. None of the belts on the machine require greasing.


The timing belt is installed so the blades are 90 degrees to each other. Maintenance consist of cleaning under the belt shield and tension adjustment of the idler pulley. Not maintaining tension (over tension and under tension), will cause the loss of material of the flat areas of belt and pulleys.

The BBC belt is tensioned by the bail and cable. See the Controls section.

The transmission belt is self-tensioning and has minimal maintenance.

# Service and Repairs

## Belts Assembly 1



g299420

**Figure 133**

- |                  |                      |
|------------------|----------------------|
| 1. BBC Belt      | 3. Transmission Belt |
| 2. Engine Pulley | 4. Belt Guide Rod    |

# BBC Belt Replacement

## BBC Belt Removal

1. Park the machine on a level surface and engage the parking brake. Stop the engine and wait for all moving parts to stop. Shut the fuel off.
2. Remove the grass bagger assembly if attached.
3. Using an appropriate lifting device, raise the rear of the machine off the ground.
4. Open and secure the rear cover.
5. Remove the 1/4–20 inch taptite screw securing the frame cover to the frame.



g296174

**Figure 134**

- 
6. Remove the 4 (1/4–20 inch) taptite screws securing the belt cover to the frame.



g296175

**Figure 135**

## BBC Belt Removal (continued)

7. Rotate the belt tensioner arm by turning the 7/16 inch nut on the bottom side of the transmission clockwise.



g302330

**Figure 136**

- 
8. Align the idler pulley with the access hole on the bottom side of the transmission to remove the belt tension. Insert a quarter inch screw driver.

**Note:** Screw driver needs to fit through access hole and the idler pulley slot securing the arm/pulley into position.




g296176

**Figure 137**

- 
9. Remove the transmission belt from the engine pulley.

**Note:** Access belt from the front of the mower.

## BBC Belt Removal (continued)




g302331

**Figure 138**

---

10. Remove the belt from the rear of the mower.



g296178

**Figure 139**

---

11. Remove the 2 (1/4–20 inch) taptite screws securing the front BBC belt guide to the bosses on the frame. Remove the belt guide.

## BBC Belt Removal (continued)



g296179

**Figure 140**

- 
12. Loosen the  $\frac{1}{2}$  inch nylock nut from the BBC idler arm pivot until flush with bottom bolt. Secure the topside of the bolt with a  $\frac{1}{2}$  inch wrench.

**Note:** Gain access through the front of the main frame, top side of the deck.




g296180

**Figure 141**

- 
13. Move the brake arm downwards to release from the pulley.

**Note:** Releases pulley pressure from belt.

## BBC Belt Removal (continued)



g302385

**Figure 142**

- 
14. Remove the BBC belt from the pulley.



g296181

**Figure 143**

- 
15. Remove the BBC belt from rear of the mower.

## BBC Belt Installation

1. Install the BBC belt through the rear of the mower.
2. Install the BBC belt to the engine pulley.
3. Install the BBC belt to the brake pulley.


## BBC Belt Installation (continued)



g296181

**Figure 144**

- 
4. Move the brake upwards to align with the pulley.



g302385


**Figure 145**



5. Tighten the 1/2 inch nylock nut to the BBC idler arm pivot. Secure the topside of the bolt with a 1/2 inch wrench. Torque nut and bolt to 200 ± 20 in-lbs. (22 ± 2 Nm).

**Note:** Access through the front side of the frame.

## BBC Belt Installation (continued)



g305213

Figure 146



6. Install the belt guide. Install the 2 (1/4–20 inch) taptite screws securing the front BBC belt guide to the bosses on the frame. Torque screws to  $110 \pm 11$  in-lbs. ( $12 \pm 2$  Nm).




g296179

Figure 147

7. Install the transmission belt through the rear of the mower.
8. Install the transmission belt to the engine pulley.  
**Note:** Access belt/engine pulley from the front of the mower.

## BBC Belt Installation (continued)



g302331

**Figure 148**

9. Install the transmission belt to the transmission pulley.
10. Using a 7/16 inch nut on the bottom of the transmission, release pressure on the quarter inch screw driver. Remove the quarter inch screw driver, allowing idler arm to put tension on the belt.
11. Reinstall the cable guide.
12. Install the 4 (1/4–20 inch) taptite screws securing the belt cover to the frame. Torque bolts to  $55 \pm 5$  in-lbs. ( $6 \pm 1$  Nm).



g296175

**Figure 149**



## BBC Belt Installation (continued)

13. Install the 1/4–20 inch taptite screw securing the frame access cover to the frame. Torque bolt to  $110 \pm 11$  in-lbs. ( $12 \pm 2$  Nm).



g296174

**Figure 150**

- 
14. Lower the rear cover.
  15. Using an appropriate lifting device, lower the rear of the machine to the ground.

## Transmission Belt Replacement

### Transmission Belt Removal

1. Park the machine on a level surface and engage the parking brake. Stop the engine and wait for all moving parts to stop. Shut the fuel off.
2. Remove the grass bagger assembly if attached.
3. Using an appropriate lifting device, raise the rear of the machine off the ground.
4. Open and secure the rear cover.
5. Remove the 1/4–20 inch taptite screw securing the access cover to the frame.

## Transmission Belt Removal (continued)



g296174

**Figure 151**

- 
6. Remove the 4 (1/4–20 inch) taptite screws securing the front cover to the frame.



g296175

**Figure 152**

- 
7. Rotate the belt tensioner arm clockwise from the bottom side of the transmission.

## Transmission Belt Removal (continued)



g302330

**Figure 153**

- 
- To remove belt tension, align the idler pulley with the access hole on the bottom side of the transmission. Insert a quarter inch screw driver.

**Note:** Screw driver needs to fit through access hole and the idler pulley slot securing the pulley/idler arm into position.




g296176

**Figure 154**

- 
- Remove the transmission belt from the engine pulley.

**Note:** Access belt from the front of the mower.


## Transmission Belt Removal (continued)



g302331

Figure 155

- 
10. Remove the belt from the rear of the mower.



g296178

Figure 156


---

## Transmission Belt Installation

1. Install the belt through the rear of the mower.
2. Install the transmission belt to the engine pulley.

**Note:** Access belt/engine pulley from the front of the mower.

## Transmission Belt Installation (continued)



g302331

**Figure 157**

3. Install the belt on the transmission pulley.
4. Using a 7/16 inch nut on the bottom of the transmission, release pressure on the quarter inch screw driver. Remove the quarter inch screw driver, allowing idler arm to put tension on the belt.
5. Install the 4 (1/4–20 inch) taptite screws securing the belt cover to the frame. Torque bolts to  $55 \pm 5$  in-lbs. ( $6 \pm 1$  Nm).



g296175

**Figure 158**

6. Install the 1/4–20 inch taptite screw securing the frame access cover to the frame. Torque bolt to  $110 \pm 11$  in-lbs. ( $12 \pm 2$  Nm).



## Transmission Belt Installation (continued)



g296174

**Figure 159**

- 
7. Lower the rear cover.
  8. Using an appropriate lifting device, lower the rear of the machine to the ground.

## Engine Pulley Belt Guide Replacement

### Engine Pulley Belt Guide Removal

1. Park the machine on a level surface and engage the parking brake. Stop the engine and wait for all moving parts to stop. Shut the fuel off.
2. Remove the grass bagger assembly if attached.
3. Using an appropriate lifting device, raise the rear of the machine off the ground.
4. Open and secure the rear cover.
5. Remove the 1/4–20 inch taptite screw securing the frame access cover to the frame.

## Engine Pulley Belt Guide Removal (continued)



g296174

**Figure 160**

- 
6. Remove the 4 (1/4–20 inch) taptite screws securing the belt cover to the frame.



g296175

**Figure 161**

- 
7. Rotate the belt tensioner arm by turning the 7/16 inch nut on the bottom side of the transmission clockwise.

## Engine Pulley Belt Guide Removal (continued)



g302330

**Figure 162**

- 
- To remove belt tension, align the idler pulley with the access hole on the bottom side of the transmission. Insert a quarter inch screw driver.

**Note:** Screw driver needs to fit through access hole and the idler pulley slot securing the pulley/idler arm into position.




g296176

**Figure 163**

- 
- Remove the transmission belt from the engine pulley.

**Note:** Access belt from the front of the mower.

## Engine Pulley Belt Guide Removal (continued)



g302331

**Figure 164**

---

10. Remove the belt through the rear of the mower.



g296178

**Figure 165**

---

11. Remove the 2 (1/4–20 inch) taptite screws securing the front BBC belt guide to the bosses on the frame. Remove the belt guide.

## Engine Pulley Belt Guide Removal (continued)




g296179

**Figure 166**

- 
12. Loosen the  $\frac{1}{2}$  inch nylock nut from the BBC idler arm pivot until flush with bottom bolt. Secure the topside of the bolt with a  $\frac{1}{2}$  inch wrench.

**Note:** Access through the front side of the frame.




g305213

**Figure 167**

- 
13. Move the brake arm downwards to release from pulley.

**Note:** Releasing pulley pressure from the belt.

## Engine Pulley Belt Guide Removal (continued)



g302385

**Figure 168**

- 
14. Remove the BBC belt from the pulley.



g296181

**Figure 169**

- 
15. Remove the BBC belt from rear of the mower.
  16. Remove the 2 (1/4–20 inch) taptite screws securing the guide to the frame.

**Note:** To remove front bolt, go through the access hole in the deck with a 10 (3/8 inch) drive extension and a 3/8 inch socket with a universal joint.

## Engine Pulley Belt Guide Removal (continued)



g296180

**Figure 170**

- 
17. Remove the belt guide.
  18. Replace engine pulley belt guide.

## Engine Pulley Belt Guide Installation

1. Using a 6 inch long, quarter inch drive extension and a 1/2 inch deep well socket, put the extension in the access hole with socket off. Then from the back side reinstall the socket to extension (hole is only large enough for extension). Place the socket on top of the extension on the top of the deck



g296180

**Figure 171**




2. Install the 2 (1/4–20 inch) taptite screws securing the belt guide and guide to the machine. Torque  $80 \pm 10$  in-lbs. ( $9 \pm 1$  Nm).

## Engine Pulley Belt Guide Installation (continued)

**Note:** To install the front bolt, go through the access hole in the deck with a 10 (3/8 inch) drive extension and a 3/8 inch socket with a universal joint.


3. Install the BBC belt through the rear of the mower.



g296178

**Figure 172**

4. Install the BBC belt to the engine pulley.
5. Install the BBC belt to the BBC brake pulley.




g296181

**Figure 173**

6. Move the brake arm upwards to engage the belt with the idler pulley.

## Engine Pulley Belt Guide Installation (continued)



g302385

Figure 174



7. Tighten the  $\frac{1}{2}$  inch nylock nut to the BBC idler arm pivot. Secure the topside of the bolt with a  $\frac{1}{2}$  inch wrench. Torque nut and bolt to  $200 \pm 20$  in-lbs. ( $22 \pm 2$  Nm).



8. Install the belt guide. Install the 2 ( $\frac{1}{4}$ -20 inch) taptite screws securing the front BBC belt guide to the bosses on the frame. Torque bolts to  $110 \pm 11$  in-lbs. ( $12 \pm 2$  Nm).




g296179

Figure 175

9. Install the transmission belt to through rear of the mower.
10. Install the transmission belt to the engine pulley.

**Note:** Access belt/engine pulley from the front of the mower.

## Engine Pulley Belt Guide Installation (continued)



g302331

**Figure 176**

11. Install the transmission belt to the transmission pulley.
12. Using a 7/16 inch nut on the bottom of the transmission, release pressure on the quarter inch screw driver. Remove the quarter inch screw driver, allowing idler arm to put tension on the belt.
13. Install the 4 (1/4–20 inch) taptite screws securing the belt cover to the frame. Torque bolts to  $55 \pm 5$  in-lbs. ( $6 \pm 1$  Nm).



g296175

**Figure 177**

14. Install the 1/4–20 inch taptite screw securing the frame cover to the frame. Torque bolt to  $110 \pm 11$  in-lbs. ( $12 \pm 2$  Nm).



## Engine Pulley Belt Guide Installation (continued)



g296174

**Figure 178**

- 
15. Lower the rear cover.
  16. Using an appropriate lifting device, lower the rear of the machine to the ground.





## Table of Contents


General Information .....	7-2
Service and Repairs .....	7-3
Deck Replacement.....	7-6
Height-of-Cut Replacement .....	7-26
Front Bumper Replacement.....	7-55
Blade Drive Assembly Replacement.....	7-63
Door and Chute Assembly Replacement .....	7-77
Blade Break Arm Replacement.....	7-83

# General Information

Deck is constructed to side discharge, mulch and bag. Unit has 2 blades that utilize a sheer pin driver to protect the deck from damage in the event of the blade impacting an object. Only maintenance needed is occasional cleaning of the underside of the deck.

# Service and Repairs

## Deck Assembly 1




g299472

**Figure 179**

- |                           |                    |
|---------------------------|--------------------|
| 1. Belt Cover             | 12. Control Baffle |
| 2. Access Door            | 13. Door Handle    |
| 3. Chute                  | 14. Rear Door Asm. |
| 4. Mulch Plug             | 15. Bumper         |
| 5. Traction Cable Bracket | 16. Seal Clip      |
| 6. Frame Cover            | 17. Torsion Spring |
| 7. Button Plug            | 18. Retaining Ring |
| 8. 30 Inch Frame          | 19. Hinge Pin      |
| 9. Trailing Shield        | 20. Hinge Bracket  |
| 10. 30 Inch Deck          | 21. Door Seal      |
| 11. ExMark 30 Inch Deck   |                    |

## Deck Assembly 2




g299485

**Figure 180**

- |                         |                            |
|-------------------------|----------------------------|
| 1. Synchronous Belt     | 11. RH Spindle Shaft       |
| 2. Spindle Belt Guide   | 12. Blade Adapter          |
| 3. Spindle Brake Pulley | 13. Rotary Blade           |
| 4. Button Plug          | 14. LH Spindle Shaft       |
| 5. Sprocket Asm.        | 15. Idler Pulley           |
| 6. Flat Idler Pulley    | 16. Brake Extension Spring |
| 7. Idler Bracket        | 17. Brake Spacer           |
| 8. Bore Adapter         | 18. Brake Arm Asm.         |
| 9. Spindle Asm.         | 19. Coolant Hose           |
| 10. Flat Spring         |                            |

## Deck Assembly 3



g299487

**Figure 181**

- |                              |                   |
|------------------------------|-------------------|
| 1. Side Discharge Chute Asm. | 4. Torsion Spring |
| 2. Discharge Cover           | 5. Spacer         |
| 3. Hinge                     |                   |

# Deck Replacement

## Deck Removal

1. Park the machine on a level surface and engage the parking brake. Stop the engine and wait for all moving parts to stop. Shut the fuel off.
2. Remove the grass bagger assembly if attached.
3. Using an appropriate lifting device, raise the rear of the machine off the ground.
4. Open and secure the rear cover.
5. Remove the 1/4–20 inch taptite screw securing the cover to the frame.



g296174

**Figure 182**

- 
6. For Kawasaki engines, remove the 4 (1/4–20 inch) taptite screws securing the front cover to the frame. For Kohler engines, remove the 3 (1/4–20 inch) taptite screws and christmas tree clip securing the front cover to the frame.



g296175

**Figure 183**

## Deck Removal (continued)

7. Rotate the belt tensioner arm by using a 7/16 inch socket on the nut at the bottom side of the transmission, turning clockwise.



g302330

**Figure 184**

- 
8. To remove belt tension, align the idler pulley with the access hole on the bottom side of the transmission. Insert a quarter inch screw driver.

**Note:** Screw driver needs to fit through access hole and the idler pulley slot securing the pulley into position.




g296176

**Figure 185**

- 
9. Remove the transmission belt from the engine pulley.

**Note:** Access belt from the front of the mower.

## Deck Removal (continued)




g302331

**Figure 186**

---

10. Remove the belt from the rear of the mower.



g296178

**Figure 187**

---

11. Remove the 2 (1/4–20) taptite screws securing the front BBC belt guide to the bosses on the frame. Remove the belt guide.


## Deck Removal (continued)



g296179

**Figure 188**

- 
12. From the front, loosen the 5/16–18 inch nylock nut from the BBC idler arm pivot until flush with bottom bolt. Secure the topside of the bolt with a ½ inch wrench.




g305213

**Figure 189**

- 
13. Move the brake arm downwards to release from pulley.

**Note:** Releasing pulley pressure from the belt.

## Deck Removal (continued)



g302385

**Figure 190**

- 
14. Remove the BBC belt from the pulley.




g296181

**Figure 191**

- 
15. Remove the BBC belt from rear of the mower.
  16. Remove the belt tension (5/16–18 inch) bolt and nut to relieve tension from the blade timing belt.

## Deck Removal (continued)




g298542

**Figure 192**

- 
17. Remove the 2 (1/2–20) inch nut from the BBC pulley. Pull the BBC brake pulley off the left side spindle.

**Note:** Secure blade with a wood block.




g298543

**Figure 193**

- 
18. Remove both dust covers and idler pulleys from the main frame.
  19. Remove the 5/16–18 inch bolt securing the fixed idler pulley to the frame.


## Deck Removal (continued)



g298544

**Figure 194**

- 
20. Remove the 5/16–18 inch bolt securing the idler pulley to the belt tension assembly.




g304130

**Figure 195**

- 
21. Remove the blade timing belt from the spindle pulleys.
  22. Remove the 2 (1/4–20 inch) shoulder bolts securing the tension idler bracket from the frame.

## Deck Removal (continued)



g298545

**Figure 196**

---

23. Remove the 2 sprocket pulleys and BBC pulley from the spindle assembly.

24. Remove blade and spindle shaft from spindle hub.

**Note:** Spindle shaft and blade will drop out of the bottom side of the machine.



g298546

**Figure 197**

---

25. Remove the 8 (5/16–18 inch) tapite screws securing spindle hub assembly to the main frame.

## Deck Removal (continued)



g298547

**Figure 198**

- 
26. Remove the 2 (1/2 inch) nuts to carriage bolts securing the deck shell to the main frame.



g304131

**Figure 199**

- 
27. Remove the deck shell from the main frame.

**Note:** Image shows the front bumper removed.

## Deck Removal (continued)



g298548

**Figure 200**

---

## Deck Disassembly

1. Pull up on the spring latch and remove the discharge cover.



g298549

**Figure 201**

2. Remove the 2 (5/16–18 inch) carriage bolts securing the spring latch to the deck shell.

## Deck Disassembly (continued)



g298613

**Figure 202**

3. Remove the 5/16–18 inch nut and bolt securing the spring bushing to the spring bracket.



g304132

**Figure 203**

## Deck Assembly



1. Install the 5/16–18 inch bolt and flange nut securing the spring bushing to the spring bracket. Torque nut and bolt to  $200 \pm 20$  in-lbs. ( $22 \pm 2$  Nm).

## Deck Assembly (continued)




g298614

**Figure 204**



2. Install the 2 (5/16–18 inch) bolt and nut securing the spring latch to the deck shell. Torque screw to  $25 \pm 3$  in-lbs. ( $2.8 \pm 0.4$  Nm).



g298613

**Figure 205**

3. Install the discharge cover.

## Deck Assembly (continued)



g298549

Figure 206

---

## Deck Installation

1. Install the deck shell to the main frame.



g298548

Figure 207



2. Install the 2 (5/16–18 inch) nuts to carriage bolts securing the deck shell to the main frame. Torque bolts to 200 in-lbs. (22.6 Nm).

**Note:** Bolt is installed from the bottom and the nut from on top.

## Deck Installation (continued)



g304131

**Figure 208**



3. Install the 8 (5/16–18 inch) bolts securing spindle hub assembly to the main frame. Torque bolts to  $160 \pm 16$  in-lbs. ( $18 \pm 2$  Nm).



g298547

**Figure 209**

4. Install the blade and spindle shaft to the spindle hub.


## Deck Installation (continued)



g298546

**Figure 210**

- 
5. Install the 2 sprocket pulleys and BBC pulley to the spindle assembly.
  6. Loosely install the 1/2–20 nut to spindle shaft.
  7. Install the 2 (1/4–20 inch) shoulder bolts securing the tension idler bracket to the frame. Torque bolts to 110 ± 11 in-lbs. (12 ± 2 Nm).




g298545

**Figure 211**

- 
8. Install the blade timing belt to the spindle pulleys.  
**Note:** Blades need to be timed 90 degrees apart.
  9. Install the 5/16–18 bolt securing the idler pulley to the belt tension assembly. Torque bolt to 160 ± 16 ft-lbs. (18 ± 2 Nm).



## Deck Installation (continued)




g298544

Figure 212



10. Install the 5/16–18 inch bolt securing the fixed idler pulley to the frame. Torque bolt to 160 ± 16 in-lbs. (18 ± 2 Nm).



g298544


Figure 213



11. Install both dust covers and idler pulleys to the main frame.
12. Tighten the 2 (1/2–20 inch) nuts to the spindle pulleys. Torque nut to 60 ± 5 ft-lbs. (81.3 ± 6.7 Nm).

**Note:** Secure blade with a wood block.

## Deck Installation (continued)




g298543

**Figure 214**



13. Install the belt tension 5/16–18 inch bolt and nut to tension the blade timing belt. Tighten bolt until there is 0.010–0.030 gap between the spring washer and frame for proper belt tension.



g298542

**Figure 215**

14. Install the BBC belt through the rear of the mower.
15. Install the BBC belt around the engine pulley.
16. Install the BBC belt around the brake pulley.


## Deck Installation (continued)



g296181

**Figure 216**

- 
17. Move the brake arm upwards to secure the pulley.



g302385


**Figure 217**



18. Secure the topside of the bolt with a ½ inch wrench. Torque nut and bolt to 200 ± 20 in-lbs. (22 ± 2 Nm).

**Note:** Access the bottom nut from the front of the machine.

## Deck Installation (continued)



g305213

Figure 218



19. Install the belt guide. Install the 2 (1/4–20 inch) taprite screws securing the front BBC belt guide to the bosses on the frame. Torque bolts to  $110 \pm 11$  in-lbs. ( $12 \pm 2$  Nm).




g296179

Figure 219

20. Install the belt to the rear of the mower.
21. Install the transmission belt to the engine pulley.

**Note:** Access belt/engine pulley from the front of the mower.

## Deck Installation (continued)



g302331

**Figure 220**

22. Install the transmission belt to the transmission pulley.
23. Using a 7/16 inch socket on the bottom of the transmission, release pressure on the quarter inch screw driver. Remove the quarter inch screw driver, allowing the idler arm to put tension on the belt.



24. Install the 4 (1/4–20 inch) taptite screws securing the belt cover to the frame. Torque screws to 55 ± 5 in-lbs. (6 ± 1 Nm).



g296175

**Figure 221**



25. Install the 1/4–20 inch taptite screw securing the frame cover to the frame. Torque bolt to 110 ± 11 in-lbs. (12 ± 2 Nm).

## Deck Installation (continued)



g296174

**Figure 222**

- 
26. Lower the rear cover.
  27. Using an appropriate lifting device, lower the rear of the machine to the ground.

## Height-of-Cut Replacement

### Height-of-Cut Removal

1. Park the machine on a level surface and engage the parking brake. Stop the engine and wait for all moving parts to stop. Shut the fuel off.
2. Remove the grass bagger assembly if attached.
3. Using an appropriate lifting device, raise the rear of the machine off the ground.
4. Open and secure the rear cover.
5. Remove the 1/4–20 inch taptite screw securing the cover to the frame.

## Height-of-Cut Removal (continued)



g296174

**Figure 223**

- 
6. Remove the 4 (1/4–20 inch) taptite screws securing the front cover to the frame.



g296175

**Figure 224**

- 
7. Rotate the belt tensioner arm by using a 7/16 inch socket on the nut at the bottom side of the transmission, turning clockwise.

## Height-of-Cut Removal (continued)



g302330

**Figure 225**

- 
- To remove belt tension, align the idler pulley with the access hole on the bottom side of the transmission. Insert a quarter inch screw driver.

**Note:** Screw driver needs to fit through access hole and the idler pulley slot securing the pulley into position.




g296176

**Figure 226**

- 
- Remove the transmission belt from the engine pulley.

**Note:** Access belt from the front of the mower.

## Height-of-Cut Removal (continued)




g302331

**Figure 227**

---

10. Remove the belt from the rear of the mower.




g296178

**Figure 228**

- 
11. Using an appropriate lifting device, lower the rear of the machine onto the ground.
  12. Set the rear height-of-cut to 5 inch.
  13. Using a 9/16 inch socket, remove the 2 nuts securing the wheels to the rear axles.
  14. Remove the T-30 screw securing the dust cover to the axle assembly.


## Height-of-Cut Removal (continued)



g297057

**Figure 229**

- 
15. Remove the 5/16–18 inch nut on carriage bolt securing the spring bracket to the frame.



g297058

**Figure 230**

- 
16. Using snap ring pillars, remove the snap ring retaining the pinion gear from axle shaft.

**Note:** Inspect the pinion gear to wheel gear mesh for abnormal wear, broken teeth, and uneven wear. Replace pinion gear to wheel gear mesh if needed.


## Height-of-Cut Removal (continued)



g297059

**Figure 231**

- 
17. Remove the 5/16–18 inch bolt securing the axle bearing housing to the axle height-of-cut plate.




g297060

**Figure 232**

- 
18. While holding up the spring loaded height-of-cut handle, apply pressure to the back of the axle bearing housing assembly, separating from axle weldment.

## Height-of-Cut Removal (continued)



g297061

**Figure 233**

- 
19. Using a 3/8 inch socket, remove the bolt securing the transmission cable guard and parking brake mount bolt to the frame.




g297062

**Figure 234**

- 
20. Remove the 1/4–20 inch bolt securing the parking brake to the transmission.

## Height-of-Cut Removal (continued)



g297064

**Figure 235**

---

21. Remove the 2 Phillip head screws from the trailing shield to the main frame.



g297065

**Figure 236**

---


22. Remove the 5/16–18 inch nut to carriage bolt on LH side. Remove the RH 5/16–18 inch taptite screw to main frame securing the transmission assembly to the main housing.

## Height-of-Cut Removal (continued)



g297066

**Figure 237**



g297531

**Figure 238**

---

23. Slide transmission to the right. Line up RH side height-of-cut notch with bolt.

## Height-of-Cut Removal (continued)



g297894

**Figure 239**

- 
24. Remove the height-of-cut weldment from the chassis. Slide the LH side of the height-of-cut weldment first before the RH side.




g297895

**Figure 240**

- 
25. Center the transmission. Pinch the traction cable towards the transmission and rotate the front transmission and cable downward.

## Height-of-Cut Removal (continued)



g297896

**Figure 241**

- 
26. To remove the transmission from the frame, rotate the transmission upside down and slide the transmission to the right. Remove the transmission from the frame with the traction cable attached.




g298181

**Figure 242**

- 
27. Remove the torsion spring from the RH side axle shaft.

## Height-of-Cut Removal (continued)



g298182

**Figure 243**

- 
28. Using needle nose plier, squeeze the cable anchor and remove cable anchor from the cable mount.



g298183

**Figure 244**

- 
29. Pull the cable and remove from the cable anchor mount.

## Height-of-Cut Removal (continued)



g298184

**Figure 245**

---

30. Remove the spring hook from the transmission clutch lever.



g298185

**Figure 246**

---

31. Remove the 6 (5/16–18 inch) nuts to carriage bolts securing the engine cage to chassis.

## Height-of-Cut Removal (continued)



g298693

**Figure 247**

- 
32. Remove the handle from the machine.
  33. Remove the 2 (5/16–18 inch) bolts on the RH side of the height-of-cut plate.



g298694

**Figure 248**

- 
34. Remove the height-of-cut plate from the main frame.
  35. Remove the height-of-cut adjustment spring.

**Note:** Spring is inside the frame.

## Height-of-Cut Removal (continued)



g298697

**Figure 249**

---

36. Remove the upper T-30 torx screw from the LH height adjuster handle.



g298695

**Figure 250**

---

37. Remove the washer between lever and plate.

38. Remove the 2 (5/16–18 inch) bolts securing LH height-of-cut plate to the main frame.

## Height-of-Cut Removal (continued)




g298696

**Figure 251**

---

## Height-of-Cut Disassembly

Remove the T-30 bolt from 5/16–18 inch nylock height lock adjustment.



g298698

**Figure 252**

---

## Height-of-Cut Assembly



Install the T-30 bolt to the 5/16–18 inch nylock height lock adjustment. Torque bolt to  $160 \pm 16$  in-lbs. ( $18 \pm 2$  Nm).

## Height-of-Cut Installation



1. Install the 2 (5/16–18 inch) bolts securing LH height-of-cut plate to the main frame. Torque bolts to  $160 \pm 16$  in-lbs. ( $18 \pm 2$  Nm).



g298696

**Figure 253**

- 
2. Install the washer between the lever and plate.



3. Install the upper T-30 torx screw to the LH height adjuster handle. Torque screw to  $160 \pm 16$  in-lbs. ( $18 \pm 2$  Nm).



g298695

**Figure 254**

- 
4. Install the height-of-cut adjustment spring.

## Height-of-Cut Installation (continued)



g298697

**Figure 255**

- 
5. Install the height-of-cut plate to the main frame.

**Note:** The spring is inside the frame.



6. Install the 2 (5/16–18 inch) bolts on the RH side of the height-of-cut plate. Torque bolts to  $160 \pm 16$  in-lbs. ( $18 \pm 2$  Nm).



g298694

**Figure 256**

- 
7. Install the engine cage to the chassis.



8. Install the 6 (5/16–18 inch) nuts to carriage bolt securing the engine cage to chassis. Torque nuts to  $140 \pm 15$  in-lbs. ( $15.8 \pm 1.7$  Nm).

## Height-of-Cut Installation (continued)



g298693

**Figure 257**

- 
9. Install the spring hook to the transmission lever.



g298185

**Figure 258**

- 
10. Install the cable to the cable anchor mount.

## Height-of-Cut Installation (continued)



g298184

**Figure 259**

---

11. Using needle a nose plier, install the cable anchor to the cable mount.




g298183

**Figure 260**

---

12. Install the height-of-cut spring to the RH side axle shaft.

## Height-of-Cut Installation (continued)




g298182

**Figure 261**

---

13. Install the transmission to the frame with the traction cable attached.




g298181

**Figure 262**

---

14. Rotate the front transmission and cable upward. Pinch the traction cable towards the transmission.

## Height-of-Cut Installation (continued)



g297896

**Figure 263**

- 
15. Slide the RH side of the height-of-cut weldment first before the LH side. Install the height-of-cut weldment to the chassis.



g297895

**Figure 264**

- 
16. Line up the RH side height-of-cut notch with bolt. Slide the transmission to the left.

## Height-of-Cut Installation (continued)




g297894

**Figure 265**



17. Put anti-seize inside the axle bearing before sliding over the shaft. Install the axle bearing housing assembly over the axle. Line up the mounting hole on the bearing housing assembly to the weldment hole. Install the bearing retainers into the rear axle weldment and rear height-of-cut plate for alignment purposes before securing the transmission to the frame. Install the 5/16–18 inch bolt to the axle weldment. Torque bolt to  $160 \pm 16$  in-lbs. ( $18 \pm 2$  Nm).




g297061

**Figure 266**



18. Install LH 5/16–18 inch nut to carriage bolt and the RH 5/16–18 inch taptite screw to the main frame securing the transmission assembly to the main housing. Torque nut to carriage bolt to  $140 \pm 5$  in-lbs. ( $16 \pm 0.5$  Nm). Torque taptite screw to  $160 \pm 16$  in-lbs. ( $18 \pm 2$  Nm).

## Height-of-Cut Installation (continued)



g297531

**Figure 267**



g297066

**Figure 268**



19. Install the 2 Phillip head screws securing the trailing shield to the main frame. Torque screws to  $9 \pm 1$  in-lbs. (1 Nm).

## Height-of-Cut Installation (continued)




g297065

**Figure 269**



20. Install the 1/4–20 inch bolt securing the parking brake to the transmission. Torque bolt to  $85 \pm 15$  in-lbs. ( $9 \pm 2$  Nm).



g297064

**Figure 270**

21. Install the 1/4–20 taptite screw securing the transmission cable guide to the frame.

## Height-of-Cut Installation (continued)



g297062

**Figure 271**

- 
22. Using snap ring pillars, Install the snap ring retaining the pinion gear to axle shaft.



g297059

**Figure 272**



- 
23. Install the 5/16–18 inch nut on carriage bolt securing the spring bracket to the frame. Torque nut to 115 ± 15 in-lbs. (13 ± 2 Nm).

## Height-of-Cut Installation (continued)



g297058

**Figure 273**

---

24. Install the mulch plug to the rear discharge.



25. Install the T-30 screw securing the dust cover to the axle assembly. Torque screw to  $55 \pm 5$  in-lbs. ( $6 \pm 1$  Nm).



g297057


**Figure 274**



26. Using a socket, install the 2 ( $3/8$ -16 inch) nuts securing the wheels to the rear axles. Torque nuts to  $180 \pm 20$  in-lbs. ( $20 \pm 2$  Nm).

27. Install the belt through the rear of the mower.

## Height-of-Cut Installation (continued)




g296178

**Figure 275**

---

28. Install the transmission belt to the engine pulley.

**Note:** Access belt from the front of the mower.



g296177

**Figure 276**

---

29. Install the transmission belt to the transmission pulley.

30. Using a 7/16 inch socket on the bottom of the transmission, release pressure on the quarter inch screw driver. Remove the quarter inch screw driver, allowing idler arm to put tension on the belt.

31. Install the belt to the input pulley on the transmission.



32. Install the 4 (1/4–20 inch) taptite screws securing the belt cover to the frame. Torque bolts to 55 ± 5 in-lbs. (6 ± 1 Nm).

## Height-of-Cut Installation (continued)



g296175

**Figure 277**



33. Install the 1/4–20 inch taprite screw securing the frame cover to the frame. Torque bolt to  $110 \pm 11$  in-lbs. ( $12 \pm 2$  Nm).



g296174

**Figure 278**

34. Lower the rear cover.
35. Using an appropriate lifting device, lower the rear of the machine to the ground.
36. Reinstall the cable guide.

# Front Bumper Replacement

## Front Bumper Removal

1. Park the machine on a level surface and engage the parking brake. Stop the engine and wait for all moving parts to stop. Shut the fuel off.
2. Remove the grass bagger assembly if attached.
3. Move the front axle height-of-cut to 5 inches.
4. Place wood blocks under the deck assembly to support the deck.
5. Remove the 4 (5/16–18 inch) (2 per side) nuts to carriage bolts securing engine guard to front bumper assembly.



g298855

**Figure 279**

- 
6. Remove the 4 (5/16–18 inch) center nuts to carriage bolts securing the front bumper assembly to the deck assembly.



g298856

**Figure 280**

- 
7. Remove the front axle assembly from the deck.

## Front Bumper Removal (continued)



g298858

Figure 281

---

## Front Bumper Disassembly

1. Roll the front bumper assembly over.
2. Using a 9/16 inch socket and wrench, remove 3/8–16 inch nut from 3/8–16 inch bolt securing the front wheels to the axle.




g298895

Figure 282

3. Remove the 4 (1/4–20 inch) bolts to captured nuts on the two piece axle bushings.


**Note:** Remove the 2 furthest forward bolts first.

## Front Bumper Disassembly (continued)



g298896

**Figure 283**



g298897

**Figure 284**

4. Remove the 4 bushings from the axle.
5. Roll the front bumper assembly over.




**CAUTION**



**The spring is loaded.**

6. Depress the height-of-cut lockout lever and rotate axle forward releasing spring tension.


## Front Bumper Disassembly (continued)



g298898

**Figure 285**

7. Depress the height-of-cut lockout lever and rotate axle forward releasing spring tension.
8. Apply downward pressure on the spring mandrell to remove the mandrell from the spring.



g298899

**Figure 286**

9. Remove the 3/16 inch allen head screw securing the spring to the front bumper assembly.
10. Remove the 5/16–18 inch bolt and nut securing the height-of-cut/lockout lever to the front bumper.

## Front Bumper Disassembly (continued)




g298900

**Figure 287**

- 
11. Squeeze the height-of-cut/lockout lever and remove the 5/16–18 inch bolt from the front bumper assembly.

## Front Bumper Assembly

1. Place the spring onto the front bumper assembly. Loosely install the 3/16 inch allen head screw.




g298901

**Figure 288**

- 
2. Install the axle weldment onto the front bumper assembly.
  3. Place one end of the spring onto the axle weldment, install the mandrell, and then place the opposite end of the spring onto the axle weldment.

## Front Bumper Assembly (continued)




g298929

**Figure 289**



4. Tighten the 3/16 inch Allen head screw. Torque to  $140 \pm 15$  in-lbs. ( $15.8 \pm 1.7$  Nm).




g298930

**Figure 290**

5. Roll the front bumper assembly over.
6. Squeeze the lever and rotate the front axle height-of-cut until aligned with the 5 inch mark.

## Front Bumper Assembly (continued)



g298931

**Figure 291**

7. Slightly raise the axle weldment and install bushing on the bottom for the non-height-of-cut side of the axle weldment. Install the other bushing for the top of the non-height-of-cut side of the axle weldment. Install the (7/16 inch) bolt and nut securing the bushing to the axle weldment until finger tight, do not fully tighten fastener. Repeat for opposite side.

**Note:** Install the 5/16–18 inch bolts in the following order:

Non-height-of-cut lower 5/16–18 inch bolt and nut

Height-of-cut lower 5/16–18 inch bolt and nut

Height-of-cut upper 5/16–18 inch bolt and nut

Non-height-of-cut upper 5/16–18 inch bolt and nut



g298928

**Figure 292**



8. Install the 5/16–18 inch bolt and nut to both ends of the front bumper assembly. Torque all bolts to  $140 \pm 5$  in-lbs. ( $15.8 \pm 0.5$  Nm).

## Front Bumper Installation

1. Install the front axle assembly to the deck.



g298858

Figure 293



2. Install the 4 (5/16–18 inch) center nuts to carriage bolts securing the front bumper assembly to the deck assembly. Torque center nuts to carriage bolts to  $140 \pm 5$  in-lbs. ( $15.8 \pm 0.5$  Nm).



g298856

Figure 294



3. Install the 4 (5/16–18 inch) (2 per side) nuts to carriage bolts securing engine guard to front bumper assembly. Torque nuts to carriage bolts to  $140 \pm 5$  in-lbs. ( $15.8-0.5$  Nm).

## Front Bumper Installation (continued)



g298854

**Figure 295**

---

## Blade Drive Assembly Replacement

### Blade Drive Assembly Removal

1. Park the machine on a level surface and engage the parking brake. Stop the engine and wait for all moving parts to stop. Shut the fuel off.
2. Remove the grass bagger assembly if attached.
3. Using an appropriate lifting device, raise the rear of the machine off the ground.
4. Open and secure the rear cover.
5. Remove the 1/4–20 inch taptite screw securing the cover to the frame.



g296174

**Figure 296**

## Blade Drive Assembly Removal (continued)

6. Remove the 4 (1/4–20 inch) taptite screws securing the front cover to the frame.



g296175

**Figure 297**

- 
7. Rotate the belt tensioner arm by using a 7/16 inch socket on the nut at the bottom side of the transmission, turning clockwise.



g302330

**Figure 298**

- 
8. To remove belt tension, align the idler pulley with the access hole on the bottom side of the transmission. Insert a quarter inch screw driver.

**Note:** Screw driver needs to fit through access hole and the idler pulley slot securing the pulley into position.

## Blade Drive Assembly Removal (continued)




g296176

**Figure 299**

- 
9. Remove the transmission belt from the engine pulley.

**Note:** Access belt from the front of the mower.




g302331

**Figure 300**

- 
10. Remove the belt from the rear of the mower.

## Blade Drive Assembly Removal (continued)



g296178

**Figure 301**

- 
11. Remove the 2 (1/4–20 inch) taptite screws securing the front BBC belt guide to the bosses on the frame. Remove the belt guide.




g296179

**Figure 302**

- 
12. From the front, loosen the 5/16–18 inch nylock nut from the BBC idler arm pivot until flush with bottom bolt. Secure the topside of the bolt with a 1/2 inch wrench.

## Blade Drive Assembly Removal (continued)




g305213

**Figure 303**

---

13. Move the brake arm downwards to release from pulley.

**Note:** Releasing pulley pressure from the belt.




g302385

**Figure 304**

---

14. Remove the BBC belt from the pulley.


## Blade Drive Assembly Removal (continued)



g296181

**Figure 305**

- 
15. Remove the BBC belt from rear of the mower.
  16. Remove the belt tension (5/16–18 inch) bolt and nut to relieve tension from the blade timing belt.




g298542

**Figure 306**

- 
17. Remove the 2 (1/2–20 inch) nut from the BBC pulley. Pull the BBC brake pulley off the left side spindle.

**Note:** Secure blade with a wood block.


## Blade Drive Assembly Removal (continued)



g298543

**Figure 307**

- 
18. Remove both dust covers and idler pulleys from the main frame.
  19. Remove the 5/16–18 inch idler bolt securing the fixed idler pulley to the frame.




g298544

**Figure 308**

- 
20. Remove the blade timing belt from spindle pulleys.
  21. Remove the 2 (1/4–20 inch) shoulder bolts securing the tension idler bracket from the frame.

## Blade Drive Assembly Removal (continued)



g298545

**Figure 309**

---

22. Remove the 2 sprocket pulleys and BBC pulley from the spindle assembly.

23. Remove blade and spindle shaft from spindle hub.

**Note:** Spindle shaft and blade will drop out of the bottom side of the machine.



g298546

**Figure 310**

---

24. Remove the 8 (5/16–18 inch) taptite screws securing spindle hub assembly to the main frame.

## Blade Drive Assembly Removal (continued)



g298547

**Figure 311**

---

## Blade Drive Assembly Installation



1. Install the 8 (5/16–18 inch) taptite screws securing spindle hub assembly to the main frame. Torque bolts to  $160 \pm 16$  in-lbs. ( $18 \pm 2$  Nm).



g298547

**Figure 312**

- 
2. Install the blade and spindle shaft to the spindle hub.


## Blade Drive Assembly Installation (continued)



g298546

**Figure 313**

3. Install the 2 sprocket pulleys and BBC pulley to the spindle assembly.
4. Loosely install the 1/2–20 inch nuts to spindle shaft.
5. Install the 2 (1/4–20 inch) shoulder bolts securing the tension idler bracket to the frame. Torque bolts to 110 ± 11 in-lbs. (12 ± 2 Nm).




g298545

**Figure 314**

6. Install the blade timing belt to the spindle pulleys.  
**Note:** Blades need to be timed 90 degrees apart.
7. Install the 5/16–18 inch bolt securing the fixed idler pulley to the frame. Torque bolt to 160 ± 16 in-lbs. (18 ± 2 Nm).



## Blade Drive Assembly Installation (continued)



g298544

Figure 315


---

8. Install both dust covers and idler pulleys to the main frame.



9. Install the 2 (1/2–20 inch) nut to the BBC pulley. Pull the BBC pulley on the left side spindle. Torque nut to 60 ± 5 ft-lbs. (81.3 ± 6.7 Nm).

**Note:** Secure the blade with a wood block.



g298543

Figure 316

---


10. Install the belt tension 5/16–18 inch bolt and nut to tension the blade timing belt. Tighten bolt until there is 0.010–0.030 gap between the spring washer and frame for proper belt tension.

11. Install the BBC belt through the rear of the mower.

12. Install the BBC belt to the engine pulley.

13. Install the BBC belt to the brake pulley.


## Blade Drive Assembly Installation (continued)



g296181

**Figure 317**

- 
14. Move the brake arm upwards to secure the pulley.



g302385


**Figure 318**



15. Secure the topside of the bolt with a 1/2 inch wrench. Torque nut and bolt to  $100 \pm 15$  in-lbs. ( $11.3 \pm 1.7$  Nm).

**Note:** Access bottom nut from the front of the machine.

## Blade Drive Assembly Installation (continued)



g305213

Figure 319



16. Install the belt guide. Install the 2 (1/4–20 inch) taprite screws securing the front BBC belt guide to the bosses on the frame. Torque bolts to  $110 \pm 11$  in-lbs. ( $12 \pm 2$  Nm).




g296179

Figure 320

17. Install the belt to the rear of the mower.
  18. Install the transmission belt to the engine pulley.
- Note:** Access belt/engine pulley from the front of the mower.

## Blade Drive Assembly Installation (continued)



g302331

**Figure 321**

19. Install the transmission belt to the transmission pulley.
20. Using a 7/16 inch socket on the bottom of the transmission, release pressure on the quarter inch screw driver. Remove the quarter inch screw driver, allowing idler arm to put tension on the belt.
21. Install the 4 (1/4–20 inch) taptite screws securing the belt cover to the frame. Torque screws to 55 ± 5 in-lbs. (6 ± 1 Nm).



g296175

**Figure 322**

22. Install the 1/4–20 inch taptite screw securing the frame cover to the frame. Torque bolt to 110 ± 11 in-lbs. (12 ± 2 Nm).



## Blade Drive Assembly Installation (continued)



g296174

**Figure 323**

- 
23. Lower the rear cover.
  24. Using an appropriate lifting device, lower the rear of the machine to the ground.

## Door and Chute Assembly Replacement

### Door and Chute Assembly Removal

1. Park the machine on a level surface and engage the parking brake. Stop the engine and wait for all moving parts to stop. Shut the fuel off.
2. Remove the grass bagger assembly if attached.
3. Remove the 4 (1/4–20 inch) taptite screws securing the belt cover to the frame.



g296175

**Figure 324**

## Door and Chute Assembly Removal (continued)

4. Remove the 4 (1/4–20 inch) taptite screws securing the chute and door assembly to the chassis.



g299115

**Figure 325**

- 
5. Slide the door and chute assembly rearward and remove from the machine.
  6. Remove the 2 (1/4–10 inch) taptite screws securing the door to the chute.



g299116

**Figure 326**

- 
7. Separate the door and chute assembly.

## Door Disassembly

1. Remove the 2 (1/4–10 inch) taptite screws securing the handle to the rear door.

## Door Disassembly (continued)



g299117

**Figure 327**

- 
2. Remove the seal clip from the door assembly.



g299118

**Figure 328**

- 
3. Remove the push nut, rod, and spring from the hinge bracket to the rear door.

## Door Disassembly (continued)



g299119

**Figure 329**

---

## Door Assembly

1. Install the push nut, rod, and spring to the hinge bracket to the rear door.



g299119

**Figure 330**

---

2. Install the seal clip to the door assembly.

## Door Assembly (continued)



g299118

**Figure 331**



3. Install the 2 (1/4–10 inch) taptite screws securing the handle to the rear door. Torque bolts to  $17 \pm 2$  in-lbs. ( $1.9 \pm 0.3$  Nm).



g299117

**Figure 332**

## Door and Chute Assembly Installation

1. Attach the door and chute assembly.



## Door and Chute Assembly Installation (continued)

2. Install the 2 (1/4–10 inch) taptite screws securing the door to the chute. Torque bolts to  $30 \pm 4$  in-lbs. ( $3.4 \pm 0.5$  Nm).



g299116

**Figure 333**

- 
3. Slide the door and chute assembly onto the machine.



4. Install the 4 (1/4–20 inch) bolts securing the chute and door assembly to the chassis. Torque bolts to  $55 \pm 5$  in-lbs. ( $6 \pm 1$  Nm).



g299115

**Figure 334**



5. Install the belt cover onto the machine. Install the 4 (1/4–20 inch) taptite screws securing the belt cover to the frame. Torque bolts to  $55 \pm 5$  in-lbs. ( $6.2 \pm 0.5$  Nm).

## Door and Chute Assembly Installation (continued)



g296175

**Figure 335**

---

## Blade Break Arm Replacement

### Blade Break Arm Removal

1. Park the machine on a level surface and engage the parking brake. Stop the engine and wait for all moving parts to stop. Shut the fuel off.
2. Remove the grass bagger assembly if attached.
3. Using an appropriate lifting device, raise the rear of the machine off the ground.
4. Open and secure the rear cover.
5. Remove the 1/4–20 inch taptite screw securing the frame cover to the frame.



g296174

**Figure 336**

## Blade Break Arm Removal (continued)

6. Remove the 4 (1/4–20 inch) taptite screws securing the belt cover to the frame.



g296175

**Figure 337**

- 
7. Rotate the belt tensioner arm by using a 7/16 inch socket on the nut at the bottom side of the transmission, turning clockwise.



g302330

**Figure 338**

- 
8. To remove belt tension, align the idler pulley with the access hole on the bottom side of the transmission. Insert a quarter inch screw driver.

**Note:** Screw driver needs to fit through access hole and the idler pulley slot securing the pulley into position.

## Blade Break Arm Removal (continued)




g296176

**Figure 339**

- 
9. Remove the transmission belt from the engine pulley.

**Note:** Access belt from the front of the mower.




g302331

**Figure 340**

- 
10. Remove the belt from the rear of the mower.

## Blade Break Arm Removal (continued)



g296178

**Figure 341**

- 
11. Remove the 2 (1/4–20 inch) taptite screws securing the front BBC belt guide to the bosses on the frame. Remove the belt guide.




g296179

**Figure 342**

- 
12. From the front, loosen the 5/16–18 inch nylock nut from the BBC idler arm pivot until flush with bottom bolt. Secure the topside of the bolt with a 1/2 inch wrench.

## Blade Break Arm Removal (continued)




g305213

**Figure 343**

---

13. Move the brake arm downwards to release from the pulley.

**Note:** Releasing pulley pressure from the belt.



g302385

**Figure 344**

---

14. Remove the BBC belt from the pulley.


## Blade Break Arm Removal (continued)



g296181

**Figure 345**

- 
15. Remove the BBC belt from rear of the mower.
  16. Remove the belt tension (5/16–18 inch) bolt and nut to relieve tension from the blade timing belt.




g298542

**Figure 346**

- 
17. Remove both dust covers and idler pulleys from the main frame.
  18. Remove the 1/2–20 inch nut from the BBC pulley. Pull the BBC brake pulley off the left side spindle.

**Note:** Secure blade with a wood block.


## Blade Break Arm Removal (continued)



g298543

**Figure 347**

- 
19. Remove the 5/16–18 inch bolt securing the fixed idler pulley to the main frame.




g298544

**Figure 348**

- 
20. Remove fixed idler pulley from the main frame.
  21. Remove the blade timing belt from the spindle pulleys.
  22. Unhook the brake spring extension from the frame.
  23. Remove the BBC cable spring from the brake idler arm.

## Blade Break Arm Removal (continued)



g302428

**Figure 349**

- 
24. Remove the 5/16–18 inch nut securing the brake idler arm to the main frame. Pull the 5/16–18 inch bolt upwards and pull brake idler arm downwards to separate.




g304647

**Figure 350**

- 
25. Remove the blade brake spring from the brake idler arm.

## Blade Break Arm Removal (continued)



g302428

**Figure 351**

- 
26. Remove the brake extension spring from the engine deck mount.
  27. Remove the BBC cable spring from the brake idler arm.
  28. Remove the brake extension spring from the brake idler arm.

## Blade Break Arm Disassembly

Remove the 7/16 inch nut and bolt securing the idler pulley from brake idler arm.



g299121

**Figure 352**


## Blade Break Arm Assembly



Install the 7/16 inch nut and bolt securing the idler pulley to the brake idler arm. Torque nut and bolt to 100 ± 15 in-lbs. (11.3 ± 1.7 Nm).

## Blade Break Arm Installation

1. Install the brake extension spring to the brake idler arm.
2. Install the BBC cable spring to the brake idler arm.
3. Install the blade brake idler arm to the 5/16 inch pivot bolt and install the 5/16–18 inch nylock nut flush with the bottom of the bolt.
4. Hook the brake spring to the frame.
5. Install the blade timing belt to the spindle pulleys. Blades need to be timed 90 degrees difference.
6. Install the 5/16–18 inch bolt securing the fixed idler pulley to the main frame. Torque bolt to  $160 \pm 16$  in-lbs. ( $18 \pm 2$  Nm).




g298544

**Figure 353**

- 
7. Install the dust cover to the fixed idler pulley.
  8. Install the belt tension 5/16–18 inch bolt and nut to tension the blade timing belt. Tighten bolt until there is 0.010–0.030 gap between the spring washer and frame for proper belt tension.

## Blade Break Arm Installation (continued)



g298542

**Figure 354**

---

9. Install the BBC belt to the rear of the mower.

10. Install the BBC belt to the pulley.




g296181

**Figure 355**

---

11. Move the brake arm upwards to secure the pulley.

## Blade Break Arm Installation (continued)



g302385

Figure 356



12. Secure the topside of the bolt with a 1/2 inch wrench. Torque nut and bolt to  $200 \pm 20$  in-lbs. ( $22 \pm 2$  Nm).

**Note:** Access bottom nut from front of the machine.



13. Install the belt guide. Install the 2 (1/4–20 inch) taptite screws securing the front BBC belt guide to the bosses on the frame. Torque screws to  $110 \pm 11$  in-lbs. ( $12 \pm 2$  Nm).




g296179

Figure 357

14. Install the belt to the rear of the mower.
15. Install the transmission belt to the engine pulley.

**Note:** Access belt/engine pulley from the front of the mower.

## Blade Break Arm Installation (continued)



g302331

**Figure 358**

16. Install the transmission belt to the transmission pulley.
17. Using a 7/16 inch socket on the bottom of the transmission, release pressure on the quarter inch screw driver. Remove the quarter inch screw driver, allowing idler arm to put tension on the belt.
18. Install the 4 (1/4–20 inch) taptite screws securing the belt cover to the frame. Torque screws to 55 ± 5 in-lbs. (6 ± 1 Nm).



g296175

**Figure 359**

19. Install the 1/4–20 inch taptite screw securing the frame cover to the frame. Torque screw to 110 ± 11 in-lbs. (12 ± 2 Nm).



## Blade Break Arm Installation (continued)



g296174

**Figure 360**

- 
20. Lower the rear cover.
  21. Using an appropriate lifting device, lower the rear of the machine to the ground.



## Table of Contents


General Information .....	8-2
Service and Repairs .....	8-3
Transmission Replacement.....	8-6

# General Information

This machine uses a MV702 transmission from General Transmission and is equipped with a parking brake caliper and rotor. Transmission is a two piece axle system with a fixed mount and idler arm for increased belt life.

# Service and Repairs

## Drive System Assembly 1




g299500

Figure 361

- |                           |                        |
|---------------------------|------------------------|
| 1. Brace                  | 8. Spring Mandrell     |
| 2. Shield                 | 9. Torsion Spring      |
| 3. Height Adjustment Lock | 10. Front Axle Asm.    |
| 4. Spacer                 | 11. Front Bushing      |
| 5. Torsion Spring         | 12. Wheel Cover Spacer |
| 6. U-Nut                  | 13. Wheel              |
| 7. Front Bumper Asm.      |                        |


## Drive System Assembly 2



g299501

**Figure 362**

- |                       |                                    |
|-----------------------|------------------------------------|
| 1. RH Brace           | 5. Front Block                     |
| 2. Engine Guard       | 6. Wheel Axle                      |
| 3. Compression Spring | 7. 9 inch Wheel Asm. with Bearings |
| 4. Front Height Plate |                                    |



g299502

Figure 363

- |                           |                                |
|---------------------------|--------------------------------|
| 1. RH HOC Plate Asm.      | 12. Torsion Spring             |
| 2. LH HOC Plate Asm.      | 13. Rotor Hub                  |
| 3. Extension Spring       | 14. Bracket                    |
| 4. Height Adjustment Lock | 15. Disc Brake Caliper         |
| 5. Custom Ball Bearing    | 16. Brake Rotor                |
| 6. 15T Pinion Gear        | 17. Brake Mount Bracket        |
| 7. Wheel Cover            | 18. Cable Guide                |
| 8. Wheel Asm.             | 19. Roll Pin                   |
| 9. 10.5 Inch Wheel Asm.   | 20. Rear Axle Asm.             |
| 10. Bearing Retainer Asm. | 21. Transmission               |
| 11. Bearing Cover         | 22. Front Transmission Bracket |

# Transmission Replacement

## Transmission Removal

1. Park the machine on a level surface and engage the parking brake. Stop the engine and wait for all moving parts to stop. Shut the fuel off.
2. Remove the grass bagger assembly if attached.
3. Using an appropriate lifting device, raise the rear of the machine off the ground.
4. Open and secure the rear cover.
5. Remove the 1/4–20 inch taptite screw securing the cover to the frame.



g296174

**Figure 364**

- 
6. Remove the 4 (1/4–20 inch) taptite screws securing the front cover to the frame.



g296175

**Figure 365**

## Transmission Removal (continued)

7. Rotate the belt tensioner arm by using a 7/16 inch socket on the nut at the bottom side of the transmission, turning clockwise.



g302330

**Figure 366**

- 
8. To remove belt tension, align the idler pulley with the access hole on the bottom side of the transmission. Insert a quarter inch screw driver.

**Note:** Screw driver needs to fit through access hole and the idler pulley slot securing the pulley into position.




g296176

**Figure 367**

- 
9. Remove the transmission belt from the engine pulley.

**Note:** Access belt from the front of the mower.

## Transmission Removal (continued)



g302331

**Figure 368**

---

10. Remove the belt from the rear of the mower.




g296178

**Figure 369**

- 
11. Using an appropriate lifting device, lower the rear of the machine off the ground.
  12. Set the rear height-of-cut to 5 inch.
  13. Using a 9/16 inch socket, remove the 2 nuts securing the wheels to the rear axles.
  14. Remove the T-30 screw securing the dust cover to the axle assembly.


## Transmission Removal (continued)



g297057

**Figure 370**

- 
15. Remove the 5/16–18 inch nut on carriage bolt securing the spring bracket to the frame.



g297058

**Figure 371**

- 
16. Using snap ring pillars, remove the snap ring retaining the pinion gear from axle shaft.

**Note:** Inspect the pinion gear to wheel gear mesh for abnormal wear, broken teeth, and uneven wear. Replace pinion gear to wheel gear mesh if needed.


## Transmission Removal (continued)



g297059

**Figure 372**

- 
17. Remove the 5/16–18 inch bolt securing the axle bearing housing to the axle height-of-cut plate.




g297060

**Figure 373**

- 
18. While holding up the spring loaded height-of-cut handle, apply pressure to the back of the axle bearing housing assembly, separating from axle weldment.

## Transmission Removal (continued)



g297061

**Figure 374**

- 
19. Remove the 1/4–20 taptite screw securing the transmission cable guide to the frame.




g297062

**Figure 375**

- 
20. Remove the 1/4–20 inch bolt securing the parking brake to the transmission.

## Transmission Removal (continued)



g297064

**Figure 376**

---

21. Remove the 2 Phillip head screws from the trailing shield to the main frame.



g297065

**Figure 377**

---


22. Remove the 5/16–18 inch nut to carriage bolt on LH side. Remove the RH 5/16–18 inch taptite screw to main frame securing the transmission assembly to the main housing.

## Transmission Removal (continued)



g297066

**Figure 378**



g297531

**Figure 379**

---

23. Slide transmission to the right. Line up RH side height-of-cut notch with bolt.

## Transmission Removal (continued)



g297894

**Figure 380**

- 
24. Remove the height-of-cut weldment from the chassis. Slide the LH side of the height-of-cut weldment first before the RH side.




g297895

**Figure 381**

- 
25. Center the transmission. Pinch the traction cable towards the transmission and rotate the front transmission and cable downward.


## Transmission Removal (continued)



g297896

**Figure 382**

- 
26. To remove the transmission from the frame, rotate the transmission upside down and slide the transmission to the right. Remove the transmission from the frame with the traction cable attached.




g298181

**Figure 383**

- 
27. Remove the torsion spring from the RH side axle shaft.

## Transmission Removal (continued)



g298182

**Figure 384**

- 
28. Using needle nose plier, squeeze the cable anchor and remove cable anchor from the cable mount.



g298183

**Figure 385**

- 
29. Pull the cable and remove from the cable anchor mount.

## Transmission Removal (continued)



g298184

**Figure 386**

---

30. Remove the spring hook from the transmission clutch lever.



g298185

**Figure 387**

---

## Transmission Disassembly

1. Remove the 2 (5/16–18 inch) nuts from carriage bolts securing the transmission mount plate to the transmission.

## Transmission Disassembly (continued)



g299150

**Figure 388**

- 
2. Support the transmission axle, drive the roll pin out using a 3/16 inch punch securing the brake hub to the transmission axle. Slide the brake hub from the transmission axle.



g299143

**Figure 389**

- 
3. Remove the T-25 mounting screws securing the brake rotor to the brake hub.  
**Note:** Mounting screws may vary per unit.

## Transmission Disassembly (continued)



g299144

**Figure 390**

- 
4. Secure the input shaft with a 1/8 inch drift punch inserted into the hole on the input shaft.



g299145

**Figure 391**

- 
5. Using a 9/16 inch socket, remove the nut securing the fan to the input shaft.

## Transmission Disassembly (continued)



g304900

**Figure 392**

- 
- Using a 9/16 inch socket, remove the nut securing the input pulley to the input shaft.




g304907

**Figure 393**

- 
- Remove the washer from the input shaft.

## Transmission Disassembly (continued)



g304923

**Figure 394**

- 
8. Remove the 1/4 inch nut from the idler shaft on the bottom side of the transmission.
  9. Pull the idler shaft out of the pivot bearing.




g304924

**Figure 395**

- 
10. Remove idler shaft and spring from the spring mount.
  11. Remove the bearings from the transmission.

## Transmission Disassembly (continued)




g299151

**Figure 396**

---

## Transmission Assembly

1. Install the bearings to the transmission.




g299151

**Figure 397**

---

2. Install the idler shaft and spring to the spring mount.
3. Install the idler shaft into the pivot bearing.


## Transmission Assembly (continued)



g304924

**Figure 398**

- 
4. Install the M8 inch nut to the idler shaft on the bottom side of the transmission.




g309825

**Figure 399**

- 
5. Install the washer to the input shaft.

## Transmission Assembly (continued)



g304923

**Figure 400**



6. Using a 9/16 inch socket, install the nut securing the input pulley to the input shaft. Torque nut to 70.8 in-lbs. (8 Nm).



g304907

**Figure 401**



## Transmission Assembly (continued)


- Using a 9/16 inch socket, install the nut securing the fan to the input shaft. Torque nut to 70.8 in-lbs. (8 Nm).



g304900

**Figure 402**

- 
- Secure the input shaft with a 1/8 inch drift punch inserted into the hole on the input shaft.



g299145

**Figure 403**

- 
- Install the T-25 mounting screws securing the brake rotator to the brake hub. Torque mounting screws to  $38 \pm 7$  in-lbs. ( $4.3 \pm 0.8$ Nm).

**Note:** Mounting screws may vary per unit.

## Transmission Assembly (continued)



g299144

**Figure 404**

- 
10. Slide the brake hub into the transmission axle. Support the transmission axle, drive the roll pin in using a 3/16 inch punch securing the brake hub to the transmission axle.



g299143

**Figure 405**



11. Install the 2 (5/16–18 inch) nuts from carriage bolts securing the transmission mount plate to the transmission. Torque nuts to  $160 \pm 16$  in-lbs. ( $18 \pm 2$  Nm).

## Transmission Assembly (continued)



g299150

**Figure 406**

---

## Transmission Installation

1. Install the spring hook to the transmission lever.



g298185

**Figure 407**

---

2. Install the cable to the cable anchor mount.

## Transmission Installation (continued)



g298184

**Figure 408**

- 
- Using needle a nose plier, install the cable anchor to the cable mount.




g298183

**Figure 409**

- 
- Install the height-of-cut spring to the RH side axle shaft.

## Transmission Installation (continued)



g298182

**Figure 410**

- 
5. Install the transmission to the frame with the traction cable attached.




g298181

**Figure 411**

- 
6. Rotate the front transmission and cable upward. Pinch the traction cable towards the transmission.

## Transmission Installation (continued)



g297896

**Figure 412**

- 
7. Slide the RH side of the height-of-cut weldment first before the LH side. Install the height-of-cut weldment to the chassis.



g297895

**Figure 413**

- 
8. Line up the RH side height-of-cut notch with bolt. Slide the transmission to the left.

## Transmission Installation (continued)




g297894

**Figure 414**



9. Put anti-seize inside the axle bearing before sliding over the shaft. Install the axle bearing housing assembly over the axle. Line up the mounting hole on the bearing housing assembly to the weldment hole. Install the bearing retainers into the rear axle weldment and rear height-of-cut plate for alignment purposes before securing the transmission to the frame. Install the 5/16–18 inch bolt to the axle weldment. Torque bolt to  $160 \pm 16$  in-lbs. ( $18 \pm 2$  Nm).




g297061

**Figure 415**



10. Install LH 5/16–18 inch nut to carriage bolt and the RH 7/16–18 inch taptite screw to the main frame securing the transmission assembly to the main housing. Torque nut to carriage bolt to  $140 \pm 5$  in-lbs. ( $16 \pm 0.5$  Nm). Torque taptite screw to  $160 \pm 16$  in-lbs. ( $18 \pm 2$  Nm).

## Transmission Installation (continued)



g297531

**Figure 416**



g297066

**Figure 417**



11. Install the 2 Phillip head screws securing the trailing shield to the main frame. Torque screws to  $9 \pm 1$  in-lbs. (1 Nm).

## Transmission Installation (continued)




g297065

**Figure 418**



12. Install the 1/4–20 inch bolt securing the parking brake to the transmission. Torque bolt to  $85 \pm 15$  in-lbs. ( $9 \pm 2$  Nm).



g297064

**Figure 419**

13. Install the 1/4–20 taptite screw securing the transmission cable guide to the frame.


## Transmission Installation (continued)



g297062

**Figure 420**

- 
14. Using snap ring pillars, Install the snap ring retaining the pinion gear to axle shaft.



g297059

**Figure 421**



- 
15. Install the 5/16–18 inch nut on carriage bolt securing the spring bracket to the frame. Torque nut to 115 ± 15 in-lbs. (13 ± 2 Nm).

## Transmission Installation (continued)



g297058

**Figure 422**



16. Install the T-30 screw securing the dust cover to the axle assembly. Torque screw to  $55 \pm 5$  in-lbs. ( $6 \pm 1$  Nm).




g297057

**Figure 423**



17. Using a socket, install the 2 ( $3/8$ -16 inch) nuts securing the wheels to the rear axles. Torque nuts to  $180 \pm 20$  in-lbs. ( $20 \pm 2$  Nm).
18. Install the belt through the rear of the mower.

## Transmission Installation (continued)




g296178

**Figure 424**

- 
19. Install the transmission belt to the engine pulley.

**Note:** Access belt from the front of the mower.



g296177

**Figure 425**

- 
20. Install the transmission belt to the transmission pulley.
  21. Using a 7/16 inch socket on the bottom of the transmission, release pressure on the quarter inch screw driver. Remove the quarter inch screw driver, allowing idler arm to put tension on the belt.
  22. Install the belt to the input pulley on the transmission.
  23. Install the 4 (1/4–20 inch) taptite screws securing the belt cover to the frame. Torque bolts to 55 ± 5 in-lbs. (6 ± 1 Nm).



## Transmission Installation (continued)



g296175

**Figure 426**



24. Install the 1/4–20 inch taptite screw securing the frame cover to the frame. Torque bolt to  $110 \pm 11$  in-lbs. ( $12 \pm 2$  Nm).



g296174

**Figure 427**

25. Lower the rear cover.
26. Using an appropriate lifting device, lower the rear of the machine to the ground.
27. Reinstall the cable guide.