



523Dxi Garden Tractor

Model No. 73590—210000001 & Up

Set Up Instructions

Loose Parts


Note: Use the chart below to identify parts for assembly.

DESCRIPTION	QTY.	USE
Rear Wheel	2	Installing the rear wheels
Wheel Bolt	10	
R.H. Wheel Spindle	1	Installing the front wheels
L.H. Wheel Spindle	1	
Unplated Thrust Washer – 1.56" O.D x .06" Thick	2	
Plated Wheel Washer – 1.50" O.D x .05" Thick	4	
Bolt – 5/16"-18 x 2.25" Long	2	
Hex Nut – 5/16"-18	2	
Spindle Cap	2	
Front Wheel	2	
Hubcap Washer – 2.50" O.D x .05" Thick	2	
Cotter Pin – .156" x 1.50" Long	2	
Shim Washer – 1.50" O.D x .015" Thick	2	
Hubcap	2	
Steering Wheel	1	Installing the steering wheel
Boot Washer	1	
Nut	1	
Lock Washer	1	
Trim Cover	1	
Seat Assembly	1	Installing the seat
Shoulder Bolt – 5/16"	2	
Locknut – 5/16"	2	

DESCRIPTION	QTY.	USE
Grill Screw - #8 x .50" Long	2	Securing the grill
Grill Washer - .75" O.D.	2	
Hitch Pin	1	Installing the drawbar hitch pin
Hairpin Cotter	1	
Flat Washer - .50" I.D.	1	
Key	2	Use in ignition and "Key Choice" switches
Operator's Manual	1	Read before operating the tractor
Engine Operator's Manual	1	Read before operating the tractor

Installing the Rear Wheels

1. Remove the four wheel bolts holding the rear shipping brackets to the rear hubs.
2. Using a jack or suitable hoist, raise the rear of the tractor only high enough to install the rear wheels.
3. Install the wheels onto the hubs with the valve stems facing inward (Fig. 1).
4. Tighten the wheel bolts to 75-80 ft-lb (105-112 N•m).



m-1278


Figure 1

1. Hub
2. Rear wheel
3. Wheel bolt (5)

Installing the Front Wheels

IMPORTANT: Never raise the front of the tractor by placing a jack under the bumper or front axle because the tractor may be damaged.

1. The front hood support braces have two slots (Fig. 2) that may be used to lift the tractor to install the front wheel spindles. To access these slots, remove the front grill and raise the hood.



M-4255

Figure 2

1. Slots
2. Grill Grommets

Note: Remove, or be careful not to damage, the two upper grill grommets (Fig. 2).

2. Using a suitable hoist, raise the front of the tractor only high enough to install the front wheel spindles.

IMPORTANT: Do not pivot the weight of the tractor onto the rear drawbar hitch because the hitch will be damaged.

3. Install a 1.56" O.D. x .06" thick unplated thrust washer onto the splined shaft of the R.H. wheel spindle (Fig. 4).
4. Install the splined end of the R.H. spindle through the R.H. end of the front axle and into the steering arm (Fig. 4).

Note: The L.H. and R.H. spindles are different. Assemble the spindles as shown in figure 3.

Note: The outside edge of the spindle must be parallel to the end of the steering arm (Fig. 3).




Figure 3

- | | |
|-----------------|--------------------------|
| 1. R.H. Spindle | 3. Steering arm |
| 2. L.H. Spindle | 4. Parallel relationship |

5. Secure the spindle shaft to the steering arm with a 5/16"-18 x 2.25" bolt and 5/16" nut (Fig. 4). Torque the nut to 230 ± 25 in-lbs.
6. Insert a 1.50" O.D x .05" thick plated wheel washer onto the R.H. spindle (Fig. 4).

7. Install a front wheel onto the R.H. spindle with the valve stem facing inward (Fig 4).
8. Insert another 1.50" O.D x .05" thick plated wheel washer onto the R.H. spindle (Fig. 4).
9. Install a 2.50" O.D x .05" thick hub cap washer onto the spindle. Now insert a .156 x 1.50" long cotter pin into the hole in the spindle (Fig. 4).
10. Check the front wheel end play. Install shim washers inside the hubcap washer as necessary so there is minimum end play.




Figure 4

- | | |
|--|--|
| 1. Wheel spindle | 8. Plated wheel washer 1.50" O.D. x .05" thick |
| 2. Unplated thrust washer 1.56" x .06" thick | 9. Hub cap washer 2.50" O.D. x .05" thick |
| 3. Front axle | 10. Shim washer 1.50" O.D. x .015" thick |
| 4. Steering arm | 11. Cotter pin .056" x 1.50" |
| 5. Bolt 5/16"-18 x 2.25" | 12. Hubcap |
| 6. Nut 5/16" | |
| 7. Spindle cap | |

11. Secure the wheel to the spindle with a cotter pin. Bend the ends of the cotter pin completely around the spindle.
12. Install a hubcap onto the hubcap washer until it snaps in place (Fig. 4).

13. Look at the end of the steering arm and the inside edge of the tire. The end of the steering arm and the inside edge of the tire must be parallel (Fig. 5). Adjust the steering arm if required.




Figure 5

- | | |
|-----------------|--------------------------|
| 1. Wheel | 3. Parallel relationship |
| 2. Steering arm | |

14. Insert a spindle cap into the steering arm (Fig. 4).
15. Repeat the procedure on the opposite end of the front axle.
16. Lubricate the spindles and front axle pivot until grease begins to come out of the bearings.
17. After servicing the battery, replace the front grill of the tractor and secure the grill with two #8 x .50" long grill screws and .75" O.D. grill washers in the upper two grill mounting holes (Fig. 6).




Figure 6

- | | |
|-------------------------|--------------------------|
| 1. Grill screw (1 of 2) | 2. Grill washer (1 of 2) |
|-------------------------|--------------------------|

Installing the Steering Wheel

1. Install the boot washer onto the steering shaft (Fig. 7).
2. Remove the plastic trim cover from the steering wheel (Fig. 7)
3. Install the steering wheel onto the shaft, carefully aligning the splines (Fig. 7).

Note: There is no fixed straight ahead position on power steering models.

4. Secure the steering wheel to the shaft with a lock washer and nut (Fig. 7). Tighten the retaining nut to 45-50 ft-lbs.
5. Install the trim cover on the steering wheel.




Figure 7

- | | |
|-------------------|----------------|
| 1. Boot washer | 4. Lock washer |
| 2. Steering shaft | 5. Nut |
| 3. Steering wheel | 6. Trim cover |

Checking Front Wheel Toe-in

1. With the tractor on a level surface, check to make sure the front wheel toe-in is between 1/8" and 1/4". For instructions on adjusting toe-in, refer to the Maintenance section in Operator's Manual.

Check to Insure that Steering Linkage is Centered

1. With the tractor on a level surface, turn the steering wheel fully to the left and check the clearance of the left hand spindle stop to the stop on the front axle. There should be a slight clearance between the stops (Fig. 8).




Figure 8

- | | |
|---------------------------|--------------|
| 1. Left hand spindle stop | 3. Clearance |
| 2. Axle stop | |

2. Repeat for the right front tire in a right turn.
3. If the stops on one side hit, and on the other side have clearance, shorten the tie rod on the side that hits, and equally lengthen the tie rod on the opposite side until both sides have clearance. Recheck the toe in.

Checking Tire Pressure

Check front and rear tire pressure. The correct front and rear tire pressure is 20 psi (138 kPa).

Installing the Seat

1. Mount the seat to the seat base using two 5/16" shoulder bolts and lock nuts (Fig. 9).
2. Insert the seat switch wire through the center opening in the seat base (Fig 9).
3. Push the seat switch wire connector into the wire harness connector.




Figure 9

- | | |
|----------------------------|---------------------------------|
| 1. Seat | 5. Seat switch wire connector |
| 2. Seat base | 6. Opening for seat switch wire |
| 3. 5/16" shoulder bolt (2) | |
| 4. 5/16" Locknut (4) | |

Activating the Battery



Battery posts, terminals, and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and reproductive harm. *Wash hands after handling.*

DANGER

POTENTIAL HAZARD


- Battery electrolyte contains sulfuric acid which is a deadly poison and it causes severe burns.

WHAT CAN HAPPEN

- If you carelessly drink electrolyte you could die or if it gets onto your skin you will be burned.

HOW TO AVOID THE HAZARD

- Do not drink electrolyte and avoid contact with skin, eyes or clothing. Wear safety glasses to shield your eyes and rubber gloves to protect your hands.
- Fill the battery where clean water is always available for flushing the skin.
- Follow all instructions and comply with all safety messages on the electrolyte container.



m-3799

Figure 10

1. Cell cover
2. Electrolyte
3. Lower part of tube

1. Remove the battery from the tractor (refer to Removing the Battery in your tractor Operator's Manual).

Note: Never fill the battery electrolyte with the battery installed in the tractor.

2. Remove the cell cover from the battery. Slowly pour electrolyte into each cell until the electrolyte level is up to the lower part of the tube (Fig. 10). Use an electrolyte with a specific gravity of 1.265.

WARNING

POTENTIAL HAZARD

- Charging battery produces gasses.

WHAT CAN HAPPEN

- Battery gasses can explode.

HOW TO AVOID THE HAZARD

- Keep cigarettes, sparks and flames away from battery.

3. Leave the cell cover off and connect a 3-4 amp battery charger to the battery posts (Fig. 11). Charge the battery at a rate of 4 amperes or less for 4 hours (12 volts).

4. When the battery is fully charged, unplug the charger from electrical outlet, then disconnect the charger leads from the battery posts (Fig. 11).




Figure 11


- | | |
|--------------------------|---------------------------|
| 1. Positive battery post | 3. Red (+) charger lead |
| 2. Negative battery post | 4. Black (-) charger lead |

5. Slowly pour electrolyte into each cell until the level is once again up to the lower part of the tube (Fig. 10), then install the cell cover.
6. Install the battery in the tractor and connect the battery cables (refer to Installing the Battery in your tractor Operator's Manual).

Note: Do not run the tractor with the battery disconnected.

Installing the Drawbar Hitch Pin

Insert the drawbar hitch pin into the drawbar hitch and secure it with a .50" I.D. flat washer and hairpin cotter (Fig. 12).



m-2481

Figure 12

- | | |
|----------------------|---------------------|
| 1. Drawbar hitch pin | 3. .50" Flat washer |
| 2. Drawbar hitch | 4. Hairpin cotter |

Checking the Wiring and Fasteners

- Inspect the tractor for any loose electrical connections and secure them as required. Check the wire routing to make sure moving parts do not interfere with wires and cause a short.
- Ensure that all fasteners are tight.

Test Driving the Tractor

1. Check the oil level in the crankcase (refer to Engine Oil in your tractor Operator's Manual for oil type, viscosity and crankcase capacity).
2. Check the oil level in the transaxle (refer to Transaxle Fluid in your tractor Operator's Manual for oil type, viscosity and capacity).
3. Check that the coolant level is between the two lines on the coolant recovery tank when the engine is cold (refer to Check the Cooling System in your tractor Operator's Manual).

4. Make sure all water is drained from the fuel filter (refer to Draining Water From The Fuel Filter/Water Separator in your tractor Operator's Manual).
5. Check to make sure all lubrication points have been greased as shown in the Maintenance section of tractor Operator's Manual.
6. Fill the tank with fresh diesel fuel with a minimum cetane rating of 40 and the proper grade for the ambient temperature conditions (refer to Adding Fuel in your tractor Operator's Manual) Open the fuel shutoff valve and check the fuel hose and fittings for leaks.
7. As applicable, check and test the operation of the following:
 - Engine and throttle controls
 - Gauges
 - Headlights and taillights
 - Indicator lights
 - PTO clutch and brake
 - Lift system
 - Service and parking brakes
 - Transmission controls
 - Steering
 - Tractor operation in forward and reverse
8. Test the operation of the safety interlock system (refer to the tractor Operator's Manual for the correct procedure).