



# **Workman<sup>®</sup> 3300-D & 4300-D**



## **Liquid-Cooled Diesel Utility Vehicle**

**Model No. 07213TC—Serial No. 220000001 and Up**

**Model No. 07217TC—Serial No. 220000001 and Up**

# Foreword



The TORO Workman® was developed to provide an efficient, versatile, trouble free and economical work vehicle. The latest concepts of engineering, design and safety have been incorporated into this machine, along with the highest quality parts and workmanship. Excellent service will be derived if proper operation and maintenance practices are followed.

	<b>WARNING</b>	
The Workman® is an off-highway vehicle only, and is not designed, equipped, or manufactured for use on public streets, roads or highways.		

You know, since you have purchased the industry leader in maintenance excellence, that future performance and dependability are of prime importance. TORO also is concerned about future use of the machine and of safety to the user. Therefore, this manual must be read by you and those involved with the Workman® to make sure that safety, proper set up, operation and maintenance procedures are followed at all times. The major sections of the manual are:

1. Safety Instructions
2. Set-Up Instructions
5. Maintenance
3. Before Operating
4. Operating Instructions

Safety, mechanical and some general information in this manual are emphasized. DANGER, WARNING and CAUTION identify safety messages. Whenever the triangle safety symbol appears, it is followed by a safety message that must be read and understood. For more details concerning safety, read the safety instructions on pages 5–7. **Important** identifies special mechanical information and **NOTE** identifies general information worthy of special attention.

	<b>WARNING</b>	
Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, or other reproductive harm.		

The TORO Workman® meets the requirements of ANSI B56.8a–1994.

Supervisors, operators and service persons should be familiar with the following standards and publications: (The material may be obtained from the address shown).

- Flammable and Combustible Liquids Code: ANSI/NFPA 30
- National Fire Protection Association: ANSI/NFPA # 505; Powered Industrial Trucks  
ADDRESS: National Fire Prevention Association, Barrymarch Park, Quincy, Massachusetts 02269 U.S.A.
- ANSI/ASME B56.8 Personal Burden Carriers  
ADDRESS: American National Standards Institute, Inc. 1430 Broadway, New York, New York 10018 U.S.A.
- ANSI/UL 558; Internal Combustion Engine, Powered Industrial Trucks  
ADDRESS: American National Standards Institute, Inc., 1430 Broadway, New York, New York 10018 U.S.A.

OR

Underwriters Laboratories, 333 Pfingsten Road, Northbrook, Illinois 60062 U.S.A.

## Optional Spark Arrester

In some places a spark arrester muffler must be used because of local, state or federal regulations. The spark arrester, available from your local Toro Distributor is approved by the United States Department of Agriculture and the United States Forest Service.

When the machine is used or operated on any California forest, brush or grass covered land, a properly operating spark arrester must be attached to the muffler. The operator is violating state law, Section 442 Public Resources Code if a spark arrester is not used.

If help concerning set up, operation, maintenance or safety is ever needed, contact your local Authorized TORO Distributor. In addition to genuine TORO replacement parts, the distributor also has optional equipment for the complete line of TORO turf care equipment. Keep your TORO all-TORO. Buy genuine TORO parts and accessories.

# Table of Contents

Foreword	2	Maintenance	34
Table of Contents	3	Quick Reference Chart	35
Safety Instructions	4	Fluid Specifications/Change Intervals	35
Sound Pressure Level	7	Lubrication	36
Vibration Level	7	Using Bed Safety Support	37
Safety and Instruction Decals	8	Jacking the Vehicle	38
Specifications	10	General Air Cleaner Maintenance Practices	39
Set-Up Instructions	12	Servicing the Air Cleaner	39
Install Rear Fenders	13	Changing Engine Oil and Filter	40
Install Wheels	13	Fuel System	40
Install Steering Wheel	13	Bleeding Air from Injectors	41
Install Front Fenders	14	Removing Debris From Engine Cooling System	41
Install the Roll-Over Protection System	14	Changing Engine Coolant	41
Activate and Charge the Battery	14	Adjusting Belts	42
Before Operating	16	Adjusting Accelerator Pedal	43
Check Engine Oil	16	Cylinder Head Bolts	43
Fill the Fuel Tank	17	Changing Transaxle/Hydraulic Fluid	43
Check the Cooling System	17	Replacing Hydraulic Filter	44
Check Hydraulic Fluid	18	Change Front Differential Oil	44
Check Front Differential Oil	18	Cleaning Hydraulic Strainer	45
Check Torque of Wheel Nuts	18	Adjusting the Brake Pedal	45
Check Tire Pressure	18	Adjusting the Clutch Pedal	45
Check Brake Fluid	19	Adjusting Parking Brake	46
Controls	20	Adjusting Shift Cables	46
Operating Instructions	24	Adjusting the High-Low Cable	46
Pre-Starting Checks	24	Adjusting Differential Lock Cable	47
Starting the Engine	24	Emergency Box Raising	47
Bleeding the Fuel System	24	Inspect Brakes	47
Driving the Vehicle	25	Inspect Tires	47
Stopping the Vehicle	25	Front Wheel Toe-In	47
Stopping Engine	25	Inspect Constant Velocity Boot	48
New Vehicle Break-In	25	Fuses	48
Checking the Interlock System	26	Jump Starting Procedure	48
Operating Characteristics	26	Battery Storage	49
Passengers	27	Battery Care	49
Speed	27	Hydraulic Schematic (Base Vehicle)	51
Turning	27	Hydraulic Schematic (Vehicle w/Remote Hydraulic Kit)	52
Braking	27	Electrical Schematic (Base Vehicle)	53
Hills	29	Electrical Schematic (Vehicle w/Remote Hydraulic Kit)	54
Loading and Dumping	29	Identification And Ordering	55
Using the Differential Lock	30		
Four-Wheel Drive	30		
Transporting the Vehicle	31		
Towing the Vehicle	31		
Trailer Towing	31		
Remote Hydraulic Control (Optional)	32		
Quick Coupler Operation	33		
Remote Hydraulic Control Trouble Shooting:	33		

# Safety Instructions

The Workman® was designed and tested to offer safe service when operated and maintained properly. Although hazard control and accident prevention partially are dependent upon the design and configuration of the machine, these factors are also dependent upon the awareness, concern, and proper training of the personnel involved in the operation, maintenance and storage of the machine. Improper use or maintenance of the machine can result in injury or death.

This is a specialized utility vehicle designed for off-road use only. Its ride and handling will have a different feel than what drivers experience with passenger cars or trucks. So take time to become familiar with your Workman®.

Not all of the attachments that adapt to the Workman® are covered in this manual. See the specific Operator's Manual provided with attachment for additional safety instructions. **READ THESE MANUALS.**

**TO REDUCE THE POTENTIAL FOR INJURY OR DEATH, COMPLY WITH THE FOLLOWING SAFETY INSTRUCTIONS.**

## Supervisor's Responsibilities

1. Make sure operators are thoroughly trained and familiar with the operator's manual and all labels on the vehicle.
2. Be sure to establish your own special procedures and work rules for unusual operating conditions (e.g., slopes too steep for vehicle operation). Use the 3rd high lockout switch if high speed could result in a safety or vehicle abuse situation.

## Before Operating

3. Operate the machine only after reading and understanding the contents of this manual. A replacement manual is available by sending complete model and serial number to:

The Toro Company 8111 Lyndale Avenue South,  
Bloomington, Minnesota 55420-1196.

4. Never allow children to operate the vehicle. Never allow adults to operate it without proper instructions. Only trained and authorized persons should operate this vehicle. Make sure all operators are physically and mentally capable of operating the vehicle. Anyone who operates the vehicle should have a motor vehicle license.
5. This vehicle is designed to carry only you, the operator, and one passenger in the seat provided by the manufacturer. Never carry any other passengers on the vehicle.
6. Never operate the vehicle when under the influence of drugs or alcohol.
7. Become familiar with the controls and know how to stop the engine quickly.
8. Keep all shields, safety devices and decals in place. If a shield, safety device or decal is malfunctioning, illegible, or damaged, repair or replace it before operating the machine.
9. Always wear substantial shoes. Do not operate machine while wearing sandals, tennis shoes or sneakers. Do not wear loose fitting clothing or jewelry which could get caught in moving parts and cause personal injury.
10. Wearing safety glasses, safety shoes, long pants and a helmet is advisable and required by some local safety and insurance regulations.
11. Keep everyone, especially children and pets, away from the areas of operation.
12. Before operating the vehicle, always check all parts of the vehicle and any attachments. If something is wrong, stop using vehicle. Make sure problem is corrected before vehicle or attachment is operated again.
13. Since diesel fuel is highly flammable, handle it carefully.
  - A. Use an approved fuel container.
  - B. Do not remove cap from fuel tank when engine is hot or running.

- C. Do not smoke while handling fuel.
  - D. Fill fuel tank outdoors and to about one inch below top of tank (bottom of filler neck). Do not overfill.
  - E. Wipe up any spilled fuel.
14. Check the safety interlock system daily for proper operation; refer to page 26. If a switch should malfunction, replace the switch before operating machine. After every two years, replace the interlock switches in the safety system, whether they are working properly or not.

## While Operating

15. Operator and passenger should remain seated whenever the vehicle is in motion. Operator should keep both hands on steering wheel, whenever possible and passenger should use hand holds provided. Keep arms and legs within the vehicle body at all times. Never carry passengers in box or on attachments. Remember your passenger may not be expecting you to brake or turn and may not be ready.
16. Never overload your vehicle. Name plate (located under dash on passenger side) shows load limits for vehicle. Never overfill attachments or exceed the vehicle maximum gross vehicle weight.
17. When starting the engine:
- A. Sit on operator's seat and engage parking brake.
  - B. Disengage any attachments and return hand throttle lever to OFF position (if so equipped).
  - C. Move shift lever to NEUTRAL and depress clutch pedal.
  - D. Keep foot off accelerator pedal.
  - E. Turn ignition key to ON, hold glow plug switch ON (Maximum 30 seconds).
  - F. Turn ignition key to START.
18. Using the machine demands attention. Failure to operate vehicle safely may result in an accident, tip over of vehicle and serious injury or death. Drive carefully. To prevent tipping or loss of control:
- A. Use extreme caution, reduce speed and maintain a safe distance around sand traps, ditches, creeks, ramps, any unfamiliar areas or other hazards.
  - B. Watch for holes or other hidden hazards.
  - C. Use caution when operating vehicle on a steep slope. Normally travel straight up and down slopes. Reduce speed when making sharp turns or when turning on hillsides. Avoid turning on hillsides whenever possible.
  - D. Use extra caution when operating vehicle on wet surfaces, at higher speeds or with a full load. Stopping time will increase with a full load. Shift into a lower gear before starting up or down a hill.
  - E. When loading bed, distribute load evenly. Use extra caution if the load exceeds the dimensions of the vehicle/bed. Operate vehicle with extra caution when handling off-center loads that cannot be centered. Keep loads balanced and secure to prevent them from shifting.
  - F. Avoid sudden stops and starts. Do not go from reverse to forward or forward to reverse without first coming to a complete stop.
  - G. Do not attempt sharp turns or abrupt maneuvers or other unsafe driving actions that may cause a loss of vehicle control.
  - H. When dumping, do not let anyone stand behind vehicle and do not dump load on anyone's feet. Release tailgate latches from side of box, not from behind.
  - I. Before backing up, look to the rear and assure no one is behind. Back up slowly.
  - J. Watch out for traffic when near or crossing roads. Always yield the right of way to pedestrians and other vehicles. This vehicle is not designed for use on streets or highways. Always signal your turns or stop early enough so other persons know what you plan to do. Obey all traffic rules and regulations.
  - K. Never operate vehicle in or near an area where there is dust or fumes in the air which are explosive. The electrical and exhaust systems of the vehicle can produce sparks capable of igniting explosive materials.

- L. Always watch out for and avoid low overhangs such as tree limbs, door jambs, over head walkways, etc. Make sure there is enough room over head to easily clear the vehicle and your head.
  - M. If ever unsure about safe operation, STOP WORK and ask your supervisor.
19. Do not touch engine, transaxle, radiator, muffler or muffler shield while engine is running or soon after it has stopped because these areas may be hot enough to cause burns.
  20. If the machine ever vibrates abnormally, stop immediately, turn engine off, wait for all motion to stop and inspect for damage. Repair all damage before commencing operation.
  21. Before getting off the seat:
    - A. Stop movement of the machine.
    - B. Lower the bed.
    - C. Shut engine off and wait for all movement to stop.
    - D. Set parking brake.
    - E. Remove key from ignition.
    - F. Block wheels if machine is on an incline.
  22. Before disconnecting or performing any work on the hydraulic system, all pressure in system must be relieved by stopping engine, cycling dump valve from raise to lower and/or lowering box and attachments. Place the remote hydraulics lever in the float position. If box must be in raised position, secure with safety support.
  23. To make sure entire machine is in good condition, keep all nuts, bolts and screws properly tightened.
  24. To reduce potential fire hazard, keep the engine area free of excessive grease, grass, leaves and accumulation of dirt.
  25. If the engine must be running to perform a maintenance adjustment, keep hands, feet, clothing, and any parts of the body away from the engine and any moving parts. Keep everyone away.
  26. Do not overspeed engine by changing governor settings. Maximum engine speed is 3650 rpm. To assure safety and accuracy, have an Authorized TORO Distributor check maximum engine speed with a tachometer.
  27. If major repairs are ever needed or assistance is required, contact an Authorized TORO Distributor.

## Maintenance

22. Before servicing or making adjustments to the machine, stop engine, set parking brake and remove key from ignition to prevent accidental starting of the engine.
23. Never work under a raised bed without placing bed safety support on fully extended cylinder rod.
24. Make sure all hydraulic line connectors are tight, and all hydraulic hoses and lines are in good condition before applying pressure to the system.
25. Keep body and hands away from pin hole leaks or nozzles that eject hydraulic fluid under high pressure. Use paper or cardboard, not hands, to search for leaks. Hydraulic fluid escaping under pressure can have sufficient force to penetrate skin and do serious damage. If fluid is injected into the skin it must be surgically removed within a few hours by a doctor familiar with this form of injury or gangrene may result.
26. To be sure of optimum performance and safety, always purchase genuine TORO replacement parts and accessories. Replacement parts and accessories made by other manufacturers could be dangerous. Altering this vehicle in any manner may affect the vehicle's operation, performance, durability or its use may result in injury or death. Such use could void the product warranty of The TORO Company.
27. This vehicle should not be modified without the TORO Company's authorization. Direct any inquiries to:
 

The TORO Company Commercial Division Vehicle Engineering Dept., 300 West 82nd St. Bloomington, Minnesota 55420-1196 USA

## **Sound Pressure Level**

This unit has an equivalent continuous A-weighted sound pressure at the operator ear of 84 dB(A), based on measurements of identical machines per Directive 98/37/EC and amendments.

## **Vibration Level**


### **Hand Arm**


This unit does not exceed a vibration level of 2.5 m/s<sup>2</sup>, at the hands based on measurements of identical machines per ISO 5349 procedures.

### **Whole Body**

This unit does not exceed a vibration level of 0.5 m/s<sup>2</sup> at the posterior based on measurements of identical machines per ISO 2631 procedures.

# Safety and Instruction Decals





THROWN OR FLYING OBJECTS, FACE EXPOSURE

SEVERING OF FINGERS OR HAND, ENGINE FAN

RIDING ON THIS MACHINE IS ALLOWED ONLY ON A PASSENGER SEAT & ONLY IF THE DRIVER'S VIEW IS NOT HINDERED

SHUT OFF ENGINE & REMOVE KEY BEFORE PERFORMING MAINTENANCE OR REPAIR WORK



MACHINE TIPPING

USE CAUTION ON STEEP HILLS

MACHINE TIPPING

MACHINE TIPPING




DO NOT JUMP FROM TIPPING MACHINE

HOLD TIGHT & BRACE FEET

LEAN AWAY FROM TIP


HOLD HIP RESTRAINT & HAND HOLD, BRACE FEET



STAY CLEAR OF ARTICULATION AREA WHILE ENGINE IS RUNNING


RUNOVER/BACKOVER, VEHICLE

REAR POWER TAKE OFF




GREASE LUBRICATION POINT

GREASE LUBRICATION POINT



MACHINE DIRECTION OF MOVEMENT


BEFORE LEAVING OPERATOR POSITION, TURN OFF IGNITION, LOCK PARKING BRAKE, DISENGAGE PTO, REMOVE KEY FROM IGNITION.




BEFORE LEAVING OPERATOR POSITION, TURN OFF IGNITION AND REMOVE KEY.

LOAD RATING, HOPPER


LOAD RATING, TRAILER AND HITCH



LOAD RATING



LOAD RATING



LOAD RATING, HOPPER

# Specifications

**Type:** 4-wheel step through, out front operator style, two-person vehicle. Certified to meet ANSI Specifications B56.8a-1994.

**Engine:** Daihatsu three-cylinder, liquid-cooled, counterbalanced, diesel engine. Rated at 19.8 kW (26.5 hp), governed to a maximum speed of 3650 rpm by a mechanical governor. 58 cu. in. (952 cc) displacement. Forced lubrication by gear pump. 12-volt electric starter. Spin-on oil filter.

**Air Cleaner:** Heavy-duty, 2-stage, remote mounted air cleaner.

**Battery:** 12 volt with 650 cold cranking amps @ -17.8 degrees C.

**Cooling System:** Mid mounted radiator with removable screen and lower clean out access. Cooling system capacity is approximately 3.8 l (4 qts.) of 50/50 mixture of ethylene glycol anti-freeze.

**Fuel System:** Fuel tank capacity is 26.5 liter (7 gallons). 12-volt electric (transistor type) fuel pump with replaceable filter. Replaceable fuel filter/water separator with 3-micron filtration.

**Transmission:** Rear transaxle configuration, twin axle drive. 3-speed synchromesh, H-shift pattern with high-low range providing 6 forward and 2 reverse speeds. Manual engage differential lock. 4-wheel drive output shaft (4-wd only).

**Clutch:** 17cm (6.7") clutch and pressure plate.

**Front Differential:** (4-wd only) 5.0 to 1 ratio.

**Center Differential:** (4-wd only) Bi-directional overrunning clutch.

**Frame:** Welded, high strength steel channels and tubes.

**Front Suspension:** Independent "A" frame control arm, dual progressive rate coil springs and dual shock absorbers with anti-sway bar.

**Rear Suspension:** DeDion axle (weight carrying axle is independent of transaxle), leaf spring and dual

shock absorbers.

**Steering System:** Power assist, 3-position tilt steering wheel, 3-¾ turns lock-to-lock. 17.5 to 1 ratio, 35cm (14") diameter steering wheel.

**Tires:** Front tires: 20" x 10" 10, 4-ply rating, rib tread. Rear tires: 23" x 13" 12, 6-ply rating, turf tread.

**Brakes:** 4-wheel hydraulic, dual safety circuit self-adjusting drum: 17.7cm (7") diameter front and 20.3cm (8") diameter rear (2-wd) 20.3 cm (8") diameter front and rear (4-wd). Hand-actuated parking brake actuates rear brake shoes.

**Roll-over protection system:** 2-post roll-over protection structure with shoulder restraint.

**Hydraulics:** 4.25 gpm pressure balanced gear pump provides hydraulic flow for power steering, lift and optional remote hydraulics. Lift control valve and dual cylinders for lifting dump box. Transaxle is used for reservoir for hydraulic system. 7.6 l (8 quart) total capacity. Spin-on, 10-micron hydraulic oil filter. 100-mesh strainer in transaxle. The optional, remote hydraulic control kit supplies "live" hydraulic power from the vehicle pump whenever the engine is running.

**Seat:** Bucket seats with shoulder and hip restraints.

**Controls:** Foot-operated accelerator, clutch and brake pedals. Hand-operated shifter, differential lock, parking brake, high-low range shifter, hydraulic lift and tilt steering levers. Ignition switch, light switch, glow plug switch, horn button and 3rd high-lockout switch.

**Gauges:** Hour meter, fuel gauge, coolant temperature gauge. Warning light cluster includes engine low oil pressure, charge indicator and glow indicator. Tachometer optional.

**Lights:** Twin halogen headlights and single taillight. Rear stop light.

**Tow Hitch:** Hitch has hole for ball or pin.

**Interlocks:** Clutch pedal must be depressed to start engine.

**Ground Speed:**

### **Forward Speeds w/23" Rear Tires**

**High range:** 12/18.5/31.9 kmh (6/11.5/19.8 mph)

**Low range:** 4.7/7.2/12.4 kmh (2.9/4.5/7.7 mph)

### **Reverse Speeds w/24" Tires**

High range: 11.6 kmh (7.2 mph)

Low range: 4.5 kmh (2.8 mph)

### **General Specifications (approx.):**

**Base Weight:** Dry w/o flatbed 522.5 kg (1400lbs)  
(2wd); 597kg (1600 lbs.)(4-wd)

**Rated Capacity:** \*970.42kg ( 2,600 lbs.)

\* includes 75 kg. operator and 75 kg. passenger and loaded attachment.

**Maximum. Gross Vehicle Weight:** 1493kg (4,000 lbs). (2wd); 1568 kg (4,200 lbs.) (4-wd)

**Tow Capacity:** Tongue weight 75 kg (200 lbs.)

Maximum trailer weight 560 kg (1,500 lbs.)

**Overall Width:** 160cm (63")

**Overall Length:** 316 cm (124.5") w/o bed; 322cm (127") w/full bed 337.8cm (133") with  $\frac{3}{8}$  bed in rear mounting location

**Height:** 190.5cm (75") to top of roll-over protection system

**Ground Clearance:** 17.8cm (7") w/no load

**Wheel Base:** 177.8cm (70")

**Wheel Tread:** (center line to center line)

116.8 cm (46"); Front 121cm (47.7")

**Rear Specifications and design subject to change without notice.**

# Set-Up Instructions

## Loose Parts Chart

**Note:** Use this chart as a checklist to assure all parts necessary for assembly have been received. Without these parts, total set up cannot be completed. Some parts may have already been assembled at factory.

DESCRIPTION	QTY.	USE
Fenders-Rear	2	Mount rear fenders
Capscrew $\frac{5}{16}$ -18 x 1" lg.	4	
Flatwasher .344" I. D.	4	
Locknut $\frac{5}{16}$ -18	4	
Capscrew $\frac{1}{4}$ -20 x 1" lg.	12	
Flatwasher .281" I. D.	12	
Locknut $\frac{1}{4}$ -20	12	
Trusshead Screw	6	
Locknut $\frac{3}{8}$ -16	6	
Wheel Nut	10	Mount wheels.
Wheel—Front	2	
Wheel Nut	10	
Wheel—Rear	2	
Steering wheel	1	Install steering wheel
Foam Seal	1	
Washer	1	
Nut	1	
Cap	1	
Fenders-Front	2	Install front fenders
Phillips Screw 10-24	14	
Washer	14	
Locknut 10-24	14	
Roll-Over Protection System	1	Mount Roll-Over Protection System
Capscrew $\frac{1}{2}$ -13 x 3" lg.	4	
Locknuts $\frac{1}{2}$ -13	4	
Operator's Manual (Vehicle)	2	Read before operating machine.
Parts Catalog	1	
Registration Card	1	Fill out and return to Toro

## Install Rear Fenders (Fig. 1–2)

1. Loosen the locknuts and capscrews securing tail light plates to right and left frame brackets.
2. Pivot tail light plates rearward and tighten capscrews and locknuts.




Figure 1

1. Tail light plate
2. Frame bracket
3. Tail light mounting bracket

3. Secure rear of each tail light plate to rear of frame brackets with a  $\frac{5}{16}$ -18 x 1" lg. capscrew, .344" I. D. flatwasher and nut, as shown in figure 1.
4. On left side, remove (2) capscrews, washers and nuts securing tail light mounting bracket to tail light plate.




Figure 2

1. Fender
2. Fender mounting bracket

5. Position a fender over each tail light plate, aligning mounting holes.
6. On left side, loosely secure tail light mounting

bracket, rear of fender and tail light plate together with (2) capscrews, washers and nuts, previously removed.

7. On right side, secure rear of fender to tail light plate with (2)  $\frac{1}{4}$ -20 x 1" lg. capscrews, .281" I. D. flatwashers and nuts
  8. Loosely secure front of each fender mounting bracket to frame with a  $\frac{1}{4}$ -20 x 1" lg. capscrew and locknut.
  9. Loosely secure side of each fender to frame (3)  $\frac{3}{8}$ -16 x 1" lg. truss head screws and locknuts.
- Note:** Capscrews securing fronts of fenders to mounting brackets may have to be loosened to align all mounting holes.
10. Tighten all fasteners.

## Install Wheels (Fig. 3)

1. Remove and discard fasteners securing wheels.
2. Mount wheels and torque nuts to 61–75 Nm (45–55 ft lb.).




Figure 3

1. Wheel
2. Wheel Nut

## Install Steering Wheel (Fig. 4)

1. Remove jam nut from steering shaft. Slide foam seal, steering wheel and washer onto steering shaft.

- Secure steering wheel to shaft with jam nut and tighten it to 14–20 Nm (10–15 ft lb.).
- Install cap to steering wheel.




Figure 4

- Steering Wheel
- Jam Nut
- Cap
- Washer
- Foam Seal

## Install Front Fenders (Fig. 5)

- Mount a fender to each side of skirt with (7) 10-24 Phillips screws, flat washers and locknuts.




Figure 5

- Fender

## Install the Roll-Over Protection System (Fig. 6)

- Insert each side of the system into the mounting bracket on each side of the vehicle frame, positioning the protection system as shown in figure 6.
- Secure each side of the roll-over protection

system to mounting brackets with (2) ½-13 x 3” lg. capscrews and locknuts.




Figure 6

- Roll-over protection system
- Mounting brackets

## Activate and Charge the Battery (Fig. 7 & 8)


If the battery is not filled with electrolyte or activated, it must be removed from vehicle, filled with electrolyte and charged. Bulk electrolyte with 1.260 specific gravity can be purchased from a local battery supply outlet.

- Loosen knobs securing battery cover to battery base and slide cover off.
- Remove capscrew, washers and locknut securing battery hold down to battery base. Remove hold

⚠
CAUTION
⚠

Electrolyte gases are explosive and can cause serious injury to eyes, lungs and skin. Wear safety goggles and rubber gloves when working with electrolyte or battery. Charge the battery in a well-ventilated place so gasses produced while charging can dissipate. Since the gases are explosive, keep open flames and electrical spark away from the battery; do not smoke. Nausea may result if the gases are inhaled. Unplug charger from electrical outlet before connecting to or disconnecting charger leads from battery posts.


down and slide battery out of battery base.



**Figure 7**

1. Battery cover
2. Knob
3. Battery base



3. Remove filler caps from battery and slowly fill each cell until electrolyte is just above the plates.
4. Replace filler caps and connect a 3- to 4-amp battery charger to the battery posts. Charge the battery at a rate of 3 to 4 amperes for 4 to 8 hours.
5. When battery is charged, disconnect charger from electrical outlet and battery posts.
6. Remove filler caps. Slowly add electrolyte to each cell until level is up to fill ring. Install filler caps.  
**Important** Do not overfill battery. Electrolyte will overflow onto other parts of the vehicle and severe corrosion and deterioration will result.
7. Slide battery into battery base so battery terminals are toward the rear of the vehicle.



**Figure 8**

1. Positive (+) cable
2. Hold down

8. Install the positive (+) cable to the positive (+) terminal and the negative cable (black) to the negative (-) terminal of the battery and secure with capscrews and nuts. Slide the rubber boot over the positive terminal to prevent possible short-out from occurring.

	<b>WARNING</b>	
<p>Connecting cables to the wrong post could result in personal injury and/or damage to the electrical system. Make sure battery or cables do not interfere or rub on any moving or hot parts.</p>		

9. Install battery hold down and secure to base with capscrew, washers and locknut.
10. Reinstall battery cover to battery base and tighten knobs.

# Before Operating



## CAUTION



Before servicing or making adjustments to the machine, stop engine, set parking brake and remove key from the switch. Any load material must be removed from bed or other attachment before working under raised bed. Always place the safety support on extended lift cylinder to hold box up.

## Check Engine Oil (Fig. 9–11)

The engine is shipped with approximately 3.3 l (3.5 qts.) (w/filter) of oil in the crankcase; however, level of oil must be checked before and after the engine is first started.

1. Position machine on a level surface.
2. Remove dipstick and wipe it with a clean rag. Insert dipstick into tube and make sure it is seated fully. Remove dipstick and check level of oil.




Figure 9

1. Dipstick

3. The engine uses any high quality 10W30 detergent oil having the American Petroleum Institute API “service classification” CF or better.
4. If oil level is low, remove filler cap and add enough oil to raise level to FULL mark on dipstick.




Figure 10

1. Filler cap

**Note:** When adding oil, remove dipstick to allow proper venting, pour oil slowly and check the level often during this process. **DO NOT OVERFILL.**

**Important** When adding engine oil or filling oil, there must be clearance between the oil fill device and the oil fill hole in the valve cover as shown in figure 11. This clearance is necessary to permit venting when filling, which prevents oil from overrunning into breather.




Figure 11

1. Note Clearance

5. Install the dipstick firmly in place.

**Important** Check level of oil every 8 operating hours or daily. Change oil and filter initially after the first 50 hours of operation, thereafter, change oil and filter every 100 hours. However, change oil more frequently when engine is operated in extremely dusty or dirty conditions.

**Note:** After filling or changing oil, start and run the engine at idle for 30 seconds. Shut engine off. Wait 30 seconds and check oil level. Add enough oil to raise level to FULL mark on dipstick.

## Fill the Fuel Tank (Fig. 12)

Fuel tank capacity is approximately 26.5 l (7 gallons).

The engine runs on No. 2-D or 1-D automotive type diesel fuel with a minimum cetane rating of 40.

**Note:** Higher cetane rated fuel may be required if machine is to be used at high altitude and low atmospheric temperatures.



**Figure 12**

1. Fuel tank cap

1. Clean area around fuel tank cap.
2. Remove fuel tank cap.
3. Fill tank to about one inch below top of tank, (bottom of filler neck) with diesel fuel. **DO NOT OVERFILL.** Then install cap.
4. Wipe up any fuel that may have spilled to prevent a fire hazard.



## DANGER



Because diesel fuel is flammable, caution must be used when storing or handling it. Do not fill fuel tank while engine is running, hot, or when machine is in an enclosed area. Vapors may build up and be ignited by a spark or flame source many feet away. **DO NOT SMOKE** while filling the fuel tank to prevent the possibility of an explosion. Always fill fuel tank outside and wipe up any spilled diesel fuel before starting engine. Use a funnel or spout to prevent spilling diesel fuel and fill tank to about 1 inch (25 mm) below the filler neck. Store diesel fuel in a clean, safety approved container and keep the cap in place on the container. Keep diesel fuel in a cool, well ventilated place; never in an enclosed area such as a hot storage shed. To assure volatility and to prevent contamination, do not buy more than a 6 month supply.

## Check the Cooling System (Fig. 13)

Capacity of cooling system is approximately 3.8 l (4 qts.).

The cooling system is filled with a 50/50 solution of water and permanent ethylene glycol anti-freeze. Check level of coolant at beginning of each day before starting the engine.

1. Park machine on a level surface.



## CAUTION



If engine has been running, pressurized hot coolant can escape if radiator cap is removed and cause burns. Allow engine to cool at least 15 minutes or until the radiator cap is cool enough to touch without burning hand.

2. Check coolant level. Coolant should be up to COLD line on reserve tank, when engine is cold.
3. If coolant is low, remove reserve tank cap and add a 50/50 mixture of water and permanent ethylene glycol anti-freeze. **DO NOT OVERFILL.**

4. Install reserve tank cap.




Figure 13

1. Reserve tank
2. Cold line
3. Hot line

## Check Hydraulic Fluid (Fig. 14)

The transaxle reservoir is filled with Dextron III ATF. Check level before engine is first started and every 8 hours or daily, thereafter. Capacity of system is 7.1 l (7.5 qts.).

1. Position the vehicle on a level surface.
2. Clean area around dipstick.
3. Unscrew dipstick from top of transaxle and wipe it with a clean cloth.




Figure 14

1. Dip stick

4. Screw dipstick into transaxle and make sure it is seated fully. Unscrew dipstick and check fluid level. Fluid should be up to top of flat portion of dipstick. If level is low, add enough fluid to achieve the proper level.

## Check Front Differential Oil

### Four-Wheel Drive Model Only (Fig. 15)

The differential is filled with 10W30 oil. Check level of oil every 100 hours or monthly. Capacity of system is 0.9 l (1 qt.).

1. Position the vehicle on a level surface.
2. Clean area around fill/check plug on side of differential.




Figure 15

1. Front differential
2. Fill/check plug
3. Drain plug

3. Remove fill/check plug and check level of oil. Oil should be up to hole. If oil is low, add 10W30 oil.
4. Re-install fill/check plug.

## Check Torque of Wheel Nuts

	<b>WARNING</b>	
<p>Failure to maintain proper torque could result in failure or loss of wheel and may result in personal injury. Torque front and rear wheel nuts to 61–88 Nm (45–65 ft-lb) after 1 to 4 hours of operation and again after 10 hours of operation and every 200 hours thereafter.</p>		



## Check Tire Pressure

Check tire pressure every 8 hours or daily to assure proper levels.

Maximum air pressure in front tires is 138 kPa (20 psi) and rear tires is 124 kPa (18 psi).

1. The air pressure needed is determined by the payload carried.
2. The lower the air pressure, the less the compaction and tire marks are minimized. Lower pressure should not be used for heavy payloads at high speeds. Tire damage may result.
3. Higher pressures should be used for heavier payloads at higher speeds. Do not exceed the maximum pressure. Use the following charts to determine correct tire pressures for tire size and payload of vehicle.


**Important** When replacing vehicle tires, only use replacements approved for the Workman®. Use of tires not approved may cause turf damage or accelerated drive train damage.



## Check Brake Fluid (Fig. 16)

The brake fluid reservoir is shipped from the factory filled with "DOT 3" brake fluid. Check level before engine is first started and every 8 hours or daily, thereafter.

1. Park machine on a level surface.
2. Fluid level should be up to FULL line on reservoir.
3. If fluid level is low, clean area around cap, remove reservoir cap and fill to proper level. DO NOT OVERFILL.



**Figure 16**

1. Brake fluid reservoir
2. Full line

# Controls

**Accelerator Pedal** (Fig. 17)—The accelerator pedal gives the operator the ability to vary engine and ground speed of the vehicle, when the transmission is in gear. Depressing the pedal increases engine RPM and ground speed. Releasing pedal will decrease engine RPM and ground speed of the machine.



**Figure 17**

1. Accelerator pedal
2. Clutch pedal
3. Brake pedal

**Clutch Pedal** (Fig. 17)—The clutch pedal must be fully depressed to disengage clutch when starting engine or shifting transmission gears. Release pedal smoothly when transmission is in gear to prevent unnecessary wear on transmission and other related parts.

**Important** Do not ride clutch pedal during operation. Clutch pedal must be fully out or clutch will slip causing friction and wear. Never hold the vehicle stopped on a hill using the clutch pedal. Damage to the clutch may occur.

**Brake Pedal** (Fig. 17)—The brake pedal is used to apply service brakes to stop or slow vehicle.

**CAUTION**

Worn or misadjusted brakes may result in personal injury. If brake pedal travels to within 1-½" of the vehicle floor board, the brakes must be adjusted or repaired.

**Gear Shift Lever** (Fig. 18)—Fully depress clutch pedal and move shift lever into desired gear selection. A diagram of the shift pattern is indicated below.

**Shift Pattern**



- R = reverse
- 1 = First gear
- 2 = Second gear
- 3 = Third gear

**Important** Do not shift the transaxle to the reverse or forward gear unless the vehicle is standing still. Damage to transaxle may occur.

**CAUTION**


Down shifting from too high a speed can cause the rear wheels to skid resulting in loss of vehicle control as well as clutch and/or transmission damage. Shift smoothly to avoid grinding gears.

**Differential Lock** (Fig. 18)—Allows rear axle to be locked for increased traction. Differential lock may be engaged with vehicle in motion. Move lever forward and to the right to engage lock.

**Note:** Vehicle motion plus a slight turn is required to engage or disengage differential lock.

**WARNING**

Turning with the differential lock on can result in loss of vehicle control. Do not operate with differential lock on when making sharp turns or at high speeds. Refer to *Using the Differential Lock*, page 30.



**Figure 18**

1. Gear shift lever
2. Differential lock
3. Parking brake
4. High-low range shifter
5. Hydraulic lift
6. Hydraulic lift lock

**Parking Brake** (Fig. 18)—Whenever the engine is shut off, the parking brake must be engaged to prevent accidental movement of the vehicle. To engage the parking brake, pull back on lever. To disengage, push lever forward. Make sure parking brake is released before moving vehicle. If vehicle is parked on a steep grade, make sure parking brake is applied. Also, shift the transmission into 1st gear on a uphill grade or reverse on a down hill grade. Place chocks at the down hill side of wheels.

**Hydraulic Lift** (Fig. 18)—Raises and lowers bed. Move rearward to raise, forward to lower.

**Important** When lowering bed, hold lever in forward position for 1 or 2 seconds after bed contacts frame to secure it in lowered position.

⚠
CAUTION
⚠

When raising or lowering bed or implement, hydraulic oil will bypass over a relief valve when cylinders reach the end of their travel, stopping power assist to steering gear and increasing steering effort. Release lift levers to NEUTRAL immediately after bed or implement is raised or lowered, to regain assist to power steering.

**Important** Do not hold the hydraulic lift in either the raise or lower position, for more than 5 seconds, once the cylinders have reached the end of their travel. The hydraulic pump may over heat, resulting in pump damage.

**Hydraulic Lift Lock** (Fig. 18)—Locks lift lever so

hydraulic cylinders do not operate when vehicle is not equipped with a bed.

**Passenger Hand Hold** (Fig. 18)—Left side of passenger seat.

**High-Low Range Shifter** (Fig. 18)—Adds three additional speeds for precise speed control.

- A. Vehicle must be completely stopped before shifting between High and Low range.
- B. Shift only on level ground.
- C. Depress clutch pedal fully.
- D. Move lever fully forward for High and fully rearward for Low.

HIGH is for higher speed driving on level, dry surfaces with light loads.


LOW is for low speed driving. Use this range when greater than normal power or control is required. For example, steep grades, difficult terrain, heavy loads, slow speed but high engine speed (spraying).

**NOTE:** There is a location between HIGH and LOW in which the transaxle is in neither range. This should not be used as a neutral position because the vehicle could move unexpectedly if the HIGH-LOW shifter is bumped and the gear shift lever is in gear.

**Tilt Steering Lever** (Fig. 19)—Lever on right side of console allows steering wheel to be adjusted for operator comfort.

**Coolant Temperature Gauge** (Fig. 19)—Registers coolant temperature in engine. Operates only when ignition switch is in On position.

**Horn Button** (Fig. 19)—Pressing button activates horn.



**Figure 19**

1. Tilt steering lever
2. Ignition switch
3. Horn button
4. Coolant temp. gauge
5. Engine low oil pressure light
6. Charge indicator
7. Glow plug switch
8. Glow plug indicator light

**Engine Low-Oil Pressure Light** (Fig. 19)—Light glows if engine oil pressure drops below a safe level while engine is running. If light flickers or remains ON, stop vehicle, turn off engine and check oil level. If oil level was low, but adding oil does not cause light to go out when engine is restarted, turn engine off immediately and contact your local TORO distributor for assistance.

**Important** Do not operate vehicle until repair is complete. Failure to observe this precaution may result in damage to the engine.

**Glow Plug Switch and Indicator** (Fig. 19)—Use to preheat engine cylinders prior to cold engine starting procedures—cylinders are preheated automatically during warm engine start operation. For cold starting, push switch lever upward and hold while watching indicator. Indicator will glow orange when the glow plugs are activated. Length of time necessary to preheat cylinders should be determined by atmospheric temperature; refer to Starting /Stopping Engine, p. 24.

**Ignition Switch** (Fig. 19)—The ignition switch, used to start and stop the engine, has three positions: OFF, ON /Preheat and START. Rotate key clockwise—START position—to engage starter motor. Release key when engine starts. The key will move automatically to the ON position. To shut engine off, rotate key counterclockwise to OFF position.

**Charge Indicator** (Fig. 19)—Illuminates when battery is being discharged. If light illuminates during operation, stop vehicle, turn off engine and check for possible causes, such as alternator belt.

**Important** If alternator belt is loose or broken, do not operate vehicle until adjustment or repair is complete. Failure to observe this precaution may result in damage to the engine.

To check operation of warning lights:


1. Apply parking brake.
2. Turn ignition key to “ON”, but do not start engine. The charge indicator and oil pressure lights should glow. If any light does not function, either a bulb is burned out or there is a malfunction in the system that must be repaired.

**Note:** High water temperature function on warning light cluster is not used.

**Hour Meter** (Fig. 20)—Indicates the total hours of machine operation. The hour meter starts to function whenever the key switch is rotated to “ON” position.

**Light Switch** (Fig. 20)—Toggle switch to activate headlights. Push to turn lights “ON”.

**3rd High-Lockout Switch** (Fig. 20)—Moving switch to slow-position and removing key will prevent use of third gear when in the High range. Engine will shut off if shift lever is moved to third gear when in High range. Key is installed with teeth pointing downward. Push key in to turn. Key is removable in either position.



**Figure 20**

1. Light switch
2. Hour meter
3. Fuel gauge
4. 3rd High-lockout switch
5. Steering wheel

**Fuel Gauge** (Fig. 20)—Shows amount of fuel in tank. Operates only when ignition switch is in “ON” position.

**Steering Wheel** (Fig. 20)—Turns vehicle. If engine stalls or power assist fails due to a malfunction, vehicle steering will require greater effort.

**Passenger Hand Hold** (Fig. 21)—On dashboard.



**Figure 21**

1. Passenger hand hold
2. Tachometer (Optional)

**Tachometer—Optional** (Fig. 21)—Indicates engine RPM. Gear selection graphics indicates speed.

**Remote Hydraulic Lever** (optional-not shown)—Controls hydraulic flow to optional quick rear couplers.

# Operating Instructions

## Pre-Starting Checks

Safe operation begins before taking the vehicle out for a day's work. You should check these items each time:

1. Check tire pressure.  
**Note:** These tires are different than car tires, they require less pressure to minimize turf compaction and damage.
2. Check all fluid levels and add the appropriate amount of Toro-specified fluids, if any are found to be low.
3. Check brake pedal operation.
4. Check to see that the lights and horn are working.
5. Turn steering wheel to the left and right to check steering response.
6. Check for oil leaks, loose parts and any other noticeable malfunctions. Make sure engine is off and all moving parts have stopped before checking for oil leaks, loose parts and other malfunctions.

If any of the above items are not correct, notify your mechanic or check with your supervisor before taking the vehicle out for the day. Your supervisor may want you to check other items on a daily basis, so ask what your responsibilities are.

## Starting the Engine

**Important** The fuel system must be bled if any of the following situations have occurred.

- A. Initial start up of a new machine.
- B. Engine has ceased running due to lack of fuel.
- C. Maintenance has been performed upon fuel system components; i.e., filter replaced, separator serviced, etc.

**Refer to Bleeding the Fuel System.**

1. Sit on operator's seat and engage parking brake.
2. Disengage PTO (if so equipped) and return hand throttle lever to OFF position (if so equipped).
3. Move shift lever to NEUTRAL position and depress clutch pedal.
4. Keep foot off accelerator pedal.
5. When temperature is below 15° C (60° F), push glow plug switch upward to ON position (Fig. 19) and hold for suggested interval.

**Note:** Do not exceed 30 seconds of continuous use or glow plug may burn out prematurely.

**Note:** Refer to chart indicating approximate preheat time suggested in various temperature ranges.


Temperature	Preheat time (sec)
Above 5° C (41° F)	10
+ 5° C (41° F) to -5° C (23° F)	20
Below -5° C (23° F)	30

5. Insert key into ignition switch and rotate it clockwise to start the engine. Release key when engine starts.

**Note:** Do not run starter motor more than 20 seconds at a time or premature starter failure may result. If engine fails to start after 20 seconds, turn key to OFF position, recheck controls and procedures, wait 10 additional seconds and repeat starter operation.

## Bleeding the Fuel System

1. Loosen air bleed screw on top of fuel filter/water separator (Fig. 22).



**Figure 22**

1. Fuel filter/water separator
2. Air bleeder screw

3. Turn key in ignition switch to the ON position. Electric fuel pump will begin operation, thereby forcing air out around air bleed screw. Leave key in ON position until solid stream of fuel flows out around screw. Tighten screw and turn key to OFF.
4. Open the air bleed screw on the fuel injection pump (Fig. 23) with a 10 mm wrench.



**Figure 23**

1. Fuel injection pump bleeder

5. Turn key in ignition switch to the ON position. Electric fuel pump will begin operation, thereby forcing air out around air bleed screw on fuel injection pump. Leave key in ON position until solid stream of fuel flows out around the screw. Tighten screw and turn key to OFF.

**Note:** Normally, engine should start after above bleeding procedures are followed. However, if engine does not start, air may be trapped between injection pump and injectors; refer to *Bleeding Air from Injectors*, p. 41

## Driving the Vehicle

1. Release parking brake.
2. Fully depress clutch pedal.
3. Move gear shift lever to 1st gear.
4. Release clutch pedal smoothly while depressing accelerator pedal.
5. When vehicle gains enough speed, remove foot from accelerator pedal, fully depress clutch pedal, move gear shift lever to next gear and release clutch pedal while depressing accelerator pedal. Repeat procedure until desired speed is attained. Stop vehicle before shifting to reverse and forward.

**Note:** Avoid long periods of engine idling.

**Note:** Leaving ignition switch in “ON” position for long periods of time without running engine will discharge battery.

**Important** Do not hold front wheels turned against the right or left stops for longer than 5 seconds. The hydraulic pump may over heat, resulting in pump or steering gear damage.

6. Do not attempt to push or tow vehicle to get it started. Damage to drive train could result.

## Stopping the Vehicle

To stop machine, remove foot from accelerator pedal, depress clutch pedal, then depress brake pedal.

## Stopping Engine

To stop engine, rotate ignition key to OFF and engage parking brake. Remove key from switch to prevent accidental starting.

## New Vehicle Break-In

Your Workman® vehicle is ready for work. To provide proper performance and long vehicle life, follow these guidelines for the first 100 operating hours.



- Check the fluid and engine oil levels regularly and be alert for indications of overheating in any

component of the vehicle.

- After starting a cold engine, let it warm up for about 15 seconds before shifting into gear.
- Avoid racing the engine.
- Avoid hard braking situations for the first several hours of new vehicle brake-in operation. New brake linings may not be at optimum performance until several hours of use has caused the brakes to become burnished (broke-in). However, a specific brake burnish procedure may be followed to allow optimum performance right away.
- To burnish brakes: Operate the vehicle at full speed for 3 minutes, apply the brakes for 30 seconds while engaging the accelerator pedal. Repeat these steps 20 to 30 times. To verify the brakes are completely burnished remove a rear tire and inspect the brake drum for residue. The residue color should be light grey to almost white color.
- Vary vehicle speeds during operation. Avoid excessive idling. Avoid fast starts and quick stops.
- A break-in oil for engine is not required. Original engine oil is the same type specified for regular oil changes.
- Refer to *Maintenance* section of the operator's manual for any special low-hour checks.

## Checking the Interlock System

The purpose of the interlock system is to prevent the engine from cranking or starting unless the clutch pedal is depressed.

CAUTION

The interlock switches are for the operator's protection, so do not bypass them. Check operation of the switches daily to assure interlock system is operating. If a switch is malfunctioning replace it before operating. Regardless whether switches are operating properly or not, replace them every two years to assure maximum safety. Do not rely entirely on safety switches—use common sense!



To verify clutch interlock switch operation:

1. Sit on operator's seat and engage parking brake. Move shift lever to NEUTRAL position.
2. Without depressing clutch pedal, rotate key clockwise to start position.
3. If engine cranks or starts, there is a malfunction in the interlock system that must be repaired before operating vehicle.

Refer to the attachment operator's manual for the procedure on checking the attachment interlock system.

## Operating Characteristics

The vehicle is designed with safety in mind. It has four wheels for added stability. It uses familiar automotive style controls, including the steering wheel, brake pedal, clutch pedal, accelerator pedal, and gear shifter. It is important to remember, however, that this vehicle is not a passenger car. It is a work vehicle and is designed for off road use only.

WARNING

The Workman® is an off-highway vehicle only, and is not designed, equipped, or manufactured for use on public streets, roads or highways.

The vehicle has special tires, low gear ratios, a locking differential, and other features that give it extra traction. These features add to the versatility of the vehicle but, they can also get you into dangerous situations. You must keep in mind that the vehicle is not a recreation vehicle. It is not an all terrain vehicle. And, it is definitely not meant for "stunt driving" or "horsing around". It is a work vehicle, not a play vehicle. Children should not be allowed to operate the vehicle. Anyone who operates the vehicle should have a motor vehicle license.

If you are not experienced at driving the vehicle, practice driving it in a safe area away from other people. Be sure you are familiar with all the vehicle's controls, particularly those used for braking, steering and transmission shifting. Learn how your vehicle handles on different surfaces. Your operating skills will improve with experience, but as in operating any vehicle, take it easy as you begin. Be sure you know how to stop quickly in an emergency. If you need help, ask your supervisor for assistance.

Many factors contribute to accidents. You have control over several of the most important. Your actions, such as driving too fast for conditions, braking too fast, turning too sharp, and combinations of these, are frequent cause of accidents.

One of the major causes of accidents is fatigue. Be sure to take occasional breaks. It is very important that you stay alert at all times.

Never operate the vehicle, or any equipment, if you are under the influence of alcohol or other drugs. Even prescription drugs and cold medicines can cause drowsiness. Read the label on the medicine or check with your doctor or pharmacist if you are unsure about a certain medication.

One of the most important rules to follow is to go slower in unfamiliar areas. It is surprising how much damage and injury common things can cause. Tree branches, fences, wires, other vehicles, tree stumps, ditches, sand traps, streams, and other things found in most parks and golf courses can be hazardous to the operator and passenger.

Avoid driving when it is dark, especially in unfamiliar areas. If you must drive when it is dark, be sure to drive cautiously, use the head lights, and even consider adding additional lights.

## Passengers

Whenever you have a passenger riding in the vehicle make sure he or she is holding on securely. Drive slower and turn less sharply because your passenger does not know what you are going to do next and may not be prepared for turning, stopping, accelerating, and bumps.

You and your passenger should remain seated at all times, keeping arms and legs inside the vehicle. The operator should keep both hands on steering wheel, whenever possible and passenger should use hand holds provided.

There should never be passengers in the dump box or on any attachments. The vehicle is meant to have one driver and only one passenger-no more.

## Speed

Speed is one of the most important variables leading to

accidents. Driving too fast for the conditions can cause you to lose control and have an accident. Speed can also make a minor accident worse. Driving head-on into a tree at slow speed can cause injury and damage, but, driving into a tree at high speed can destroy the vehicle and kill you and your passenger.

Never drive too fast for the conditions. If there is any doubt about how fast to drive, slow down.

When using heavy attachments (more than 373 kg), such as sprayers, top dressers, or spreaders, etc., operating speeds should be restricted by moving 3rd high lockout switch to the slow position.

## Turning

Turning is another important variable leading to accidents. Turning too sharply for the conditions can cause the vehicle to lose traction and skid, or even tip over.

Wet, sandy and slippery surfaces make turning more difficult and risky. The faster you are going, the worse this situation becomes so, slow down before turning.

During a sharp turn at higher speeds, the inside rear wheel may lift off of the ground. This is not a flaw in the design, it happens with most four wheel vehicles including passenger cars. If this happens, you are turning too sharply for the speed at which you are traveling. Slow down!

## Braking

It is good practice to slow down before you get near an obstacle. This gives you extra time to stop or turn away. Hitting an obstacle can damage the vehicle and its contents. More important, it can injure you and your passenger.

Gross vehicle weight has a major impact on your ability to stop and/or turn. Heavier loads and heavier attachments make a vehicle harder to stop or turn. The heavier the load, the longer it takes to stop.

The braking characteristics also change with no bed or attachment on the vehicle. Fast stops may cause the rear wheels to lock up before the front wheels lock up, which may affect the control of the vehicle. It is a good idea to decrease vehicle speed with no bed or attachment.

Turf and pavement are much slipperier when they are wet. It can take 2 to 4 times as long to stop on wet surfaces as on dry surfaces.

If you drive through standing water deep enough to get the brakes wet, they will not work well until they are dry. After driving through water, you should test the brakes to make sure they work properly. If they do not, drive slowly in first gear while putting light pressure on the brake pedal. This will dry the brakes out.

Do not downshift for braking on icy or slippery surfaces (wet grass) or while going down a hill because engine braking may cause skidding and loss of control. Shift to a lower gear before starting down a hill.


The best way for operators to prevent serious injury or death to themselves or others, is to familiarize themselves with the proper operation of the utility vehicle, to stay alert and to avoid actions or conditions which could result in an accident. In the event of a tip over, the risk of serious injury or death will be reduced if the operator is using the roll-over protection system and follows the instructions provided.

## Tipovers

The TORO Workman® is equipped with a roll bar, hip restraints, shoulder restraints and hand hold. The roll-over protection system used on the vehicle will reduce the risk of serious or fatal injury in the unlikely event of a tipover, although the system cannot protect the operator from all possible injuries.

Replace a damaged roll-over protection system, do not repair or revise. Any alteration of roll-over protection system must be approved by manufacturer.

The best way to prevent accidents involving utility vehicles is through continuous supervision and training of operators and paying constant attention to the area in which vehicle is being operated.





Slow down and shift into a lower gear before starting up or down a hill. If you have to turn while on a hill, do it as slowly and cautiously as possible. Never make sharp or fast turns on a hill.

If you stall or begin to lose headway while climbing a steep hill, quickly apply the brakes, shift to neutral, restart the engine and shift to reverse. At idle speed, engine and transaxle drag will aid the brakes in controlling the vehicle on the hill and help you back down the hill more safely.

Reduce the weight of the load if it is a steep hill or if the load has high center of gravity. Remember, loads can shift. Secure them.

**Note:** The Workman® has excellent hill climbing ability. The differential lock will increase this ability.

## Hills

! **WARNING** !

- Tipping or rolling the vehicle on a hill will cause serious personal injury.
- If engine stalls or you lose headway on a hill, never attempt to turn vehicle around.
- Always back straight down a hill in reverse gear.
- Never back down in neutral or with the clutch depressed, using only the brakes.
- Never drive across a steep hill, always drive straight up or down.
- Avoid turning on a hill
- Don't "drop the clutch" or slam on the brakes. Sudden speed change can initiate tipover.

Use extra care when on hills. Never go on hills that are extremely steep. Stopping while going down a hill will take longer than on level ground. Turning while going up or down a hill is more dangerous than turning on the level. Turns while going down hill, especially with the brakes on, and, turning up hill while traversing a hill are particularly dangerous. Even at a slow speed and without a load, tip overs are more likely if you turn on a hill.

## Loading and Dumping

The weight and position of the cargo and passenger can change the vehicle center of gravity and vehicle handling. To avoid loss of control resulting in personal injury, follow these guidelines.

Do not carry loads that exceed the load limits described on the vehicle weight label.

! **WARNING** !

The bed will lower whenever the dump lever is pushed down, even when the engine is off. Turning off the engine will NOT prevent the box from lowering. Always place the safety support on extended lift cylinder to hold box up if you are not going to lower it right away.

! **WARNING** !

When lowering the box it is possible for you or others to get their hands or other body parts in the wrong spot and have them crushed. Take extra care that no one will get hurt. Also, do not dump on anyone's feet. It may seem funny but, it can be dangerous.

The vehicle has several combinations of boxes, platforms, and attachments available. These can be used in various combinations that allow for maximum capacity and versatility. The full sized box is 140 cm

wide by 165 cm long and can hold up to 746 kg of evenly distributed cargo.

Loads vary in how they are distributed. Sand spreads out evenly and quite low. Other items, such as bricks, fertilizer or landscape timbers, stack higher in the box.

The height and weight of the load has a significant influence on tip overs. The higher a load is stacked, the more likely the vehicle is to tip over. You may find that 746 kg stacks too high for safe operation. Reducing the total weight is one way to reduce the risk of a tip over. Distributing the load as low as possible is another way to reduce the risk of a tip over.

If the load is positioned toward one of the sides, it will make the vehicle much more likely to tip over on that side. This is especially true when turning if the load is on the outside of the turn.

Never position heavy loads behind the rear axle. If the load is positioned so far to the rear that it is behind the rear axle, it will reduce the weight on the front wheels and this will reduce steering traction. With the load all the way to the back, the front wheels can even come off of the ground when going over bumps or up a hill. This will result in a loss of steering and may lead to the vehicle tipping over.

As a general rule, position the weight of the load evenly from front to rear and evenly from side to side.

If a load is not secured, or you are transporting a liquid in a large container such as a sprayer, it can shift. This shifting happens most often while turning, going up or down hills, suddenly changing speeds or while driving over rough surfaces. Shifting loads can lead to tip overs. Always secure loads so that they do not shift. Never dump the load while the vehicle is sideways on the hill.

Heavy loads increase stopping distance and reduce your ability to turn quickly without tipping over.



The rear cargo space is intended for load carrying purposes only, not for passengers.

## Using the Differential Lock

The differential lock increases the vehicle's traction by locking the rear wheels so one wheel will not spin out. This can help when you have heavy loads to haul on wet turf or slippery areas, going up hills and on sandy

surfaces. It is important to remember however, that this extra traction is only for temporary limited use. Its use does not replace the safe operation, already discussed concerning steep hills and heavy loads.

The differential lock causes the rear wheels to spin at the same speed. When using differential lock your ability to make sharp turns is somewhat restricted and may scuff the turf. Use the differential lock only when needed, at slower speeds and only in first or second gear.

WARNING

Tipping or rolling the vehicle on a hill will cause serious injury.

- The extra traction available with the differential lock can be enough to get you into dangerous situations such as climbing slopes that are too steep to turn around. Be extra careful when operating with the differential lock on, especially on steeper slopes.
- If the differential lock is on when making a sharp turn at a higher speed and inside rear wheel lifts off the ground, there may be a loss of control that could cause vehicle to skid (Refer to section on *Using the Differential Lock*, p. 30). Use the differential lock only at slower speeds.

## Four-Wheel Drive

### Four-Wheel Drive Model Only


The “Automatic on Demand” four-wheel drive feature, on this vehicle, does not require operator activation. The front wheel drive is not engaged (no power delivered to front wheels) until the rear wheels begin to lose traction. The bi-directional clutch senses the rear wheels slipping, engages the front wheel drive and delivers power to the front wheels. The four-wheel drive system continues to deliver power to the front wheels until the rear wheels have enough traction to move the vehicle without slipping. Once this occurs, the system stops delivering power to the front wheels and the handling characteristics become similar to that of a two-wheel drive vehicle. The four-wheel drive system functions in both forward and reverse, however, when turning the rear wheels will slip slightly more before power is delivered to the front

wheels.

**WARNING**

Tipping or rolling the vehicle on a hill will cause serious injury.

The extra traction available with the four wheel drive feature can be enough to get you into dangerous situations such as climbing slopes that are too steep to turn around. Be careful when operating, especially on steeper slopes.




**Figure 24**  
1. Eye holes in frame

## Transporting the Vehicle

For moving the vehicle long distances, a trailer should be used. Make sure the vehicle is secured to the trailer. Refer to Figures 24 and 25 for location of tie down points.

## Towing the Vehicle

In case of emergency, the vehicle can be towed for a short distance. However, Toro does not recommend this as a standard procedure.



**Figure 25**  
1. Axle tube  
2. Hitch plate

**WARNING**

Towing at excessive speeds could cause vehicle to lose steering control. Never tow vehicle faster than 5 mph.

Towing the vehicle is a two-person job. Affix a tow line to holes in front frame member. Move shifter to Neutral and release parking brake. If machine must be moved a considerable distance, transport it on a truck or trailer.

**Note:** The power steering will not function, making it difficult (increase effort) to steer.

## Trailer Towing

The Workman® is capable of pulling trailers and attachments of greater weight than the vehicle itself.

Several types of tow hitches are available for the Workman®, depending on your application. Contact your Authorized TORO Distributor for details.

When equipped with a tow hitch bolted onto rear axle tube, your Workman® can tow trailers or attachments with a Gross Trailer Weight (GTW) up to 560 kg. Always load a trailer with 60% of the cargo weight in the front of the trailer. This places approximately 10% (75 kg, max.) of the Gross Trailer Weight (GTW) on the tow hitch of the vehicle.

When towing either standard tongue or 5th wheel trailers having a Gross Trailer Weight (GTW) in excess of 560 kg, use either a chassis mounted draw bar hitch (rated for 1306 kg lb. GTW) or 5th wheel kit with brakes. Trailer brakes are required whenever a trailer over 560 kg GTW is towed behind a Workman® vehicle.

When hauling cargo or towing a trailer (attachment),

do not overload your vehicle or trailer. Overloading can cause poor performance or damage to the brakes, axle, engine, transaxle, steering, suspension, body structure or tires.

**Important** To reduce potential for drive-line damage, use low range.


When towing 5th wheel attachments, like a fairway aerator, always install the “wheely bar”(included with the 5th wheel kit) to prevent the front wheels from lifting off the ground if the towed attachments movement is suddenly impaired.

## Remote Hydraulic Control (Optional)

The remote hydraulic control kit supplies “live” hydraulic power from the vehicle pump whenever the engine is running. The power can be used through the quick couplers at the rear of the vehicle.

### Control Lever Positions

#### REMOTE HYDRAULICS



1. FLOAT
2. ON
3. OFF

**Off Position:** This is the normal position for the control valve when it is not being used. This position allows the oil leaving the dump valve to flow through the remote hydraulic valve to the power steering circuit. In this position the work ports of the control valve are blocked and any load will be held by the check valves in both directions.

**Raise (Quick Coupler “B” Position):** This is the position that will lift the rear hitch attachment or apply pressure to quick coupler “B”. This also allows return oil from quick coupler “A” to flow back into the valve and then out to the power steering circuit. This is a momentary position and when the lever is released it spring returns to the center off position.

**Important** Use double acting cylinders only. Using a single acting cylinder does not allow return flow of hydraulic oil and makes steering more difficult. Using a single acting cylinder can lower oil level in transaxle and cause damage to hydraulic pump and transaxle.

**On Position:** This position is similar to *Raise* (quick coupler “B” position). It also directs oil to quick coupler “B” except that the lever is held in this position by a detent notch in the control panel. This allows oil to flow continuously to equipment that uses a hydraulic motor. This position must only be used on attachments with a hydraulic motor attached.


**Note:** If hydraulic motor is used, it may see 6900 kPa (1000 psi) back pressure.

**Important** If used with a hydraulic cylinder or no attachment, the *Raise* or *On* position causes the oil flow to go over a relief valve which can damage the hydraulic system. Additionally this condition does not allow return flow to supply the power steering circuit, which makes steering more difficult. Use these positions only momentarily or with a motor attached.

**Lower (Quick Coupler “A” Position):** This position will lower the rear hitch attachment or apply pressure to quick coupler “A”. This also allows return oil from quick coupler “B” to flow back into the valve and then out to the power steering circuit. This is a momentary position and when the lever is released it spring returns to the center off position. Momentarily holding and then releasing the control lever in this position will provide flow to quick coupler “A” which provides power down on the rear hitch. When released, it will hold the down pressure on the hitch.



**Important** If used with a hydraulic cylinder, holding the control lever in the lower position causes the oil flow to go over a relief valve which can damage the hydraulic system.

**Float Position:** This valve position allows oil to flow in and out of the work ports and is connected to the inlet and outlet ports at the same time. This allows for attachments as the rear hitch to “float” up and down. The same pressure is applied to both quick couplers due to back pressure from the steering circuit.

 **CAUTION** 

Use caution when moving lever to the float position because it will allow rear implement to lower unimpeded.

**Important** Check hydraulic oil level after installation of attachment. Check operation of attachment by cycling attachment several times to purge air from system, then recheck hydraulic oil level. Attachment cylinder will slightly affect transaxle oil level. Operation of vehicle with low oil level can damage pump, remote hydraulics, power steering and vehicle transaxle.

 **CAUTION** 

Hydraulic fluid escaping under pressure can have sufficient force to penetrate skin and do serious damage. Care must be used when connecting or disconnecting hydraulic quick couplers. Stop engine, apply parking brake, lower attachment and place remote hydraulic valve in float detent position to relieve hydraulic pressure before connecting or disconnecting quick couplers.

## Quick Coupler Operation

### CONNECTION

**Important** Clean dirt from quick couplers before connecting. Dirty couplers can introduce contamination to hydraulic system.

Insert hose nipple into coupler until it snaps into position.

**Note:** When attaching remote hydraulic cylinders to the quick couplers, determine which side of the remote cylinder requires pressure, then attach that hose to quick coupler “B”. Only connect double acting cylinders (two hoses).

### DISCONNECTION

Pull hose firmly from coupler

**Important** Clean and install dust plug and dust covers to quick coupler ends when not in use.

## Remote Hydraulic Control Trouble Shooting:

- A.** Difficulty in connecting or disconnecting quick couplers.

Pressure not relieved (Quick coupler under pressure).

Engine running. Remote hydraulic valve not placed in float.

- B.** Power steering hard. Remote valve not in neutral or float position. Remote hydraulic valve linkage out of adjustment.

Hydraulic oil level low.

Hydraulic oil hot.

- C.** Hydraulic leaks. Fittings loose. Fitting missing o-ring.

- D.** Attachment does not function. Quick couplers not fully engaged. Quick couplers are interchanged.

- E.** Squealing noise. Remote valve left in *ON* detent position causing hydraulic oil to flow over relief valve.

# Maintenance

## Maintenance Chart and Checklist

Daily Maintenance: (duplicate this page for routine use) Check proper section of Operator's Manual for fluid specifications

Maintenance Check Item	Daily Maintenance Check For Week Of _____						
	MON	TUES	WED	THURS	FRI	SAT	SUN
✓ Safety Interlock Operation							
✓ Service & Park Brake Operation							
✓ Fuel Level							
✓ Accelerator Operation							
✓ Clutch & Shifter Operation							
✓ Engine Oil Level							
✓ Transaxle Oil Level							
✓ Cooling System Fluid Level <sup>1</sup>							
✓ Brake Fluid Level							
✓ Air Cleaner <sup>2</sup>							
✓ Unusual Engine Noises							
✓ Unusual Operating Noises							
✓ Tire Pressure							
✓ Radiator Screen/Clean out Door <sup>2</sup>							
✓ Hydraulic Hoses for Damage							
✓ Fluid Leaks							
✓ Instrument Operation							
Lubricate All Grease Fittings <sup>3</sup>							
Touch-up Damaged Paint							


1= Inspect at Overflow Tank

2= More often when conditions are dirty

3= Immediately after every washing, regardless of the interval listed.

# Quick Reference Chart

## 4-Wheel Drive Chart Shown





1. Engine oil level
2. Engine oil drain
3. Transaxle/hydraulic oil level (dip stick)
4. Belts (Governor, water pump, hydraulic pump)
5. Coolant level fill
6. Fuel (Diesel fuel only)
7. Grease points (37) 100 hours
8. Radiator screen
- 8.1. Radiator cleanout door
9. Air cleaner
10. Fuel pump
11. Battery
12. Tire pressure—maximum 20 psi front; 18 psi rear (24" tire)
13. Fuses (lights—10 amp; ignition—7.5 amp; dash accessories—7.5 amp)
14. Hydraulic strainer
15. Hydraulic oil filter
16. Brake fluid
17. Water separator
18. Differential fill/check
19. 4-WD shaft

## Fluid Specifications/Change Intervals

See operator's manual for initial changes	Fluid Type	Capacity		Change Intervals		Filter Part No.
		Liter	Quart	Fluid	Filter	
Engine Oil	SAE 10W-30 CD	3.7	3.9	100 hours	100 hours	67-4330 A
Trans/Hydraulic Oil	Dextron III ATF	7.1	7.5	800 hours	800 hours	54-0110 C
Air Cleaner	Clean every 50 hours				200 hours	33-1300 B
Fuel > 0° C	No. 2 D	26.5	7 gal.	—	400 hours	83-8300 E
Fuel Pump	—	—	—	—	400 hours	43-2550 D
Coolant 50/50 Ethylene Glycol/Water	—	4.3	4.5	1200 hours	—	—
Strainer	—	—		Clean 800 hours		87-3990
Differential Oil	SAE 10W-30 CD	.95	1	800 hours	—	—

# Lubrication

## Greasing Bearings And Bushings (Fig. 26–32)

 **WARNING** 

Before servicing or making adjustments to the machine, stop engine, set parking brake and remove key from ignition switch. Any load material must be removed from bed or other attachment before working under raised bed. Always place the safety support on extended lift cylinder to hold box up.

The vehicle has grease fittings that must be lubricated regularly with No. 2 General Purpose Lithium Base Grease. If machine is operated under normal conditions, lubricate all bearings and bushings after every 100 hours of operation. More frequent lubrication is required if used for heavy-duty vehicle operations.

The grease fitting locations and quantities are: Tie rod ends (4) (Fig. 26), Front ball joints (4) (Fig. 26), Rear drive shafts (18) (Fig. 27) Front pivot bushings (2) (Fig. 28); Mid drive shaft -4 wd only (3) (Fig. 29); Pedal Pivots (4) (Fig. 30); Steering shaft (1) (Fig. 31) and Accelerator Arm (1) (Fig. 32).

**Important** When greasing drive shaft universal shaft bearing crosses, pump grease until it comes out of all 4 cups at each cross.

1. Wipe grease fitting clean so foreign matter cannot be forced into the bearing or bushing.
2. Pump grease into the bearing or bushing.
3. Wipe off excess grease.




Figure 26




Figure 27



Figure 28



Figure 29




Figure 30



Figure 31




Figure 32

## Important

### Heavy-Duty Operation

If vehicle is subjected to conditions listed below, maintenance should be performed twice as frequently.

- Desert operation
- Cold climate operation (below 0° C)
- Trailer or 5th wheel towing
- Frequent operation on dusty roads
- Frequent operation under maximum vehicle gross weight
- Construction work
- After extended operation in mud, sand, water or similar dirty conditions, have your brakes inspected and cleaned and drive axle joints greased as soon as possible. This will prevent any abrasive material from causing excessive wear.
- Under frequent heavy duty operating conditions, lubricate all grease fittings and inspect air cleaner daily to prevent excessive wear.



## CAUTION



Only qualified and authorized personnel shall be permitted to maintain, repair, adjust or inspect the vehicle.

Avoid fire hazards and have fire protection equipment present in the work area. Do not use an open flame to check level or leakage of fuel, battery electrolyte or coolant. Do not use open pans of fuel or flammable cleaning fluids for cleaning parts.

### Using Bed Safety Support (Fig. 33 & 34)

Many of the subjects covered in this maintenance section require raising and lowering the bed. The following precautions must be taken or serious injury or death could result.




## WARNING



Before servicing or making adjustments to the machine, stop engine, set parking brake and remove key from ignition switch. Any load material must be removed from bed or other attachment before working under raised bed. Always place the safety support on extended lift cylinder to hold box up.

After maintenance is completed, remove safety support, slide it onto storage stud and lower bed.


1. Raise bed until lift cylinders are fully extended.
2. Remove bed support from storage brackets on back of the roll-over protection panel (Fig. 33).



**Figure 33**

1. Bed support

3. Push bed support onto cylinder rod, making sure support end tabs rest on end of cylinder barrel and on cylinder rod end (Fig. 34).




**Figure 34**

1. Bed support
2. Cylinder barrel
3. Bed

4. To store bed support, remove bed support from cylinder and insert into brackets on back of the roll-over protection system.
5. Always install or remove bed support from outside of bed.
6. Do not try to lower bed with bed safety support on cylinder.


## Jacking the Vehicle (Fig. 35 & 36)

1. Do not start engine while vehicle is on jack, because engine vibration or wheel movement could cause vehicle to slip off jack.
2. Do not work under vehicle without jack stands supporting it. The vehicle could slip off jack, injuring any one beneath it.
3. The jacking point at the front of the vehicle is under the front center frame support and at the rear it is under the axle tube.
4. When jacking up front of vehicle, always place a 5 x 10 cm (2" x 4") block (or similar material) between jack and vehicle frame.




**Figure 35**

1. Front jacking point



**Figure 36**

1. Rear jacking points



**Figure 37**

1. Air cleaner latches  
2. Dust cup  
3. Filter

## General Air Cleaner Maintenance Practices (Fig. 37)

Inspect air cleaner and hoses periodically to maintain maximum engine protection and to ensure maximum service life.

1. Check air cleaner body for damage that could possibly cause an air leak. Replace a damaged air cleaner body.
2. Clean the air cleaner filter every 50 hours and change every 200 hours (more frequently in extreme dusty or dirty conditions).

## Servicing the Air Cleaner

1. Release latches securing air cleaner cover to air cleaner body. Separate cover from body. Clean inside of air cleaner cover.

2. Gently slide filter out of air cleaner body to reduce the amount of dust dislodged. Avoid knocking filter against air cleaner body.
3. Inspect filter and discard if damaged. Do not wash or reuse a damaged filter. Clean the filter as follows:

### Washing Method

- A. Prepare a solution of filter cleaner and water and soak filter element about 15 minutes. Refer to directions on filter cleaner carton for complete information.
- B. After soaking filter for 15 minutes, rinse it with clear water. Maximum water pressure must not exceed 276 kPa (40 psi) to prevent damage to the filter element. Rinse filter from clean side to dirty to side.
- C. Dry filter element using warm, flowing air 71°C (160° F) max), or allow element to air-dry. Do not use a light bulb to dry the filter element because damage could result.

### Compressed Air Method


- A. Blow compressed air from inside to the outside of dry filter element. Do not exceed 689 kPa (100 psi) to prevent damage to the element.
- B. Keep air hose nozzle at least 5cm (2") from filter and move nozzle up and down while rotating the filter element. Inspect for holes and tears by looking through the filter toward a bright light.

5. Inspect new filter for shipping damage. Check sealing end of filter. Do not install a damaged filter.
6. Insert new filter properly into air cleaner body. Make sure filter is sealed properly by applying pressure to outer rim of filter when installing. Do not press on flexible center of filter.
7. Reinstall cover and secure latches.

## Changing Engine Oil and Filter (Fig. 38 & 39)

Change oil and filter initially after the first 50 hours of operation, thereafter, change oil and filter every 100 hours.

1. Raise bed (if so equipped) and place safety support on extended lift cylinder to hold up bed.
2. Remove drain plug and let oil flow into drain pan. When oil stops, install drain plug.



**Figure 38**

1. Engine Oil Drain Plug



**Figure 39**

1. Engine Oil Filter

3. Remove oil filter. Apply a light coat of clean oil to the new filter seal before screwing it on. Screw filter on until gasket contacts mounting plate, then tighten  $\frac{1}{2}$  to  $\frac{3}{8}$  of a turn. **DO NOT OVERTIGHTEN.**
4. Add oil to crankcase, refer to *Check Engine Oil*, p. 16.

## Fuel System (Fig. 40)


### Fuel Lines and Connections

Check lines and connections every 400 hours or yearly, whichever comes first. Inspect for deterioration, damage, or loose connections.

### Fuel Filter/Water Separator

Drain water or other contaminants from fuel filter/water separator daily by loosening drain plug (Fig. 40) on filter canister. Tighten plug after draining. Replace filter canister after every 400 hours of operation.

1. Raise bed (if so equipped) and place safety support on extended lift cylinder to hold up bed.
2. Fuel filter/water separator is mounted on inner side of right frame rail.



**Figure 40**

1. Drain plug
2. Filter canister

3. Clean area around filter canister mounting surface.
4. Remove filter canister and clean mounting surface.
5. Lubricate gasket on filter canister with clean engine oil.
6. Install filter canister by hand until gasket contacts mounting surface, then rotate an additional  $\frac{1}{2}$  turn.

## Bleeding Air from Injectors (Fig. 41)

**Note:** This procedure should be used only if fuel system has been purged of air through normal priming procedures and engine still will not start; refer to *Bleeding the Fuel System*, p 24.

1. Raise bed (if so equipped) and place safety support on extended lift cylinder to hold up bed.
2. Loosen the pipe connection to the No. 1 nozzle and holder assembly (Fig. 41).




Figure 41

1. Fuel injectors (3)

3. Slowly depress accelerator pedal to full FAST position.
4. Turn key in key switch to START position and watch fuel flow around connector. Turn key to OFF position when solid flow is observed.
5. Tighten pipe connector securely.
6. Repeat steps 1–4 on No. 2 and 3 nozzles.

## Removing Debris From Engine Cooling System (Fig. 42)

Remove debris from engine area and radiator daily, clean more frequently in dirty conditions.

1. Remove radiator cover.
2. Turn engine off. Clean engine area thoroughly of all debris.
3. Remove screen cover from front of radiator.

4. Open radiator screen clean out door at lower left side of radiator and remove all debris from bottom of radiator inlet area.
5. Clean radiator thoroughly with water or compressed air.






Figure 42

1. Radiator screen cover
2. Clean out door


## Changing Engine Coolant (Fig. 43)

1. Park machine on a level surface.

CAUTION

If engine has been running, pressurized hot coolant can escape if radiator cap is removed and cause burns. Allow engine to cool at least 15 minutes or until the radiator cap is cool enough to touch without burning hand.


2. Raise the bed (if so equipped) and place safety support on extended lift cylinder to hold up the bed.
3. Remove radiator and reserve tank caps.



**Figure 43**

1. Radiator cap
2. Reserve tank cap

4. Open the coolant drain cock at bottom of the radiator and allow coolant to flow into drain pan. When coolant stops, close drain cock.
5. Open bleed screw on top of water pump (Fig. 44).



**Figure 44**

1. Bleed screw

6. Remove coolant drain plug from engine and allow coolant to flow into drain pan. When coolant stops, install drain plug.
7. Slowly fill radiator with a 50/50 mixture of water and permanent ethylene glycol anti-freeze. Install radiator cap.
8. Slowly fill reserve tank until level reaches COLD line. DO NOT OVERFILL. Install reserve tank cap.
9. Start engine and operate until warm. Tighten water pump bleed screw when water appears at the bleed screw.
10. Stop engine. Recheck level and replenish, if required.

## Adjusting Belts (Fig. 45–46)


Check condition and tension of all belts after first day of operation and every 200 operating hours thereafter. Raise bed (if so equipped) and place safety support on extended lift cylinder to hold up bed.

### Alternator Belt (Fig. 45)

1. Check tension by depressing belt at mid span of crankshaft and alternator pulleys with 30 Nm (22 lbs.) of force. A new belt should deflect 7–12 mm (0.3–0.5 in.). A used belt should deflect 10–14mm (0.4–0.55 in.). If deflection is incorrect, proceed to next step. If correct, continue operation.

2. To adjust belt tension:

Loosen alternator mounting bolts. Using a bar, rotate alternator until proper belt tension is attained, then tighten mounting bolts.



**Figure 45**

1. Alternator belt
2. Alternator brace

### Fan Belt (Fig. 46)

1. Check tension by depressing belt at mid span of fan and drive shaft pulleys with 10 Kg (22 lbs.) of force. A new belt should deflect 12–14mm (0.48–0.58 in.). A used belt should deflect 14–16mm (0.55–0.65 in.). If deflection is incorrect, proceed to next step. If correct, continue operation.

2. To adjust belt tension, loosen idler pulley mounting nut, move pulley to increase tension and tighten nut.




Figure 46

1. Fan belt
2. Idler pulley

## Adjusting Accelerator Pedal (Fig. 47)

If engine throttle lever does not contact high idle stop when accelerator pedal is fully depressed, an adjustment to the accelerator cable is required. Check adjustment every 200 operating hours.

1. Position vehicle on level surface, stop engine and engage the parking brake.

**Note:** Engine must not be running and return spring must be attached.

2. Adjust ball joint on accelerator cable to allow 2.5–6.3mm (0.100”–0.250”) clearance between accelerator pedal and top of diamond tread floor plate, when a 11kg (25 lb. force) is applied to center of pedal. Tighten locknut.




Figure 47

1. Accelerator cable
2. Ball joint
3. Locknut

3. Maximum high idle speed 3650 rpm. High idle stop should not be adjusted.



## WARNING



Engine must be running so final adjustment can be performed. To guard against possible personal injury, engage parking brake and keep hands, feet, face and other parts of the body away from fan or other moving parts.

## Cylinder Head Bolts

Re-torque initially after 50 operating hours and check every 1000 operating hours or annually thereafter.

## Engine Valve Clearance


Adjust initially at 50 operating hours and check every 600 operating hours or annually thereafter.

## Changing Transaxle/Hydraulic Fluid (Fig. 48)

Change Transaxle hydraulic fluid, filter and clean strainer every 800 hours.

1. Position the vehicle on a level surface, stop engine, engage the parking brake and remove key from ignition switch.
2. Remove drain plug from side of reservoir and let hydraulic fluid flow into drain pan. Reinstall and tighten plug when hydraulic fluid stops draining.
3. Fill reservoir with approximately 7.1 l (7.5 qt.) of Dexron III ATF. Refer to *Check Hydraulic Fluid*, p 18.
4. Start engine and operate to fill hydraulic system. Recheck oil level and replenish, if required.

**Important** Use only hydraulic fluids specified. Other fluids could cause system damage.



**Figure 48**

1. Hydraulic Reservoir
2. Drain plug

## Replacing Hydraulic Filter (Fig. 49)

Use the Toro replacement filter (Part No. 54-0110).

**Important** Use of any other filter may void the warranty on some components.

1. Position vehicle on a level surface, stop engine, engage parking brake and remove key from ignition switch.
2. Clean area around filter mounting area. Place drain pan under filter and remove filter.



**Figure 49**

1. Hydraulic Filter
2. Gasket


3. Lubricate new filter gasket.
4. Assure filter mounting area is clean. Screw filter on until gasket contacts mounting plate. Then tighten filter one-half turn.
5. Start engine and let run for about two minutes to purge air from the system. Stop the engine and check the hydraulic oil level and for leaks.

## Change Front Differential Oil

### Front-Wheel Drive Models Only (Fig. 50)

Change front differential oil every 800 hours.

1. Position vehicle on a level surface, stop engine, engage parking brake and remove key from ignition switch.
2. Clean area around drain plug on side of differential. Place drain pan under drain plug.




**Figure 50**

1. Front differential
2. Fill/check plug
3. Drain plug

3. Remove drain plug and let oil flow into drain pan. Reinstall and tighten plug when oil stops draining.
4. Clean area around fill/check plug on side of differential.
5. Remove fill/check plug and add 10W30 oil until oil is up to hole.
6. Re-install fill/check plug.

## Cleaning Hydraulic Strainer (Fig. 51)

1. Position the vehicle on a level surface, stop engine, engage the parking brake and remove key from ignition switch.
2. Remove drain plug (Fig. 48) from side of reservoir and let hydraulic fluid flow into drain pan.
3. Remove hydraulic line and fitting connected to strainer on side of reservoir.



**Figure 51**


1. Hydraulic strainer

4. Remove strainer and clean by back flushing with a clean degreaser. Allow to air dry before reinstalling.
5. Reinstall strainer.
6. Reinstall hydraulic line and fitting to strainer.
7. Reinstall and tighten drain plug.
8. Fill reservoir with approximately 7.1 l (7.5 qt.) of Dexron III ATF. Refer to *Check Hydraulic Fluid*, p 18.

## Adjusting the Brake Pedal (Fig. 52–53)

Check adjustment every 200 hours.

1. Loosen jam nut on link rod ball joint.
2. Rotate rod until gap between brake pedal and up stop is 0,5mm—2mm (0.020–0.080”).



**Figure 52**

1. Link rod ball joint

3. Tighten jam nut after adjustment has been attained.



**Figure 53**

1. Brake pedal
2. Clutch pedal
3. Clutch pedal up stop

## Adjusting the Clutch Pedal (Fig. 53–54)

Check adjustment every 200 hours.

1. Loosen jam nuts securing clutch cable to bracket on bell housing.

**Note:** Ball joint may be removed and rotated if additional adjustment is required.


2. Disconnect return spring from clutch lever.
3. Adjust jam nuts and/or ball joint until bottom rear edge of clutch pedal is 9.5 cm ± 3mm (3.75” ± 0.12”) from top of floor plate diamond pattern, when a 4-lb. force is applied to pedal.

**Note:** Force is applied so release bearing lightly contacts pressure plate fingers.

4. Reconnect return spring to clutch lever.
5. Verify that rear edge of clutch pedal is 14 cm ± 3mm (5.5" ± 0.12") from the top of the floor plate diamond pattern. If dimension is not attained, adjust clutch pedal up stop.


**Note:** Clutch free play should never be less than 1.9 cm (0.75").

6. Tighten jam nuts after adjustment has been attained.
7. Recheck clutch safety switch adjustment (Fig. 55). Engine must not crank unless clutch pedal is 2.9cm ± 6mm (1.25" ± .25") from floor. If an adjustment is required, loosen switch jam nuts and adjust up or down.



**Figure 54**

1. Clutch cable
2. Jam nuts
3. Return spring
4. Ball joint



**Figure 55**


1. Clutch switch

## Adjusting Parking Brake (Fig. 56)

Check adjustment every 200 hours.

1. Loosen the set screw securing knob to parking brake lever.

2. Rotate knob until a force of 47–61 Nm (35–45 lbs.) for 2-wd models and 61–75 Nm (45–55 lbs.) for 4-wd models is required to actuate lever.
3. Tighten set screw after adjustment has been attained.



**Figure 56**

1. Parking brake lever
2. Knob
3. Set screw

## Adjusting Shift Cables (Fig. 57)


Check adjustment every 200 hours.

1. Move shift lever to Neutral position.
2. Remove clevis pins securing shift cables to transaxle shift arms.
3. Loosen clevis jam nuts and adjust each clevis so cable free play is equal forward and backward relative to hole in transaxle shift arm (With transaxle lever free play taken up in same direction).
4. Reinstall clevis pins and tighten jam nuts after adjustments have been attained.

## Adjusting the High-Low Cable (Fig. 57)

Check adjustment every 200 hours.

1. Remove clevis pin securing High-Low cable to transaxle.
2. Loosen clevis jam nut and adjust clevis so clevis hole aligns with hole in transaxle bracket.
3. Reinstall clevis pin and tighten jam nut after adjustment has been attained.




**Figure 57**

1. Shift arm (1st—Rev.)
2. Shift arm (2nd—3rd)
3. Shift arm (High—low)

## Adjusting Differential Lock Cable (Fig. 58)

Check adjustment every 200 hours.

1. Move differential lock lever to Off position.
2. Loosen jam nuts securing differential lock cable to bracket on transaxle.



**Figure 58**

1. Differential lock cable
2. Transaxle bracket
3. Spring

3. While pulling back on spring, adjust jam nuts to obtain 0.89mm ± 0.64mm ( 0.035" ± .025") gap between spring hook and O. D. of hole in transaxle lever.

4. Tighten jam nuts after adjustment has been attained and recheck.

## Emergency Box Raising (without starting the engine)

The box can be raised in an emergency by cranking the starter and holding the lift lever. Run starter for 15 seconds then wait 60 seconds before engaging starter again.

If engine will not crank, the load and box (attachment) must be removed to service engine or transaxle.

## Inspect Brakes

Visually inspect brakes for worn brake shoes after every 600 hours of operation.


## Inspect Tires

Check tire condition at least every 100 hours of operation. Operating accidents, such as hitting curbs, can damage a tire or rim and also disrupt wheel alignment, so inspect tire condition after an accident.

## Front Wheel Toe-In (Fig. 59–60)

After every 600 operating hours or annually, check front wheel toe-in.

1. Measure center-to-center distance (at axle height) at front and rear of steering tires. Front measurement must be equal to the rear measurement ±3mm (1/8 in.).



**Figure 59**

1. Center-to-center distance

2. To adjust, loosen jam nuts at both ends of tie rod.



**Figure 60**

1. Tie rod

3. Rotate tie rod to move front of tire inward or outward.
4. Tighten tie rod jam nuts when adjustment is correct.

## Inspect Constant Velocity Boot

### Four-Wheel Drive Models Only


After every 200 operating hours, inspect constant velocity boot for cracks, holes or a loose clamp.

## Fuses (Fig. 61)

There are 3 fuses in the machine's electrical system. They are located under right side of dash panel.

### FUSES

OPEN	—
LIGHTS & HORN	10A
DASH	7.5A
IGNITION	7.5A



**Figure 61**

1. Fuse block

## Jump Starting Procedure




### WARNING



Jump starting can be dangerous. To avoid personal injury or damage to electrical components in vehicle, observe the following warnings:

- Never jump start with a voltage sources greater than 15 volts D. C. This will dam age the electrical system.
- Never attempt to jump start a discharged battery that is frozen. It could rupture or explode during jump starting.
- Observe all battery warnings while jump starting your vehicle.
- Be sure your vehicle is not touching the jump start vehicle.
- Connecting cables to the wrong post could result in personal injury and/or damage to the electrical system.

1. Loosen knobs securing battery cover to battery base and slide cover off.
2. Connect a jumper cable between the positive posts of the two batteries. The positive post may be identified by a "+" sign on top of battery cover.



**Figure 62**

1. Positive (+) cable

3. Connect one end of the other jumper cable to the

negative terminal of the battery in the other vehicle. The negative terminal has “NEG” on the battery cover. Do not connect the other end of the jumper cable to the negative post of the discharged battery. Connect it to the engine. Do not connect the jumper cable to the fuel system.

4. Start the engine in the vehicle providing the jump start. Let it run a few minutes, then start your engine.
5. Remove the negative jumper cable first from your engine, then the battery in the other vehicle.
6. Reinstall battery cover to battery base and tighten knobs.

## Battery Storage

If the machine will be stored for more than 30 days, remove the battery and charge it fully. Either store it on the shelf or on the machine. Leave the cables disconnected if stored on the machine. Store the battery in a cool atmosphere to avoid quick deterioration of the charge in the battery. To prevent battery from freezing, make sure it is fully charged. The specific gravity of a fully charged battery is 1.250.

## Battery Care

1. Battery electrolyte level must be properly maintained and the top of the battery kept clean. If the machine is stored in a location where temperatures are extremely high, the battery will run down more rapidly than if the machine is stored in a location where temperatures are cool.



### CAUTION



Wear safety goggles and rubber gloves when working with electrolyte. Charge the battery in a well-ventilated place so gasses produced while charging can dissipate. Since the gases are explosive, keep open flames and electrical spark away from the battery; do not smoke. Nausea may result if the gases are inhaled. Unplug charger from electrical outlet before connecting to or disconnecting charger leads from battery posts.

with a brush dipped in ammonia or bicarbonate of soda solution. Flush the top surface with water after cleaning. Do not remove the fill cap while cleaning.

3. Battery cables must be tight on terminals to provide good electrical contact.
4. If corrosion occurs at terminals, remove battery cover, disconnect cables, negative (-) cable first and scrape clamps and terminals separately. Reconnect cables, positive (+) cable first and coat terminals with petroleum jelly.
5. Check the electrolyte level every 50 operating hours or, if machine is in storage, every 30 days.
6. Maintain cell level with distilled or demineralized water. Do not fill cells above the bottom of the fill ring inside each cell.


2. Keep top of battery clean by washing periodically

# Maintenance Schedule


## Minimum Recommended Maintenance Intervals

Maintenance Procedure	Maintenance Interval & Service																		
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="padding: 5px;">Check battery fluid level/ cable connections</td> <td style="text-align: center; padding: 5px;">Every 50 hours</td> <td style="padding: 5px;">†</td> <td style="padding: 5px;">Every 100 hours</td> <td style="padding: 5px;">Every 200 hours</td> <td style="padding: 5px;">Every 400 hours</td> <td style="padding: 5px;">Every 800 hours</td> </tr> <tr> <td style="padding: 5px;">‡</td> <td style="padding: 5px;">Check dust cup/baffle</td> <td style="padding: 5px;">†</td> <td style="padding: 5px;">Every 100 hours</td> <td style="padding: 5px;">Every 200 hours</td> <td style="padding: 5px;">Every 400 hours</td> <td style="padding: 5px;">Every 800 hours</td> </tr> </table> <p style="margin-top: 10px;">Lubricate all grease fittings Inspect the condition and wear of the tires Check front differential oil level (4WD) ‡Change engine oil and filter Inspect cooling system hoses</p> <p>†Check cable adjustments †Check alternator and fan belts Service the air filter Check front axle boot joint (4-wheel drive) Check engine RPM (idle and full throttle) †Torque the wheel lug nuts</p> <p>Check front wheel alignment Inspect service and parking brakes Inspect fuel lines Replace electric fuel pump filter ‡Torque cylinder head and adjust valves</p> <p>†Replace the transaxle filter Change the transaxle oil Clean the transaxle strainer Change the front differential oil (4-wheel drive) Pack the front wheel bearings</p>	Check battery fluid level/ cable connections	Every 50 hours	†	Every 100 hours	Every 200 hours	Every 400 hours	Every 800 hours	‡	Check dust cup/baffle	†	Every 100 hours	Every 200 hours	Every 400 hours	Every 800 hours					
Check battery fluid level/ cable connections	Every 50 hours	†	Every 100 hours	Every 200 hours	Every 400 hours	Every 800 hours													
‡	Check dust cup/baffle	†	Every 100 hours	Every 200 hours	Every 400 hours	Every 800 hours													
<p>‡ Initial break in at 10 hours † Initial break in at 50 hours</p>																			
<p>Replace all interlock switches Flush the cooling the cooling system and replace fluid Drain and flush the fuel tank Change the brake fluid</p>	<p><b>Annual Recommendations</b> Items are recommended every 1200 hours or 2 years, whichever occurs first.</p>																		


# Hydraulic Schematic (Base Vehicle)



# Hydraulic Schematic (Vehicle w/Remote Hydraulic Kit) (MODELS 07205 TC and 07215 TC Only)




# Electrical Schematic (Base Vehicle)



T-3172-

# Electrical Schematic (Vehicle w/Remote Hydraulic Kit) (MODELS 07205 TC and 07215 TC Only)



# Identification And Ordering

## Model and Serial Numbers

The Workman® has two identification numbers: a model number and a serial number. These numbers are stamped into a plate located on the right frame member under dash. In any correspondence concerning the unit, supply the model and serial numbers to ensure correct information and replacement parts are obtained.

Note: Do not order by reference number if a parts catalog is being used; use the part number.

To order replacement parts from an authorized TORO Distributor, supply the following information:

1. Model and serial numbers.
2. Part number, description, and quantity of parts desired.