



**Count on it.**


Form No. 3447-541 Rev A

**Operator's Manual**

# MMX-658H-S and MMX-858H-S Mortar Mixer

Model No. 60216—Serial No. 322000001 and Up

Model No. 60220—Serial No. 322000001 and Up



G028568



It is a violation of California Public Resource Code Section 4442 or 4443 to use or operate the engine on any forest-covered, brush-covered, or grass-covered land unless the engine is equipped with a spark arrester, as defined in Section 4442, maintained in effective working order or the engine is constructed, equipped, and maintained for the prevention of fire.

The enclosed engine owner's manual is supplied for information regarding the US Environmental Protection Agency (EPA) and the California Emission Control Regulation of emission systems, maintenance, and warranty. Replacements may be ordered through the engine manufacturer.

**Tire Information**—The DOT tire information is located on the side of each tire. This information gives load and speed ratings. Replacement tires should have the same or better ratings; refer to [Specifications \(page 12\)](#) to ensure that the tires on your machine meet or exceed the weight requirements of your machine.

**⚠ WARNING**

**CALIFORNIA  
Proposition 65 Warning**

**The engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.**

**Use of this product may cause exposure to chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.**

# Introduction

This machine is designed to mix mortar, plaster, fireproofing material, grout, and other small-grained Portland cement products. A vehicle equipped with an appropriate pintle or ball hitch can tow the machine. Using this product for purposes other than its intended use could prove dangerous to you and bystanders.


Read this information carefully to learn how to operate and maintain your product properly and to avoid injury and product damage. You are responsible for operating the product properly and safely.

Visit [www.Toro.com](http://www.Toro.com) for more information, including safety tips, training materials, accessory information, help finding a dealer, or to register your product.

Whenever you need service, genuine Toro parts, or additional information, contact an Authorized Service

Dealer or Toro Customer Service and have the model and serial numbers of your product ready. [Figure 1](#) identifies the location of the model and serial numbers on the product. Write the numbers in the space provided.

**Important:** With your mobile device, you can scan the QR code on the serial number decal (if equipped) to access warranty, parts, and other product information.



**Figure 1**

1. Model and serial number location

**Model No.** \_\_\_\_\_

**Serial No.** \_\_\_\_\_

This manual identifies potential hazards and has safety messages identified by the safety-alert symbol ([Figure 2](#)), which signals a hazard that may cause serious injury or death if you do not follow the recommended precautions.



**Figure 2**  
Safety-alert symbol

This manual uses 2 words to highlight information. **Important** calls attention to special mechanical information and **Note** emphasizes general information worthy of special attention.

# Contents

Safety .....	4
General Safety .....	4
Safety and Instructional Decals .....	5
Setup .....	7
1 Installing the Dump Handle .....	7
2 Installing the Tow Pole .....	7
3 Installing the Safety Chain .....	8
4 Adjusting the Mixing Paddles .....	8
Product Overview .....	9
Controls .....	9
Engine Controls .....	11
Specifications .....	12
Before Operation .....	13
Before Operation Safety .....	13
Towing the Machine .....	14
Preparing to Use the Machine .....	17
Opening and Closing the Cowl .....	17
Adding Fuel .....	17
Performing Daily Maintenance .....	19
During Operation .....	19
During Operation Safety .....	19
Starting the Engine .....	20
Shutting Off the Engine .....	20
Adjusting the Axle Width .....	21
Mixing the Material .....	22
Dumping the Material .....	23
After Operation .....	23
After Operation Safety .....	23
Cleaning the Drum .....	23
Maintenance .....	24
Maintenance Safety .....	24
Recommended Maintenance Schedule(s) .....	24
Pre-Maintenance Procedures .....	25
Preparing the Machine for Maintenance .....	25
Disconnecting the Spark-Plug Wire .....	25
Removing the Divider Plate .....	26
Installing the Divider Plate .....	26
Lubrication .....	27
Lubricating the Bearings and Seals .....	27
Greasing the Wheel Bearings .....	28
Engine Maintenance .....	29
Servicing the Air Cleaner .....	29
Servicing the Engine Oil .....	30
Servicing the Spark Plug .....	32
Cleaning the Spark Arrester .....	33
Removing and Installing the Engine .....	34
Fuel System Maintenance .....	35
Cleaning the Fuel-Sediment Cup .....	35
Draining the Fuel Tank .....	36
Drive System Maintenance .....	36
Tire Air Pressure .....	36
Inspecting the Tires .....	36
Torquing the Wheel Lug Nuts .....	37
Servicing the Reduction Case .....	37
Belt Maintenance .....	39
Inspecting the Belts .....	39

# Safety

## **⚠ WARNING**

**Machining or handling stone, masonry, concrete, metal, and other materials can generate dust, mists, and fumes containing chemicals, such as silica, known to cause serious or fatal injury or illness, such as respiratory disease, silicosis, cancer, birth defects, or other reproductive harm.**

- **Control dust, mist, and fumes at the source where possible. Use water for dust suppression whenever possible.**
- **Use good work practices and follow the recommendations of the manufacturer or suppliers, OSHA, and other occupational and trade associations.**
- **Always follow respiratory precautions.**
- **When you cannot eliminate the hazards from inhalation, you and all bystanders should wear a respirator approved by OSHA for the material that you are handling.**

## **General Safety**

This product is capable of amputating hands. Always follow all safety instructions to avoid serious injury or death.

- Read and understand the contents of this *Operator's Manual* before starting the engine.
- Use your full attention while operating the machine. Do not engage in any activity that causes distractions; otherwise, injury or property damage may occur.

Adjusting the Belt Tension.....	39
Replacing the Belts.....	41
Aligning the Pulleys .....	42
Paddle Maintenance .....	43
Adjusting the Paddles .....	43
Cleaning .....	45
Cleaning the Machine .....	45
Storage .....	46
Storage Safety.....	46
Preparing the Machine for Storage .....	46
Troubleshooting .....	47

# Safety and Instructional Decals




Safety decals and instructions are easily visible to the operator and are located near any area of potential danger. Replace any decal that is damaged or missing.



125-4939

decal125-4939


1. Warning—read the *Operator's Manual*.
2. Hand and arm entanglement at the belt drive; crushing hazard of hand; entanglement hazard of hand at the shaft—keep hands away from moving parts; keep all guards and shields in place.
3. Entanglement hazard at paddles—shut off the engine and wait for all moving parts to stop before performing maintenance.
4. Toxic gas inhalation hazard—do not run the engine in an enclosed space.
5. Explosion hazard—shut off the engine and keep away from flames when refueling.



125-8175

decal125-8175


1. Read the *Operator's Manual* for information on greasing the machine.



125-8216

decal125-8216

1. Read the *Operator's Manual* for information on how to tow the machine.
2. Warning—limit towing speed to less than 88 km/h (55 mph).



decal130-8322

**130-8322**

1. Use only fuel with an alcohol content by volume under 10%.
2. Read the *Operator's Manual* for more information on fuel.
3. Do not use fuel with an alcohol content by volume greater than 10%.

---

**⚠ WARNING:** Cancer and Reproductive Harm - [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov).  
For more information, please visit [www.tcoCAProp65.com](http://www.tcoCAProp65.com)

**CALIFORNIA SPARK ARRESTER WARNING**  
Operation of this equipment may create sparks that can start fires around dry vegetation. A spark arrester may be required. The operator should contact local fire agencies for laws or regulations relating to fire prevention requirements.

133-8062

decal133-8062

**133-8062**

# Setup

## Loose Parts

Use the chart below to verify that all parts have been shipped.

Procedure	Description	Qty.	Use
<b>1</b>	Dump handle	1	Install the dump handle.
	Carriage bolt	2	
	Nut	2	
<b>2</b>	Tow pole kit (sold separately)	1	Install the tow pole (side-dump models only).
<b>3</b>	Safety chain (included with the tow pole kit)	1	Install the safety chain.
	Connecting link (included with the tow pole kit)	2	
<b>4</b>	No parts required	–	Adjusting the mixing paddles.

# 1


## Installing the Dump Handle

Parts needed for this procedure:

1	Dump handle
2	Carriage bolt
2	Nut

## Procedure

1. Cut the cable ties to remove the dump handle from the underside of the grate.
2. Install the dump handle to the side of the drum using 2 carriage bolts (installed on the inside of the drum) and nuts as shown in [Figure 3](#).



**Figure 3**

G028569  
g028569

# 2

## Installing the Tow Pole

### Parts needed for this procedure:

1	Tow pole kit (sold separately)
---	--------------------------------

### Tow Pole Specifications

Purchase the tow pole kit (including fasteners) that meets your needs from your Authorized Service Dealer. The machine has the following tow pole options:

Hitch Type	Length
50 mm (2 inch) ball—stamped	78.7 cm (31 inches) or 127 cm (50 inches)
50 mm (2 inch) ball—forged	78.7 cm (31 inches) or 127 cm (50 inches)
Pintle	78.7 cm (31 inches) or 127 cm (50 inches)

### Installing the Tow Pole

1. Remove the bolt and nut from the tow pole (Figure 4).




Figure 4

- |               |                  |
|---------------|------------------|
| 1. Tow pole   | 4. Bolt hole     |
| 2. Front post | 5. Frame fitting |
| 3. Bolt       | 6. Nut           |

2. Slide the tow pole forward and align the hole in the pole with the hole in the frame fitting (Figure 4).
3. Insert the bolt through the holes in the fitting and the pole (Figure 4).

4. Thread the nut onto the bolt and tighten them until they are tight against the frame fitting (Figure 4).

**Note:** If the self-locking nylon insert in the locknut wears with use, replace the nut with a new Grade 5 or Grade 8 locknut.

# 3

## Installing the Safety Chain

### Parts needed for this procedure:

1	Safety chain (included with the tow pole kit)
2	Connecting link (included with the tow pole kit)

### Procedure

Safety chain and connecting link are included in the tow pole kit (sold separately); refer to [2 Installing the Tow Pole \(page 7\)](#).

Form a hook on the end of a bendable piece of rod or stiff wire (not included) and install the safety chain and connecting links as shown in Figure 5.




Figure 5

**Note:** Ensure that approximately equal lengths of safety chain extend from either side of the front post.


# 4

## Adjusting the Mixing Paddles

No Parts Required

### Procedure

If the mixing paddles and wipers need adjustment, adjust the paddles and wipers; refer to [Adjusting the Paddles \(page 43\)](#).



**Figure 6**  
Right side


- |                   |                          |                    |
|-------------------|--------------------------|--------------------|
| 1. Rear cowl      | 7. Clutch lever          | 13. Chute          |
| 2. Front cowl     | 8. Drum latch            | 14. Axle           |
| 3. Grate          | 9. Front post            | 15. Wheel assembly |
| 4. Bag splitter   | 10. Tow pole             | 16. Cowl latch     |
| 5. Dump handle    | 11. Safety-chain keyhole |                    |
| 6. Grate lift arm | 12. Drum                 |                    |

## Controls

Become familiar with all the controls before you operate the machine.

### Clutch Lever

Use the clutch lever to engage and disengage the paddles.




**Figure 7**

- 
- 1. Clutch lever

## Dump Handle

Use the dump handle to rotate the drum to the dump position and to rotate the drum to the mix position (upright).




**Figure 9**

- 
- 1. Dump handle

## Drum Latch


Use the drum latch to secure the drum to the mix position (upright) for mixing operations and when transporting the machine.



**Figure 8**

- 
- 1. Drum latch

# Engine Controls




G019744  
g019744

**Figure 10**

- |                        |                   |
|------------------------|-------------------|
| 1. Recoil-start handle | 5. Fuel cap       |
| 2. Fuel valve          | 6. Oil dipstick   |
| 3. Choke lever         | 7. Oil-drain plug |
| 4. Throttle lever      | 8. On/Off switch  |

## Fuel Valve

The fuel valve (Figure 11) is located underneath the choke lever. Move the lever for the fuel valve to the ON position before attempting to start the engine. When you have finished mixing, shut off the engine and move the fuel-valve lever to the OFF position.



G018792

g018792

**Figure 11**

- |                |                   |
|----------------|-------------------|
| 1. Fuel valve  | 3. Throttle lever |
| 2. Choke lever |                   |

## Choke Lever

Use the choke lever (Figure 11) to start a cold engine. Before pulling the recoil-start handle, move the choke lever to the CLOSED position. Once the engine is running, move the choke lever to the OPEN position. Do not use the choke if the engine is already warmed up or if the air temperature is high.


## Throttle Lever

The throttle lever (Figure 11) controls the speed (rpm) of the engine. It is located next to the choke lever. It sets the engine speed and therefore can increase and decrease the rotation speed of the mixing paddles. For best performance, set this control to the FAST position when mixing material.

## Engine On/Off Switch

The On/Off switch is located on the front of the engine.

- Rotate it to the ON position to start and run the engine.
- Rotate it to the OFF position to shut off the engine.



G021103  
g021103

**Figure 12**

- |                 |                |
|-----------------|----------------|
| 1. OFF position | 2. ON position |
|-----------------|----------------|

## Recoil-Start Handle

To start the engine, pull the recoil-start handle (Figure 10) quickly to turn the engine over. The engine controls described above must all be set correctly for the engine to start.

## Oil-Level Switch

The oil-level switch is located inside the engine, and it does not allow the engine to run in the event the oil level is below the safe operating limit.

# Specifications

**Note:** Specifications and design are subject to change without notice.

## Machine Specifications

<b>Model</b>	60216	60220
<b>Batch Capacity</b>	0.23 m <sup>3</sup> (8.0 ft <sup>3</sup> )	0.23 m <sup>3</sup> (8.0 ft <sup>3</sup> )
<b>Total Volume</b>	0.24 m <sup>3</sup> (8.6 ft <sup>3</sup> )	0.24 m <sup>3</sup> (8.6 ft <sup>3</sup> )
<b>Drum Material</b>	Steel	Steel
<b>Length</b> (without tow pole)	168 cm (66 inches)	200 cm (79 inches)
<b>Width</b>	86 cm (34 inches)	86 cm (34 inches)
<b>Height</b>	142 cm (56 inches)	142 cm (56 inches)
<b>Weight</b>	289 kg (638 lb)	295 kg (650 lb)
<b>Axle</b>	87 to 117 cm (34 to 46 inches) extendable	88 to 117 cm (34 to 46 inches) extendable
<b>Engine</b>	Honda® GX240	Honda® GX240
<b>Drive</b>	Belt	Belt

# Operation

## Before Operation

### Before Operation Safety

#### General Safety

- All operators and mechanics should be trained. The owner is responsible for training them.
- Never let children or untrained people operate or service the equipment. Local regulations may restrict the age of the operator.
- Become familiar with the safe operation of the equipment, operator controls, and safety decals.
- Ensure that everyone using this product knows how to use it and understands the warnings.
- Ensure that all guards are securely in place before operating the machine.
- Park the machine on a level surface, shut off the engine, wait for all moving parts to stop, and allow the machine to cool before adjusting, cleaning, storing, or repairing the machine.

#### Fuel Safety

- Use extreme care in handling fuel. It is flammable and its vapors are explosive.
- Extinguish all cigarettes, cigars, pipes, and other sources of ignition.
- Use only an approved fuel container.
- Do not remove the fuel cap or fill the fuel tank while the engine is running or hot.
- Do not add or drain fuel in an enclosed space.
- Do not store the machine or fuel container where there is an open flame, spark, or pilot light, such as on a water heater or other appliance.
- If you spill fuel, do not attempt to start the engine; avoid creating any source of ignition until the fuel vapors have dissipated.

#### Towing Safety

- Check with your local county or state towing safety regulations before towing the machine.
- To reduce the possibility of an accident while transporting the machine on public roads, ensure that the towing vehicle is mechanically sound and in good operating condition.
- Shut off the engine and turn the fuel valve to the OFF position before transporting the machine.

- When towing with a ball hitch, ensure that it is the proper size for the hitch coupler on the machine.
- When towing with a pintle hitch, ensure that the eye of the tow pole is the correct dimension for the pintle hook.
- Inspect the hitch and coupling for wear. Do not tow the machine with damaged or worn hitches, couplings, chains, or other components.
- Check the air pressure of the tires on the towing vehicle and adjust the pressure as needed.
- Check the tire tread and sidewall for damage and wear and replace the tire if necessary.
- Properly attach the safety chains to the towing vehicle by crossing the chains and removing extra slack.
- Ensure that the directional and brake lights are working properly (if equipped).
- Ensure that the directional, backup, and brake lights of the tow vehicle are working properly (if equipped).
- Before towing, ensure that your machine is correctly and securely attached to the towing vehicle.
- Ensure that the safety chains are properly secured to the vehicle, and leave enough slack for turning.
- Do not carry any material in the machine when towing.
- Avoid sudden stops and starts. This can cause skidding or jackknifing. Smooth, gradual starts and stops improves towing.
- Avoid sharp turns to prevent rolling. Tow only with a vehicle that has a hitch designed for towing. Do not attach towed equipment except at the hitch point.
- Do not tow the machine faster than 88 km/h (55 mph).
- Use caution when backing up; use a spotter outside the vehicle to guide you.
- Do not allow anyone to sit or ride on the machine.
- Disconnect the machine from the tow vehicle before using it.
- Secure the machine to keep it from moving before you tow it.
- Place chocks underneath the tires to prevent them from rolling while the machine is parked.
- Park the machine on a level surface, shut off the engine, wait for all moving parts to stop, and allow the machine to cool before adjusting, cleaning, storing, or repairing the machine.

# Towing the Machine

Before towing the machine, read all the information and perform all the applicable procedures to in this section to ensure safe and proper towing.

## ⚠ WARNING

Towing the machine at high speed increases the risk of a hitch malfunction and tire failure. Higher speeds also increase the momentum of the machine and braking distance. If the machine detaches from the tow vehicle at high speed, it could cause damage to property, or injury or death to bystanders.

Do not exceed 88 km/h (55 mph) when towing the machine. For poor road conditions or inclement weather, reduce speed accordingly.

## ⚠ WARNING

Towing the machine with material in the drum increases the risk of a hitch malfunction and tire failure. In addition, material could bounce out of the drum and hit other vehicles and/or people. Material in the drum increases the weight, which affects momentum and braking distance.

Do not tow the machine with material in the drum.

- Test the brakes of the tow vehicle before towing.
- Avoid sudden starts and stops while towing the machine.

## Tow Vehicle Requirements

Before connecting the machine to your tow vehicle, ensure that your vehicle is prepared as follows:

- Ensure that your tow vehicle has towing capacity for the weight of the machine; refer to [Specifications \(page 12\)](#).
- Use a Class 2 or larger receiver.
- Ensure that your tow vehicle has the appropriate hitch to tow the machine; options include a 50 mm (2 inch) ball hitch or a pintle hitch.
- If the machine is equipped with a trailer-light kit, ensure that the electrical connector of the tow vehicle is compatible with the electrical connector of the machine. The machine uses a standard 4-pin, flat plug. If your tow vehicle has a different type of plug, obtain an adapter from an automotive parts store.

# Preparing the Machine for Towing

1. Shut off the engine and fuel valve.
2. Empty the drum.
3. Position the drum in the mix position (upright) and lock it.
4. Close the engine cowl and secure the cowl latches ([Figure 13](#)).




Figure 13

G022324

g022324

5. If you have adjusted the axle to the narrow position (if equipped on your model), extend the axle; refer to [Adjusting the Axle Width \(page 21\)](#).
6. Inspect the tires; refer to [Inspecting the Tires \(page 36\)](#).

## Hitching the Machine to a Tow Vehicle

Your machine is equipped with 1 of the following hitch types; hitch it as described in the appropriate procedure:

- Stamped-ball coupler— [Hitching a Stamped-Ball Coupler \(page 14\)](#)
- Forged-ball coupler— [Hitching a Forged-Ball Coupler \(page 15\)](#)
- Pintle-hitch coupler— [Hitching a Pintle-Hitch Coupler \(page 15\)](#)

### Hitching a Stamped-Ball Coupler

1. Apply chassis grease to the socket of the coupler and the area of the clamp that contacts the ball.
2. Oil the pivot points and sliding surfaces of the coupler with SAE 30 motor oil.
3. Hitch the machine as shown in [Figure 14](#).




Figure 14

### Hitching a Forged-Ball Coupler

1. Apply removable thread-locking compound to the threads of the coupler bolt to prevent the coupler handle from coming loose.

**Important:** Apply thread-locking compound as needed in the future.

2. Apply chassis grease to the socket of the coupler and the area of the clamp that contacts the ball.
3. Hitch the machine as shown in [Figure 15](#).




Figure 15

**Note:** Use a wrench to keep the bolt from spinning.

### Hitching a Pintle-Hitch Coupler





Figure 16

## Connecting the Safety Chains to the Tow Vehicle

1. Pull the safety chain through the slots in the keyholes, so that the lengths on each side are equal.
2. Cross both lengths of chain **under** the tow pole.

**Note:** Crossing the chains decreases the chances of the front of the machine dropping to the ground if the hitch does not hold the connection.



**Figure 17**


G021177  
g021177

1. Connecting links
2. Keyholes in front post
3. Chain crossed under tow pole

3. Connect each length of chain to the safety chain mounting point on the tow vehicle with the connecting links (Figure 18).

**Important:** Ensure that the chain has enough slack for turning around corners when towing the machine.

**Note:** Stow the excess chain inside the bottom of the front post by pushing it into the keyholes and latching the appropriate links into the keyhole slots.



G019927

g019927


**Figure 18**

1. Connecting link
2. Safety chain mounting point on tow vehicle
3. Chain link
4. Chain

## Connecting and Checking the Lights

### Machines Equipped with a Light Kit Only

1. Connect the electrical plug of the machine with the electrical plug of the tow vehicle (Figure 28).



G020828

g020828

**Figure 19**

**Note:** The machine uses a standard 4-pin, flat plug. If your tow vehicle has a different type of plug, obtain an adapter from an automotive parts store.

2. Ensure that the tow vehicle is in the NEUTRAL position, engage the parking brake, and start the engine.
3. Test the lights as follows:
  - A. Turn on the headlights of the tow vehicle. The tail lights of the machine should illuminate.
  - B. Press the brake pedal of the tow vehicle. The brake lights of the machine should illuminate.
  - C. Operate each turn signal of the tow vehicle in turn.

The corresponding turn-signal lights of the machine should illuminate.

## Preparing to Use the Machine

1. Park the machine on a level surface and disconnect the machine from the tow vehicle.
2. Ensure that all guards and paddles are in place and in good condition.
3. Perform all daily maintenance procedures prescribed in [Maintenance \(page 24\)](#).
4. Check the front and back of the tires to prevent the machine from moving.
5. Move the drum to the upright position and lock it.

## Opening and Closing the Cowl

### Opening the Cowl




Figure 20

### Closing the Cowl




Figure 21

## Adding Fuel

### **⚠ DANGER**

In certain conditions, fuel is extremely flammable and highly explosive. A fire or explosion from fuel can burn you and others and can damage property.

- Fill the fuel tanks outdoors, in an open area, when the engine is cold. Wipe up any fuel that spills.
- Never fill the fuel tanks inside an enclosed trailer.
- Never smoke when handling fuel and stay away from an open flame or where fuel fumes may be ignited by a spark.
- Store fuel in an approved container and keep it out of the reach of children. Never buy more than a 30-day supply of fuel.
- Do not operate without entire exhaust system in place and in proper working condition.

## ⚠ DANGER

In certain conditions during fueling, static electricity can be released, causing a spark that can ignite the fuel vapors. A fire or explosion from fuel can burn you and others and can damage property.

- Always place fuel containers on the ground away from your vehicle before filling.
- Do not fill fuel containers inside a vehicle or on a truck or trailer bed, because interior carpets or plastic truck bed liners may insulate the container and slow the loss of any static charge.
- When practical, remove equipment from the truck or trailer and refuel the equipment with its wheels on the ground.
- If this is not possible, then refuel such equipment on a truck or trailer from a portable container rather than from a fuel-dispenser nozzle.
- If you must use a fuel-dispenser nozzle, keep the nozzle in contact with the rim of the fuel tank or container opening at all times until fueling is complete.

## ⚠ WARNING

Fuel is harmful or fatal if swallowed. Long-term exposure to vapors can cause serious injury and illness.

- Avoid prolonged breathing of vapors.
- Keep your face away from the nozzle and fuel tank opening.
- Keep fuel away from your eyes and skin.

## Fuel Tank Specifications


Capacity	5.3 L (1.40 US gallons)
Type	Unleaded gasoline
Minimum octane rating	87 (US) or 91 (research octane; outside the US)
Ethanol	No more than 10% by volume
Methanol	None
MTBE (methyl tertiary butyl ether)	Less than 15% by volume
Oil	Do not add to the fuel

Use only clean, fresh (no more than 30 days old), fuel from a reputable source.

**Important:** To reduce starting problems, add fuel stabilizer/conditioner to fresh fuel as directed by the fuel-stabilizer/conditioner manufacturer.

## Filling the Fuel Tank

1. Park the machine on a level surface, shut off the engine, and allow the engine to cool.
2. Clean around the fuel cap and remove it (Figure 22).




G019799  
g019799

Figure 22

1. Fuel cap
3. Add fuel to the fuel tank until the level is at the maximum fuel level (Figure 23).

**Important:** This space in the tank allows fuel to expand. Do not fill the fuel tank completely full.



**Figure 23**

G020679  
g020679

1. Maximum fuel level

- 
4. Install the fuel cap securely ([Figure 22](#)).
  5. Wipe up any spilled fuel.

## Performing Daily Maintenance

Before starting the machine each day, perform the Each Use/Daily procedures listed in [Maintenance \(page 24\)](#).

## During Operation


## During Operation Safety

### General Safety

- The owner/user can prevent and is responsible for accidents or injuries to people or damage to property.
- Wear personal protective equipment (PPE) and appropriate clothing, including the following:
  - Hard hat
  - Respirator or dust mask
  - Face shield

- Safety glasses
  - Hearing protection
  - Substantial, slip-resistant footwear
  - Long pants
  - Shirt with long sleeves that are tight at the wrists
  - Tight-fitting gloves without drawstrings or loose cuffs
- Wear appropriate clothing, including eye protection; long pants; substantial, slip-resistant footwear; and hearing protection. Tie back long hair and do not wear loose clothing or loose jewelry.
  - Do not operate the machine under ill, tired, or under the influence of alcohol or drugs.
  - Use your full attention while operating the machine. Do not engage in any activity that causes distractions; otherwise, injury or property damage may occur.
  - Ensure that the machine is on a level surface before operating it.
  - Chock the tires of the machine to prevent unintended movement.
  - Before every use, do the following:
    - Inspect the coupler, ball, and hitch.
    - Ensure that all lights are functioning properly (if equipped).
    - Ensure that the tires are properly inflated.
    - Ensure that the lug nuts are tight and torqued properly.
    - Ensure that the machine is properly secured.
  - Before starting the machine, ensure that there are no people or obstacles near or under the machine.
  - Operate the machine only in good lighting conditions.
  - Do not place your hands or any solid object into the drum while the machine is in operation.
  - Never move the machine while the engine is running.
  - Keep the cowl closed and latched during operation.
  - Keep your hands away from any moving parts. Keep your feet away from the tires and the front post.
  - If the mixing paddles strike an object or if the machine starts making an unusual noise or vibration, shut off the engine, wait for all moving parts to stop, and empty the drum. Inspect for clogging or damage. Clean, repair, and/or replace any damaged parts.

- Operate the machine only in good visibility and appropriate weather conditions. Do not operate the machine when there is the risk of lightning.
- Do not run an engine in an enclosed or poorly ventilated area.
- Engine exhaust contains carbon monoxide, which is lethal if inhaled. Do not run the engine indoors or in an enclosed area.
- Always shut off the engine and wait for all moving parts to stop before leaving the machine.
- Use only accessories and attachments approved by Toro.




**Figure 25**

1. Engine switch—OFF position
2. Engine switch—ON position

## Starting the Engine

1. Ensure that the choke lever is in the OFF position.
2. Move the fuel valve to the OPEN position, all the way to the right (Figure 24).



**Figure 24**


1. Choke lever
2. Fuel valve
3. Throttle lever

3. Move the choke lever to the ON position (Figure 24).

**Note:** A warm or hot engine may not require choking.

4. Move the throttle lever 1/3 of the way toward the MAX position.
5. Move the engine switch to the ON position (Figure 25).

6. Pull the starter handle lightly until you feel resistance, then pull the handle briskly (Figure 26). Return the starter handle gently.



**Figure 26**

7. After the engine starts, gradually move the choke lever back to the OFF position. If the engine stalls or hesitates, move the choke back to the ON position again until the engine warms up. Then move it to the OFF position.

## Shutting Off the Engine

1. Move the throttle lever to the MIN position (Figure 11).


**Note:** If the engine has been working hard or is hot, let it idle for a minute before shutting off the engine. This helps to cool the engine before stopping. In an emergency, shut off the engine immediately.

2. Move the engine switch to the OFF position.
3. Move the fuel valve to the CLOSED position, all the way to the left.

# Adjusting the Axle Width

## Models with Adjustable Axles Only

If your model is equipped with an adjustable axle (Figure 28), you can adjust the axle to the narrow position to move the machine through a narrow access point, such as the gate of a fence or the doorway of a building.



1  
G020019

Figure 27

g020019

### ⚠ WARNING

The machine is not stable when towed with the axle in the narrow position.

Tow the machine with the axle in the wide position.

**Important:** The machine is less stable with the axle in the narrow position. Only adjust it to the narrow position when necessary to move past an obstruction, then return it to the wide position before towing or operating the machine.

1. Park the machine on a level surface and disconnect the machine from the tow vehicle.
2. Secure the machine from movement.
3. Empty the drum, move it to the upright position, and lock the drum.
4. Align a jack with an adequate lift height and weight capacity under the axle; refer to [Specifications \(page 12\)](#).
5. Lift the machine until the tires are off the ground.
6. Use a jack stand at each support point on the rear frame extension (Figure 27).


### ⚠ WARNING

Mechanical or hydraulic jacks may fail to support the machine and cause serious injury.

Use jack stands when supporting the machine.

1. Support point (2)

7. Remove the bolts and nuts that secure the inner axle to the outer axle (Figure 28).



G020020

g020020

Figure 28

1. Wide position (towing)
2. Narrow position
3. Nut—wide position
4. Nut—narrow position
5. Bolt—wide position
6. Bolt—narrow position

8. Align the inner axle to the desired position as follows:
  - Slide each side of the axle inward to the narrow position (Figure 28).
  - Slide each side of the axle outward to the wide (tow) position (Figure 28).
9. Secure the axle with the bolts and nuts removed previously (Figure 28) and torque them to 87 N·m (64 ft-lb).

# Mixing the Material

## ⚠ DANGER

Eye and skin contact with concrete materials and breathing the dust involved is hazardous to your health.

- Ensure that there is adequate air ventilation.
- Wear a dust mask to prevent inhalation of dust while using the machine.
- Avoid direct contact of cement and concrete materials with skin and eyes.

## ⚠ DANGER

This machine is capable of amputating hands.

- Stay in the operator's position while the machine is running.
- Keep bystanders away from the machine.
- Stop the machine immediately if any people or animals enter the work area.
- Never place any part of your body into a position that causes an unsafe operating condition.

**Important:** Do not add more material than the batch capacity of the machine; refer to [Specifications \(page 12\)](#).

**Note:** Follow the manufacturer's instructions that are printed on the packaging of the product you are using.


1. Ensure that there is no old, loose material in the drum that can contaminate the batch of material; refer to [Cleaning the Drum \(page 23\)](#) and [Dumping the Material \(page 23\)](#), then return the drum to the upright position.

**Note:** Ensure that the drum is in the mix position (upright) and the drum latch is engaged.

2. Move the clutch lever to the OFF position ([Figure 29](#)).
3. Start the engine.

**Note:** Allow the engine to warm up at 2/3 throttle for 1 to 2 minutes.

4. Set the throttle lever on the engine to the MAX position.
5. Move the clutch lever to the ON position ([Figure 29](#)).



G019873


g019873

Figure 29

1. OFF position
2. ON position

6. Add the ingredients for the batch as follows:
  - A. Pour water into the drum through the grate.
  - B. Add the plaster, cement, or other binding material.

**Note:** You can open bags of cement, plaster, and binding materials by lowering the bag onto the bag splitter ([Figure 30](#)).



G021179

g021179

Figure 30

- C. If you are using sand and/or other reinforcing materials, add them into the drum.

- Allow the paddles to mix the material until the ingredients have a uniform appearance.

**Note:** If needed, add water or plaster, cement, or other binding material until the consistency of the batch is correct.

## Dumping the Material


### **⚠ DANGER**

Contact with the mixing paddles could cause damage or injury.

Never put your hands inside the drum while the engine is running.

**Note:** When dumping a batch of material, leave the engine/motor running and the clutch in the ON position so that the rotating paddles help discharge the material.

- Align a wheelbarrow or similar container of adequate capacity in the path of the drum opening.
- Grasp the dump handle with your left hand (Figure 31).



**Figure 31**

- |                                |                               |
|--------------------------------|-------------------------------|
| 1. Dump handle—Mix position    | 3. Drum latch—Locked position |
| 2. Drum latch—Release position | 4. Dump handle—Dump position  |

- Lift the handle of the drum latch (Figure 31).

- With both hands on the dump handle, rotate it counterclockwise to discharge the contents of the drum (Figure 31).

**Note:** Allow the machine to completely discharge the contents of the drum.

- Rotate the dump handle **clockwise** until the drum latch locks the drum in the upright position (Figure 31).
- After dumping a batch of material, clean the drum to prevent dried material from contaminating the next batch of material; refer to [Cleaning the Drum \(page 23\)](#).

## After Operation

### After Operation Safety

#### General Safety

- Park the machine on a level surface, shut off the engine, wait for all moving parts to stop, and allow the machine to cool before adjusting, cleaning, storing, or repairing the machine.
- Chock the tires of the machine or keep it attached to the towing vehicle when it is not in use.
- Do not touch parts that may be hot from operation. Allow them to cool before attempting to maintain, adjust, or service the machine.

### Cleaning the Drum

**Important:** Do not strike on the drum with a shovel, hammer, or any other device to loosen any accumulated dried materials.

- Move the clutch lever to the OFF position to stop the paddles.
- Shut off the engine/motor.
- Ensure that the drum is in the mix position (upright).
- Spray the machine with water to remove any accumulated material.
- Start the engine/motor.
- Move the clutch lever to the ON position to start the paddles.
- Dump the drum.

# Maintenance

## **▲ WARNING**

Failure to properly maintain the machine could result in premature failure of machine systems, causing possible harm to you or bystanders.

Keep the machine well maintained and in good working order as indicated in these instructions.

*Important:* Refer to your engine operator's manual for additional maintenance procedures.

## Maintenance Safety

- Never allow untrained personnel to service the machine.
- Before performing maintenance, do the following:
  - Park the machine on a level surface.
  - Shut off the engine, disconnect the spark-plug wire, and wait for all movement to stop before adjusting, cleaning, or repairing the machine.
  - Allow the engine to cool before performing maintenance or storing the machine.
  - Disengage all power and operation controls.
- Keep your hands, feet, and clothing away from moving parts. If possible, do not make adjustments with the engine running.
- Never lubricate, service, repair, or adjust the machine while the engine is running.
- Keep all parts in good working condition and all hardware tightened. Replace all worn or damaged decals.
- Shut off the machine and inspect it if an object enters the drum or causes another obstruction. Make all necessary repairs before starting the machine.
- Do not tamper with safety devices.
- Remove any buildup of grease, oil, or debris from the machine.
- Keep equipment materials clear from the muffler and engine to prevent fires. Clean up oil or fuel spills.
- Keep all hardware and hose clamps securely tightened and all equipment in good working condition.
- Do not change the engine governor setting or overspeed the engine.
- Use only genuine Toro replacement parts.

## Recommended Maintenance Schedule(s)

Maintenance Service Interval	Maintenance Procedure
After the first 20 hours	<ul style="list-style-type: none"><li>• Change the reduction-case oil.</li></ul>
After the first 25 hours	<ul style="list-style-type: none"><li>• Change the engine oil.</li><li>• Inspect the belts and adjust as necessary (belt-drive models only).</li></ul>
Before each use or daily	<ul style="list-style-type: none"><li>• Inspect the air-cleaner elements.</li><li>• Check the engine-oil level.</li><li>• Inspect the tires.</li><li>• Check the reduction-case oil.</li></ul>
After each use	<ul style="list-style-type: none"><li>• Clean the drum between mixing batches of material.</li><li>• Lubricate the trunnions.</li><li>• Torque the wheel lug nuts to 108 to 122 N·m (80 to 90 ft-lb) after towing.</li></ul>
Every 40 hours	<ul style="list-style-type: none"><li>• Inspect the belts and adjust as necessary (belt-drive models only).</li><li>• Check the clutch operation</li></ul>
Every 50 hours	<ul style="list-style-type: none"><li>• Clean the air-cleaner elements. Clean them more frequently in dusty operating conditions.</li></ul>

Maintenance Service Interval	Maintenance Procedure
Every 100 hours	<ul style="list-style-type: none"> <li>• Change the engine oil.</li> <li>• Check the spark plug.</li> <li>• Clean the spark arrester (if equipped).</li> <li>• Clean the fuel-sediment cup.</li> <li>• Change the reduction-case oil.</li> </ul>
Every 300 hours	<ul style="list-style-type: none"> <li>• Replace the paper air-cleaner element. Replace it more frequently in dusty operating conditions.</li> <li>• Replace the spark plug.</li> </ul>
Monthly	<ul style="list-style-type: none"> <li>• Lubricate the pillow-block bearings.</li> </ul>
Yearly	<ul style="list-style-type: none"> <li>• Grease the wheel bearings.</li> </ul>
Yearly or before storage	<ul style="list-style-type: none"> <li>• Clean the fuel-sediment cup.</li> </ul>
Every 2 years	<ul style="list-style-type: none"> <li>• Replace the belts (belt-drive models only).</li> </ul>

**Important:** Refer to your *Engine Owner's Manual* for additional maintenance procedures.


## Pre-Maintenance Procedures

### Preparing the Machine for Maintenance

1. Shut off the engine and allow it to cool completely.
2. Park the machine on a level surface.
3. Remove the machine from the tow vehicle.
4. Secure the machine from movement.
5. Disconnect the spark-plug wire.

### Disconnecting the Spark-Plug Wire

Pull the spark-plug wire off the terminal of the spark plug ([Figure 32](#)).



G019281

g019281

**Figure 32**

1. Spark plug

## Removing the Divider Plate

If your model has a divider plate, you may need to remove it before performing some maintenance procedures:

1. Open the cowl.
2. Use a wrench to remove the 4 bolts that secure the divider plate to the front cowl.

**Note:** Retain the fasteners for installing the divider plate.




Figure 33

## Installing the Divider Plate

When finished performing maintenance, install the divider plate as follows:

1. Guide the divider plate into position against the front cowl.

**Note:** Start with the divider plate rotated slightly counterclockwise, and then rotate it clockwise while lowering it into position.

Ensure that the divider plate is not backward.




Figure 34

3. To remove the divider plate, lift it upward and tilt it back so that it clears various components.

2. Align the bolt holes in the divider plate and the front cowl.
3. Install each of the 4 bolts, and hand-tighten them to prevent cross-threading.
4. Tighten the bolts with a wrench until they are secure.

# Lubrication

## Lubricating the Bearings and Seals


**Service Interval:** After each use—Lubricate the trunnions.

Monthly—Lubricate the pillow-block bearings.

**Note:** The pillow-block bearings are inside the cowl—remove the divider plate if equipped) to access them; refer to [Removing the Divider Plate \(page 26\)](#).


**Grease Type:** No. 2 lithium grease.

1. Complete the procedures listed in [Preparing the Machine for Maintenance \(page 25\)](#).
2. Clean the area around each grease fitting with a rag and lift the plastic cap off the grease fitting ([Figure 35](#)).



G020684

g020684



G020685

g020685

**Figure 35**

1. Pillow-block bearings
2. Rear trunnion
3. Front trunnion

3. Pump grease into each fitting as follows:
  - For the pillow-block bearings, pump 1 shot of grease into each fitting ([Figure 35](#)).
  - For the trunnions, pump several shots of grease into each fitting until it starts to ooze out of the bearing housing ([Figure 35](#)).

**Important:** Pump grease in slowly and carefully to prevent damage to the bearing seals.

4. Wipe up any excess grease.

# Greasing the Wheel Bearings

## Removing the Wheels and Hub Assembly

1. Support the machine with jack stands.
2. Remove the lug nuts securing the wheel to the hub (Figure 36).




Figure 36

g314126

3. Remove the dust cap, cotter pin, nut retainer, and washer from the hub assembly (Figure 37).




Figure 37

g314127

- |                 |               |
|-----------------|---------------|
| 1. Hub assembly | 4. Cotter pin |
| 2. Washer       | 5. Dust cap   |
| 3. Nut retainer |               |

4. Remove the hub from the spindle.
5. Wipe clean the spindle with a rag.
6. Repeat steps 1 through 4 on the other side of the machine.

# Greasing the Wheel Bearings

Service Interval: Yearly

1. Remove the seal and bearings from the hub.




Figure 38

g314128

- |          |            |
|----------|------------|
| 1. Bolts | 3. Bearing |
| 2. Seal  | 4. Hub     |

2. Wipe clean the seal and check for wear and damage.

**Note:** Do not use cleaning solvent to clean the seal. Replace the seal if it is worn or damaged.

3. Clean the bearings and check for wear and damage.

**Note:** Replace all worn or damaged parts. Ensure that the bearings are clean and dry.

4. Clean the cavity of the hub of all grease, dirt, and debris.

5. Pack the bearings with the specified grease.

6. Fill the cavity of hub 50 to 80% full of the specified grease.

7. Assemble the bearing and seal back into the hub.

8. Repeat steps through on the other hub.

## Installing the Hub Assembly and Wheels

1. Apply a light coat of the specified grease to the spindle.

2. Assemble the hub assembly onto the spindle.

3. Assemble the outboard bearing onto the spindle and seat the bearing to the hub assembly.


4. Assemble the washer onto the spindle.

5. Thread the spindle nut onto the spindle and tighten the nut while rotating the hub.

**Note:** Tighten the nut and rotate the spindle until the bearings are fully seated and the hub has no linear-end movement.

6. Loosen the spindle nut until the hub rotates freely.

7. Torque the spindle nut to 27 N·m (20 ft-lb) while rotating the hub. Back the nut off 1 turn, and torque the spindle nut to 9 N·m (7 ft-lb).
8. Install the nut retainer and check the alignment of the slot in the retainer and the hole in the spindle for the cotter pin ([Figure 39](#)).



**Figure 39**

g314511

- 
9. Install the cotter pin and bend each leg around the retainer.
  10. Install the dust cap onto the hub.
  11. Secure the wheel on the machine with the lug nuts removed in [Removing the Wheels and Hub Assembly \(page 28\)](#).
  12. Torque the lug nuts to 108 to 122 N·m (80 to 90 ft-lb).
  13. Repeat steps 1 through 12 on the other side of the machine.

## Engine Maintenance

### Servicing the Air Cleaner

**Service Interval:** Before each use or daily—Inspect the air-cleaner elements.

Every 50 hours—Clean the air-cleaner elements. Clean them more frequently in dusty operating conditions.

Every 300 hours/Yearly (whichever comes first)—Replace the paper air-cleaner element. Replace it more frequently in dusty operating conditions.

**Important:** Do not operate the engine without the air-filter assembly; extreme engine damage will occur.

1. Shut off the engine and wait for all moving parts to stop.
2. Disconnect the wire from the spark plug; refer to [Disconnecting the Spark-Plug Wire \(page 25\)](#).
3. Remove the nut that secures the cover ([Figure 40](#)).




Figure 40

G019728 g019728

1. Cover nut
2. Cover
3. Wing nut
4. Foam element
5. Paper element
6. Base

4. Remove the cover.

**Note:** Be careful to prevent dirt and debris from falling into the base.

5. Remove the foam and paper elements from the base (Figure 40).
6. Remove the foam element from the paper element (Figure 40).
7. Inspect the foam and paper elements and replace them if they are damaged or excessively dirty.

**Note:** Never try to brush dirt off the paper element; brushing forces the dirt into the fibers.

8. Clean the foam element in warm, soapy water or in a **nonflammable** solvent.

**Note:** Do not use fuel to clean the foam element because it could create a risk of fire or explosion.

9. Rinse and dry the foam element thoroughly.
10. Dip the foam element in clean engine oil, then squeeze out the excess oil.

**Note:** Excess oil in the foam element restricts the air flow through the element and may reach the paper filter and clog it.

11. Wipe dirt from the base and the cover with a moist rag.

**Note:** Be careful to prevent dirt and debris from entering the air duct leading to the carburetor.

12. Install the air-cleaner elements and ensure that they are properly positioned.
13. Securely install the cover with the nut.

## Servicing the Engine Oil

### Engine-Oil Specifications


Toro Premium Engine Oil is available from your Authorized Toro Dealer.

**Important:** Use 4-cycle engine oil that meets or exceeds the requirements for API service category SJ, SL, SM, or higher.

Model(s)	Crankcase Capacity
60213 and 60213C	0.58 L (19.6 oz)
60216, 60216C, 60220, and 60220C	1.1 L (1.2 US qt)

**Important:** If the oil level in the crankcase is too low or too high and you run the engine, you may damage the engine. This type of damage is not covered by the warranty.

**Note:** Use SAE 10W-30 for general use. You can use the other viscosities shown in the chart when the average temperature in your area is within the indicated range (Figure 41).



g013375

g013375

Figure 41

## Checking the Engine-Oil Level

**Service Interval:** Before each use or daily

1. Park the machine on a level surface and shut off the engine.
2. Allow the engine to cool.
3. Disconnect the wire from the spark plug; refer to [Disconnecting the Spark-Plug Wire \(page 25\)](#).
4. Clean around the dipstick.
5. Check the oil level as shown in [Figure 42](#).




Figure 42

## Changing the Engine Oil

**Service Interval:** After the first 25 hours

Every 100 hours

### ⚠ WARNING

Oil may be hot after the engine has been run, and contact with hot oil can cause severe personal injury.

Avoid contacting the hot engine oil when you drain it.

1. Shut off the engine and wait for all moving parts to stop.
2. Disconnect the wire from the spark plug; refer to [Disconnecting the Spark-Plug Wire \(page 25\)](#).
3. Place a drain pan under the oil-drain hole of the engine ([Figure 43](#)).




Figure 43

1. Oil-drain plug
2. Oil-drain hole
3. Oil-drain pan

4. Remove the drain plug and catch the oil in the oil-drain pan ([Figure 43](#)).
5. When the oil has drained completely, install the drain plug with a new washer ([Figure 43](#)).

**Note:** Dispose of the used oil at a certified recycling center.

6. Remove the dipstick ([Figure 44](#)) and slowly pour oil into the fill hole until the oil reaches the upper-limit mark (bottom edge of the oil-fill hole) on the dipstick.




Figure 44

- |                  |                          |
|------------------|--------------------------|
| 1. Oil-fill hole | 3. Oil-level upper limit |
| 2. Dipstick      | 4. Oil-level lower limit |




Figure 45

- |               |         |
|---------------|---------|
| 1. Spark plug | 2. Wire |
|---------------|---------|

7. Replace and secure the dipstick.
8. Wipe up any spilled oil.

## Servicing the Spark Plug

**Service Interval:** Every 100 hours/Every 6 months (whichever comes first)—Check the spark plug.

Every 300 hours/Yearly (whichever comes first)—Replace the spark plug.

### Spark Plug Specifications

**Type:** NGK BPR6ES or equivalent

**Gap:** 0.7 to 0.8 mm (0.028 to 0.031 inch)

**Note:** Use a 21 mm (13/16 inch) spark-plug wrench for removing and installing the spark plug.

### Removing the Spark Plug

1. Park the machine on a level surface and shut off the engine.
2. Ensure that the machine surfaces are cool.
3. Pull the spark-plug wire off the terminal of the spark plug (Figure 45).

4. Clean around the spark plug.
5. Rotate the spark plug counterclockwise using a 21 mm (13/16 inch) spark-plug wrench to remove the plug and the sealing washer (Figure 46).




Figure 46

### Installing the Spark Plug

**Important:** Ensure that the gap between the side and center electrodes is correct before installing the spark plug.

1. Thread the spark plug clockwise into the spark-plug hole by hand.

**Note:** Avoid cross-threading the spark plug with the threads of the spark-plug hole.

2. Rotate the spark plug clockwise using a 21 mm (13/16 inch) spark-plug wrench until the plug and sealing washer are seated (Figure 46).
3. Tighten the spark plug as follows:

- When installing an **in-service** spark plug, tighten the plug an additional 1/8 to 1/4 turn.
- When installing a **new** spark plug, tighten the plug an additional 1/2 turn.

**Important:** A loose spark plug may cause the cylinder to overheat. An over-tight spark plug may damage the threads in the cylinder head.

4. Push the spark-plug wire onto the terminal of the spark plug ([Figure 45](#)).

## Cleaning the Spark Arrester

**Service Interval:** Every 100 hours


**Note:** A spark arrester is available as an option. If you require a spark arrester, contact your Authorized Service Dealer. Genuine Toro spark arresters are approved by the USDA Forestry Service.

### ⚠ WARNING

If the engine has been running, the muffler will be hot. Contact with hot surfaces may cause personal injury.

Keep your hands, feet, face, clothing and other body parts away from the muffler and other hot surfaces until they have cooled.

1. Park the machine on a level surface and shut off the engine.
2. Allow the engine to cool.
3. Disconnect the wire from the spark plug; refer to [Disconnecting the Spark-Plug Wire \(page 25\)](#).
4. Remove the divider plate (if equipped); refer to [Removing the Divider Plate \(page 26\)](#).
5. Remove the 2 nuts (8 mm) and remove the muffler from the cylinder ([Figure 47](#)).




**Figure 47**

- |                              |                 |                   |
|------------------------------|-----------------|-------------------|
| 1. Deflector (if applicable) | 5. Exhaust pipe | 9. Spark arrester |
| 2. Protector                 | 6. Nut (8 mm)   | 10. Screws (5 mm) |
| 3. Screw (6 mm)              | 7. Gasket       | 11. Exhaust port  |
| 4. Muffler                   | 8. Bolt (8 mm)  | 12. Screw (4 mm)  |

6. Remove the 3 screws (4 mm) from the exhaust deflector, and remove the deflector ([Figure 47](#)).

- Remove the screws (5 mm and 6 mm) from the muffler protector, and remove the muffler protector (Figure 47).
- Remove the screws (4 mm) from the spark arrester, and remove the spark arrester from the muffler (Figure 47).
- Use a brush to carefully remove carbon deposits from the spark-arrester screen (Figure 48).

**Note:** Replace the spark arrester if it has breaks or holes.




**Figure 48**

- Screen
- Brush

- Using a spring-removal tool (Toro Part No. 92-5771), remove the spring from the anchor bracket on the engine deck (Figure 49).

**Note:** Leave the other end of the spring attached to the frame of the machine.



**Figure 49**

- Anchor bracket
- Engine deck
- Spring-removal tool (Toro Part No. 92-5771)
- Spring-removal tool (spring removed)
- Spring (spring removed)

- Install the spark arrester, muffler protector, exhaust deflector, and muffler in the reverse order of disassembly.
- Install the divider plate (if equipped); refer to [Installing the Divider Plate \(page 26\)](#).

## Removing and Installing the Engine

### Removing the Engine


#### **⚠ WARNING**

The spring is under tension when installed and can cause personal injury.

Be careful when removing the spring.

- Park the machine on a level surface and shut off the engine.
- Allow the engine to cool.
- Disconnect the wire from the spark plug; refer to [Disconnecting the Spark-Plug Wire \(page 25\)](#).
- Remove the divider plate; refer to [Removing the Divider Plate \(page 26\)](#).
- Remove the belt guide; refer to [Adjusting the Belt Guide \(page 42\)](#).
- Remove the belts; refer to [Removing the Belts \(page 41\)](#).

- Remove the bolt and nut that secure the rear bracket for the engine deck hinge to the frame of the machine (Figure 50).



**Figure 50**

- Engine deck
  - Pivot
  - Rear hinge bracket
  - Frame
  - Nut
  - Bolt
- Lift up the rear edge of the engine deck and remove the hinge bracket (Figure 50).
  - Slide the engine deck rearward and out from the forward hinge bracket (Figure 51).

**Note:** Do not remove the forward hinge bracket.




Figure 51

G020121  
g020121

11. Remove the engine and engine deck from the machine (Figure 51).

## Installing the Engine

1. Align the engine and engine deck to the rear frame of the machine.  
**Note:** The drive pulley on the engine must align forward.
2. Align the pivot on the engine deck with the forward hinge bracket (Figure 51).
3. Slide the engine deck forward and the pivot into the forward hinge bracket (Figure 51).
4. Align the rear hinge bracket with the pivot on the engine-deck hinge (Figure 51).
5. Lift up on the rear edge of the engine deck and slip the hinge bracket onto the pivot.
6. Secure the rear bracket to the frame of the machine using the bolt and nut (Figure 50) removed in step 8 of Removing the Engine (page 34).
7. Using a spring-removal tool (Toro Part No. 92-5771), install the tension spring to the anchor bracket on the engine deck (Figure 49).
8. Install the belts and belt guide; refer to Installing the Belts (page 41).
9. Adjust the belt guide; refer to Adjusting the Belt Guide (page 42).
10. Install the divider plate; refer to Installing the Divider Plate (page 26).

# Fuel System Maintenance

## Cleaning the Fuel-Sediment Cup

**Service Interval:** Every 100 hours/Every 6 months (whichever comes first)—Clean the fuel-sediment cup.

Yearly or before storage—Clean the fuel-sediment cup.

Underneath the fuel valve is a sediment cup to catch dirt in the fuel.

1. Park the machine on a level surface and shut off the engine.
2. Allow the engine to cool.
3. Disconnect the wire from the spark plug; refer to [Disconnecting the Spark-Plug Wire \(page 25\)](#).
4. Move the lever of the fuel valve to the OFF position, all the way to the left (Figure 52).
5. Unscrew the fuel-sediment cup (Figure 52).
6. Remove and retain the fuel filter and O-ring (Figure 52).

**Note:** Do not clean the O-ring in solvent.




Figure 52

G019333  
g019333


1. Fuel valve—OFF position
2. O-ring
3. Fuel filter
4. Fuel-sediment cup

7. Clean the fuel filter and sediment cup using a nonflammable solvent, and dry it carefully.
8. Wipe the O-ring with a clean, dry cloth.
9. Install the fuel filter in the bottom of the carburetor (Figure 52).

10. Align the O-ring in to the groove in the sediment cup and install the sediment cup to the fuel-valve housing.
11. Move the lever of the fuel valve to the ON position (all the way to the right) and check for leaks. If it leaks, replace the O-ring.

## Draining the Fuel Tank

1. Remove the engine; refer to [Removing and Installing the Engine](#) (page 34).
2. Remove the fuel cap by rotating it counterclockwise ([Figure 53](#)).




G035167

Figure 53

g035167

3. Align a drain pan to the hinge of the engine deck.
4. Rotate the engine on the hinge side of the engine deck and drain the fuel from the tank ([Figure 54](#)).



G035168

Figure 54

g035168

5. Carefully lower the engine and engine deck.
6. Install the fuel cap.
7. Install the engine; refer to [Installing the Engine](#) (page 35).

# Drive System Maintenance

## Tire Air Pressure

The following table shows the appropriate air pressure for the tires as installed at the factory.

**Important:** Always check the information on the actual tires for the correct air pressure requirement.

Model	Maximum Air Pressure
60212, 60213, and 60216	414 kPa (60 psi)
60218, 60219, and 60220	241 kPa (35 psi)

## Inspecting the Tires

**Service Interval:** Before each use or daily

### ⚠ WARNING


Failure to maintain correct tire pressure may result in tire failure and loss of control, resulting in property damage and serious injury or death.

- Check the tire pressure frequently to ensure proper inflation. If the tires are not inflated to the correct pressure, they will wear prematurely.
- Inspect the tire condition before towing and after any operating accident.

The DOT tire information is located on the side of each tire. This information gives load and speed ratings. Replacement tires should have the same or better ratings


**Note:** Ensure that any tires installed on your machine meet or exceed the weight requirements of your machine as listed in [Specifications](#) (page 12).

1. Visually inspect the tires for damage and wear ([Figure 55](#) and [Figure 56](#)).



**Figure 55**

1. Example of tire wear caused by underinflation



**Figure 56**

1. Example of tire wear caused by overinflation
2. Ensure that the tires are inflated to the correct air pressure; refer to [Tire Air Pressure \(page 36\)](#).


**Important:** The most common cause of tire trouble is under-inflation. Maintain full air pressure.

## Torquing the Wheel Lug Nuts

**Service Interval:** After each use

Torque the wheel lug nuts initially and after towing.

Torque the wheel lug nuts 108 to 122 N·m (80 to 90 ft-lb), in the sequence shown in [Figure 57](#).



**Figure 57**

## Servicing the Reduction Case

**Important:** If the oil level in the reduction case is too low or too high and you run the engine, you may damage the engine or the reduction case. This type of damage is not covered by the warranty.

### Reduction-Case Oil Specifications

**Oil type:** 4-cycle, SAE 10W-30 motor oil


**Oil API service category:** SJ, SL, SM, or higher

**Reduction-case capacity:** 1.2 L (40 fl oz)

### Checking the Reduction-Case Oil

**Service Interval:** Before each use or daily—Check the reduction-case oil.

1. Park the machine on a level surface and shut off the engine.
2. Allow the engine to cool.
3. Disconnect the wire from the spark plug; refer to [Disconnecting the Spark-Plug Wire \(page 25\)](#).
4. Remove the divider plate; refer to [Removing the Divider Plate \(page 26\)](#).
5. Locate the reduction case between the engine and the engine pulley ([Figure 58](#)).




**Figure 58**

- |                                    |                           |
|------------------------------------|---------------------------|
| 1. Oil-level-check bolt and washer | 3. Reduction case         |
| 2. Oil level (normal)              | 4. Filler bolt and washer |

6. Align a rag below the oil-level port in the side of the reduction case.

7. Remove the oil-level-check bolt and washer from the oil-level port (Figure 58).
  - If the oil level is below the threads in the oil-level port, add oil as follows:
    - A. Remove the filler bolt and washer from the filler port on the top of the reduction case (Figure 58).
    - B. Slowly pour the specified oil into the fill port until the oil level is level with the threads at the bottom of the oil-level port.
    - C. Install the filler bolt and the washer to the filler port of the reduction case, and tighten the filler bolt (Figure 58).
  - If the oil level is too high, allow the oil to flow out until it is flush with the threads at the bottom of the oil-level port.
8. When the oil level is flush with the threads at the bottom of the oil-level port, install the oil-level-check bolt and washer to the port, and tighten the bolt (Figure 58).
9. Install the divider plate; refer to [Disconnecting the Spark-Plug Wire](#) (page 25).



**Figure 59**

- |                         |                   |                     |
|-------------------------|-------------------|---------------------|
| 1. Oil-level-check bolt | 3. Oil-level port | 5. Filler port bolt |
| 2. Washer               | 4. Pulley         | 6. Filler bolt      |


## Changing the Reduction-Case Oil

**Service Interval:** After the first 20 hours—Change the reduction-case oil.

Every 100 hours/Every 6 months (whichever comes first)—Change the reduction-case oil.

1. Park the machine on a level surface and shut off the engine.
2. Allow the engine to cool.
3. Disconnect the wire from the spark plug; refer to [Disconnecting the Spark-Plug Wire](#) (page 25).
4. Remove the engine; refer to [Removing the Engine](#) (page 34).
5. Drain the fuel tank; refer to [Draining the Fuel Tank](#) (page 36).
6. Remove the filler bolt and washer from the filler port on the top of the reduction case (Figure 59).

7. Remove the oil-level-check bolt and washer from the oil-level port in the side of the reduction case (Figure 59).
8. Align a drain pan to the hinge of the engine deck (Figure 60).



**Figure 60**

9. Rotate the engine on the hinge side of the engine deck, and drain the oil from the reduction case (Figure 60).
10. Carefully lower the engine and engine deck.
11. Slowly pour the specified oil into the fill port until the oil level is level with the threads at the bottom of the oil-level port (Figure 58).
12. Install the oil-level-check bolt and washer to the oil-level port of the reduction case, and tighten the bolt (Figure 59).

13. Install the filler bolt and washer to the filler port of the reduction case and tighten the filler bolt ([Figure 59](#)).
14. Install the engine; refer to [Installing the Engine \(page 35\)](#).

## **Belt Maintenance**

### **Inspecting the Belts**

**Service Interval:** After the first 25 hours—Inspect the belts and adjust as necessary (belt-drive models only).


Every 40 hours—Inspect the belts and adjust as necessary (belt-drive models only).

1. Park the machine on a level surface and shut off the engine.
2. Allow the machine to cool.
3. Disconnect the wire from the spark plug; refer to [Disconnecting the Spark-Plug Wire \(page 25\)](#).
4. Remove the divider plate; refer to [Removing the Divider Plate \(page 26\)](#).
5. Move the clutch lever to the OFF position.
6. Examine the belts for wear or damage. If the belts are worn or damaged, replace them; refer to [Replacing the Belts \(page 41\)](#).
7. Examine the pulleys for wear, damage, and misalignment; refer to [Aligning the Pulleys \(page 42\)](#).
8. Install the divider plate; refer to [Installing the Divider Plate \(page 26\)](#).

### **Adjusting the Belt Tension**


**Clutch air gap:** 2.5 to 6.5 mm (3/32 to 1/4 inch)

1. Park the machine on a level surface and shut off the engine.
2. Allow the machine to cool.
3. Disconnect the wire from the spark plug; refer to [Disconnecting the Spark-Plug Wire \(page 25\)](#).
4. Move the clutch lever to the ON position.
5. Measure the air gap between the engine deck and the roller on the clutch ([Figure 61](#)).



**Figure 61**

- |                  |   |
|------------------|---|
| 1. Engine deck   | 3. Clutch air gap: 2.5 to 6.5 mm (3/32 to 1/4 inch) |
| 2. Clutch roller |   |




**Figure 63**

- |                            |                 |
|----------------------------|-----------------|
| 1. Engine pulley           | 5. Idler shaft  |
| 2. Idler pulley            | 6. Jam nut      |
| 3. Reduction case (engine) | 7. Setscrew     |
| 4. Belt guide              | 8. Straightedge |

6. If the measured air gap is not within the specified range, adjust the gap as follows:

- A. Move the clutch lever to the OFF position.
- B. Loosen the nuts and bolts that secure the engine to the engine deck (Figure 62).



**Figure 62**

- |                 |                 |
|-----------------|-----------------|
| 1. Idler pulley | 3. Nut and bolt |
| 2. Setscrew     | 4. Engine deck  |

- C. Move the engine position as follows:
  - **Increase the air gap**—move the engine **away** from the idler pulley (Figure 62).
  - **Decrease the air gap**—move the engine **toward** the idler pulley (Figure 62).
- D. Align a straightedge across the engine pulley and the idler pulley (Figure 63).

- E. If necessary, pivot the engine on the engine deck until the engine pulley and idler pulley are aligned to the straightedge (Figure 63).
- F. Tighten the nuts and bolts that secure the engine to the engine deck to a torque of 18 N·m (13 ft-lb).
- G. Check the air gap between the engine deck and the roller on the clutch. If the air gap is not within the specified range, repeat step 6 until the air gap measurement is within the specified range.
- H. Install the divider plate; refer to [Installing the Divider Plate \(page 26\)](#).


**Important:** Ensure that the paddles do not rotate when the clutch lever is in the OFF position.

# Replacing the Belts

**Service Interval:** Every 2 years (belt-drive models only).


## Removing the Belts

1. Park the machine on a level surface and shut off the engine.
2. Allow the machine to cool.
3. Disconnect the wire from the spark plug; refer to [Disconnecting the Spark-Plug Wire \(page 25\)](#).
4. Move the clutch lever to the OFF position.
5. Remove the divider plate; refer to [Removing the Divider Plate \(page 26\)](#).
6. Remove the bolt that secures the belt guide to the engine, and remove the belt guide ([Figure 64](#)).



1. Bolt
2. Belt guide

7. Slip the forward belt forward and off the idler pulley ([Figure 65](#)).



**Figure 65**

1. Engine pulley
2. Forward belt
3. Idler pulley
4. Rear belt

8. Slip the rear belt rearward and off the idler pulley ([Figure 65](#)).
9. Slip the belts off the engine pulley.
10. Remove the belts from the machine.

## Installing the Belts


1. Park the machine on a level surface and shut off the engine.
2. Allow the machine to cool.
3. Disconnect the wire from the spark plug; refer to [Disconnecting the Spark-Plug Wire \(page 25\)](#).
4. Ensure that the clutch lever is in the OFF position.
5. Align the rear belt to the rear groove in the engine pulley.
- Note:** Do not align the rear belt to the idler pulley.
6. Align the forward belt to the forward groove of the idler pulley.
7. Slip the rear belt over the idler pulley and align the belt to the rear pulley groove.
8. Slip the forward belt over the engine pulley and align the belt to the forward pulley groove.
9. Check the belt tension; refer to step 4 through 6 in [Adjusting the Belt Tension \(page 39\)](#).
10. Loosely secure the belt guide to the engine ([Figure 64](#)) with the bolt that was removed in step 6 of [Replacing the Belts \(page 41\)](#).
11. Adjust the belt guide; refer to [Adjusting the Belt Guide \(page 42\)](#).
12. Install the divider plate; refer to [Installing the Divider Plate \(page 26\)](#).

## Adjusting the Belt Guide

**Note:** To access the belt guide, remove the divider plate; refer to [Removing the Divider Plate \(page 26\)](#).

**Guide air gap:** 2.5 to 4.0 mm (3/32 to 5/32 inch)

1. Park the machine on a level surface and shut off the engine.
2. Allow the machine to cool.
3. Disconnect the wire from the spark plug; refer to [Disconnecting the Spark-Plug Wire \(page 25\)](#).
4. Ensure that the clutch lever is in the ON position.
5. Ensure that the belt tension is correct; refer to [Adjusting the Belt Tension \(page 39\)](#).
6. Check that the air gap between the belt guide and the belts is 2.5 to 4.0 mm (3/32 to 5/32 inch); refer to [Figure 66](#).



**Figure 66**

- |   |               |
|---|---------------|
| 1. Engine pulleys                                   | 4. Belt guide |
| 2. Belts  | 5. Bolt       |
| 3. Guide air gap: 2.5 to 4.0 mm (3/32 to 5/32 inch) |               |

7. If the air gap is not within the specified range, do the following:
  - A. Loosen the bolt that secures the belt guide to the engine ([Figure 66](#)).

**Important:** Ensure that the belt guide is toward the engine pulley.

- B. Rotate the belt guide up or down until there is an air gap of 2.5 to 4.0 mm (3/32 to 5/32 inch) between the guide and each belt ([Figure 66](#)).

**Important:** The belt guide should not contact the belts with the clutch lever in the ON position.

**Note:** If the air gap between the belt guide and both belts cannot be attained, then 1 of the belts is too long.

- C. Tighten the bolt that secures the belt guide to the engine ([Figure 66](#)).
  - D. Check the clutch operation; refer to [Checking the Clutch Operation \(page 42\)](#).
8. Install the divider plate; refer to [Installing the Divider Plate \(page 26\)](#).

## Checking the Clutch Operation

**Service Interval:** Every 40 hours

**Important:** The paddles must not rotate in an empty drum when the clutch lever is in the OFF position.


1. Move the clutch lever to the OFF position.
2. Start the engine.
3. If the paddles rotate with the clutch lever to the OFF position do the following:
  - A. Shut off the engine.
  - B. Check the air gap between the belt guide and the belts.

**Note:** If the air gap is larger than 4.0 mm (5/32 inch), decrease the gap between the belt guide and the belts; refer to [Adjusting the Belt Guide \(page 42\)](#).

4. Repeat steps 1 through 3 until all the following conditions are met:
  - The engine is run at 2/3 throttle.
  - The clutch lever is in the OFF position.
  - The paddles do not rotate in an empty drum while the engine is running.

## Aligning the Pulleys

1. Park the machine on a level surface and shut off the engine.
2. Allow the machine to cool.
3. Disconnect the wire from the spark plug; refer to [Disconnecting the Spark-Plug Wire \(page 25\)](#).
4. Remove the divider plate; refer to [Removing the Divider Plate \(page 26\)](#).
5. Place a straightedge across the face of the engine pulley and idler pulley ([Figure 67](#)).



**Figure 67**

- |                  |                |
|------------------|----------------|
| 1. Engine pulley | 4. Idler shaft |
| 2. Idler pulley  | 5. Locknut     |
| 3. Straightedge  | 6. Set screw   |

**Note:** Both pulleys must be aligned flush with the straightedge.

6. If the pulleys are not aligned do the following:
  - A. Move the clutch lever to the OFF position.
  - B. Loosen the locknuts and setscrews that secure the idler pulley to the idler shaft (Figure 67).
  - C. Using a soft-face mallet, tap the idler pulley forward or backward along the idler shaft until the engine pulley and idler pulley are aligned to the straight edge (Figure 67).
  - D. Tighten the set screws and locknuts that secure the idler pulley to the idler shaft (Figure 67).
7. Install the divider plate; refer to [Installing the Divider Plate \(page 26\)](#).

# Paddle Maintenance


## Adjusting the Paddles

**Important:** Complete the [Preparing the Machine for Maintenance \(page 25\)](#) before adjusting any of the paddles.

**Note:** Over time, you may need to adjust the mixer paddles to account for wear.


## Aligning the Circumferential-Drum Wipers

1. Rotate a paddle from the left row of paddles around the drum and locate at the interior of the drum the smallest distance between the drum and the wiper of the paddle (Figure 68).
2. Mark the inside of the inside of the drum at the location that you determined in step 1.



**Figure 68**


3. Align the wiper of a paddle to the mark.
4. Loosen the carriage bolts and flanged locknuts that secure the paddle blade and wiper to the paddle (Figure 69).



**Figure 69**

- |  |                                      |
|--|--------------------------------------|
| 1. Wiper   | 4. Paddle blade                      |
| 2. Distance between paddle-blade edge and wiper edge—3 to 6 mm (1/8 to 1/4 inch) | 5. Carriage bolt and flanged locknut |
| 3. Wiper bar   |                                      |

- Adjust the position of the wiper so that the wiper lightly contacts the drum across the length of the wiper ([Figure 70](#)).




**Figure 70**

- Wiper lightly contacting the drum at the smallest distance between the drum and the wiper of the paddle
- Adjust the position of the paddle blade so that the outer edge is 3 to 6 mm (1/8 to 1/4 inch) from the outer edge of the wiper.
- Torque the carriage bolts and nuts to 19 to 25 N-m (14 to 18 ft-lb).
- Repeat steps 4 through 7 for the other paddle for that paddle row.
- Repeat the procedure for the other paddle rows.

## Aligning the End-Paddle Wipers

- Rotate the wiper and fixed paddle around the end plate of the drum and locate smallest distance between the drum and the wiper of the paddle.
- Mark the inside of the end plate at the location that you determined in step 1.



**Figure 71**

- |                                      |                           |
|--------------------------------------|---------------------------|
| 1. Carriage bolt and flanged locknut | 3. Drum end plate locknut |
| 2. Closest point of contact          |                           |

- Align the wiper of a paddle to the mark.
- Loosen the carriage bolts and flanged locknuts that secure the paddle blade and wiper to the fixed paddle. ([Figure 71](#))
- Adjust the position of the wiper so that the wiper lightly contacts the end plate across the length of the wiper.
- Adjust the position of the paddle blade so that the outer edge of the bar is 3 to 6 mm (1/8 to 1/4 inch) from the outer edge of the wiper.
- Torque the carriage bolts and nuts to 19 to 25 N-m (14 to 18 ft-lb).
- Repeat the procedure for the wiper at the end plate on the other end of the drum.

## Aligning the Adjustable-End Paddles

1. Align the adjustable-end paddle to the mark that you made in step 2 of [Aligning the End-Paddle Wipers](#) (page 44).
2. Loosen the carriage bolts and flanged locknuts that secure the adjustable end paddle to the fixed paddle. ([Figure 72](#))




Figure 72

1. Carriage bolt and flanged locknut
2. Closest point of contact
3. Drum endplate

3. Adjust the position of the adjustable-end paddle so that it is as close to the end plate as possible, across the length of the paddle, without touching end plate when the paddles are rotated.
4. Torque the carriage bolts and nuts to 37 to 45 N·m (27 to 33 ft-lb).
5. Repeat the procedure for the adjustable end paddle at the end plate on the other end of the drum.

## Cleaning

### Cleaning the Machine

Regular cleaning and washing with mild detergent and water increases the life span of the machine. Clean the machine after each use before the dirt hardens.

Remove dirt and grime from the external parts of the entire machine, especially the engine. Clean dirt and concrete materials from the outside of the engine.

Ensure that the fuel cap and the oil-fill cap/dipstick are secure to avoid getting water in the engine.

Use care when using a high-pressure sprayer because it can damage the safety decals, instruction signs, and the engine.

**Important:** Lubricate the bearings and seals after cleaning; refer to [Lubricating the Bearings and Seals](#) (page 27).

# Storage

## Storage Safety

- Allow the engine to cool before performing maintenance or storing the machine.
- Chock the tires when storing the machine.

## Preparing the Machine for Storage

For storage over 30 days, prepare the machine as follows:

1. Remove dirt and grime from the external parts of the entire machine, especially the engine. Clean dirt and debris from the outside of the engine cylinder-head fins and blower housing.

**Important:** You can wash the machine with mild detergent and water.

2. Condition the fuel system as follows:
  - A. Add a petroleum-based stabilizer/conditioner to fuel in the tank. Follow the mixing instructions from the stabilizer manufacturer. **Do not** use an alcohol-based stabilizer (ethanol or methanol).

**Important:** Do not store stabilizer/conditioned fuel over 90 days.

**Note:** Fuel stabilizer/conditioner is most effective when mixed with fresh fuel and used at all times.
  - B. Run the engine for 5 minutes to distribute the conditioned fuel through the fuel system.
  - C. Shut off the engine, allow it to cool, and drain the fuel tank using a pump-type siphon. Dispose of fuel properly; recycle it according to local codes.
  - D. Start the engine and run it until it stops.
  - E. Choke the engine.
  - F. Start and run the engine until it does not start again.
3. Clean the sediment cup; refer to [Cleaning the Fuel-Sediment Cup \(page 35\)](#).
4. Service the air cleaner; refer to [Servicing the Air Cleaner \(page 29\)](#).
5. Change the engine oil; refer to [Changing the Engine Oil \(page 31\)](#).
6. Remove the spark plug and check the condition; refer to [Servicing the Spark Plug \(page 32\)](#).

7. Condition the engine as follows:
  - A. Pour 2 tablespoons of engine oil into the spark-plug hole; refer to [Removing the Spark Plug \(page 32\)](#).
  - B. Pull the recoil-start handle slowly to crank the engine and distribute the oil inside the cylinder.
  - C. Install the spark plug; refer to [Installing the Spark Plug \(page 32\)](#).

**Note:** Do not install the wire on the spark plug.
8. Grease the machine; refer to [Lubricating the Bearings and Seals \(page 27\)](#).
9. Check and tighten all bolts, nuts, and screws. Repair or replace any part that is damaged.
10. Paint all scratched or bare metal surfaces with paint available from your Authorized Service Dealer.
11. Store the machine in a clean, dry garage or storage area.
12. Cover the machine to protect it and keep it clean.

# Troubleshooting

Problem	Possible Cause	Corrective Action
The engine does not start.	<ol style="list-style-type: none"> <li>1. The fuel-valve lever is in the OFF position.</li> <li>2. The choke is closed</li> <li>3. The choke is open.</li> <li>4. The engine On/Off switch is in the OFF position.</li> <li>5. The engine oil level is low (engines with the oil-level switch).</li> <li>6. The fuel tank is empty.</li> <li>7. The engine contains bad/old fuel.</li> <li>8. The spark plug is fouled or improperly gapped.</li> <li>9. The spark plug is wet with fuel (flooded engine).</li> <li>10. The spark-plug wire is loose or disconnected.</li> </ol>	<ol style="list-style-type: none"> <li>1. Move the fuel-valve lever to the ON position.</li> <li>2. Open the choke when starting a hot engine.</li> <li>3. Close the choke when starting a cold engine.</li> <li>4. Rotate the switch to the ON position.</li> <li>5. Fill the engine, with the recommended oil, to the proper level.</li> <li>6. Fill the fuel tank with fresh fuel.</li> <li>7. Drain the fuel tank and carburetor. Refuel with fresh fuel.</li> <li>8. Gap or replace the spark plug.</li> <li>9. Remove the spark plug, dry it, and install the plug. Start the engine with the throttle in the MAX position.</li> <li>10. Remove the spark-plug wire, clean the spark-plug terminal and the terminal socket in the boot of the spark-plug wire, and install the spark-plug wire.</li> </ol>
The engine lacks power or runs rough.	<ol style="list-style-type: none"> <li>1. The air filter is restricted.</li> <li>2. The engine contains bad or old fuel.</li> <li>3. There is water or contamination in the fuel.</li> <li>4. The fuel line is restricted.</li> <li>5. The choke is closed</li> <li>6. The spark plug is worn or has buildup on the electrodes.</li> <li>7. There is too much oil in the engine crankcase.</li> </ol>	<ol style="list-style-type: none"> <li>1. Clean or replace the air-filter element(s).</li> <li>2. Drain the fuel tank and carburetor. Refuel with fresh fuel.</li> <li>3. Drain the fuel tank and carburetor. Refuel with fresh fuel.</li> <li>4. Clean the fuel filter and sediment cup.</li> <li>5. Open the choke.</li> <li>6. Check the electrode gap and adjust or replace the spark plug.</li> <li>7. Drain the oil to the proper level.</li> </ol>
The belt slips or comes off the pulleys.	<ol style="list-style-type: none"> <li>1. The belt tension is insufficient.</li> <li>2. The belt is worn.</li> <li>3. The pulley(s) are worn.</li> <li>4. The pulley(s) are misaligned.</li> </ol>	<ol style="list-style-type: none"> <li>1. Adjust the belt tension.</li> <li>2. Replace the belt.</li> <li>3. Contact your Authorized Service Dealer.</li> <li>4. Align the pulley(s).</li> </ol>
The paddles rotate when the clutch lever is in the OFF position.	<ol style="list-style-type: none"> <li>1. The clutch lever is not adjusted correctly.</li> <li>2. The belt guide is not adjusted correctly.</li> </ol>	<ol style="list-style-type: none"> <li>1. Adjust the belt tension.</li> <li>2. Adjust the belt guide.</li> </ol>
The paddles do not rotate when the clutch lever is in the ON position.	<ol style="list-style-type: none"> <li>1. The clutch lever is not adjusted correctly.</li> <li>2. The paddles are stuck in the drum</li> </ol>	<ol style="list-style-type: none"> <li>1. Adjust the belt tension.</li> <li>2. Clean the paddles and drum.</li> </ol>
The paddles rotate slowly when the clutch lever is in the ON position.	<ol style="list-style-type: none"> <li>1. The clutch lever is not adjusted correctly.</li> </ol>	<ol style="list-style-type: none"> <li>1. Adjust the belt tension.</li> </ol>

# California Proposition 65 Warning Information

## What is this warning?

You may see a product for sale that has a warning label like the following:



**WARNING: Cancer and Reproductive Harm—[www.p65Warnings.ca.gov](http://www.p65Warnings.ca.gov).**

## What is Prop 65?

Prop 65 applies to any company operating in California, selling products in California, or manufacturing products that may be sold in or brought into California. It mandates that the Governor of California maintain and publish a list of chemicals known to cause cancer, birth defects, and/or other reproductive harm. The list, which is updated annually, includes hundreds of chemicals found in many everyday items. The purpose of Prop 65 is to inform the public about exposure to these chemicals.

Prop 65 does not ban the sale of products containing these chemicals but instead requires warnings on any product, product packaging, or literature with the product. Moreover, a Prop 65 warning does not mean that a product is in violation of any product safety standards or requirements. In fact, the California government has clarified that a Prop 65 warning "is not the same as a regulatory decision that a product is 'safe' or 'unsafe.'" Many of these chemicals have been used in everyday products for years without documented harm. For more information, go to <https://oag.ca.gov/prop65/faqs-view-all>.

A Prop 65 warning means that a company has either (1) evaluated the exposure and has concluded that it exceeds the "no significant risk level"; or (2) has chosen to provide a warning based on its understanding about the presence of a listed chemical without attempting to evaluate the exposure.

## Does this law apply everywhere?

Prop 65 warnings are required under California law only. These warnings are seen throughout California in a wide range of settings, including but not limited to restaurants, grocery stores, hotels, schools, and hospitals, and on a wide variety of products. Additionally, some online and mail order retailers provide Prop 65 warnings on their websites or in catalogs.

## How do the California warnings compare to federal limits?

Prop 65 standards are often more stringent than federal and international standards. There are various substances that require a Prop 65 warning at levels that are far lower than federal action limits. For example, the Prop 65 standard for warnings for lead is 0.5 µg/day, which is well below the federal and international standards.

## Why don't all similar products carry the warning?

- Products sold in California require Prop 65 labelling while similar products sold elsewhere do not.
- A company involved in a Prop 65 lawsuit reaching a settlement may be required to use Prop 65 warnings for its products, but other companies making similar products may have no such requirement.
- The enforcement of Prop 65 is inconsistent.
- Companies may elect not to provide warnings because they conclude that they are not required to do so under Prop 65; a lack of warnings for a product does not mean that the product is free of listed chemicals at similar levels.

## Why does Toro include this warning?

Toro has chosen to provide consumers with as much information as possible so that they can make informed decisions about the products they buy and use. Toro provides warnings in certain cases based on its knowledge of the presence of one or more listed chemicals without evaluating the level of exposure, as not all the listed chemicals provide exposure limit requirements. While the exposure from Toro products may be negligible or well within the "no significant risk" range, out of an abundance of caution, Toro has elected to provide the Prop 65 warnings. Moreover, if Toro does not provide these warnings, it could be sued by the State of California or by private parties seeking to enforce Prop 65 and subject to substantial penalties.