



Form No. 3378-845 Rev D

**Count on it.**

# Parts Catalog

## Groundsmaster® 3500-D Rotary Mower

Model No. 30807—Serial No. 313000001 and Up



# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

## Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

## Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

## Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.


For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# Contents

|                                                |    |
|------------------------------------------------|----|
| Frame and Roll-Over Protection System Assembly | 5  |
| Engine Installation Assembly                   | 6  |
| Air Cleaner and Exhaust Assembly               | 8  |
| Air Cleaner Assembly No. 93-2190               | 9  |
| Radiator and Oil Cooler Assembly               | 10 |
| Rear Lift Arm and Carrier Frame Assembly       | 12 |
| Hydraulic Cylinder Assembly No. 112-9916       | 13 |
| Sidewinder Carrier Assembly                    | 14 |
| Scissor Frame and Link Assembly                | 16 |
| Hydraulic Motor and Cutting Unit Assembly      | 17 |
| Gear Motor Assembly No. 117-5141               | 18 |
| Roller and Carrier Frame Assembly              | 19 |
| Roller Assembly No. 112-5265                   | 20 |
| Height-of-Cut Bracket Assembly                 | 21 |
| Chamber, Blade and Spindle Assembly            | 22 |
| Spindle Assembly No. 115-3435                  | 23 |
| Fuel Tank Assembly                             | 24 |
| Hydraulic Tank and Filter Assembly             | 26 |
| Battery Assembly                               | 27 |
| Seat Assembly                                  | 28 |
| Control Panel Assembly                         | 29 |
| Parking Brake and Dash Cover Assembly          | 30 |
| 2-Spool Control Valve Assembly                 | 31 |
| 2-Spool Control Valve Assembly No. 95-8581     | 32 |
| Manifold Block Assembly No. 115-3486           | 33 |
| Steering Arm Assembly                          | 34 |
| Steering Valve Assembly No. 104-5180           | 35 |
| Floorplate Assembly                            | 36 |
| Traction Pedal Assembly                        | 37 |
| Hood Assembly                                  | 38 |
| Wheel Motor and Brake Assembly                 | 39 |
| Brake Assembly No. 104-7705                    | 40 |
| Rear Fork and Wheel Assembly                   | 41 |
| Hydraulic Cylinder Assembly No. 94-8141        | 42 |
| Hydraulic Motor Assembly No. 95-8694           | 43 |
| Neutral Arm Assembly                           | 44 |
| Gear Pump and Piston Pump Assembly             | 45 |
| Hydraulic Pump Assembly No. 104-4890           | 46 |
| Hydraulic Gear Pump Assembly No. 108-9036      | 48 |
| Traction Hydraulic Assembly                    | 49 |
| Lift Hydraulic Assembly                        | 50 |
| Steering Hydraulic Assembly                    | 51 |
| Sidewinder Hydraulic Assembly                  | 52 |
| Mow Hydraulic Assembly                         | 53 |
| Crankcase Assembly                             | 54 |
| Oil Pan Assembly                               | 55 |
| Cylinder Head Assembly                         | 56 |
| Gear Case and Oil Filter Cartridge Assembly    | 57 |
| Cylinder Head Cover Assembly                   | 58 |
| Dipstick and Guide Assembly                    | 59 |
| Main Bearing Case Assembly                     | 60 |
| Camshaft and Idle Gear Shaft Assembly          | 61 |
| Piston and Crankshaft Assembly                 | 62 |
| Flywheel Assembly                              | 63 |

## Contents (continued)


|                                                     |    |
|-----------------------------------------------------|----|
| Fuel Camshaft and Governor Shaft Assembly . . . . . | 64 |
| Idle Apparatus and Stop Solenoid Assembly . . . . . | 65 |
| Injection Pump Assembly . . . . .                   | 66 |
| Governor Assembly . . . . .                         | 67 |
| Speed Control Plate Assembly . . . . .              | 68 |
| Nozzle Holder and Glow Plug Assembly . . . . .      | 69 |
| Nozzle Holder Assembly . . . . .                    | 70 |
| Alternator and Pulley Assembly . . . . .            | 71 |
| Alternator Components Assembly . . . . .            | 72 |
| Starter Assembly . . . . .                          | 73 |
| Starter Component Assembly . . . . .                | 74 |
| Water Flange and Thermostat Assembly . . . . .      | 75 |
| Water Pump Assembly . . . . .                       | 76 |
| Valve and Rocker Arm Assembly . . . . .             | 77 |
| Inlet and Exhaust Manifold Assembly . . . . .       | 78 |
| Miscellaneous Engine Parts . . . . .                | 79 |
| Upper and Lower Gasket Kits . . . . .               | 80 |
| Attachments and Accessories . . . . .               | 81 |



## Frame and Roll-Over Protection System Assembly

| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 1    | 120-3549-03 | 1    | Frame                  |
| 2    | 95-8568-03  | 1    | Frame-Lower            |
| 3    | 32144-15    | 2    | Screw-HHFTF            |
| 4    | 3234-38     | 8    | Screw-HHF              |
| 5    | 32128-49    | 12   | Nut-HHF                |
| 6    | 99-3375-03  | 1    | Step                   |
| 7    | 2412-72     | 3    | Clip-Closed, Insulated |
| 8    | 95-8615     | 1    | Tube-Breather          |
| 9    | 32144-10    | 6    | Screw-HWH              |
| 10   | 3234-4      | 2    | Screw-HHF              |
| 11   | 104-0468-01 | 1    | Cover-Frame            |
| 12   | 3234-5      | 2    | Screw-HHF              |
| 13   | 107-7833    | 1    | ROPS ASM               |
| 13:1 | 107-7831    | 1    | Decal-ROPS             |


| Ref. | Part Number | Qty. | Description               |
|------|-------------|------|---------------------------|
| 14   | 3234-40     | 4    | Screw-HF                  |
| 15   | 32148-8     | 2    | Nut-Clinch                |
| 16   | 115-3417-03 | 1    | Bracket-Bulkhead, Scissor |
| 17   | 104-7050    | 1    | Tube-Manual               |
| 18   | 2412-133    | 2    | Clamp-R                   |
| 19   | 32144-70    | 2    | Screw-HWHTF               |
| 20   | 3256-23     | 2    | Washer-Plain              |
| 21   | 2412-108    | 1    | Clamp-Worm                |
| 22   | 32148-6     | 2    | Nut-Clinch                |
| 23   | 104-4634-03 | 1    | Toolbox                   |
| 24   | 104-4633-03 | 1    | Cover-Toolbox             |
| 25   | 104-0484    | 1    | Decal-Danger              |
| 26   | 104-5181    | 1    | Decal-Danger, CE          |
| 27   | 104-7048    | 1    | Cap-Housing               |



## Engine Installation Assembly

| Ref. | Part Number | Qty. | Description                |
|------|-------------|------|----------------------------|
| 1    | 125-4314    | 1    | Engine-Kubota, D1105       |
| 2    | 83-1030     | 2    | Mount-Engine               |
| 3    | 93-5265     | 1    | Mount-Engine               |
| 4    | 32128-20    | 6    | Nut-HF                     |
| 5    | 323-11      | 3    | Screw-HH                   |
| 6    | 3234-5      | 6    | Screw-HHF                  |
| 7    | 3255-8      | 1    | Washer-Lock                |
| 8    | 3296-39     | 3    | Nut-Lock, NI               |
| 9    | 80-8560     | 3    | Washer-Hardened            |
| 10   | 42-9370     | 1    | Screw-HH                   |
| 11   | 80-6990     | 9    | Washer-Hardened            |
| 12   | 95-8812     | 5    | Screw-HH                   |
| 13   | 99-3618-03  | 1    | Mount-Engine, Front        |
| 14   | 95-8937-03  | 1    | Mount-Engine, LH           |
| 15   | 100-4838-03 | 1    | Mount-Engine               |
| 16   | 63-7790     | 4    | Screw-Cap                  |
| 17   | 99-3626-03  | 1    | Pulley                     |
| 18   | 56-2140     | 3    | Screw-HH                   |
| 19   | 32128-44    | 2    | Nut                        |
| 20   | 115-3487-03 | 1    | Bracket-Mount, Fuel Filter |
| 21   | 98-9311     | 1    | Swivel-Throttle            |


| Ref. | Part Number | Qty. | Description                |
|------|-------------|------|----------------------------|
| 22   | 3296-20     | 1    | Nut-Lock, NI               |
| 23   | 81-1690     | 1    | Clamp-Cable                |
| 24   | 32105-13    | 1    | Screw-HWH                  |
| 25   | 3290-379    | 2    | Tie-Cable                  |
| 26   | 3296-2      | 1    | Nut-Lock, NI               |
| 27   | 3255-9      | 1    | Washer-Lock                |
| 28   | 3256-25     | 1    | Washer-Flat                |
| 29   | 3234-17     | 2    | Screw-HHF                  |
| 30   | 3256-78     | 1    | Washer-Flat                |
| 31   | 2412-10     | 1    | Clamp-R                    |
| 32   | 43-5930     | 1    | Washer-Lock, Spring        |
| 33   | 48-7890     | 1    | Nut-Hex                    |
| 34   | 99-3441     | 1    | Harness-Wire, Fusible Link |
| 35   | 2412-34     | 2    | Clamp-Hose                 |
| 36   | 3290-378    | 14   | Tie-Cable                  |
| 37   | 95-8736     | 1    | Spacer                     |
| 38   | 98-9611     | 1    | Gasket                     |
| 39   | 3256-24     | 3    | Washer-Flat                |
| 40   | 106-7772    | 1    | Thermoswitch               |
| 41   | 112-9919    | 1    | Stop-Cable, Throttle       |
| 42   | 110-9009-03 | 1    | Bracket-Cable, Throttle    |



## Engine Installation Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|------|-------------|------|-------------|
| 43   | 70-8470     | 1    | Screw-HH    |
| 44   | 33104-016   | 1    | Screw-HHF   |
| 45   | 33114-060   | 3    | Screw-HH    |

| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 46   | 87-8640     | 3    | Washer-Flat        |
| 47   | 120-3375-03 | 1    | Plate-Mount, Pump  |
| 48   | 95-8941     | 4    | Spacer-Mount, Pump |



## Air Cleaner and Exhaust Assembly


| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 1    | 120-3354    | 1    | Hose-Air Inlet, Upper |
| 2    | 95-8947     | 1    | Hose-Air Inlet, Lower |
| 3    | 32128-44    | 6    | Nut                   |
| 4    | 3234-5      | 3    | Screw-HHF             |
| 5    | 3256-23     | 2    | Washer-Plain          |
| 6    | 33114-016   | 2    | Screw-HH              |
| 7    | 99-3355-03  | 1    | Bracket-Filter, Air   |
| 8    | 2412-92     | 3    | Clamp-Hose            |
| 9    | 93-2190     | 1    | Air Cleaner ASM       |
| 10   | 33014-00    | 4    | Nut-Hex               |
| 11   | 3253-4      | 4    | Washer-Lock           |

| Ref. | Part Number | Qty. | Description                   |
|------|-------------|------|-------------------------------|
| 12   | 93-2191     | 1    | Air Cleaner Mounting Band ASM |
| 12:2 | 94-3653     | 1    | Bolt                          |
| 12:3 | 94-3654     | 1    | Spring                        |
| 12:4 | 48-9510     | 1    | Nut                           |
| 13   | 104-4834    | 1    | Muffler                       |
| 14   | 95-8943-03  | 1    | Bracket-Muffler               |
| 15   | 99-3425-03  | 1    | Guard-Exhaust                 |
| 16   | 32144-4     | 4    | Screw-HWH                     |
| 17   | 3234-17     | 3    | Screw-HHF                     |
| 18   | 2412-130    | 1    | Clamp-Hose                    |



## Air Cleaner Assembly No. 93-2190


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 2           | 108-3811           | 1           | Filter-Air         |
| 3           | 94-3652            | 1           | Cover ASM          |
| 3:1         | 1-643283           | 2           | Latch-Cleaner, Air |
| 4           | 87-9400            | 1           | Valve-Vacuator     |
| 5           | 285-17             | 1           | Plug-Pipe          |



## Radiator and Oil Cooler Assembly


| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 1    | 304-46      | 1    | Draincock              |
| 2    | 32104-116   | 10   | Screw-HWHTF            |
| 3    | 32128-44    | 4    | Nut                    |
| 4    | 3230-1      | 4    | Bolt-CARR              |
| 5    | 117-5135    | 1    | Radiator               |
| 5:1  | 121-3518    | 1    | Cap-Radiator           |
| 6    | 100-4885-03 | 1    | Shroud-Fan, Top        |
| 7    | 119-2008-03 | 1    | Shroud-Fan, Lower      |
| 8    | 3234-1      | 4    | Screw-HHF              |
| 9    | 92-2379     | 2    | Clamp-Hose             |
| 10   | 104-4855-03 | 1    | Frame-Radiator         |
| 11   | 2412-129    | 4    | Clamp-Hose             |
| 12   | 3234-5      | 2    | Screw-HHF              |
| 13   | 100-4899-03 | 1    | Bracket-Reservoir      |
| 14   | 95-8702-03  | 1    | Shield-Radiator, Lower |
| 15   | 99-3497     | 1    | Magnet                 |
| 16   | 100-4869    | 1    | Cooler-Oil             |
| 17   | 104-0454    | 1    | Hose-Radiator, Upper   |
| 18   | 120-3353    | 1    | Hose-Radiator, Lower   |
| 19   | 2412-34     | 2    | Clamp-Hose             |
| 20   | 99-3644     | 1    | Tube-Head, Filter      |

| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 21   | 100-4925    | 1    | Fitting-Bulkhead       |
| 22   | 99-3646     | 2    | Hose-Cooler, Oil       |
| 23   | 99-7435     | 1    | Relay                  |
| 24   | 32105-13    | 1    | Screw-HWH              |
| 25   | 109-0274    | 1    | Hose-Fuel              |
| 26   | 115-3489    | 1    | Tube ASM               |
| 27   | 3296-2      | 1    | Nut-Lock, NI           |
| 28   | 104-9318    | 1    | Bottle-Overflow        |
| 29   | 93-6681     | 1    | Decal-Warning, Fan     |
| 30   | 32128-20    | 2    | Nut-HF                 |
| 31   | 340-126     | 1    | Nut-Bulkhead           |
| 32   | 100-4866    | 1    | Grommet                |
| 33   | 100-4858    | 2    | Form-Wire              |
| 34   | 100-4859    | 2    | Bracket-Cooler, Keeper |
| 35   | 100-4860    | 2    | Bracket-Clamp          |
| 36   | 322-17      | 2    | Screw-HH               |
| 37   | 3296-47     | 2    | Nut-Lock, NI           |
| 38   | 104-9459    | 2    | Seal-Foam              |
| 39   | 119-2038    | 1    | Screw-HWH              |
| 40   | 340-66      | 1    | Fitting-Straight       |



## Radiator and Oil Cooler Assembly (continued)


| Ref. | Part Number | Qty. | Description |
|------|-------------|------|-------------|
| 40:1 | 237-80      | 1    | O-Ring      |
| 40:2 | 237-58      | 1    | O-Ring      |



## Rear Lift Arm and Carrier Frame Assembly


| Ref. | Part Number | Qty. | Description               |
|------|-------------|------|---------------------------|
| 1    | 112-9916    | 1    | HYD Cylinder ASM          |
| 2    | 3-6498      | 1    | Washer-Thrust             |
| 3    | 95-8990     | 1    | Shaft-Pivot, Rear         |
| 4    | 3220-9      | 1    | Nut-Jam                   |
| 5    | 86-1480     | 1    | Washer                    |
| 6    | 115-3473    | 1    | Rear Liftarm ASM          |
| 6:1  | 69-6470     | 2    | Bushing-Caster            |
| 6:3  | 302-5       | 1    | Fitting-Grease            |
| 7    | 3234-27     | 1    | Screw-HHF                 |
| 8    | 75-7730     | 1    | Washer-Thrust             |
| 10   | 100-4944    | 1    | Shaft-Pivot, Cutting Unit |
| 11   | 323-6       | 1    | Screw-HH                  |
| 12   | 323-4       | 1    | Screw-HH                  |
| 13   | 63-7400     | 1    | Washer-Rebound            |

| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 14   | 3-6781      | 1    | Washer-Thrust          |
| 15   | 283-71      | 1    | Pin-Lynch              |
| 16   | 104-0453-03 | 1    | Guard                  |
| 17   | 322-12      | 2    | Screw-HH               |
| 18   | 322-3       | 2    | Screw-HH               |
| 19   | 32128-20    | 4    | Nut-HF                 |
| 20   | 32120-93    | 3    | Ring-Retaining         |
| 21   | 95-8575     | 1    | Pin-Clevis             |
| 22   | 104-4229    | 1    | Rear Carrier Frame ASM |
| 22:2 | 108-4000    | 2    | Bushing                |
| 23   | 95-8936     | 1    | Strip-Wear             |
| 24   | 3269-18     | 4    | Rivet-Blind            |
| 25   | 302-60      | 1    | Fitting-Grease         |




## Hydraulic Cylinder Assembly No. 112-9916

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 115-3410           | 1           | Seal Kit           |
| 2           | 108-9035           | 1           | Clevis             |
| 3           | 3220-7             | 1           | Nut-Jam            |



## Sidewinder Carrier Assembly


| Ref. | Part Number | Qty. | Description          | Ref. | Part Number | Qty. | Description             |
|------|-------------|------|----------------------|------|-------------|------|-------------------------|
| 1    | 112-9916    | 1    | HYD Cylinder ASM     | 22   | 104-4820-03 | 1    | Bracket-Stop, Carrier   |
| 2    | 100-4939-03 | 1    | Carrier-Sidewinder   | 23   | 115-3462    | 1    | RH Liftarm ASM          |
| 3    | 32128-33    | 1    | Nut-HF               | 23:1 | 69-6470     | 2    | Bushing-Caster          |
| 4    | 3234-4      | 1    | Screw-HHF            | 24   | 115-3461    | 1    | LH Liftarm ASM          |
| 5    | 99-3433     | 1    | Wire-Center          | 24:1 | 69-6470     | 2    | Bushing-Caster          |
| 6    | 104-0416-03 | 1    | Bracket-Slide        | 25   | 323-6       | 2    | Screw-HH                |
| 7    | 104-0417    | 2    | Slide-Plastic        | 26   | 95-8979     | 2    | Shaft                   |
| 8    | 3234-11     | 8    | Screw-HHF            | 27   | 3-6781      | 2    | Washer-Thrust           |
| 9    | 95-8531     | 2    | Shaft-Pivot, Liftarm | 28   | 283-71      | 2    | Pin-Lynch               |
| 10   | 32121-122   | 2    | Pin-Roll             | 29   | 104-0472    | 1    | Rod                     |
| 11   | 3234-27     | 2    | Screw-HHF            | 30   | 323-42      | 2    | Screw-HH                |
| 12   | 325-19      | 8    | Screw-HH             | 31   | 3290-467    | 2    | Pin-Hair                |
| 13   | 104-4865    | 8    | Cap-Bearing          | 32   | 110-8793-03 | 1    | Stop-Deck, RH           |
| 14   | 3218-5      | 4    | Nut-Jam              | 33   | 110-8794-03 | 1    | Stop-Deck, LH           |
| 15   | 325-7       | 2    | Screw-HH             | 34   | 3269-11     | 4    | Rivet-Pop               |
| 16   | 3296-23     | 8    | Nut-Lock, NI         | 35   | 86-5350     | 2    | Bumper-Rubber           |
| 17   | 87-7270     | 16   | Washer-Thrust        | 36   | 104-8301    | 6    | Nut-HF, NI              |
| 18   | 99-3373     | 4    | Bar-Support, Slide   | 37   | 302-5       | 2    | Fitting-Grease          |
| 19   | 95-8575     | 2    | Pin-Clevis           | 38   | 110-8787    | 2    | Front Carrier Frame ASM |
| 20   | 75-9590     | 2    | Spacer-Cylinder      | 38:2 | 108-4000    | 2    | Bushing                 |
| 21   | 32120-93    | 4    | Ring-Retaining       | 39   | 93-8806     | 2    | Washer-Hardened         |



## Sidewinder Carrier Assembly (continued)

| Ref. | Part Number | Qty. | Description      |
|------|-------------|------|------------------|
| 40   | 104-4613    | 2    | Tube-Latch       |
| 41   | 104-4612    | 2    | Rod-Latch        |
| 42   | 104-4237    | 2    | Clip-Rod         |
| 43   | 3290-271    | 4    | Rivet-Pop        |
| 44   | 104-4828-03 | 2    | Bracket-Actuator |
| 45   | 3230-23     | 8    | Bolt-CARR        |
| 46   | 32128-44    | 12   | Nut              |
| 47   | 104-4826-03 | 1    | Actuator-RH      |


| Ref. | Part Number | Qty. | Description       |
|------|-------------|------|-------------------|
| 48   | 104-4827-03 | 1    | Actuator-LH       |
| 49   | 104-4819-03 | 1    | Bracket-Pivot, LH |
| 50   | 104-4825-03 | 1    | Bracket-Pivot, RH |
| 51   | 323-11      | 2    | Screw-HH          |
| 52   | 322-11      | 2    | Screw-HH          |
| 53   | 104-4821    | 2    | Spring-Torsion    |
| 54   | 32128-43    | 8    | Nut-Flange        |



## Scissor Frame and Link Assembly


| Ref. | Part Number | Qty. | Description     |
|------|-------------|------|-----------------|
| 1    | 95-8526     | 6    | Bushing-Plastic |
| 2    | 95-8527-03  | 1    | Link-Scissor    |
| 3    | 95-8883     | 1    | Mount-Scissor   |
| 4    | 323-7       | 4    | Screw-HH        |
| 5    | 104-8301    | 4    | Nut-HF, NI      |
| 6    | 95-8521-03  | 1    | Frame-Scissor   |
| 7    | 95-8512     | 1    | Cylinder-HYD    |
| 8    | 95-8603     | 2    | Spacer          |
| 9    | 87-5330     | 2    | Washer          |

| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 10   | 324-6       | 2    | Screw-HH           |
| 11   | 3296-48     | 2    | Nut-Hex            |
| 12   | 95-8529     | 3    | Pin                |
| 13   | 3234-14     | 3    | Screw-HHF          |
| 14   | 32152-1     | 3    | Nut-Lock, Cone     |
| 15   | 46-6350     | 2    | Spacer             |
| 16   | 99-3505     | 1    | Scissors Link ASM  |
| 16:1 | 94-3353     | 1    | Decal-Point, Pinch |
| 17   | 32120-93    | 2    | Ring-Retaining     |




## Hydraulic Motor and Cutting Unit Assembly

| Ref. | Part Number | Qty. | Description     |
|------|-------------|------|-----------------|
| 1    | 117-5141    | 3    | HYD Motor ASM   |
| 3    | 112-9901-03 | 1    | Guard-Foot, RH  |
| 4    | 112-9902-03 | 1    | Guard-Foot, LH  |
| 5    | 112-9900-03 | 1    | Guard-Foot      |
| 6    | 3274-7      | 6    | Screw-HSH       |
| 7    | 3256-24     | 6    | Washer-Flat     |
| 8    | 323-52      | 6    | Screw-HH        |
| 9    | 93-8806     | 6    | Washer-Hardened |
| 10   | 95-8803     | 6    | Bushing-Flange  |
| 11   | 104-8301    | 10   | Nut-HF, NI      |
| 12   | 323-11      | 4    | Screw-HH        |




## Gear Motor Assembly No. 117-5141

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|----------------------|
| 1           | 117-0235           | 1           | Seal Kit             |
| 2           | 107-7820           | 1           | Valve-Relief         |
| 3           | 107-7821           | 1           | Valve-Anticavitation |




## Roller and Carrier Frame Assembly

| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 1    | 100-5780-03 | 1    | Frame-Deck             |
| 2    | 115-3418    | 2    | Roller ASM             |
| 2:1  | 104-1093    | 1    | Roller                 |
| 2:2  | 100-5762    | 1    | Spacer-Bearing         |
| 2:3  | 120-3366    | 2    | Bearing                |
| 3    | 327-15      | 2    | Screw-HH               |
| 4    | 112-5270    | 2    | Roller Shaft Screw ASM |
| 4:2  | 302-5       | 1    | Fitting-Grease         |
| 9    | 112-5265    | 1    | Roller ASM             |
| 10   | 323-7       | 2    | Screw-HH               |
| 11   | 3234-11     | 4    | Screw-HHF              |
| 12   | 112-5268    | 2    | Mount-Roller           |
| 13   | 107-7816    | 2    | Bracket-Skid           |




## Roller Assembly No. 112-5265

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       |
|-------------|--------------------|-------------|--------------------------|
| 1           | 112-5274-03        | 1           | Tube ASM                 |
| 2           | 117-5100           | 1           | Shaft-Roller, Rear       |
| 7           | 108-0989           | 2           | Screw-Set                |
| 8           | 114-5430           | 1           | Roller Rebuild Kit       |
| 8:1         | 114-3717           | 2           | Seal-Oil                 |
| 8:2         | 112-5290           | 2           | Bearing-Steel, Stainless |
| 8:3         | 112-7494           | 4           | Seal                     |
| 8:4         | 114-5411           | 2           | Nut-Lock, Bearing        |




## Height-of-Cut Bracket Assembly

| Ref. | Part Number | Qty. | Description         |
|------|-------------|------|---------------------|
| 1    | 100-5797-03 | 1    | Bracket-HOC, RH     |
| 2    | 323-12      | 2    | Screw-HH            |
| 3    | 80-6990     | 2    | Washer-Hardened     |
| 4    | 104-1052-03 | 1    | Bracket-HOC, Front  |
| 5    | 100-5799    | 18   | Shim-HOC, .060 Inch |
| 6    | 3231-9      | 4    | Screw-CARR          |
| 7    | 104-4641    | 3    | Shim-HOC, .030 Inch |
| 8    | 32128-43    | 6    | Nut-Flange          |
| 9    | 3234-24     | 3    | Screw-HHF           |
| 10   | 105-9226    | 3    | Spacer-HOC          |
| 11   | 104-4624-03 | 1    | Bracket-HOC, LH     |
| 12   | 105-9225    | 3    | HOC Plate ASM       |
| 12:2 | 32121-3     | 1    | Pin-Spring          |




## Chamber, Blade and Spindle Assembly

| Ref. | Part Number | Qty. | Description              |
|------|-------------|------|--------------------------|
| 1    | 32128-39    | 6    | Nut-HHF                  |
| 3    | 104-1051-03 | 1    | Plate-Spindle            |
| 4    | 115-3479    | 1    | Chamber ASM              |
| 4:2  | 117-4764    | 2    | Decal-Danger             |
| 4:3  | 93-7818     | 1    | Decal-Torque, Blade Bolt |
| 4:4  | 104-1086    | 1    | Decal-HOC                |
| 5    | 237-161     | 1    | O-Ring                   |
| 6    | 115-3435    | 1    | Spindle ASM              |
| 8    | 107-0235-03 | 1    | Blade-Atomic             |
| 8    | 108-9026-03 | 1    | Blade-Combo              |
| 9    | 72-9361     | 1    | Cup-Scalp, Anti          |
| 10   | 92-5816     | 1    | Bolt-Blade               |
| 11   | 108-9025-01 | 1    | Baffle-Mulching          |
| 12   | 46-8560     | 5    | Screw-HHFTF              |



## Spindle Assembly No. 115-3435


| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 1    | 115-3434    | 1    | Spindle                |
| 1:2  | 10-6830     | 6    | Stud-Type, Drive       |
| 2    | 100-5703    | 1    | Spacer And Bearing ASM |
| 3    | 100-5705    | 1    | Spindle Shaft ASM      |
| 4    | 253-154     | 2    | Seal-Oil               |
| 5    | 69-6950     | 1    | Spacer-Shaft, Spindle  |
| 6    | 100-5709    | 1    | Nut-Spindle, Spcl      |
| 7    | 302-62      | 2    | Fitting-Grease         |
| 8    | 94-2703     | 1    | Plug                   |



## Fuel Tank Assembly

| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 1    | 321-2       | 2    | Screw-HH              |
| 2    | 105-7865    | 1    | Tank-Fuel             |
| 2:1  | 95-8971     | 1    | Gauge-Fuel            |
| 2:2  | 95-8972     | 1    | Grommet               |
| 3    | 95-8881     | 1    | Strap-Line, Fuel      |
| 4    | 32144-10    | 3    | Screw-HWH             |
| 5    | 114-5064    | 1    | Cap-Diesel            |
| 6    | 95-8968-03  | 1    | Support-Tank, Fuel    |
| 7    | 46-6550     | 1    | Fitting-Elbow, 90 DEG |
| 8    | 110-9689    | 1    | Pipe-Stand            |
| 9    | 304-73      | 1    | Fitting-Straight      |
| 10   | 321-14      | 1    | Screw-HH              |
| 11   | 32128-33    | 1    | Nut-HF                |
| 12   | 3256-22     | 1    | Washer-Flat           |
| 13   | 354-20      | 1    | Fitting-Tee           |
| 14   | 354-21      | 1    | Fitting-Barbed        |
| 15   | 354-22      | 1    | Fitting-Barbed        |
| 16   | 46-6560     | 2    | Bushing               |
| 17   | 77-3180     | 1    | Spacer                |
| 18   | 92-2379     | 7    | Clamp-Hose            |
| 19   | 110-9044    | 1    | Separator-Filter      |


| Ref. | Part Number | Qty. | Description                |
|------|-------------|------|----------------------------|
| 19:1 | 110-9049    | 1    | Filter-Spin On, Fuel/Water |
| 20   | 353-783     | 1    | Fitting-STR                |
| 21   | 3234-17     | 2    | Screw-HHF                  |
| 22   | 32128-44    | 2    | Nut                        |
| 23   | 353-781     | 1    | Fitting-HYD, 90            |
| 24   | 110-6187    | 1    | Hose-Fuel                  |
| 25   | 110-8751    | 1    | Hose-Fuel                  |
| 26   | 110-5701    | 1    | Hose-Fuel                  |
| 27   | 110-4100    | 1    | Hose-Fuel                  |
| 28   | 110-4109    | 1    | Hose-Fuel                  |
| 29   | 110-4113    | 1    | Hose-Fuel                  |
| 30   | 2412-73     | 1    | Clamp-R                    |
| 31   | 110-8806    | 1    | Pump-Fuel                  |
| 32   | 110-8817    | 1    | Bracket-Pump, Fuel         |
| 33   | 105-4094    | 1    | Hose-Formed                |
| 34   | 2412-129    | 2    | Clamp-Hose                 |
| 35   | 110-8754    | 1    | Trim                       |
| 36   | 2412-80     | 2    | Clamp-Hose                 |
| 37   | 322-8       | 1    | Screw-HH                   |
| 38   | 3256-23     | 2    | Washer-Plain               |
| 39   | 56-7971     | 2    | Clamp-Tube                 |



## Fuel Tank Assembly (continued)

| Ref. | Part Number | Qty. | Description  |
|------|-------------|------|--------------|
| 40   | 3296-29     | 1    | Nut-Lock, NI |


| Ref. | Part Number | Qty. | Description |
|------|-------------|------|-------------|
| 41   | 1-543296    | 1    | Grommet     |
| 42   | 2412-108    | 2    | Clamp-Worm  |



## Hydraulic Tank and Filter Assembly

| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 1    | 240-11      | 4    | Bushing-Flange        |
| 2    | 3234-11     | 4    | Screw-HHF             |
| 3    | 353-987     | 1    | Fitting-Elbow, 90     |
| 3:1  | 237-81      | 1    | O-Ring                |
| 4    | 100-4890    | 1    | Fitting-Check         |
| 4:1  | 237-79      | 1    | O-Ring                |
| 4:2  | 237-30      | 1    | O-Ring                |
| 5    | 63-8410     | 4    | Washer                |
| 6    | 104-4840    | 1    | Tank-HYD              |
| 7    | 2412-34     | 2    | Clamp-Hose            |
| 8    | 353-979     | 1    | Fitting-STR           |
| 8:1  | 237-42      | 1    | O-Ring                |
| 9    | 3234-13     | 2    | Screw-HHF             |
| 10   | 340-142     | 1    | Fitting-Elbow, 90 DEG |
| 10:1 | 237-58      | 1    | O-Ring                |
| 10:2 | 237-81      | 1    | O-Ring                |


| Ref. | Part Number | Qty. | Description       |
|------|-------------|------|-------------------|
| 11   | 86-3010     | 1    | Filter-Oil        |
| 12   | 57-5420     | 1    | Screw-Shoulder    |
| 13   | 104-7546    | 1    | Tank Strainer ASM |
| 13:1 | 340-136     | 1    | O-Ring            |
| 14   | 119-6968    | 1    | Dipstick-Oil      |
| 15   | 92-5821     | 1    | Head-Filter       |
| 16   | 93-7160     | 1    | Cap-Oil, HYD      |
| 17   | 2412-36     | 1    | Clamp-Hose        |
| 18   | 104-0486    | 1    | Hose-HYD          |
| 19   | 104-4836    | 1    | Fitting-Tee       |
| 19:1 | 237-58      | 2    | O-Ring            |
| 19:2 | 237-81      | 1    | O-Ring            |
| 20   | 104-0487    | 1    | Hose-HYD          |
| 21   | 95-3502     | 1    | Fitting-Elbow 90  |
| 21:1 | 237-81      | 1    | O-Ring            |
| 22   | 104-5486    | 1    | Hose              |



## Battery Assembly

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 2           | 233-70             | 2           | Knob-Star, Three   |
| 3           | 32128-43           | 3           | Nut-Flange         |
| 4           | 3230-6             | 1           | Bolt-CARR          |
| 5           | 3234-1             | 3           | Screw-HHF          |
| 6           | 3256-23            | 1           | Washer-Plain       |
| 7           | 3296-29            | 1           | Nut-Lock, NI       |
| 8           | 66-2490            | 1           | Retainer-Battery   |
| 9           | 32144-15           | 1           | Screw-HHFTF        |
| 10          | 95-8796-03         | 1           | Support-Battery    |


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       |
|-------------|--------------------|-------------|--------------------------|
| 11          | 99-3602            | 1           | Battery Cover ASM        |
| 11:2        | 93-7276            | 1           | Decal-Danger             |
| 11:3        | 87-7620            | 1           | Shield-Terminal, Battery |
| 11:4        | 3269-27            | 4           | Rivet-Snap               |
| 12          | 95-8853            | 1           | Cable-Battery, Positive  |
| 13          | 95-8854            | 1           | Cable-Battery, Negative  |
| 14          | 32148-6            | 2           | Nut-Clinch               |
| 15          | 99-3513            | 1           | Tray-Battery             |



## Seat Assembly

| Ref. | Part Number | Qty. | Description                |
|------|-------------|------|----------------------------|
| 1    | 104-4620    | 1    | Seat                       |
| 2    | 100-4928    | 1    | Belt-Seat                  |
| 3    | 3234-14     | 6    | Screw-HHF                  |
| 4    | 104-8300    | 4    | Nut-HF, NI                 |
| 5    | 92-8990     | 1    | Adjuster-Seat, Non-Locking |
| 6    | 92-8991     | 1    | Adjuster (W/Latch)         |
| 7    | 3212-4      | 2    | Screw-HH                   |
| 8    | 3253-6      | 2    | Washer-Lock                |
| 9    | 92-6282     | 1    | Switch-Seat                |
| 10   | 32144-10    | 2    | Screw-HWH                  |
| 11   | 104-0467-03 | 2    | Strap-Support, Seat        |
| 12   | 95-8896     | 2    | Foam                       |
| 13   | 3234-11     | 2    | Screw-HHF                  |
| 14   | 104-0466    | 2    | Spacer                     |
| 15   | 323-14      | 2    | Screw-HH                   |
| 16   | 3256-24     | 2    | Washer-Flat                |
| 17   | 104-4833-03 | 1    | Shield-Heat                |


| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 18   | 92-7307     | 1    | LH Armrest ASM         |
| 18:1 | 69-0760     | 1    | Bracket-Arm, LH        |
| 18:2 | 92-7301     | 1    | Spacer                 |
| 18:3 | 69-1180     | 1    | Armrest                |
| 18:4 | 323-9       | 1    | Screw-HH               |
| 18:5 | 32128-19    | 1    | Nut-HF Lock, Large Flg |
| 18:7 | 3256-24     | 1    | Washer-Flat            |
| 18:8 | 92-7318     | 1    | Screw                  |
| 19   | 92-7306     | 1    | RH Armrest ASM         |
| 19:1 | 69-0770     | 1    | Bracket-Arm, RH        |
| 19:2 | 92-7301     | 1    | Spacer                 |
| 19:3 | 69-1180     | 1    | Armrest                |
| 19:4 | 323-9       | 1    | Screw-HH               |
| 19:5 | 32128-19    | 1    | Nut-HF Lock, Large Flg |
| 19:7 | 3256-24     | 1    | Washer-Flat            |
| 19:8 | 92-7318     | 1    | Screw                  |
| 99   | 3290-378    | 1    | Tie-Cable              |



## Control Panel Assembly

| Ref. | Part Number | Qty. | Description          |
|------|-------------|------|----------------------|
| 1    | 32128-32    | 1    | Nut-HHF              |
| 2    | 3256-22     | 1    | Washer-Flat          |
| 3    | 115-3496-03 | 1    | Panel-Control        |
| 4    | 3290-134    | 4    | Screw                |
| 5    | 32128-43    | 5    | Nut-Flange           |
| 6    | 3234-1      | 5    | Screw-HHF            |
| 7    | 321-8       | 3    | Screw-HH             |
| 8    | 110-8795    | 1    | Cable-Throttle       |
| 9    | 104-0421    | 1    | Plate-Stop, Throttle |
| 10   | 75-6820     | 1    | Hourmeter            |
| 11   | 32144-18    | 2    | Screw-HWH            |
| 12   | 100-8070    | 1    | Lamp-Warning         |
| 13   | 104-2541    | 1    | Ignition Switch ASM  |
| 13:1 | 218-461     | 1    | Nut-HH               |
| 13:2 | 3254-5      | 1    | Washer-Lock          |
| 14   | 63-8360     | 2    | Key-Ignition         |
| 15   | 95-8999     | 1    | Switch               |


| Ref. | Part Number | Qty. | Description              |
|------|-------------|------|--------------------------|
| 16   | 104-5191    | 1    | Decal-Console            |
| 17   | 112-9911    | 1    | Harness-Wire             |
| 17:1 | 218-578     | 2    | Fuse-Blade, 10 Amp       |
| 17:2 | 109355      | 1    | Fuse-Blade, 15 Amp       |
| 17:3 | 94-6710     | 1    | Fuse-2 Amp               |
| 17:4 | 100-4918    | 1    | Diode                    |
| 18   | 99-3401-03  | 1    | Lever-Valve, Lock        |
| 19   | 3290-477    | 1    | Washer-Curved            |
| 20   | 63-3410     | 1    | Screw-Shoulder           |
| 21   | 32144-10    | 1    | Screw-HWH                |
| 22   | 98-7611     | 1    | Controller-Glow          |
| 25   | 99-3558     | 1    | Decal-Console, CE        |
| 26   | 3290-148    | 4    | Nut-HF                   |
| 27   | 100-8071    | 1    | Lamp-Warning             |
| 28   | 106-9277    | 1    | Module-Control, Standard |
| 29   | 32128-33    | 3    | Nut-HF                   |



## Parking Brake and Dash Cover Assembly

| Ref. | Part Number | Qty. | Description              |
|------|-------------|------|--------------------------|
| 1    | 3269-5      | 4    | Rivet-Pop                |
| 2    | 95-8707     | 1    | Cover-Dash               |
| 3    | 95-8763     | 2    | Bracket-Hold Down, Cover |
| 4    | 32128-43    | 2    | Nut-Flange               |
| 5    | 3234-1      | 2    | Screw-HHF                |
| 6    | 95-8764-03  | 1    | Support-Magnet           |
| 7    | 32144-10    | 4    | Screw-HWH                |
| 8    | 95-8765     | 2    | Bracket-Strike, Magnet   |
| 9    | 58-4250     | 2    | Catch-Magnetic           |
| 10   | 3256-23     | 3    | Washer-Plain             |
| 11   | 3296-42     | 1    | Nut-Lock, NI             |
| 12   | 3272-10     | 1    | Pin-Cotter               |
| 13   | 95-8684     | 1    | Pad-Bumper               |


| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 14   | 3289-4      | 2    | Screw-FH              |
| 15   | 104-4628-03 | 2    | Link-Brake, Parking   |
| 16   | 283-62      | 1    | Pin-Clevis            |
| 17   | 94-3829     | 1    | Pin-Clevis            |
| 18   | 104-4817    | 1    | Lever-Brake           |
| 19   | 87-4710     | 1    | Spacer-Brake, Parking |
| 20   | 32105-9     | 2    | Screw                 |
| 21   | 95-8900     | 1    | Switch                |
| 22   | 3256-21     | 4    | Washer-Flat           |
| 23   | 3296-9      | 2    | Nut-Hex               |
| 24   | 321-10      | 1    | Screw-HH              |
| 25   | 3272-6      | 1    | Pin-Cotter            |
| 26   | 32128-32    | 2    | Nut-HHF               |



## 2-Spool Control Valve Assembly

| Ref. | Part Number | Qty. | Description               |
|------|-------------|------|---------------------------|
| 1    | 95-8581     | 1    | 2-Spool Control Valve ASM |
| 2    | 32128-33    | 2    | Nut-HF                    |
| 3    | 233-42      | 1    | Knob                      |
| 4    | 95-8633     | 1    | Bracket-Valve, Actuator   |
| 5    | 42-3560     | 2    | Bolt-Shoulder             |
| 6    | 3272-6      | 1    | Pin-Cotter                |
| 7    | 95-8635     | 1    | Lever-Valve               |
| 8    | 95-8638     | 1    | Trunnion-Valve, Actuator  |
| 9    | 92-8916     | 1    | Bolt-Shoulder             |


| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 10   | 95-8634     | 4    | Link               |
| 11   | 283-16      | 3    | Pin-Clevis         |
| 12   | 3272-1      | 3    | Pin-Cotter         |
| 13   | 32151-106   | 2    | Ring-Retaining     |
| 14   | 3230-33     | 2    | Screw-CARR         |
| 15   | 32128-32    | 3    | Nut-HHF            |
| 16   | 104-0430    | 2    | Stud               |
| 17   | 115-3486    | 1    | Manifold Block ASM |
| 18   | 32128-20    | 2    | Nut-HF             |



## 2-Spool Control Valve Assembly No. 95-8581

| Ref. | Part Number | Qty. | Description    |
|------|-------------|------|----------------|
| 1    | 58-6290     | 3    | Poppet         |
| 2    | 69-1840     | 1    | Plunger        |
| 3    | 58-6310     | 2    | Spacer         |
| 5    | 58-6330     | 3    | Seat           |
| 5:1  | 58-6340     | 1    | O-Ring         |
| 6    | 58-6350     | 1    | Plug           |
| 6:1  | 60-5720     | 1    | O-Ring         |
| 6:2  | 58-6370     | 1    | Washer         |
| 7    | 69-1800     | 2    | Plug ASM       |
| 7:1  | 60-5720     | 1    | O-Ring         |
| 7:2  | 58-6370     | 1    | Washer         |
| 8    | 58-6400     | 2    | Bushing        |
| 9    | 69-1810     | 3    | Spring         |
| 10   | 58-6420     | 2    | Cap            |
| 12   | 58-6450     | 4    | O-Ring         |
| 13   | 58-6460     | 2    | Ring-Retaining |
| 14   | 65-2770     | 2    | Washer         |
| 15   | 99-3526     | 1    | Plug ASM       |
| 15:1 | 60-5720     | 1    | O-Ring         |
| 15:2 | 59-7730     | 1    | Washer-Backup  |

| Ref. | Part Number | Qty. | Description      |
|------|-------------|------|------------------|
| 16   | 99-3531     | 2    | Spring           |
| 17   | 60-6450     | 1    | Disc             |
| 18   | 353-989     | 1    | Plug-Hex, Hollow |
| 18:1 | 237-42      | 1    | O-Ring           |
| 19   | 58-6780     | 1    | Plug             |
| 19:1 | 58-6790     | 1    | O-Ring           |
| 20   | 58-6320     | 2    | Wiper            |
| 21   | 99-3528     | 1    | Plunger          |
| 22   | 58-6770     | 1    | Plunger          |
| 23   | 58-6760     | 1    | Spring           |
| 31   | 99-3530     | 1    | Seal Kit         |
| 31:1 | 58-6290     | 3    | Poppet           |
| 31:2 | 58-6450     | 4    | O-Ring           |
| 31:3 | 58-6460     | 2    | Ring-Retaining   |
| 31:4 | 58-6320     | 2    | Wiper            |
| 31:5 | 58-6790     | 1    | O-Ring           |
| 31:6 | 60-5720     | 4    | O-Ring           |
| 31:7 | 58-6340     | 2    | O-Ring           |
| 31:8 | 237-42      | 1    | O-Ring           |
| 31:9 | 59-7730     | 2    | Washer-Backup    |




## Manifold Block Assembly No. 115-3486

| Ref. | Part Number | Qty. | Description                       |
|------|-------------|------|-----------------------------------|
| 3    | 106-1026    | 2    | Plug-HYD                          |
| 3:1  | 237-42      | 1    | O-Ring                            |
| 4    | 117-0115    | 1    | Plug                              |
| 4:1  | 237-78      | 1    | O-Ring                            |
| 5    | 110-8768    | 1    | Valve-Relief, Solenoid (3000 PSI) |
| 5:1  | 110-6316    | 1    | Seal Kit ●                        |
| 5:2  | 130-8180    | 1    | Nut-Coil                          |
| 6    | 117-5110    | 1    | Valve-Counterbalance              |
| 6:1  | 117-5111    | 1    | Seal Kit                          |
| 7    | 119-2011    | 1    | Valve-Logic, Adjustable           |
| 7:1  | 119-2159    | 1    | Seal Kit                          |
| 8    | 110-6344    | 1    | Coil-12V, DC                      |

● Not illustrated






## Steering Valve Assembly No. 104-5180

| Ref. | Part Number | Qty. | Description         |
|------|-------------|------|---------------------|
| 1    | 106-6716    | 1    | Seal Kit            |
| 1:1  |             | 1    | Ring-Seal, Dust ●   |
| 1:2  |             | 1    | Seal-Shaft ●        |
| 1:3  |             | 1    | O-Ring ●            |
| 1:4  |             | 2    | O-Ring ●            |
| 1:5  |             | 5    | O-Ring ●            |
| 2    |             | 1    | Housing ●           |
| 3    |             | 1    | Ball ●              |
| 4    |             | 1    | Stop-Ball ●         |
| 7    |             | 1    | Bearing ASM ●       |
| 10   |             | 1    | Ring ●              |
| 11   |             | 1    | Pin-Cross ●         |
| 12   |             | 1    | Springs ●           |
| 13   |             | 1    | Shaft ●             |
| 14   |             | 1    | Spacer ●            |
| 16   |             | 1    | Plate-Distributor ● |
| 17   |             | 1    | Gearwheel Set ●     |
| 19   |             | 1    | Cover-End ●         |
| 22   |             | 1    | Screw-Special ●     |
| 23   |             | 4    | Screw-Special ●     |
| 24   |             | 1    | Plate-Name ●        |
| 25   | 3296-33     | 1    | Nut-Lock, NI        |
| 26   | 237-22      | 3    | O-Ring              |
| 27   | 237-21      | 2    | O-Ring              |


● Not serviced separately



## Floorplate Assembly

| Ref. | Part Number | Qty. | Description             |
|------|-------------|------|-------------------------|
| 1    | 32128-20    | 17   | Nut-HF                  |
| 2    | 3230-6      | 1    | Bolt-CARR               |
| 3    | 3256-3      | 1    | Washer-Flat             |
| 4    | 3256-40     | 1    | Washer-Flat             |
| 5    | 65-9940     | 1    | Spring                  |
| 6    | 95-8866     | 1    | Tube-Arm, Rocker        |
| 7    | 32105-9     | 2    | Screw                   |
| 8    | 3296-9      | 2    | Nut-Hex                 |
| 9    | 99-3593     | 1    | Arm-Rocker              |
| 10   | 95-8900     | 1    | Switch                  |
| 11   | 3218-2      | 1    | Nut-Hex Jam             |
| 12   | 322-41      | 1    | Bolt-Hex,TAP            |
| 13   | 3230-23     | 4    | Bolt-CARR               |
| 14   | 95-8869-03  | 1    | Bracket-Pedal, Traction |
| 15   | 95-8893     | 1    | Bar-Deflector           |
| 16   | 3274-22     | 1    | Screw-HSH               |
| 17   | 106-4154    | 1    | Floorplate ASM          |
| 17:3 | 99-3478     | 1    | Tread-Foot              |
| 17:4 | 99-3444     | 1    | Decal-Mow / Transport   |
| 20   | 106-2661-01 | 1    | Plate-Support           |
| 21   | 3234-5      | 10   | Screw-HHF               |


| Ref. | Part Number | Qty. | Description             |
|------|-------------|------|-------------------------|
| 22   | 99-3388     | 1    | Decal                   |
| 23   | 99-3565     | 1    | Nut-Square              |
| 24   | 3217-6      | 1    | Nut-Hex                 |
| 25   | 3256-23     | 1    | Washer-Plain            |
| 26   | 3296-29     | 1    | Nut-Lock, NI            |
| 27   | 100-4871    | 1    | Bracket-Switch, Neutral |
| 28   | 100-4872    | 1    | Plate-Switch, Neutral   |
| 29   | 3229-20     | 1    | Screw-CARR              |
| 30   | 3256-14     | 1    | Washer-Flat             |
| 31   | 3255-17     | 1    | Washer-Lock, EXT        |
| 32   | 3296-2      | 1    | Nut-Lock, NI            |
| 33   | 3229-1      | 2    | Screw-CARR              |
| 34   | 3256-22     | 2    | Washer-Flat             |
| 35   | 3255-7      | 2    | Washer-Lock/EXT         |
| 36   | 3217-5      | 2    | Nut-Hex                 |
| 37   | 100-1270    | 1    | Switch-Proximity        |
| 38   | 323-9       | 2    | Screw-HH                |
| 39   | 3256-4      | 2    | Washer-Flat             |
| 40   | 104-4613    | 2    | Tube-Latch              |
| 41   | 32128-43    | 2    | Nut-Flange              |



## Traction Pedal Assembly

| Ref. | Part Number | Qty. | Description             |
|------|-------------|------|-------------------------|
| 1    | 100-4815    | 1    | Cable-Control, Traction |
| 1:1  | 3220-1      | 2    | Nut-Jam                 |
| 2    | 76-8870     | 1    | Damper-Lever            |
| 3    | 32128-20    | 5    | Nut-HF                  |
| 4    | 322-10      | 1    | Screw-HH                |
| 5    | 3256-23     | 2    | Washer-Plain            |
| 6    | 93-2092     | 1    | Clamp-Cable             |
| 7    | 2411-41     | 1    | Rod End-Ball Joint      |
| 8    | 2412-41     | 1    | Clamp-R                 |
| 9    | 3290-357    | 1    | Nut-HHF, Whiz           |
| 10   | 323-6       | 1    | Screw-HH                |
| 11   | 3296-42     | 1    | Nut-Lock, NI            |
| 12   | 95-8861     | 1    | Slide                   |
| 13   | 32151-84    | 2    | Ring-Shaft, EXT         |
| 14   | 41-8440     | 1    | Washer                  |
| 15   | 74-9100     | 1    | Pad-Pedal, Forward      |
| 16   | 104-4852-03 | 1    | Pedal-Traction          |
| 17   | 256-243     | 2    | Bearing-Flange          |

| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 18   | 99-3379     | 1    | Pedal-Reverse ASM  |
| 18:2 | 256-243     | 2    | Bearing-Flange     |
| 19   | 74-9110     | 1    | Pad-Pedal, Reverse |
| 20   | 75-5470     | 1    | Spacer-Bearing     |
| 21   | 99-3476     | 1    | Spring-Extension   |
| 22   | 251-259     | 1    | Bearing-Ball       |
| 23   | 322-7       | 1    | Screw-HH           |
| 24   | 3296-47     | 3    | Nut-Lock,NI        |
| 25   | 32151-3     | 1    | Ring-Grip          |
| 26   | 302-5       | 1    | Fitting-Grease     |
| 27   | 3230-27     | 1    | Screw-CARR         |
| 28   | 321-10      | 1    | Screw-HH           |
| 29   | 33093-00    | 3    | Washer-Flat        |
| 30   | 99-3545     | 1    | Spacer             |
| 31   | 3256-22     | 1    | Washer-Flat        |
| 32   | 73-0040     | 4    | Washer-Thrust      |
| 33   | 3230-23     | 2    | Bolt-CARR          |
| 34   | 3256-24     | 1    | Washer-Flat        |




## Hood Assembly

| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 1    | 3234-4      | 6    | Screw-HHF              |
| 2    | 100-4932    | 1    | Trim-Seal              |
| 3    | 3296-42     | 6    | Nut-Lock, NI           |
| 4    | 104-4853-03 | 1    | Screen-Hood            |
| 5    | 100-4855    | 1    | Hood                   |
| 5:1  | 106-8115    | 1    | Heat Tape Repair Kit ● |
| 6    | 95-8728     | 2    | Bracket-Pivot, Hood    |
| 7    | 3256-24     | 8    | Washer-Flat            |
| 8    | 59-9740     | 2    | Flex Draw Latch ASM    |
| 8:2  | 249-40      | 1    | Keeper                 |
| 9    | 107-0333    | 4    | Rivet-Pop              |
| 10   | 3290-55     | 4    | Rivet-Pop              |
| 11   | 3269-10     | 4    | Washer-Back            |

| Ref. | Part Number | Qty. | Description   |
|------|-------------|------|---------------|
| 12   | 104-5152    | 2    | Decal-Hood    |
| 13   | 323-6       | 4    | Screw-HH      |
| 14   | 3290-467    | 1    | Pin-Hair      |
| 15   | 117-5103    | 1    | Decal-Service |
| 16   | 3269-21     | 2    | Rivet-Pop     |
| 17   | 119-2004    | 1    | CE Latch Kit  |
| 17:2 | 107-0333    | 2    | Rivet-Pop     |
| 17:3 | 322-10      | 1    | Screw-HH      |
| 17:4 | 3296-47     | 1    | Nut-Lock,NI   |
| 17:5 | 3269-10     | 2    | Washer-Back   |
| 18   | 106-6754    | 1    | Decal-Danger  |
| 20   | 66-6140     | 2    | Decal         |

● Not illustrated




## Wheel Motor and Brake Assembly

| Ref. | Part Number | Qty. | Description          |
|------|-------------|------|----------------------|
| 1    | 110-8785    | 1    | HYD Motor ASM (CCW)  |
| 2    | 110-8786    | 1    | HYD Motor ASM (CW)   |
| 3    | 3274-99     | 8    | Screw-HSH            |
| 4    | 84-2000-03  | 2    | Bracket-Brake        |
| 5    | 3296-23     | 8    | Nut-Lock, NI         |
| 6    |             | 2    | Wheel Hub/Stud ASM ● |
| 6:1  | 104-0462    | 1    | Hub-Wheel, Spacer    |
| 6:2  | 10-6830     | 4    | Stud-Type, Drive     |
| 7    | 26-3790     | 2    | Nut-Lock             |
| 8    |             | 2    | Wheel And Tire ASM ● |
| 8:1  | 117-5126    | 1    | Rim                  |
| 8:2  | 117-5125    | 1    | Tire                 |
| 8:3  | 232-27      | 1    | Stem-Valve           |
| 9    | 242-50      | 8    | Nut-Lug              |
| 10   | 321-5       | 8    | Screw-HH             |
| 11   | 3296-42     | 8    | Nut-Lock, NI         |
| 12   | 104-7705    | 2    | Brake ASM            |
| 13   | 104-0485-03 | 2    | Shield-Wheel         |


| Ref. | Part Number | Qty. | Description          |
|------|-------------|------|----------------------|
| 14   | 119-8238    | 8    | Spacer-Deck Pulley   |
| 15   | 114-2726    | 2    | Lever-Brake          |
| 16   | 283-1       | 2    | Pin-Clevis           |
| 17   | 115-6672    | 2    | Brake Lever ASM      |
| 17:1 | 104-4627    | 1    | Rod-Adjusting        |
| 17:2 | 1-303105    | 1    | Yoke-Adjustable      |
| 17:3 | 3220-2      | 1    | Nut-Jam              |
| 18   | 3272-6      | 2    | Pin-Cotter           |
| 19   | 104-4625-03 | 1    | Shaft-Pivot, Brake   |
| 20   | 95-8683     | 2    | Bracket-Pivot, Brake |
| 21   | 3234-11     | 4    | Screw-HHF            |
| 22   | 32128-43    | 4    | Nut-Flange           |
| 23   | 256-156     | 2    | Bushing-Flange       |
| 24   | 104-7706    | 2    | E-Ring, Bowed        |
| 25   | 3274-105    | 8    | Screw-HSBH           |
| 26   | 104-4809    | 2    | Drum-Brake           |
| 27   | 3272-10     | 2    | Pin-Cotter           |

● Not serviced separately



## Brake Assembly No. 104-7705

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 70-9870            | 1           | Plate-Backing      |
| 2           | 104-7707           | 1           | Shaft-Cam, Brake   |
| 3           | 104-7706           | 1           | E-Ring, Bowed      |
| 4           | 70-9880            | 2           | Spring-Return      |
| 5           | 70-9840            | 2           | Shoe-Brake         |




## Rear Fork and Wheel Assembly

| Ref. | Part Number | Qty. | Description                         |
|------|-------------|------|-------------------------------------|
| 1    |             | 1    | Steering Cylinder / Balljoint ASM ● |
| 1:1  | 94-8141     | 1    | HYD Cylinder ASM                    |
| 1:2  | 106-6774    | 2    | Joint-Ball                          |
| 1:3  | 32151-104   | 2    | Ring-Retaining, External            |
| 2    | 302-5       | 1    | Fitting-Grease                      |
| 3    | 302-59      | 1    | Plug-EXT Hex Spl                    |
| 4    | 3220-6      | 4    | Nut-Jam                             |
| 5    | 95-8905-01  | 1    | Fork-Rear                           |
| 6    | 325-3       | 1    | Screw-HH                            |
| 7    | 3255-2      | 1    | Washer-Lock, EXT                    |
| 8    | 75-7730     | 1    | Washer-Thrust                       |
| 9    |             | 1    | Wheel And Tire ASM ●                |
| 9:1  | 117-5129    | 1    | Rim                                 |
| 9:2  | 115-1572    | 1    | Tire                                |
| 9:3  | 232-27      | 1    | Stem-Valve                          |
| 10   | 3274-93     | 4    | Screw-HSH                           |

| Ref.   | Part Number | Qty. | Description          |
|--------|-------------|------|----------------------|
| 11     | 3296-23     | 4    | Nut-Lock, NI         |
| 12     |             | 1    | Wheel Hub/Stud ASM ● |
| 12:1   | 10-6870-03  | 1    | Hub-Wheel            |
| 12:2   | 10-6830     | 4    | Stud-Type, Drive     |
| 13     | 26-3790     | 1    | Nut-Lock             |
| 14     | 95-8694     | 1    | HYD Motor ASM        |
| 15     | 242-50      | 4    | Nut-Lug              |
| 16     | 82-8170     | 2    | Clamp                |
| 17     | 93-7960     | 2    | Spacer               |
| 18     | 93-7961     | 1    | Clamp-Drain, Case    |
| 19     | 107-7828-03 | 1    | Casting-Rear         |
| 19:1   |             | 1    | Rear Casting ASM ●   |
| 19:1:2 | 95-8805     | 2    | Bushing              |
| 19:1:3 | 302-5       | 1    | Fitting-Grease       |
| 20     | 3234-38     | 8    | Screw-HHF            |
| 21     | 322-13      | 2    | Screw-HH             |
| 22     | 3296-29     | 2    | Nut-Lock, NI         |


● Not serviced separately



## Hydraulic Cylinder Assembly No. 94-8141

| Ref. | Part Number | Qty. | Description      |
|------|-------------|------|------------------|
| 1    | 86-5390     | 1    | Seal Kit         |
| 1:1  |             | 1    | Uniring ●        |
| 1:2  |             | 1    | O-Ring ●         |
| 1:3  |             | 1    | Seal-Rod ●       |
| 1:4  |             | 1    | O-Ring ●         |
| 1:5  |             | 1    | Ring-Backup ●    |
| 1:6  |             | 1    | O-Ring ●         |
| 2    |             | 1    | Rod ●            |
| 3    |             | 1    | Piston ●         |
| 4    |             | 1    | Gland ●          |
| 5    |             | 1    | Nut-Lock ●       |
| 6    |             | 1    | Ring-Retaining ● |

● Not serviced separately




## Hydraulic Motor Assembly No. 95-8694

| Ref. | Part Number | Qty. | Description                 |
|------|-------------|------|-----------------------------|
| 1    | 76-0810     | 1    | Housing ASM                 |
| 5    | 99-3090     | 1    | Shaft-Coupling              |
| 7    | 76-0850     | 1    | Bearing-Thrust              |
| 8    | 76-0870     | 1    | Plate-Wear                  |
| 9    | 99-3537     | 1    | Link-Drive                  |
| 10   | 99-3539     | 1    | Set-Rotor                   |
| 11   | 99-3535     | 1    | Manifold                    |
| 12   | 76-0880     | 1    | Commutator ASM              |
| 12:1 |             | 1    | Commutator ●                |
| 12:2 |             | 1    | Ring-Commutator ●           |
| 14   | 99-3538     | 1    | End Cover ASM               |
| 14:1 |             | 1    | Spring Cap And O-Ring ASM ● |


| Ref. | Part Number | Qty. | Description                 |
|------|-------------|------|-----------------------------|
| 14:2 | 99-3541     | 1    | Spring                      |
| 14:3 | 99-3540     | 1    | Ball                        |
| 15   | 99-3536     | 7    | Screw-HH                    |
| 19   | 3257-42     | 1    | Key-Woodruff                |
| 20   | 94-8178     | 1    | Seal Kit                    |
| 20:1 |             | 1    | Seal-Dirt And Water ●       |
| 20:2 |             | 1    | Backup-Ring ●               |
| 20:3 |             | 1    | Seal-Shaft ●                |
| 20:4 |             | 1    | Washer-Backup ●             |
| 20:5 |             | 5    | Seal-Square, Ring (Inner) ● |
| 20:6 |             | 1    | Seal-Commutator ●           |

● Not serviced separately



## Neutral Arm Assembly


| Ref. | Part Number | Qty. | Description      | Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------|------|-------------|------|------------------------|
| 1    | 95-8960-03  | 1    | Bracket-Neutral  | 16   | 3234-17     | 2    | Screw-HHF              |
| 2    | 32128-43    | 1    | Nut-Flange       | 17   | 104-0464-03 | 1    | Bracket-Support, Cable |
| 3    | 3234-11     | 3    | Screw-HHF        | 18   | 251-259     | 1    | Bearing-Ball           |
| 4    | 104-0422    | 1    | Neutral Arm ASM  | 19   | 2411-41     | 1    | Rod End-Ball Joint     |
| 4:2  | 256-113     | 2    | Bushing-Flange   | 20   | 3296-42     | 1    | Nut-Lock, NI           |
| 5    | 3-6498      | 1    | Washer-Thrust    | 21   | 3274-104    | 1    | Screw-HSBH             |
| 6    | 302-60      | 1    | Fitting-Grease   | 22   | 99-3556     | 1    | Hose                   |
| 7    | 3296-29     | 1    | Nut-Lock, NI     | 23   | 99-3594-03  | 1    | Lever-Pump             |
| 8    | 100-4817    | 1    | Spacer           | 24   | 321-8       | 1    | Screw-HH               |
| 9    | 76-8640     | 1    | Stud-Traction    | 25   | 2844        | 3    | Washer                 |
| 10   | 33093-00    | 2    | Washer-Flat      | 26   | 95-3857     | 3    | Screw-HSBH             |
| 11   | 94-1369     | 1    | Spring-Extension | 27   | 63-9750     | 3    | Mount                  |
| 12   | 3210-6      | 1    | Screw-HH         | 28   | 3296-39     | 3    | Nut-Lock, NI           |
| 13   | 88-7200     | 1    | Washer-Flat      | 29   | 3256-22     | 1    | Washer-Flat            |
| 14   | 99-3598-03  | 1    | Hub              | 30   | 32153-3     | 1    | Nut-Hex, Side Deform   |
| 15   | 32128-44    | 2    | Nut              |      |             |      |                        |



## Gear Pump and Piston Pump Assembly

| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 1    | 104-4890    | 1    | Piston Pump ASM    |
| 2    | 323-8       | 2    | Screw-HH           |
| 3    | 3296-39     | 2    | Nut-Lock, NI       |
| 4    | 80-6990     | 3    | Washer-Hardened    |
| 5    | 32128-54    | 1    | Nut-HF             |
| 6    | 99-3624     | 1    | Shaft-Pivot, Idler |
| 7    | 302-5       | 1    | Fitting-Grease     |
| 8    | 32128-21    | 1    | Nut-HF Lock        |
| 9    | 32151-36    | 1    | Ring-Retaining     |
| 10   | 323-10      | 1    | Screw-HH           |
| 11   | 74-1810     | 1    | Washer             |
| 12   | 107-7834    | 1    | Pulley-Idler       |
| 13   | 115-3488    | 1    | Spring-Torsion     |
| 14   | 99-3623-03  | 1    | Arm-Idler          |
| 15   | 32128-43    | 4    | Nut-Flange         |
| 16   | 323-19      | 2    | Screw-HH           |
| 17   | 3234-11     | 4    | Screw-HHF          |
| 18   | 99-3436-03  | 1    | Support-Pump       |
| 19   | 99-3440     | 2    | Spacer             |

| Ref. | Part Number | Qty. | Description         |
|------|-------------|------|---------------------|
| 20   | 33114-060   | 4    | Screw-HH            |
| 21   | 87-8640     | 3    | Washer-Flat         |
| 22   | 120-3375-03 | 1    | Plate-Mount, Pump   |
| 23   | 95-8941     | 4    | Spacer-Mount, Pump  |
| 24   | 120-3350    | 1    | Pulley-3V           |
| 25   | 321-13      | 3    | Screw-HH            |
| 26   | 3253-3      | 3    | Washer-Lock         |
| 27   | 100-4813    | 1    | Bushing-Lock, Taper |
| 28   | 120-3351    | 1    | Belt-3V             |
| 29   | 70-2041     | 1    | Trim                |
| 30   | 353-949     | 1    | O-Ring              |
| 31   | 108-9036    | 1    | HYD Gear Pump ASM   |
| 32   | 323-7       | 2    | Screw-HH            |
| 33   | 3256-24     | 2    | Washer-Flat         |
| 34   | 99-3631     | 2    | Bushing-Flange      |
| 35   | 99-3625     | 1    | Spacer-Arm, Idler   |
| 36   | 100-4852    | 2    | Washer-Hardened     |
| 37   | 3245-7      | 1    | Screw-Set           |




## Hydraulic Pump Assembly No. 104-4890

| Ref. | Part Number | Qty. | Description      |
|------|-------------|------|------------------|
| 1    | 94-3645     | 1    | Key              |
| 2    | 94-6359     | 1    | Shaft-Drive      |
| 3    | 104-4046    | 2    | Bearing-Cup      |
| 4    | 98-4640     | 6    | Screw-Cap        |
| 5    | 98-4644     | 1    | Plate-Cover      |
| 6    | 105-9762    | 6    | Washer           |
| 7    | 100-3182    | 2    | Shim Kit         |
| 8    | 98-4639     | 2    | Bearing-Cone     |
| 9    | 94-3646     | 1    | Key              |
| 10   | 104-4888    | 1    | Swashplate       |
| 11   | 76-6070     | 1    | Rotating Kit     |
| 13   | 104-0429    | 1    | Plate-Valve      |
| 15   | 76-6150     | 2    | Pin-Dowel        |
| 16   | 105-3813    | 1    | Endcover Sub ASM |
| 16:1 | 94-6368     | 1    | Bearing          |
| 16:2 |             | 1    | Pin-Roll ■       |
| 18   | 74-9280     | 2    | Plug ASM         |
| 18:1 |             | 1    | Ring-Retaining ■ |

| Ref. | Part Number | Qty. | Description       |
|------|-------------|------|-------------------|
| 19   | 104-4889    | 1    | Relief Valve ASM  |
| 20   | 105-3812    | 1    | Valve-Check       |
| 21   | 105-3811    | 1    | Valve-Bypass      |
| 22   | 76-6170     | 2    | Capscrew          |
| 23   | 76-6160     | 2    | Capscrew          |
| 25   | 98-4645     | 1    | Plate-Cover       |
| 29   | 100-3176    | 1    | Housing ASM       |
| 29:1 | 94-6363     | 1    | Bearing           |
| 31   | 252-71      | 2    | Washer-Thrust     |
| 32   | 252-66      | 1    | Bearing-Thrust    |
| 33   | 33-3720     | 1    | Washer            |
| 39   | 98-4635     | 1    | Insert-Plate, Cam |
| 42   | 74-9040     | 1    | Coupler           |
| 43   | 120-5754    | 1    | Seal Kit          |
| 43:1 |             | 2    | Ring-Retaining ■  |
| 43:2 |             | 2    | Ring-Retaining ■  |
| 43:3 |             | 1    | Seal-Shaft ■      |
| 43:4 |             | 1    | Gasket ■          |

● Not illustrated

■ Not serviced separately




## Hydraulic Pump Assembly No. 104-4890 (continued)

| Ref.  | Part Number | Qty. | Description                                 |
|-------|-------------|------|---------------------------------------------|
| 43:5  |             | 1    | Ring-Retaining ■                            |
| 43:6  |             | 1    | Seal-Shaft ■                                |
| 43:7  |             | 1    | Ring-Retaining ■                            |
| 43:8  |             | 5    | Ring-Retaining ■                            |
| 43:9  |             | 1    | Ring-Retaining ■                            |
| 43:10 |             | 1    | O-Ring (Not Used For This Configuration) ■● |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>                                 |
|-------------|--------------------|-------------|----------------------------------------------------|
| 43:11       |                    | 1           | O Ring-Molded (Not Used For This Configuration) ■● |
| 43:12       |                    | 2           | Ring-Retaining ■                                   |
| 43:13       |                    | 1           | O-Ring (Not Used For This Configuration) ■●        |


● Not illustrated

■ Not serviced separately



## Hydraulic Gear Pump Assembly No. 108-9036


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 110-8755           | 1           | Seal Kit           |



## Traction Hydraulic Assembly

| Ref. | Part Number | Qty. | Description         |
|------|-------------|------|---------------------|
| 1    | 340-7       | 5    | Fitting-Straight    |
| 1:1  | 237-65      | 1    | O-Ring              |
| 1:2  | 237-80      | 1    | O-Ring              |
| 2    | 322-9       | 2    | Screw-HH            |
| 3    | 3256-23     | 4    | Washer-Plain        |
| 4    | 3296-29     | 1    | Nut-Lock, NI        |
| 5    | 56-7971     | 4    | Clamp-Tube          |
| 6    | 95-8783     | 1    | Tube ASM            |
| 6:1  | 237-65      | 1    | O-Ring              |
| 7    | 353-990     | 1    | Plug ASM            |
| 7:1  | 237-78      | 1    | O-Ring              |
| 8    | 95-8784     | 1    | Tube ASM            |
| 8:1  | 237-65      | 1    | O-Ring              |
| 9    | 340-14      | 2    | Fitting-HYD, 45 DEG |
| 9:1  | 237-65      | 1    | O-Ring              |
| 9:2  | 237-80      | 1    | O-Ring              |
| 10   | 105-1213    | 1    | Hose-HYD            |
| 11   | 105-1212    | 1    | Hose-HYD            |
| 12   | 100-4887    | 1    | Fitting-Elbow, 90   |
| 12:1 | 237-42      | 1    | O-Ring              |


| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 13   | 340-2       | 1    | Fitting-Straight      |
| 13:1 | 237-22      | 1    | O-Ring                |
| 13:2 | 237-42      | 1    | O-Ring                |
| 14   | 104-0488    | 1    | Hose-HYD              |
| 15   | 92-7595     | 1    | Hose-HYD              |
| 16   | 80-7342     | 1    | Hose-HYD              |
| 17   | 340-8       | 1    | Fitting-Straight      |
| 17:1 | 237-65      | 1    | O-Ring                |
| 17:2 | 237-81      | 1    | O-Ring                |
| 18   | 340-17      | 1    | Fitting-Elbow, 90 DEG |
| 18:1 | 237-65      | 1    | O-Ring                |
| 18:2 | 237-80      | 1    | O-Ring                |
| 19   | 105-1214    | 1    | Hose-HYD              |
| 20   | 2412-36     | 1    | Clamp-Hose            |
| 21   | 340-139     | 1    | Fitting-Elbow 90      |
| 21:1 | 237-81      | 1    | O-Ring                |
| 21:2 | 237-65      | 1    | O-Ring                |
| 22   | 340-18      | 1    | Fitting-HYD, 90 DEG   |
| 22:1 | 237-79      | 1    | O-Ring                |
| 22:2 | 237-22      | 1    | O-Ring                |



## Lift Hydraulic Assembly

| Ref. | Part Number | Qty. | Description          |
|------|-------------|------|----------------------|
| 1    | 340-2       | 2    | Fitting-Straight     |
| 1:1  | 237-22      | 1    | O-Ring               |
| 1:2  | 237-42      | 1    | O-Ring               |
| 2    | 340-70      | 2    | Nut-Lock             |
| 3    | 104-0407    | 1    | Hose-HYD             |
| 4    | 100-4891    | 1    | Hose-HYD             |
| 5    | 95-8790     | 1    | Tube-HYD             |
| 6    | 95-8791     | 1    | Tube-HYD             |
| 7    | 340-154     | 2    | Union-Bulkhead       |
| 7:1  | 237-22      | 2    | O-Ring               |
| 8    | 85-9720     | 1    | Fitting-STR, Orifice |
| 8:1  | 237-78      | 1    | O-Ring               |


| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 8:2  | 237-21      | 1    | O-Ring                |
| 9    | 95-8838     | 1    | Hose-HYD              |
| 10   | 340-132     | 1    | Fitting-Elbow, 90 DEG |
| 10:1 | 237-78      | 1    | O-Ring                |
| 10:2 | 237-21      | 1    | O-Ring                |
| 11   | 95-8839     | 1    | Hose-HYD              |
| 12   | 69-8940     | 4    | Washer                |
| 13   | 240-4       | 2    | Grommet-Rubber        |
| 14   | 69-8970     | 2    | Spacer                |
| 15   | 340-77      | 3    | Fitting-Elbow, 90 DEG |
| 15:1 | 237-22      | 1    | O-Ring                |
| 15:2 | 237-42      | 1    | O-Ring                |



## Steering Hydraulic Assembly

| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 1    | 95-8842     | 1    | Hose-HYD              |
| 2    | 95-8843     | 1    | Hose-HYD              |
| 3    | 100-4892    | 1    | Hose-HYD              |
| 4    | 100-4893    | 1    | Hose-HYD              |
| 5    | 95-8846     | 1    | Hose-HYD              |
| 6    | 340-132     | 2    | Fitting-Elbow, 90 DEG |
| 6:1  | 237-78      | 1    | O-Ring                |
| 6:2  | 237-21      | 1    | O-Ring                |


| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 7    | 69-4320     | 1    | Fitting-HYD, 90 DEG   |
| 7:1  | 237-22      | 1    | O-Ring                |
| 7:2  | 237-42      | 1    | O-Ring                |
| 8    | 340-77      | 2    | Fitting-Elbow, 90 DEG |
| 8:1  | 237-22      | 1    | O-Ring                |
| 8:2  | 237-42      | 1    | O-Ring                |
| 9    | 353-397     | 1    | Reducer-Adapter       |
| 9:1  | 237-79      | 1    | O-Ring                |



## Sidewinder Hydraulic Assembly

| Ref. | Part Number | Qty. | Description                |
|------|-------------|------|----------------------------|
| 1    | 340-3       | 1    | Fitting-Straight           |
| 1:1  | 237-22      | 1    | O-Ring                     |
| 1:2  | 237-79      | 1    | O-Ring                     |
| 2    | 104-0402    | 1    | Tube-HYD                   |
| 2:1  | 237-22      | 1    | O-Ring                     |
| 3    | 340-70      | 4    | Nut-Lock                   |
| 4    | 340-68      | 1    | Fitting-Tee, Bulkhead      |
| 4:1  | 237-22      | 3    | O-Ring                     |
| 5    | 340-77      | 3    | Fitting-Elbow, 90 DEG      |
| 5:1  | 237-22      | 1    | O-Ring                     |
| 5:2  | 237-42      | 1    | O-Ring                     |
| 6    | 104-0403    | 1    | Tube ASM                   |
| 6:1  | 237-22      | 1    | O-Ring                     |
| 7    | 340-71      | 1    | Fitting-Straight, Bulkhead |
| 7:1  | 237-22      | 2    | O-Ring                     |


| Ref. | Part Number | Qty. | Description      |
|------|-------------|------|------------------|
| 8    | 340-7       | 2    | Fitting-Straight |
| 8:1  | 237-65      | 1    | O-Ring           |
| 8:2  | 237-80      | 1    | O-Ring           |
| 9    | 340-92      | 1    | Fitting-Straight |
| 9:1  | 237-78      | 1    | O-Ring           |
| 9:2  | 237-21      | 1    | O-Ring           |
| 10   | 100-4827    | 1    | Tube-HYD         |
| 11   | 95-8822     | 1    | Hose-HYD         |
| 12   | 104-0405    | 1    | Hose-HYD         |
| 13   | 95-8821     | 1    | Hose-HYD         |
| 14   | 104-0406    | 1    | Hose-HYD         |
| 15   | 340-2       | 2    | Fitting-Straight |
| 15:1 | 237-22      | 1    | O-Ring           |
| 15:2 | 237-42      | 1    | O-Ring           |



## Mow Hydraulic Assembly

| Ref. | Part Number | Qty. | Description              |
|------|-------------|------|--------------------------|
| 1    | 340-70      | 1    | Nut-Lock                 |
| 2    | 340-68      | 1    | Fitting-Tee, Bulkhead    |
| 2:1  | 237-22      | 3    | O-Ring                   |
| 3    | 340-74      | 7    | Nut-Lock, Bulkhead       |
| 4    | 340-72      | 1    | Fitting-Bulkhead, 90 DEG |
| 4:1  | 237-65      | 2    | O-Ring                   |
| 5    | 100-4879    | 2    | Hose-HYD                 |
| 6    | 115-3411    | 1    | Hose-HYD                 |
| 7    | 104-0401    | 1    | Tube ASM                 |
| 7:1  | 237-58      | 1    | O-Ring                   |
| 8    | 104-0400    | 1    | Tube ASM                 |
| 8:1  | 237-58      | 1    | O-Ring                   |
| 9    | 104-0404    | 1    | Tube ASM                 |
| 9:1  | 237-22      | 1    | O-Ring                   |
| 10   | 99-3641     | 2    | Clamp-Tube               |
| 11   | 3256-22     | 4    | Washer-Flat              |
| 12   | 321-11      | 2    | Screw-HH                 |
| 13   | 3296-42     | 2    | Nut-Lock, NI             |
| 14   | 3334-945    | 2    | Tie-Cable                |


| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 15   | 99-3640     | 1    | Tube ASM              |
| 15:1 | 237-58      | 1    | O-Ring                |
| 16   | 340-78      | 1    | Nut-Lock              |
| 17   | 105-1216    | 2    | Hose-HYD              |
| 18   | 340-7       | 1    | Fitting-Straight      |
| 18:1 | 237-65      | 1    | O-Ring                |
| 18:2 | 237-80      | 1    | O-Ring                |
| 19   | 105-1215    | 2    | Hose-HYD              |
| 20   | 340-92      | 3    | Fitting-Straight      |
| 20:1 | 237-78      | 1    | O-Ring                |
| 20:2 | 237-21      | 1    | O-Ring                |
| 21   | 104-1080    | 2    | Hose-HYD              |
| 22   | 100-4876    | 1    | Hose-HYD              |
| 23   | 99-3477     | 1    | Fitting-Tee           |
| 23:1 | 237-42      | 2    | O-Ring                |
| 24   | 100-4880    | 2    | Hose-HYD              |
| 25   | 340-17      | 5    | Fitting-Elbow, 90 DEG |
| 25:1 | 237-65      | 1    | O-Ring                |
| 25:2 | 237-80      | 1    | O-Ring                |



## Crankcase Assembly


| Ref. | Part Number | Qty. | Description    |
|------|-------------|------|----------------|
| 10   | 115-3443    | 1    | Crankcase ASM  |
| 20   | 98-9398     | 4    | Cap-Sealing    |
| 30   | 98-7539     | 1    | Cap-Sealing    |
| 40   | 98-7540     | 3    | Plug           |
| 50   | 105-3779    | 1    | Plug           |
| 60   | 98-9597     | 3    | Plug           |
| 70   | 98-7487     | 2    | Plug           |
| 80   | 98-9379     | 3    | Plug-Expansion |
| 90   | 98-9668     | 1    | Plug-Expansion |
| 100  | 98-9375     | 2    | Pin-Straight   |
| 110  | 98-9377     | 2    | Pin-Straight   |
| 120  | 98-9376     | 2    | Pin-Straight   |

| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 130  | 98-9387     | 2    | Pin-Pipe               |
| 140  | 98-9539     | 1    | Pin-Pipe               |
| 150  | 98-9599     | 1    | Plug                   |
| 160  | 98-9630     | 1    | Pin-Spring, Start      |
| 170  | 98-9675     | 1    | Plug                   |
| 180  | 98-9656     | 1    | Bushing-Governor, Gear |
| 190  | 120-2559    | 1    | Plug                   |
| 200  | 98-7428     | 1    | Gasket                 |
| 210  | 99-3447     | 1    | Plug                   |
| 220  | 106-7056    | 1    | Gasket                 |
| 230  | 98-9416     | 1    | Switch-Oil             |




## Oil Pan Assembly

| Ref. | Part Number | Qty. | Description |
|------|-------------|------|-------------|
| 10   | 98-9685     | 1    | Pan-Oil     |
| 30   | 98-9351     | 22   | Bolt        |
| 40   | 114-8151    | 2    | Plug-Drain  |
| 50   | 98-7524     | 2    | Gasket      |
| 60   | 112-7044    | 1    | Head-Filter |
| 70   | 98-7526     | 1    | Bolt        |
| 80   | 105-3776    | 1    | O-Ring      |



## Cylinder Head Assembly


| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 10   | 98-7531     | 2    | Hook-Engine           |
| 20   | 100-9195    | 2    | Bolt                  |
| 30   | 108-6573    | 1    | Gasket-Head, Cylinder |
| 40   | 115-3445    | 1    | Cylinder Head ASM     |
| 50   | 105-3705    | 1    | Cap-Sealing           |
| 60   | 98-7540     | 2    | Plug                  |
| 70   | 107-9066    | 3    | Guide-Valve, Inlet    |
| 80   | 107-9067    | 3    | Guide-Valve, Exhaust  |
| 90   | 98-9389     | 2    | Cap-Sealing           |
| 100  | 98-9479     | 12   | Bolt-Head, Cylinder   |
| 110  | 98-9647     | 2    | Bolt-Head, Cylinder   |
| 120  | 98-9444     | 1    | Plug                  |



## Gear Case and Oil Filter Cartridge Assembly


| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 10   | 115-4105    | 1    | Gear Case ASM      |
| 20   | 98-9598     | 2    | Plug               |
| 25   | 98-7487     | 1    | Plug               |
| 30   | 98-7562     | 1    | Washer-Plain       |
| 40   | 98-9388     | 1    | Joint-Pipe         |
| 50   | 98-9544     | 1    | Spring             |
| 60   | 98-9543     | 1    | Seat-Valve         |
| 70   | 98-9380     | 1    | Ball               |
| 80   | 98-9540     | 1    | Oil Pump Rotor ASM |
| 90   | 107-9069    | 1    | Cover-Pump, Oil    |
| 95   | 107-9072    | 2    | Pin-Straight       |
| 100  | 107-9071    | 5    | Screw              |

| Ref. | Part Number | Qty. | Description       |
|------|-------------|------|-------------------|
| 110  | 98-9633     | 1    | Gasket-Case, Gear |
| 120  | 107-9073    | 3    | Bolt              |
| 130  | 105-3797    | 4    | Bolt              |
| 140  | 98-9356     | 4    | Bolt              |
| 150  | 107-9074    | 1    | Bolt              |
| 160  | 98-9586     | 1    | Bolt              |
| 170  | 105-3709    | 1    | Stud              |
| 180  | 100-2203    | 1    | Nut-Flange        |
| 190  | 119-8038    | 1    | Seal-Oil          |
| 200  | 105-3710    | 2    | Stud              |
| 210  | 98-9641     | 1    | Cover-Case, Gear  |
| 220  | 108-3841    | 1    | Filter-Oil        |




## Cylinder Head Cover Assembly

| Ref. | Part Number | Qty. | Description             |
|------|-------------|------|-------------------------|
| 10   | 115-3446    | 1    | Cylinder Head Cover ASM |
| 30   | 98-9615     | 1    | Gasket-Cover, Head      |
| 40   | 110-3715    | 1    | Valve-Breather          |
| 50   | 110-3714    | 1    | Cover-Breather          |
| 60   | 98-9364     | 4    | Screw (With Washer)     |
| 70   | 98-7766     | 1    | Pipe-Return, Water      |
| 80   | 98-9455     | 3    | Nut-Cap                 |
| 90   | 98-9454     | 3    | Gasket                  |
| 100  | 107-7836    | 1    | Tube-Breather           |
| 110  | 108-2859    | 1    | Clamp-Hose              |
| 120  | 108-2860    | 1    | Clamp-Hose              |
| 130  | 107-9075    | 1    | Plug-Filler, Oil        |
| 140  | 99-3446     | 1    | O-Ring                  |



## Dipstick and Guide Assembly


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 10          | 107-9076           | 1           | Gauge-Oil          |
| 20          | 105-4580           | 1           | Guide-Gauge, Oil   |
| 30          | 110-3720           | 1           | Plug-Gauge, Oil    |



## Main Bearing Case Assembly


| Ref. | Part Number | Qty. | Description               |
|------|-------------|------|---------------------------|
| 10   | 112-7026    | 1    | Wheel Bearing Case ASM    |
| 20   | 98-9484     | 2    | Bolt-Case, Bearing        |
| 25   | 115-4121    | 1    | Metal-Crankshaft (STD)    |
| 25   | 112-7039    | 1    | Metal-Crankshaft (0.2Mm)  |
| 25   | 112-7040    | 1    | Metal-Crankshaft (-0.4Mm) |
| 30   | 98-9634     | 1    | Gasket-Case, Bearing      |
| 40   | 112-7046    | 1    | Cover-Case, Bearing       |
| 50   | 112-0180    | 1    | Seal-Oil                  |
| 60   | 112-7037    | 1    | Gasket-Cover, Case        |
| 70   | 98-9352     | 8    | Bolt                      |
| 80   | 98-7568     | 9    | Bolt                      |

| Ref. | Part Number | Qty. | Description             |
|------|-------------|------|-------------------------|
| 90   | 115-4106    | 1    | Main Bearing Case ASM   |
| 100  | 98-9484     | 2    | Bolt-Case, Bearing      |
| 105  | 112-7011    | 1    | Bearing-Main (STD)      |
| 105  | 112-7012    | 1    | Metal-Crankpin (-0.2MM) |
| 105  | 112-7013    | 1    | Metal-Crankpin (-0.4MM) |
| 110  | 98-9485     | 2    | Bolt-Case, Bearing      |
| 120  | 115-4107    | 1    | Main Bearing Case ASM   |
| 130  | 98-9484     | 2    | Bolt-Case, Bearing      |
| 140  | 112-7011    | 1    | Bearing-Main (STD)      |
| 140  | 112-7012    | 1    | Metal-Crankpin (-0.2MM) |
| 140  | 112-7013    | 1    | Metal-Crankpin (-0.4MM) |



## Camshaft and Idle Gear Shaft Assembly


| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 10   | 112-0185    | 6    | Tappet             |
| 20   | 98-9509     | 6    | Rod-Push           |
| 30   | 108-6576    | 1    | Camshaft ASM       |
| 40   | 110-3729    | 1    | Ball               |
| 50   | 98-9512     | 1    | Gear-Cam           |
| 60   | 98-9378     | 1    | Key-Feather        |
| 70   | 98-9510     | 1    | Stopper-Camshaft   |
| 80   | 98-7692     | 2    | Bolt               |
| 90   | 98-9649     | 1    | Idle Gear ASM      |
| 100  | 98-9650     | 1    | Bushing-Gear, Idle |
| 110  | 98-9535     | 1    | Collar-Gear, Idle  |
| 120  | 98-9536     | 1    | Collar-Gear, Idle  |
| 130  | 98-9534     | 1    | Circlip-Gear, Idle |
| 140  | 98-9533     | 1    | Shaft-Gear, Idle   |
| 150  | 98-7692     | 3    | Bolt               |



## Piston and Crankshaft Assembly


| Ref. | Part Number | Qty. | Description              |
|------|-------------|------|--------------------------|
| 10   | 112-8404    | 3    | Piston (STD)             |
| 10   | 112-8414    | 3    | Piston (+0.5Mm)          |
| 20   | 98-9551     | 3    | Piston Ring ASM (STD)    |
| 20   | 108-1404    | 3    | Piston Ring ASM (+0.5MM) |
| 30   | 98-9513     | 3    | Pin-Piston               |
| 40   | 98-9514     | 6    | Circlip-Pin, Piston      |
| 50   | 117-7586    | 3    | Connecting Rod ASM       |
| 60   | 115-3014    | 3    | Bushing-Pin, Piston      |
| 70   | 98-9517     | 6    | Bolt-Rod, Connecting     |
| 80   | 98-9553     | 3    | Bearing-Rod (STD)        |
| 80   | 117-7587    | 3    | Metal-Crankpin (-0.2MM)  |
| 80   | 117-7588    | 3    | Metal-Crankpin (-0.4MM)  |
| 90   | 98-9642     | 1    | Crankshaft ASM           |
| 100  | 117-7561    | 1    | Gear-Crankshaft          |

| Ref. | Part Number | Qty. | Description             |
|------|-------------|------|-------------------------|
| 110  | 98-9666     | 1    | Key                     |
| 120  | 98-9542     | 1    | Gear-Drive, Oil Pump    |
| 130  | 98-9522     | 1    | Sleeve-Crankshaft       |
| 140  | 98-9521     | 1    | Collar-Crankshaft       |
| 150  | 105-3783    | 1    | O-Ring                  |
| 160  | 112-7005    | 1    | Bearing-Main (STD)      |
| 160  | 112-7009    | 1    | Metal-Crankpin (-0.2MM) |
| 160  | 112-7010    | 1    | Metal-Crankpin (-0.4MM) |
| 170  | 98-9413     | 2    | Bearing-Thrust (STD)    |
| 170  | 98-9414     | 2    | Bearing-Thrust (0.2MM)  |
| 170  | 98-9415     | 2    | Bearing-Thrust (0.4MM)  |
| 180  | 98-9688     | 2    | Bearing-Thrust (STD)    |
| 180  | 98-9689     | 2    | Bearing-Thrust (0.2MM)  |
| 180  | 98-9690     | 2    | Bearing-Thrust (0.4MM)  |



## Flywheel Assembly


| Ref. | Part Number | Qty. | Description     |
|------|-------------|------|-----------------|
| 10   | 105-3784    | 1    | Flywheel ASM    |
| 20   | 115-3015    | 1    | Gear-Ring       |
| 30   | 98-9537     | 6    | Bolt-Flywheel   |
| 40   | 98-9486     | 1    | Plate-End, Rear |
| 50   | 98-9392     | 8    | Bolt            |



## Fuel Camshaft and Governor Shaft Assembly

| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 10   | 98-9459     | 1    | Camshaft-Fuel          |
| 20   | 107-9077    | 1    | Bearing-Ball           |
| 30   | 107-9078    | 1    | Bearing-Ball           |
| 60   | 98-9590     | 1    | Nut-Cap                |
| 70   | 120-2562    | 1    | Gear-Pump, Injection   |
| 80   | 98-9595     | 1    | Key-Woodruff           |
| 90   | 98-9511     | 1    | Stopper-Fuel, Camshaft |
| 100  | 98-7692     | 2    | Bolt                   |
| 110  | 98-9644     | 1    | Governor Shaft ASM     |
| 120  | 98-9562     | 1    | Holder-Gear, Governor  |


| Ref. | Part Number | Qty. | Description             |
|------|-------------|------|-------------------------|
| 130  | 98-9673     | 1    | Gear-Governor           |
| 140  | 98-9561     | 1    | Holder-Weight, Governor |
| 150  | 98-9559     | 2    | Governor Weight ASM     |
| 160  | 98-9560     | 2    | Shaft-Weight, Governor  |
| 170  | 98-9692     | 2    | Roller                  |
| 180  | 98-9563     | 1    | Sleeve-Governor         |
| 190  | 98-9564     | 1    | Washer-Thrust           |
| 200  | 107-9079    | 1    | Bearing-Ball            |
| 210  | 98-9657     | 1    | Circlip-Shaft, Governor |
| 220  | 98-9565     | 1    | Screw-Set               |



## Idle Apparatus and Stop Solenoid Assembly

| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 10   | 98-9678     | 1    | Idle Apparatus ASM |
| 20   | 112-7014    | 1    | Adjusting Bolt ASM |
| 30   | 98-9439     | 1    | Nut                |
| 40   | 112-0181    | 1    | Nut                |
| 50   | 98-7654     | 2    | Gasket             |
| 60   | 98-7656     | 1    | Cap                |
| 70   | 112-7015    | 1    | Bolt-Adjusting     |
| 80   | 100-2175    | 1    | Nut-Lock           |
| 90   | 112-0181    | 1    | Nut                |

| Ref. | Part Number | Qty. | Description       |
|------|-------------|------|-------------------|
| 100  | 98-7654     | 1    | Gasket            |
| 110  | 107-9081    | 1    | Gasket            |
| 120  | 104-5155    | 1    | Solenoid-Stop     |
| 130  | 115-3039    | 2    | Bolt-HSH          |
| 140  | 99-3514     | 1    | Cover             |
| 150  | 117-7562    | 1    | Gasket-Pump, Fuel |
| 160  | 100-2203    | 2    | Nut-Flange        |
| 170  | 112-7016    | 1    | Cover-Pump        |




## Injection Pump Assembly

| Ref. | Part Number | Qty. | Description              |
|------|-------------|------|--------------------------|
| 10   | 98-9596     | 1    | Joint-Eye                |
| 20   | 98-9643     | 1    | Injection Pump ASM       |
| 30   | 98-9464     | 1    | Bolt-Joint               |
| 40   | 98-9445     | 2    | Gasket                   |
| 50   | 98-9430     | 1    | Screw                    |
| 60   | 98-9446     | 1    | Gasket                   |
| 70   | 98-9466     | 1    | Plug                     |
| 80   | 98-9451     | 1    | Gasket                   |
| 90   | 115-3045    | 1    | Shim-Injection (0.175MM) |

| Ref. | Part Number | Qty. | Description             |
|------|-------------|------|-------------------------|
| 90   | 98-9456     | 1    | Shim-Injection (0.20MM) |
| 90   | 98-9457     | 1    | Shim-Injection (0.25MM) |
| 90   | 98-9458     | 1    | Shim-Injection (0.30MM) |
| 90   | 115-3046    | 1    | Shim-Injection (0.35MM) |
| 100  | 117-7564    | 2    | Bolt-Hex Soc HD         |
| 110  | 98-9438     | 2    | Stud                    |
| 120  | 98-9440     | 2    | Nut-Cap                 |
| 130  | 98-7699     | 4    | Washer-Spring           |






## Speed Control Plate Assembly

| Ref. | Part Number | Qty. | Description          |
|------|-------------|------|----------------------|
| 10   | 105-3735    | 1    | Control Plate ASM    |
| 20   | 98-9662     | 1    | Lever-Control, Speed |
| 30   | 98-9572     | 2    | Lever-Control, Speed |
| 40   | 105-3788    | 1    | O-Ring               |
| 50   | 98-7602     | 2    | Pin-Spring           |
| 60   | 98-9594     | 2    | Washer-Plain         |
| 70   | 98-9589     | 2    | Nut                  |
| 80   | 98-9658     | 1    | Governor Lever ASM   |
| 90   | 98-9663     | 1    | Lever-Stop, Engine   |


| Ref. | Part Number | Qty. | Description       |
|------|-------------|------|-------------------|
| 100  | 98-7601     | 1    | Seal-Oil          |
| 110  | 98-9472     | 1    | Spring-Return     |
| 120  | 98-9664     | 1    | Shaft-Lever, Stop |
| 130  | 98-9637     | 1    | Gasket            |
| 140  | 98-7692     | 1    | Bolt              |
| 150  | 99-8348     | 1    | Bolt              |
| 160  | 98-7654     | 1    | Gasket            |
| 170  | 105-3710    | 2    | Stud              |
| 180  | 100-2203    | 2    | Nut-Flange        |



## Nozzle Holder and Glow Plug Assembly


| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 10   | 98-9620     | 1    | Overflow Pipe ASM  |
| 20   | 98-9431     | 1    | Screw-Bleeder, Air |
| 30   | 98-7654     | 1    | Gasket             |
| 40   | 98-9420     | 1    | Overflow Pipe ASM  |
| 45   | 112-0182    | 1    | Pipe-Overflow      |
| 50   | 98-7671     | 2    | Clip-Pipe          |
| 60   | 108-2866    | 3    | Nozzle Holder Kit  |
| 70   | 98-7676     | 3    | Gasket             |
| 80   | 98-7677     | 3    | Seal-Heat          |

| Ref. | Part Number | Qty. | Description      |
|------|-------------|------|------------------|
| 90   | 98-9622     | 1    | Pipe-Injection   |
| 100  | 98-9654     | 1    | Pipe-Injection   |
| 110  | 98-9655     | 1    | Pipe-Injection   |
| 120  | 98-7682     | 2    | Clamp-Pipe       |
| 130  | 98-7683     | 2    | Clamp-Pipe       |
| 140  | 98-7684     | 2    | Screw (W/Washer) |
| 150  | 115-3019    | 3    | Plug-Glow        |
| 160  | 98-9631     | 3    | Cord-Plug, Glow  |
| 170  | 99-8377     | 1    | Nut-Flange       |




## Nozzle Holder Assembly

| Ref. | Part Number | Qty. | Description            | Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|------|-------------|------|------------------------|
| 10   | 108-2866    | 3    | Nozzle Holder Kit      | 110  | 99-8311     | 3    | Washer-Adjust (0.20MM) |
| 20   | 99-8301     | 3    | Nut                    | 110  | 99-8312     | 3    | Washer-Adjust (0.30MM) |
| 30   | 99-8302     | 3    | Washer-Adjusting       | 110  | 99-8313     | 3    | Washer-Adjust (0.40MM) |
| 40   | 99-8303     | 3    | Spring-Nozzle          | 110  | 99-8314     | 3    | Washer-Adjust (0.50MM) |
| 50   | 99-8304     | 3    | Spacer-Distance        | 110  | 99-8315     | 3    | Washer-Adjust (0.52MM) |
| 60   | 99-8305     | 3    | Rod-Push               | 110  | 99-8316     | 3    | Washer-Adjust (0.54MM) |
| 70   | 99-8306     | 3    | Nut-Nozzle             | 110  | 99-8317     | 3    | Washer-Adjust (0.56MM) |
| 80   | 99-8307     | 3    | Washer-Plain           | 110  | 99-8318     | 3    | Washer-Adjust (0.58MM) |
| 90   | 107-7826    | 3    | Piece-Nozzle           | 110  | 99-8319     | 3    | Washer-Adjust (0.80MM) |
| 100  | 99-8309     | 3    | Adjusting Washer ASM   | 120  | 98-7676     | 3    | Gasket                 |
| 110  | 99-8310     | 3    | Washer-Adjust (0.10MM) | 130  | 98-7677     | 3    | Seal-Heat              |



## Alternator and Pulley Assembly


| Ref. | Part Number | Qty. | Description       |
|------|-------------|------|-------------------|
| 10   | 98-9474     | 1    | Alternator ASM    |
| 20   | 112-7047    | 1    | Stay-Dynamo       |
| 30   | 108-7088    | 1    | Bolt              |
| 40   | 98-9360     | 1    | Bolt              |
| 50   | 98-9366     | 1    | Washer-Plain      |
| 60   | 98-7738     | 1    | Washer-Spring     |
| 70   | 98-7737     | 1    | Nut               |
| 80   | 98-7692     | 1    | Bolt              |
| 100  | 98-9473     | 1    | Pulley-Drive, Fan |
| 110  | 98-9585     | 1    | Bolt              |
| 120  | 104-3494    | 1    | Belt-V            |
| 130  | 107-9096    | 1    | Fan-Cooling       |
| 140  | 108-2873    | 4    | Bolt-Flange       |
| 150  | 104-3497    | 1    | Pulley-Fan        |
| 160  | 108-2872    | 1    | Collar-Fan        |



## Alternator Components Assembly


| Ref. | Part Number | Qty. | Description         |
|------|-------------|------|---------------------|
| 10   | 98-9474     | 1    | Alternator ASM      |
| 20   | 98-9453     | 1    | Pulley-Dynamo       |
| 30   | 98-7708     | 1    | Nut                 |
| 40   | 98-7709     | 1    | Collar              |
| 50   | 107-0136    | 1    | Rotor ASM           |
| 60   | 98-7711     | 1    | Cover-Bearing       |
| 70   | 107-0138    | 1    | Bearing-Ball        |
| 80   | 98-7713     | 1    | Washer-Thrust       |
| 90   | 107-0139    | 1    | Drive End Frame ASM |
| 100  | 98-7715     | 1    | Plate-Retainer      |
| 110  | 98-7716     | 4    | Screw-Head, Round   |
| 120  | 98-7717     | 2    | Bolt-Through        |
| 130  | 107-0137    | 1    | Bearing-Ball        |
| 140  | 107-9087    | 1    | Frame-End           |

| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 150  | 107-0140    | 1    | Cover-End          |
| 160  | 98-7721     | 1    | Rectifier ASM      |
| 170  | 98-7722     | 1    | Bushing-Insulation |
| 180  | 107-0141    | 1    | Brush Holder ASM   |
| 190  | 98-7724     | 2    | Brush              |
| 200  | 98-7725     | 2    | Spring-Brush       |
| 210  | 98-7726     | 2    | Screw-Head, Round  |
| 220  | 98-7727     | 6    | Screw-Head, Round  |
| 230  | 98-7728     | 1    | Screw-Head, Round  |
| 240  | 98-7729     | 3    | Bolt               |
| 250  | 98-7730     | 2    | Nut                |
| 260  | 98-7731     | 2    | Bolt               |
| 270  | 98-7732     | 1    | Nut                |
| 280  | 110-3799    | 1    | Regulator ASM      |



## Starter Assembly


| Ref. | Part Number | Qty. | Description   |
|------|-------------|------|---------------|
| 10   | 98-9705     | 1    | Starter ASM   |
| 20   | 98-7697     | 2    | Bolt          |
| 30   | 98-7739     | 1    | Nut           |
| 40   | 105-2893    | 1    | Washer-Spring |



## Starter Component Assembly


| Ref. | Part Number | Qty. | Description          |
|------|-------------|------|----------------------|
| 10   | 98-9705     | 1    | Starter ASM          |
| 20   | 104-8608    | 1    | Yoke ASM             |
| 30   | 98-7742     | 1    | Armature ASM         |
| 40   | 98-7744     | 1    | Bearing              |
| 50   | 98-7743     | 1    | Bearing              |
| 60   | 99-8373     | 1    | Clutch-Running, Over |
| 70   | 99-8374     | 1    | Frame-End, Drive     |
| 80   | 105-3746    | 1    | Magnetic Switch ASM  |
| 90   | 98-7748     | 1    | Frame-End            |
| 100  | 98-7749     | 1    | Brush Holder ASM     |
| 110  | 98-7750     | 4    | Spring-Brush         |
| 120  | 98-7751     | 1    | Gear                 |
| 130  | 98-7752     | 1    | Retainer             |

| Ref. | Part Number | Qty. | Description         |
|------|-------------|------|---------------------|
| 140  | 98-7753     | 5    | Roller              |
| 150  | 98-7754     | 1    | Spring              |
| 160  | 98-7755     | 1    | Ball                |
| 170  | 98-7756     | 2    | Bolt                |
| 180  | 98-7757     | 2    | O-Ring              |
| 190  | 100-9240    | 2    | Bolt                |
| 200  | 98-7758     | 2    | Bolt ASM            |
| 210  | 99-8375     | 1    | Cover               |
| 220  | 99-8371     | 1    | Nut-Hex             |
| 230  | 98-9711     | 1    | Cord-Solenoid, Stop |
| 240  | 99-8376     | 1    | Nut-Hex             |
| 250  | 98-7759     | 1    | Pipe-Drain          |
| 260  | 98-9712     | 1    | Band-Cover          |




## Water Flange and Thermostat Assembly

| Ref. | Part Number | Qty. | Description          |
|------|-------------|------|----------------------|
| 10   | 98-9713     | 1    | Water Flange ASM     |
| 20   | 98-9580     | 1    | Pipe-Return, Water   |
| 30   | 105-3747    | 1    | Plug                 |
| 40   | 99-3583     | 1    | Gasket               |
| 50   | 98-9638     | 1    | Gasket-Flange, Water |
| 60   | 98-7692     | 3    | Bolt                 |
| 70   | 98-9356     | 1    | Bolt                 |
| 80   | 98-9578     | 1    | Pipe-Return, Water   |
| 90   | 98-9579     | 2    | Band-Pipe            |
| 100  | 98-9719     | 1    | Thermoswitch         |
| 110  | 98-7778     | 1    | Thermostat ASM       |
| 120  | 104-4804    | 1    | Outlet-Water         |
| 130  | 105-3748    | 1    | Gasket-Thermostat    |
| 140  | 98-7777     | 2    | Bolt                 |



## Water Pump Assembly


| Ref. | Part Number | Qty. | Description          |
|------|-------------|------|----------------------|
| 10   | 107-9089    | 1    | Water Pump ASM       |
| 20   | 99-3516     | 1    | Flange-Pump, Water   |
| 40   | 105-3750    | 1    | Mechanical Seal ASM  |
| 50   | 112-7017    | 1    | Impeller-Pump, Water |
| 60   | 100-1932    | 1    | Pipe-Return, Water   |
| 70   | 99-3454     | 1    | Gasket-Pump, Water   |
| 80   | 98-9353     | 4    | Bolt                 |
| 90   | 98-9357     | 2    | Bolt                 |
| 100  | 98-9716     | 1    | Pipe-Water           |
| 110  | 107-9091    | 1    | Pipe-Water           |
| 120  | 98-9717     | 2    | Clamp                |



## Valve and Rocker Arm Assembly


| Ref. | Part Number | Qty. | Description          |
|------|-------------|------|----------------------|
| 10   | 120-2563    | 3    | Valve-Inlet          |
| 20   | 120-2564    | 3    | Valve-Exhaust        |
| 30   | 98-9648     | 6    | Spring-Valve         |
| 40   | 107-9092    | 6    | Retainer-Spring      |
| 50   | 117-7572    | 6    | Collet-Spring, Valve |
| 60   | 99-8385     | 6    | Seal-Stem, Valve     |
| 70   | 98-9497     | 6    | Cap-Valve            |
| 80   | 105-3790    | 1    | R-Arm Shaft ASM      |
| 90   | 100-9265    | 2    | Bolt                 |
| 100  | 98-9505     | 3    | Bracket-Arm, Rocker  |

| Ref. | Part Number | Qty. | Description              |
|------|-------------|------|--------------------------|
| 110  | 105-3758    | 1    | Pin-Spring               |
| 120  | 98-9507     | 2    | Washer-Shaft, Rocker Arm |
| 130  | 110-3832    | 2    | Washer-Plain             |
| 140  | 98-9504     | 2    | Spring-Arm, Rocker       |
| 160  | 112-7020    | 6    | Rocker Arm ASM           |
| 170  | 98-9502     | 6    | Screw-Adjusting          |
| 180  | 98-9503     | 6    | Nut                      |
| 190  | 98-9506     | 3    | Stud                     |
| 200  | 98-9393     | 3    | Nut                      |
| 210  | 98-9385     | 3    | Washer-Flat              |




## Inlet and Exhaust Manifold Assembly

| Ref. | Part Number | Qty. | Description              |
|------|-------------|------|--------------------------|
| 10   | 107-7843    | 1    | Manifold Inlet ASM       |
| 20   | 98-9492     | 1    | Joint-Pipe, Breather     |
| 30   | 98-9609     | 1    | Gasket-Manifold, Inlet   |
| 40   | 98-7605     | 3    | Bolt                     |
| 50   | 98-9353     | 1    | Bolt                     |
| 60   | 105-3797    | 2    | Bolt                     |
| 70   | 107-9093    | 1    | Manifold-Exhaust         |
| 80   | 99-8327     | 1    | Gasket-Manifold, Exhaust |
| 90   | 98-9588     | 6    | Stud                     |
| 100  | 98-9665     | 6    | Nut                      |
| 110  | 98-7769     | 4    | Stud                     |



## Miscellaneous Engine Parts

| Ref. | Part Number | Qty. | Description             |
|------|-------------|------|-------------------------|
| 10   | 98-7612     | 1    | Filter-Fuel             |
| 20   | 99-8343     | 1    | Gasket-Muffler          |
| 40   | 98-7611     | 1    | Controller-Glow         |
| 50   | 106-7772    | 1    | Thermoswitch            |
| 60   | 117-8836    | 1    | Manual-Operator, Kubota |
| 70   | 110-0806    | 1    | Decal-Caution           |
| 80   | 110-3843    | 1    | Label-Instruction       |
| 90   | 104-9318    | 1    | Bottle-Overflow         |
| 100  | 115-4132    | 1    | Cap                     |
| 110  | 105-3755    | 1    | Gasket                  |
| 120  | 105-3756    | 1    | Plate                   |



## Upper and Lower Gasket Kits

| Ref. | Part Number | Qty. | Description              |
|------|-------------|------|--------------------------|
| 10   | 107-7848    | 1    | Upper Gasket Kit         |
| 20   | 108-6573    | 1    | Gasket-Head, Cylinder    |
| 30   | 98-9615     | 1    | Gasket-Cover, Head       |
| 40   | 98-9609     | 1    | Gasket-Manifold, Inlet   |
| 50   | 99-8343     | 1    | Gasket-Muffler           |
| 60   | 99-8327     | 1    | Gasket-Manifold, Exhaust |
| 70   | 98-9638     | 1    | Gasket-Flange, Water     |
| 80   | 105-3748    | 1    | Gasket-Thermostat        |
| 90   | 99-3446     | 2    | O-Ring                   |
| 100  | 98-9454     | 3    | Gasket                   |
| 110  | 99-8385     | 6    | Seal-Stem, Valve         |
| 120  | 107-9095    | 1    | Lower Gasket Kit         |
| 130  | 98-9637     | 1    | Gasket                   |
| 140  | 98-9633     | 1    | Gasket-Case, Gear        |

| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 150  | 98-9634     | 1    | Gasket-Case, Bearing   |
| 160  | 112-7037    | 1    | Gasket-Cover, Case     |
| 170  | 98-9636     | 1    | Gasket-Pump, Fuel      |
| 180  | 98-9632     | 1    | Gasket-Pump, Water     |
| 190  | 99-3454     | 1    | Gasket-Pump, Water     |
| 200  | 98-9682     | 1    | Gasket                 |
| 210  | 98-9683     | 1    | Gasket-Cover, Solenoid |
| 220  | 105-3781    | 2    | O-Ring                 |
| 230  | 105-3777    | 2    | O-Ring                 |
| 240  | 105-3783    | 1    | O-Ring                 |
| 250  | 105-3776    | 1    | O-Ring                 |
| 260  | 105-3788    | 1    | O-Ring                 |
| 270  | 98-7601     | 1    | Seal-Oil               |

# Attachments and Accessories

## For 30807 Groundsmaster 3500-D Rotary Mower

| Product Name                              | Model/Part  |
|-------------------------------------------|-------------|
| Blade-High Lift .....                     | 104-5183    |
| Blade-Angle Sail .....                    | 105-9810-03 |
| Blade-Atomic .....                        | 107-0235-03 |
| 27in Blade Service Pack (qty 6) .....     | 108-1462    |
| Blade-Combo.....                          | 108-9026-03 |
| Sectional Roller Assembly .....           | 117-5121    |
| 400-hour Filter Maintenance MVP Kit ..... | 30090       |
| Premium Seat Kit.....                     | 30629       |
| 27in Rotary Cutting Unit.....             | 30834       |
| Leaf Mulching Kit .....                   | 30836       |
| Work Light Kit .....                      | 30841       |

**Notes:**

**Notes:**



**Count on it.**