



MODEL NO. 30385—70001 & OVER

**OPERATOR'S
MANUAL**

84" REAR DISCHARGE DECK



Table of Contents

SPECIFICATIONS	2	MAINTENANCE	12
SAFETY INSTRUCTIONS	3	Lubrication	12
Symbol Glossary	6	Disconnecting Cutting Unit from Traction Unit	13
BEFORE OPERATING	9	Connecting Cutting Unit to Traction Unit	13
Check Lubricant in Gear Box	9	Changing Gear Box Lubricant	14
Adjusting Height-of-Cut	9	Replacing Drive Belt	15
Adjusting Skids	9	Servicing Front Bushings in Castor Forks	16
Adjusting Rollers	10	Servicing Castor Wheels and Bearings	18
Adjusting Deck Pitch	10	Removing Cutter Blades	17
OPERATING INSTRUCTIONS	11	Inspecting and Sharpening Blades	17
Operating Tips	11	Correcting Cutting Unit Mismatch	18
		IDENTIFICATION AND ORDERING	18

Specifications

Type: 84" (213 cm) width of cut, 5 blades, 3-blade center section, and 2 one-blade wings. Toro Recycler technology.

Mowing Rate: Mows up to 4.4 acres/hr at 8.8 kmh.

Trimming Ability: Deck is centered on tractor with 12.7 cm of over hang on each side. Uncut circle is 61 cm on both left and right with no brakes.

Height Of Cut: 2.5–12.7 cm adjustable in 1.7 cm increments. Front adjustment is with snapper pin and grooves in castor shaft. Rear adjustment is with hanger brackets and pin.

Construction: 12-gauge steel, 10.8 cm deep, welded construction and reinforced with 10-gauge steel channels. Bolt-in 12-gauge steel recycling chambers.

Cutter Drive: Isolation mount PTO driven gearbox with 1:1.35 spiral bevel gears. One "BB" section belt on center section. One "B" section belt on each wing. Fixed idler on main deck with spring adjustment. Self-tensioning idler pulleys on each wing.

3.2 cm diameter spindle shafts, turn on two greaseable tapered roller bearings (greaseable from top of deck). A positive splined connection attaches pulleys to spindle shafts for high-torque capacity.

Blades: Five 48-cm long, 6.3-mm thick, heat-treated steel.

Suspension & Castor Wheels: Two front castors, consisting of 25.4 cm pneumatic wheel and tire assembly with sealed ball bearings. Rear of deck is suspended from lift arms with adjustable deck rake. Hydraulic counter balance and lift system designed integral with deck for maximum flotation.

Deck Covers: High-impact plastic covers.

Quick Attach System: Tapered joint with over center adjustable tensioning latch.

Weight: 243 kg.

Specifications and design subject to change without notice.

SAFETY

Training

1. Read the instructions carefully. Be familiar with the controls and the proper use of the equipment.
 2. Never allow children or people unfamiliar with these instructions to use the lawnmower. Local regulations may restrict the age of the operator.
 3. Never mow while people, especially children, or pets are nearby.
 4. Keep in mind that the operator or user is responsible for accidents or hazards occurring to other people or their property.
 5. Do not carry passengers.
 6. All drivers should seek and obtain professional and practical instruction. Such instruction should emphasize:
 - the need for care and concentration when working with rideon machines;
 - control of a ride on machine sliding on a slope will not be regained by the application of the brake. The main reasons for loss of control are:
 - insufficient wheel grip;
 - being driven too fast;
 - inadequate braking;
 - the type of machine is unsuitable for its task;
 - lack of awareness of the effects of ground conditions, especially slopes;
- Refuel outdoors only and do not smoke while refueling.
 - Add fuel before starting the engine. Never remove the cap of the fuel tank or add petrol while the engine is running or when the engine is hot.
 - If petrol is spilled, do not attempt to start the engine but move the machine away from the area of spillage and avoid creating any source of ignition until petrol vapors have dissipated.
 - Replace all fuel tanks and container caps securely.
4. Replace faulty silencers.
 5. Before using, always visually inspect to see that the blades, blade bolts and cutter assembly are not worn or damaged. Replace worn or damaged blades and bolts in sets to preserve balance.
 6. On multi-bladed machines, take care as rotating one blade can cause other blades to rotate.

Preparation

1. While mowing, always wear substantial footwear and long trousers. Do not operate the equipment when barefoot or wearing open sandals.
 2. Thoroughly inspect the area where the equipment is to be used and remove all objects which may be thrown by the machine.
 3. **WARNING—Petrol is highly flammable.**
 - Store fuel in containers specifically designed for this purpose.
1. Do not operate the engine in a confined space where dangerous carbon monoxide fumes can collect.
 2. Mow only in daylight or in good artificial light.
 3. Before attempting to start the engine, disengage all blade attachment clutches and shift into neutral.
 4. Do not use on slopes of more than:
 - Never mow side hills over 5°
 - Never mow uphill over 10°
 - Never mow downhill over 15°
 5. Remember there is no such thing as a “safe” slope. Travel on grass9 slopes requires particular care. To guard against overturning:
 - do not stop or start suddenly when going up or downhill;
 - engage clutch slowly, always keep machine in gear, especially when travelling downhill;
 - machine speeds should be kept low on slopes

- and during tight turns;
 - stay alert for bumps and hollows and other hidden hazards;
 - never mow across the face of the slope, unless the lawnmower is designed for this purpose.
6. Use care when pulling loads or using heavy equipment.
 - Use only approved drawbar hitch points.
 - Limit loads to those you can safely control.
 - Do not turn sharply. Use care when reversing.
 - Use counterweight(s) or wheel weights when suggested in the instruction handbook .
 7. Watch out for traffic when crossing or near roadways.
 8. Stop the blades rotating before crossing surfaces other than grass.
 9. When using any attachments, never direct discharge of material toward bystanders nor allow anyone near the machine while in operation .
 10. Never operate the lawnmower with defective guards, shields or without safety protective devices in place.
 11. Do not change the engine governor settings or over-speed the engine. Operating the engine at excessive speeds may increase the hazard of personal injury.
 12. Before leaving the operator's position:
 - disengage the power take-off and lower the attachments;
 - change into neutral and set the parking brake;
 - stop the engine and remove the key.
 13. Disengage drive to attachments, stop the engine, and disconnect the spark plug wire(s) or remove the ignition key
 - before cleaning blockages or unclogging chute;
 - before checking, cleaning or working on the lawnmower;
 - after striking a foreign object. Inspect the lawnmower for damage and make repairs before restarting and operating the equipment;
 - if the machine starts to vibrate abnormally (check immediately).
 14. Disengage drive to attachments when transporting or not in use.
 15. Stop the engine and disengage drive to attachment
 - before refueling;
 - before removing the grass catcher;
 - before making height adjustment unless adjustment can be made from the operator's position.
 16. Reduce the throttle setting during engine runout and, if the engine is provided with a shutoff valve, turn the fuel off at the conclusion of mowing.

Maintenance and Storage

1. Keep all nuts, bolts and screws tight to be sure the equipment is in safe working condition.
2. Never store the equipment with petrol in the tank inside a building where fumes may reach an open flame or spark.
3. Allow the engine to cool before storing in any enclosure.
4. To reduce the fire hazard, keep the engine, silencer, battery compartment and petrol storage area free of grass, leaves, or excessive grease.
5. Check the grass catcher frequently for wear or deterioration.
6. Replace worn or damaged parts for safety.
7. If the fuel tank has to be drained, this should be done outdoors
8. On multi-bladed machines, take care as rotating one blade can cause other blades to rotate.
9. When machine is to be parked, stored or left unattended, lower the cutting means unless a

Sound & Vibration Levels

Sound Levels

This unit has an equivalent continuous A-weighted sound pressure at the operator ear of: 88 dB(A), based on measurements of identical machines per 84/538/EEC.

This unit has a sound power level of 104 dB(A)/1pW, based on measurements of identical machines per procedures outlined in Directive 79/113/EEC and amendments.


Vibration Levels

This unit has a vibration level of 2.5 m/s² at the posterior, based on measurements of identical machines per ISO 2631 procedures.


This unit does not exceed a vibration level of 0.5 m/s² at the posterior based on measurements of identical machines per ISO 2631 procedures.

PROTOTYPE


Symbol Glossary




Caustic liquids, chemical burns to fingers or hand
 Poisonous fumes or toxic gases, asphyxiation
 Electrical shock, electrocution
 High pressure fluid, injection into body
 High pressure spray, erosion of flesh
 High pressure spray, erosion of flesh
 Crushing of fingers or hand, force applied from above
 Crushing of toes or foot, force applied from above



Crushing of whole body, applied from above
 Crushing of torso, force applied from side
 Crushing of fingers or hand, force applied from side
 Crushing of leg, force applied from side
 Crushing of whole body
 Crushing of head, torso and arms
 Cutting of fingers or hand
 Cutting of foot



Severing of fingers or hand, mower blade
 Severing of toes or foot, mower blade
 Severing of toes or fingers, rotary mower blade
 Cutting or entanglement of foot, rotating auger
 Severing of foot, rotating knives
 Severing of fingers or hand, impeller blade
 Dismemberment, front engine mower in forward motion
 Dismemberment, front engine mower in rearward motion











Severing of fingers or hand, engine fan
 Whole body entanglement, implement input drive line
 Fingers or hand entanglement, chain drive
 Hand & arm entanglement, belt drive
 Thrown or flying objects, whole body exposure
 Thrown or flying objects, face exposure
 Thrown or flying objects, rotary mower




Runover/backover, vehicle
 Machine tipping, riding mower
 Machine rollover, ROPS (rear engine mower)
 Stored energy hazard, kickback or upward motion
 Hot surfaces, burns to fingers or hands
 Explosion
 Fire or open flame
 Secure lifting cylinder with locking device before getting in hazardous area




Stay a safe distance from the machine
 Stay clear of articulation area while engine is running
 Do not open or remove safety shields while engine is running
 Do not step on loading platform if PTO is connected to tractor & engine is running
 Do not step
 Wait until all machine components have completely stopped before touching them
 Shut off engine & remove key before performing maintenance or repair work
 Riding on this machine is allowed only on a passenger seat & only if the driver's view is not hindered






Engine start Engine stop Engine failure/malfunction Engine rotational speed/frequency Choke Primer (start aid) Electrical preheat (low temperature oil start aid) Transmission




Transmission oil pressure Transmission oil temperature Transmission failure/malfunction Clutch Neutral High Low Forward




Reverse Park First gear Second gear Third gear (other #'s may be used until the maximum # of forward gears is reached.) Hydraulic oil Hydraulic oil pressure Hydraulic oil level




Hydraulic oil filter Hydraulic oil temperature Hydraulic oil failure/malfunction Parking brake Fuel Fuel level Fuel filter Fuel system failure/malfunction




Diesel fuel Unleaded fuel Headlights Lock Unlock Differential lock 4-Wheel drive Power Take-Off



Power Take-Off, rotational speed Blade cutting element Blade cutting element, height adjustment Cutting unit Cutting unit, raise Cutting unit, lower Cutting unit, hold Cutting unit, float



Cutting unit, transport position Cutting unit, raise to transport position Cutting unit, lower to transport position Attachment lower Attachment raise Spacing distance Snow thrower, collector auger Traction



Above working temperature range Drilling Manual metal arc welding Manual Water pump Keep dry Weight Do not dispose in the garbage CE logo

Before Operating

CHECK LUBRICANT IN GEAR BOX

(Fig. 1)

The gear box is designed to operate with SAE 80-90 wt. gear lube. Although the gear box is shipped with lubricant from the factory, check the level before operating the cutting unit.

1. Position the machine and cutting unit on a level surface.
2. Remove the check plug from the side of the gear box and make sure the lubricant is up to the bottom of the hole. If the lubricant level is low, remove the fill plug on top of the gear case and add enough lubricant to bring it up to the bottom of the hole in the side.




Figure 1

1. Filler Plug
2. Check Plug

ADJUSTING HEIGHT OF CUT (Fig. 2-5)

The height of cut is adjustable from 2.5 to 12.7 cm in 2.5 cm increments.

- 1 Start the engine and raise the cutting unit. Stop the engine after the cutting unit is raised.
2. Remove front snapper pins from castor arms and slide castor wheel assembly up or down.
3. Insert the snapper pin into the castor arm and through the groove in the castor shaft to get the desired height of cut
4. Remove hair pin cotter and clevis pin securing height-of-cut straps to rear of deck.
5. Mount the height-of-cut straps to desired height-of-cut hole with the clevis pin and hair pin cotter.
6. When using 2.5 cm height of cut, move skids, rollers, and wing wheels to the highest holes.




Figure 2

1. Snapper Pin




Figure 3

ADJUSTING SKIDS (Fig. 4)

Skids should be located in upper holes for 2.5 and 3.8 cm heights of cut and lower holes for 5 to 12.7 cm heights of cut.

1. Adjust skids by removing flange nuts, positioning as desired and installing the flange nuts.




Figure 4

1. Height-of-cut chain

ADJUSTING ROLLERS (Fig. 6)

Rollers should be located in the upper holes for 2.5 and 3.8 cm heights of cut and lower holes for 5 to 12.7 cm heights of cut. Five rollers are located on the deck, three under the main deck and one on each wing.

1. Adjust the rollers by removing the lock nut and bolt, positioning as desired and then installing the lock nut and bolt.




Figure 5

ADJUSTING DECK PITCH (Fig. 7)

Deck pitch is the difference in height of cut from the front of the blade plane to the back of the blade plane. TORO recommends a blade pitch of 6.4 mm ,i.e., the back of the blade plane is .6.4 mm higher than the front.

1. Position the machine on a level surface on the shop floor.
2. Set the deck to the desired height of cut.
3. Rotate (1) blade so it points straight forward.
4. Using a short ruler, measure from the floor to the front tip of the blade and remember this dimension. Then, measure from the floor to the rear tip of the blade.
5. Subtract the front dimension from rear dimension to calculate the pitch.
6. To adjust pitch, start the tractor and raise the deck to the highest possible position and turn off the engine.
7. Loosen the jam nuts on the top or bottom of the height-of-cut chain U bolt.
8. Adjust the other set of nuts to raise or lower the rear of the No. 3 chamber and attain the correct deck pitch.
9. Tighten the jam nut.
10. Lower the deck.



Figure 6

1. Skid
2. Roller




Figure 7

1. Height-of-cut chain
2. U bolt

PROTOTYPE

Operating Instructions

OPERATING TIPS

1. **Mow When Grass Is Dry**—Mow either in the late morning to avoid the dew, which causes grass clumping or in late afternoon to avoid the damage that can be caused by direct sunlight on the sensitive, freshly mowed grass.
2. **Select The Proper Height-of-Cut Setting To Suit Conditions**— Remove one inch or no more than 1/3 of the grass blade when cutting. In exceptionally lush and dense grass you may have to raise your height of cut to the next setting.
3. **Mow At Proper Intervals**—Under most normal conditions you'll need to mow every 4–5 days. But remember, grass grows at different rates at different times. This means that to maintain the same height of cut, which is a good practice, you'll need to cut more frequently in early spring; as the grass growth rate slows in mid summer, cut only every 8–10 days. If you are unable to mow for an extended period due to weather conditions or other reasons, mow first with the height of cut at a high level; then mow again 2–3 days later with a lower height setting.
4. **Always Mow With Sharp Blades**—A sharp blade cuts cleanly and without tearing or shredding the grass blades like a dull blade. Tearing and shredding causes the grass to turn brown at the edges which impairs growth and increases susceptibility to diseases.

CAUTION: This product may exceed noise levels of 85 dB(A) at the operator position. Ear protectors are recommended for prolonged exposure to reduce the potential of permanent hearing damage.

5. **Transporting**—Use the transporting latch when transporting over long distances or in rough terrain.
6. **Trailer**—When loading or unloading the machine from a trailer, disconnect the rear height-of-cut chains to allow maximum deck rotation.
7. **After Operating**—To assure optimum performance, clean the underside of the mower housing after each use. If residue is allowed to build up in the mower housing and on inserts, cutting performance will decrease.

8. **Deck Pitch**—Toro recommends a blade pitch of 6.4 mm. A pitch larger than 6.4 mm will result in less power required, larger clippings and a poorer quality

of cut. A pitch less than 6.4 mm will result in more power required, smaller clippings and a better quality of cut.

Maintenance

LUBRICATION

GREASE BEARINGS, BUSHINGS AND GEAR BOX (Fig. 8)

The cutting unit must be lubricated regularly. If the machine is operated under normal conditions, lubricate the castor bearings and bushings with No. 2 general purpose lithium base grease or molybdenum base grease, after every 8 hours of operation or daily, whichever comes first. Lubricate fittings immediately after every washing, regardless of the interval listed.

1. The cutting unit has bearings and bushings that must be lubricated, and these lubrication points are: gage wheels (2) (Fig.), front castor shaft bushings (2), blade spindle bearings (5), idler arm pivots (2), drive shaft (3), Wing deck pivots (2) and right and left push arm ball joints (Fig. 8).
2. Position the machine and cutting unit on a level surface and lower the cutting unit. Remove the check plug from the side of gear box and make sure lubricant is up to the bottom of the hole. If the level of lubricant is low, remove the fill plug on top of the gear case and add SAE 80-90 wt. gear lube until the level is up to the bottom of hole in side.



Fig. 8




Figure 9

1. Filler plug
2. Check/Drain plug



CAUTION

To prevent accidental starting of the engine while performing maintenance, shut of the engine and remove the key from the ignition switch.

DISCONNECTING THE CUTTING UNIT FROM THE TRACTION UNIT

(Fig. 10–12)

Note: Implements are heavy and may require two people to handle.

1. Start the tractor and raise the deck to the highest possible position and turn off the engine.
2. Remove the hair pin cotter and clevis pin securing the height-of-cut straps to the rear height-of-cut brackets.
3. Turn the ignition key to the run position and move the lift lever forward to lower the cutting unit.
4. Raise the seat and open the needle valve. This allows the lift arms to float freely.
5. Remove the hair pin cotter and clevis pin securing the latch cover to the lift arm .
6. Loosen the release lever by rotating it counterclockwise.
7. Pivot the release lever upward and remove the shaft latch from the slot in the traction unit lift arm.
8. Pull rearward on the lock collar to release the drive shaft coupler from the tractor.
9. Stay clear of lift arms and move the deck away from the tractor, allowing the lift arms to fall.
10. Secure the hair pin cotter and clevis pin to height-of-cut straps for storage.
11. Close the needle valve




Figure 10

1. Height-of-cut chain




Figure 11

1. Needle Valve




Figure 11

- | | |
|------------------|---------------------------|
| 1. Latch Cover | 4. Traction Unit lift Arm |
| 2. Release Lever | 5. Machined Surface |
| 3. Shaft latch | |

CONNECTING THE CUTTING UNIT TO THE TRACTION UNIT (Fig. 9–11)

1. Center the traction unit in front of the cutting unit on any flat hard surface.

2. Raise the seat and open the needle valve. This allows the lift arms to float freely.
3. Adjust the lift arms heights, making sure that the machined surface on top of each traction unit lift arm is parallel to the ground (Fig. 11). (Raise or lower the lift arm casting by pushing up or down from behind the front tires or by using a wrench in front of the tractor)
4. Check for dirt and debris on mating parts and clean as required.
5. Turn the castor wheels so they point straight forward and the deck moves easily toward the tractor.
6. Secure the first lift arm assembly to the traction unit as follows:

- A. Remove the hair pin cotter and clevis pin securing the latch cover to the lift arm.
- B. Pivot the release lever upward.
- C. Slide the cutting unit lift arm onto the traction unit lift arm, inserting the shaft latch into the slot in the traction unit lift arm.

Note: If the latch does not fall into the slot in the traction unit lift arm, raise or lower the lift arm casting by pushing up or down from behind the front tires.

- D. Pivot the release lever downward and tighten securely by rotating clockwise.
7. Install the other lift arm on the tractor by rotating the deck toward tractor, aligning the lift arm to tractor arm and repeating step 5. If the latch does not fall into the slot in the traction unit lift arm, the arms are not lined up.
 - A. If the lift arms on the traction unit are not at the correct height for deck arms to slide on, push up or down on the lift arm castings from behind the front tires until deck arms line up and slide on.
 - B. If lift arms on deck do not line up side to side, rotate the castor wheels side ways so the deck moves easier from side to side. Move the deck side to side until the lift arms line up and slide on.
 8. Move the deck from side to side to check for tightness and re-tighten the latches, if required.
 9. Install the latch covers to the lift arms and secure them with clevis pins and hair pin cotters.
 10. Connect the drive shaft to the traction unit.
 11. Close the needle valve and lower the seat.
 12. Start the tractor and raise the deck to the highest possible position. Then turn off the engine.
 13. Align the height-of-cut straps with the hole for desired height of cut, install the clevis pin and secure it with a hair pin cotter.

CHANGING GEAR BOX LUBRICANT (Fig. 13)

The gear box lubricant must be changed initially after the first 400 hours of operation, and subsequently after every 1600 hours of operation.

1. Position the machine and cutting unit on a level surface.
2. Loosen the fixed idler pulley locking nut.
3. Loosen the spring tensioning nut and remove the belt.
4. Remove the four (4) locknuts securing the gearbox mount to the deck.
5. Remove the belt from the pulley.
6. Remove the check plug from the side of the gear box and tip the gear box assembly, allowing lubricant to drain from the gear box.
7. Install the belt to the pulley.
8. Install the gear box assembly to the deck.
9. Remove the fill plug on top of the gear case and add SAE 80–90 weight gear lube until the level is up to the bottom of the hole in the side.
10. Install the check plug to the side of the gear box and the fill pug to the top of the gear case.
11. Re-tension the belt.

REPLACING DRIVE BELTS (Fig. 14–15)

The blade drive consists of three belts—one main drive belt and two wing belts. The main drive belt is tensioned by a fixed idler with a spring adjustment. The wing belts have spring-loaded idlers. All belts are very durable but after many hours of use, the belt will show signs of wear. Signs of a worn belt are: squealing when belt is rotating, blades slipping when cutting grass, frayed edges, burn marks and cracks. Replace any belt if any of these conditions are evident. Adjust belt tension on main belt after 10 hours of operation to assure maximum durability.

1. Lower the cutting unit to the shop floor. Remove the belt covers from the top of the cutting unit and set the covers aside.
2. Pull on the spring loaded idlers and remove the wing belts.
3. Loosen the fixed idler pulley locking nut.
4. Loosen the spring tensioning nut as required and remove the belt.
5. Route new belts around the spindle pulleys and through the idler pulley assemblies as shown in figure 15.
6. Tighten the spring tensioning nut until the spring length is 9.9 cm inside the spring loops (Fig. 14).
7. Tighten the idler pulley locking nut.
8. Pull on the spring loaded idlers and install wing belts.
9. Install belt covers to top of the cutting unit.

SERVICING THE FRONT BUSHINGS IN THE CASTOR FORKS (Fig. 16)

The castor forks have bushings pressed into the top and bottom of the casting and after many hours of operation, the bushings will wear. To check the bushings, move the castor fork back and forth and from side to side. If the castor spindle is loose around the bushings, the bushings are worn and must be replaced.

1. Start the tractor and raise the deck to the highest possible position and turn off the engine.
2. Remove the front snapper pins from the castor arms and slide the castor wheel assembly out of the castor arm




Figure 13

1. Gear box mount
2. Filler plug
3. Check plug




Figure 14

1. Idler pulley
2. Spring tensioning nut
3. Idler pulley locking nut




Figure 15

tube.

3. Remove the locknut from the capscrew holding the castor wheel assembly between the castor fork. Grasp the castor wheel and slide the capscrew out of the fork.
4. Remove the retaining ring, washer and wavy washer securing the castor shaft to the castor fork. Remove the shaft from the fork.
5. Insert a pin punch into the top or bottom of the castor fork and drive the bushing out of the fork. Repeat for the other bushing. Clean inside of the forks to remove dirt.
6. Apply grease to the inside and outside of the new bushings. Using a hammer and flat plate, drive the bushings into the fork.
7. Inspect the castor shaft and fork for wear and replace if damaged.
8. Push the castor shaft through bushings and fork and secure with wavy washer, washer and retaining ring.
9. Insert snapper pin into the castor arm and through the groove in the castor shaft at the desired height of cut.




Figure 16

1. Front castor fork
2. Retaining ring
3. Washer
4. Wavy washer
5. Castor shaft
6. Bushings

SERVICING CASTOR WHEELS AND BEARINGS (Fig. 17)

The castor wheel rotates on a high-quality roller bearing. Even after many hours of use, provided that the bearing was kept well-lubricated, bearing wear will be minimal. However, failure to keep the bearing lubricated will cause rapid wear. A wobbly castor wheel usually indicates a worn bearing.

1. Remove the locknut from the capscrew holding the castor wheel assembly between the castor fork. Grasp the castor wheel and slide the capscrew out of the fork.
2. Remove the bearing from the wheel hub and allow the spacer to fall out. Remove the bearing from the opposite side of the wheel hub.
3. Check the bearings, spacer and inside of the wheel hub for wear. Replace defective parts as required.
4. To assemble the castor wheel, push the bearing into the wheel hub. Slide the spacer into the wheel hub. Push the other bearing into open end of the wheel hub to captivate the spacer inside the wheel hub.




Figure 17

1. Bearing
2. Spacer

5. Install the castor wheel assembly between the castor forks and secure in place with capscrew and locknut.

REMOVING CUTTER BLADE (Fig. 18)

The blade must be replaced if a solid object is hit, the blade is out of balance or if the blade is bent. Always use genuine TORO replacement blades to be sure of safety and optimum performance. Never use replacement blades made by other manufacturers because they could be dangerous.


WARNING

Do not try to straighten a blade that is bent, and never weld a broken or cracked blade. Always use a new blade to assure continued safety certification of the product.

1. Raise the cutting unit to the highest position, shut the engine off and engage the parking brake.
2. Remove the hair pin cotters and clevis pins securing the height-of-cut straps to the rear of the deck.
3. Rotate the front of the deck upward and insert the latch rod into the front hole (service position) in the latch plate.
4. Grasp the end of the blade using a rag or thickly padded glove. Remove the blade bolt, cup and blade from the spindle shaft.
5. Install blade sail facing (up) toward the cutting unit with the cup and blade bolt. Tighten the blade bolt to 115–145 Nm.




Figure 18

1. Blade bolt
2. Cup




Figure 19

1. Sail
2. Wear
3. Slot formed

INSPECTING AND SHARPENING THE BLADE (Fig. 19–20)

1. Raise the cutting unit to the highest position, shut the engine off and engage the parking brake.
2. Remove the hair pin cotters and clevis pins securing the height of-cut straps to the rear of the deck.
3. Rotate the front of the deck upward and insert the latch rod into the front hole (service position) in the latch plate.
4. Examine the cutting ends of the blade carefully, especially where the flat and curved parts of the blade meet (Fig. 19-A). Since sand and abrasive material can wear




Figure 20

1. Sharpen at this angle only
2. End view

away the metal that connects the flat and curved parts of the blade, check the blade before using the machine. If wear is noticed (Fig. 19-B), replace the blade: refer to *Removing The Cutter Blade*.



DANGER

If the blade is allowed to wear, a slot will form between the sail and flat part of the blade (Fig. 17-C). Eventually a piece of the blade may break off and be thrown from under the housing, possibly resulting in serious injury to yourself or a bystander.

5. Inspect the cutting edges of all blades. Sharpen the cutting edges if they are dull or nicked. Sharpen only the top of the cutting edge and maintain the original cutting angle for best performance (Fig. 20). The blade will remain balanced if the same amount of metal is removed from both cutting edges.
6. To check the blade for being straight and parallel, lay the blade on a level surface and check its ends. Ends of the blade must be slightly lower than the center, and the cutting edge must be lower than the heel of the blade. This blade will produce good quality of cut and require minimal power from the engine. By contrast, a blade that is higher at the ends than the center, or that has a cutting edge higher than the heel, is bent or warped and must be replaced.
7. Install the blade sail facing (up) toward the cutting unit with cup and blade bolt. Tighten blade bolt to 115–149Nm.
4. Position the tip of the outer blade and adjacent blade tip as close together as possible at the intersection of the two cutting chambers. Note the height of the outer blade tip with respect to the height of the adjacent blade tip.
5. Rotate the outer blade 180° and note the height of the outer blade tip with respect to the height of the adjacent blade tip. If the relative height changed by more than 3 mm after rotating the blade, then the outer blade is bent and should be replaced..
6. Repeat steps 4 and 5 until all pairs of adjacent blades have been checked at both blade tips. Note the relative difference in blade height at each blade intersection after replacing any bent blades. This height difference should be less than 3 mm for all adjacent blades.
7. 'Raise the height-of-cut to the highest position and lower the deck to the floor.
8. Rotate an outer blade until the tip is positioned nearest to the skid on the side of the deck housing. Measure the distance from the bottom of the blade to the floor. Repeat the measurement on the opposite side of the deck. If the two measurements differ by more than 6 mm, go to step 9 and add shims as instructed.
9. Remove the capscrews, flatwashers, lockwashers and nuts from the outer spindle in the area where shims must be added. To raise or lower the blade, add a shim, Part No. 3256-24, between the spindle housing and the bottom of the cutting unit. Continue to check the alignment of the blades and add shims until the tips of the blades are within the required dimension.

CORRECTING CUTTING UNIT MISMATCH

If there is mismatch between the blades, the grass will appear streaked when it is cut. This problem can be corrected by making sure the blades are straight and all blades are cutting on the same plane.

1. Position the machine on a level surface on the shop floor.
2. Release the belt tension on the belts.
3. Raise the deck to the transport position and lock the transport latch.

IMPORTANT: Do not use more than three shims at any individual hole location. Use decreasing numbers of shims in adjacent holes if more than one shim is added to a hole location.

10. Re-tension the belts. Reinstall the belt covers.

IDENTIFICATION AND ORDERING

MODEL AND SERIAL NUMBERS

The cutting deck has two identification numbers: a model number and a serial number. The two numbers

are stamped into a plate on the front channel of the mower deck, under cover. In any correspondence concerning the mower, supply the model and serial numbers to assure that correct information and replacement parts are obtained.

To order replacement parts from an authorized TORO Distributor, supply the following information:

1. Model and serial numbers of the machine.
2. Part number, description and quantity of parts desired.

Note: Do not order by reference number if a parts catalog is being used; use the part number.

PROTOTYPE



PROTOTYPE