



Tow Behind Trailer

Trans Pro 100

Model No. 04240—220000001 and Up

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form **a:b**. The **a** represents the reference number of the entire service assembly and the **b** represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number **6**, the tire by **6:1**, the valve by **6:2**, and the wheel by **6:3**. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually.

Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form **nX y**. The **n** represents the quantity of the part, the **X** is the multiplication symbol, and the **y** represents the reference number.

For example, in an illustration, the reference number **2X 37** means that two of the parts identified by reference number 37 are indicated.

Contents

Description	Page	Description	Page
Trailer Bed Assembly	3	Ramp Assembly	5
Tongue Assembly	4	Hub and Wheel Assembly	6


Accessories

Description	Model / Part No.	Description	Model / Part No.
High Ramp Conversion Kit	04241	18" Conversion Kit	04242

Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.


Abbreviation	Meaning	Abbreviation	Meaning
AR	as required	HYD	hydraulic
ASM	assembly	INC	incorporated
CARR	carriage	LH	left hand
DEG	degrees	NI	nylon insert
FH	flat head	PPH	Phillips pan head
GA	gauge	PTH	Phillips truss head
HF	hex flange	PTO	power take off
HH	hex head	RH	right hand
HHF	hex head flange	SFH	slotted fillister head
HLH	hex lag head	SHH	slotted hex head
HJ	hex jam	SQH	square head
HOC	height-of-cut	SHWH	slotted hex washer head
HS	hex socket	SPH	slotted pan head
HSBH	hex socket button head	SRH	slotted round head
HSFH	hex socket flat head	STD	standard
HSH	hex socket head	TAP	self tapping
HWH	hex washer head	TTH	Torx truss head
HWHTF	hex washer head thread forming	WH	wing head



Sheet No.:2

Trailer Bed Assembly

Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
1	104-0545	1	Bed ASM				
1:1	98-8688	1	Decal-Caution				
1:2	98-8687	1	Decal-Pressure, Air				
2	32128-36	22	Nut-HF				
3	98-8761-01	2	Guide-Wheel				
4	3231-21	20	Screw-CARR				
6	105-5395	4	Bracket-Rod				
7	98-8697	4	Spring-Latch				
9	105-5394	4	Rod-Wheel, Large				
10	98-8756	2	Spacer-Stop				
11	323-38	2	Screw-HH				
12	98-8677-01	2	Insert-Standard				
13	105-5392	12	Rivet-Drive				
14	98-8776	1	Mat-Bed				
15	98-8777	2	Spacer				
16	98-8694	2	Decal-Trans Pro 100				




Sheet No.:3

Tongue Assembly

Ref. No.	Part No.	Qty.	Description
1	323-13	4	Screw-HH
2	98-8779-01	2	Hitch-Trailer
4	32128-36	4	Nut-HF
5	99-4543-01	1	Tongue-Trailer
6	98-8780	4	Spacer-Hitch


Ref. No.	Part No.	Qty.	Description



Sheet No.:4

Ramp Assembly

Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
1	104-0546	1	Ramp ASM				
1:1	98-8676	1	Decal-Caution				
2	98-8775	1	Mat-Ramp				
3	105-5392	8	Rivet-Drive				
4	3256-26	1	Washer-Flat				
5	3272-7	3	Pin-Cotter				
6	98-8754	1	Latch-Ramp				
7	98-8759	1	Hinge-Rod				
8	66-1210	1	Decal-Toro				



Sheet No.:5

Hub and Wheel Assembly

Ref. No.	Part No.	Qty.	Description
1	98-8690	2	Hub ASM
1:1	242-50	4	Nut-Lug
1:2	99-4501	2	Cone-Bearing
1:4	99-4500	1	Seal-Grease
1:5	99-4502	1	Hub
1:5:1	99-4512	4	Stud-In, Screw
1:5:2	99-4511	2	Race-Bearing
1:6	99-4503	1	Cap-Grease
1:7	99-4504	1	Plug-Cap, Grease
2	98-8691	2	Wheel ASM
3	98-8766-01	2	Axle
3:1	99-4505	1	Washer
3:2	99-4508	1	Nut-Castle
3:3	99-4509	1	Washer-Tang
3:4	302-58	1	Fitting-Grease
4	3231-22	8	Screw-CARR
6	32128-36	8	Nut-HF
99	232-47	2	Tube

Ref. No.	Part No.	Qty.	Description

Maintenance Record

