



Count on it.

Parts Catalog

Workman® UTX 4 Passenger Utility Vehicle

Model No. 08101—Serial No. 400000000 and Up



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.


Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Frame and ROPS Assembly	4
Front Suspension Assembly	6
Front Control Arm Assembly No. 145-7771	7
Rear Suspension and Subframe Assembly	8
Pedals and Controls Assembly	10
Steering Assembly	11
Brake Assembly	12
Master Cylinder Assembly No. 104-6782	13
Brake Caliper Assembly No. 127-7424	14
Hood and Front Fender Assembly	15
Dash Assembly	16
Seat Base Assembly	17
Cargo Bed Assembly	18
Cargo Bed Kit Assembly	19
Electrical Assembly	20
Battery Assembly	22
Engine Drivetrain and Exhaust Assembly	23
Engine, Transaxle and Clutch Assembly	24
Transaxle Assembly No. 140-2611	25
Secondary Clutch Assembly No. 139-4591	26
Primary Clutch Assembly No. 139-4590	27
Front Differential and Driveshaft Assembly	28
Front Differential Assembly No. 140-4752	29
Intermediate Driveshaft Assembly No. 140-4771	30
Driveshaft Assembly No. 140-4763	31
Cooling System Assembly	32
Radiator Assembly No. 140-2641	33
Fuel System Assembly	34
Air Cleaner Assembly	35
Air Cleaner Assembly No. 106-5277	36
Hose Intake Assembly No. 145-2118	37
Cylinder Block Assembly	38
Crankshaft and Piston Assembly	39
Camshaft and Rocker Arm Assembly	40
Cylinder Head Assembly	41
Timing Cover Assembly	42
Intake Manifold Assembly	43
Exhaust Manifold Assembly	44
Oil Pan Assembly	45
Oil Pump Assembly	46
Water Pump Assembly	47
Starter Assembly	48
Alternator Assembly	49
Rear Plate Assembly	50
Ignition Assembly	51
Throttle Body Assembly	52
Coolant Plug Assembly	53
Coolant Inlet Assembly	54
Electrical Assembly	55
Attachments and Accessories	56




Frame and ROPS Assembly

Ref.	Part Number	Qty.	Description
1	137-6850-03	1	Crew Front Frame ASM [black]
2	137-2800-03	1	Rear Frame ASM [black]
3		1	Standard ROPS Kit ●
3:1	137-2737-05	1	Front ROPS ASM-LH
3:2	137-2738-05	1	Front ROPS ASM-RH
3:3	140-2583	1	ROPS Front Crosslink ASM
3:3:2	144-1143	1	Decal-Utx, Safety
3:4	138-9438-05	1	Panel-Back, Seat
3:5	140-2597	1	LH ROPS Rear Tube ASM
3:5:2	145-2215	1	Decal-ROPS Safety, Utx
3:5:3	144-2267	1	Decal-Compliance, ROPS
3:6	137-2726-05	1	ROPS Rear Tube ASM-RH
3:7	138-5787-05	2	Tube-Restraint, Shoulder
3:8	137-6892-05	1	Crosslink-Rear, ROPS
4		1	Mid ROPS Kit (Crew) ●
4:1	137-2845-05	1	ROPS Middle Tube ASM-LH [blk-Tx

Ref.	Part Number	Qty.	Description
4:2	137-2846-05	1	ROPS Middle Tube ASM-RH [blk-Tx
4:3	137-2848-05	2	ROPS Connector Tube ASM [blk-Tx
4:4	138-5787-05	2	Tube-Restraint, Shoulder
4:5	137-2835-05	1	ROPS Support Tube ASM [blk-Txt]
4:6	137-2916-05	1	Rear Seat Handle ASM [blk-Txt]
4:7	138-9438-05	1	Panel-Back, Seat
5	145-7960-03	1	Panel-Underseat
6	116-4701	4	Screw-HHF
7	104-8301	6	Nut-HF, NI
8		1	Crew ROPS Hardware Kit ●
8:1	144-2258	20	Screw-HH
8:2	144-2265	16	Bolt-CARR
8:3	32144-70	8	Screw-HWHTF
8:4	49-2040	24	Screw-HWHTF

● Not serviced separately




Frame and ROPS Assembly (continued)

Ref.	Part Number	Qty.	Description
8:5	32144-86	2	Screw-HWHTF
8:6	126-7439	4	Screw-Torx
8:7	144-2409	2	Screw-HHF
8:8	3234-42	4	Screw-HHF
8:9	104-8300	20	Nut-HF, NI
8:10	104-8301	26	Nut-HF, NI
8:11	3296-73	2	Nut-Lock, NI
8:12	144-2269	4	Nut-HF, NI
8:13	107069	4	Clip
9	139-3432	1	Support-Skirt, LH Side
10	139-3433	1	Support-Skirt, RH Side
11	138-9409	2	Skirt-Side
12	32144-4	3	Screw-HWH
13	125-9622	16	Rivet-Blind
14	138-5775	6	Screw-Delta Point
15	32144-70	20	Screw-HWHTF

Ref.	Part Number	Qty.	Description
16	139-3436	4	Grommet
17	240-12	1	Grommet-Rubber
18	139-4433-03	2	Rail-Frame
19	3234-6	7	Screw-HHF
20	3290-378	6	Tie-Cable
21	140-4775	2	Pin-Latch
22	3231-37	2	Screw-CARR
23	144-2225-0P	1	Brace-Cross
24	144-2245	1	Cover-Access
25	117-1092	4	Screw-PTH
26	3256-67	6	Washer
29	145-7990	1	Foam-Barrier, Heat
30	110-5090	1	Grommet
31	145-7998	1	Foam-Barrier, Heat
32	145-2225	1	Decal-Fuse, Utx
33	144-2259	1	Decal-Service, Gas


● Not serviced separately



Front Suspension Assembly


Ref.	Part Number	Qty.	Description
1	147-2706	2	Strut ASM
2	138-9319	1	Knuckle ASM-Front, LH
2:2	133-7272	1	Bearing-Ball
2:3	144-2207	1	Ring-Retaining
3	138-9320	1	Knuckle ASM-Front, RH
3:2	133-7272	1	Bearing-Ball
3:3	144-2207	1	Ring-Retaining
4	145-7771	2	Control Arm ASM-Front
5	137-6754	2	Hub ASM
5:2	137-6760	4	Stud-Wheel
7	242-50	8	Nut-Lug

Ref.	Part Number	Qty.	Description
8	325-39	2	Screw-HH
9	136-9419	2	Tire/Wheel ASM
9:1	136-9418	1	Wheel-12X7-12
9:2	232-27	1	Stem-Valve
9:3	137-2689	1	Tire
11	137-6766	2	Bracket-Hose, Brake
12	3234-46	4	Screw-HHF
13	99-5107	6	Nut-Lock
14	115-2398	2	Bolt-HH
15	3296-48	2	Nut-Hex
16	112-2844	6	Nut-HF



Front Control Arm Assembly No. 145-7771


<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	145-7762	1	Control Arm-Front
2	115-2165	1	Ball Joint
2:1	302-5	1	Fitting-Grease
3	32151-104	1	Ring-Retaining, External
4	87-2420	1	Seal-Joint, Ball
5	145-7757	1	Spacer
6	145-7756	2	Bushing-Ball
8	302-60	1	Fitting-Grease



Rear Suspension and Subframe Assembly

Ref.	Part Number	Qty.	Description
1	139-4592-03	1	Engine Cradle ASM
2	145-7775	1	Control Arm ASM-Rear, LH Upper
2:1	145-7765	1	Control Arm-Rear Uprr, LH
2:2	137-2659	1	Bushing-Tension
2:3	145-7770	1	Spacer
2:4	145-7756	2	Bushing-Ball
2:5	302-5	1	Fitting-Grease
3	145-7772	2	Control Arm ASM-Rear
3:1	145-7763	1	Control Arm-Rear, Lower
3:2	145-7757	1	Spacer
3:3	145-7756	2	Bushing-Ball
3:4	302-5	1	Fitting-Grease
4	145-7773	2	Knuckle ASM-Rear
4:1	145-7764	1	Knuckle-Rear
4:2	133-7272	1	Bearing-Ball
4:3	144-2207	1	Ring-Retaining
4:4	145-7770	2	Spacer
4:5	145-7756	4	Bushing-Ball
4:6	302-60	2	Fitting-Grease
5	145-7758	2	Shock/Spring ASM


Ref.	Part Number	Qty.	Description
6	145-7774	1	Control Arm ASM-Rear, RH Upper
6:1	145-7766	1	Control Arm-Rear Uprr, RH
6:2	137-2659	1	Bushing-Tension
6:3	145-7770	1	Spacer
6:4	145-7756	2	Bushing-Ball
6:5	302-5	1	Fitting-Grease
7	137-6754	2	Hub ASM
7:2	137-6760	4	Stud-Wheel
10	3234-27	2	Screw-HHF
11	325-22	6	Screw-HH
12	325-39	2	Screw-HH
13	99-5107	12	Nut-Lock
15	242-50	8	Nut-Lug
16	136-9420	2	Tire/Wheel ASM
16:1	136-9418	1	Wheel-12X7-12
16:2	232-27	1	Stem-Valve
16:3	137-2690	1	Tire
17	3234-46	2	Screw-HHF
18	114-8419	2	Screw-HHF
19	104-8301	8	Nut-HF, NI



Rear Suspension and Subframe Assembly (continued)

Ref.	Part Number	Qty.	Description
20	3234-39	8	Screw-HHF
21	140-2608	2	Cv Axle ASM
22	115-2164	2	Nut-Spindle


Ref.	Part Number	Qty.	Description
23	119-1156	2	O-Ring
24	145-2205	1	Decal-Load, Towing



Pedals and Controls Assembly

Ref.	Part Number	Qty.	Description
1	138-5761-03	1	Brake Pedal ASM
2	138-5763-03	1	Brake Pedal ASM
3	32144-70	2	Screw-HWHTF
4	256-116	2	Bushing-Flange
5	136-9306	1	Pivot Shaft ASM
6	49-2040	1	Screw-HWHTF
7	144-2740	1	Pedal ASM-Accelerator
8	140-4572	1	Pedal Pad-Throttle
9	120-4654	3	Screw-HHF
10	104-7201	3	Nut-HF, NI
11	145-2108	1	Shifter ASM


Ref.	Part Number	Qty.	Description
12	139-4655	1	Knob-Shifter
13	256-156	2	Bushing-Flange
14	92-1057	1	Bolt-Shoulder
15	104-8301	1	Nut-HF, NI
16	7-3900	1	Pad-Brake
17	140-4652	1	Cable-Shift (Crew)
18	110-2554	1	Rod End-Spherical
19	147-2705	1	Rod End-Spherical
20	3296-3	1	Nut-Lock
21	32180-030	2	Clip-Tie



Steering Assembly

Ref.	Part Number	Qty.	Description
1	138-9322	1	Steering Rack ASM
1:21	140-4823	1	Kit-Tie Rod ASM, Utx
1:22	140-4592	1	Kit-Rod End ASM
1:22:2	3272-42	1	Pin-Cotter
1:22:3	140-2493	1	Nut-Hex, Slotted
2	32144-49	4	Screw-HWHTF
3	138-3347	1	Steering Shaft ASM
4	3274-18	3	Screw-HSH
5	138-3348	1	Motor-Power Steering
6	33104-016	3	Screw-HHF
7	138-3344	1	Upper Steering Shaft ASM
8	139-4439	1	Tilt Steering Column ASM


Ref.	Part Number	Qty.	Description
8:2	133-0594	2	Bushing-Flange
9	115-1958	2	Bolt-Shoulder
10	110-3318	2	Bushing-Snap
11	137-2827	1	Spring-Gas, Adjustable Stop
12	3290-511	2	Screw-HSBH
13	130-6655	2	Nut-Flange, NI
14	138-5773	1	Wheel-Steering
15	99-5107	1	Nut-Lock
16	138-3349	1	Controller-Power Steering
17	33103-050	2	Screw-HHF
18	131-3630	1	Cap-Wheel, Steering



Brake Assembly


Ref.	Part Number	Qty.	Description
1	104-6782	1	Master Cylinder ASM
2	119-4061	2	Screw-HHF
3	104-8301	2	Nut-HF, NI
4	133-7273	4	Rotor-Brake
5	127-7424	4	Brake Caliper ASM
6	144-5550	8	Screw-Spl
7	119-9509	4	Screw-Bleed
8	283-2	1	Pin-Clevis
9	1-806003	1	Pin-Cotter

Ref.	Part Number	Qty.	Description
10	115-2341	12	Washer-Banjo
11	120-4875	4	Bolt-Flange, Banjo
12	137-6768	1	Hose ASM-Brake, Front
14	139-4403	1	Hose ASM-Brake, Rear (Extended)
15	32180-030	9	Clip-Tie
16	32144-4	4	Screw-HWH
17	144-2227	2	Switch-Brake, Pressure




Master Cylinder Assembly No. 104-6782

Ref.	Part Number	Qty.	Description
1	104-6845	1	Reservoir ASM
1:1	92-4112	1	Cap ASM
2	93-8971	2	Seal-Port, Flange
3	92-4103	1	Pin-Stop
4	92-4102	1	Secondary Piston ASM
5	92-4110	1	Clevis
6	21-0360	1	Nut-Hex
7	94-5209	1	Cover-Dust
8	94-5210	1	Rod-Push
9	92-4109	1	Ring-Snap
10	92-4108	1	Retainer-Washer
11	92-4101	1	Primary Piston ASM



Brake Caliper Assembly No. 127-7424


<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	133-0628	1	Brake Pad Kit
2	119-9511	1	Bracket Kit
3	133-0614	1	Piston Kit



Hood and Front Fender Assembly

Ref.	Part Number	Qty.	Description
1	137-2816SP	1	Fender-Front, LH
2	137-2817SP	1	Fender-Front, RH
3	136-9540	1	UTV Bumper ASM
4	144-2421-05	1	Bracket-Mount, Utx Bumper [blk-Txt]
5	32144-70	4	Screw-HWHTF
6	3234-42	2	Screw-HHF
7	104-8301	2	Nut-HF, NI
8	138-5778	1	Headlight ASM, LH
9	138-5779	1	Headlight ASM, RH
10	137-6820SP	1	UTV Hood ASM
10:1:2	137-6817	2	Bracket-Pivot, Hood
10:1:3	114439	6	Rivet-Blind
11	137-6856	2	Strap-Hood


Ref.	Part Number	Qty.	Description
12	136-7192	2	Bolt-Shoulder, HHF
13	104-8300	2	Nut-HF, NI
14	137-6827	4	Plug-Plastic
15	139-3430	8	Screw-Bhf
16	140-4646	1	Grill-Utx
17	138-5765	1	Fender-Inner, LH
18	138-5766	1	Fender-Inner, RH
19	138-5775	9	Screw-Delta Point
20	49-2040	12	Screw-HWHTF
21	132-6777	2	Screw-Twh Thd Roll
22	144-2294	1	Emblem-Toro
23	144-2423-05	1	Bracket-Mount, Utx Bumper [blk-Txt]
24	144-1145	2	Decal-Utx, Emblem



Dash Assembly

Ref.	Part Number	Qty.	Description
1	137-2749SP	1	Footboard
2	701243	4	Screw-Thd Roll, HWH
3	145-2174-03	1	Bracket-Dash, LH
4	145-2178-03	1	Bracket-Dash, RH
5	49-2040	10	Screw-HWHTF
6	138-0041SP	1	Panel-Windshield, Dash
7	138-0040SP	1	Dash
8	125-9622	8	Rivet-Blind
9	138-0039SP	1	Door-Glove Box
10	139-3462	1	Seal-Door, Glove Box
11	140-4679	1	Latch-Quarter Turn


Ref.	Part Number	Qty.	Description
12	139-3436	1	Grommet
13	139-3487	1	Grommet-Shifter
14	139-3488	1	Grommet-Steering Column
15	139-3489	1	Grommet-Brake Pedal
16	139-3449-05	1	Bracket-Mount, Radio
17	104-7201	2	Nut-HF, NI
18	140-4680	1	Cam-Latch, Quarter Turn
19	145-0840	2	Bracket-Glove Box
20	32144-42	2	Screw-Thd Form, HWH
21	147-2822	1	Seal-Foam, Steering Column



Seat Base Assembly

Ref.	Part Number	Qty.	Description
1	137-6896-03	2	Frame-Seat, Bottom
2	3230-23	4	Bolt-CARR
3	104-8300	8	Nut-HF, NI
4	137-2746-03	2	Tube-Support, Seat
5	32144-57	4	Screw
6	137-6888	4	Wire-Hinge
7	321-3	8	Screw-HH
8	104-7201	8	Nut-HF, NI
9	137-6874SP	2	Plate-Floor
10	701243	12	Screw-Thd Roll, HWH
11	137-6875SP	2	Panel-Seat Base
12	138-5775	28	Screw-Delta Point
13	137-2813SP	2	Panel-Seat Base, LH
14	137-2814SP	2	Panel-Seat Base, RH
15	49-2040	12	Screw-HWHTF
16	32144-70	2	Screw-HWHTF
17	140-2676	2	Retractor-Seat Belt, LH

Ref.	Part Number	Qty.	Description
18	140-2677	2	Retractor-Seat Belt, RH
19	140-2678	1	Buckle-Seat Belt, W/Switch
20	140-2679	3	Buckle-Seat Belt
21	144-2269	12	Nut-HF, NI
22	144-2289	12	Screw-HHF
23	138-9420	4	Seat Backrest ASM
24	138-9419	2	Bench Seat Bottom ASM
25	145-7954	4	Bracket-Hinge, Seat
26	3274-55	4	Screw-HSBH
27	138-9411	2	Support-Panel-Side
28	136-9791	1	Plug-Panel
29	137-2949	1	Panel-Rear, Seat
31	139-3454	2	Cup Holder
32	3230-5	4	Bolt-CARR
33	145-2183-03	1	Bracket-Stiffener, Footboard
34	145-2184-03	1	Bracket-Stiffener, Footboard
35	145-2182	4	Adhesive-Strip




Cargo Bed Assembly

Ref.	Part Number	Qty.	Description
1		1	Cargo Bed Kit ●
2	139-4421-03	1	Tube-Latch
3	145-2001	2	Latch-Bed
4	139-4422	2	Plate-Threaded
5	32105-18	2	Screw-HHF
6	140-2663	2	Spring-Extension
7	1-633268	2	Grip-Lever
8	93-9719	2	Block-Wear
9	3274-69	4	Screw-HSBH
10	120-4578	4	Nut-HF
11	139-2071	2	Light-Rear Tail/Stop/Turn
12	3250-52	4	Screw-PPH
13	139-4417	1	Spring-Gas
14	283-5	2	Pin-Clevis
15	3290-467	2	Pin-Hair

Ref.	Part Number	Qty.	Description
16	3234-39	2	Screw-HHF
17	104-8301	2	Nut-HF, NI
18	66-6500	4	Spacer-Wheel
19	136-7192	2	Bolt-Shoulder, HHF
20	120-9471	4	Bolt-Shoulder
21	130-5726	2	Lanyard
22	126-6268	15	Screw-TTH
23	144-2211	2	Sleeve-Pivot, Bed
24	125-5239	4	Bushing-Flange
25	133-7146	2	Plug-Tailgate, Anti-Rattle
26	144-1145	1	Decal-Utx, Emblem
27	144-2277	2	Decal-Red Stripe, 43"
28	144-2281	1	Decal-Red Stripe, 55.25"
29	144-2293	1	Decal-Cargo Bed Safety, Crew




● Not serviced separately



Cargo Bed Kit Assembly

Ref.	Part Number	Qty.	Description
1	139-4420	1	Flat Bed ASM
1:12	138-2899	11	Nut-Clinch
2	140-4675	1	Panel ASM-Front, Bed
2:2	138-2899	4	Nut-Clinch
3	140-4625	1	Bed Side ASM, LH
3:2	140-2690	1	Retainer-Tailgate
3:3	139-4690	1	Bushing-Tailgate
3:4	138-5775	3	Screw-Delta Point
3:5	105-1217	1	Decal




Ref.	Part Number	Qty.	Description
3:6	140-4835	1	Decal-Workman, Gray
4	140-4635	1	Bed Side ASM, RH
4:2	140-2690	1	Retainer-Tailgate
4:3	139-4690	1	Bushing-Tailgate
4:4	138-5775	3	Screw-Delta Point
4:5	105-1217	1	Decal
4:6	140-4835	1	Decal-Workman, Gray
5	144-2275	1	Tailgate ASM
5:2	105-1217	1	Decal



Electrical Assembly

Ref.	Part Number	Qty.	Description
1	121-5159	1	Switch-Ignition
1:1	121-5160	1	Nut-Hex
1:2	122-2704	1	Nut-Face, M22 (Plastic)
1:3	121-5162	1	Set-Key, Ignition
2	127-2770	1	Controller
3	42862	1	Block-Terminal, Ground
4	42863	1	Strip-Jumper
5	100-4351	2	Screw-HWH
6	32144-110	4	Screw-HWH
7	99-7435	3	Relay
8	136-9450	1	Cluster-Instrument
9	144-2440	1	Switch-Rocker, On-None-On
10	144-2445	1	Switch-Rocker, On-On-On
11	99-7420	5	Plug-Hole
12	144-2405	1	Switch-Rocker, On-None-On
13	139-3420	1	Port-USB
14	32144-112	5	Screw-HWH
18	33103-012	2	Screw-HHF

Ref.	Part Number	Qty.	Description
19	122-2316	1	Harness-Wire, Utx Gas 4 Passenger
19:30	32180-156	1	Cap-Plug, 6 Way
19:33	32180-089	1	Cap-Plug, 3 Way
19:34	100-4918	1	Diode
19:37	126-3991	4	Relay-Micro
19:38	121-8864	1	Fuse-Mini Blade, 5 Amp
19:39	121-8865	3	Fuse-Mini Blade, 7.5 Amp
19:40	121-8866	9	Fuse-Mini Blade, 10 Amp
19:42	121-8868	3	Fuse-Mini Blade, 20 Amp
19:43	121-8870	1	Fuse-Mini Blade, 30 Amp
19:47	121-8861	1	Fuse-Mini Blade, 2 Amp
19:49	32180-282	1	Resistor-120 Ohm
19:52	32160-128	1	Connector-Mp280, 3M (Sealed)
19:54	121-8869	1	Fuse-Mini Blade, 25 Amp
19:56	126-6157	4	Relay-Micro 280, Spdt
20	139-4557	1	Horn-ASM
21	32144-70	1	Screw-HWHTF
22	144-2415	1	Switch-Rocker, (On)-None-Off




Electrical Assembly (continued)

Ref.	Part Number	Qty.	Description
23	3234-13	2	Screw-HHF
24	99-3441	1	Harness-Wire, Fusible Link
25	139-2080	1	Flasher-Dual Rate
26	144-2425	1	Switch-Rocker, On-Off-On

Ref.	Part Number	Qty.	Description
27	144-2400	1	Switch-Rocker, On-None-On
28	145-2160	1	Plug-Panel
29	145-2200	1	Switch-Rocker, (On)-On-Off

L2




Engine Drivetrain and Exhaust Assembly

Ref.	Part Number	Qty.	Description
1		1	Engine/Drivetrain ASM ●
2	138-9335	1	Muffler ASM (With Mounts)
2:1	138-9300	4	Isolator-Mount, Muffler
3	3234-36	5	Screw-HHF
4	104-8300	11	Nut-HF, NI
5	139-0856	3	Mount-Engine
6	138-6462	1	Support-Isolator
7	80-8560	2	Washer-Hardened
8	323-11	2	Screw-HH
9	104-8301	2	Nut-HF, NI
10	3234-47	6	Screw-HHF
11	140-4667	1	Duct-Inlet, Cvt
12	2412-125	1	Clamp-Hose
13	140-4685-03	1	Link Rod ASM [black]
14	140-4697	2	Bushing, Rubber

Ref.	Part Number	Qty.	Description
15	109-5010	2	Spacer
16	3234-46	2	Screw-HHF
17	99-5107	2	Nut-Lock
18	110-4110	1	Hose-LP
19	140-2617	1	Pipe-Exhaust
20	131-5945	1	Isolator-Engine
21	144-2413	1	Clamp-Manifold (1.87" DIA)
22	136-8683	2	Nut-Lock
23	32144-110	4	Screw-HWH
24	32151-86	1	E-Ring
25	145-2119	1	Gasket-Exhaust
26	138-9301	4	Mount-Top Hat, Muffler
27	323-12	1	Screw-HH
28	144-2433	1	Arrester- Spark, 1.75


● Not serviced separately



Engine, Transaxle and Clutch Assembly

Ref.	Part Number	Qty.	Description
1	144-2216	1	Engine (Gas)
2	145-2143	1	Housing-Flywheel, Gas
3	139-4598-0P	1	Plate-Spanner
4	140-2611	1	Transaxle ASM
5	139-4591	1	Clutch-Secondary
6	145-2145	1	Adapter-Clutch
7	139-4590	1	Clutch-Primary
8	104-6550	1	Washer-Clutch
9	99-7201	1	Screw-HH
10	140-4777	1	Screw-HHF
11	140-2603	1	Enclosure-Cvt
12	140-2604-0P	1	Bracket-Transmission, LH
13	145-7785-0P	1	Bracket-Trans, RH (Gas)
14	33104-020	6	Screw-HHF
15	110-3986	14	Screw
16	140-4669	6	Clip-Spring


Ref.	Part Number	Qty.	Description
17	145-7789	1	Belt-Variable
18	145-2235-0P	1	PSI Front Engine Mount ASM [pri
19	140-2624-0P	1	Bracket-Drivetrain, Rear
20	33115-140	2	Screw-HH
21	103-9511	2	Nut-Lock, NI
22	120-4839	4	Screw-HHF
23	140-2689	2	Screw-HH
24	114-8417	2	Nut-HF, NI
25	3234-38	2	Screw-HHF
26	99-5107	2	Nut-Lock
27	104-2628	4	Screw
28	145-2146	1	Bearing-Ball
29	133-1717	1	Screw-Set
30	3290-378	1	Tie-Cable



Transaxle Assembly No. 140-2611


Ref.	Part Number	Qty.	Description
1	145-2039	1	Sensor,Speed, Transaxle
2	145-2040	1	Sensor, Assembly, Rotary Position
3	145-2030	1	Plug-Expansion 80MM X 10MM
29	130-4616	2	Bearing-Needle
30	145-2031	2	Bearing, Ball 6204 C3
31	145-2032	2	Bearing, Ball 6205 C3
32	130-4666	2	Bearing-Ball
33	145-2033	1	Bearing, Ball 6206 C3
34	145-2034	2	Bearing, Ball 6207 C3
35	145-2035	1	Bearing, Ball 6208 C3
36	130-4618	1	Bearing-Needle
37	145-2036	1	Bearing, Ball 6203 C3

Ref.	Part Number	Qty.	Description
59	145-2037	1	Tube,Vent, 90-1/4" Hose
83	145-2038	1	Subassembly, Bellcrank
89	145-2041	1	Shift Actuator, 2 Position
93	145-2042	1	Seal, Triple Lip, 0.984 X 2.047 X 0.394
95	145-2043	1	O-Ring
96	145-2044	1	O-Ring, 0.530 ID X .082 Wide
97	145-2045	2	Seal, Triple Lip, Viton, 40 X 70 X 7
98	145-2046	1	Seal, Triple Lip, 1.180 X 1.8520 X 0.315
99	145-2047	1	O-Ring, Nitrile




Secondary Clutch Assembly No. 139-4591

Ref.	Part Number	Qty.	Description
1	145-2104	4	Screw, Machine Torx Sfch 10-32 X .625
3	145-2025	1	Spider 9.5 25T Mach
4	145-2026	4	Roller-Clutch 1.135 X .550
5	130-4059	2	Washer-Thrust
6	130-4058	2	E-Ring
7	145-2027	1	Spring-Comp 2.00 OD Secondary 175-320
10	130-4063	2	Pin-Roller
11	130-4065	2	Pin-Spring, Slotted
13	145-2028	1	Bearing-Ball
14	145-2029	1	Sleeve-Shoulder



Primary Clutch Assembly No. 139-4590


Ref.	Part Number	Qty.	Description
4	145-2018	1	Washer-Thrust
5	145-2019	1	Subassembly, Idler Primary
6	130-4069	1	Washer-Thrust
7	145-2020	1	Cap-Idler Sleeve
9	145-2103	3	Nut, Lock Hex 10-24 Flexloc
10	119-6016	3	Screw-Shoulder
11	145-2021	3	Weight-Clutch M17-198
12	145-2022	1	Spring-Compression 2.00 OD Primary 70-13
15	145-2023	1	Nut-Jam
16	145-2024	6	Screw-Hex Flange 1/4-20 X 1.25
20	145-7784	1	Collar Primary Shift Stop



Front Differential and Driveshaft Assembly

Ref.	Part Number	Qty.	Description
1	140-4752	1	Differential-Front
2	144-2213-0P	1	Mount ASM-Differential, LH
3	140-4692-0P	1	Mount-Differential, RH
4	145-7778	2	Screw-HHF
5	323-26	1	Screw-HH
6	104-8301	1	Nut-HF, NI
7	126-6095	4	Mount-Isolator
8	109-6919	4	Washer-Clutch
9	144-2215	4	Screw-Bht
10	114-8417	4	Nut-HF, NI


Ref.	Part Number	Qty.	Description
11	140-4771	1	Driveshaft ASM-Intermediate
12	105-4886	2	Nut-Tinnerman
13	3234-42	2	Screw-HHF
14	140-4763	1	Driveshaft ASM (Crew)
15	139-3392	4	Screw-Lock
16	140-2644	2	Cv Axle ASM, Front
17	115-2164	2	Nut-Spindle
18	32180-030	1	Clip-Tie
19	145-7787	1	Bumper-Drive Shaft



Front Differential Assembly No. 140-4752


Ref.	Part Number	Qty.	Description
1	145-7895	1	Cover
2	145-7896	1	Housing
3	145-7897	1	Pinion
4	145-7898	1	Planet Carrier Sub-ASM
5	145-7899	1	Clutch
6	145-7900	1	Support Ring
7	145-7901	1	Fork
8	145-7902	1	Gear A
9	145-7903	1	Pin, 5 X 62L
10	145-7904	1	Retaining Ring, External 34
11	145-7905	2	Bolt, M10 X 10L
12	145-7906	1	Slider A
13	145-7907	1	Slider B
14	145-7908	1	O-Ring, 62 I.D. X 2 Wide
15	145-7909	3	Screw, Sh, M8X20L
16	145-7910	1	Nut, M74
17	145-7911	1	Flange
18	145-7912	1	Bushing
19	145-7913	1	Needle Bearing, Hk1612
20	145-7914	1	Ball Bearing, 6207
21	145-7915	1	Ball Bearing, 16007

Ref.	Part Number	Qty.	Description
22	145-7916	2	Washer, 8.2 X 16 X 2T
23	145-7917	1	Shim, 50.5 X 61
24	145-7918	1	Lock Washer
25	145-7919	1	Shim, 36 X 44
26	145-7920	1	Shim, 79 X 89
27	145-7921	1	Washer, 14.5 X 22 X 1T
28	145-7922	1	O-Ring, P26
29	145-7923	2	Seal, 25 X 45 X 7T X 11T
30	145-7924	1	Seal, 40 X 75 X 8T X 12T
31	145-7925	1	Plug, M14 X 9.5L
32	145-7926	2	Screw, HH, M8Xp1.25X12L
33	145-7927	6	Screw, HH, M8Xp1.25X30L
34	145-7928	1	Retaining Ring, Internal 62
35	145-7929	1	Location Pin
36	145-7930	1	Breathing Tube
37	145-7931	1	Ring
38	145-7932	1	Tube, Vent, 90 DEG
39	145-7933	1	Screw, HH, M10Xp1.25X20L
40	145-7934	1	Pin, 5 X 4.63 X 62L
41	145-7935	1	Actuator




Intermediate Driveshaft Assembly No. 140-4771

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
2	139-4442	1	Bearing-Hanger
3	144-2208	1	Retainer-Bearing
4	302-5	1	Fitting-Grease
5	140-4772	1	Boot-Joint, Slip
6	140-4760	1	Band



Driveshaft Assembly No. 140-4763


Ref.	Part Number	Qty.	Description
1	138-9162	2	U-Joint Kit
2	138-9178	1	Yoke-Flange
4	140-4753	1	Yoke-Slip, Female
5	140-4754	1	Boot-Joint, Slip
6	110-4755	1	Fitting-Grease
7	140-4760	1	Band



Cooling System Assembly

Ref.	Part Number	Qty.	Description
1	137-6828	5	Bushing-Flange
2	140-2641	1	Radiator ASM
3	138-9349	1	Tube ASM-Coolant, Extended
4	140-2628	1	Hose-Radiator, Upper
5	140-4751	1	Hose ASM-Coolant
6	140-2634	1	Hose-Coolant, Upper
7	144-2242	1	Hose-Coolant, Lower
8	32144-4	3	Screw-HWH
9	144-2246	8	Clamp-Sc Band
10	144-0033	1	Tank-ASM

Ref.	Part Number	Qty.	Description
11	32144-70	4	Screw-HWHTF
12	138-9327-05	1	Bracket-Mount, Radiator
13	32180-030	2	Clip-Tie
14	120-4867	1	Cap-Coolant, Threaded (15 PSI)
15	144-2220	1	Hose-Coolant, Minor
16	140-4757	1	Hose-Coolant
17	144-2248	5	Clamp-Sc Band
18	120-5019	1	Hose-Coolant
19	92-2379	2	Clamp-Hose
20	106-6755	1	Decal-Cap, Radiator




Radiator Assembly No. 140-2641

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	140-4695	1	Radiator
2	703856	4	Nut-Sq, Caged
3	139-4587	1	Shroud-Fan, Radiator
4	140-4694	1	Fan
5	3234-30	4	Screw-HHF
6	120-4564	4	Screw-BHCS




Ref.	Part Number	Qty.	Description
13	119-3517	1	Hose-Fuel
14	109-0298	1	Line-Fuel
15	125-2921	1	Fitting-Fuel
16	115-7854	1	Filter-Fuel, Inline
17	106-5317	1	Hose-Fuel
18	120-2038	1	Cartridge-Valve, Check
19	92-2379	2	Clamp-Hose
20	3234-26	2	Screw-HHF
21	3296-56	2	Nut-Lock, NI
23	3290-378	2	Tie-Cable ●
24	92-5753	2	Clamp-Hose
25	32144-4	2	Screw-HWH

R2




Air Cleaner Assembly

Ref.	Part Number	Qty.	Description
1	98-4525	1	Bracket-Cleaner, Air
2	106-5277	1	Air Cleaner ASM
3	145-2118	1	Hose ASM-Intake
4	144-2200	2	Clamp-Sc Band
5	3234-36	2	Screw-HHF
6	104-8300	2	Nut-HF, NI
7	127-1777	1	Hose-Fuel
8	2412-143	2	Clamp-Hose




Air Cleaner Assembly No. 106-5277

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
2	108-3810	1	Filter-Air
3	98-9771	1	Cover ASM
4	87-9400	1	Valve-Vacuator
5	285-17	1	Plug-Pipe




Hose Intake Assembly No. 145-2118

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	145-2116	1	Hose-Air Intake, A
2	145-2117	1	Hose-Air Intake, B
3	145-2112	1	Fitting-Tee
4	144-2200	2	Clamp-Sc Band



Cylinder Block Assembly


Ref.	Part Number	Qty.	Description
1	145-7937	1	Dip Stick, Oil
2	145-7938	1	Tube, Dipstick
8	145-7939	1	Gasket, Water Sealing Cover
9	145-7940	1	Gasket, Water Sealing
10	145-7941	4	Bolt
12	145-7942	1	Filter, Oil
13	145-7943	1	Fitting, Oil Filter
21	145-7944	1	Switch, Oil Pressure
22	145-7945	1	Seal, Dipstick Tube



Crankshaft and Piston Assembly


Ref.	Part Number	Qty.	Description
1	145-7946	1	Bearing, Main (Set Of 10)
2	145-7947	1	Bearing, Connecting Rod
3	145-7948	1	Bearing, Thrust
4	145-7949	1	Pin, Locating
5	147-2550	1	Gasket, Oil Seal Housing
6	147-2551	1	Housing, Oil Seal
7	147-2552	4	Bolt, Oil Seal Housing
8	147-2553	1	Seal, Oil (Rear)
9	147-2554	2	Bolt, Oil Seal Housing
10	147-2555	3	Bushing
11	147-2556	1	Crankshaft

Ref.	Part Number	Qty.	Description
12	147-2557	1	Bolt, Crankshaft Pulley
13	147-2558	1	Pulley, Crankshaft
14	147-2559	2	Seal, Camshaft Front
15	147-2560	2	Key, Woodruff
17	147-2561	4	Connecting Rod
18	147-2562	8	Rod, Connecting
19	147-2563	8	Clip, Piston Pin
20	147-2564	4	Pin, Piston
21	147-2565	4	Piston
26	147-2566	4	Piston Ring Set - Complete




Camshaft and Rocker Arm Assembly

Ref.	Part Number	Qty.	Description
1	147-2567	8	Arm, Rocker
2	147-2568	1	Shaft, Rocker Arm
3	147-2569	1	Bolt
4	147-2570	2	Bolt
5	147-2571	1	Plate, Camshaft Thrust
6	147-2572	8	Seat, Valve Spring
7	147-2573	16	Rotaton, Valve
8	147-2574	8	Valve, Spring
9	147-2575	4	Valve, Exhaust
10	147-2576	1	Camshaft
11	147-2577	1	Seal, Camshaft
13	147-2578	4	Valve, Intake
14	147-2579	8	Seal, Valve Stem
15	147-2580	8	Seat, Valve Spring



Cylinder Head Assembly


Ref.	Part Number	Qty.	Description
6	147-2581	1	Bolt
7	147-2582	1	Sensor, Camshaft
9	147-2583	4	Bolt, Intake Manifold
11	147-2584	1	Housing, Camshaft Sensor
12	147-2585	1	Gasket, Camshaft Sensor Housing
13	147-2586	2	Pin, Locating
14	147-2587	1	Gasket, Cylinder Head
15	147-2588	4	Pin, Locating
16	147-2589	1	Head, Cylinder
17	147-2590	10	Bolt, Cylinder Head
18	147-2591	1	Gasket, Rocker Cover
19	147-2592	1	Cover, Rocker
20	147-2593	4	Spacer
21	147-2594	1	Cap, Oil
23	147-2595	4	Bolt, Rocker Cover



Timing Cover Assembly


Ref.	Part Number	Qty.	Description
1	147-2596	1	Bolt
2	147-2597	1	Front Cover
3	147-2598	1	Gasket, Front Cover
4	147-2599	1	Bolt
5	147-2600	1	Belt, Timing (90 Teeth)
6	147-2601	1	Sprocket, Camshaft
7	147-2602	2	Bolt, Front Cover
8	147-2603	2	Washer
9	147-2604	4	Spacer
10	147-2605	1	Rear Cover
11	147-2606	2	Seal, Oil Cover
12	147-2607	1	Plate, Cover
13	147-2608	1	Washer

Ref.	Part Number	Qty.	Description
14	147-2609	1	Cover
15	147-2610	2	Bolt, Front Cover
16	147-2611	2	Gasket, Rear Cover
17	147-2612	1	Bolt, Front Cover (Incls Washer)
18	147-2613	1	Bolt, Tensioner
19	147-2614	1	Bushing, Torsion Spring
20	147-2615	1	Spring, Torsion
21	147-2616	1	Tensioner
22	147-2617	1	Sprocket, Crankshaft
23	147-2618	1	Cover
24	147-2619	1	Seal, Front Cover




Intake Manifold Assembly

Ref.	Part Number	Qty.	Description	Ref.	Part Number	Qty.	Description
1	147-2620	3	Bolt, Intake Manifold	25	147-2633	1	Thermostat
2	147-2621	4	Nut, Intake Manifold	26	147-2634	2	Gasket, Intake Manifold
3	147-2622	1	Lifting Eye	27	147-2635	1	Hose, Pvc Vent
4	147-2623	1	Sensor, Water Temp	28	147-2636	1	Pcv
8	147-2624	1	Manifold, Intake	29	147-2637	1	Clamp
11	147-2625	1	Sensor, Air	30	147-2638	1	Hose, Pcv
12	147-2626	1	Bolt	31	147-2639	1	Clamp
18	147-2627	2	Clamp	32	147-2640	3	Stud, Intake Manifold
20	147-2628	1	Hose, Coolant	33	147-2641	1	Stud, Exhaust Manifold
21	147-2629	2	Clamp	34	147-2642	2	Bolt, Fuel Rail
22	147-2630	2	Bolt	35	147-2643	1	Rail, Fuel
23	147-2631	1	Outlet, Water	36	147-2583	1	Bolt, Intake Manifold
24	147-2632	1	Gasket, Thermostat Cover	37	145-7936	4	Injector W/Clip




Exhaust Manifold Assembly

Ref.	Part Number	Qty.	Description
1	147-2644	8	Stud
2	147-2645	1	Gasket, Exhaust Manifold
3	147-2646	1	Manifold, Exhaust
4	147-2647	1	Sensor, O2
5	147-2648	8	Nut
6	147-2649	5	Screw
7	147-2650	1	Shield, Exhaust
8	147-2651	2	Stud




Oil Pan Assembly

Ref.	Part Number	Qty.	Description
1	147-2652	1	Seal, Oil Strainer
2	147-2653	1	Tube, Oil Pick Up
3	147-2654	1	Gasket, Oil Pan
4	147-2569	18	Bolt
5	147-2655	1	Seal, Drain Plug
6	147-2656	1	Plug, Drain
7	147-2657	1	Pan, Oil
8	147-2658	2	Bolt




Oil Pump Assembly

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	147-2659	1	Gasket, Oil Pump
2	147-2555	1	Bushing
3	147-2660	1	Pump, Oil
4	147-2661	1	Bolt, Water Pump
5	147-2662	3	Bolt, Water Pump
6	147-2663	5	Bolt, Oil Pump




Water Pump Assembly

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	147-2664	1	Belt
2	147-2665	4	Bolt
3	147-2666	1	Pulley, Water Pump
4	147-2661	1	Bolt, Water Pump
5	147-2667	1	Pump, Water
6	147-2668	1	Gasket, Water Pump
7	147-2669	2	Stud, Water Pump
8	147-2670	2	Nut
9	147-2662	1	Bolt, Water Pump




Starter Assembly

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	147-2671	1	Starter
2	147-2672	2	Dowel
3	147-2673	2	Bolt




Alternator Assembly

Ref.	Part Number	Qty.	Description
1	147-2674	1	Bolt, Alternator
2	147-2675	1	Bracket, Alternator
3	147-2676	2	Bolt, Alt Support
4	147-2677	1	Support, Alternator
5	147-2678	1	Bolt, Alt Support
6	147-2679	1	Bolt
7	147-2680	1	Alternator
8	147-2681	3	Bolt




Rear Plate Assembly

Ref.	Part Number	Qty.	Description
1	147-2682	2	Bolt
2	147-2683	2	Spacer
3	147-2684	2	Nut
4	147-2685	2	Bolt
5	145-2003	1	Seal-Plate, Rear
6	144-2201	1	Plate-Engine




Ignition Assembly

Ref.	Part Number	Qty.	Description
1	147-2688	1	Retainer, Wire#4
2	147-2689	1	Wires, Spark Plug
3	147-2690	1	Coil, Ignition
4	145-2128	4	Kit-Spark Plug
5	147-2691	1	Bracket, Coil Rear
6	147-2692	1	Bracket, Ignition Wires
7	147-2693	2	Bolt




Throttle Body Assembly

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	147-2694	1	Body, Throttle
2	147-2695	1	Gasket
3	147-2696	4	Screw




Coolant Plug Assembly

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	147-2697	1	Hose, Heater (2 Inches)
2	147-2698	1	Fitting
3	147-2699	1	Fitting
4	145-2660	2	Clamp, Tension



Coolant Inlet Assembly

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	145-2661	1	Gasket, Water Inlet
2	145-2662	1	Inlet, Coolant Straight
3	145-2663	2	Bolt, Flange



Electrical Assembly

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	145-2010	1	Sensor-Position, Crankshaft
2	144-2232	1	Ecu
3	145-2666	1	Harness

Attachments and Accessories

For 08101 Workman UTX 4 Passenger Utility Vehicle

Product Name	Model/Part
Canopy-Crew.....	08111
Glass Windshield and Wiper.....	08112
Polycarbonate Windshield	08113
Polycarbonate Doors - Standard.....	08114
Polycarbonate Doors - Crew.....	08115
Polycarbonate Rear Windshield	08116
Overhead Console and Wire Harness	08130
Work Lights.....	08131
Beacon	08132
Electric Bed Lift.....	08134
Supervisor Key	08136
Side View Mirror Kit	08140
Rear View Mirror Kit.....	08141
Under Seat Storage	08143
27in Alloy Wheels and Tires.....	08144
Draw Bar.....	08146
Reverse Alarm Kit.....	131-8549
Universal Wireless Hourmeter Kit	144-2436
Universal 12V Power Point Kit	144-2438
Spark Arrester Kit	144-2443

Notes:

Notes:

Notes:



Count on it.