



Proline

Recycler[®] /Rear Bagger

Model No. 22162 – 8900001 & Up

Parts Catalog

ORDERING REPLACEMENT PARTS

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

Contents

Description	Page	Description	Page
Housing Assembly	1–2	Grass Bag Assembly No. 98–9220	9
Blade Brake Clutch Assembly	3	Rear Wheel & Tire Assembly	10
Fuel Tank Assembly	4	Engine GTS–200	11–19
Handle Assembly	5	Toro Part Number Index	20–23
Handle Control Assembly	6	Maintenance	24–25
Gear Case & Rear Wheel Assembly	7		
Gear Case Assembly	8		

Note:

Accessories

Description	Model / Parts No.	Description	Model / Parts No.
Side Discharge Kit	Model No. 59199		

Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

Abbreviation	Meaning	Abbreviation	Meaning
AR	as required	HWHTF	hex washer head thread forming
ASM	assembly	INC	incorporated
CARR	carriage	LH	left hand
DEG	degrees	PH	pan head
FH	flat head	PPH	Phillips pan head
GA	gauge	PTO	power take off
HF	hex flange	RH	right hand
HFW	hex flange washer	SFH	slotted fillister head
HH	hex head	SH	square head
HHF	hex head flange	SHWH	slotted hex washer head
HHST	hex head self tapping	SPH	slotted pan head
HJ	hex jam	STD	standard
HOC	height-of-cut	TAP	self tapping
HS	hex socket	TH	truss head
HSBH	hex socket button head	TTH	Torx truss head
HSFH	hex socket flat head	WH	wing head
HSH	hex socket head		
HWH	hex washer head		

Important Format Explanations

This catalog uses special formats to convey information in illustrations and parts lists. Specifically, one format is used in conjunction with service assemblies and another with quantities associated with reference numbers.

Service Assemblies

Parts within service assemblies have reference numbers in the form $X:Y$. X is the reference number of the service assembly and Y is a sequential number unique to each part within the service assembly.


For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually.

Reference numbers of this type appear in part lists and as callouts in illustrations.

Reference Numbers with Quantities

Illustrations may have a quantity in parentheses next to a reference number, in the form $X (Y)$. X is the reference number. Y in parentheses is the quantity of the part identified by the reference number.

For example, the illustration callout 4 (2) indicates that two parts are used in that instance.




Sheet No.:2

Housing Assembly

Ref. No.	Part No.	Qty.	Description
1	98-7146	1	Housing-Commercial Mach)
1:2	92-1750	1	Plate-Kicker Rear
1:3	92-1720	1	Kicker-RH
1:4	92-1730	1	Kicker-LH
1:5	32144-111	6	Screw - PPH
1:6	43-8480	1	Decal-Danger
2	3296-6	2	Nut-Lock
3	40-1940	4	Washer
4	32152-2	2	Nut-Lock HH
5	66-7560	2	ASM-Arm
6	257-3	2	Washer-Thrust
7	61-8300	2	ASM-Arm
8	52-2480	2	Spacer
9	27-6232	2	Bolt-Wheel HH
10	53-7720	2	ASM-Wheel & Tire
10:1	53-7740	2	Tire-8.00
†10:2		2	ASM-Wheel
10:3	53-7780	4	Plate-Wheel Half
10:4	52-2410	2	Hub-Bearing Support
10:5	52-2450	4	Ball Bearing
10:6	52-2440	2	Spacer-Bearing
10:7	321-2	8	Screw-HH
10:8	3296-42	8	Nut-Lock
11	323-12	2	Screw
12	25-7740	2	Knob-Arm

Ref. No.	Part No.	Qty.	Description
13	49-8760	1	Quadrant-Front
14	46-6811	1	Screw-HWH
17	44-0580	1	Shield-Trailing
18	33-3208	1	Rod-Shield
19	49-8740	1	Quadrant-Rear
20	74-1860	1	ASM-Gearcase
21	98-3214	1	Cover-Belt
22	37-7260	2	Screw-TAP
23	3296-42	2	Nut-Lock
24	49-8750	1	Quadrant-Rear
25	3256-22	2	Washer-Flat
26	321-7	2	Screw-Cap
27	77-0500	1	ASM-Plug
27:2	76-4640	1	Latch Discharge Plug
27:3	3295-35	1	Rivet Solid
27:4	76-4650	1	Grip Latch
28	46-8090	2	Screw-Tapping
29	93-3154	1	Plate-Latch
30	93-7351	1	ASM-Door
32	80-3770	1	Retainer-Door
33	76-4660	1	Spring-Extension
34	71-9350	1	Spring-Bracket
35	52-2620	1	Label-Grease
36	82-9152	1	Chute-Discharge
39	46-6810	1	Screw HWH
42	49-2040	8	Screw-HH


† Included in a service kit or in an assembly



Sheet No.:2

Housing Assembly (Cont.)

Ref. No.	Part No.	Qty.	Description
43	49-8770	1	Quadrant-Front
46	92-7988	1	Decal-Recycler
47	323-6	2	Screw-HH
48	84-8930	2	Retainer-Shield
49	3296-39	2	Nut-Lock
50	98-9227	1	Guard-Primer




Sheet No.:3

Blade Brake Clutch Assembly

Ref. No.	Part No.	Qty.	Description
1	98-9246	1	Engine Gts 200 Bbc Pro
2	2210-316	1	Rope-Stop
3	98-2002	1	Decal-Engine
4	84-4960	1	Decal-Proline
5	93-8470	1	Screw-Clamp
6	2210-249	1	Clamp-Casing
7	32144-102	3	Screw
8	66-0570	1	Guide-Belt
9	3257-17	1	Key-Woodruff
10	56-6180	1	Pulley-Driver
11	56-6160	1	Flywheel-Bbc
12	42-3190	2	Bolt-Blade
13	56-6170	1	Drum-Brake
14	42-6890	1	ASM-Hub
15	52-3480	2	Damper-Vibration
16	46-5693	1	Shield-Bbc
17	62-4280	1	Spacer-Blade
18	3296-33	1	Nut-Lock
19	91-2256	1	Blade-Generation Ii
20	91-2255	1	Stiffener-Blade
21	80-2770	1	Cup-Anti Scalp
22	54-9190	2	Nut-Lock
23	32104-107	1	Screw-HH
24	3256-23	1	Washer-Flat
25	49-2810	1	Link-Control

Ref. No.	Part No.	Qty.	Description
26	49-7960	1	Bell Crank
27	49-7950	1	Sleeve-Bell Crank
28	49-2820	1	Lever
29	32104-96	1	Screw-HHST
30	49-7970	1	Spring-Torsion
31	70-1160	1	Washer-Pm
32	68-9780	2	Bearing
33	85-6880	1	Spring-Torsion
34	84-9130	1	Brake Plate
35	42-0884	1	V Belt-Bbc
36	46-5650	1	Pulley-Idler
37	46-5631	2	Hub-Idler Pulley
38	322-6	1	Screw-HH
39	3296-47	1	Nut-Lock
41	32144-70	2	Screw-TAP
42	84-9180	1	Brake Plate ASM
43	3272-1	2	Pin-Cotter
44	84-9050	1	Pin-Spring Guide
45	65-5280	1	Retainer-Spring
46	84-9100	1	Spring-Bbc
47	46-7040	1	Screw-HWH
48	84-8870	1	Guide-Spring
49	84-8880	1	Bracket-Spring
50	84-9040	1	Pin-Cable




Sheet No.:4

Fuel Tank Assembly

Ref. No.	Part No.	Qty.	Description
1	93-3166	1	Tank-Gas
2	55-3570	1	Cap-Fuel
3	51-3210	2	Fuel Line
4	71-9280	1	Filter-Fuel
5	84-9170	1	Wa-Base
6	2412-95	4	Clamp
7	323-7	2	Screw-HH
8	46-8091	2	Screw-Tapping
9	84-8930	1	Retainer-Shield

Ref. No.	Part No.	Qty.	Description




Sheet No.:5

Handle Assembly

Ref. No.	Part No.	Qty.	Description
1	98-2385	1	Handle
2	3290-378	1	Tie-Cable
3	32111-7	2	Nut-Cap
4	3296-29	4	Nut-Lock
5	3290-456	4	Washer-Lock
6	84-8361	1	Latch-Handle
7	322-7	2	Screw-HH
9	322-6	2	Screw-HH
10	74-1741	1	Bracket-Adjust
11	46-7030	1	Retainer-Cable
13	3-3287	2	Spacer
14	27-7210	2	Screw-Shoulder
15	48-2810	1	Rod-Support
16	3296-42	1	Nut-Lock
17	46-8081	1	Guide-Rope
18	321-9	1	Screw-HH
19	3-7501	1	Washer-Curved
20	74-1970	1	Decal-Drive
21	84-8401	1	Latch-Handle
22	32144-70	1	Screw-TAP
23	3296-47	2	Nut-Lock

Ref. No.	Part No.	Qty.	Description




Sheet No.:6

Handle Control Assembly

Ref. No.	Part No.	Qty.	Description
1	98-4995	1	Control Bar W.a.
2	85-6750	1	Spring-Control
3	3250-14	4	Screw
4	98-2005	1	Control-Throttle
5	84-9120	1	Cable-Traction
6	84-9110	1	Cable-Clutch
7	3296-2	4	Nut-Lock
8	71-9310	1	Spacer
9	71-9320	1	Spacer
10	322-19	1	Screw-Hex
11	46-6430	1	Screw-Handle
12	3290-378	1	Tie-Cable
13	98-2047	1	Cable-Throttle
14	3296-29	1	Nut-Lock
15	92-1778	1	Bracket-Control
16	3296-42	1	Nut-Lock
17	98-9245	1	Panel-Control
17:1	98-2003	1	Decal-Panel
17:3	85-6720	1	Decal-Proline Panel
17:4	63-9060	1	Decal-Danger
18	49-1631	1	Spacer-Support
19	17-9427	1	Screw-Handle
20	86-9320	1	Bushing-Nylon
21	84-9000	1	Traction Lever
22	3272-1	1	Pin-Cotter
23	3296-58	1	Nut-Flange

Ref. No.	Part No.	Qty.	Description
24	84-8990	1	Bbc Lever
25	84-9040	1	Pin-Cable
26	84-9030	1	Spacer-Control Bracket
27	32151-86	1	Ring-E
31	32104-76	6	Screw-Self TAP




Sheet No.:100

Gear Case Assembly

Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
3	48-2060	2	Bearing-Needle	35	3285-19	1	Pin-Groove
8	74-1890	1	Shaft-Output	37	49-2040	6	Screw-Self Tapping
9	13-5149	1	Shaft-Input	39	29-9570	1	Bushing-Yoke
9:1	302-63	1	Fitting-Grease	40	74-1920	1	Case-Lower
10	13-9739	1	Upper Case Assembly	63	74-1760	1	Gear-Bevel
10:1	47-7270	2	Bearing-Needle	64	39-6650	1	Gear-18t
10:2	47-7260	1	Seal	65	46-3550	1	Gear-14t
12	36-4792	4	Washer-Thrust	66	46-3540	1	Gear-12t
15	39-6740	1	Pulley	67	53-7950	1	Shaft-Intermediate
16	3296-5	1	Nut-Lock	68	39-7842	1	Key-Square
17	74-1750	1	Bracket-Traction Engage	69	252-103	2	Bearing-Closed
18	49-8461	1	Bracket-Guide Belt	*70	32151-57	1	Ring-Retaining
21	47-6730	2	Seal	71	39-6660	1	Pinion-bevel
23	60-8870	1	Yoke-Shift	72	47-2910	1	Washer-Thrust
24	29-9690	1	Washer-Flat	74	3257-1	2	Key-Woodruff
25	46-3560	1	Gear-52t	75	3256-45	1	Washer-Flat
26	36-4770	3	Spacer-Gear	*	74-1861	1	Gear Case Assembly Complete
27	29-9271	1	Gear-42t				
28	42-4740	1	Gear-38t				
29	55-8020	1	Retainer-Key				
30	29-9330	2	Key-Shift				
31	39-6720	1	Sleeve				
32	29-9340	1	Collar-Shift				
33	36-4780	3	Washer-Flat				
34	55-8010	1	Sleeve-Gear				

* Not illustrated




Sheet No.:400

Rear Wheel & Tire Assembly

Ref. No.	Part No.	Qty.	Description
1	53-7740	2	Tire-8.00
†2		2	ASM-Wheel & Tire
2:1	53-7780	2	Plate-Wheel Half
2:2	52-2410	2	Hub-Bearing Support
2:3	52-2450	4	Bearing-Wheel
2:4	52-2440	2	Spacer-Bearing
2:5	321-2	8	Screw-HH
2:6	3296-42	8	Nut-Lock
2:7	92-4957	2	ASM-Wheel Half & Gear

Ref. No.	Part No.	Qty.	Description

† Included in a service kit or in an assembly



★ **REQUIRES SPECIAL TOOLS
TO INSTALL. SEE REPAIR
INSTRUCTION MANUAL.**

Assemblies include all parts shown in frames.


ENGINE GTS-200

Ref. No.	Part No.	Description	No. Used
1	99-0900	Cylinder Assembly	1
2	99-0911	Bushing	1
★3	99-0912	Seal - Oil	1
8	77-9260	Breather Assy.	1
†★9	99-0913	Gasket - Breather	1
10	99-0914	Screw - Hex.	1
11	99-0915	Tube - Breather	1
★116	99-0916	Seal - O Ring	1
227	99-0917	Lever Assembly - Gov.	1
230	99-0918	Washer - Gov. Crank	1
306	99-0919	Shield - Cylinder	1
307	99-0920	Screw - Hex.	1

Ref. No.	Part No.	Description	No. Used
523	77-7260	Dipstick	1
525	99-0906	Tube - Oil Filler	1
562	99-0921	Screw - Hex.	1
584	99-0922	Baffle - Cylinder	1
★585	99-0923	Gasket - Breather	1
592	99-0924	Nut - Hex.	1
615	99-0925	Fastener	1
616	99-0926	Crank - Governor	1
663	99-0927	Screw - Hex.	1
718	99-0928	Dowel - Sleeve	1

★ Included in Gasket Set - Part No. 99-0902

† Included in Vavel Overhaul Gasket Set - Part No. 99-0904




Assemblies include all parts shown in frames.

ENGINE GTS-200

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
5	99-0929	Head – Cylinder	1	383	99-0944	Wrench – Spark Plug	1
†★7	99-0930	Gasket – Cylinder Head	1	635	77-9190	Elbow – Spark Plug	1
13	99-0931	Screw – Hex.	1	830	99-0945	Stud – Rocker Arm	1
33	99-0932	Valve – Exhaust	1	836	99-0941	Screw – Hex.	1
34	99-0933	Valve – Intake	1	†★868	99-0946	Seal – Valve	1
35	99-0934	Spring – Valve	1	†★883	99-0947	Gasket – Exhaust	1
40	99-0935	Retainer – Valve Spring	1	†★993	99-0948	Gasket – Plate	1
45	99-0936	Tappet – Valve	1	†★1022	99-0907	Gasket – Rocker Cover	1
155	99-0938	Plate – Cylinder Head	1	1023	98-9211	Cover – Rocker	1
189	99-0939	Ball – Rocker Arm	1	1026	99-0949	Rod – Push	1
238	99-0940	Cap – Valve	1	1029	99-0950	Arm – Rocker	1
305	99-0942	Screw – Hex.	1	1034	99-0951	Guide – Push Rod	1
337	99-0943	Plug – Spark	1				
354		Nut – Hex. (Sold in Kit Only).	1				

★ Included in Gasket Set – Part No. 99-0902

† Included in Vavel Overhaul Gasket Set – Part No. 99-0904



Assemblies include all parts shown in frames.

ENGINE GTS-200

Ref. No.	Part No.	Description	No. Used
4	99-0980	Sump - Engine	1
★12	99-0953	Gasket - Crankcase	1
15	99-0954	Plug - Oil Drain	1
16	98-9213	Crankshaft	1
17	99-1031	Bearing - Ball	1
★20	99-0955	Seal - Oil	1
22	99-0956	Screw - Hex.	1
		Note: 99-1040	
		Screw - Hex.	
		(One (1) Used in Hole Nearest Breather)	
24	99-0957	Key - Flywheel	1
25	99-0958	Piston Assy. (Standard)	1
26	99-0959	Ring Set (Standard)	1
27	99-0960	Lock - Piston Pin	1
28	99-0961	Pin - Piston (Standard)	1


Ref. No.	Part No.	Description	No. Used
29	99-0962	Rod - Connecting	1
32	99-0963	Screw - Connecting Rod	1
43	99-0937	Governor/Oil Slinger	1
46	99-0965	Gear - Cam	1
116A	99-1032	Seal - O-Ring	1
146	99-0966	Key - Timing	1
188	99-1033	Screw - Hex.	1
741	99-0967	Gear - Timing	1
965	99-1034	Cover - Oil Pump	1
978	99-1035	Gasket - Adapter	1
982	99-1036	Screw - Soc. Hd.	1
1024	99-1037	Pump - Oil	1
1027	98-9217	Filter - Oil	1
1028	99-1038	Adapter - Oil Filter	1
1055	99-1039	Tube - Oil Pump	1

★ Included in Gasket Set - Part No. 99-0902

ENGINE GTS-200

Ref. No.	Part No.	Description	No. Used
		(Sold in Kit Only).	1
130	99-0974	Valve - Throttle	1
131	99-0975	Shaft - Throttle	1
133	77-8170	Float - Carburetor	1
●134	77-8110	Valve - Needle	1
●◆137		Gasket - Bowl	
		(Sold in Kit Only).	1
●◆★163	99-0976	Gasket - Air Cleaner	1
●◆634		Washer - Foam	
		(Sold in Kit Only).	1
975	99-0977	Bowl - Float	1

- ★ Included in Gasket Set – Part No. 99–0902



Assemblies include all parts shown in frames.

ENGINE GTS-200





Ref. No.	Part No.	Description	No. Used
51	99-0968	Gasket - Intake	1
51A	99-0978	Gasket - Intake	1
161	99-0979	Base - Air Cleaner/Primer	1
◆◆★163	99-0976	Gasket - Air Cleaner	1
202	99-0981	Link - Governor	1
209	99-0982	Spring - Governor	1
259	99-0984	Grommet	1
445	98-9212	Filter - Air	1

Ref. No.	Part No.	Description	No. Used
467	98-9208	Knob	1
620	99-0908	Bracket - Control	1
621	99-0986	Switch - Stop	1
642	98-9207	Cover - Air Cleaner	1
967	98-0989	Filter - Air	1
971	99-0990	Screw - Hex.	1
976	99-0991	Primer - Carburetor	1

◆ Included in Carburetor Kit - Part No. 99-0901

◆◆ Included in Carburetor Gasket Set - Part No. 99-0903

★ Included in Gasket Set - Part No. 99-0902



Assemblies include all parts shown in frames.


ENGINE GTS—200

Ref. No.	Part No.	Description	No. Used
182	98—9205	Bracket — Tank Mounting	1
188A	98—9202	Screw — Hex.	1
300	99—0995	Muffler — Exhaust	1
305A	99—9204	Screw — Hex.	1
305B	99—0998	Screw — Hex.	1
346	99—1047	Screw — Hex.	1

Ref. No.	Part No.	Description	No. Used
346A	99—0999	Screw — Hex.	1
832	98—9206	Guard — Muffler	1
836	99—0941	Screw — Hex.	1
†★883	99—0947	Gasket — Exhaust	1
930	98—9203	Guard — Rewind	1

★ Included in Gasket Set — Part No. 99—0902

† Included in Vavel Overhaul Gasket Set — Part No. 99—0904




Assemblies include all parts shown in frames.

ENGINE GTS-200

Ref. No.	Part No.	Description	No. Used
23	99-1001	Flywheel	1
37	99-1013	Guard - Flywheel	1
65	99-1002	Screw - Hex.	1
304	99-1003	Housing - Blower	1
332	99-1004	Nut - Flywheel	1
333	99-1005	Armature - Magneto	1
334	99-1006	Screw - Hex.	1
356	99-1007	Wire - Stop	1

Ref. No.	Part No.	Description	No. Used
356A	99-0910	Wire - Stop	1
363	99-1008	Puller - Flywheel	1
373	99-1009	Nut - Hex.	1
455	99-1010	Cup - Flywheel	1
836	99-0941	Screw - Hex.	1
851	77-9450	Terminal - Cable	1
1005	99-1015	Fan - Flywheel	1
1036	99-1016	Label Kit - Emission	1







Assemblies include all parts shown in frames.

ENGINE GTS-200

Ref. No.	Part No.	Description	No. Used
55	99-1048	Housing - Rewind Starter	1
56	94-1657	Pulley - Starter	1
58	94-1668	Rope - Starter	1
59	77-7210	Insert - Starter Grip	1
60	77-8520	Grip - Starter Rope	1
65	99-1002	Screw - Hex.	1

Ref. No.	Part No.	Description	No. Used
373	99-1009	Nut - Hex.	1
456	94-1659	Retainer - Spring	1
459	94-1654	Pawl - Ratchet	1
461	94-1600	Screw - Shoulder	1
515	94-1655	Spring - Friction	1
608	98-9215	Starter - Rewind	1



Assemblies include all parts shown in frames.

ENGINE GTS-200

Ref. No.	Part No.	Description	No. Used
★3	99-0912	Seal – Oil	1
†★7	99-0930	Gasket – Cylinder Head	1
†★9	99-0913	Gasket – Breather	1
★12	99-0953	Gasket – Crankcase	1
★20	99-0955	Seal – Oil	1
●104	99-0970	Pin – Float Hinge	1
●◆110		Washer – Bowl (Sold in Kit Only).	1
★116	99-0916	Seal – O Ring	1
121	99-0901	Carburetor Kit	1
●127		Plug – Welch (Sold in Kit Only).	1
●134	77-8110	Valve – Needle	1
●◆137		Gasket – Bowl (Sold in Kit Only).	1

Ref. No.	Part No.	Description	No. Used
●◆★163	99-0976	Gasket – Air Cleaner	1
358	99-0902	Gasket Set	1
★585	99-0923	Gasket – Breather	1
●◆634		Washer – Foam (Sold in Kit Only).	1
†★868	99-0946	Seal – Valve	1
†★883	99-0947	Gasket – Exhaust	1
977	99-0903	Gasket Set – Carburetor	1
†★993	99-0948	Gasket – Plate	1
†★1022	99-0907	Gasket – Rocker Cover	1
1033	99-0904	Gasket Set – Valve Overhaul	1

★ Included in Gasket Set – Part No. 99-0902

◆ Included in Carburetor Gasket Set – Part No. 99-0903

† Included in Valve Overhaul Gasket Set – Part No. 99-0904

● Included in Carburetor Kit – Part No. 99-0901

Toro Part Number Index

Part No.	Page No.	Ref. No.	Qty.	Description
612066	7	13	2	Key—Pinion
3-3287	5	13	2	Spacer
3-7501	5	19	1	Washer—Curved
13-5149	8	9	1	Shaft—Input
13-9739	8	10	1	Upper Case Assembly
17-9427	6	19	1	Screw—Handle
25-7740	1	12	2	Knob—Arm
25-7740	7	18	2	Knob—Arm
27-6232	1	9	2	Bolt—Wheel HH
27-7210	5	14	2	Screw—Shoulder
29-9271	8	27	1	Gear—42t
29-9330	8	30	2	Key—Shift
29-9340	8	32	1	Collar—Shift
29-9570	8	39	1	Bushing—Yoke
29-9690	8	24	1	Washer—Flat
33-3208	1	18	1	Rod—Shield
33-4820	9	1	1	Hinge—Door
36-4770	8	26	3	Spacer—Gear
36-4780	8	33	3	Washer—Flat
36-4792	8	12	4	Washer—Thrust
36-6910	9	4	2	Spring
36-8070	7	1	1	"v" Belt
37-7260	1	22	2	Screw—TAP
39-6650	8	64	1	Gear—18t
39-6720	8	31	1	Sleeve
39-6740	8	15	1	Pulley
39-7842	8	68	1	Key—Square
39-9160	7	7	2	Pinion
39-9650	7	12	2	Spring
40-1940	1	3	4	Washer
42-0884	3	35	1	V Belt—Bbc
42-3190	3	12	2	Bolt—Blade
42-4020	9	5	1	Frame—Bag
42-4030	9	2	1	Frame—Bag
42-4740	8	28	1	Gear—38t
42-6890	3	14	1	ASM—Hub
43-8480	1	1:6	1	Decal—Danger
44-0580	1	17	1	Shield—Trailing
46-3540	8	66	1	Gear—12t
46-3550	8	65	1	Gear—14t
46-3560	8	25	1	Gear—52t
46-5631	3	37	2	Hub—Idler Pulley
46-5650	3	36	1	Pulley—Idler
46-5693	3	16	1	Shield—Bbc
46-6430	6	11	1	Screw—Handle
46-6810	1	39	1	Screw HWH
46-6811	1	14	1	Screw—HWH
46-7030	5	11	1	Retainer—Cable
46-7040	3	47	1	Screw—HWH
46-8081	5	17	1	Guide—Rope
46-8090	1	28	2	Screw—Tapping
46-8091	4	8	2	Screw—Tapping
47-2910	8	72	1	Washer—Thrust
47-6730	8	21	2	Seal
47-6730	7	16:5	2	Seal—Oil
47-7260	8	10:2	1	Seal
47-7270	8	10:1	2	Bearing—Needle
48-2060	7	16:3	2	Bearing—Needle
48-2060	8	3	2	Bearing—Needle
48-2170	7	4	2	Cap—End
48-2810	5	15	1	Rod—Support
48-2840	9	7	1	Door—Bag

*Not Illustrated

Toro Part Number Index (cont.)

Part No.	Page No.	Ref. No.	Qty.	Description
49-1631	6	18	1	Spacer—Support
49-2040	1	42	8	Screw—HH
49-2040	8	37	6	Screw—Self Tapping
49-2810	3	25	1	Link—Control
49-2820	3	28	1	Lever
49-7700	7	15	2	Washer—Thrust
49-7950	3	27	1	Sleeve—Bell Crank
49-7960	3	26	1	Bell Crank
49-7970	3	30	1	Spring—Torsion
49-8461	8	18	1	Bracket—Guide Belt
49-8740	1	19	1	Quadrant—Rear
49-8750	1	24	1	Quadrant—Rear
49-8760	1	13	1	Quadrant—Front
49-8770	2	43	1	Quadrant—Front
51-3210	4	3	2	Fuel Line
52-2450	10	2:3	4	Bearing—Wheel
52-2410	1	10:4	2	Hub—Bearing Support
52-2410	10	2:2	2	Hub—Bearing Support
52-2440	1	10:6	2	Spacer—Bearing
52-2440	10	2:4	2	Spacer—Bearing
52-2450	1	10:5	4	Ball Bearing
52-2450	7	16:2	2	Ball Bearing
52-2480	1	8	2	Spacer
52-2620	1	35	1	Label—Grease
52-3480	3	15	2	Damper—Vibration
53-7720	1	10	2	ASM—Wheel & Tire
53-7740	1	10:1	2	Tire—8.00
53-7740	10	1	2	Tire—8.00
53-7780	1	10:3	4	Plate—Wheel Half
53-7780	10	2:1	2	Plate—Wheel Half
53-7950	8	67	1	Shaft—Intermediate
54-9190	3	22	2	Nut—Lock
55-3570	4	2	1	Cap—Fuel
55-8010	8	34	1	Sleeve—Gear
55-8020	8	29	1	Retainer—Key
56-6160	3	11	1	Flywheel—Bbc
56-6170	3	13	1	Drum—Brake
56-6180	3	10	1	Pulley—Driver
60-8870	8	23	1	Yoke—Shift
61-8300	1	7	2	ASM—Arm
62-3830	7	6	2	Washer—Thrust
62-4280	3	17	1	Spacer—Blade
63-9060	6	17:4	1	Decal—Danger
65-5280	3	45	1	Retainer—Spring
66-0570	3	8	1	Guide—Belt
66-7560	1	5	2	ASM—Arm
66-7561	7	17	2	ASM—Arm
68-9780	3	32	2	Bearing
70-1160	3	31	1	Washer—Pm
71-9280	4	4	1	Filter—Fuel
71-9310	6	8	1	Spacer
71-9320	6	9	1	Spacer
71-9350	1	34	1	Spring—Bracket
74-1640	7	8	2	Cover—Wheel
74-1650	7	11	2	Spacer—Cover
74-1720	7	9	2	ASM—Wheel & Tire
74-1741	5	10	1	Bracket—Adjust
74-1750	8	17	1	Bracket—Traction Engage
74-1760	8	63	1	Gear—Bevel
74-1810	7	3	2	Washer—Thrust
74-1851	7	16	2	ASM—Arm
74-1860	1	20	1	ASM—Gearcase

*Not Illustrated

Toro Part Number Index (cont.)

Part No.	Page No.	Ref. No.	Qty.	Description
74-1861	8	*	1	Gear Case Assembly Complete
74-1890	8	8	1	Shaft-Output
74-1920	8	40	1	Case-Lower
74-1960	7	19	1	Lever-Shift
74-1970	5	20	1	Decal-Drive
76-4640	1	27:2	1	Latch Discharge Plug
76-4650	1	27:4	1	Grip Latch
76-4660	1	33	1	Spring-Extension
77-0500	1	27	1	ASM-Plug
80-2770	3	21	1	Cup-Anti Scalp
80-3770	1	32	1	Retainer-Door
82-9152	1	36	1	Chute-Discharge
84-4960	3	4	1	Decal-Proline
84-8361	5	6	1	Latch-Handle
84-8401	5	21	1	Latch-Handle
84-8870	3	48	1	Guide-Spring
84-8880	3	49	1	Bracket-Spring
84-8930	2	48	2	Retainer-Shield
84-8930	4	9	1	Retainer-Shield
84-8990	6	24	1	Bbc Lever
84-9000	6	21	1	Traction Lever
84-9030	6	26	1	Spacer-Control Bracket
84-9040	3	50	1	Pin-Cable
84-9040	6	25	1	Pin-Cable
84-9050	3	44	1	Pin-Spring Guide
84-9100	3	46	1	Spring-Bbc
84-9110	6	6	1	Cable-Clutch
84-9120	6	5	1	Cable-Traction
84-9130	3	34	1	Brake Plate
84-9170	4	5	1	Wa-Base
84-9180	3	42	1	Brake Plate ASM
85-6720	6	17:3	1	Decal-Proline Panel
85-6750	6	2	1	Spring-Control
85-6880	3	33	1	Spring-Torsion
86-9320	6	20	1	Bushing-Nylon
91-2255	3	20	1	Stiffener-Blade
91-2256	3	19	1	Blade-Generation li
92-1720	1	1:3	1	Kicker-RH
92-1730	1	1:4	1	Kicker-LH
92-1750	1	1:2	1	Plate-Kicker Rear
92-1778	6	15	1	Bracket-Control
92-4957	10	2:7	2	ASM-Wheel Half & Gear
92-6316	7	16:7	2	Fitting-Grease
92-7988	2	46	1	Decal-Recycler
93-3154	1	29	1	Plate-Latch
93-3166	4	1	1	Tank-Gas
93-7351	1	30	1	ASM-Door
93-8470	3	5	1	Screw-Clamp
98-2002	3	3	1	Decal-Engine
98-2003	6	17:1	1	Decal-Panel
98-2005	6	4	1	Control-Throttle
98-2047	6	13	1	Cable-Throttle
98-2385	5	1	1	Handle
98-3214	1	21	1	Cover-Belt
98-4995	6	1	1	Control Bar W.a.
98-7146	1	1	1	Housing-Commercial(Mach)
98-9220	9	0	1	Grass Bag-Proline
98-9222	9	6	1	Bag-Grass
98-9227	2	50	1	Guard-Primer
98-9245	6	17	1	Panel-Control
98-9246	3	1	1	Engine Gts 200 Bbc Pro
2210-249	3	6	1	Clamp-Casing

*Not Illustrated

Toro Part Number Index (cont.)

Part No.	Page No.	Ref. No.	Qty.	Description
2210-316	3	2	1	Rope-Stop
2412-95	4	6	4	Clamp
252-103	8	69	2	Bearing-Closed
257-3	1	6	2	Washer-Thrust
302-63	8	9:1	1	Fitting-Grease
321-2	1	10:7	8	Screw-HH
321-2	10	2:5	8	Screw-HH
321-7	1	26	2	Screw-Cap
321-9	5	18	1	Screw-HH
322-6	3	38	1	Screw-HH
322-6	5	9	2	Screw-HH
322-7	5	7	2	Screw-HH
322-19	6	10	1	Screw-Hex
323-6	2	47	2	Screw-HH
323-7	4	7	2	Screw-HH
323-12	1	11	2	Screw
323-13	7	10	2	Screw-HH
3250-14	6	3	4	Screw
3256-22	1	25	2	Washer-Flat
3256-23	3	24	1	Washer-Flat
3256-45	8	75	1	Washer-Flat
3257-1	8	74	2	Key-Woodruff
3257-17	3	9	1	Key-Woodruff
3272-1	3	43	2	Pin-Cotter
3272-1	6	22	1	Pin-Cotter
3285-19	8	35	1	Pin-Groove
3290-378	5	2	1	Tie-Cable
3290-378	6	12	1	Tie-Cable
3290-422	9	3	2	Nut-Push
3290-456	5	5	4	Washer-Lock
3295-35	1	27:3	1	Rivet Solid
3296-2	6	7	4	Nut-Lock
3296-5	8	16	1	Nut-Lock
3296-6	1	2	2	Nut-Lock
3296-29	5	4	4	Nut-Lock
3296-29	6	14	1	Nut-Lock
3296-33	3	18	1	Nut-Lock
3296-39	2	49	2	Nut-Lock
3296-42	1	10:8	8	Nut-Lock
3296-42	1	23	2	Nut-Lock
3296-42	5	16	1	Nut-Lock
3296-42	6	16	1	Nut-Lock
3296-42	10	2:6	8	Nut-Lock
3296-47	3	39	1	Nut-Lock
3296-47	5	23	2	Nut-Lock
3296-58	6	23	1	Nut-Flange
32104-76	6	31	6	Screw-Self TAP
32104-96	3	29	1	Screw-HHST
32104-107	3	23	1	Screw-HH
32111-7	5	3	2	Nut-Cap
32121-99	7	20	1	Pin-Roll
32144-70	3	41	2	Screw-TAP
32144-70	5	22	1	Screw-TAP
32144-102	3	7	3	Screw
32144-111	1	1:5	6	Screw - PPH
32151-36	7	2	2	Ring-Retaining Ext
32151-57	8	70	1	Ring-Retaining
32151-68	7	14	4	Ring-Klip
32151-86	6	27	1	Ring-E
32152-2	1	4	2	Nut-Lock HH
32152-2	7	5	2	Nut-Lock HH

*Not Illustrated

[illegible]

MAINTENANCE RECORD

[illegible]