



Count on it.

Parts Catalog

Cab Kit

**Serial Number 315000001 and After
Groundsmaster® 4500/4700-D or
Reelmaster® 7000-D Traction Unit**

Model No. 30901—Serial No. 400000000 and Up



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Frame, Seal and Mirror Assembly 4

Frame Mount Assembly 6

Windshield Wiper and Condenser Core Assembly 8

Air Conditioning Duct Assembly No. 132-3468 10

Wire Harness Assembly 12

Door and Window Assembly 14

RH Door Assembly 16

LH Door Assembly 18

Rear Window Assembly 20

Washer Bottle, Air-Conditioner Hose and Heater Hose Assembly 22

Pre-Filter Screen Assembly 24

Mixing Box and Vent Hose Assembly 26

Headliner Wire Harness and Control Assembly 28

Mixing Box Mounting Bracket and Water Tray Assembly 30

Blower Fan and Evaporator Core Assembly 32


Heat / Air Conditioner Housing Assembly 34

Air Diverter and Expansion Valve Assembly 36

Air Diverter Assembly No. 121-8369 38

Attachments and Accessories 40

Frame, Seal and Mirror Assembly




Frame, Seal and Mirror Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
2	121-8275	2	Arm-Mirror, Side
3	121-8341	2	Side Mirror ASM
3:1		1	Mirror-Glass ●
3:2		1	Gasket ●
4	33103-016	4	Screw-HHF
5	121-8343	1	Interior Mirror ASM
5:1		1	Mirror ●
5:2		1	Gasket ●
6	32144-32	2	Screw-PPH
7	130-0611	3	Decal-Window, Pin
8	130-0594	1	Decal-Warning
9	130-5355	1	Decal-Window, Hood
10	130-0586	1	Seal-Foam, Frame Roof
11	130-0587	2	Seal-Foam, Roof Air Filter
12	130-0390	1	Seal-Foam, Front Center
13	130-0394	1	Seal-Foam, Front Left
14	130-0395	1	Seal-Foam, Front Right
15	130-0396	1	Seal-Foam, Left

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
16	130-0397	1	Seal-Foam, Right
17	130-0398	1	Foam-Tank, RH
18	130-0391	1	Foam-Tank, LH
19	130-0542	1	Panel-Sealing, RH
20	130-0543	1	Panel-Sealing, LH
21	130-0353	1	Foam-Mount, RH
22	130-0354	1	Foam-Mount, LH
23	130-0546	1	Foam-Rear
24	107069	4	Clip
25	32105-15	6	Screw-HWH
26	104-7201	2	Nut-HF, NI
27	130-5855	2	Seal-Tube, Rear
32	132-3253	1	Decal-Service, Seat
36	133-0982	2	Tube-Seal, Front
37	136-1768-03	1	Shelf-Mount, Fan
38	3230-18	4	Screw-CARR
39	104-8300	4	Nut-HF, NI

● Not serviced separately


Frame Mount Assembly



Frame Mount Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	130-0330-03	1	RH Rear Mount ASM	13	132-3255-03	1	Bracket-Step
2	130-0331-03	1	LH Rear Mount ASM	14	132-3256	1	Pad-Adhesive
3	110-5954	4	Mount-Center, Bonded	15	107069	2	Clip
4	115-5519	4	Washer-Plain	16	3256-1	2	Washer-Flat
5	112-7264	4	Screw-HH	17	3274-69	2	Screw-HSBH
6	99-5107	4	Nut-Lock	18	132-3254	1	Tread-Floor
7	3256-6	2	Washer-Flat	19	132-3261	1	Panel-Upholstery, Rear
8	130-0379-03	1	RH Front Mount ASM	20	132-3265	1	Blanket-Insulation
9	130-0380-03	1	LH Front Mount ASM	21	325-20	4	Screw-HH
10	323-6	7	Screw-HH	22	32128-49	4	Nut-HHF
11	104-8301	5	Nut-HF, NI	23	3234-38	8	Screw-HHF
12	3296-39	2	Nut-Lock, NI				

Windshield Wiper and Condenser Core Assembly




Windshield Wiper and Condenser Core Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
3	132-3468	1	A/C Duct ASM	19	106-8737	2	Nut-Retainer
4	132-3488	1	Panel-Fan	20	130-5871	1	Bracket-Wiper
4:1	132-3486-03	1	Plate-Mount, Fan	21	125-7452	1	Wiper Motor ASM
4:2	132-3607	2	Fan-Condenser	21:2	3253-3	1	Washer-Lock
4:3	132-3606	8	Tab-Fan	21:3	33113-025	1	Screw-HH
4:4	105-6849	8	Screw-Forming, Thread	21:4	112-2844	2	Nut-HF
5		1	Screen ASM ●	22	125-7453	1	Arm-Wiper
5:1	132-3530-03	1	Screen	23	125-7454	1	Blade-Wiper
5:4	74-5950	4	Latch-Swell	23:1	47-2830	2	Screw
6	132-3531-03	1	Seal-Front	23:2	43-5920	2	Washer-Lock, Spring
7	132-3532-03	1	Seal-Rear	24	120-4654	16	Screw-HHF
8	132-3533-03	1	Seal-Side, Left	25	32105-15	4	Screw-HWH
9	132-3534-03	1	Seal-Side, Right	26	32144-11	3	Screw-HWH
10	104-7201	8	Nut-HF, NI	27	130-6068-03	1	Plate-Washer, Wiper Motor
11	121-8457	2	Filter-Air	28	117-5976	2	Knob-Handle
12	107069	2	Clip	29	130-5661	2	Tube-Sleeve
13	126-5846	2	Knob-T	30	363-8245	8	Screw-TAP
14	125-9825-03	2	Cover-Air, Fresh	31	132-3608	2	Seal-Edge
15	3230-9	4	Screw-CARR	32	132-3609	2	Seal-Strip
16	3230-22	13	Screw-CARR	33	130-5854	2	Brace-Seal
17	3256-3	17	Washer-Flat	34	3229-30	4	Screw-CARR
18	104-8300	21	Nut-HF, NI				

● Not serviced separately





Air Conditioning Duct Assembly No. 132-3468



Air Conditioning Duct Assembly No. 132-3468 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	121-8447	1	Core-Condenser	7	132-3465-03	1	Wall-Side, Left
2	132-3469-03	2	Leg-Lower	8	132-3466	2	Seal-Strip
3	32128-44	6	Nut	9	132-3467	2	Seal-Edge
4	132-3462-03	1	Wall-Front	10	363-8245	12	Screw-TAP
5	132-3463-03	1	Wall-Back	11	107069	16	Clip
6	132-3464-03	1	Wall-Side, Right				


Wire Harness Assembly



Wire Harness Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	122-0667	1	Harness-Wire
2	3334-945	5	Tie-Cable

Door and Window Assembly




Door and Window Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	130-6193	1	Front-Lower Window ASM	21	125-9793	2	Link-Window
1:2	130-0329	1	Seal-Trim	22	125-9987	2	Mount-Latch
2	130-5680	1	Upper Front Window ASM	23	119-9812	2	Bolt-Shoulder
2:2	121-8212	1	Seal-Trim	24	104-7201	2	Nut-HF, NI
4	130-5676	1	RH-Side Window ASM	25	130-0590	2	Mount-Tab
4:2	121-8215	1	Seal-Trim	26	1-807513	4	Bolt-CARR
5	130-5677	1	LH-Side Window ASM	27	120-9681	8	Nut-Lock, NI
5:2	121-8215	1	Seal-Trim	28	3274-59	2	Screw-HSH
6	130-6191	1	RH Forward Window ASM	29	3274-14	2	Screw-HSH
6:2	130-0357	1	Seal-Trim	30	127-9850	2	Pin-Release, Quick
7	130-6192	1	LH Forward Window ASM	31	132-3718	2	Stud-Striker
7:2	130-0357	1	Seal-Trim	32	125-9992	2	Adjuster-Stud
8		1	RH Door ASM ■	33	121-8393	2	Guard-Striker
9		1	LH Door ASM ■	34	106-0327	2	Nut-Hex
10	121-8441	6	Washer-Spacer	35	73-0040	4	Washer-Thrust
11	121-8535-03	2	Hinge-Window	36	130-6083	2	Spring-Gas, Door
12	125-9982	35	Bushing-Flange	37	98-3104	2	Stud-Ball
13	127-9933	2	Plate-Backer, Windshield	38	130-5725	4	Spacer
14	104-8300	31	Nut-HF, NI	39	125-7977	4	Screw-HSBH
15	125-9520	4	Screw-Shoulder, HSH	40	130-5726	2	Lanyard
16	125-9521	19	Screw-Shldr HSH	41	120-9471	2	Bolt-Shoulder
17	125-9537	23	Bushing-Flange	42	130-5578	1	Tubing-Seal, Rubber
18	125-9676	2	Washer-Backup	43	133-1110	1	Pin-Hinge ●
19	130-5815	23	Washer-Backup	44	121-8439	1	Receiver-Pivot, Hinge ●
20	125-9792	2	Handle-Window	45	121-8440	1	Pivot-Hinge ●

● Not illustrated

■ Not serviced separately


RH Door Assembly



RH Door Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	130-6188	1	RH Door ASM	12	121-8630	1	Handle ASM
1:2	130-0362	1	Trim-Door	12:2	121-8628	1	Cylinder-Mounting, Key
2	125-9982	20	Bushing-Flange	12:3	121-8322	1	Grommet-Mounting, Large
3	121-8331	1	Gasket-Handle	12:4	121-8327	1	Washer
4	130-0367-03	1	Frame-Door, RH	12:5	121-8328	1	Nut
5	125-9618-03	2	Hinge-Door, RH	12:6	121-8627	1	Cylinder-Mounting, End
6	125-9520	10	Screw-Shoulder, HSH	12:7	121-8323	1	Grommet-Mounting, Small
7	104-8300	12	Nut-HF, NI	12:8	125-9531	1	Key-Set
8	125-9676	6	Washer-Backup	13	33103-025	1	Screw-HHF
9	98-3104	1	Stud-Ball	14	121-8395	1	Plate-Support, Latch
10	120-9471	1	Bolt-Shoulder	15	3234-21	2	Screw-HHF
11	121-8390	1	Latch-RH	16	104-7201	2	Nut-HF, NI


LH Door Assembly



LH Door Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	130-6189	1	LH Door ASM	12	121-8630	1	Handle ASM
1:2	130-0362	1	Trim-Door	12:2	121-8628	1	Cylinder-Mounting, Key
2	125-9982	20	Bushing-Flange	12:3	121-8322	1	Grommet-Mounting, Large
3	121-8331	1	Gasket-Handle	12:4	121-8327	1	Washer
4	130-0368-03	1	Frame-Door, LH	12:5	121-8328	1	Nut
5	125-9619-03	2	Hinge-Door, LH	12:6	121-8627	1	Cylinder-Mounting, End
6	125-9520	10	Screw-Shoulder, HSH	12:7	121-8323	1	Grommet-Mounting, Small
7	104-8300	12	Nut-HF, NI	12:8	125-9531	1	Key-Set
8	125-9676	6	Washer-Backup	13	33103-025	1	Screw-HHF
9	98-3104	1	Stud-Ball	14	121-8395	1	Plate-Support, Latch
10	120-9471	1	Bolt-Shoulder	15	3234-21	2	Screw-HHF
11	121-8391	1	Latch-LH	16	104-7201	2	Nut-HF, NI


Rear Window Assembly



Rear Window Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	130-5682	1	Rear Window ASM	11	125-9676	2	Washer-Backup
1:2	130-0637	1	Seal-Trim	12	119-9812	2	Bolt-Shoulder
2	125-9982	12	Bushing-Flange	13	125-9987	2	Mount-Latch
3	121-8535-03	2	Hinge-Window	14	104-7201	2	Nut-HF, NI
4	125-9520	4	Screw-Shoulder, HSH	15	125-9792	2	Handle-Window
5	127-9933	2	Plate-Backer, Windshield	16	127-9850	2	Pin-Release, Quick
6	104-8300	4	Nut-HF, NI	17	125-9793	2	Link-Window
7	121-8441	2	Washer-Spacer	18	3274-59	2	Screw-HSH
8	130-0590	2	Mount-Tab	19	3274-14	2	Screw-HSH
9	1-807513	4	Bolt-CARR	20	120-0250	1	Decal-Warning
10	120-9681	8	Nut-Lock, NI	21	130-5578	1	Tubing-Seal, Rubber


Washer Bottle, Air-Conditioner Hose and Heater Hose Assembly



Washer Bottle, Air-Conditioner Hose and Heater Hose Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	120-4947	1	Valve-Heater	8:2:2	117-2780	1	O-Ring
2	130-0578	2	Fitting-Barb, 90 DEG	8:2:3	117-2784	1	Cap-Side, Low
3	2412-129	6	Clamp-Hose	8:3	130-5754	1	Fitting-Male, 45 DEG
4	125-9702	1	Hose ASM	8:3:1	130-5775	1	Fitting Kit
4:2	130-5753	1	Fitting-45 DEG	8:3:2	117-2780	1	O-Ring
4:2:1	130-5772	1	Fitting Kit	8:4	130-5959	1	Cover-Foam
4:2:2	117-2778	1	O-Ring	8:5	3290-378	16	Tie-Cable
4:3	130-5751	1	Fitting-Female, 90 DEG	9	125-9865	2	Hose-Drain
4:3:1	130-5772	1	Fitting Kit	10	125-9866	2	Hose-Drain
4:3:2	117-2778	1	O-Ring	11	127-9901	1	Hose-Washer Fluid
4:4	130-5958	1	Cover-Foam	12	2412-39	2	Clamp-R
4:5	3290-378	8	Tie-Cable	15	127-9905	1	Fitting-Hose, Barb
5	125-9703	1	Hose ASM	16	117-2779	1	O-Ring
5:2	130-5751	2	Fitting-Female, 90 DEG	17	117-2780	1	O-Ring
5:2:1	130-5772	1	Fitting Kit	18	125-5257	1	Tank-Fluid, Washer
5:2:2	117-2778	1	O-Ring	18:1	125-5258	1	Lid-Tank, Washer Fluid
5:3	130-5958	1	Cover-Foam	19	132-3268-03	1	Mount-Washer Bottle
5:4	3290-378	8	Tie-Cable	20	132-3269-03	1	Plate-Bottle
6	125-9706	1	Hose-Heater	21	3230-23	4	Bolt-CARR
7	132-3333	1	Hose ASM	22	104-8300	4	Nut-HF, NI
7:2	130-5752	1	Fitting-Female, 90 DEG	23	2412-74	1	R-Clamp
7:2:1	130-5773	1	Fitting Kit	24	74-5950	1	Latch-Swell
7:2:2	117-2778	1	O-Ring	25	119-0129	1	Fitting-Elbow, 90 DEG
7:3	130-5757	1	Fitting-Straight, Female	26	119-0128	1	Fitting-Elbow, 90 DEG
7:3:1	130-5773	1	Fitting Kit	27	117-9410	2	Fitting-Straight
7:3:2	117-2779	1	O-Ring	28	132-3347	2	Hose-Heater
7:3:3	117-2783	1	Cap-Side, High	29	2412-73	1	Clamp-R
8	125-9862	1	Hose ASM	34	133-1025	1	Wrap-Abrasion
8:2	130-5755	1	Fitting-Female, Straight	35	94-3890	2	Tie-Cable
8:2:1	130-5775	1	Fitting Kit				


Pre-Filter Screen Assembly



Pre-Filter Screen Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	130-0640-03	1	Screen	7	112-3169	4	Screw-HHF, Serrated
2	130-0642-03	2	Backplate	8	3296-54	4	Nut-Lock
3	65-5100	2	Handle-Door	9	132-3630-03	1	Screen-Mount, Front
4	46-8092	4	Screw-Plastite	10	136-2171	2	Mount-Latch
5	130-0643	2	Latch-Push To Close	11	32104-82	7	Screw-HHF
6	130-5875	1	Pre-Filter				

Mixing Box and Vent Hose Assembly




Mixing Box and Vent Hose Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	121-8470	1	Headliner	22	130-5927	2	Adapter-Bleed
2	121-8495	1	Box-Mixing, Heater A/C	23		1	Roof ASM ●
3	130-0558	3	Backplate-Rivet	23:1	132-3602	1	Roof
4	130-5938	2	Tube-Support	23:2	130-5961	4	Seal-Corner
5	104-7201	24	Nut-HF, NI	23:3	130-5960	2	Seal-Side
6	130-5860	2	Hose-Vent	23:4	130-5962	2	Seal-Front, Rear
7	130-0455	2	Louver-Round, Snap-In	24	119-3301	22	Bolt-Pivot, Eccentric
8	125-7503	20	Rivet-Pop	25	130-5939	4	Tube-Support
9	130-0465	3	Louver-Round, Snap-In (4 Inch)	27	130-5999	1	Drier-Receiver
10	121-8473	2	Hose-Intake, Fresh Air	29	3334-945	2	Tie-Cable
11	130-5861	1	Hose-Vent, Outer (LH)	30	3274-69	2	Screw-HSBH
12	121-8477	1	Hose-Vent, Defrost (LH)	31	3256-1	2	Washer-Flat
13	130-0437	1	Hose-Vent, Center	33	119-4501	1	Switch-Function, Dual
14	121-8478	1	Hose-Vent, Defrost (RH)	34	46-6560	1	Bushing
15	130-5862	1	Hose-Vent, Outer (RH)	35	104-5228	1	Fitting-Elbow, 90 DEG
16	2412-110	11	Clamp-Band/Screw	36	130-0445	4	Backplate-Rivet
17	107069	2	Clip	37	130-0444	1	Foam-Inlet, Airbox
18	125-9532	1	Filter-Cab, Inside	38	2412-130	2	Clamp-Hose
19	125-9604-03	1	Plate-Cover, Recirculation	39	132-3474	2	Insert-Seal, Filter
20	125-7438	2	Knob-Screw, Thumb	40	132-1461-03	2	Strap-Cab, Side
21	106-8737	2	Nut-Retainer	41	132-1462-03	2	Strap-Cab
				42	3256-74	22	Washer-Flat

● Not serviced separately


Headliner Wire Harness and Control Assembly



Headliner Wire Harness and Control Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	122-0723	1	Harness-Wire, Headliner	16:1	3254-20	1	Washer-Lock, Int
1:8	109355	2	Fuse-Blade, 15 Amp	16:2	3220-4	1	Nut-Jam
1:9	109103	1	Fuse-Blade, 30 Amp	17	122-0150	1	Switch, Rotary
1:14	109101	1	Fuse-Blade, 20 Amp	18	125-9510	3	Knob-Control
1:15	109102	1	Fuse-Blade, 25 Amp	19	99-7420	6	Plug-Hole
2	125-9606-03	1	Bracket-Fuse Block	20	95-8999	1	Switch-Rocker, On-None-On
3	104-2408	22	Screw-HSBH	21	125-9691-03	1	Panel-Switch, Lights
4	120-4578	29	Nut-HF	22	125-9688	1	Decal-Washer
5	99-7430	1	Relay-Mini	23	119-8355	1	Switch-Rocker
6	130-0588	1	Nut-Switch	24	125-7437	1	Light-Dome
7	42863	1	Strip-Jumper	25	130-5867	2	Cover-Light, Rear
8	42862	1	Block-Terminal, Ground	26	3229-34	8	Screw-CARR
9	32105-13	3	Screw-HWH	27	3256-14	14	Washer-Flat
10	107-1013	4	Nut-Speed	28	132-3600	1	Decal-Panel, Fuse
11	609900	2	Nut-Speed	30	130-0436	3	Panel-Switch
12	125-9603-03	1	Plate-Cover, Fuse	31	92-9698	4	Screw-Shoulder
13	125-7438	2	Knob-Screw, Thumb	32	94-8196	4	Washer-Nylon
14	106-8737	2	Nut-Retainer	33	3256-2	4	Washer-Flat
15	121-8481	1	Panel-Air/Heat	34	104-7201	4	Nut-HF, NI
15:2	121-8378	1	Decal, Air/Heat	35	130-5868	2	Cover-Light, Front
16	125-9677	1	Control-Rotary, Linear				


Mixing Box Mounting Bracket and Water Tray Assembly



Mixing Box Mounting Bracket and Water Tray Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	130-5655-03	1	Bracket-Mount	5	130-5653	1	Gasket-Mount, LH Bracket
2	130-5659	1	Seal-Foam	6	130-5654	1	Gasket-Mount, RH Bracket
3	130-5808	2	Seal-Foam, Front	7	130-5660	1	Tray-Water
4	130-0602	2	Seal-End				

Blower Fan and Evaporator Core Assembly




Blower Fan and Evaporator Core Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	130-5392	1	Core-Evaporator
2	130-5658	4	Gasket-Coil
3	130-5807	1	Foam
4	130-5806	2	Tape, Double-Sided
5	127-9915	1	Core-Heater
6	121-8451	1	Fan-Blower

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
7	363-8245	13	Screw-TAP
8	130-5656-03	1	Cover, Bracket-Mount
9	130-5652	1	Gasket-Mount, Cover Bracket
10	121-8385	1	Thermostat-Switch, Freeze


Heat / Air Conditioner Housing Assembly



Heat / Air Conditioner Housing Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	130-5830	1	Housing-Heat/AC	8	125-7504	1	Plate-Backer, Center
2	121-8491	1	Plate-Support	9	130-0554	1	Bracket-Airbox, Center
3	3229-11	12	Screw-CARR	10	130-5601	2	Drain-Lower
4	121-8490	1	Bracket-Mount, Drier	11	108-0342	2	Fitting-Straight
5	104-7201	12	Nut-HF, NI	12	121-6840	4	Washer-Rubber
6	130-5834	2	Bracket-Support	13	107-3041	2	Washer-Flat
7	130-5821	2	Bracket-Airbox, Side	14	130-0293	2	Drain-Upper


Air Diverter and Expansion Valve Assembly



Air Diverter and Expansion Valve Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	121-8369	1	Air Diverter ASM	7	125-9524	2	O-Ring
2	3229-11	2	Screw-CARR	8	121-8384	1	Valve-Expansion
3	121-8491	1	Plate-Support	10	125-9622	19	Rivet-Blind
4	104-7201	2	Nut-HF, NI	11	122-0153	1	Harness-Wire, Heat/AC Blower
5	125-7528	1	Grommet-Cable	12	121-8449	1	Housing-Ventilation, Upper
6	125-9678	1	Control-Rotary, Linear	13	130-5614	1	Insulation-Cover
6:1	3254-20	1	Washer-Lock, Int				
6:2	3220-4	1	Nut-Jam				

Air Diverter Assembly No. 121-8369



Air Diverter Assembly No. 121-8369 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	125-9697	1	Base-Mount	8	121-8256	1	Clamp-Conduit
2	121-8381	1	Shaft-Baffle, RH	9	108-2992	4	Pin-Hair
3	121-8382	1	Shaft-Baffle, LH	10	1-807513	2	Bolt-CARR
4	125-9698	2	Baffle-Air	11	120-4578	3	Nut-HF
5	3256-51	4	Washer-Flat	12	115-9830	1	Screw-HSBH
6	125-9696	1	Link-Baffle	13	3290-271	4	Rivet-Pop
7	121-8374	1	Mount-Cable	14	125-9699	4	Damper-Foam

Attachments and Accessories

For 30901 Cab Kit Serial Number 315000001 and After Groundsmaster 4500/4700-D or Reelmaster 7000-D Traction Unit

Product Name	Model/Part
Work Light Kit	114-5610
Exterior Mirror Kit.....	130-5448
Interior Mirror Kit.....	130-5449
Window Guard Kit, 2015 and After Reelmaster 7000-D Traction Unit with Cab	132-3295
Cab A/C Kit (Yanmar)	30877
Beacon Kit, 2015 and After Groundsmaster Series Traction Unit	31509
CE Light Kit, Groundsmaster 4500-D, 4700-D or Reelmaster 7000-D Traction Unit	31573
LED Work Light Kit, 2015 and After Cab and 2 Post ROPS Extension Kit.....	31596

Notes:

Notes:

Notes:



Count on it.