

TORO


MODEL NO. 41514-30101 & UP

OPERATOR'S
MANUAL**MULTI-PRO 5200
VEHICLE**

To assure maximum safety, optimum performance, and to gain knowledge of the product, it is essential that you or any other operator of this Vehicle read and understand the contents of this manual before the engine is ever started. Pay particular attention to the **SAFETY INSTRUCTIONS** highlighted by this symbol —



The safety alert symbol means **CAUTION**, **WARNING** or **DANGER** — personal safety instruction. Failure to comply with the instruction may result in personal injury.




IDENTIFICATION NUMBERS


MULTI-PRO 5200 VEHICLE

MODEL NO. 41514-30101 & UP

VEHICLE
SERIAL NUMBER _____



ENGINE MODEL: VSG4131 6005 A
SERIAL NUMBER _____




Record these numbers in the space above as soon as possible as it is necessary to include this information when ordering service parts or requesting information. Fill out the individual warranty cards and mail immediately.

Date Purchased.....

This vehicle is not a motor vehicle as defined by the National Traffic Motor Vehicle Safety Act. It is not designed or manufactured for use on roads, streets or highways and is not to be licensed as a motor vehicle.

Be sure to record the key code number which is stamped on your Ignition Keys. If original Keys are lost, duplicates can be made, but it will be necessary to provide the key code numbers. Contact any "All Lock" dealer or locksmith to duplicate your specific key. The key code number is also engraved on the body of the Ignition Switch.

KEY CODE NUMBER



KEY CODE NUMBER _____

safety

RECOGNIZE SAFETY INFORMATION



This safety-alert symbol is used to call attention to a dangerous situation, which could result in serious injury or death to the operator, a passenger or a bystander.

Follow recommended precautions and safe operating practices.

It is important to always replace any lost or damaged safety-alert and informational decals on the vehicle and accessories immediately.

UNDERSTAND SIGNAL WORDS

Be aware of the symbols and signal words used throughout this manual.

A signal word—DANGER, WARNING, or CAUTION—is used with the safety-alert symbol. DANGER identifies the most serious hazards.

Safety signs with signal word DANGER or WARNING are typically near specific hazards.

General precautions are listed on CAUTION safety signs. CAUTION also calls attention to safety messages in this manual.

Instructions beginning with the signal words “IMPORTANT” or “NOTE”, provide essential information regarding the operation and maintenance of this machine.

FOLLOW SAFETY INSTRUCTIONS

Read this manual and the engine manual BEFORE attempting to operate the vehicle. It is important that ALL operators of this vehicle have easy access to these instructions and safety information at all times. Keep this manual, the engine manual and any accessory manuals, in the plastic tube behind the operator seat when not in use.

Carefully read all safety messages in this manual and on your machine safety signs. Keep safety signs in good condition. Replace missing or damaged safety signs.

Learn how to operate the machine and how to use controls properly. Do not let anyone operate without instruction.

Keep your machine in proper working condition. Unauthorized modifications to the machine may impair the function and/or safety and affect machine life.

Read the engine manufacturer's operating instructions. Make note of the safety-alert messages and follow them.




DANGER

WARNING

CAUTION

IMPORTANT!

NOTE:



OPERATE SAFELY

This manual is provided as a guide in the safe operation and proper maintenance of this vehicle. However, the operator's personal safety, as well as those persons in the work area, will depend on the careful actions and good judgement of the operator.

DO NOT operate the vehicle in or near any area where there are explosive fumes or dust. This vehicle's electrical and exhaust systems will make sparks . . . which can ignite explosive fumes or dust!



This vehicle is designed to carry the OPERATOR and ONE PASSENGER ONLY. DO NOT permit any other person on this vehicle. DO NOT allow any passenger to ride anywhere other than the seat provided by the manufacturer. Make sure the passenger uses the hand holds provided.

DRIVE SAFELY

Always SLOW the vehicle when approaching, and while making, a turn.


Always SLOW the vehicle when driving in unfamiliar areas or over rough terrain.

Always SLOW the vehicle when changing the direction of travel or preparing to stop.

DO NOT make sudden or sharp turns or change direction of travel, on an incline, ramp, grade, slope or similar surface.

Adjust the vehicle speed to allow for existing conditions such as wet, slick surfaces, low visibility, etc.

Drive the vehicle UP and DOWN the face of the slopes, inclines or grades whenever possible. DO NOT drive ACROSS the face if at all possible. There is a risk of upsetting the vehicle, which can result in serious injury or death.



Be especially careful when driving a heavily loaded vehicle down an incline or slope. SLOW the vehicle with the Vehicle Drive Control Foot Pedal. In case of the need for an emergency stop, use the foot brake.

Keep both hands on the steering wheel whenever possible. Keep all body parts within the vehicle while it is moving. Arms and legs sticking out past the vehicle sides could be seriously injured by nearby objects being passed.

PREVENT MACHINE RUNAWAY

Avoid possible injury or death from machinery runaway.

Do not start engine by shorting across starter terminals. Machine will start in gear if normal circuitry is bypassed.

NEVER start engine while standing on ground. Start engine only from operator's seat, with transmission in neutral or park




AVOID TIPPING

Do not drive where machine could slip or tip.

Stay alert for holes, rocks, and roots in the terrain, and other hidden hazards. Keep away from drop-offs.

Slow down before you make a sharp turn.

The center of gravity is higher when sprayer tank or hopper is full, and vehicle can tip at any speed.



PROTECT BYSTANDERS

DO NOT operate near bystanders, ramp edges, platforms or other equipment. Watch for overhead obstacles, low hanging tree limbs, door jambs, etc.


Be aware of your surroundings, bystanders and other equipment. Always back the vehicle carefully and only at a reasonable speed. ALWAYS look to be sure there is no one behind you!

PARK SAFELY

Disengage all power, shut off engine, and be sure all moving parts have stopped before servicing, lubricating, or unclogging machine.

Always stop engine and remove key before leaving operator's seat. Do not leave engine running unattended.

Park vehicle with park brake engaged.



HANDLE FUEL SAFELY—AVOID FIRES

Handle fuel with care: it is highly flammable. Do not refuel the machine while smoking or when near open flame or sparks.

Always stop engine before refueling machine. Fill fuel tank outdoors.


Prevent fires by keeping machine clean of accumulated trash, grease, and debris. Always clean up spilled fuel.



AVOID INJURY FROM MOVING PARTS

Keep hands, feet, and clothing away from power-driven parts.

Never clean, lubricate or adjust machine while it is running.



STAY CLEAR OF ROTATING DRIVELINES

Entanglement in rotating driveline can cause serious injury or death.

Keep tractor master shield and driveline shields in place at all times. Make sure rotating shields turn freely.

Wear close fitting clothing. Stop the engine and be sure PTO driveline is stopped before making adjustments, connections, or cleaning out PTO driven equipment.



AVOID HIGH-PRESSURE FLUIDS

Escaping fluid under pressure can penetrate the skin causing serious injury. Relieve pressure before unhooking hydraulic or other lines. Tighten all connections before applying pressure. Keep hands and body away from pinholes and nozzles which eject fluids under high pressure. Use a piece of cardboard to search for leaks.

If ANY fluid is injected into the skin, it must be surgically removed within a few hours by a doctor familiar with this type of injury or gangrene may result.



PREPARE FOR EMERGENCIES

Be prepared if a fire starts.

Keep a first aid kit and fire extinguishers handy.

Keep emergency numbers for doctors, ambulance service, hospital, and fire department near your telephone.



PRACTICE SAFE MAINTENANCE

Understand service procedure before doing work. Keep area clean and dry.

Never lubricate or service machine while it is moving. Keep hands, feet, and clothing from power-driven parts. Disengage all power and operate controls to relieve pressure. Lower equipment to the ground. Stop the engine. Remove the key. Allow machine to cool.

Securely support any machine elements that must be raised for service work.

Keep all parts in good condition and properly installed. Fix damage immediately. Replace worn or broken parts. Remove any buildup of grease, oil, or debris.

Disconnect battery ground cable (—) before making adjustments on electrical systems or welding on machine.

Remove all traces of fertilizer from cavities and tubes before any type welding takes place.

Always use the hydraulic lock when servicing vehicle with utility bed raised.



INSPECT MACHINE SAFELY

Always check all parts of the vehicle and any attachments before actual use. If there is a problem, make sure it is corrected BEFORE the unit is put in operation.

Foam marker tank is under pressure. Shut off compressor and put control handles in the open position while servicing the foam marker tank.

Shields and guards must be in place and in good condition before starting.

Keep nuts, bolts, and all connections tight. Replace worn parts.



SERVICE TIRES SAFELY

Failure to follow proper procedures when mounting a tire on a wheel or rim can produce an explosion which may result in serious injury or death. Do not attempt to mount a tire unless you have the proper equipment and experience to perform the job. Have it done by your distributor or a qualified tire repair service.

When sealing tire beads on rims, never exceed 35 psi (241 kPa) (2.4 bar) or maximum inflation pressures specified by tire manufacturers for mounting tires. Inflation beyond this maximum pressure may break the bead, or even the rim, with dangerous explosive force. If both beads are not seated when the maximum recommended pressure is reached, deflate, reposition tire, relubricate bead, and reinflate.




WEAR PROTECTIVE CLOTHING

Wear close fitting clothing and safety equipment appropriate to the job.


Prolonged exposure to loud noise can cause impairment or loss of hearing.

Wear a suitable hearing protective device such as earmuffs or earplugs to protect against objectionable or uncomfortable loud noises.



BATTERY PRECAUTIONS

Batteries generate explosive gases. Keep sparks, flames, burning cigarettes, or other ignition sources away at all times. Always wear safety goggles when working near batteries.



PREVENT BATTERY EXPLOSIONS

Battery gas can explode. Keep sparks and flames away from batteries. Use a flashlight to check battery electrolyte level.

Never check battery charge by placing a metal object across the posts. Use a voltmeter or hydrometer.

Always remove grounded (-) battery clamp first and replace it last.



AVOID ACID BURNS

Sulfuric acid in battery electrolyte is poisonous. It is strong enough to burn skin, eat holes in clothing, and cause blindness if splashed into eyes.

Avoid the hazard by:


1. Filling batteries in a well-ventilated area.
2. Wearing eye protection and rubber gloves.
3. Avoiding breathing fumes when electrolyte is added.
4. Avoiding spilling or dripping electrolyte.

If you spill acid on yourself:

1. Flush your skin with water.
2. Apply baking soda or lime to help neutralize the acid.
3. Flush your eyes with water for 10-15 minutes. Get medical attention immediately.

If acid is swallowed:

1. Drink large amounts of water or milk.
2. Then drink milk of magnesia, beaten eggs, or vegetable oil.
3. Get medical attention immediately.



AVOID TOXIC FUMES

Some chemicals are toxic and, in sufficient quantities, may be fatal. Ill effects or death does not have to be from direct contact.

Wear a filtered respirator. Wear goggles to protect your eyes.

Keep dust away from skin and hair.

Keep containers low when pouring.

Let the wind blow fumes away from you when mixing or filling.

Use chemicals only in applications for which they are recommended.

Clean equipment in a recommended manner.



HANDLE CHEMICALS SAFELY

Chemicals can be dangerous. Improper selection or use can injure persons, animals, plants, soils or other property.

Select the right chemical for the job.

Handle and apply chemicals with care.

Follow instructions issued by chemical manufacturer.

Study all labels carefully. DO NOT remove labels.

Wear goggles to protect your eyes.

Wash exposed skin areas frequently—do not leave chemicals on your skin.

Do not smoke while handling chemicals.

Properly dispose of chemical containers, unused chemicals and left-over treated seed and fertilizer.

Read and observe manufacturer's recommendations.

Remove clothing and bathe skin immediately if chemicals contact skin. Launder contaminated clothing.

Wash hands before eating.

Apply chemicals at recommended time, rate, and manner. Do not allow chemicals to drift to neighboring areas.

See a physician immediately if symptoms of illness occur during or shortly after the use of any chemicals.




Store chemicals in a separate, plainly marked, LOCKED building.

Store chemicals in original containers with labels intact.

Federal and state laws govern the use of chemicals. Before using any chemical, consult state agricultural agent or chemical supplier for proper uses.

See a physician or druggist for first aid kits and learn how to use them.



INSTALLING AND USING ATTACHMENTS:

Always read the operating instructions that are included with the accessories BEFORE actually operating the unit. Carefully read and follow any "set-up" instructions that are given.

The installation of accessories on the TORO vehicle other than those designed and sold for that express purpose by TORO may adversely affect the performance and safety characteristics of this vehicle.

The addition of accessories, with their added weight and bulk will make the vehicle somewhat less stable. When turning or driving on slopes, always SLOW the vehicle before making a turn, and then SLOWLY turn the vehicle to prevent loss of control and possibly upset the vehicle.

DO NOT OVERLOAD THE VEHICLE. Maximum load limits are shown on decals used on all accessories . . . do not exceed these limits.

Failure to position loads carefully can result in their shifting or tipping over suddenly, causing the vehicle to upset.

Distribute loads evenly, keeping them low so as to prevent the vehicle from becoming top-heavy. When loading the cargo bed, have heavy loads to the front of the rear axle. Heavy loads in back of the rear axle can raise the front wheels clear of the ground, causing a loss of steering control and making the vehicle unstable.



Keep all Decals in good condition. Replace missing or damaged Decals as soon as possible.

CAUTION



• TO AVOID PERSONAL INJURY KEEP ALL SHIELDS IN PLACE.
• DISENGAGE AND SHUT OFF ENGINE BEFORE SERVICING OR UNBLOCKING MACHINE
• KEEP HANDS, FEET AND CLOTHING AWAY FROM POWER-DRIVEN PARTS.

#87-0450 Located on top of Engine Cover.



READ YOUR OPERATOR'S MANUAL FOR OPERATING AND SAFETY INSTRUCTIONS. TO GET A REPLACEMENT MANUAL SEND MODEL AND SERIAL NUMBERS TO: THE TORO CO. 611 LYNDALE AVE. S. MPLS. MN 55420

65-3090

#65-3090 Located on left-hand side of Dash Panel.



FAILURE TO OBEY THE SAFETY WARNINGS MAY RESULT IN INJURY TO YOU OR OTHERS.

THIS VEHICLE IS OF SUFFICIENT SIZE AND WEIGHT TO CAUSE SERIOUS INJURY IN CASE OF UPSET OR COLLISION.

WHILE OPERATING VEHICLE:

- READ AND UNDERSTAND OPERATOR'S MANUAL LOCATED BEHIND SEAT.
- DO NOT EXCEED PAYLOAD CAPACITY OF VEHICLE AND/OR TORO ACCESSORIES OR PERMIT PASSENGER ANY PLACE ON VEHICLE EXCEPT SEAT.
- USE HAND HELDS WHERE APPLICABLE.
- PLACE HEAVY LOADS FORWARD OF REAR AXLE. UNBALANCED OR TOP HEAVY LOADS CAN CAUSE UPSET.

WHILE OPERATING VEHICLE:

- REMAIN SEATED AND USE BOTH HANDS FOR STEERING.
- KEEP ARMS AND LEGS WITHIN VEHICLE BODY.
- AVOID SUDDEN STARTS AND STOPS.
- SUDDEN SHARP TURNS CAN CAUSE UPSET.
- REGULATE SPEED TO MEET ROAD AND WEATHER CONDITIONS.
- DO NOT OPERATE IN OR NEAR AN EXPLOSIVE ENVIRONMENT.
- IF A MALFUNCTION OCCURS, CEASE OPERATION. DO NOT OPERATE VEHICLE UNTIL CONDITION IS CORRECTED.

BEFORE LEAVING VEHICLE:

- TURN IGNITION TO "OFF" POSITION, REMOVE KEY.
- APPLY PARKING BRAKE. PARKING BRAKE IS NOT AUTOMATICALLY APPLIED.

87-0580

#87-0580 Located on right-hand side of Dash Panel.

IMPORTANT

HYDRAULIC FLUID ONLY
USE 10W40 MOTOR OIL
WHICH MEETS API SERVICES
SG, SF/CD SPECIFICATIONS.

#87-0500 Located on top of Hydraulic Tank.



FAST
SLOW
THROTTLE

#87-0640 Located on front of Seat Support, next to Throttle Control.



GAS
ONLY

#71-3730 Located on top of Gasoline Tank.

TRACTION PEDAL

FORWARD



REVERSE

VEHICLE SPEED
INCREASES
WITH MORE PEDAL
PRESSURE.

#92-0479 Located left-hand side of Speed Controls.



(P) PARKING BRAKE

1. DEPRESS BRAKE PEDAL
2. PULL LEVER TO LOCK

67-0530

#87-0530 Located on Dash Panel next to Brake Lock.



#41176 Located on Dash Panel next to Key Switch.



#41174 Located next to Directional Control Valve.

SPEED CONTROL

INDICATOR

INSTRUCTIONS

TO ENGAGE
1. FLIP TOGGLE SWITCH "ON"
2. OBTAIN DESIRED SPEED WITH FOOT
PEDAL
3. PUSH "GET" BUTTON TO LOCK SPEED

ON

OFF

TO DISENGAGE
1. FLIP TOGGLE SWITCH TO "OFF"
OR
2. FOR EMERGENCY STOP ACTIVATE BRAKE

CAUTION

TO AVOID ABRUPT STOP, PLACE
FOOT ON TRACTION PEDAL BEFORE
TURNING TOGGLE SWITCH OFF

SET

#92-0480 Located right-hand side of Speed Controls.

WARNING

AVOID POSSIBLE INJURY OR DEATH FROM
A MACHINE RUNAWAY.

1. Do not start engine by shorting across
starter terminals. Machine will start in
gear and move if normal starting circuitry
is bypassed.
2. Start engine only from operator's seat
with transmission in
neutral or park. NEVER start engine
while standing on
ground.

67-0430

#87-0430 Located on left-hand side of
Seat Support.

pre-USE service

IMPORTANT: THE BATTERY ON THIS VEHICLE MUST BE BROUGHT TO A FULL CHARGE PRIOR TO CONNECTING THE BATTERY CABLES AND OPERATION OF THE VEHICLE



CAUTION: Batteries contain sulfuric acid . . . avoid contact with skin, eyes, or clothing. Batteries produce explosive gas when being charged. Ventilate area when charging battery. Keep cigarettes, open flame and sparks away from battery at all times. Keep batteries and acid out of reach of children. Remove all jewelry when working on battery.

After bringing the battery to a full charge:

- Connect the positive (+) cable first, and cover the terminal with the rubber protective cap.
- **ALWAYS** connect the negative (−) cable last.

ELECTRICAL SYSTEM:

DO NOT connect the battery cables until all wiring harness connections have been made and properly tightened.

If accidentally grounded, the lead to the battery terminal will burn the wiring harness.



When removing battery from equipment, always disconnect the negative (−) (ground) cable first.

When replacing battery, connect the negative (−) (ground) cable last.

Disconnect battery before any welding by removing negative (−) (ground) cable first.

IMPORTANT!

When towing or otherwise attempting to move the MULTI-PRO 5200 without engine power, it is necessary to engage the Tow Valve on the left side of the Piston Pump. Failure to do so will result in damage to the hydrostatic Piston Motor. See FIG. 10, Page 18.

IMPORTANT!

Spark arrestors are required by California Public Resources Code, Sections 4428-4422, when operating any internal combustion engine on hydrocarbon fuels, on forest, brush or grass-covered lands.

VEHICLE GAUGES AND CONTROLS

Familiarize yourself with the controls and recommended operating procedures before operating the MULTI-PRO. These procedures will help to maintain the efficient performance this machine was designed to deliver.

VEHICLE DRIVE CONTROL FOOT PEDAL:

Controls the direction and ground speed of the MULTI-PRO 5200. Applying pressure with the toe on the top of the pedal, away from the operator, will move the vehicle forward (SEE FIG. 1). Depressing the pedal further forward, increases the speed of the forward motion. Applying pressure with the toe at the bottom or "tail" of the pedal (SEE FIG. 2), towards the operator, will move the vehicle backward.

The Drive Control Foot Pedal provides positive braking action. The vehicle speed decreases as the foot pedal is moved towards the NEUTRAL or "CENTER" position. With the foot pedal "CENTERED", the vehicle stops.

Any movement of the Drive Control Foot Pedal whether to slow, speed-up, or stop the MULTI-PRO, should be in a slow and steady motion. It is recommended that the operator become familiar with the action and feel of the foot pedal before operating the vehicle.

CAUTION!!

WHEN THE MULTI-PRO 5200 IS IN MOTION, REMOVAL OF THE OPERATOR'S FOOT FROM THE FOOT PEDAL WILL RESULT IN AN ABRUPT STOP OF THE VEHICLE DUE TO THE HYDROSTATIC BRAKING ACTION OF THE VEHICLE.

SPEED CONTROL: When activated, it locks the foot pedal at a desired location that allows the MULTI-PRO to be driven at a constant ground speed.




FIG. 1

1. Foot Pedal




FIG. 2

PARKING/EMERGENCY BRAKE: Functions as a parking brake and as an emergency brake in situations demanding an immediate stop.

When starting the engine or parking on hills or slopes...

1. Fully depress the Brake Pedal and pull up on the Brake Lock to lock the Brake Pedal in position.
2. After engine has started, fully depress the Brake Pedal again to release the Brake Pedal Lock.

To stop the Vehicle in an emergency (such as a person or another vehicle crossing your path, or a loss of hydraulic power) depress the Brake Pedal until the Vehicle comes to a stop. **DO NOT USE THE BRAKE PEDAL TO STOP THE VEHICLE ON A ROUTINE BASIS! USE THE VEHICLE DRIVE CONTROL PEDAL FOR NORMAL OPERATING STOPS.**

CONTROLS

BRAKE LOCK: Locks the Brake Pedal in a depressed position for starting the engine or to act as a Parking Brake. Depress the Brake Pedal and lift the Knob to lock. Depress the Brake Pedal again and the Brake Lock is disengaged to release the Brake Pedal.

HOUR METER: Records the number of hours that the engine has been operated. To be used as an aid in scheduling equipment maintenance.

VOLTMETER: Indicates the battery voltage when the ignition key is in the ON position. After the engine is started, the pointer will move into the white marked area, and in normal operation, remain there. (12.8-14.8 volts) If the pointer remains in either red marked area, have the engine's electrical system checked.

COOLANT TEMPERATURE GAUGE:

Indicates the temperature of the engine coolant when the ignition switch is in the ON or ACC position. The pointer will move to the NORMAL band as the engine warms up. When operating in hot weather or with very heavy loads, the pointer may read at the very top of the NORMAL band. If the pointer moves out of the NORMAL band into the H (hot) position, the engine is over heating and engine damage may result. Idle the engine for 2 minutes, turn off the engine and let it cool. See the engine manual, pages 8 and 21.

ENGINE WARNING LIGHT: Indicates dangerously low oil pressure. If light comes on with the engine running, STOP as soon as possible and correct the cause of low oil pressure before re-starting the engine.




FIG. 3

1. Speed Control Set Button	6. Parking/Emergency Brake
2. Speed Control Toggle Switch	7. Coolant Temperature Gauge
3. Voltmeter	8. Ignition Switch
4. Hour Meter	9. Brake Lock
5. Engine Warning Light	

VEHICLE OPERATION

IMPORTANT!
SEE THE FORD ENGINE MANUAL FOR
"INITIAL START-UP" PROCEDURES, (PAGE
18)

**ALWAYS CHECK THE OIL AND COOLANT
LEVELS BEFORE STARTING THE ENGINE.**
Make sure the engine is stopped and the
engine is parked on a level surface. Allow time
for the engine to cool and oil to drain into the
sump.

NOTE: Turn the ignition switch to the ON
position to make sure the warning light is
operating before starting the engine.

STARTING THE ENGINE:

CAUTION!

Start the engine ONLY outdoors or in a
well ventilated area. Exhaust fumes are
very dangerous.

NOTE: It is recommended that the Parking/
Emergency Brake be fully depressed and
locked in place before starting the MULTI-PRO
vehicle. As a safety feature the MULTI-PRO
5200 is designed so that the engine cannot be
started until the transmission is in NEUTRAL.

CAUTION!

If the engine WILL start or the vehicle
creeps when the foot pedal is NOT IN
THE NEUTRAL POSITION...DO NOT
OPERATE THE VEHICLE! Immediately
check the foot Pedal/Transmission
Neutral Adjustments as detailed in the
ADJUSTMENT SECTION of this manual.

1. Move the Throttle Lever to midway between "SLOW" and "FAST" positions.
2. Pull the Choke out to full choke position, if cold starting engine.
3. Turn the Ignition Key to the full right (START POSITION). Release the Key as soon as the engine starts.




FIG. 4

1. Throttle
2. Choke

IMPORTANT!

DO NOT HOLD the Key in the start
position longer than 15 seconds at one
time. If the engine fails to start, wait at
least 2 minutes before attempting to
start again.

4. Gradually push the Choke Control in to the "OFF" position as the engine starts and warms up.
5. Position the Throttle Lever at the desired engine speed.

With the operator's foot positioned on the foot
pedal as shown (SEE FIG. 1, PAGE 10), slowly
apply pressure with the toe on top of the
pedal, away from the operator, to move the
MULTI-PRO in a **forward** direction.

With the operator's foot positioned on the foot
pedal as shown (SEE FIG. 2, PAGE 10), slowly
apply pressure with the toe at the bottom or
"tail" of the pedal to move the MULTI-PRO in a
backwards or **reverse** direction.

VEHICLE OPERATION

CAUTION!

BE ESPECIALLY CAREFUL WHEN DRIVING IN REVERSE!

Slowly moving the foot pedal to the "NEUTRAL" or "CENTERED" position will allow the vehicle to stop.

When changing directions of travel or making momentary stops, slowly move the foot pedal towards NEUTRAL to decrease vehicle speed. When stopping on a hillside or slope, always use the Parking Brake to prevent the vehicle from "creeping".

The foot pedal should always operate freely and return positively to the NEUTRAL or "CENTERED" position when the operator's foot is removed from the foot pedal. IF NOT, DO NOT OPERATE THE VEHICLE, see the Foot Pedal and Linkage Maintenance steps in the ADJUSTMENT SECTION of this manual.

Slowly applying further pressure to the top or bottom of the foot pedal will increase the speed of the forward or reverse motion.

CAUTION!

WHEN THE MULTI-PRO 5200 IS IN MOTION, REMOVAL OF THE OPERATOR'S FOOT FROM THE FOOT PEDAL WILL RESULT IN AN ABRUPT STOP OF THE VEHICLE DUE TO THE HYDROSTATIC BRAKING ACTION OF THE VEHICLE.

SPEED CONTROL OPERATION:

NOTE: The Speed Control can be engaged with the MULTI-PRO in operation and when the accessories are in use.

1. Flip the toggle switch to the "ON" position to enable the Speed Control.
2. Depress the foot pedal forward until the vehicle reaches the desired speed of operation.

3. Depress the "SET" button to lock "ON" the Speed Control.

To disengage the Speed Control, the brake must be depressed or the toggle switch must be turned to the "OFF" position.

When the Speed Control is disengaged with the **foot brake**, the operator MUST depress the "SET" button to re-lock "ON" the Speed Control.

When the Speed Control is disengaged with the **toggle switch**, the operator MUST flip the toggle switch to the "ON" position and depress the "SET" button to lock "ON" the Speed Control.

CAUTION!

TO AVOID ABRUPT STOP, PLACE FOOT ON TRACTION PEDAL BEFORE TURNING TOGGLE SWITCH OFF.

STOPPING THE ENGINE:

NOTE: If the engine has been running under high power, let it run at fast idle speed a few minutes to cool the engine down, before turning the ignition switch to OFF position.

NOTE: Do not pull out on Choke to "prime" the engine for the next start. Raw gasoline will wash oil from the cylinder walls and cause engine damage when engine is re-started without proper lubrication.

1. Move the Throttle Lever to "SLOW" and turn Ignition Key to "OFF".
2. Remove the Ignition Key and engage the Emergency/Parking Brake.

CAUTION!

NEVER leave the Vehicle unattended with the engine running. **ALWAYS** bring the Vehicle to a full stop, engage the Emergency/Parking Brake and lock it, turn the Ignition Switch to OFF and remove the key.

—NOTES—

maintenance schedule

The Maintenance Schedule in this Manual specifies maintenance and lubrication periods based on normal operating conditions. Check and service the MULTI-PRO and its attachments more frequently when operating in extremely cold, hot or dusty conditions.

For additional engine maintenance information, see the FORD Engine Manual. Use a high quality, anti-knock 87 (minimum) octane gasoline.

	HOURS OF OPERATION									
	daily	50	100	200	300	400	500	600	700	800
Replace Hydraulic Filter AFTER FIRST FIVE HOURS										
Check Engine Oil Level	X									
Check/Clean Air Cleaner	X									
Check Engine Coolant Level	X									
Check for Fuel, Oil and Coolant Leaks	X									
Check Tire Pressures	X									
Check Hydraulic Fluid Level	X									
Replace Hydraulic Filter AFTER FIRST FIFTY HOURS		X			X				X	
Check Differential Oil Level		X	X	X	X	X	X	X	X	X
Replace Air Filter Element			X	X	X	X	X	X	X	X
Change Engine Oil and Filter			X	X	X	X	X	X	X	X
Check Battery Charge & Level			X	X	X	X	X	X	X	X
Check Governor Oil Level			X	X	X	X	X	X	X	X
Clean Crankcase Breather Cap			X	X	X	X	X	X	X	X
Inspect and Clean Radiator Exterior				X		X		X		X
Clean Battery Terminals					X		X		X	X
Check and Adjust Tension of Fan, Alternator & Governor Belts.					X		X		X	X
Lubricate Throttle, Governor and Choke Linkage.					X		X		X	X
Replace Fuel Filter						X				X
Check or Refill Radiator						X				X
Check and Adjust Idle Speed and Idle Mixture						X				X
Clean, Adjust and Test or Replace Spark Plugs						X				X
Check and Adjust Valve Clearance							X			X
Replace PCV Valve										X
Adjust Throttle and Governor										X
Replace Coolant										X
Torque Intake Manifold Bolts										X
Check Tightness of All Bolts and Nuts										X

MAINTENANCE

CAUTION! Disengage all power, shut off the engine and be sure all moving parts have stopped BEFORE servicing, lubricating or unclogging this machine.

ENGINE CRANKCASE OIL & FILTER:

IMPORTANT!

SEE THE FORD ENGINE MANUAL FOR "INITIAL START-UP" PROCEDURES, (PAGE 18)

Check the oil level daily, before engine start-up, while engine is cool. Have the machine on a level surface with the engine OFF. Maintain the oil level between the minimum and maximum marks on the dipstick. Do not operate the engine with the oil level below the bottom mark. Never add oil above the top mark.

IMPORTANT!

SEE THE FORD ENGINE MANUAL FOR DETAILED INSTRUCTIONS REGARDING MAINTENANCE, LUBRICATION AND ADJUSTMENTS OF THE ENGINE.

AIR CLEANER:

Service daily if engine is operated in very dusty and dry conditions. Extensive damage can result from operating with a dirty Air Cleaner.

- Squeeze the Vacuator Valve to eject dust and water.

After every 100 hours, more often under extremely dusty conditions,

- Loosen the Air Cleaner Strap and remove the Dust Cup.
- Remove the dirty element and discard.
- Wipe out the inside of the Air Cleaner housing with a damp rag. Check body and sealing surfaces for damage or build-up that may cause contaminant to leak into the Air Cleaner.
- Inspect the new element for any shipping damage. Install the new element and secure the Air Cleaner Strap.
- Check all ducting, piping hoses and clamp connections for leaks.




FIG. 5




FIG. 6

CAUTION! The engine and exhaust system can be extremely hot. Do not operate with any shrouds, covers or guards removed.

MAINTENANCE

HYDRAULIC RESERVOIR:

IMPORTANT

ALWAYS use extreme caution when filling the Reservoir or checking the level of the hydraulic oil, to keep the system free of contaminants.

Check the hydraulic fluid level daily and maintain at approximately 2 inches from the top. Replenish as required with 10W40 Motor Oil.

To fill and check the hydraulic system:

- Fill the hydraulic tank.
- Start the engine.
- Turn the Steering Wheel full left, then full right.
- Turn off the engine and recheck level of hydraulic fluid. Replenish as required.

HYDRAULIC SYSTEM FILTER:

IMPORTANT

Keeping the hydraulic system clean is essential. Servicing the Hydraulic Filter is critical to the life of the hydraulic system.

This unit is equipped with a "throw-away" type cartridge.

- CHANGE THE CARTRIDGE AFTER THE FIRST FIVE HOURS OF OPERATION.
- CHANGE THE CARTRIDGE AGAIN AFTER THE FIRST FIFTY HOURS OF OPERATION.
- CHANGE THE CARTRIDGE EVERY 300 HOURS THEREAFTER.

OIL COOLER:

Check frequently and keep free of any accumulation of dirt and debris.

COOLING SYSTEM:

Check the coolant level in the radiator daily, but ONLY WHEN THE ENGINE IS COOL.

CAUTION: NEVER remove the radiator cap, under any conditions, while the engine is operating. Use extreme care when removing the cap from a hot radiator...scalding hot coolant or steam can blow out of the radiator, causing serious injury! NEVER add coolant to an engine that has become overheated, until the engine has cooled.

Use a permanent-type coolant that meets Ford Specification ESE-M97B44-A. Maintain the coolant level at approximately 3/4 to 1-1/2 inches below the filler neck seat on the radiator, when the coolant is cold.




FIG. 7

NOTE: The Hydraulic Reservoir's fill-tube and cap are fitted with lugs which, with the addition of a lock, will help prevent the contamination of the hydraulic fluid.




FIG. 8

The cooling system has a total capacity of 12 qts. (11.5 liters). A 50/50 mix of 6 qts. (5.75 liters) of anti-freeze to 6 qts. (5.75 liters) of water is recommended.

RADIATOR:

While checking coolant level, check condition of radiator cap rubber seal and the filler neck. Make sure both are kept clean.


Every 200 hours (more often in dusty areas) inspect the exterior for obstructions. Remove all bugs, dirt or foreign material with a soft brush or cloth. Use care not to damage the fins. If available, use low pressure air or a stream of water in the opposite direction to normal air flow.

MAINTENANCE

DIFFERENTIAL

The Differential has a capacity of 6 U.S. pints (2.81 l). Check the oil level after first 50 hours of operation and every 100 hours thereafter.

To check the oil level remove the pipe plug from the rear of the Differential housing. If oil does not run out, replenish with a high quality SAE 85-140 gear oil at temperatures above 32°F. Add oil until it begins to drip from hole where plug was removed.



TIRE PRESSURE:

Check the tires frequently and maintain the pressures at:

FRONT TIRES: 20 p.s.i. (max.)

REAR TIRES: 20 p.s.i. (max.)

Tire pressure is a matter of individual preference and Vehicle load. Once the desired pressure has been ascertained, it should be used as a factor in the computer programming and maintained, to insure the accuracy of the spraying system.

WHEEL TORQUE SPECIFICATIONS

After the "initial run-in" (approximately one to two hours) check all the fasteners for tightness. Particularly the Front and Rear Wheels. Check periodically thereafter and maintain the wheel nuts at:



FRONT WHEELS: 55-65 ft. lbs. (75-88 N-m)

REAR WHEELS: 75-85 ft. lbs. (102-116 N-m)

AFTER EVERY 50 HOURS:

Use a hand grease gun with a good grade of general purpose grease to lubricate through grease fittings at the

- COMPANION FLANGE
- UNIVERSAL JOINT
- FRONT AXLE SPINDLES (2)
- LINKAGE CONTROL ARMS (FIG. 11, PAGE 21)



ADJUSTMENTS

CAUTION! Disengage all power, shut off the engine and be sure all moving parts have stopped BEFORE servicing, lubricating or unclogging this machine.

IMPORTANT!

SEE THE FORD ENGINE MANUAL FOR DETAILED INSTRUCTIONS REGARDING ANY NECESSARY ENGINE ADJUSTMENTS.

TOW VALVE:

When towing or otherwise attempting to move the MULTI-PRO 5200 without engine power, it is necessary to engage the Tow Valve located on the left side of the Piston Pump. Failure to do so will result in damage to the hydrostatic Piston Motor.

To engage the Tow Valve, turn the Valve so that the "flats" are at 90 degrees to the normal operating position in FIG. 9




FIG. 9

1. Tow Valve

DRIVE BELTS:

Any belt that has operated for a minimum of 10 minutes is considered a used belt, and when adjusted, it must be adjusted to the reset tension shown in the specifications, shown in the Ford Engine Manual, page 36.

DO NOT pry against the armatures steel counter-section (stator), the rear housing, or the through bolts when adjusting drive belt tension. Always place the pry bar against the front housing.

ADJUSTMENTS

VEHICLE DRIVE CONTROL FOOT PEDAL:

CAUTION!

These adjustments are very important! They are critical for the safety of the operator and the performance of the vehicle!

VEHICLE DRIVE CONTROL FOOT PEDAL LINKAGE MAINTENANCE: It is very important that the foot pedal operate freely and return positively to the NEUTRAL or "CENTERED" position. Periodic maintenance of the foot pedal requires applying grease to the grease fittings on the linkage control arms as shown in FIG. 11.

VEHICLE DRIVE CONTROL FOOT PEDAL LINKAGE TROUBLESHOOTING:

If the foot pedal fails to operate smoothly and freely, or fails to return to the NEUTRAL or "CENTERED" position, the following steps should be checked and corrected if required: (See Fig. 10)

1. Check that the foot pedal pivot tube is free on the pivot pin.
2. Check that the control linkage front and rear ball joints move freely.
3. Check that no cables, wiring harnesses, etc. are restricting or interfering with the linkage travel.
4. Check that the linkage centering arms are pivoting freely.
5. Check that both centering springs are in their proper position.
6. Check that the control plate is rotating freely.
7. Check that speed control clutch plate is operating freely.

VEHICLE DRIVE CONTROL FOOT PEDAL/TRANSMISSION NEUTRAL ADJUSTMENT:

CAUTION!

This adjustment is very important! It is critical for the safety of the operator and the performance of the vehicle!

The foot pedal and transmission adjustments are factory pre-set to assure the transmission is in the NEUTRAL or "CENTERED" position. If the MULTI-PRO vehicle should experience "creep" when the foot pedal is in the NEUTRAL or "CENTERED" position, adjust as follows:

1. Have the MULTI-PRO on a hard level surface and the engine off.
2. Depress and lock the Parking/Emergency Brake pedal.
3. Raise the rear wheels clear of the ground surface and support with jackstands. BLOCK the front wheels to prevent the vehicle from rolling forward.
4. Remove the control linkage from the control plate at the rod end and pull away from the control plate.
5. Pull both control arms away from the control plate bearings (SEE FIG. 11). When the control plate is adjusted correctly, the control plate WILL NOT rotate when the control arms are pulled away.
6. If control plate IS NOT adjusted correctly, proceed to STEP 8.
7. If control plate IS adjusted correctly, proceed to STEP 9.
8. To adjust the control plate, loosen the 2 control plate mount bolts, so it allows the control plate to center itself and allows the servo control arm to move independently as shown in FIG. 11.

ADJUSTMENTS

VEHICLE DRIVE CONTROL FOOT PEDAL/TRANSMISSION NEUTRAL ADJUST. (Cont.)

Retighten the 2 control plate mount bolts and verify the proper adjustment by pulling both control arms away from the control plate bearings. The control plate SHOULD NOT ROTATE! After proper adjustment proceed to STEP 11.

9. Make a chalk mark on the servo adjusting screw to use as reference point.

10. Loosen the jam nut on the servo adjusting screw. (SEE FIG. 11.) Release the brake pedal, start the engine, and turn the servo adjusting screw CCW (Counter Clockwise) until the rear wheels begin to move. Make a chalk mark on the servo housing next to the servo screw mark to show this location. (SEE FIG. 11.) Rotate the servo adjusting screw CW (Clockwise) until the rear wheels begin to rotate in the opposite direction. Make a chalk mark on the servo housing next to the servo screw mark to show this location. Turn the servo adjusting screw to midway between these two marks and retighten the jam nut. After proper adjustment, proceed to STEP 11.

11. Reattach the control linkage to the control plate.

TO TEST THE ADJUSTMENT:

1. Lower the vehicle from the jackstands.
2. Start the engine and release the Parking/Emergency Brake pedal.
3. Verify the proper adjustment. The vehicle SHOULD NOT experience any "creep".

If "creep" is still present, recheck the control plate adjustment and the servo adjustment. (REFER TO STEPS 1-10)




FIG. 11

1. Servo Adj. Screw	4. Control Arm
2. Jam Nut	5. Control Plate
3. Servo Arm	6. Control Plate Bolt




FIG. 10

1. Pivot Pin	3. Clutch Plate	5. Centering Arms	7. Ball Joint
2. Pivot Tube	4. Centering Springs	6. Control Plate	8. Control Linkage

ADJUSTMENTS

BRAKE ADJUSTMENT:

The MULTI-PRO 5200 is equipped with a self-adjusting disc brake. As the brake pads begin to wear and affect the Brake Pedal "travel", adjustments can be made before it becomes necessary to replace the brake pads. Adjust first, by tightening the jam nuts at the Compression Spring. Further adjustment can be made at the brake cable bracket, if necessary. See FIG. 13.

Periodically inspect brake pads for wear and replace as necessary.

IMPORTANT: The Brake Pedal is to be used as a parking brake and as an emergency brake in situations demanding an immediate stop or when disengaging the speed control. DO NOT USE THE BRAKE PEDAL FOR MAKING ROUTINE STOPS! Use the Vehicle Drive Control Foot Pedal for normal stops. The brake pedal MUST BE DEPRESSED AND LOCKED every time the vehicle is parked. Operating the MULTI-PRO in this manner will prolong the life of the brake pads and minimize the service requirements.





FIG. 12

1. Brake Pads
2. Brake Cable Bracket
3. Compression Spring

wiring diagram

IGNITION SYSTEM:

The ignition system used on the MULTI-PRO's Ford engine is a "Distributorless Ignition System", as described in the Ford Engine Manual.



storage

Check the machine thoroughly for any replacement parts required. In the event parts are needed, place your order with your dealer in the fall or winter to avoid the delays caused by the usual spring rush. When ordering parts please specify the MODEL NUMBER and the SERIAL NUMBER of the MULTI-PRO (not the engine).

ENGINE:

IMPORTANT!

SEE THE FORD ENGINE MANUAL FOR DETAILED INSTRUCTIONS REGARDING ENGINE STORAGE.

CAUTION! NEVER STORE A MACHINE WITH GASOLINE IN THE TANK OR INSIDE A BUILDING WHERE FUMES MAY REACH AN OPEN FLAME OR SPARK. ALLOW THE ENGINE TO COOL BEFORE STORING IN ANY ENCLOSURE.

VEHICLE

Check all visible moving parts for damage or wear.

Check oil level in the differential.

Remove the battery, clean terminals and coat lightly with grease. Check liquid level and add distilled water if necessary. Bring battery to full charge. Store in a cool, dry area where battery will not freeze. Do not allow battery to sit directly on floor.

INDEX

"ADJUSTMENTS" SECTION	19-21
Brakes	22
Tow Valve	19
Vehicle Drive Control	20 & 21
"MAINTENANCE & LUBRICATION" SECTION	15-18
Air Cleaner	16
Crankcase Oil	16
Differential	18
Fuel	15
Hydraulic Filter	17
Hydraulic Fluid	17
Maintenance Schedule	15
Oil Cooler	17
Radiator	17
Tires	18
"PRE-USE SERVICE"	9
Battery	9
"SAFETY" SECTION	1-8
"STORAGE"	24
"VEHICLE GAUGES & CONTROLS"	10
Brake Lock Knob	11
Coolant Temperature Gauge	11
Engine Warning Light	11
Hour Meter	11
Parking/Emergency Brake	10
Speed Control Switches	10
Vehicle Drive Control	10
Voltmeter	11
"VEHICLE OPERATION"	12 & 13
Initial Start-UP	12
Starting the Engine	12
Stopping the Engine	13
"WIRING DIAGRAM"	23

The Toro Promise

A ONE YEAR LIMITED WARRANTY

The Toro Company promises to repair your TORO Product if defective in materials or workmanship. The following time periods from the date of purchase apply:

Commercial Products 1 Year

The costs of parts and labor are included, but the customer pays the transportation costs on walk rotary mowers with cutting unit widths of less than 25".

If you feel your TORO product is defective and wish to rely on The Toro Promise, the following procedure is recommended:

1. Contact your Authorized TORO Distributor or Commercial Dealer (the Yellow Pages of your telephone directory is a good reference source).
2. The TORO Distributor or Commercial Dealer will advise you on the arrangements that can be made to inspect and repair your product.
3. The TORO Distributor or Commercial Dealer will inspect the product and advise you whether the product is defective and, if so, make all repairs necessary to correct the defect without an extra charge to you.

If for any reason you are dissatisfied with the distributor's analysis of the defect or the service performed, you may contact us.

Write:

TORO Commercial Products Service Department
8111 Lyndale Avenue South
Minneapolis, Minnesota 55420

The above remedy of product defects through repair by an Authorized TORO Distributor or Commercial Dealer is the purchaser's sole remedy for any defect.

THERE IS NO OTHER EXPRESS WARRANTY. ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR USE ARE LIMITED TO THE DURATION OF THE EXPRESS WARRANTY.

Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

This Warranty applies only to parts or components which are defective and does not cover repairs necessary due to normal wear, misuse, accidents, or lack of proper maintenance. Regular, routine maintenance of the unit to keep it in proper condition is the responsibility of the owner.

All warranty repairs reimbursable under the Toro Promise must be performed by an Authorized TORO Commercial Dealer or Distributor using Toro approved replacement parts.

Repairs or attempted repairs by anyone other than an Authorized TORO Distributor or Commercial Dealer are not reimbursable under the Toro Promise. In addition, these unauthorized repair attempts may result in additional malfunctions, the correction of which is not covered by warranty.

THE TORO COMPANY IS NOT LIABLE FOR INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES IN CONNECTION WITH THE USE OF THE PRODUCT INCLUDING ANY COST OR EXPENSE OF PROVIDING SUBSTITUTE EQUIPMENT OR SERVICE DURING PERIODS OF MALFUNCTION OR NON-USE.

Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

COUNTRIES OTHER THAN THE UNITED STATES OR CANADA

Customers who have purchased TORO products exported from the United States or Canada should contact their TORO Distributor (Dealer) to obtain guarantee policies for your country, province or state. If for any reason

you are dissatisfied with your Distributor's service or have difficulty obtaining guarantee information, contact the TORO importer. If all other remedies fail, you may contact us at The Toro Company.