



Model No. 41020-80001 & UP  
 Model No. 41021-80001 & UP  
 Model No. 41120-80001 & UP  
 Model No. 41128-80001 & UP  
 Model No. 41130-80001 & UP  
 Model No. 41038-80001 & UP

## OPERATOR'S INSTRUCTIONS

### PRO CONTROL™ SPRAY SYSTEM for the MULTI PRO® 1100 Vehicle

To assure maximum safety, optimum performance, and to gain knowledge of the product, it is essential that you or any other operator of this Vehicle read and understand the contents of this manual and the vehicle's manuals before the engine is ever started. Pay particular attention to the **SAFETY INSTRUCTIONS** highlighted by the triangular safety alert symbol.

The safety alert symbol means **CAUTION, WARNING or DANGER** - personal safety instruction. Failure to comply with the instruction may result in personal injury.

## SAFETY INSTRUCTIONS

Keep this and all Operator's Manuals in the plastic tube behind the operator seat.

It is very important that all persons operating this equipment have easy access to these instructions at all times!

Carefully read and follow the "Set-Up" Instructions that are provided with this equipment and the Safety Instructions in the Multi-Pro® Operator's Manual.

### RECOGNIZE SAFETY INFORMATION

This safety-alert symbol is used to call attention to a **dangerous** situation, which could result in serious injury or death to the operator or a bystander.

Safety, mechanical and some general information in this manual are emphasized. **DANGER, WARNING and CAUTION** identify safety messages. Whenever the triangular safety symbol appears, it is followed by a safety message that must be read and understood. For more details concerning safety, read the Safety Instructions on this page and page 2. **IMPORTANT** identifies special mechanical information and **NOTE** identifies general information worthy of special attention.

These instructions are provided as a guide for the safe operation and maintenance of this equipment. However, the operator's personal safety, as well as those persons in the work area, will depend on the careful actions and good judgement of the operator. **To reduce the potential for injury or death, comply with the following safety instructions.**

### BEFORE OPERATING:

1. Operate this machine only after reading and understanding the contents of this manual. A replacement manual is available by sending complete model and serial number to: Hahn Equipment Co., 1625 N. Garvin, Evansville, IN 47711.

2. Learn how to operate the Sprayer and how to use the controls properly. **DO NOT** let anyone operate this equipment without first receiving thorough instructions.

3. Keep all shields, safety devices and decals in place. If a shield, safety device or decal is malfunctioning, illegible or damaged, repair or replace it before operating the machine.

4. Chemicals can injure persons, animals, plants, soils or other property. To eliminate environmental damage and personal injury:

**A.** Select the proper chemical for the job.

**B.** Follow manufacturer's instructions on chemical container labels. Apply and handle chemicals as recommended.

**C.** Handle and apply chemicals with care. Wear goggles and other necessary protective equipment. Handle chemicals in well ventilated areas. Never smoke while handling chemicals.

**D.** Properly dispose of chemical container and unused chemicals.

# SAFETY INSTRUCTIONS

## WHILE OPERATING:

### 5. Drive the Vehicle safely.

**A.** Always SLOW the Vehicle when approaching and while making a turn.

**B.** Always SLOW the Vehicle when driving in unfamiliar areas or over rough terrain.

**C.** Always SLOW the Vehicle when changing the direction of travel or preparing to stop.

**D.** When turning or driving on slopes, always SLOW the Vehicle, then turn the vehicle to prevent loss of control and possible upset.

**E.** DO NOT make sudden or sharp turns. DO NOT suddenly change direction of travel on an incline, ramp, grade, slope or similar surface.

**F.** Always adjust the vehicle speed to allow for existing conditions such as wet, slick surfaces, low visibility, etc.

**G.** Be especially careful when driving a heavily loaded vehicle down an incline or slope. Drive the vehicle UP and DOWN the face of the slopes, inclines or grades whenever possible. DO NOT DRIVE ACROSS the face if at all possible. There is a risk of upsetting the vehicle, which can result in serious injury or death.

**6. DO NOT OVERLOAD THE VEHICLE.** Failure to position loads carefully can result in their shifting or tipping over. Distribute loads evenly, keeping them as low as possible to prevent them from becoming top-heavy.

**7.** Make certain everyone is clear of the machine before starting the engine to move the vehicle or to engage the Sprayer Pump drive.

**8.** Before backing up, look to the rear and assure no one is behind. Back up **slowly**.

**9.** Watch out for traffic when near or crossing roads. Always yield the right of way to pedestrians and other vehicles.

**10.** If equipment begins to vibrate abnormally, stop **immediately**. Shut off the vehicle engine and disengage all power. Repair all damage before commencing operation.

## MAINTENANCE:

**11. Before** servicing or making any adjustments to the Sprayer:

**A.** Stop the Vehicle and set the parking brake.

**B.** Shut off the vehicle's engine and remove key from ignition.


**C.** Disengage all power and wait until all moving parts have stopped.

**12.** Keep all nuts, bolts and other fasteners tightened securely. Replace any shields removed during servicing or adjustments.

**13.** To be sure of optimum performance and safety, always purchase genuine TORO replacement parts and accessories. Replacement parts and accessories made by other manufacturers could be dangerous. Altering this equipment in any manner may affect the machine's operation, performance, durability or its use may result in injury or death. Such use could void the product warranty of the TORO Company.

## SAFETY & INSTRUCTION DECALS

The following safety and instruction decals are installed on the PRO CONTROL™. If any become damaged or illegible, replace them. Decals and part numbers are listed below and in the parts catalog. Order replacements from your Authorized Toro Distributor.



Part No. 93-0688: Located on Lid of Sprayer Tank.



Part No. 87-0570: Located on Rear Tank Band.



Part No. 93-0800: Located on side of Clear Water Wash Tank Saddle.

# INTRODUCTION

The Toro Pro-Control™ Spray System is designed to improve the accuracy and uniformity of spray applications. Its performance relies on the installation and preventive maintenance of the complete Sprayer. This Manual provides a simple step-by-step procedure for installing and operating the Toro Pro-Control™ Spray System.

The Toro Pro-Control™ System consists of a computer based Control Console, a Speed Sensor, Turbine Type Flow Meter and a Motorized Control Valve. The Speed Sensor is mounted on the left rear wheel of the Vehicle. Appropriate cabling is furnished for installation.

The operator sets the target volume per area to be sprayed and the Control Console automatically maintains the flow regardless of vehicle speed or gear selection. A manual override switch allows the operator to manually control flow for system check out spot spraying. Actual volume per area being applied is displayed at all times. The Pro-Control additionally functions as an area monitor, speed monitor and volume totalizer.

## CONTROLS

**NOTE: “Right”, “Left”, “Front” and “Rear” are referenced while seated in the operator’s position.**

**PUMP ENGAGEMENT LEVER:** Pivot the pump engagement lever DOWN to lower the centrifugal pump and ENGAGE the drive belt. Pull the lever UP to DISENGAGE the drive belt. See FIG. 1.




FIG. 1

- |                          |                         |
|--------------------------|-------------------------|
| 1. Pump Engagement Lever | 3. Suction Valve Handle |
| 2. Agitator Valve Handle | 4. By-Pass Valve Handle |

**AGITATOR VALVE HANDLE:** Opens and closes the Agitator Valve to activate, adjust or stop the agitation of the spray solution in the Tank.

**SUCTION VALVE HANDLE:** Opens and closes the Suction Line Valve. Close during maintenance to the Suction Line Strainer or Centrifugal Pump.

**IMPORTANT! The Pump will be damaged if it is activated with the Suction Line Valve closed, or before the tank contains enough liquid to flood the pump.**

**BY-PASS VALVE:** Use to adjust and maintain the maximum pressure in the spraying system.

**CONSOLE COMPUTER:** Receives data for desired rate of application and automatically maintains that rate. See FIG. 2.





FIG. 2

1. Console Computer

# CONSOLE FEATURES



Console REV. (Revision) can be determined by letter stamped in REV. box on label.

Console PGM (Program) can be determined by letter stamped in PGM box on label.


**IMPORTANT:** This Console requires selection of area measurement in **US** (acres); **SI** [hectares] or **TU** {1,000 sq. ft.} and type of speed sensor **SP1** (wheel drive, etc.), **SP2** (radar) speed sensor, or **SP3** (wheel drive). **(The Toro Multi Pro 1100 Pro-Control uses the SP1 wheel drive sensor.)**

Selects Manual or fully Automatic control. Can automatically control two rates.

**POWER** - Turns Console OFF or ON. Turning Console OFF does not affect data stored in the computer.

Manual override control provides capability for spot spraying.

Booms can be controlled individually, or all at once with MASTER ON/OFF switch.



Displays operating rate of application.

Displays function and calibration data.

**CE** - Use like you do CE key on a calculator. This key is also used to select an area base measurement of US (acres), SI [hectares], or TU {1,000 sq. ft.} when programming console.

**ENTER** - Used only to enter data into the console.

**CALIBRATION KEYS** - Used to enter data to the Console to calibrate the system.

|            |                               |
|------------|-------------------------------|
| BOOM 1 CAL | Length of Boom 1              |
| BOOM 2 CAL | Length of Boom 2              |
| BOOM 3 CAL | Length of Boom 3              |
| SPEED CAL  | Determined by Wheel Size      |
| METER CAL  | Flow Meter Calibration Number |
| VALVE CAL  | Control Valve Response Time   |
| RATE 1 CAL | Target Application Rate       |
| RATE 2 CAL | Target Application Rate       |
| SELF TEST  | Simulates vehicle speed       |

**FUNCTION KEYS** - Used to display data.

|              |                                                   |
|--------------|---------------------------------------------------|
| TOTAL AREA   | Total Area Sprayed                                |
| TOTAL VOLUME | Total Volume Sprayed                              |
| FIELD AREA   | Field Area Sprayed                                |
| FIELD VOLUME | Volume Applied to Field                           |
| DISTANCE     | Distance Traveled                                 |
| SPEED        | Speed of Vehicle                                  |
| VOLUME/MIN   | Volume Sprayed per Minute at Speed Being Traveled |
| VOLUME/ TANK | Volume Remaining in Tank                          |
| AREA/HOUR    | Area Sprayed per Hour at Speed Being Traveled     |
| TIME         | 24 hour clock (military time)                     |

# BEFORE SPRAYING

## CONSOLE CALIBRATION:

### CALCULATING "BOOM CAL" (Boom 1, Boom 2, Boom 3)

Boom cal is calculated by multiplying the number of spray tips times the tip spacing. For the Toro Pro-Control™, having nozzles at 20" [50 cm] spacing, the Console should be programmed as follows: "Boom 1 (left)" - 80 [204]: "Boom 2 (center)" - 60 [152]: "Boom 3 (right)" - 80 [204].

### CALCULATING "SPEED CAL"

**NOTE:** This measurement is critical to the performance of the Toro Pro-Control™ Spray System. **MEASURE CAREFULLY.** Be sure tire is properly inflated before measuring. Measure tire in type of soil in which you will be spraying and with Carrier Tank one half full. Circumference of tire will vary when measured in soft soil versus hard packed soil. For best results, measure several times and average the results. Re-measure periodically.




FIG. 3.


1. Place chalk mark or tape on vehicle tire, on which Speed Sensor is mounted. See FIG. 3.
2. Mark initial spot on the ground.
3. Drive vehicle straight ahead counting 10 revolutions of the wheel with the mark stopping at the same position as starting.
4. Measure distance from start mark in inches. [Decimeters]. Round off fractions. **This measurement should be approximately 706" [179].**
5. Write down this SPEED CAL calibration number on page 14 for future reference when programming the Control Console.

## CALCULATING "METER CAL"

The Flow meter calibration number is stamped on the white tag attached to each Flow Meter Cable. Record this number in a safe place in case the tag is ever lost or disfigured.

## CALCULATING "VALVE CAL"

1. The initial Valve calibration number for VALVE CAL is 2611. The VALVE CAL number is used to control response time of the Motorized Control Valve to the change in vehicle speed. After operating the system, you may desire to refine this number. See definitions below:



### Valve Backlash -

Controls the time of the first correction pulse after a change in correction direction is detected (**Inc. to Dec. or Dec. to Inc.**).

Range: 1 to 9 1 - Short Pulse, 9 - Long Pulse

### Valve Speed Digit -

Controls response time of Control Valve motor. **CAUTION: Running the Control Valve too fast will cause the system to oscillate.**

Range: 1 to 9 1 - Slow, 9 - Fast

### Brake Point Digit Percent-

Sets the point at which the Control Valve motor begins braking, so as not to over shoot the desired rate. Digit is percent away from target rate.

Range: 0 to 9 0 = 5%, 1 = 10%, 9 = 90%

### Dead-Band Digit -

Allowable difference between target and actual application rate, where rate correction is not performed.

Range: 1 to 9 1 = 1%, 9 = 9%

# BEFORE SPRAYING

## CONSOLE CALIBRATION (CONT'D):

**NOTE:** For new installations you must first perform the "Initial Console Programming" on page 9.

## CALCULATING "RATE 1" AND "RATE 2"

Refer to the Chemical Manufacturer's instructions on the chemical container label to determine the application rate of the chemical to be sprayed.

Enter the application rate (noting decimal) in RATE 1 and RATE 2. Enter the rates in gallons per acre (US mode), gallons per 1000 sq. ft. (TU mode) or liters per hectare (SI mode) depending on the base measurement selected. **NOTE:** If you do not use a second rate, enter the same rate in both RATE 1 and RATE 2.

See the nozzle charts on page 7 or 8 to be sure that your spray nozzles have the capacity necessary to achieve the application rate selected.

### To select the proper nozzle, you need to know:

1. Recommended chemical application rate in gallons per acre, gallons per 1000 sq. ft. or liters per hectare.
2. Average Vehicle speed in Miles per hour or kilometers per hour.
3. Nozzle spacing (20 inches or 50 centimeters.)

With this information you can calculate the volume per minute per nozzle, using the formulas below.

### US FORMULA:

$$\text{G.P.M.} = \frac{\text{G.P.A.} \times \text{M.P.H.} \times 20 \text{ ins.}}{5940}$$

(Per Nozzle)

### TU (Turf) FORMULA:

$$\text{G.P.M.} = \frac{\text{G.P.K.} \times \text{M.P.H.} \times 20 \text{ ins.}}{137}$$

(Per Nozzle)

### SI (METRIC) FORMULA:

$$\text{lit/min} = \frac{\text{lit/ha} \times \text{km/h} \times 50 \text{ cm}}{60,000}$$

(Per Nozzle)

Use G.P.M. (lit/min) and Pressure to select appropriate nozzle from chart on page 7 or 8.

### EXAMPLE (US FORMULA):

Application Rate = 75 Gallons/Acre  
Vehicle Speed = 4 M.P.H.  
Nozzle Spacing = 20 inches

$$\frac{75 \text{ G.P.A.} \times 4 \text{ M.P.H.} \times 20}{5940} = 1.00 \text{ G.P.M. (per nozzle)}$$

**With 1.00 G.P.M. and a pressure of 40 P.S.I. you would select Nozzle No. 95-9188.**

### EXAMPLE (TU FORMULA):

Application Rate = 1.70 Gal./1000 sq. ft.  
Vehicle Speed = 4 M.P.H.  
Nozzle Spacing = 20 inches

$$\frac{1.70 \text{ G.P.K.} \times 4 \text{ M.P.H.} \times 20}{137} = 1.00 \text{ G.P.M. (per nozzle)}$$

### EXAMPLE (SI FORMULA):

Application Rate = 907 lit/hectare  
Vehicle Speed = 5 km/h  
Nozzle Spacing = 50 cm

$$\frac{907 \text{ lit/ha} \times 5 \text{ km/h} \times 50}{60,000} = 3.78 \text{ lit/min. (per nozzle)}$$

**With 3.78 lit/min and a pressure at 275 kPa you would select nozzle No. 95-9188**

## SYMBOL DEFINITIONS:

|         |                             |
|---------|-----------------------------|
| GPM     | - Gallons per minute        |
| lit/min | - Liters per minute         |
| dl/min  | - Deciliter per minute      |
| PSI     | - Pounds per square inch    |
| kPa     | - Kilopascal                |
| GPA     | - Gallons per acre          |
| lit/ha  | - Liter per hectare         |
| ml/ha   | - Milliliter per hectare    |
| GPk     | - Gallons per 1,000 sq. ft. |
| mm      | - Millimeters               |
| cm      | - Centimeters               |
| dm      | - Decimeters                |
| m       | - Meter                     |
| MPH     | - Miles per hour            |
| km      | - Kilometers                |
| km/h    | - Kilometers per hour       |
| US      | - Volume per ACRE           |
| SI      | - Volume per HECTARE        |
| TU      | - Volume per 1,000 sq. ft.  |

## LIQUID CONVERSIONS

U.S. Gallons x 128 = Fluid Ounces  
U.S. Gallons x 3.785 = Liters  
U.S. Gallons x 0.83267 = Imperial Gallons  
U.S. Gallons x 8.34 = Pounds (Water)

## LENGTH

1 millimeter (mm) = 0.039 inch  
1 centimeter (cm) = 0.393 inch  
1 meter (m) = 3.281 feet  
1 kilometer (km) = 0.621 mile  
1 inch = 25.4 millimeters; 2.54 centimeters  
1 mile = 1.609 kilometers

## PRESSURE

1 psi = 6.89 kPa

## AREA

1 square meter = 10.764 sq. feet  
1 hectare (ha) = 2.471 acres; 10,000 sq.meters  
1 acre = 0.405 hectare; 43,560 sq. ft.  
1 sq. mile = 640 acres; 258.9 hectares

## Gallons Per Acre Application Rates

| TORO<br>Part No. | Nozzle<br>Number | Pressure<br>(PSIG) | Capacity<br>1 Nozzle<br>(GPM) | Gallons per Acre at 20" Spacings |       |         |       |         |       |         |       |
|------------------|------------------|--------------------|-------------------------------|----------------------------------|-------|---------|-------|---------|-------|---------|-------|
|                  | Color Code       |                    |                               | 2.5 MPH                          | 3 MPH | 3.5 MPH | 4 MPH | 4.5 MPH | 5 MPH | 5.5 MPH | 6 MPH |
| 95-9221          | Yellow           | 20                 | 0.14                          | 16.6                             | 13.9  | 11.9    | 10.4  | 9.2     | 8.3   | 7.6     | 6.9   |
|                  |                  | 30                 | 0.17                          | 20.2                             | 16.8  | 14.4    | 12.6  | 11.2    | 10.1  | 9.2     | 8.4   |
|                  |                  | 40                 | 0.20                          | 23.8                             | 19.8  | 17.0    | 14.9  | 13.2    | 11.9  | 10.8    | 9.9   |
|                  |                  | 50                 | 0.22                          | 26.1                             | 21.8  | 18.7    | 16.3  | 14.5    | 13.1  | 11.9    | 10.9  |
| 95-9222          | Red              | 20                 | 0.28                          | 33                               | 28    | 24      | 21    | 18      | 17    | 15      | 14    |
|                  |                  | 30                 | 0.35                          | 42                               | 35    | 30      | 26    | 23      | 21    | 19      | 17    |
|                  |                  | 40                 | 0.40                          | 48                               | 40    | 34      | 30    | 26      | 24    | 22      | 20    |
|                  |                  | 50                 | 0.45                          | 53                               | 45    | 38      | 33    | 30      | 27    | 24      | 22    |
| 95-9223          | Brown            | 20                 | 0.35                          | 42                               | 35    | 30      | 26    | 23      | 21    | 19      | 17    |
|                  |                  | 30                 | 0.43                          | 51                               | 43    | 36      | 32    | 28      | 26    | 23      | 21    |
|                  |                  | 40                 | 0.50                          | 59                               | 50    | 42      | 37    | 33      | 30    | 27      | 25    |
|                  |                  | 50                 | 0.56                          | 67                               | 55    | 48      | 42    | 37      | 33    | 30      | 28    |
| 95-9224          | Gray             | 20                 | 0.42                          | 50                               | 42    | 36      | 31    | 28      | 25    | 23      | 21    |
|                  |                  | 30                 | 0.52                          | 62                               | 51    | 44      | 39    | 34      | 31    | 28      | 26    |
|                  |                  | 40                 | 0.60                          | 71                               | 59    | 51      | 45    | 40      | 36    | 32      | 30    |
|                  |                  | 50                 | 0.67                          | 80                               | 66    | 57      | 50    | 44      | 40    | 36      | 33    |
| 95-9225          | White            | 20                 | 0.57                          | 68                               | 56    | 48      | 42    | 38      | 34    | 31      | 28    |
|                  |                  | 30                 | 0.69                          | 82                               | 68    | 59      | 51    | 46      | 41    | 37      | 34    |
|                  |                  | 40                 | 0.80                          | 95                               | 79    | 68      | 59    | 53      | 48    | 43      | 40    |
|                  |                  | 50                 | 0.89                          | 106                              | 88    | 76      | 66    | 59      | 53    | 48      | 44    |
| 95-9188          | Light Blue       | 20                 | 0.71                          | 84                               | 70    | 60      | 53    | 47      | 42    | 38      | 35    |
|                  |                  | 30                 | 0.87                          | 103                              | 86    | 74      | 65    | 57      | 52    | 47      | 43    |
|                  |                  | 40                 | 1.00                          | 119                              | 99    | 85      | 74    | 66      | 59    | 54      | 50    |
|                  |                  | 50                 | 1.12                          | 133                              | 111   | 95      | 83    | 74      | 67    | 60      | 55    |
| 95-9226          | Light Green      | 20                 | 1.06                          | 126                              | 105   | 90      | 79    | 70      | 63    | 57      | 52    |
|                  |                  | 30                 | 1.30                          | 154                              | 129   | 110     | 97    | 86      | 77    | 70      | 64    |
|                  |                  | 40                 | 1.50                          | 178                              | 149   | 127     | 111   | 99      | 89    | 81      | 74    |
|                  |                  | 50                 | 1.68                          | 200                              | 166   | 143     | 125   | 111     | 100   | 91      | 83    |

## Gallons Per 1000 Sq. Ft. Application Rates

| TORO<br>Part No. | Nozzle<br>Number | Pressure<br>(PSIG) | Capacity<br>1 Nozzle<br>(GPM) | Gallons per 1000 Sq. Ft. at 20" Spacings |       |         |       |         |       |         |       |
|------------------|------------------|--------------------|-------------------------------|------------------------------------------|-------|---------|-------|---------|-------|---------|-------|
|                  | Color Code       |                    |                               | 2.5 MPH                                  | 3 MPH | 3.5 MPH | 4 MPH | 4.5 MPH | 5 MPH | 5.5 MPH | 6 MPH |
| 95-9221          | Yellow           | 20                 | 0.14                          | 0.38                                     | 0.32  | 0.27    | 0.24  | 0.21    | 0.19  | 0.17    | 0.16  |
|                  |                  | 30                 | 0.17                          | 0.46                                     | 0.39  | 0.33    | 0.29  | 0.26    | 0.23  | 0.21    | 0.19  |
|                  |                  | 40                 | 0.20                          | 0.54                                     | 0.45  | 0.39    | 0.34  | 0.30    | 0.27  | 0.25    | 0.23  |
|                  |                  | 50                 | 0.22                          | 0.60                                     | 0.50  | 0.43    | 0.37  | 0.33    | 0.30  | 0.27    | 0.25  |
| 95-9222          | Red              | 20                 | 0.28                          | 0.76                                     | 0.63  | 0.54    | 0.48  | 0.42    | 0.38  | 0.35    | 0.32  |
|                  |                  | 30                 | 0.35                          | 0.95                                     | 0.79  | 0.68    | 0.60  | 0.53    | 0.48  | 0.43    | 0.40  |
|                  |                  | 40                 | 0.40                          | 1.09                                     | 0.91  | 0.78    | 0.68  | 0.60    | 0.54  | 0.49    | 0.45  |
|                  |                  | 50                 | 0.45                          | 1.22                                     | 1.02  | 0.87    | 0.77  | 0.68    | 0.61  | 0.56    | 0.51  |
| 95-9223          | Brown            | 20                 | 0.35                          | 0.95                                     | 0.79  | 0.68    | 0.60  | 0.53    | 0.48  | 0.43    | 0.40  |
|                  |                  | 30                 | 0.43                          | 1.17                                     | 0.97  | 0.84    | 0.73  | 0.65    | 0.58  | 0.53    | 0.49  |
|                  |                  | 40                 | 0.50                          | 1.36                                     | 1.13  | 0.97    | 0.85  | 0.76    | 0.68  | 0.62    | 0.57  |
|                  |                  | 50                 | 0.56                          | 1.52                                     | 1.27  | 1.09    | 0.95  | 0.85    | 0.76  | 0.69    | 0.63  |
| 95-9224          | Gray             | 20                 | 0.42                          | 1.14                                     | 0.95  | 0.82    | 0.71  | 0.63    | 0.57  | 0.52    | 0.48  |
|                  |                  | 30                 | 0.52                          | 1.41                                     | 1.18  | 1.01    | 0.88  | 0.79    | 0.71  | 0.64    | 0.59  |
|                  |                  | 40                 | 0.60                          | 1.63                                     | 1.36  | 1.17    | 1.02  | 0.91    | 0.82  | 0.74    | 0.68  |
|                  |                  | 50                 | 0.67                          | 1.82                                     | 1.52  | 1.30    | 1.14  | 1.01    | 0.91  | 0.83    | 0.76  |
| 95-9225          | White            | 20                 | 0.57                          | 1.55                                     | 1.29  | 1.11    | 0.97  | 0.86    | 0.78  | 0.70    | 0.65  |
|                  |                  | 30                 | 0.69                          | 1.88                                     | 1.56  | 1.34    | 1.17  | 1.04    | 0.94  | 0.85    | 0.78  |
|                  |                  | 40                 | 0.80                          | 2.18                                     | 1.81  | 1.55    | 1.36  | 1.21    | 1.09  | 0.99    | 0.91  |
|                  |                  | 50                 | 0.89                          | 2.42                                     | 2.02  | 1.73    | 1.51  | 1.34    | 1.21  | 1.10    | 1.01  |
| 95-9188          | Light Blue       | 20                 | 0.71                          | 1.93                                     | 1.61  | 1.38    | 1.21  | 1.07    | 0.97  | 0.88    | 0.80  |
|                  |                  | 30                 | 0.87                          | 2.37                                     | 1.97  | 1.69    | 1.48  | 1.31    | 1.18  | 1.08    | 0.99  |
|                  |                  | 40                 | 1.00                          | 2.72                                     | 2.27  | 1.94    | 1.70  | 1.51    | 1.36  | 1.24    | 1.13  |
|                  |                  | 50                 | 1.12                          | 3.05                                     | 2.54  | 2.18    | 1.90  | 1.69    | 1.52  | 1.38    | 1.27  |
| 95-9226          | Light Green      | 20                 | 1.06                          | 2.88                                     | 2.40  | 2.06    | 1.80  | 1.60    | 1.44  | 1.31    | 1.20  |
|                  |                  | 30                 | 1.30                          | 3.54                                     | 2.95  | 2.53    | 2.21  | 1.96    | 1.77  | 1.61    | 1.47  |
|                  |                  | 40                 | 1.50                          | 4.08                                     | 3.40  | 2.91    | 2.55  | 2.27    | 2.04  | 1.85    | 1.70  |
|                  |                  | 50                 | 1.68                          | 4.57                                     | 3.81  | 3.26    | 2.86  | 2.54    | 2.28  | 2.08    | 1.90  |

## Liters Per Hectare Application Rates

| TORO<br>Part No. | Nozzle<br>Number | Pressure<br>(kPa) | Capacity<br>1 Nozzle<br>(L/min) | Liters per Hectare at 50 cm Spacings |        |        |        |        |        |         |         |
|------------------|------------------|-------------------|---------------------------------|--------------------------------------|--------|--------|--------|--------|--------|---------|---------|
|                  | Color Code       |                   |                                 | 4 km/h                               | 5 km/h | 6 km/h | 7 km/h | 8 km/h | 9 km/h | 10 km/h | 11 km/h |
| 95-9221          | Yellow           | 150               | 0.53                            | 159                                  | 127    | 106    | 91     | 80     | 71     | 64      | 58      |
|                  |                  | 200               | 0.64                            | 192                                  | 154    | 128    | 110    | 96     | 85     | 77      | 70      |
|                  |                  | 275               | 0.76                            | 228                                  | 182    | 152    | 130    | 114    | 101    | 91      | 83      |
|                  |                  | 350               | 0.83                            | 249                                  | 199    | 166    | 142    | 125    | 111    | 100     | 91      |
| 95-9222          | Red              | 150               | 1.06                            | 318                                  | 254    | 212    | 182    | 159    | 141    | 127     | 116     |
|                  |                  | 200               | 1.32                            | 396                                  | 317    | 264    | 226    | 198    | 176    | 158     | 144     |
|                  |                  | 275               | 1.51                            | 453                                  | 362    | 302    | 259    | 227    | 201    | 181     | 165     |
|                  |                  | 350               | 1.70                            | 510                                  | 408    | 340    | 291    | 255    | 227    | 204     | 185     |
| 95-9223          | Brown            | 150               | 1.40                            | 420                                  | 336    | 280    | 240    | 210    | 187    | 168     | 153     |
|                  |                  | 200               | 1.61                            | 483                                  | 386    | 322    | 276    | 242    | 215    | 193     | 176     |
|                  |                  | 275               | 1.89                            | 567                                  | 454    | 378    | 324    | 284    | 252    | 227     | 206     |
|                  |                  | 350               | 2.13                            | 639                                  | 511    | 426    | 365    | 320    | 284    | 256     | 232     |
| 95-9224          | Grey             | 150               | 1.67                            | 501                                  | 401    | 334    | 286    | 251    | 223    | 200     | 182     |
|                  |                  | 200               | 1.93                            | 579                                  | 463    | 386    | 331    | 290    | 257    | 232     | 211     |
|                  |                  | 275               | 2.27                            | 681                                  | 545    | 454    | 389    | 341    | 303    | 272     | 248     |
|                  |                  | 350               | 2.56                            | 768                                  | 614    | 512    | 439    | 384    | 341    | 307     | 279     |
| 95-9225          | White            | 150               | 2.23                            | 669                                  | 535    | 446    | 382    | 335    | 297    | 268     | 243     |
|                  |                  | 200               | 2.58                            | 774                                  | 619    | 516    | 442    | 387    | 344    | 310     | 281     |
|                  |                  | 275               | 3.02                            | 906                                  | 725    | 604    | 518    | 453    | 403    | 362     | 329     |
|                  |                  | 350               | 3.41                            | 1023                                 | 818    | 682    | 585    | 512    | 455    | 409     | 372     |
| 95-9188          | Light Blue       | 150               | 2.79                            | 837                                  | 670    | 558    | 478    | 419    | 372    | 335     | 304     |
|                  |                  | 200               | 3.22                            | 966                                  | 773    | 644    | 552    | 483    | 429    | 386     | 351     |
|                  |                  | 275               | 3.78                            | 1134                                 | 907    | 756    | 648    | 567    | 504    | 454     | 412     |
|                  |                  | 350               | 4.28                            | 1284                                 | 1027   | 856    | 734    | 642    | 571    | 514     | 467     |
| 95-9226          | Light Green      | 150               | 4.18                            | 1254                                 | 1003   | 836    | 717    | 627    | 557    | 502     | 456     |
|                  |                  | 200               | 4.84                            | 1452                                 | 1162   | 968    | 830    | 726    | 645    | 581     | 528     |
|                  |                  | 275               | 5.67                            | 1701                                 | 1361   | 1134   | 972    | 851    | 756    | 680     | 619     |
|                  |                  | 350               | 6.40                            | 1920                                 | 1536   | 1280   | 1097   | 960    | 853    | 768     | 698     |

# BEFORE SPRAYING

## CONSOLE PROGRAMMING:

After all installation procedures have been completed and Console power is turned "ON", the Console will flash "CAL" in the RATE display. This means you must calibrate or program the Console before it can be operated. This is a one-time operation which does not have to be repeated.

**NOTE:** Turning the POWER ON/OFF switch to "OFF" does not affect the Console memory. All data is retained.

While the calibration figures shown below are useful guidelines, calculations should be carried out for your particular machine and refined to accommodate varying operating conditions and desired applications.

## DATA ENTRY:

When entering data into the console, the entry sequence is always the same. **(NOTE: DATA MUST BE ENTERED INTO THE FIRST EIGHT KEYS AFTER THE INITIAL CONSOLE PROGRAMMING IS PERFORMED).**

1. Depress the key in which you wish to enter data.
2. Depress the "ENTER" key. An "E" will illuminate in the DATA display.
3. Depress the keys corresponding to the number you wish to enter (i.e., "1", "0", "2", "4"). The numbers will be displayed in the DATA display as they are entered.
4. Complete the entry by again depressing the "ENTER" key.

## INITIAL CONSOLE PROGRAMMING:

If an entry selection error is made during steps 1,2,3, and 4, the Console can be reset by turning off console power and turning console on while depressing the  key.

1. Turn power on, the RATE window will flash "CAL". The DATA window will display "US"

- a. Depressing momentarily  steps the DATA display from US (acres) to SI [Hectares].
- b. Depressing momentarily  steps the DATA display from SI [Hectares] to TU.
- c. Depressing momentarily  steps the DATA display from TU (1,000 sq. ft.) to US.

2. Selecting US, SI or TU

a. To select US, SI or TU, step  until the desired code is displayed in DATA display.

b. Momentarily depress . The DATA display will now display SP1.

3. Display SP1, SP2 or SP3 (**Toro Multi Pro 1100 Pro Control™ uses wheel drive SP1**).

a. Depressing momentarily  steps the DATA display from SP1 (wheel drives, etc.) to SP2 or SP3.

4. Selecting SP1.

a. To select SP1, step with  until SP1 is displayed in DATA display.

b. Momentarily depress  the DATA display will now display 0.

5. Enter BOOM 1 CAL 80 [204] in key labeled: 

6. Enter BOOM 2 CAL 60 [152] in key labeled: 

7. Enter Boom 3 CAL 80 [204] in key labeled: 

8. Enter SPEED CAL in key labeled:  (Determined on page 5).

9. Enter METER CAL calibration number in key labeled: . (This number is located on white tag on Flow Meter Cable.

10. Enter VALVE CAL calibration number (**2611**) in key labeled: 

11. Enter the Application Target Rate in either gallons per acre, liters per hectare or gallons per 1000 sq. ft. (selected in Step 2) you want to spray in the key labeled: 

12. Enter a second target application rate in either gallons per acre, liters per hectare or gallons per 1000 sq. ft. (selected in Step 2) you want to spray in key labeled  if desired.

**NOTE:** If you do not use a second rate, enter the same rate in both RATE 1 and RATE 2.

**YOU HAVE NOW COMPLETED PROGRAMMING THE CONSOLE** The flashing "CAL" will now extinguish. If not, repeat procedure starting at step 5.

See page 27 & 28 for Performance Verification & Page 30 & 31 for Quick Reference Programming Cards.

## BEFORE SPRAYING

### INITIAL CONSOLE PROGRAMMING (Cont'd):

You may also want to enter data in the keys labeled:  and  although it is not required for operation of the system.

**13.**  (Optional) - Enter the amount of material in the Tank. This number must be re-entered each time the Tank is refilled. The function monitors Tank volume while spraying, based on application rate.

**14.**  "TIME" (Optional) - Enter time of day based on 24 hours. (i.e., 1:30 p.m. is 13:30), or enter "0" to measure elapsed time.

### OTHER DISPLAY FEATURES:

**1.** To display TOTAL AREA covered, momentarily depress key labeled: 

To "zero out" this total at any time, enter a "0" in this key.

**2.** To display TOTAL VOLUME sprayed, momentarily depress key labeled: 

To "zero out" this total at any time, enter a "0" in this key.

**3.** To display FIELD AREA covered, momentarily depress key labeled: 

To "zero out" this total at any time, enter a "0" in this key.

**4.** To display FIELD VOLUME sprayed, momentarily depress key labeled: 

To "zero out" this total at any time, enter a "0" in this key.

**5.** To display DISTANCE (feet [m] traveled, momentarily depress key labeled: 

To "zero out" this total at any time, enter a "0" in this key.

**6.** To display MPH [km/h], momentarily depress key labeled: 

**7.** To display VOL/MIN (volume per minute) being sprayed at speed being traveled, momentarily depress key labeled: 

To "zero out" this total at any time, enter a "0" in this key.

**8.** To display AREA/HOUR (area per hour) momentarily depress the key labeled: . This is an actual calibration of the area per hour at the present speed you are traveling. It is not an average over time.

**9.** To display US, TI or TU and SP1, SP2 or SP3 after being selected, depress and hold . These selections will be alternately displayed.

**10.** The DATA MENU button is used with an optional serial interface and printer.

### SELF TEST FEATURE

SELF TEST allows speed simulation for testing the system while the vehicle is not moving. Enter the simulated operating speed in the key labeled: 

If 4.0 MPH [6.4 km/h] is desired, depress Enter 4, 0 [6, 4] Enter.

Speed will appear in the DATA display.

The SELF TEST speed will clear itself when motion of vehicle is detected by the Speed Sensor. A SPEED CAL value of 900 [230] or greater is recommended when operating in this mode.

### SEQUENCE TO ACTIVATE DATA-LOCK\*

**1.** Depress  for 5 seconds, NEW CODE will appear.

**2.** Enter 4 digit code within 15 seconds.

**EXAMPLE:** For 1058 depress:

    and .

### SEQUENCE TO CHANGE DATA-LOCK

\* The DATA LOCK feature prohibits the entry of data without first entering the DATA LOCK CODE.

**1.** Depress  for 5 seconds, OLD CODE message will appear.

**2.** Enter 4 digit code within 15 seconds.

NEW CODE message will appear. Enter 4 digit code within 15 seconds.

**EXAMPLE:** For 1258, depress:

    and .

### ENTER MODE SEQUENCE WITH ACTIVATED DATA-LOCK

**1.** Depress the key into which you wish to enter data.

**2.** Depress , CODE message will appear. Enter your DATA LOCK CODE. If code is correct, "E" will appear. Now enter data normally.

## BEFORE SPRAYING

The DATA LOCK CODE may be cleared by entering a code of "0" or by turning off console power and turning console on while depressing the  key.

### POWER DOWN DELAY FEATURE:

To conserve the Vehicle's 12-volt battery, the Power Down Delay should be set. In this "power down" mode, all data will be retained, but the time of day clock will not operate. The Power Down Delay is initially set at 10 days.

### TO CHANGE DELAY TIME:

1. Depress "TIME" for 5 seconds and the current delay time will appear.
2. Reset the delay time by pressing "ENTER", the desired delay time (normally 1-2 days) and "ENTER".

### CONSOLE ALARM FEATURE

Console alarm sounds if application rate is 30% or more away from target application rate for 5 seconds.

1. Displaying A on or A off.
  - a. Depressing  for 5 seconds Displays A on (alarm on) or A off (alarm off).
2. Selecting A on or A off.
  - a. To select A on or A off step with  until desired code is displayed in Data display.
  - b. Depressing any other key will lock that selection.

**THE FEATURES LISTED BELOW ARE NOT NECESSARY TO THE OPERATION OF THE PRO-CONTROL™ SYSTEM, BUT ARE INCLUDED AND CAN BE ACCESSED AT THE OPERATOR'S OPTION.**

### DISPLAY MENU:

Depress  for 7 seconds until DATA display shows "d on". Depressing  key momentarily, steps the DATA display between "d on" and "doFF". "d on" means RATE displays target rate when actual rate is within a percentage of target rate. This percentage is determined by third digit of Valve CAL value as shown:

Brake point digit  
(3rd digit) of Valve Cal 2 1 2 3

|                  |                  |
|------------------|------------------|
| 0=1% + Deadband  | 5=25% + Deadband |
| 1=3% + Deadband  | 6=30% + Deadband |
| 2=7% + Deadband  | 7=35% + Deadband |
| 3=10% + Deadband | 8=40% + Deadband |
| 4=20% + Deadband | 9=45% + Deadband |

Actual rate is displayed if unit does not reach deadband within 10 seconds. "doFF" means RATE displays actual rate at all times.

### LOW LIMIT FLOW SET POINT AND LOW LIMIT ALARM

Depress  until DATA display flashes. A low limit flow rate may now be entered.

If actual Volume Per Minute falls below this limit, the Control Valve stops closing, the Alarm sounds and the rate display flashes "-LL-". The low Limit value should be determined with all Booms "on". This value is automatically proportional to the percentage of Booms that are "on". (i.e. If the entered low limit is 4 GAL/MIN and half the Total Boom length is shut off, the Console automatically reduces the low limit to 2 GAL/MIN)

### CONTROL VALVE DELAY

Depress  until DATA display flashes. The left most digit is the Valve control delay digit. This feature allows the user to set a delay between the time the Booms are turned on and when the Console begins to control the flow rate. A value of 1-9 means a delay of 1-9 seconds respectively. A value of "0" means no delay. This delay is active if the time between turning off and turning on the Booms is less than 30 seconds.

## BEFORE SPRAYING

### INITIAL SYSTEM SET-UP:

1. Fill the Tank with water and open the Suction Line Valve. See FIG. 4.

**IMPORTANT! The pump will be damaged if it is activated before it is completely filled with liquid. Be certain the suction line valve is open and liquid has reached the pump.**




FIG. 4

- |                                       |                                    |
|---------------------------------------|------------------------------------|
| 1. By-Pass Valve Handle (open)        | 3. Pump Engagement Lever (engaged) |
| 2. Pump Engagement Lever (disengaged) | 4. Suction Valve Handle (open)     |

2. Take the vehicle out of gear and set the parking brake. Move the Pump Engagement Lever **UP** to the **disengaged** position. Start the engine and set the throttle at 3/4 to full RPM to represent your desired spraying speed.

3. Place MASTER ON/OFF to "ON" and BOOM ON/OFF switches to "OFF".

4. Place MAN/AUTO switch to "MAN".

5. Place POWER ON/OFF to "ON".

6. Verify that correct Boom widths and calibrations for Speed CAL, Meter CAL, Valve CAL, RATE 1 and RATE 2 have been entered in Console.

7. Use the "SELF TEST" feature as described on page 10.

8. Move the Pump Engagement Lever **DOWN** to the **engaged** position.

9. Operate BOOM ON/OFF switches to verify that each Boom Solenoid Valve is operating and that there are no plugged nozzles.

10. Place all BOOM ON/OFF switches to "ON".

11. Hold the MAN. ADJ. switch in **INCR.** position for approximately 12 seconds. This assures that motorized Control Valve is fully **open**.

12. Verify that the maximum pressure (shown on Pressure Gauge) and RATE can be achieved. Adjust pressure with ball valve in By-Pass Line to 80 p.s.i. **max**.

13. Adjust ball valve in Agitator Line for desired agitation. Verify that maximum pressure is still present at the Pressure Gauge.

14. Hold the MAN. ADJ. switch in **DECR.** position for approximately 12 seconds. This assures that motorized Control Valve is fully **closed**.

15. Verify that minimum pressure and RATE can be achieved.

### INITIAL SYSTEM FIELD TEST:

1. Fill the Tank with water and open the Suction Line Valve. See FIG. 4.

**IMPORTANT! The pump will be damaged if it is activated before it is completely filled with liquid. Be certain the suction line valve is open and liquid has reached the pump.**

2. Drive Vehicle at desired spraying speed with Sprayer Booms off. Verify MPH readout on Console by depressing SPEED.

3. Engage the Spray Pump, place MASTER ON/OFF switch to "ON" and BOOM ON/OFF switches to "ON".

4. Place the RATE 1/ RATE2 / MAN switch to RATE 1.

5. Increase or decrease vehicle speed by one MPH. The system should automatically correct the target application rate.

If the system is unable to correct to the desired RATE, check for an empty Tank, a plugged line, a malfunctioning Pump, improper Vehicle speed, a defect in the system or improper set-up & nozzle sizes.

If after eliminating the possibilities listed above, the system is unable to correct to the desired RATE, first review the "INITIAL SYSTEM SET-UP", then refer to TROUBLESHOOTING GUIDE" on pages 16-20.

# BEFORE SPRAYING

## INITIAL SYSTEM FIELD TEST(Cont'd):

5. At the end of each swath sprayed, switch the MASTER ON/OFF to "OFF" to shut off flow. This also shuts off the acreage totalizer.
6. Verify acres covered and gallons used.

## FILLING THE SOLUTION TANK:

### DANGER

Chemicals can be hazardous!

- Read carefully the directions printed on the chemical manufacturer's labels before handling chemicals. Instructions on chemical manufacturer's container labels, regarding mixing proportions, should be read and strictly followed.
- The concentrate should not be poured into an empty Tank: fill Tank about 3/4 full with clean, clear water, add chemical concentrate SLOWLY. With full agitation finish filling Tank with water.
- Keep spray material from skin. If spray material comes in contact with body, wash it off immediately with clean water and detergent.
- Always wear goggles and other protective equipment as recommended by the Chemical Manufacturer.

**IMPORTANT! DO NOT** add chemical to Tank until just before use. Follow the chemical manufacturer's instructions for mixing spray solution to obtain desired application rate.

## FILL THE CLEAN WATER WASH TANK.

**NOTE:** Fill Clean Water Wash Tank with clean water only. Check to assure tank is full before each operation.

In case of chemical contact with skin or eyes, a fresh water wash tank has been installed on the R.H. side of the vehicle.




FIG. 5

1. Clean Water Wash Tank    2. Tank Spigot

1. Turn Tank Spigot to on position. See FIG. 5.
2. Hold contaminated area directly under water stream.

**For future reference, pencil in your calibrations numbers in the spaces below.**

|                                                                         |                    |                    |                   |                                  |                   |                    |                    |                  |               |                                              |
|-------------------------------------------------------------------------|--------------------|--------------------|-------------------|----------------------------------|-------------------|--------------------|--------------------|------------------|---------------|----------------------------------------------|
| BOOM 1<br>CAL<br>1                                                      | BOOM 2<br>CAL<br>2 | BOOM 3<br>CAL<br>3 | SPEED<br>CAL<br>4 | METER<br>CAL<br>5                | VALVE<br>CAL<br>6 | RATE 1<br>CAL<br>7 | RATE 2<br>CAL<br>8 | VOL<br>TANK<br>9 | TIME<br>0     | SELF<br>TEST<br>←                            |
| <div style="border: 1px solid black; height: 60px; width: 100%;"></div> |                    |                    | SPEED CAL NUMBER  | CALIBRATION # FROM<br>FLOW METER | 2611              | APPLICATION RATE 1 | APPLICATION RATE 2 | VOLUME-IN-TANK   | MILITARY TIME | FOR TESTING, ENTER NORMAL<br>OPERATING SPEED |
|                                                                         |                    |                    |                   |                                  |                   |                    |                    |                  |               |                                              |

1124

BOOM WIDTHS

## OPERATION

### USING THE SPRAYER:

**IMPORTANT! Check all of your equipment... make certain that all components are clean... including the Tank, Pump, Control Valves, Strainers, Check Valves, Hoses, Nozzles, Spray Tips and Suction Line Strainer.**

With the Control Console programmed to achieve the application rate of the chemical selected, and after the initial Field Test to verify the program, proceed as follows:

1. Start the vehicle engine and position the throttle at full (or nearly full) speed to provide the necessary ground speed, pressure and volume.
2. Engage the Pump and use the Master ON/OFF Switch and individual Boom Switches, to control Boom sections.

### IMPORTANT! While operating the Sprayer:

- Do not overlap areas that have been sprayed previously.
  - Watch for plugged Nozzles. Replace all worn Nozzles or those producing streaky or uneven patterns.
3. Stop the spray flow **before** stopping the vehicle.

### AFTER SPRAYING:

It is extremely important to carefully wash and clean the Tank after **every** use.

Not only the Tank but the Pump, Hoses, Nozzles, Screens, Filters, and the exterior of the Sprayer also should be cleaned.

### Flush Pump After Use

One for the most common causes for faulty pump performance is "gumming" or corrosion inside the pump. Flush the pump and entire system with a solution that will chemically neutralize the liquid pumped. Mix according to the manufacturer's directions. This will dissolve most residue remaining in the pump, leaving the inside of the pump clean for the next use.

A **minimum** of three 50 gallon rinses usually is required for all components of the Sprayer. The addition of a detergent cleaner may be advisable in the initial washing. directions for such an addition, if required, are included on the chemical container.

Cleaning of Sprayer should be accomplished in an area where there is no potential for the chemicals to be washed off in surface water or to enter subsurface drainage systems.

When Sprayer is not to be used for an extended period, refer to the STORAGE section of this Manual for the detailed instructions to prevent damage to the components.

Preventative maintenance is most important to assure long life of the Pro-Control Spray System. The following maintenance procedures should be followed on a regular basis:


Flush the entire spraying system as described on page 14 after each use. Failure to clean the system can result in a chemical residue which can plug the Flow Meter, Solenoids, Control Valve, Hoses and/or Nozzle Tips, and seriously damage the Centrifugal Pump.

Wash spray nozzles thoroughly with water. Blow out orifice, clean and dry. If orifice remains clogged, clean it with a soft bristled brush... never use a metal object.

Check all of the nozzles frequently to spot any inconsistencies in the spray pattern. Worn nozzle orifices which allow a greater volume of spray material to flow through the nozzle can cause an expensive loss in chemical and/or turf damage.

### SUCTION STRAINER:

Turn off Suction Line Valve if Tank is full of spray solution. Remove the cap and clean the strainer screen after every 50 hours when using liquid chemical, or after every use when spraying wettable powders.



**FIG. 6**

1. Suction Strainer      2. Suction Line Valve (Open)

**IMPORTANT: Do not operate the pump dry! Be certain Suction Line Valve is opened when spraying is resumed. Damage to Spray Pump will result when operating the Sprayer with Valve closed.**

### BELT TENSION:



### DANGER

**ROTATING PULLEYS AND BELTS CAN CAUSE SERIOUS INJURY.**

- Keep hands, feet and clothing clear while engine is running.
- Stop engine before attempting any belt adjustment.

The best tension for a V belt drive is the lowest tension at which the Belt will not slip under the highest load condition. Too much tension shortens Belt and Bearing life.

Keep Belt and Pulley free from any foreign material which may cause slippage. If a V belt slips, tighten it.

Check the tension on a new drive Belt **frequently** during the **first day** of operation and periodically thereafter.

Check and maintain the clearances between all Belt Guides and the outside surfaces of the Belts at 1/8 inch.

After every 200 hours of operation, check the tension of all Belts and clearances of Belt Guides. If a Belt shows signs of cracks or fraying, install a new Belt.

### CONTROL CONSOLE:

Always cover or otherwise protect the Control Console from moisture to prevent damage to the electronic system.

# MAINTENANCE

## FLOW METER:

Once per season the Flow Meter should be flushed and cleaned. Perform this procedure more often if suspension type products are being sprayed.

1. Thoroughly rinse and drain the entire spraying system.
2. Remove Flow Meter from Sprayer and flush with clean water to remove any chemicals.
3. Remove flange bolts from the Flow Meter. See FIG. 7.




FIG. 7

- |                |                  |
|----------------|------------------|
| 1. Flange Bolt | 4. Transducer    |
| 2. Turbine Hub | 5. Turbine Stud  |
| 3. Turbine     | 6. O-Ring, Viton |

4. Remove the turbine hub and turbine from inside Flow Meter.

5. Clean turbine and turbine hub of metal filings and any other foreign material, such as wettable powders. Confirm that turbine blades are not worn. Hold turbine hub and turbine in your hand and spin turbine. It should spin freely with very little drag.

6. If transducer assembly is replaced or if turbine stud is adjusted or replaced, verify the turbine fit before reassembling. Hold turbine hub with turbine on transducer. Spin turbine by blowing on it. Tighten turbine stud until turbine stalls. Loosen turbine stud 1/3 turn: the turbine should spin freely.

7. Reassemble Flow Meter.

8. Using a low pressure 5 PSI [50 kPa] jet of air, verify that the turbine spins freely. If there is drag, loosen the turbine stud on the bottom of the turbine hub by 1/3 turn, until the turbine spins freely.

## PROCEDURE TO TEST THE FLOW METER CABLE:

Disconnect the Console Control Cable from the Flow Meter Cable. Hold the cable connector so that the key way is pointing in the 12 o'clock position. See FIG. 8.




FIG. 8

## VOLTAGE READINGS

- 2 o'clock to 6 o'clock (+5 VDC)
- 2 o'clock to 10 o'clock (+5 VDC)

1. Record METER CAL value \_\_\_\_\_
2. Enter a METER CAL number of one (1) in key labeled: 
3. Depress key labeled: 
4. Place MASTER and BOOM switches ON.
5. With small jumper wire (or paper clip), short between 2 o'clock and 6 o'clock sockets with a "short - no short" motion. Each time a contact is made, the TOTAL VOLUME total should increment up 1 or more counts.
6. If TOTAL VOLUME does not count up. Replace defective cable.
7. Perform above voltage checks.
8. If cables all test good, refer to test Flow Meter.

**NOTE:** After testing is complete, re-enter correct METER CAL number before spraying.

# MAINTENANCE

## PROCEDURE TO RE-CALIBRATE FLOW METER:

1. Enter a METER CAL number of 10 [38] in key labeled: 
2. Enter a TOTAL VOLUME of 0 in key labeled: 
3. Switch OFF Boom 2 and Boom 3.
4. Remove Boom 1 hose at boom connection and place the hose in a 5 gallon [19 liter] container.
5. Switch on Boom 1 and pump exactly 10 gallons [38 liter], two 5 gallon [19 liter] buckets.
6. The readout in TOTAL VOLUME is your new METER CAL number. (Under normal circumstances, this number should be within +/- 3% of the number stamped on the tag on Flow Meter).
7. Repeat procedure several times to confirm accuracy. (Always "zero out" TOTAL VOLUME display before retesting).

NOTE: for greatest precision, set METER CAL to 100 [378] and pump 100 gallons [378 liters] of water.

8. Enter correct METER CAL number before resuming chemical spraying.

An alternate method of calibrating your Flow Meter is to fill your applicator tank with a pre-determined amount of liquid. Set your METER CAL to the number on the tag attached to the Flow Meter. Then go out and spray until the tank is empty. The number in the TOTAL VOLUME display should be the same as the amount you put in the tank. If not, increase or decrease the METER CAL by the percentage difference.

## PROCEDURE TO TEST SPEED SENSOR TO CONSOLE CONNECTION:

Disconnect the Speed Sensor Switch Assembly Cable from the back of the Control Console. See diagram of Console receptacle in FIG. 9.




FIG. 9

### VOLTAGE READINGS

- 10 o'clock to 6 o'clock (+5 VDC)
- 10 o'clock to 2 o'clock (+5 VDC)

1. Record SPEED CAL value \_\_\_\_\_.
2. Enter a SPEED CAL number of 1,000 in key labeled: 
3. Depress key labeled: 
4. With small jumper wire (or paper clip), short between 10 o'clock and 6 o'clock sockets with a "short - no short" motion. This should cause a speed reading to be displayed in the Console. If speed reading is displayed, Console power is confirmed. Therefore, replace Speed Sensor Switch Assembly.
5. If no speed reading is displayed, refer to "CONSOLE TROUBLESHOOTING", pages 18, 19 and 20.

NOTE: After testing is complete, re-enter correct SPEED CAL number before spraying.

# MAINTENANCE

## TROUBLESHOOTING GUIDE

| NO. | PROBLEM                                                                    | CORRECTIVE ACTION                                                                                                                                                                                                                                              |
|-----|----------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1   | NO DISPLAY LIGHTS WITH POWER ON                                            | <ol style="list-style-type: none"> <li>1 Check fuse on back of Console.</li> <li>2 Check battery connections</li> <li>3 Check operation of POWER ON/OFF switch.</li> <li>4 Return Console to Raven, Inc. to replace Processor Board Assembly.</li> </ol>       |
| 2   | ALL KEYBOARD LIGHTS ON AT SAME TIME                                        | <ol style="list-style-type: none"> <li>1 Return Console to Raven, Inc. to replace Processor Board Assembly.</li> </ol>                                                                                                                                         |
| 3   | A DIGIT CAN NOT BE ENTERED VIA KEYBOARD                                    | <ol style="list-style-type: none"> <li>1 Return Console to Raven, Inc. to replace Face Plate Sub-assembly.</li> </ol>                                                                                                                                          |
| 4   | AN INDICATOR LIGHT ON A KEY WILL NOT ILLUMINATE                            | <ol style="list-style-type: none"> <li>1 Return Console to Raven, Inc. to replace Face Place Sub-assembly and/or Processor Board Assembly.</li> </ol>                                                                                                          |
| 5   | CONSOLE DISPLAYS FLASHING "CAL" WHENEVER VEHICLE ENGINE IS STARTED         | <ol style="list-style-type: none"> <li>1 Check battery voltage and battery connections.</li> <li>2 Install stand-by 9-volt "alkaline" battery in battery box at rear of Console, (Duracell MN1604 or Eveready 522).</li> </ol>                                 |
| 6   | CONSOLE DISPLAYS FLASHING "CAL" WHENEVER MASTER SWITCH IS TURNED ON OR OFF | <ol style="list-style-type: none"> <li>1 Check battery voltage and battery connections.</li> </ol>                                                                                                                                                             |
| 7   | CONSOLE DISPLAYS FLASHING "CAL" WHENEVER SPEED IS CHANGED                  | <ol style="list-style-type: none"> <li>1 Check battery voltage and battery connections.</li> <li>2 Check for bad spark plug wires with engine analysis computer.</li> </ol>                                                                                    |
| 8   | TIME FUNCTION IS INACCURATE OR DRIFTING                                    | <ol style="list-style-type: none"> <li>1 Return Console to Raven, Inc. to replace Processor Board Assembly.</li> </ol>                                                                                                                                         |
| 9   | ONE DISPLAY DIGIT HAS ONE OR MORE MISSING SEGMENTS                         | <ol style="list-style-type: none"> <li>1 Return Console to Raven, Inc. to replace LCD Display Board Assembly.</li> </ol>                                                                                                                                       |
| 10  | SPEED DISPLAY "0"                                                          | <ol style="list-style-type: none"> <li>1 Check Speed Sensor switch cable connector and plug on back of Console for loose pins.</li> <li>2 Clean pins and sockets on Speed Sensor cable connectors.</li> <li>3 Replace Speed Sensor Switch Assembly.</li> </ol> |

# MAINTENANCE

## TROUBLESHOOTING GUIDE (Cont'd)

| NO. | PROBLEM                      | CORRECTIVE ACTION                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|-----|------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 11  | SPEED INACCURATE OR UNSTABLE | <ol style="list-style-type: none"> <li>1 Run speed check on hard surface road. If SPEED is not accurate, verify the clearance gap between the Wheel Magnets and the Switch Assembly. The gap should be 1/4 to 1". Adjust switch bracketry if required.</li> <li>2 Remove one red magnet and one black magnet from the wheel. (Reposition remaining red and black magnets directly across from each other). Enter a SPEED CAL number in the Console twice as large as the correct SPEED CAL number. Run speed check on hard surf.</li> </ol>                                                                                                       |
| 12  | RATE READS "0000"            | <ol style="list-style-type: none"> <li>1 Verify Speed is registering accurately. If SPEED is zero, refer to Troubleshooting Problem 11.</li> <li>2 Verify TOTAL VOLUME is registering flow. If not, refer to Troubleshooting Problem 16.</li> </ol>                                                                                                                                                                                                                                                                                                                                                                                               |
| 13  | RATE INACCURATE OR UNSTABLE  | <ol style="list-style-type: none"> <li>1 Verify that all numbers "keyed in" Console are correct. Verify SPEED is registering accurately. If SPEED is inaccurate, refer to Troubleshooting Problem 11.</li> <li>2 In MAN (Manual) operation, verify that RATE display (GPA) holds constant when SPEED is held constant. If not, refer to Troubleshooting Problem 17.</li> <li>3 In MAN (manual) operation, check low end and high end pressure range. If pressure can not be adjusted manually, refer to Troubleshooting Problem 14.</li> <li>4 If problem persists, return Console to Raven, Inc. to replace Processor Board Assembly.</li> </ol> |

# MAINTENANCE

## TROUBLESHOOTING GUIDE (Cont'd)

| NO. | PROBLEM                                            | CORRECTIVE ACTION                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|-----|----------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 14  | CAN NOT VARY RATE IN MANUAL OPERATION OR IN AUTO   | <ol style="list-style-type: none"> <li>1 Check cabling to motorized Control Valve for breaks.</li> <li>2 Check connections in cabling for cleanliness.</li> <li>3 Verify that there is voltage at the valve connector by placing MASTER switch ON; RATE 1 / RATE 2 / MAN switch to MAN; and Power switch to ON. Manually operate INCR/DECR switch to verify voltage.</li> <li>4 Verify that valve is turning, if not, replace motorized Control Valve.</li> </ol> |
| 15  | SPRAYER PRESSURE IS CORRECT BUT RATE IS LOW        | <ol style="list-style-type: none"> <li>1 Verify that nozzle strainer screens or check valves are not plugged.</li> <li>2 Verify that pressure at each boom is the same.</li> <li>3 Verify all nozzles are of proper and same orifice size.</li> </ol>                                                                                                                                                                                                             |
| 16  | TOTAL VOLUME DOES NOT REGISTER                     | <ol style="list-style-type: none"> <li>1 Check Flow Meter cable for breaks and shorts. See Page 16 for test procedure.</li> <li>2 Check internals of Flow Meter; clean and adjust. See Page 16.</li> <li>3 Replace Flow Meter Transducer.</li> </ol>                                                                                                                                                                                                              |
| 17  | TOTAL VOLUME REGISTERS FLOW INACCURATELY           | <ol style="list-style-type: none"> <li>1 Verify that arrow on Flow Meter is pointing in direction of flow.</li> <li>2 See Page 16 and 17.</li> </ol>                                                                                                                                                                                                                                                                                                              |
| 18  | MOTORIZED CONTROL VALVE ROTATES MORE THAN 1/4 TURN | <ol style="list-style-type: none"> <li>1 Replace motorized Control Valve.</li> </ol>                                                                                                                                                                                                                                                                                                                                                                              |
| 19  | WATER INSIDE COVER OF MOTORIZED CONTROL VALVE      | <ol style="list-style-type: none"> <li>1 Replace Isolation Flange Assy. and Coupler Shaft. See Page 23.</li> <li>2 Replace entire motorized Control Valve, if PC Board or Motor is corroded and will not turn.</li> </ol>                                                                                                                                                                                                                                         |
| 20  | BOOM SOLENOID(S) WILL NOT OPERATE                  | <ol style="list-style-type: none"> <li>1 Check cable for wires with breaks.</li> <li>2 Check connectors for cleanliness.</li> <li>3 Check BOOM switch and MASTER switch for operation.</li> <li>4 Service Boom Solenoid Valve. See Pages 24 and 25.</li> </ol>                                                                                                                                                                                                    |

# MAINTENANCE

## CENTRIFUGAL PUMP SEAL PROBLEM TROUBLESHOOTING

| Trouble                                                              | Probable Cause                                                                                         | Remedy                                                                                                                                     |
|----------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------|
| 1. Cracked or broken stationary seat (Ceramic)                       | Seal ran dry and heated up. When liquid reached seal faces it was cooler, causing thermal cracks.      | Check to insure seal chamber is full of liquid before starting pump. On high temperature application insure proper flushing at seal faces. |
| 2. Carbon washer scored                                              | Dirty System.                                                                                          | Have system cleaned and flushed. grooved.                                                                                                  |
| 3. Carbon washer worn                                                | Seal improperly installed. unevenly.                                                                   | Check installation instructions for proper assembly.                                                                                       |
| 4. Rubber bellows of seal are hard and brittle<br>Rapid carbon wear. | Did pump run dry or cavitate.                                                                          | Check to insure seal chamber is full of liquid before starting pump.                                                                       |
| 5. Retainer drive tabs badly worn or broken.                         | Periodic loss of lubrication at seal faces.                                                            | Insure proper flushing at seal faces.                                                                                                      |
| 6. Flexible bellows broken.                                          | Seal improperly installed.                                                                             | Check installation instructions for proper assembly.                                                                                       |
| 7. Seal wears out shaft.                                             | Check bearings for shaft end play. Check bearings for shaft radial movement. Check shaft straightness. | Replace bearings.<br>Replace shaft.                                                                                                        |

# MAINTENANCE

Always flush pump with water, or neutralizing agent before servicing.

Refer to the illustrated Parts List for part ordering information.

## Pump Housing Disassembly

In most cases, seal replacement requires disassembly of only the pump half of the unit.

1. Remove the four casing cap screws with 9/16" box end wrench. Tap pump casing on discharge port with rubber hammer, if necessary, to break loose from mounting flange. Check inside of pump casing including suction port. If badly eroded (or damaged), pump casing should be replaced. Remove O-ring and discard. O-ring should always be replaced.

2. To remove the impeller nut, clamp the flange in a vise and insert a large screwdriver or file (at least 10" long) into impeller vanes to prevent impeller from turning when loosening nut. Use a 5/8" box end or socket wrench to remove the impeller nut by turning it counter-clockwise. See FIG. 10.




FIG. 10

3. Once nut is removed, place a screwdriver on each side (FIG. 10) behind the impeller and pry away from the mounting flange. Remove woodruff key from the shaft. Remove O-ring from the mounting flange.

## Pump Seal Removal

1. Lightly lubricate shaft with mineral oil or glycerin for easier removal of seal. Using two screwdrivers positioned opposite each other, pry the rotary portion of the seal from the shaft. See FIG. 11.




FIG. 11

2. Remove stationary seat and boot by prying out with two small screwdrivers in manner similar to impeller removal. (Caution: The seal will be damaged by removal in this manner. A new seal and rubber gasket **MUST** be used when pump is reassembled.)

## Clean-Up of Pump Housing

1. Using a circular bottle-type wire brush with air or hand drill, clean the discharge port, suction port and the sealing areas of the O-ring on the pump casing and mounting flange.

2. After wire brush cleaning, it is recommended that the pump casing and mounting flange be further cleaned in a solvent tank to remove rust and corrosion particles.

## Seal Replacement/Pump Housing Reassembly

**NOTE:** Reassemble if drive end is not to be repaired.

Be extremely careful with the new seal. Take special care not to scratch the lapped sealing faces of the rotary washer and stationary seat.

1. Lubricate seal cavity in mounting flange with mineral oil or glycerin.

2. Install the stationary portion of the mechanical seal by sliding over the shaft with the ceramic side out.

**IMPORTANT:** Make sure both seal cavity and seal are clean and lubricated. **Never run the sealing faces dry.**

3. To seat the seal in the seal cavity, use a piece of 3/4" PVC pipe 4" to 6" in length. Press it in firmly and squarely.

## MAINTENANCE

4. To install the rotary portion of the mechanical seal, place it over the shaft with the carbon side facing in, and press until it bottoms out against the stationary portion. Install rubber spacer. See FIG. 11.

5. Insert key into shaft key slot. Place impeller on shaft. Put impeller nut on shaft end using a large screwdriver or file in the impeller vanes for support, tighten impeller nut securely.

6. Install O-ring on mounting flange. Replace O-ring.

7. Place pump casing on mounting flange, insert and tighten bolts evenly.

### MOTORIZED CONTROL VALVE

**Replace** the valve body with the iso-body kit (10) if the valve has been leaking internally.

**Replace** the motor assembly if the motor will not run or if the printed circuit board is corroded.

Before reassembling valve, remove the coupler shaft from the valve body. Apply Loctite to the coupler shaft (5) and the woodruff key (4). Place the coupler shaft and the woodruff key onto the motor shaft. Plug motor into the valve connector coming from the Sprayer Control Console. In manual mode operate INC/DEC switch to assure the motor rotates in both directions. Motor must stop when the coupler shaft cam releases the printed circuit board switch button.

When reassembling the valve, grease both sealing surfaces of the coupler shaft. Insert the coupler shaft into the iso-flange (9) and be sure seal properly seats on the shaft. Install on valve body and apply RTV 738 or equivalent to the mounting holes. Reassemble remaining items as shown in the parts diagram, FIG. 12.




FIG. 12

- |                   |                     |
|-------------------|---------------------|
| 1. Valve Cover    | 6. Seal             |
| 2. Screw          | 7. Valve Body       |
| 3. Motor Assembly | 8. Butterfly        |
| 4. Woodruff Key   | 9. Isolation Flange |
| 5. Coupler Shaft  | 10. ISO-Body Kit    |

# MAINTENANCE

## TROUBLESHOOTING THE 95-9237 SOLENOID VALVE

| CONDITION                                                | POSSIBLE CAUSES                                                       | HOW TO CHECK                                                                                                                                                                                                         |
|----------------------------------------------------------|-----------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1. Valve won't open                                      | <b>A.</b> No electrical power to valve                                | Manually activate valve. If stem moves freely, check and clean electrical connections. Inspect electrical system.                                                                                                    |
|                                                          | <b>B.</b> Stem movement restricted                                    | Manually activate stem by pushing on lower diaphragm piston. If more than 5 lbs. of force is required to move stem, disassemble valve, inspect and clean all parts.                                                  |
| 2. Valve won't shut off                                  | <b>A.</b> Spring malfunction                                          | Manually activate stem. Stem should offer 2-6 lbs. resistance, but movement should be quick and smooth. If there is very little resistance, disassemble and check spring.                                            |
|                                                          | <b>B.</b> Stem movement restricted                                    | Manually activate stem by pushing on lower diaphragm piston. If more than 5 lbs. of force is required to move stem, disassemble valve, inspect and clean all parts. Replace any damaged or worn parts with new ones. |
|                                                          | <b>C.</b> Seat washer blown out of retainer due to excessive pressure | Remove stem from valve body and inspect condition of seat washer.                                                                                                                                                    |
|                                                          | <b>D.</b> Seat washer worn or damaged                                 | Replace seat washer.                                                                                                                                                                                                 |
| 3. Leakage around coil or around lower diaphragm piston. | <b>A.</b> Ruptured diaphragms                                         | Disassemble valve and replace diaphragms with new ones.                                                                                                                                                              |
| 4. Blowing fuses                                         | <b>A.</b> Short circuit in power                                      | Inspect wires for worn insulation and check connections.                                                                                                                                                             |
|                                                          | <b>B.</b> Short within the coil                                       | Remove connections from coil and activate switch, making sure connections don't touch. If fuse doesn't blow, replace coil.                                                                                           |
| 5. Valve operating properly, but pressure drop too high. | <b>A.</b> Not getting full stroke                                     | Energize coil. Check length of stroke - should be approximately 1/8". If not, remove coil and check for obstructions between armature and armature stop. Clean all parts and reassemble.                             |
|                                                          | <b>B.</b> Obstruction in valve body                                   | Remove inlet and outlet connections and inspect body.                                                                                                                                                                |


# MAINTENANCE

## SOLENOID VALVE:

**IMPORTANT:** Before performing any maintenance, make sure electrical power to the coil is shut off and line pressure is relieved.

- Keep all electrical connections and coil clean at all times.
- A protective coating may be applied to the completed electrical connections if desired.
- Do not apply lubricating oils or other petroleum products to the valves, as this may cause swelling of the rubber parts. Also, check with the chemical manufacturer to be sure chemicals being used are compatible with the valve components.

See parts drawing below for reference numbers in parentheses ( ).



## TO REPLACE COIL ONLY:

1. Shut off power to coil.
2. Disconnect wires from terminals.
3. Loosen four screws (15) that secure body to coil assembly.
4. Lift off coil (1) and replace with new coil.
5. Thread four screws (15) into new coil assembly (1) and uniformly tighten to secure body.

## TO REPLACE DIAPHRAGMS AND SEAT WASHER:

1. Remove the four screws (15) that secure the lower diaphragm housing and separate coil assembly (1). Remove the lower diaphragm housing (14).

2. Remove spring (4) from armature (3).

3. Secure hole in armature (3) with 1/4" diameter rod or an allen wrench. Unscrew entire assembly with screwdriver secured in slot of lower diaphragm piston (13).

**NOTE: Stem/Seat/Diaphragm/upper diaphragm housing assembly may unscrew at lower diaphragm piston (13) or at armature (3).**

4. If lower diaphragm piston (13) unscrews, remove diaphragm (6) and washer (12) and inspect or replace as necessary. Remaining seat/upper assembly may be removed from top of polypropylene body (12) and disassembled by securing flats on stem (11) and unscrewing armature (3). Seat washer retainer (7) will then slide from the stem (11). Separate the upper diaphragm housing (2) and upper diaphragm from the seat washer retainer (7).

5. If armature (3) unscrews, remove the upper diaphragm housing (2) and the diaphragm (6). The seat washer retainer (7) slides off the stem (11) which allows the spacer (9) and seat washer (8) to be removed. The lower diaphragm piston (13) can be disassembled from the stem (11) by securing the stem with a wrench and unscrewing the lower diaphragm piston (13).

## TO REASSEMBLE:

1. Reassemble seat washer retainer (7), seat washer (8) and spacer (9) onto stem (11).

2. Reassemble upper diaphragm (6) (with "Fluid Side" marking facing valve body), the upper diaphragm housing (2) and armature (3) onto stem end (11) and tighten securely against the seat washer retainer (7).

3. Insert the entire subassembly into valve body (10) from top. Screw lower diaphragm piston (13) with diaphragm (6) and washer (12) in proper order into bottom end of stem assembly. Tighten snugly with screwdriver.

4. Reinstall spring (4) over armature (3). Place coil assembly (1) on top of upper diaphragm housing (2).

# MAINTENANCE

## SOLENOID VALVE (Cont'd)

5. Position valve body subassembly and coil subassembly together.

6. Replace lower diaphragm housing (14). Secure coil assembly (1), body subassembly and lower diaphragm housing (14) using four screws (15). Care must be exercised to uniformly tighten the retaining screws (15).

7. Replace electrical connections. There is no positive or negative terminal.

# STORAGE

## FLUSH PUMP AFTER USE

One of the most common causes for faulty pump performance is “gumming” or corrosion inside the pump. Flush the pump and entire system with a solution that will chemically neutralize the liquid pumped. Mix according to manufacturer’s directions. This will dissolve most residue remaining in the pump, leaving the inside of the pump clean for the next use.

## TO PREVENT CORROSION

After cleaning the pump as directed above, flush it with a permanent type automobile antifreeze (Prestone, Zerex, etc.) containing a rust inhibitor. Use a 50% solution - that is, half antifreeze and half water, or fill pump with FLUID FILM and then drain it. A protective coating of FLUID FILM will remain on the inner pump surfaces. Save the excess FLUID FILM for the next application. Plug the ports to keep out air during storage. For short periods of idleness, non-corrosive liquids may be left in the pump, BUT AIR MUST BE KEPT OUT. Plug ports or seal port connections.

**IMPORTANT: FREEZING TEMPERATURES MAY DAMAGE THE PUMP, FLOWMETER, THE MOTORIZED CONTROL VALVE, AND THE ELECTRIC SOLENOIDS IF THE WATER IS NOT DRAINED COMPLETELY!**

Remove and clean the Flow Meter at the end of each spraying season. See page 16. Clean Flow Meter turbine and inlet hub. Clean off all metal filings and wettable powders which have hardened on the plastic and metal parts. Check the inlet hub and turbine assembly for worn or damaged turbine blades and bearings. Flush Flow Meter with clear water and drain.

**IMPORTANT! When a high pressure washer or garden hose is used for cleaning, it is necessary to cover or otherwise protect the control Console. Water entering the Control Console will cause serious damage, to the electronic system.**

Remove the Control Console from the Vehicle for storage, or otherwise protect it from the elements.

Should the Control Console require service, refer to the serial number decal on the bottom of the console when requesting assistance or information from your TORO distributor.

## SERVICING AFTER STORAGE:

Flush the entire spraying system with clean water and detergent.

Flush the entire spraying system again with clean, clear water to rinse.

Drain entire spraying system.

## STORAGE AND DISPOSAL OF CHEMICALS:

Follow chemical manufacturer’s recommendations for storage and disposal of chemicals.

# PERFORMANCE VERIFICATION

Refer to the preceding information in this manual for complete and detailed instructions.  
Follow all Safety Instructions .

## Gallons Per Acre

Determine Desired Application Rate From Manufacturers Labeling \_\_\_\_\_ G.P.A.

Determine a Vehicle Application Speed \_\_\_\_\_ M.P.H.

Verify Nozzle Spacing is 20".

Determine Gallons Per Minute \_\_\_\_\_ G.P.M. (See **Nozzle Chart on Page 7**) and Use The Following Formula to verify.

$$\frac{\text{G.P.A.} \times \text{M.P.H.} \times 20''}{5940} = \frac{\text{ } \times \text{ } \times 20}{5940} = \text{ } \text{G.P.M.}$$

Select Nozzle Size (See **Nozzle Chart on Page 7**) \_\_\_\_\_ based on G.P.M.

Determine Application Pressure \_\_\_\_\_ P.S.I. (See **Nozzle Chart on Page 7**).

## Gallons Per 1,000 sq. ft.

Determine Desired Application Rate From Manufacturers Labeling \_\_\_\_\_ G.P. 1,000 sq. ft.

Determine a Vehicle Application Speed \_\_\_\_\_ M.P.H.

Verify Nozzle Spacing is 20"

Determine Gallons Per Minute \_\_\_\_\_ G.P.M. ( See **Nozzle Chart on Page 7**) and Use The Following Formula to verify

$$\frac{\text{G.P. 1,000 sq. ft.} \times \text{M.P.H.} \times 20''}{136} = \frac{\text{ } \times \text{ } \times 20}{136} = \text{ } \text{G.P.M.}$$

Select Nozzle Size (See **Nozzle Chart on Page 7**) based on G.P.M.

Determine Application Pressure \_\_\_\_\_ P.S.I. (See **Nozzle Chart on Page 7**)

## Set Up Spray System

### Set Parking Brake.

Fill tank ½ full with water **DO NOT** add Chemical at this time.

Install Correct Nozzles.

Open Suction, Bypass, and Agitation Valve Handles.

Program Pro Control™ Console

Drive Vehicle at Selected Spraying Speed \_\_\_\_\_ MPH.

Engage Pump Lever.

Turn Booms On.

Visually Inspect The Output Of All Nozzles.

Record Engine RPM at Selected Spraying Speed, \_\_\_\_\_ RPM.

Verify Pro Control Will Hold Preset Rate At Selected Speed.

Turn Booms Off.

Disengage Pump Lever.

Perform Rate Check.

*High application rates may necessitate the reduction of bypass volume to maintain application pressure.*

## Rate Check

Verify G.P.A. application rate via **1/128th Acre Method**

Mark off a test course in a flat area at 204 feet.

Drive the Sprayer with a ½ full tank of water at selected **application speed** and record the time it takes to drive 204 feet. \_\_\_\_\_ seconds. **NOTE: It is important to maintain your application speed during test.**

## Rate Check (Cont'd)

Park Vehicle. **SET PARKING BRAKE.**

Engage pump, turn on all booms and maintain the same engine RPM used to drive the test course to maintain the application rate pressure.

Set Pro Control in Self Test Mode (enter your **application speed**).

Hold a graduated cylinder under the far left nozzle on the left boom. Collect the output for the same amount of time that it took to travel 204 ft.

Each ounce of fluid collected equals a 1 gallon per acre application rate.

Repeat collection test twice for each nozzle record amount collected each test below.

*Proceed through each column separately and completely.*

**Each Nozzle Should Be Within  $\pm 5\%$  Of The GPA Average Of All Nozzles**

**Replace Each Nozzle Not  $\pm 5\%$  Of The GPA Average Range**

**Replace All Nozzles If Two or More Are Not Within The  $\pm 5\%$  GPA Range**

|           |      |        |
|-----------|------|--------|
| #1        |      | oz/GPA |
| #2        |      | oz/GPA |
| #3        |      | oz/GPA |
| #4        |      | oz/GPA |
| #5        |      | oz/GPA |
| #6        |      | oz/GPA |
| #7        |      | oz/GPA |
| #8        |      | oz/GPA |
| #9        |      | oz/GPA |
| #10       |      | oz/GPA |
| #11       |      | oz/GPA |
| Total     |      |        |
|           | ÷ 11 |        |
| Average 1 |      | GPA    |

|           |      |        |
|-----------|------|--------|
| #1        |      | oz/GPA |
| #2        |      | oz/GPA |
| #3        |      | oz/GPA |
| #4        |      | oz/GPA |
| #5        |      | oz/GPA |
| #6        |      | oz/GPA |
| #7        |      | oz/GPA |
| #8        |      | oz/GPA |
| #9        |      | oz/GPA |
| #10       |      | oz/GPA |
| #11       |      | oz/GPA |
| Total     |      |        |
|           | ÷ 11 |        |
| Average 1 |      | GPA    |

Both Averages Should Be Within 5% Of Each Other

## CALCULATE RANGE

**Gallons Per Acre**

$$\begin{aligned} \text{Average 1 } \underline{\hspace{1cm}} \times .95 &= \boxed{\hspace{1cm}} = -5\% \\ \text{Average 1 } \underline{\hspace{1cm}} \times 1.05 &= \boxed{\hspace{1cm}} = +5\% \end{aligned}$$

(GPA Range)

Your GPA Application Rate must fall within the GPA Range

**Gallons Per 1,000 sq. ft.**

$$\begin{aligned} \text{Average 1 } \underline{\hspace{1cm}} \times .95 &= \boxed{\hspace{1cm}} \div 43.56 = \boxed{\hspace{1cm}} = -5\% \text{ G.P. 1,000 sq. ft.} \\ \text{Average 1 } \underline{\hspace{1cm}} \times 1.05 &= \boxed{\hspace{1cm}} \div 43.56 = \boxed{\hspace{1cm}} = +5\% \text{ G.P. 1,000 sq. ft.} \end{aligned}$$

(GPA Range)                      (GP 1,000 sq. ft. Range)

Your GP 1,000 sq. ft. Application Rate must fall within the GP 1,000 sq. ft. Range

# CONTENTS

|                                           |         |
|-------------------------------------------|---------|
| SAFETY INSTRUCTIONS .....                 | 1&2     |
| RECOGNIZE SAFETY INFORMATION .....        | 1       |
| BEFORE OPERATING: .....                   | 1       |
| WHILE OPERATING: .....                    | 2       |
| MAINTENANCE: .....                        | 2       |
| SAFETY & INSTRUCTION DECALS .....         | 2       |
| INTRODUCTION .....                        | 3       |
| CONTROLS .....                            | 3       |
| CONSOLE FEATURES .....                    | 4       |
| BEFORE SPRAYING .....                     | 5       |
| CONSOLE CALIBRATION: .....                | 5       |
| CALCULATING "BOOM CAL" .....              | 5       |
| CALCULATING "SPEED CAL" .....             | 5       |
| CALCULATING "METER CAL" .....             | 5       |
| CALCULATING "VALVE CAL" .....             | 5       |
| CALCULATING "RATE1" AND "RATE 2" .....    | 5       |
| FOUMULAS & SYMBOL DEFINITIONS: .....      | 6       |
| NOZZLE SELECTION .....                    | 7       |
| CONSOLE PROGRAMMING: .....                | 9       |
| DATA ENTRY: .....                         | 9       |
| INITIAL CONSOLE PROGRAMMING: .....        | 9       |
| OTHER DISPLAY FEATURES: .....             | 10      |
| SELF TEST FEATURE .....                   | 10      |
| DATA-LOCK .....                           | 10 & 11 |
| POWER DOWN .....                          | 11      |
| CONSOLE ALARM .....                       | 11      |
| DISPLAY MENU: .....                       | 11      |
| LOW LIMIT FLOW & ALARM .....              | 11      |
| CONTROL VALVE DELAY .....                 | 11      |
| INITIAL SYSTEM SET-UP: .....              | 12      |
| INITIAL SYSTEM FIELD TEST: .....          | 12 & 13 |
| FILL THE CLEAN WATER WASH TANK .....      | 13      |
| OPERATION .....                           | 14      |
| USING THE SPRAYER: .....                  | 14      |
| AFTER SPRAYING: .....                     | 14      |
| PREVENTIVE MAINTENANCE .....              | 15      |
| MAINTENANCE .....                         | 16      |
| FLOW METER: .....                         | 16 & 17 |
| SPEED SENSOR .....                        | 17      |
| TROUBLESHOOTING GUIDE .....               | 18 - 20 |
| CENTRIFUGAL PUMP TROUBLESHOOTING .....    | 21 & 23 |
| MOTORIZED CONTROL VALVE .....             | 23      |
| TROUBLESHOOTING SOLENOID VALVE .....      | 24 - 26 |
| STORAGE .....                             | 26      |
| FLUSH PUMP AFTER USE .....                | 26      |
| TO PREVENT CORROSION .....                | 26      |
| SERVICING AFTER STORAGE: .....            | 26      |
| STORAGE AND DISPOSAL OF CHEMICALS: .....  | 26      |
| PERFORMANCE VERIFICATION .....            | 27      |
| SET-UP SPRAY SYSTEM .....                 | 27      |
| RATE CHECK .....                          | 27 & 28 |
| CALCULATE RANGE .....                     | 28      |
| CONTENTS .....                            | 29      |
| CONSOLE PROGRAMMING QUICK REFERENCE ..... | 30 & 31 |

# MULTI PRO® 1100

## INITIAL CONSOLE PROGRAMMING

When you first turn on Console power, after all installation procedures have been completed, the Console will flash "CAL" in the RATE display. This means you must "calibrate" or program the Console before it can be operated. (This is a one-time operation which does not have to be repeated. Turning OFF the POWER ON/OFF Switch does not affect the Console memory. All data is retained.)

**The following steps must be followed:**

If an entry selection error is made during steps 1,2 or 3, the Console can be reset by depressing  for 20 seconds (data displays US.), on Console Model 063019531. On Console Model 063017269, turn power off, hold  and power on at the same time to reset programming.

### **Step 1**

Selecting US (Acres), SI [Hectares], or TU {1,000 Sq. Ft.}

- (a) Momentarily depress  until you reach the desired setting (US, SI or TU).
- (b) Once the desired setting has been reached, momentarily depress  to lock in your selection. The DATA display will now display SP1.

### **Step 2**

Selecting SP1 & 3 (Wheel Drives, etc.) or SP2 (Radar Sensor).

**NOTE: THE TORO MULTI PRO 1100 USES THE WHEEL DRIVE SETTING (SP1), THEREFORE YOUR ENTRY SHOULD BE SP1.**

Momentarily depress  until you reach the (SP1) setting, then momentarily depress  to lock in your setting.

**Step 3** *Note: Step 3 may be needed on some Consoles. If not continue to back of this card.*

Momentarily depress  until you reach the (C-Sd) setting.  
Momentarily depress  to lock in your setting.

*Refer to the back of this card to complete console programming.*

# Multi Pro® 1100 PRO CONTROL SPRAY SYSTEM

*\*Calibration numbers listed are for reference only. Before spraying, check your sprayer to confirm the numbers used are correct.*

|                                                                                                                            |                           |                               |                                                                                                              |
|----------------------------------------------------------------------------------------------------------------------------|---------------------------|-------------------------------|--------------------------------------------------------------------------------------------------------------|
| <b>* Use 80" [204 cm]</b><br>Number of nozzles<br>x spacing in<br>inches [cm] of left boom.                                | <b>BOOM 1</b><br>CAL<br>1 | <b>CE</b>                     | Clear entry - Will clear a<br>wrong entry. Also used<br>in Initial programming to<br>toggle between settings |
| <b>* Use 60" [152 cm]</b><br>Number of nozzles<br>x spacing in inches [cm]<br>of center boom.                              | <b>BOOM 2</b><br>CAL<br>2 | <b>TOTAL</b><br><b>AREA</b>   | Totals area covered in<br>acres, 1000 Sq. Ft.<br>or ltr/ha until<br>cleared to zero.                         |
| <b>* Use 80" [204 cm]</b><br>Number of nozzles<br>x spacing in<br>inches [cm] of right boom.                               | <b>BOOM 3</b><br>CAL<br>3 | <b>TOTAL</b><br><b>VOLUME</b> | Monitors volume applied<br>in gallons or liters<br>until cleared to zero.                                    |
| <b>* Use 720.</b> Distance in<br>inches for 10 revolutions<br>of tire with wheel sensor.                                   | <b>SPEED</b><br>CAL<br>4  | <b>FIELD</b><br><b>AREA</b>   | Totals area covered in<br>acres, 1000 Sq. Ft.<br>or ltr/ha until<br>cleared to zero.                         |
| Use number stamped on<br>Yellow Label on Flow<br>Meter or White Tag<br>on the Flow Meter's cable.                          | <b>METER</b><br>CAL<br>5  | <b>FIELD</b><br><b>VOLUME</b> | Monitors volume applied<br>in gallons or liters<br>until cleared to zero.                                    |
| <b>* Use 2611.</b> Sets system<br>response: Consult<br>Operator's Manual to<br>modify number.                              | <b>VALVE</b><br>CAL<br>6  | <b>DISTANCE</b>               | Measures distance in<br>feet or meters until<br>cleared to zero.                                             |
| First rate of application<br>in Gal/Acre, Gal/1000<br>Sq. Ft., or lit/ha depending<br>on initial set up.                   | <b>RATE 1</b><br>CAL<br>7 | <b>SPEED</b>                  | Displays speed in MPH<br>or km/h.                                                                            |
| Second rate. If only<br>one rate is used, use<br>same value here,<br>that was used in Rate 1.                              | <b>RATE 2</b><br>CAL<br>8 | <b>VOL/<br/>MIN</b>           | Displays gallons or<br>liters per minute that<br>system is currently<br>using.                               |
| Volume in sprayer tank -<br>Reset volume when filling.                                                                     | <b>VOL</b><br>TANK<br>9   | <b>AREA/<br/>HOUR</b>         | Displays acres, 1000<br>Sq. Ft. or hectare<br>covered per hour<br>at speed driven.                           |
| 24 Hour Clock (Military Time)<br>or Elapsed Timer                                                                          | <b>TIME</b><br>0          | <b>DATA</b><br><b>Menu</b>    | Used For Optional<br>Serial Interface<br>and Printer.                                                        |
| Simulates speed to allow<br>operator to check system<br>operation before applying<br>chemicals while vehicle is<br>parked. | <b>SELF</b><br>TEST<br>↑  | <b>ENTER</b>                  | Used to enter data<br>into console.                                                                          |

## Programming

- (1) Depress the key in which you wish to enter data (i.e. "Boom 1 Cal", "Speed Cal", etc.)
- (2) Depress ENTER.
- (3) Depress the keys corresponding to the number you wish to enter (i.e. "2", "4", etc.)
- (4) Complete the entry by again depressing the ENTER key.

**Consult Operator's Manual For Full Details on Set-Up and Operation**



# The Toro Commercial Products Two Year Limited Warranty

The Toro Company warrants your 1996 or newer Toro Commercial Product ("Product") purchased after January 1, 1997, to be free from defects in materials or workmanship for the period of time listed below. Where a warrantable condition exists, Toro will repair the Product at no cost to you including diagnosis, labor, parts, and transportation. This warranty begins on the date the Product is delivered to the original retail purchaser.

**Warranty Duration: Two years or 1500 operational hours\*, whichever occurs first.**

**\*Product equipped with hour meter**

## Owner Responsibilities:

As the Product owner, you are responsible for required maintenance and adjustments stated in your Owner's Manual. Failure to perform required maintenance and adjustments can be grounds for disallowing a warranty claim.

## Instructions for Obtaining Warranty Service:

You are responsible for notifying the Commercial Products Distributor or Authorized Commercial Products Dealer from whom you purchased the Product as soon as you believe a warrantable condition exists.

If you need help locating a Commercial Products Distributor or Authorized Dealer, or if you have questions regarding your warranty rights or responsibilities, you may contact us at:

TORO Commercial Products Service Department  
8111 Lyndale Avenue South  
Minneapolis, MN 55420-1196  
Telephone: (612) 888-8801  
Facsimile: (612) 887-8258  
E-Mail: Commercial.Service@Toro.Com

## Maintenance Parts:

Parts scheduled for replacement as required maintenance ("Maintenance Parts"), are warranted for the period of time up to the scheduled replacement time for that part.

## Items/Conditions Not Covered:

Not all product failures or malfunctions that occur during the warranty period are defects in material or workmanship. The items / conditions listed below are not covered by this warranty:

- Product failures which result from the use of non-Toro replacement parts, or from installation and use of add-on, modified, or unapproved accessories are not covered.
- Product failures which result from failure to perform required maintenance and/or adjustments are not covered.
- Product failures which result from operating the Product in an abusive, negligent, or reckless manner are not covered.

- This warranty does not apply to parts subject to consumption through use unless found to be defective. Examples of parts which are consumed, or used up, during normal Product operation include, but are not limited to, blades, reels, bedknives, tines, spark plugs, castor wheels, tires, filters, belts, etc.
- This warranty does not apply to failures caused by outside influence. Items considered to be outside influence include, but are not limited to, weather, storage practices, contamination, use of unapproved coolants, lubricants, additives, or chemicals, etc.
- This warranty does not apply to normal "wear and tear" items. Normal "Wear and Tear" includes, but is not limited to, damage to seats due to wear or abrasion, worn painted surfaces, scratched decals or windows, etc.

## Other Legal Disclaimers:

The above remedy of product defects through repair by an authorized distributor or dealer is the purchaser's sole remedy for any defect. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

**Except for the Emissions warranty referenced below, If applicable, there is no other express warranty. All implied warranties of merchantability and fitness for use are limited to the duration of the express warranty.**

Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.

**The Toro Company is not liable for indirect, incidental or consequential damages in connection with the use of the Product, including any cost or expense of providing substitute Product or service during periods of malfunction or non-use.**

Some states do not allow the exclusion of incidental or consequential damages, so the above exclusion may not apply to you.

**Note to California residents:** The Emissions Control System on your Product may be covered by a separate warranty meeting requirements established by the U.S. Environmental Protection Agency (EPA), or the California Air Resources Board (CARB). The hour limitations set forth above do not apply to the Emissions Control System Warranty. Refer to the California Emission Control Warranty Statement printed in your Owner's Manual or contained in the engine manufacturer's documentation for details.