


Count on it.

Operator's Manual

Multi Pro® 5800 Turf Sprayer with GeoLink® Precision Spray System

Model No. 41394GK—Serial No. 417382544 and Up



This product complies with all relevant European directives; for details, please see the separate product specific Declaration of Conformity (DOC) sheet.

It is a violation of California Public Resource Code Section 4442 or 4443 to use or operate the engine on any forest-covered, brush-covered, or grass-covered land unless the engine is equipped with a spark arrester, as defined in Section 4442, maintained in effective working order or the engine is constructed, equipped, and maintained for the prevention of fire.

The enclosed engine owner's manual is supplied for information regarding the US Environmental Protection Agency (EPA) and the California Emission Control Regulation of emission systems, maintenance, and warranty. Replacements may be ordered through the engine manufacturer.

A WARNING

CALIFORNIA Proposition 65 Warning

The engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.

Battery posts, terminals, and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and reproductive harm. Wash hands after handling.

Use of this product may cause exposure to chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.

Introduction

This machine is a dedicated turf spray application vehicle and is intended to be used by professional, hired operators in commercial applications. It is designed primarily for spraying on well-maintained lawns in parks, golf courses, sports fields, and on commercial grounds.

This machine is designed primarily for off-road use and is not intended for extensive driving on public roads. Using this product for purposes other than its intended use could prove dangerous to you and bystanders.

Read this information carefully to learn how to operate and maintain your product properly and to avoid injury and product damage. You are responsible for operating the product properly and safely.

Visit www.Toro.com for more information, including safety tips, training materials, accessory information, help finding a dealer, or to register your product.

Whenever you need service, genuine Toro parts, or additional information, contact an Authorized Service Dealer or Toro Customer Service and have the model and serial numbers of your product ready. Figure 1 identifies the location of the model and serial numbers on the product. Write the numbers in the space provided.

Important: With your mobile device, you can scan the QR code on the serial number decal (if equipped) to access warranty, parts, and other product information.




Figure 1

1. Model and serial number location

Model No	
Serial No	

This manual identifies potential hazards and has safety messages identified by the safety-alert symbol (Figure 2), which signals a hazard that may cause serious injury or death if you do not follow the recommended precautions.



Figure 2
Safety-alert symbol

g000502

This manual uses 2 words to highlight information. **Important** calls attention to special mechanical information and **Note** emphasizes general information worthy of special attention.

Safety 4

Contents

General Safety	4
Safety and Instructional Decals	
Setup	
1 Installing the Display	
2 Adjusting the Wheel Angle Sensor	
(WAS)	12
3 Assembling the Sprayer Tank Fill	
Fitting	13
4 Removing the Shipping Bumper	14
5 Installing the CE Kit	
6 Installing the Plus+1 Service Tool	
7 Setting Up and Calibrating the	
Software	21
8 Completing the Setup	24
Product Overview	26
Controls	27
Specifications	32
Attachments/Accessories	32
Before Operation	32
Before Operation Safety	32
Performing Pre-Starting Checks	33
Preparing the Machine	
Breaking in a New Machine	34
Preparing the Sprayer	35
Filling the Tanks	
Agitation-Bypass Valve Knob Position	
Calibrating the Agitation-Bypass Valve	
Locating the Spray Pump	
During Operation	41

During Operation Safety	41
Operating the Machine	
Engine Messaging	
Operating the Sprayer	
Catch Test	
Positioning the Spray Booms	45
Taking Proper Turf Care Precautions while	
Operating in Stationary Modes	46
Spraying Tips	46
Unclogging a Nozzle	
After Operation	
After Operation Safety	
Cleaning the Sprayer	
Hauling the Machine	
Towing the Sprayer	
Maintenance	
Maintenance Safety	
Recommended Maintenance Schedule(s)	54
Daily Maintenance Checklist	
Notation for Areas of Concern	
Pre-Maintenance Procedures	
Raising the Sprayer	
Accessing the Engine	
Lubrication	
Greasing the Spray Pump	
Greasing the Steering and Suspension	
Greasing the Boom Hinges	60
Greasing the Actuator-Rod Bearings	61
Engine Maintenance	
Engine Safety	62
Checking the Air Cleaner	62
Replacing the Air-Filter Element	63
Engine-Oil Specification	
Checking the Engine Oil	
Changing the Engine Oil Filter	04
Changing the Engine Oil Filter	04
Engine-Oil Quantity	65
Changing the Engine Oil	
Checking the PCV Valve	
Performing Yearly Engine Maintenance	66
Fuel System Maintenance	67
Checking the Fuel Line and	
Connections	67
Bleeding the Fuel System	
Servicing the Fuel Filter	
Draining the Fuel Tank	
Electrical System Maintenance	
Electrical System Safety	72
Replacing the Fuses	/2
Servicing the Battery	72
Drive System Maintenance	
Inspecting the Wheels/Tires	74
Gearbox Specification	74
Checking the Gearbox Oil	74
Changing the Gearbox Oil	75
Adjusting the Front Wheel Toe-In	
Cooling System Maintenance	
Cooling System Safety	
Coolant Specifications	
L DOUGHT SHARMING TO THE CONTRACT OF THE CONTR	, ,

Checking the Coolant Level	77
Changing the Coolant	
Brake Maintenance	
Adjusting the Brakes	
Belt Maintenance	
Servicing the Alternator Belt	80
Hydraulic System Maintenance	81
Hydraulic System Safety	81
Hydraulic Fluid Specifications	
Checking the Hydraulic Fluid	81
Replacing the Hydraulic Filters	82
Hydraulic-Fluid Quantity	83
Changing the Hydraulic Fluid	83
Sprayer System Maintenance	
Inspecting the Hoses	84
Changing the Suction Filter	84
Changing the Pressure Filter	84
Changing the Nozzle Filter	
Adjusting the Booms to Level	
Inspecting the Nylon Pivot Bushings	86
Pump Maintenance	
Inspecting the Pump	87
Cleaning	88
Cleaning the Radiator-Cooling Fins	88
Cleaning the Flow Meter	
Storage	89
Storage Safety	89
Preparing the Machine for Storage	89
Troubleshooting	91

Safety

General Safety

This product is capable of causing personal injury. Always follow all safety instructions to avoid serious personal injury.

- Read and understand the contents of this Operator's Manual before starting the engine.
- Use your full attention while operating the machine. Do not engage in any activity that causes distractions; otherwise, injury or property damage may occur.
- Use appropriate personal protective equipment (PPE) to guard against contact with chemicals.
 Chemical substances used in the sprayer system may be hazardous and toxic.
- Do not put your hands or feet near moving components of the machine.
- Do not operate the machine without all guards and other safety protective devices in place and working on the machine.
- Keep clear of any discharge area of the sprayer nozzles and spray drift. Keep bystanders and children out of the operating area.
- Never allow children to operate the machine.
- Park the machine on a level surface, engage the parking brake, shut off the engine, remove the key (if equipped), and wait for all movement to stop before you leave the operator's position. Allow the machine to cool before adjusting, servicing, cleaning, or storing it.

Improperly using or maintaining this machine can result in injury. To reduce the potential for injury, comply with these safety instructions and always pay attention to the safety-alert symbol A, which means Caution, Warning, or Danger—personal safety instruction. Failure to comply with these instructions may result in personal injury or death.

Not all the attachments that adapt to this machine are covered in this manual. Refer to the operator's manual provided with each attachment for additional safety instructions.

Safety and Instructional Decals



Safety decals and instructions are easily visible to the operator and are located near any area of potential danger. Replace any decal that is damaged or missing.



93-6686

decal93-6686


- 1. Hydraulic fluid
- Read the Operator's Manual.



106-5517

decal106-5517


1. Warning—do not touch the hot surface.



107-8667


decal107-8667

- Jacking
- 2. Jack-point locations
- 3. Warning—Read the *Operator's Manual* for more information on jacking the vehicle.




decal107-8724

- 1. Traction drive
- To drive in reverse, press the bottom of the pedal rearward and down.
- To drive forward, press the top of the traction pedal forward and down.
- 4. Vehicle speed increases with more pedal pressure.



decal107-8731

- 107-8731
- 2. Torque the lug nuts to 75 to 102 N·m (55 to 75 ft-lb).



decal107-8732

107-8732

1. Warning—read the Operator's Manual.

1. Warning—read the Operator's Manual.

2. Torque the lug nuts to 95 to 122 N·m (75 to 90 ft-lb).



decal117-3276

117-3276


- Engine coolant under pressure
- 2. Explosion hazard—read the *Operator's Manual*.
- 3. Warning—do not touch the hot surface.
- Warning—read the Operator's Manual.



117-4955

decal117-4955

- Warning—read the Operator's Manual; wear the seat belt when seated in the operator's position; avoid tipping the machine.
- 2. Warning—wear hearing protection.




decal163-2971

163-2971

- 1. TEC logic—2 A
- 2. TEC power—7.5 A
- 3. AutoSteer—10 A
- 4. Ignition—15 A
- 5. TEC power—7.5 A
- 6. Boom control-10 A
- 7. GeoLink-10 A

- 8. Work light—15 A
- 9. TEC power-7.5 A
- 10. Cruise control—10 A
- 11. InfoCenter—1 A
- 12. Boom and headlight—30 A
- 13. USB power—15 A
- 14. Tank spray-40 A



decal120-0616

120-0616


 Warning—read the Operator's Manual; use fresh, clean water for first-aid washing.



decal120-0622

120-0622


- 1. Warning—read the Operator's Manual.
- 2. Warning—do not enter the tank.
- 3. Caustic liquid/chemical burn and toxic gas inhalation hazards—wear hand, skin, eye, and respiratory protection.



120-0623

decal120-0623

- 1. Tow hitch location
- 2. Tie down locations
- Warning—Read the Operator's Manual.



120-0624

- 1. Crushing/dismemberment hazard of bystanders—do not enter or exit the machine while it is moving; stop the machine before entering or exiting.
- 2. Falling, crushing hazard—no riders on tank; keep arms and legs inside of the vehicle at all times, use passenger hand holds.



decal120-0627

120-0627

Cutting/dismemberment hazard, fan—stay away from moving parts; keep all guards and shields in place.



120-0625

decal120-0625


1. Pinch point, hand—keep hands away.



decal120-0617

120-0617

- Pinch point—keep hands away from the hinge.
- Crushing hazard, boom—keep bystanders away.




decal127-6979

127-6979

- Pump-return flow
- Flow

3. Agitation flow




decal127-6981

127-6981

- Bypass-return flow
- Flow

3. Section spray




decal132-7689

decal132-7708

132-7689


- 1. Auto spray mode
- 2. Spray mode
- 3. Manual spray mode
- 4. Foam marker—on
- 5. Foam marker—off
- 6. Rinse system—on
- 7. Rinse system—off
- 8. Sonic sensor—on
- 9. Sonic sensor—off
- 10. Application rate—increase
- 11. Application rate—decrease



132-7708

3. Horn

- 1. Headlight—on
- 2. Headlight-off
- 1



decal136-2351

136-2351

- To engage the parking brake, press down the brake and parking-brake pedal.
- 2. To disengage the parking brake, press and release the brake pedal.


▲ WARNING: Cancer and Reproductive Harm - www.P65Warnings.ca.gov. For more information, please visit www.ttcoCAProp65.com

CALIFORNIA SPARK ARRESTER WARNING

Operation of this equipment may create sparks that can start fires around dry egetation. A spark arrester may be required. The operator should contact local fire agencies for laws or regulations relating to fire prevention requirements.

decal133-8062


133-8062



decal132-7783

132-7783

- 1. Engine stop
- 2. Engine run
- 3. Engine start




decal138-6278

138-6278

- 1. Off
- 2. On

- 3. Autosteer engage/disengage button
- Read the Operator's Manual.



161-4186

decal161-4186

1. Spray mode

2. Transport mode



decal120-0619

120-0619

- Warning—read the Operator's Manual.
- 2. Warning—do not operate this machine unless you are trained.
- 3. Warning—stay away from moving parts, keep all guards and shields in place.
- Crushing/dismemberment hazard of bystanders—do not start the engine while entering or exiting the vehicle; engage the parking brake, insert the key, and start the engine while seated in the operator's seat.
- Tipping hazard—do not turn sharply while traveling fast, drive slowly when turning; use caution and drive slowly when traveling across or up and down slopes.
- To start the engine, engage the parking brake, insert the ignition key and turn it to the START position.
- To shut off the engine, press the brake, ensure that the traction pedal is in the NEUTRAL position, engage the parking brake, release the brake, turn the key to the STOP position, and remove the key.




decal132-7786

132-7786

1. Spray—off


2. Spray-on

3. USB



decal132-7695

- 1. Pump—on
- 2. Pump-off
- 3. Agitation—on
- 4. Agitation-off
- 5. Speed control—on
- 6. Speed control—off
- 7. Lower the left section.
- —off 8. Raise the left section.
- 9. Lower the right section.
- 10. Raise the right section.
- 11. Engine speed—fast
- 12. Engine speed—slow
- 13. Left section spray
- Center section spray
- 15. Right section spray



decal139-3065

139-3065

1. Read the Operator's Manual.

Setup

Loose Parts

Use the chart below to verify that all parts have been shipped.

Procedure	Description	Qty.	Use
1	Hex-head bolt (1/4-20 x 1-1/2 inches) Locknut (1/4 inch)	4 4	Install the display.
2	No parts required	-	Adjust the wheel angle sensor (WAS).
3	Quick-disconnect fitting	1	Assemble the sprayer tank fill fitting.
4	No parts required	-	Remove the shipping bumper.
5	No parts required	-	Install the CE kit.
6	No parts required	_	Install the Plus+1 service tool.
7	No parts required	_	Set up the GeoLink software.
8	No parts required	_	Complete the setup.

Media and Additional Parts

Description	Qty.	Use
Starter key	2	
Operator's Manual	1	
Engine owner's manual	1	Read the manuals before operating the machine.
Parts Catalog Instruction Card	1	
Screen filter	2	

Note: Determine the left and right sides of the machine from the normal operating position.

Note: If you have questions or need additional information regarding the spray control system, refer to the *Operator's Manual* supplied with the system.

Important: This sprayer is sold without spray nozzles.

To use the sprayer, you must obtain and install the nozzles. Contact your authorized Toro distributor for information on the available section kit and accessories.

1


Installing the Display

Parts needed for this procedure:

4	ļ	Hex-head bolt (1/4-20 x 1-1/2 inches)
4	1	Locknut (1/4 inch)

Procedure

1. Secure the ball mount onto the bracket using 4 hex-head bolts (1/4-20 x 1-1/2 inches) and 4 locknuts (1/4 inch).



- Figure 3
- 2. Install the display and display arm onto the ball mount.
- 3. Tighten the display arm knob in the desired location.


2

Adjusting the Wheel Angle Sensor (WAS)


No Parts Required

Procedure

- 1. Lift the machine and support it with jack stands..
- 2. Remove the 5 wheel nuts that secure the left tire and wheel to the wheel hub, and remove the wheel from the machine.



- Figure 4
- 1. Wheel hub
- 2. Wheel nut
- 3. Tire and wheel
- 3. Adjust the position of the WAS until you measure a gap 4 mm (0.16 inch) between the target and the face of sensor.




- Figure 5
- 1. Wiring port (sensor)
- 3. Indicator line (WAS)
- 2. Gap 3.5 mm (0.14 inch)
- 4. Jam nut

g506948

- 4. Rotate the WAS until the indicator line that is stamped into the flat face of the WAS aligns with the wiring port of the sensor.
- 5. Tighten the jam nut.
- 6. Measure the gap between the target and the face of sensor. You should measure 2 to 4 mm (0.08 to 0.16 inch).

Note: If the gap is smaller than 2 mm (0.08 inch) or larger than 4 mm (0.16 inch)—adjust the position of the WAS, align the indicator line, and tighten the jam nut.

7. Align the holes of the wheel onto the studs of the wheel hub.



1. Stud

- 2. Wheel nut
- 8. Assemble the wheel to the studs with the 5 wheel nuts, and tighten them by hand.
- 9. Lower the machine and remove the jack stands.
- 10. Torque the wheel nuts in a crossing pattern to 75 to 102 N·m (55 to 75 ft-lb).

3

Assembling the Sprayer Tank Fill Fitting


Parts needed for this procedure:

1 Quick-disconnect fitting


Procedure

Note: To complete this procedure, you will need to supply a hose with 1 inch male national pipe thread (NPT) fitting and PTFE thread sealant.

1. At the forward, right side of the tank cover, remove the 2 hairpins that secure the latches for the quick-disconnect coupling for the anti-siphon fill receptacle.



- 1. Quick-disconnect fitting
- 3. Latches (quick-disconnect coupling)
- 2. Hairpins
- 2. Rotate the latches open to unlock the quick-disconnect fitting from the quick-disconnect coupling.
- 3. Remove the quick-disconnect fitting from the quick-disconnect coupling.
- 4. Close the latches and install the hair pins into the flanges of the quick-disconnect coupling.
- 5. Apply PTFE thread sealant to the threads of the fill hose fitting (1 inch—national pipe thread).



- 1. PTFE thread sealant
- 2. Fill hose fitting (1 inch-national pipe thread)
- 3. Quick-disconnect fitting

g191615

Thread the quick-disconnect coupling onto the fill hose and tighten it by hand.



Removing the Shipping **Bumper**

No Parts Required

Procedure

Remove the bolts, washers, and nuts that secure the shipping bumper to the front chassis plate.




Figure 9

- 1. Nut
- 2. Shipping bumper
- 3. Washer
- 4. Bolt
- Remove the shipping bumper from the machine. 2.

Note: Discard the bolts, washers, nuts, and shipping bumper.

Installing the CE Kit

Machines Operated in EU Countries

No Parts Required

Procedure

Install the CE kit for your machine; refer to the Multi Pro 5800 CE Kit Installation Instructions.



Installing the Plus+1 **Service Tool**

No Parts Required

Downloading the Software

Go to Gateway and click on Service Library.




Figure 10

Select GeoLink Solutions.



Figure 11

Select Autosteer Software.

Note: The file saves to the Downloads directory of your laptop computer.



Figure 12

4. Select the download and click Extract all.




Figure 13

In the Extract Compressed dialog box, ensure that the SHOW EXTRACTED FILES WHEN COMPLETE check box is selected, and click the EXTRACT button .




Figure 14

Installing the Software and Driver Files


Important: The person installing the PLUS+1 Service tool must have administrative privileges on the laptop computer.

 Double click the PLUS+1 ServiceTool 12.0.7 setup.exe file.



Figure 15

2. If the User Account Control dialog box displays, click the YES button (Figure 16).



- 1. YES button
- In the Select Destination Location dialog box, click the NEXT button.



Figure 17

4. In the Plus+1 Online dialog box, click the NEXT button.



Figure 18

5. In the Select Additional Tasks dialog box, click the NEXT button.



Figure 19

6. In the Ready to Install dialog box, click the INSTALL button.



Figure 20

Note: The progress dialog box displays.




Figure 21

7. In the Completing Service Tool Setup Wizard dialog box, click the FINISHED button.




Figure 22

Installing the Drivers

1. In the Select Destination Location dialog box, click the NEXT button.




Figure 23

g483719

In the Ready to Install dialog box, click the INSTALL button.




Figure 24

g483720

Note: The progress dialog box displays.

g483730




Figure 25

3. In the Would you like to install this device software dialog box, click the INSTALL button.




Figure 26

In the Would you like to install this device software dialog box, click the INSTALL button.




Figure 27

5. In the Completing Service Tool Drivers Setup Wizard dialog box, click the FINISHED button.




Figure 28

Installing the Service and Data Files

1. Double click on the Plus+1 Service Tool icon.




Figure 29

g483731

Read the license information, check the boxes noting you have read and agree to the agreement, and click OK.




Figure 30

Click Ok on the confirmation screen.




Figure 31

4. Click on the folder with magnifying glass icon to Scan for Service Application File.




Figure 32

- Navigate to the Service tool folder in the PVED-CLS 2.00 firmware release package folder
- Click on PVED-CLS_2.00_rev_D and click OPEN.



Figure 33

Click CLOSE if you receive this error. This is a passive error and will not effect the installation or use of this tool.



Figure 34

g483736

g483735

g483734

Installing the Diagnostic Data

 Click the FILE icon, and in the drop-down list, click the INSTALL DIAGNOSTIC DATA . . . icon.




Figure 35

 In the Install Diagnostic Data dialog box, click the PLUS+1 protocol icon, and press the INSTALL icon.




Figure 36

 Navigate to the Diagnostic data files folder in the PVED-CLS 2.00 firmware release package folder

4. Select all the files in this folder and click Ok.




Figure 37

In the INSTALL DIAGNOSTIC DATA dialog box, click the CLOSE icon.




Figure 38


In the INSTALL DIAGNOSTIC DATA dialog box, click the CLOSE icon.




Figure 39



- 1. Plug a Toro Diag cable into the USB port of the laptop computer and open the Plus+1 software program.
- 2. On the ribbon bar, click the Communication button.



- 1. Communication button
- 2. Gateway button
- Advanced button
- 4. Select Gateway... button
- 3. In the Communication drop-down menu, click the Gateway button.
- 4. In the Gateway drop-down menu, click the Advanced button.
- In the Advanced drop-down menu, click the Select Gateway... button.
- 6. On the Select Gateway Channel screen, click the Kvaser option in the Gateways list.



Kvaser option (Gateways list)

g483708

- Diagnostic Cable option (Channels menu)
- 3. CHANGE button (Current Selection heading)
- 4. Refresh button
- 7. In the Channels menu, click the Diagnostic Cable option.

Note: If a diagnostic cable option does not display in the Channels menu, verify that the Toro Diag cable is plugged into the USB port of the laptop computer, click the Refresh button on the Select Gateway Channel screen, and click the Diagnostic Cable option.

8. Click the CHANGE button under the Current Selection heading.



Setting Up and Calibrating the Software

No Parts Required

Calibrating the Compass

Ensure that the GeoLink compass is calibrated, refer to the GeoLink *Software Guide* for your machine.

Preparing to Calibrate the Machine

Installer provided equipment: a USB/CAN interface cable (Toro DIAG cable) Part No. 115-1944

Park the machine on the grass at a level location.

Shut off the engine and engage the parking brake

Connecting the Laptop Computer to the Machine

1. If the Toro Diag application is running on the laptop computer, close the Toro Diag application.

Important: Do not begin the calibration process if the Toro Diag application is running on the laptop computer.

- 2. Plug the USB/CAN interface cable into a USB port of the laptop computer.
- 3. At the machine, rotate the key to the ON position.
- 4. Open the Plus+1 program.
- Remove the cap from the 3-socket connector of the kit wire harness CAN port labeled DUPLICATE DIAG CONNECTOR, and plug the 3-pin connector USB/CAN interface cable into the 3-socket connector.




Figure 42

- 3-socket connector (labeled DUPLICATE DIAG CONNECTOR—kit wire harness)
- 3. Cap
- 3-pin connector (USB/CAN interface cable)
- 6. On the dash panel of the machine, press enable/transport switch to the ENABLE MODE position.
- 7. In the System Navigator tab, navigate to the AUTO CALIBRATION directory, expand the directory, and click on WAS Calibration.





Figure 43

3. Click GOTO WAS CALIBRATION MODE button.

Capturing Steering Values


- 1. Start the engine of the machine.
- 2. Fully turn the steering wheel to the left and stop.
- 3. Click the CAPTURE L button.

Note: The sensor value changes as you turn the steering wheel.



- 1. Sensor value
- 2. CAPTURE L button
- 4. Fully turn the steering wheel to the right and stop.
- Click the CAPTURE R button.

Note: The sensor value changes as you turn the steering wheel.



- 1. Sensor value
- 2. CAPTURE R button
- 6. Turn the steering wheel until the tires align straight ahead and stop.
- 7. Click the CAPTURE N button.

Note: The sensor value changes as you turn the steering wheel.




Figure 46

- 1. Sensor value
- 2. CAPTURE N button

Verifying / Checking the WAS Calibration Values

1. Ensure that your values are within the minimum and maximum ranges as listed.




Figure 47

Click the ACCEPT AND SAVE button.

Running Spool Calibration Process

- 1. Turn the steering wheel as needed to position the front tires straight ahead.
- 2. In the System Navigator tab, navigate to the AUTO CALIBRATION directory, expand the directory, and click on SPOOL CALIBRATION.




Figure 48


- On the spool calibration page, click the GOTO SPOOL CALIBRATION MODE button.
- 4. Click the START CALIBRATION button.

Note: The service mode state must display Spool Calibration Armed before starting calibration.

Important: Do not touch the steering wheel.

The steering wheel moves while spool calibrations proceeds. The spool calibration process takes several minutes. Note that the

wheel movement status changes in Status tab. Calibration is finished when Service Mode State field displays SPOOL PARAMETERS READY TO UPDATE.



- Service mode state field—SPOOL CALIBRATION ARMED
- 2. START CALIBRATION icon
- Service mode state field—SPOOL PARAMETERS READY TO UPDATE

4. Wheel movement status

- Service mode state field—SPOOL CALIBRATION IN PROGRESS
- 5. At the bottom of the spool calibration screen, click the ACCEPT AND SAVE icon (Figure 50).




Figure 50

1. ACCEPT AND SAVE icon

- 6. Shut off the engine.
- 7. Remove the connector of the USB/CAN interface cable from the connector of the kit wire harness, and install the cap onto the wire harness connector.




Figure 51

- 3-socket connector
 (labeled DUPLICATE DIAG
 CONNECTOR—kit wire
 harness)
- 2. 3-pin connector (USB/CAN interface cable)
- 3. Cap




Completing the Setup

No Parts Required

Procedure

Refer to the *GeoLink Software Guide* to complete the setup.


Product Overview



g513688

- GeoLink display
- 2. Antenna
- 3. Navigation receiver
- 4. Roll bar (ROPS)
- 5. Fresh-water tank
- 6. Tank lid

- 7. Chemical tank
- 8. Drain valve (sprayer tank)
- 9. Spray pump
- 10. Operator's seat
- 11. Battery
- 12. Work lights



g513689

Figure 53

- 1. Lift cylinder
- 2. Boom-transport cradle
- 3. Valve manifolds
- 4. Fuel tank
- 5. Hydraulic tank
- 6. Right boom section
- 7. Center boom section
- 8. Left boom section

Controls




Figure 54

g513684

- 1. Work-light switch
- 2. Fuel gauge
- 3. GeoLink display
- 4. Passenger-hand hold

- 5. Storage compartment
 - 6. InfoCenter
 - 7. Quick Find™ console
 - 8. Ignition switch

Vehicle Controls

Traction Pedal


The traction pedal (Figure 55) controls the movement of the machine, both forward and reverse. Using the toe or heel of your right foot, press the top of the pedal to move forward or the bottom of the pedal to move the machine in reverse. Release the pedal to slow and stop the machine.

Important: Ensure that you allow the sprayer to come to a stop before switching between the FORWARD and the REVERSE positions.

Note: The farther you press the pedal in either direction, the faster the sprayer travels. To obtain maximum forward speed, set the throttle lever to the FAST position and press the traction pedal all the way forward.

Note: To get maximum power under heavy load or when ascending a hill, move the throttle in the FAST position while pressing traction pedal slightly to keep

the engine speed high. When the engine speed begins to decrease, release the traction pedal slightly to allow the engine speed to increase.



- 1. Parking-brake pedal
- Brake pedal
- 3. Traction pedal

Brake Pedal

Use the brake pedal to stop or slow the machine (Figure 55).

A CAUTION

If you operate the sprayer with poorly adjusted or worn brakes, you could lose control of the sprayer, resulting in serious injury or death to you or bystanders.

Always check the brakes before operating the sprayer and keep them properly adjusted and repaired.

Parking Brake

The parking brake is a pedal to the left of the brake pedal (Figure 55). Engage the parking brake whenever you leave the seat to prevent the sprayer from accidently moving. To engage the parking brake, press the brake pedal and while holding the brake, press the parking-brake pedal. To disengage, press and release the brake pedal. If the sprayer is parked on a steep grade, apply the parking brake and place chocks on the downhill side of the wheels.

Ignition Switch

The ignition switch (Figure 54), is used to start and shut off the engine, and the switch has 3 positions: OFF, ON/PREHEAT, and START.

Speed-Lock Switch

The speed-lock switch locks the position of the traction pedal when the switch is set (Figure 56). This ensures that the sprayer travels at a constant speed while driving the machine on level ground.




Figure 56

- 1. Center console
- 2. Speed-lock switch
- 3. Throttle lever

Throttle Lever

The throttle lever is located on the control panel between the seats (Figure 56), and the throttle is used to control the engine speed. Push the lever forward to increase the engine speed and pull it rearward to decrease the engine speed.

Work-Light Switch


Toggle the switch to operate the work lights (Figure 54). Push it forward to turn the lights on and rearward to turn them off.

Fuel Gauge

The fuel gauge is located on the dash of the machine and the gauge displays the level of the fuel in the tank (Figure 54).

USB Power Port

The 2-socket USB power port is located at the back of the armrest (Figure 57).



1. USB port

2. USB sockets

Sprayer Controls




Figure 58

- 1. AutoSteer enable switch
- 2. Tank-agitation switch
- Spray-pump switch
- 4. Left boom-section lift switch
- 5. Right boom-section lift switch
- Master section switch
- 7. Left-section switch
- Center-section switch
- Right-section switch
- 10. AutoSteer engage switch

AutoSteer Enable Switch

Use the Autosteer enable/transport switch to enable the steering assist (Spray Mode) function or put the machine in transport mode.

AutoSteer Engage Switch

Use the Autosteer engage/disengage switch to engage or disengage the steering assist function.

Spray-Pump Switch

The spray-pump switch is located on the center console to the right of the seat (Figure 58). Toggle this switch forward to run the spray pump or rearward to stop the pump. When the switch is turned on, a light on the switch illuminates.

Important: Engage the spray-pump switch only when the engine is at LOW IDLE to avoid damaging the pump drive.

Boom-Section Lift Switches

The boom-section lift switches are located on the center console to the right of the seat and used to raise or lower the left and right boom sections (Figure 58).

Master Section Switch

The master section switch is located on the center console of the machine. The switch allows you to start or stop the spray operation. Press the switch to enable or disable the spray system (Figure 58).

Left, Center, and Right Section Switches

The 3 section switches are located on the center console in the front of the armrest (Figure 58). Toggle each switch forward to turn the corresponding section on and rearward to turn each off. When the switch is in the ON position, an icon appears at the top of the InfoCenter.


Note: These switches affect the spray system only when the master section switch is in the O_N position.

Agitation Switch

The agitation switch is located on the center console to the right of the seat (Figure 58). Toggle this switch forward to turn on the agitation in the tank or rearward to stop the agitation. When the switch is turned on, a light on the switch illuminates. To operate the agitation function, you must run the sprayer system pump and you must run the engine above low idle.

Agitation-Bypass Valve

The agitation-bypass valve redirects the flow of fluid to the sprayer-system pump when you turn off the agitation function (Figure 59). The agitation-bypass valve is located above the agitation valve. You can adjust the bypass valve to ensure that the pressure remains constant when cycling agitation on or off; refer to Calibrating the Agitation-Bypass Valve (page 39).



- 1. Actuator (agitation valve)
- 3. Flow meter
- Agitation-bypass-valve handle

Flowmeter

The flowmeter measures the flow rate of the fluid for use by the InfoCenter system and when spraying in the application rate mode (Figure 59).

Agitation-Throttle Valve

The agitation-throttle valve is a manually-operated ball valve that controls flow to the agitation nozzles in the main tank. This valve allows you to control the sprayer-system pressure at the agitation nozzles of the main tank when larger application rates are required. The agitation-throttle valve is located above the pump (Figure 60).




Figure 60

1. Agitation-throttle-valve handle

Anti-Siphon Fill Receptacle

At the front of the tank cover is a hose receptacle with a threaded fitting, a 90-degree barbed fitting, and a short hose, which you can direct toward the tank opening. This receptacle allows you to connect a water hose to it and fill the tank with water without contaminating the hose with the chemicals in the tank.

Important: Do not lengthen the hose to allow contact with the tank fluids. The distance from the end of the hose to the uppermost water level should be within local regulatory limits.




Figure 61

1. Anti-siphon fill receptacle 2. Tank cover

Tank Cover

The tank cover is located in the center, top of the tank. To open the cover, shut off the engine, turn the front half of the cover to the left, and swing it open. You can remove the strainer inside for cleaning. To seal the tank, close the cover and rotate the front half toward the right.

InfoCenter Controls

The InfoCenter controls use the 5 buttons below the LED display to navigate menus, enter data, and change functions. Refer to the *Software Guide* for more information.




Figure 62

1. Up arrow

a013787

- 2. Button 1
- 3. Down arrow
- 4. Button 2
- 5. Button 3

- 6. Button 4
- 7. Select arrow
- 8. Button 5
- 9. Exit

Specifications

Note: Specifications and design are subject to change without notice.

Machine Specifications

Description	Measurement
Base weight	1307 kg (2,882 lb)
Weight with standard spray system, empty, without operator	1307 kg (2,882 lb)
Weight with standard spray system, full, without operator	2499 kg (5,510 lb)
Maximum gross vehicle weight (GVW) (on level ground)	3023 kg (6,665 lb)
Tank capacity	1135.6 L (300 US gallons)
Overall width with standard spray system sections stored in the X position	226 cm (89 inches)

Sprayer Specifications

Description	Measurement
Overall length with standard spray system	391 cm (154 inches)
Overall length with standard spray system to the top of the sections stored in the X position	442 cm (174 inches)
Overall height with standard spray system	146 cm (57.5 inches)
Overall height with standard spray system to the top of the sections stored in the X position	231 cm (91 inches)
Ground clearance	18.4 cm (7.25 inches)
Wheel base	198 cm (78 inches)

Attachments/Accessories

A selection of Toro approved attachments and accessories is available for use with the machine to enhance and expand its capabilities. Contact your authorized Toro distributor.

To ensure optimum performance and continued safety certification of the machine, use only genuine Toro replacement parts and accessories.

Operation

Note: Determine the left and right sides of the machine from the normal operating position.

Before Operation

Before Operation Safety

General Safety

- Never allow children or untrained people to operate or service the machine. Local regulations may restrict the age of the operator. The owner is responsible for training all operators and mechanics.
- Become familiar with the safe operation of the equipment, operator controls, and safety signs.
- Shut off the engine, remove the key (if equipped), and wait for all movement to stop before you leave the operator's position, Allow the machine to cool before adjusting, servicing, cleaning, or storing it.
- Know how to stop the machine and shut off the engine quickly.
- Check that operator-presence controls, safety switches, and guards are attached and functioning properly. Do not operate the machine unless they are functioning properly.
- If the machine does not function correctly or is damaged in any way, do not use the machine.
 Correct the problem before you operate the machine or attachment.
- Ensure that the operator and passenger areas are clean and free from chemical residue and debris buildup.
- Ensure that all fluid line connectors are tight and that all hoses are in good condition before applying pressure to the system.

Fuel Safety

- Use extreme care in handling fuel. It is flammable and its vapors are explosive.
- Extinguish all cigarettes, cigars, pipes, and other sources of ignition.
- Use only an approved fuel container.
- Do not remove the fuel cap or fill the fuel tank while the engine is running or hot.
- Do not add or drain fuel in an enclosed space.

- Do not store the machine or fuel container where there is an open flame, spark, or pilot light, such as on a water heater or other appliance.
- If you spill fuel, do not attempt to start the engine; avoid creating any source of ignition until the fuel vapors have dissipated.

Chemical Safety

Chemical substances used in the sprayer system may be hazardous and toxic to you, bystanders, and animals, and they may damage plants, soil, and other property.

- Read the information on each chemical. Refuse to operate or work on the sprayer if this information is not available.
- Before working on a sprayer system, ensure that it has been neutralized and triple rinsed according to the recommendations of the chemical manufacturer(s) and that all the valves have been cycled 3 times.
- Verify that there is an adequate supply of clean water and soap nearby, and immediately wash off any chemicals that contact you.
- Carefully read and follow the chemical warning labels and safety data sheets (SDSs) for all chemicals used, and protect yourself according to the chemical manufacturer's recommendations.
- Always protect your body while using chemicals.
 Use the appropriate personal protective equipment (PPE) to guard against contact with chemicals, such as the following:
 - safety glasses, goggles, and/or face shield
 - a chemical suit
 - a respirator or filter mask
 - chemical-resistant gloves
 - rubber boots or other substantial footwear
 - a clean change of clothes, soap, and disposable towels for cleanup
- Obtain proper training before using or handling chemicals.
- · Use the correct chemical for the job.
- Follow the chemical manufacturer's instructions for the safely applying the chemical. Do not exceed the recommended system application pressure.
- Do not fill, calibrate, or clean the machine while people, especially children, or pets are in the area.
- Handle chemicals in a well-ventilated area.
- Do not eat, drink, or smoke while working near chemicals.
- Do not clean spray nozzles by blowing through them or placing them in your mouth.
- Always wash your hands and other exposed areas as soon as possible after working with chemicals.

- Keep chemicals in their original packages and stored in a safe location.
- Properly dispose of unused chemicals and chemical containers as instructed by the chemical manufacturer and your local codes.
- Chemicals and fumes are dangerous; never enter the tank or place your head over or in the opening of a tank.
- Follow all local, state, and federal regulations for spreading or spraying chemicals.

Performing Pre-Starting Checks

Check the following items each time you begin use of the sprayer for the day:

Check the air pressure in the tires.

Note: The tires of this machine are different than car tires; they require less air pressure to minimize turf compaction and damage.

- Check all fluid levels and add the appropriate amount of specified fluids, if any are found to be low.
- · Check the brake pedal operation.
- Check to see that the lights are working.
- Turn the steering wheel to the left and right to check steering response.
- With the engine shut off, check for oil leaks, loose parts, and any other noticeable malfunctions.

If any of the above items are not correct, notify your mechanic or check with your supervisor before taking the sprayer out for the day. Your supervisor may want you to check other items daily, so ask what inspections you are responsible to perform.

Preparing the Machine

- · Check the engine oil level.
- Check the cooling system.
- Check the hydraulic system.
- Check the tire pressure.
- · Check the brakes.

Checking the Tire Air Pressure

Service Interval: Before each use or daily

Check the tire air pressure in the tires to ensure proper levels. Fill the tires to 138 kPa (20 psi).

Note: Also, check the tires for wear or damage.

Checking the Brakes

Service Interval: Before each use or daily

Before starting the sprayer, lightly press the brake pedal. If the pedal travels more than 2.5 cm (1 inch) before you feel resistance, adjust the brakes; refer to Adjusting the Brakes (page 79).

A WARNING

If you operate the sprayer with poorly adjusted or worn brakes, you could lose control of the sprayer, resulting in serious injury or death to you or bystanders.

Always check the brakes before operating the sprayer and keep them properly adjusted and repaired.

Adding Fuel

Fuel Specification

Petroleum fuel	Use unleaded gasoline with an octane rating of 87 or higher ((R+M)/2 rating method).
	Use an unleaded-gasoline blend with up to 10% ethanol (gasohol) or 15% MTBE (methyl tertiary butyl ether) by volume is acceptable. Ethanol and MTBE are not the same.
Ethanol blended fuel	Gasoline with 15% ethanol (E15) by volume is not approved for use. Never use gasoline that contains more than 10% ethanol by volume, such as E15 (contains 15% ethanol), E20 (contains 20% ethanol), or E85 (contains up to 85% ethanol). Using unapproved gasoline may cause performance problems and/or engine damage which may not be covered under warranty.

Important: For best results, use only clean, fresh fuel (less than 30 days old).

- Do not use gasoline containing methanol.
- Do not store fuel either in the fuel tank or fuel containers over the winter unless you use a fuel stabilizer.
- Do not add oil to gasoline.

Filling the Fuel Tank

Fuel tank capacity: approximately 45 L (12 US gallons).

- Park the machine on a level surface, engage the parking brake, shut off the spray pump, shut off the engine, remove the key, and allow the engine to cool.
- Clean the area around the fuel-tank cap (Figure 63).




Figure 63

a354647

- 1. Fuel-tank cap
- Remove the fuel-tank cap.
- 4. Fill the tank to about 2.5 cm (1 inch) below the top of the tank (bottom of the filler neck).

Note: This air space in the tank allows fuel to expand. **Do not overfill the tank.**

- Install the fuel-tank cap to the tank securely.
- 6. Wipe up any fuel that may have spilled.

Breaking in a New Machine

Service Interval: After the first 100 hours—To provide proper performance and long sprayer life, follow these guidelines for the first 100 operating hours:

- Check the engine-oil and fluid levels regularly and be alert for indications of overheating in any component of the sprayer.
- After starting a cold engine, let it warm up for about 15 seconds before accelerating.
- Avoid racing the engine.
- Vary the sprayer speed during operation. Avoid fast starts and quick stops.
- Refer to Maintenance (page 53) for any special, low-hour checks.

Preparing the Sprayer

Selecting a Nozzle

Note: Refer to the nozzle-selection guide that is available through your authorized Toro distributor.

The turret bodies can accept up to 3 different nozzles. To select the desired nozzle, perform the following:

- Stop the sprayer on a level surface, shut off the engine, remove the key, and engage the parking brake.
- Set the master section switch to the OFF position and set the spray-pump switch to the OFF position.
- 3. Rotate the turret of the nozzles in either direction to the correct nozzle.
- For machines operated in the application rate mode, perform a flow calibration; refer to the GeoLink Software Guide.

Selecting a Suction Filter

Standard Equipment: 50 mesh suction filter (blue)

Use the suction filter table to identify the screen mesh for the spray nozzles you are using based on chemicals products or solutions with a viscosity equivalent to water.

Suction Filter Table

Spray Nozzle Color Code (flow rate)	Screen Mesh Size*	Filter Color Code
Yellow (0.2 gpm)	50	Blue
Red (0.4 gpm)	50	Blue
Brown (0.5 gpm)	50 (or 30)	Blue (or green)
Gray (0.6 gpm)	30	Green
White (0.8 gpm)	30	Green
Blue (1.0 gpm)	30	Green
Green (1.5 gpm)	30	Green

*The mesh size of the suction filters in this table are based on spray chemicals or solutions with the viscosity equivalent to water.

Important: When you spray with higher viscosity (thicker) chemical products or solutions with wettable powders, you may need to use a coarser screen mesh for the optional suction filter; refer to Figure 64.





Figure 64

Mesh size—chemical or solution viscosity

- Higher-viscosity chemicals 3. Screen mesh size or solutions
- Lower-viscosity chemicals or solutions

When you spray at a higher application rate, consider using a coarser optional suction-filter mesh; refer to Figure 65.



Mesh size—application rate

- 1. Higher application rate
- 3. Screen mesh size
- 2. Lower application rate

Selecting a Pressure Filter

Available screen sizes include:

Standard Equipment: 50 mesh suction filter (blue)


Use the pressure filter table to identify the screen mesh for the spray nozzles you are using based on chemicals products or solutions with a viscosity equivalent to water.

Pressure Filter Table

Spray Nozzle Color Code (flow rate)	Screen Mesh Size*	Filter Color Code
As required for low viscosity chemicals or solutions or low application rates	100	Green
Yellow (0.2 gpm)	80	Yellow
Red (0.4 gpm)	50	Blue
Brown (0.5 gpm)	50	Blue
Gray (0.6 gpm)	50	Blue
White (0.8 gpm)	50	Blue
Blue (1.0 gpm)	50	Blue
Green (1.5 gpm)	50	Blue
As required for high viscosity chemicals or solutions or high application rates	30	Red
As required for high viscosity chemicals or solutions or high application rates	16	Brown

*The mesh size of the pressure filters in this table are based on spray chemicals or solutions with the viscosity equivalent to water.

Important: When you spray with higher viscosity (thicker) chemical products or solutions with wettable powders, you may need to use a coarser screen mesh for the optional pressure-filter; refer to Figure 66.




Mesh size—chemical or solution viscosity

a214211

a214240

- Higher-viscosity chemicals 3. Screen mesh size or solutions
- 2. Lower-viscosity chemicals or solutions

When you spray at a higher application rate, consider using a coarser optional pressure-filter mesh; refer to Figure 67.



Mesh size—application rate

- 1. Higher application rate
- 2. Lower application rate
- 3. Screen mesh size

Selecting a Nozzle-Tip Filter (Optional)

Note: The use the optional nozzle-tip filter to protect the spray-nozzle tip and increase its service life.


Use the nozzle-tip filter table to identify the screen mesh for the spray nozzles you are using based on chemicals products or solutions with a viscosity equivalent to water.

Nozzle-Tip Filter Table

Spray Nozzle Color Code (flow rate)	Filter Mesh Size*	Filter Color Code
Yellow (0.2 gpm)	100	Green
Red (0.4 gpm)	50	Blue
Brown (0.5 gpm)	50	Blue
Gray (0.6 gpm)	50	Blue
White (0.8 gpm)	50	Blue
Blue (1.0 gpm)	50	Blue
Green (1.5 gpm)	50	Blue

*The mesh size of the nozzle filters in this table are based on spray chemicals or solutions with the viscosity equivalent to water.


Important: When you spray with higher viscosity (thicker) chemical products or solutions with wettable powders, you may need to use a coarser screen mesh for the optional tip-filter; refer to Figure 68.



Mesh size—chemical or solution viscosity

- Higher-viscosity chemicals 3. Screen mesh size or solutions
- 2. Lower-viscosity chemicals or solutions

When you spray at a higher application rate, consider using a coarser tip-filter mesh; refer to Figure 69.



Mesh size—application rate

- Higher application rate
 Lower application rate
- 3. Screen mesh size

37

a214245

Filling the Tanks


Filling the Fresh-Water Tank

Important: Do not use reclaimed water (gray water) in the fresh-water tank.

Note: The fresh-water tank is used to supply a source of fresh water for you to wash chemicals off your skin, eyes, or other surfaces in the case of accidental exposure.

Always fill the fresh-water tank with clean water before handling or mixing any chemicals.

- To fill the tank, unscrew the cap at the top of the tank, fill the tank with fresh water, and install the cap (Figure 70).
- To open the fresh-water tank spigot, turn the lever on the spigot (Figure 70).



1. Filler cap

3. Spigot

2. Fresh-water tank

Filling the Spray Tank

Install the optional Chemical Pre-Mix Kit for optimal mixing and exterior tank cleanliness.

Important: Whenever possible, do not use reclaimed water (gray water) in the spray tank.

Important: Ensure that the chemicals you use are compatible with Viton[™] (see the manufacturer's label; it should indicate if it is not compatible). Using a chemical that is not compatible with Viton

will degrade the O-rings in the sprayer, causing leaks.


Important: The tank-volume markings are for reference only and cannot be considered accurate for calibration. We recommend using an in-line flow meter.

- Stop the machine on a level surface, shut off the engine, remove the key, and engage the parking brake.
- Determine the amount of water needed to mix the amount of chemical you need as prescribed by the chemical manufacturer.
- 3. Open the tank cover on the spray tank.

Note: The tank cover is located at the center of the top of the tank. To open it, turn the front half of the cover counterclockwise and swing it open. You can remove the strainer under the tank cover and clean the strainer.

- 4. Assemble the fill hose to the quick disconnect fitting of the anti-siphon fill receptacle.
- 5. Add 3/4 of the required water to the spray tank (Figure 71).

Important: Always use fresh, clean water in the spray tank. Do not pour concentrate into an empty tank.



- 6. Start the engine, engage the parking brake, set the spray-pump switch to the ON position, and move the throttle lever to HIGH IDLE.
- 7. Set the agitation switch to the O_N position.

Important: Prior to introducing wettable powders into any Toro Spray System mix the powders in a suitable container with enough fresh water to create a free flowing slurry. Failure to do so may result in chemical deposits on the bottom of the tank, degraded agitation, clogging of filters, and improper application rates.

Toro recommends using the approved Eductor Kit for this machine. Contact your authorized Toro distributor for more information.

- 8. Add the proper amount of chemical concentrate to the tank, as directed by the chemical manufacturer.
- Add the remaining water to the tank, remove the fill hose, and close the tank cover.

Note: To seal the tank, close the cover and rotate the front half clockwise.

Important: After filling the tank for the first time, check the tank straps for any play. Tighten as necessary.

Inspecting the Tank Straps

Service Interval: Before each use or daily—Check the tank straps.

Important: Overtightening the tank strap fasteners can result in deforming and damaging the tank and straps.

Important: Whenever possible, do not use reclaimed water (gray water) in the spray tank.

- 1. Fill the main tank with water.
- 2. Check to see if there is any movement between the tank straps and the tank (Figure 72).




Figure 72

- Rear tank strap
- 2. Bolt
- 3. Flanged locknut
- 4. Forward tank strap
- 5. Front of the machine
- 3. If the tank straps fit loose to the tank, tighten the flanged locknuts and bolts at the top of straps until the straps are flush with the surface of the tank (Figure 72).

Note: Do not overtighten the tank strap hardware.

Agitation-Bypass Valve Knob Position

- The agitation-bypass valve is in the full-open position as shown in Figure 73A.
- The agitation-bypass valve is in the closed (0) position as shown in Figure 73B.
- The agitation-bypass valve is in an intermediate (adjusted relative to the pressure for the sprayer system) position as shown in Figure 73C.




Figure 73

g214029

- 1. Open
- 2. Closed (0)
- Intermediate position

Calibrating the Agitation-Bypass Valve

Service Interval: Yearly—Calibrate the agitation-bypass valve.

Important: Whenever possible, do not use reclaimed water (gray water) in the spray tank.

- 1. Select an open, flat area to perform this procedure.
- 2. Fill the spray tank half full with clean water.
- 3. Verify that the agitation-control valve is open.

Note: If it has been adjusted, open it completely at this time.

- 4. Engage the parking brake and start the engine.
- 5. Set the sprayer to PRESSURE mode in the RATE CONTROL MODE section on the GeoLink display; refer to the *GeoLink Software Guide*.





Figure 74


- 6. Set the spray-pump switch and the agitation switch to the ON position.
- 7. Turn the master section switch to the OFF position.
- 8. Move the throttle lever to the FAST position.
- 9. Set the pressure to 689 kPa (100 psi) on the GeoLink display.
- 10. Turn the agitation switch to the OFF position and check the display for the pressure.
 - If the pressure reading indicates 689 kPa (100 psi), the agitation-bypass valve is properly calibrated.
 - If the pressure reading indicates differently, continue to the next step.
- Adjust the agitation-bypass valve on the backside of the agitation valve until the sprayer system pressure indicated on the display indicates 689 kPa (100 psi).



- 1. Actuator (agitation valve)
- 2. Agitation-bypass valve
- 12. Turn the spray-pump switch to the OFF position.
- 13. Move the throttle lever to the IDLE/SLOW position and turn the key switch to the OFF position.

Locating the Spray Pump

The spray pump is located near the back of the tank on the left side (Figure 76).



1. Spray pump

During Operation

During Operation Safety

General Safety

- The owner/operator can prevent and is responsible for accidents that may cause personal injury or property damage.
- Wear appropriate clothing, including eye protection; long pants; substantial, slip-resistant footwear; and hearing protection. Tie back long hair and do not wear loose clothing or loose jewelry.
- Wear appropriate personal protective equipment as directed in Chemical Safety.
- Use your full attention while operating the machine. Do not engage in any activity that causes distractions; otherwise, injury or property damage may occur.
- Do not operate the machine while ill, tired, or under the influence of alcohol or drugs.
- Do not carry more than 1 passenger on the machine; the passenger should sit in the designated seating position only.
- Operate the machine only in good visibility. Avoid holes or hidden hazards.
- Before you start the engine, ensure that you are in the operating position, the traction pedal is in the NEUTRAL position, and the parking brake is engaged.
- Remain seated whenever the machine is in motion. Keep both hands on the steering wheel whenever possible, and always keep your arms and legs within the operator's compartment.
- Use care when approaching blind corners, shrubs, trees, or other objects that may obscure your vision.
- Before backing up, look rearward and ensure that no one is behind you. Back up slowly.
- Never spray while people, especially children, or pets are nearby.
- Do not operate the machine near drop-offs, ditches, or embankments. The machine could suddenly roll over if a wheel goes over the edge or if the edge gives way.
- Reduce the speed when operating on rough terrain, uneven ground, and near curbs, holes, and other sudden changes in terrain. Loads may shift, causing the machine to become unstable.
- Stop the machine, shut off the engine, remove the key, engage the parking brake, and inspect for damage after striking an object or if there is

- an abnormal vibration in the machine. Make all necessary repairs before resuming operation.
- Slow down and use caution when making turns and crossing roads and sidewalks with the machine. Always yield the right-of-way.
- Use extra caution when operating the machine on wet surfaces, in adverse weather conditions, at higher speeds, or with a full load. Stopping time and distance increase in these conditions.
- Do not touch the engine or muffler while the engine is running or soon after it has shut off. These areas may be hot enough to cause burns.
- Before you leave the operator's position, do the following:
 - Park the machine on a level surface.
 - Move the traction pedal to the NEUTRAL position.
 - Shut off the spray pump.
 - Engage the parking brake.
 - Shut off the engine and remove the key (if equipped).
 - Wait for all movement to stop.
- Never run an engine in an area where exhaust gasses are enclosed.
- Do not operate the machine when there is the risk of lightning.
- Use accessories and attachments approved by Toro only.

Rollover Protection System (ROPS) Safety

Note: For each machine covered in this *Operator's Manual*, a cab installed by Toro is a ROPS.

- Do not remove the ROPS from the machine.
- Fasten the seat belt and ensure that you can release it quickly in an emergency. Always wear your seat belt.
- Check carefully for overhead obstructions and do not contact them.
- Keep the ROPS in safe operating condition by thoroughly inspecting it periodically for damage and keeping all the mounting fasteners tight.
- Maintain and clean the seat belt(s) as necessary.
- Replace any damaged ROPS component. Do not repair or alter it.

Slope Safety

Slopes are a major factor related to loss of control and rollover accidents, which can result in severe injury or

death. You are responsible for safe slope operation. Operating the machine on any slope requires extra caution.

- Review the slope instructions listed below for operating the machine on slopes and to determine whether you can operate the machine in the conditions on that day and at that job site.
 Changes in the terrain can result in a change in slope operation for the machine.
- Determine if the slope is safe for machine operation, including surveying the site. Always use common sense and good judgment when performing this survey.
- Avoid starting, stopping, or turning the machine on slopes. Travel up and down on slopes. Avoid making sudden changes in speed or direction. If you must turn the machine, turn it slowly and gradually downhill, if possible. Use care when reversing the machine.
- Do not operate a machine when you are uncertain about the traction, steering, or stability.
- Remove or mark obstructions such as ditches, holes, ruts, bumps, rocks, or other hidden hazards.
 Tall grass can hide obstructions. Uneven terrain could overturn the machine.
- Be aware that operating the machine on wet surfaces, across slopes, or downhill may cause the machine to lose traction. Loss of traction to the wheels may result in sliding and a loss of braking and steering.
- Use extreme caution when operating the machine near drop-offs, ditches, embankments, water hazards, or other hazards. The machine could suddenly roll over if a wheel goes over the edge or the edge caves in. Establish a safety area between the machine and any hazard.
- Use extra care while operating the machine with attachments; they can affect the stability of the machine.
- If the engine stalls or you begin to lose momentum while climbing a hill, gradually apply the brakes and slowly back straight down the hill.
- Always keep the transmission in gear (if applicable) when you drive the machine down a slope.
- Do not park the machine on an incline.
- The weight of the material in the tank can change the handling of the machine. To avoid loss of control and personal injury, follow these guidelines:
 - When operating with a heavy load, reduce your speed and allow for sufficient braking distance.
 Do not suddenly apply the brakes. Use extra caution on slopes.
 - Liquid loads shift, especially while turning, going up or down slopes, suddenly changing

speeds, or while driving over rough surfaces. Shifting loads can cause the machine to tip over.

Operating the Machine

Starting the Engine

- 1. Sit on the operator's seat and keep your foot off the traction pedal.
- 2. Ensure that the following controls are set:
 - The parking brake is engaged.
 - The traction pedal is in the NEUTRAL position.
 - The spray pump is shut off.
 - The throttle is in the SLOW position.
- 3. Turn the key to the START position.
- 4. Crank the engine for no longer than 15 seconds.
- 5. Release the key when the engine starts.
- 6. Run the engine at IDLE speed or partial throttle until the engine warms up.

Driving the Machine

 Release the parking brake and press the traction pedal forward to drive the machine forward or press the pedal rearward to drive the machine in reverse.

Important: Ensure that you allow the sprayer to come to a stop before switching between the FORWARD and REVERSE positions.

2. To slowly stop the machine, release the traction pedal.

Note: The traction pedal returns to the NEUTRAL position.

To stop quickly, press the brake pedal.

Note: The stopping distance of the machine may vary depending on the sprayer-tank load and ground speed of the machine.

Setting the Ground-Speed-Lock Switch

A CAUTION

If you press the ground-speed-lock switch and do not have your foot on the traction pedal, the traction unit may suddenly stop and cause you to lose control, possibly injuring you or bystanders.

Ensure that you have your foot on the traction pedal when you disengage the ground-speed-lock switch.

- 1. Start the spray pump by pressing the spray-pump switch to the ON position; refer to Spray-Pump Switch (page 29).
- 2. Drive forward and attain the desired ground speed; refer to Driving the Machine (page 42).

Note: You must drive the machine less than 11 km/h (7 mph) to set the ground-speed lock.

Press the top of the ground-speed-lock switch.

Note: The light on the switch illuminates.

4. Take your foot off the traction pedal.

Note: The sprayer maintains the speed that you set.

5. To release the ground-speed-lock switch, either place your foot on the traction pedal and press the bottom of the switch or remove your foot from the traction pedal and press the brake pedal.

Note: The light on the switch turns off and the traction control returns to the traction pedal.

Shutting Off the Engine

- 1. Move all the controls to the NEUTRAL position.
- 2. Press the brake to stop the sprayer.
- 3. Engage the parking brake.
- 4. Move the throttle lever to the IDLE/SLOW position.
- 5. Turn the key to the OFF position.
- 6. Remove the key from the switch to prevent someone from accidentally starting the engine.

Engine Messaging

There are 2 categories of engine messages that display on the InfoCenter when the engine is running outside the safe operating limit:

- Engine advisories messages
- Stop engine messages

Note: You must set the audio mute option in the InfoCenter to ON for engine advisory and stop engine alarms to sound; refer to Muting the Audio Indicator in the *Software Guide* for the Multi Pro 5800-D and 5800-G turf sprayers with ExcelaRate spray system.

Note: The symbol at the top right corner of the home screen, an engine advisory message, or a stop engine message indicates that an active fault exists for the engine.

Engine Advisories Messages

If an engine advisory message displays in the InfoCenter, you should stop spraying operation and drive the machine to the maintenance facility. Examples of the advisory screens are as follows:

 When the engine control unit (ECU) detects an advisory level fault, the engine advisory indicator displays (Figure 77).



Figure 77

g194664

2. Stop spraying operation and drive the machine to the maintenance facility.

Note: An Active Fault message displays (Figure 78).



Figure 78

Active Fault Message (Coolant Temp Too High)

- Press button 1 through 5 to view the active fault list (Figure 79).
 - Press button 1 or 2 to navigate up or down the list.
 - Press button 3 to mute the audio alarm.




Figure 79

4. Press button 5 to exit the active fault list and return to the home screen (Figure 80).




Figure 80

g194665

Stop Engine Messages

When a stop engine message displays in the InfoCenter, the operator should immediately park the machine and shutoff the engine. Examples of the advisory screens are as follows:

Important: Continued operation of the engine when a stop message displays will result in damage to the engine.

When the engine control unit (ECU) detects a severe level fault, the stop engine indicator displays (Figure 81).



Figure 81

g194667

- Immediately park the machine and shutoff the engine.
- An Active Fault message is next displayed (Figure 82).

a194666



Figure 82

g194663

- 4. Press button 1 through 5 to view the active fault list; refer to Figure 79 in Engine Advisories Messages (page 43).
 - Press button 1 or 2 to navigate up or down the list.
 - Press button 3 to mute the audio alarm.
- 5. Press button 5 to exit the active fault list and return to the home screen; refer to Figure 80 in Engine Advisories Messages (page 43).

Operating the Sprayer

To operate the sprayer: fill the sprayer tank, apply the product mix to the job site, and clean the tank and spray system. You must complete all 3 of these steps in succession to avoid damaging the sprayer. For example, do not mix and add chemicals in the sprayer tank at night and then spray in the morning. This leads to separation of the chemicals and possible damage to the sprayer components.

A CAUTION

Chemicals are hazardous and can cause personal injury.

- Read the directions on the chemical labels before handling the chemicals and follow all manufacturer recommendations and precautions.
- Keep chemicals away from your skin.
 Should contact occur, wash the affected area thoroughly with soap and clean water.
- Wear appropriate personal protective equipment (PPE) per the chemical manufacturer's instructions.

The Multi Pro® Sprayer is specifically designed for high durability, provides the long sprayer life. Different

materials have been chosen for specific reasons at different locations on your sprayer to meet this goal. Unfortunately, there is no single material which is perfect for all foreseeable applications.

Some chemicals are more aggressive than others and each chemical interacts differently with various materials. Some consistencies (e.g., wettable powders, charcoal) are more abrasive and lead to higher wear rates. If a chemical is available in a formulation that would provide increased life to the sprayer, use this alternative formulation.

As always, remember to clean your sprayer and spray system thoroughly after all applications. This ensures that your sprayer has a long and trouble-free life.

Note: If you have questions or need additional information regarding the spray-control system, refer to the *Operator's Manual* supplied with the system.

Important: To ensure that the product remains well mixed, use the agitation feature whenever you have solution in the tank.

Catch Test

Important: You will need to provide a graduated catch container (a container with 0.01 ml (1/2 fl. oz) increments is preferred) and a stopwatch to complete this procedure.

Refer to the GeoLink Software Guide.

Positioning the Spray Booms

The boom-section lift switches on the sprayer control panel allows you to move the outer spray sections between transport position and spray position without leaving the operator's seat. Whenever possible, stop the machine before changing spray section positions.

Changing the Spray Boom Position

Perform the following steps to move the outer spray sections to the spray position:

- 1. Park the machine on a level surface.
- Use the boom-section lift switches to lower the outer sections.

Note: Wait until the outer spray sections reach the full, extended spray position.

Complete the sprayer job, then perform the following steps to retract the outer spray sections into the transport position:

Important: If your machine has the Drift Reduction Boom Shroud Kit, the Ultra Sonic Boom Leveling Kit installed, or both move the outer spray sections to the transport position one at a time.

Moving both outer spray sections at the same time with the shroud kit or leveling kit installed may damage the shrouds, the sensors, or both.

- Park the machine on a level surface.
- Use the boom-section lift switches to raise the outer spray sections, until they have moved completely into boom-section transport cradles forming the "X" transport position, and the lift cylinders are fully retracted.

Important: Release the boom-section lift switch(es) once the outer spray sections have reached the desired position. Running the actuators against the mechanical stops may damage the lift cylinders and/or other hydraulic components.

Important: Ensure that the spray sections do not contact any low overhead objects while in the transport position, this can damage the spray sections.

Important: The spray sections can be damaged by transporting them in any position other than the "X" transport position using the boom transport cradle.




Figure 83 "X" transport position

Important: To prevent damage to the lift cylinder, ensure that the actuators are fully retracted before transporting the machine.

Taking Proper Turf Care Precautions while Operating in Stationary Modes

Important: Under some conditions, heat from the engine, radiator, and muffler can damage grass when operating the sprayer in a stationary mode. Stationary modes include tank agitation, hand spraying with a spray gun, or using a walking boom.

Use the following precautions:

- Avoid stationary spraying when conditions are very hot and/or dry, as turf can be more stressed during these periods.
- Avoid parking on the turf while stationary spraying.
 Park on a cart path whenever possible.
- Minimize the amount of time the machine is left running over any particular area of turf. Both time and temperature affect how much the grass may be damaged.
- Set the engine speed as low as possible to achieve the desired pressure and flow. This minimizes the heat generated and the air velocity from the cooling fan.
- Allow heat to escape upward from the engine compartment by raising the seat assemblies during stationary operation rather than being forced out under the vehicle.

Spraying Tips

- Do not overlap areas that you have previously sprayed.
- Watch for plugged nozzles. Replace all worn or damaged nozzles.
- Use the master section switch to stop the spray flow before stopping the sprayer. Once it stops, use the engine-throttle control to hold the engine speed up to keep the agitation running.
- You will obtain better results if the sprayer is moving when you turn the spray sections on.

Unclogging a Nozzle

If a nozzle becomes clogged while you are spraying, clean the nozzle as follows:

- 1. Stop the sprayer on a level surface, shut off the engine, and engage the parking brake.
- Set the master section switch to the OFF position and then set the sprayer-pump switch to the OFF position.

g467635

- 3. Remove the clogged nozzle and clean it using a spray bottle of water and a toothbrush.
- 4. Install the nozzle.

After Operation

After Operation Safety

General Safety

- Before you leave the operator's position, do the following:
 - Park the machine on a level surface.
 - Move the traction pedal to the NEUTRAL position.
 - Shut off the spray pump.
 - Engage the parking brake.
 - Shut off the engine and remove the key (if equipped).
 - Wait for all movement to stop.
 - Allow the machine to cool before adjusting, servicing, cleaning, or storing it.
- After you finish operating the machine for the day, wash off all chemical residue from the outside of the machine and ensure that the system has been neutralized and triple rinsed according to the recommendations of the chemical manufacturer(s) and that all the valves have been cycled 3 times; refer to Chemical Safety.
- Allow the engine to cool before storing the machine in any enclosure.
- Never store the machine or fuel container where there is an open flame, spark, or pilot light, such as on a water heater or other appliance.
- Keep all parts of the machine in good working condition and all hardware tightened.
- Replace all worn, damaged, or missing decals.

Cleaning the Sprayer

Wash the machine as needed using water alone or with a mild detergent. You may use a rag when washing the machine.

Important: Do not use brackish or reclaimed water to clean the machine.

Note: Do not use power-washing equipment to wash the machine. Power-washing equipment may damage the electrical system, loosen important decals, or wash away necessary grease at friction points. Avoid excessive use of water near the control panel, engine, and battery.

Important: Do not wash the machine with the engine running. Washing the machine with the engine running may result in internal engine damage.

Cleaning the Sprayer System

Draining the Tank

- Stop the sprayer, engage the parking brake, shut off the engine, and remove the key.
- 2. Locate the tank-drain valve at the left, rear fender of the machine (Figure 84).

Note: The drain valve is attached to the drain-valve bracket that is mounted to the left, rear fender.




Figure 84

g191084

- 1. Drain valve (sprayer tank)
- 3. Lift the valve until the mount studs of the valve clear the slots in the drain-valve bracket, and move the valve rearward (Figure 85A).




Figure 85

a191083

1. Drain-valve bracket

3. Drain valve handle (open position)

2. Mount studs (drain valve)

- 4. Align the end of the valve with the drain container and rotate valve handle to the open position (Figure 85B).
- 5. When the tank has drained completely, rotate the drain-valve handle to the closed position and assemble the valve onto the drain-valve bracket (Figure 85B and Figure 85A).

Important: Dispose of the sprayer tank chemicals according to local codes and the material manufacturer's instructions.

Cleaning Internal Sprayer Components

Important: Use only clean water when cleaning the sprayer.

Important: You must always drain and flush out the sprayer, including any installed spray system accessories immediately after each use. Failure to flush and clean the sprayer may allow the chemicals to dry and obstruct in the lines, filters, valves, nozzle bodies, pump, and other components.

Toro recommends using the approved Clean Rinse Kit for this machine. Contact your authorized Toro distributor for more information.

Note: The recommendations and instructions that follow assume that the Toro Rinse Kit is not installed.

Clean the spray system and any installed spray accessories after **each** spraying session. To properly clean the spray system, perform the following:

- Complete 3 separate rinse cycles.
- Use the cleaners and neutralizers as recommended by your chemical manufacturers.
- Use pure, clean water (no cleaners or neutralizers) for the **final** rinse.
- 1. Fill the tank with at least 190 L (50 US gallons) of clean water and close the cover.

Note: You can use a cleaning/neutralizing agent in the water as needed. On the final rinse, use only clean, clear water.

- 2. Lower the outer spray sections into the spray position.
- 3. Start the engine, set the parking brake, set the spray pump switch to the ON position, and move the throttle lever to a high-engine speed.
- 4. Set the agitation switch to the ON position.
- Set the sprayer to PRESSURE mode in the RATE CONTROL MODE section on the GeoLink display; refer to the GeoLink Software Guide.
- 6. Set the pressure to 689 kPa (100 psi) on the GeoLink display.
- 7. Set the individual section switches and master section switch to the ON positions.
- 8. Check the nozzles to ensure that they are all spraying correctly.
- 9. Allow all water in the tank to spray out through the nozzles.
- 10. Set the master section switch to the OFF position, the set the agitation switch and spray-pump switch to the OFF position, and shut off the engine.
- 11. Repeat steps 1 through 10 at least 2 more times to ensure that the spray system is fully cleaned.

Important: You must always complete 3 rinse cycles to ensure that the spray system and spray accessories are fully clean, preventing damage to the system.

Cleaning External Sprayer Components

 Clean the suction and pressure filters; refer to Cleaning the Suction Filter (page 49) and Cleaning the Pressure Filter (page 49).

Important: If you used wettable powder chemicals, clean the strainer after each tank.

2. Using a garden hose, rinse off the outside of the sprayer with clean water.

3. Remove the nozzles and clean them by hand.


Note: Replace damaged or worn nozzles.

Note: If your machine has optional nozzle filters, clean them before installing the nozzles; refer to Cleaning the Nozzle Filter (page 50).

Cleaning the Suction Filter

Service Interval: Before each use or daily—Clean the suction filter. Clean the suction filter (more often when using wettable powders).

- 1. Park the machine on a level surface, engage the parking brake, shut off the pump, shut off the engine, and remove the key.
- 2. At the top of the sprayer tank, remove the retainer that secures the hose fitting attached to the large hose from the filter housing (Figure 86).



- 1. Suction hose
- 2. Retainer
- 3. Remove the hose and hose fitting from the filter housing (Figure 86).
- 4. Pull the suction strainer out of the filter housing in the tank (Figure 87).




Figure 87

- . Screen vane
- 2. Suction strainer
- Clean the suction filter with clean water.


Important: Replace the filter if it is damaged or cannot be cleaned.

- 6. Insert the suction filter into the filter housing until the filter is fully seated.
- 7. Align the hose and hose fitting to the filter housing at the top of the tank, and secure fitting and housing with the retainer that you removed in step 2.

Cleaning the Pressure Filter

Service Interval: Before each use or daily—Clean the pressure filter. Clean the pressure filter (more often when using wettable powders).

- Park the machine on a level surface, engage the parking brake, shut off the sprayer pump, shut off the engine, and remove the key.
- 2. Align a drain pan under the pressure filter (Figure 88).



- 1. Filter head
- 2. Gasket (bowl)
- 3. Filter element
- 4. Bowl
- 5. Gasket (drain cap)
- 6. Drain cap
- 3. Rotate the drain cap counterclockwise and remove it from the bowl of the pressure filter (Figure 88).

Note: Allow the bowl to drain completely.

- 4. Rotate the bowl counterclockwise and remove the filter head (Figure 88).
- 5. Remove the pressure filter element (Figure 88).
- 6. Clean the pressure filter element with clean water.

Important: Replace the filter if it is damaged or cannot be cleaned.

7. Check the gasket for the drain plug (located inside the bowl) and the gasket for bowl (located inside the filter head) for damage and wear (Figure 88).

Important: Replace any damaged or worn gaskets for the plug, bowl, or both.

Install the pressure filter element into the filter head (Figure 88).

Note: Ensure that the filter element is firmly seated into the filter head.

- 9. Install the bowl onto the filter head, and tighten by hand (Figure 88).
- 10. Assemble the drain cap onto the fitting at the bottom of the bowl, and tighten the cap by hand (Figure 88).

Cleaning the Nozzle Filter

- Park the machine on a level surface, engage the parking brake, shut off the sprayer pump, shut off the engine, and remove the key.
- Remove the nozzle from the spray turret (Figure 89).




Figure 89

- 1. Spray turret
- 3. Nozzle
- 2. Nozzle filter

- Remove the nozzle filter (Figure 89).
- 4. Clean the nozzle filter with clean water.

Important: Replace the filter if it is damaged or cannot be cleaned.

5. Install the nozzle filter (Figure 89).

Note: Ensure that the filter is fully seated.

6. Install the nozzle onto the spray turret (Figure 89).

a209504

Conditioning the Spray System

Service Interval: After each use—Condition the spray system at the end of each daily use.

Conditioner Specification

Conditioner specification: propylene glycol "non-toxic RV antifreeze" with corrosion inhibitor

Important: Use only propylene glycol with corrosion inhibitor.

Do not use recycled propylene glycol. Do not use ethylene glycol base antifreeze.

Do not use propylene glycol with soluble alcohols (methanol, ethanol, or isopropanol) or brines added.

Preparing the Conditioner

- Move the machine to a level surface, set the parking brake, shut off the engine, and remove the key.
- 2. Add conditioner to the tank as follows:
 - For ready to use (premixed) propylene glycol RV antifreeze—add 10 gallons of propylene glycol RV antifreeze to the tank.
 - For concentrated propylene glycol RV antifreeze, perform the following steps:
 - A. Add a 10-gallon mixture of propylene glycol RV antifreeze and water into the sprayer tank. Prepared the antifreeze mixture as instructed manufacturer for a concentration rated for -45°C (-50°F) minimum.

Important: Use only clean water when cleaning the sprayer.

- B. Start the engine and set the spray-pump switch to the ON position.
- C. Press the accelerator pedal to increase the engine speed.
- D. Set the agitation switch to the ON position.

Allow the conditioner and water solution to circulate for 3 minutes or longer.

Spraying the Conditioner

Recommended tool: a clear catch container.

- 1. Move the machine to the drain pad area and set the parking brake.
- 2. Lower the outer booms sections.
- 3. Set the left, center, and right section switches and the master section switch to the ON position.

4. Allow the spray system to spray until the nozzles discharge the conditioner.


Note: Most propylene glycol RV antifreeze is colored pink. Use the catch container to sample the sprayer discharge at several of the nozzles.

Shut off the master section switch, 3 section switches, agitation switch, spray-pump switch, and engine.


Hauling the Machine

Use a trailer or truck when moving the machine long distances.

- Use full-width ramps for loading the machine onto a trailer or truck.
- Tie outer spray sections to the boom-section transport cradles.
- Bind the machine securely to the transport vehicle;
 Figure 90 and Figure 91 illustrate the tie-down points of the machine.



Front tie-down points (front axle)



1. Rear tie-down loop (rear axle tube)

Towing the Sprayer

In case of an emergency, the sprayer can be towed for a short distance after you open the tow valve. However, we do not recommend this as a standard procedure.


A WARNING

Towing at excessive speeds could cause a loss of steering control, resulting in personal injury.

Never tow the sprayer at faster than 4.8 kph (3 mph).

Towing the sprayer is a 2-person job. If the machine must be moved a considerable distance, transport it on a truck or trailer; refer to Hauling the Machine (page 51).

- 1. Allow the exhaust system to cool completely.
- Remove the undercarriage shroud; refer to Removing the Undercarriage Shroud (page 58).
- 3. Rotate the tow valve (Figure 92) 90° in either direction to open the tow valve.



1. Tow valve

Important: If you do not open the tow valve before towing the sprayer, you will damage the transmission.

 Affix a tow line to the frame; refer to the front and rear towing points (Figure 93 and Figure 94).





Figure 93

Front towing points



- 1. Rear towing points
- 5. Release the parking brake.
- 6. Tow the sprayer at less than 4.8 kph (3 mph).
- 7. When finished, close the tow valve and torque it to 7 to 11 N·m (5 to 8 ft-lb).

Important: Before returning the machine to service, install the undercarriage shroud; refer to Installing the Undercarriage Shroud (page 59).

Maintenance

Note: Download a free copy of the electrical or hydraulic schematic by visiting www.Toro.com.

Important: Refer to your engine owner's manual for additional maintenance procedures.

Note: Determine the left and right sides of the machine from the normal operating position.

Maintenance Safety

- Before you leave the operator's position, do the following:
 - Park the machine on a level surface.
 - Move the traction pedal to the NEUTRAL position.
 - Engage the parking brake.
 - Shut off the engine and remove the key (if equipped).
 - Wait for all movement to stop.
- Allow machine components to cool before performing maintenance.
- Allow only qualified and authorized personnel to maintain, repair, adjust, or inspect the machine.
- Before performing any maintenance, thoroughly clean and rinse the sprayer; refer to Chemical Safety.
- Chemicals used in the sprayer system may be hazardous and toxic to you, bystanders, animals, plants, soils, or other property.
 - Carefully read and follow the chemical warning labels and safety data sheets (SDSs) for all chemicals used, and protect yourself according to the chemical manufacturer's recommendations.
 - Always protect your skin while you are near chemicals. Use the appropriate personal protective equipment (PPE) to guard against contact with chemicals, including the following:
 - ♦ safety glasses, goggles, and/or face shield
 - a chemical suit
 - ♦ a respirator or filter mask
 - ♦ chemical-resistant gloves
 - v rubber boots or other substantial footwear
 - a clean change of clothes, soap, and disposable towels for cleanup
 - Refuse to operate or work on the sprayer if chemical safety information is not available.
 - Do not fill, calibrate, or clean the machine while people, especially children, or pets are in the area.

- Handle chemicals in a well-ventilated area.
- Have clean water available, especially when filling the spray tank.
- Do not eat, drink, or smoke while working near chemicals.
- Do not clean spray nozzles by blowing through them or placing them in your mouth.
- Always wash your hands and other exposed areas as soon as possible after working with chemicals.
- Chemicals and fumes are dangerous; never enter the tank or place your head over or in the opening of a tank.
- To ensure that the entire machine is in good condition, keep all hardware properly tightened.
- To reduce the potential for fire, keep the engine area free of excessive grease, chemicals, grass, leaves, and dirt.
- If you must run the engine to perform a maintenance adjustment, keep your hands, feet, clothing, and any parts of your body away from the engine and any moving parts. Keep everyone away.
- Do not adjust the ground speed of the machine. To ensure safety and accuracy, have an authorized Toro distributor check the ground speed.
- If the machine requires a major repair or you need technical help, contact an authorized Toro distributor.
- Modifying this machine in any manner may affect machine operation, performance, durability, or its use, and result in injury or death. Such use could void the product warranty.
- Support the machine with jack stands whenever you work under the machine.
- Carefully release pressure from components with stored energy.

Recommended Maintenance Schedule(s)

Maintenance Service Interval	Maintenance Procedure
After the first 8 hours	Torque the wheel-lug nuts. Check the fan/alternator belt.
After the first 50 hours	 Change the engine oil filter. Change the engine oil (including synthetic oil). Check the fuel lines and connections. Change the gearbox oil.
After the first 100 hours	To provide proper performance and long sprayer life, follow these guidelines for the first 100 operating hours:
After the first 200 hours	Pack the front wheel bearings.
Before each use or daily	 Inspect the seat belt(s) for wear, cuts, and other damage. Replace the seat belt(s) if any component does not operate properly. Check the tire air pressure. Check the brakes. Check the tank straps. Clean the suction filter. Clean the pressure filter. Check the air cleaner. Check the engine oil. Check the coolant level. Check the hydraulic-fluid level.
After each use	Clean the sprayer.Condition the spray system at the end of each daily use.
Every 50 hours	 Lubricate the pump. Lubricate all grease fittings. Grease the steering and suspension. Grease the steering and suspension. Check the battery-cable connections.
Every 100 hours	 Lubricate the boom hinges. Replace the air-filter element. Torque the wheel-lug nuts. Inspect the condition and wear of the tires. Check the fan/alternator belt.
Every 200 hours	 Change the engine oil filter. Change the filter more often when operating the machine under heavy load or in high temperatures. Change the engine oil (including synthetic oil). Change the oil more often when operating the machine under heavy load or in high temperatures. Check front wheel toe-in. Inspect all hoses and connections for damage and proper attachment. Clean the radiator fins. Clean the flow meter (more often when using wettable powders).

Maintenance Service Interval	Maintenance Procedure
Every 400 hours	 Grease the actuator-rod bearings. Perform yearly engine maintenance. Check the fuel lines and connections. Service the fuel filter. Drain and clean the fuel tank. Pack the front wheel bearings. Check the gearbox oil. Check the coolant (as directed by the manufacturer) and change if necessary. Inspect the O-rings in the valve assemblies and replace them if necessary. Change the suction filter. Change the pressure filter. Inspect the nylon pivot bushings. Inspect the pump diaphragms and replace if necessary (see an authorized Toro distributor). Inspect the pump check valves and replace if necessary (see an authorized Toro distributor).
Every 800 hours	 Change the gearbox oil. or yearly, whichever comes first. If you are not using the recommended hydraulic fluid or have ever filled the reservoir with an alternative fluid, replace the hydraulic filter. If you are not using the recommended hydraulic fluid or have ever filled the reservoir with an alternative fluid, change the hydraulic fluid.
Every 1,000 hours	Check the PCV valve. If you are using the recommended hydraulic fluid, replace the hydraulic filter.
Every 2,000 hours	If you are using the recommended hydraulic fluid, change the hydraulic fluid.
Yearly	Calibrate the agitation-bypass valve.

Daily Maintenance Checklist

Duplicate this page for routine use.

Maintenance Check Item	For the week of:						
	Monday	Tuesday	Wednesday	Thursday	Friday	Saturday	Sunday
Check the brake and parking-brake operation.							
Check the neutral-lockout-switch operation.							
Check the fuel level.							
Check the engine-oil level.							
Check the hydraulic-fluid level.							
Check the coolant level.							
Inspect the air filter.							
Inspect the radiator and oil cooler for debris.							
Check for any unusual engine noises.							
Check for any unusual operating noises.							
Check the tire air pressure.							
Check for fluid leaks.							
Check all hydraulic and fluid hoses for damage, kinks, or wear.							
Check the instrument operation.							
Check the accelerator operation.							
Clean the suction strainer.							
Lubricate all grease fittings ¹							
Wash the machine.							
Touch up any damaged paint.							

¹Immediately after **every** washing, regardless of the interval listed

Notation for Areas of Concern

Inspecti	Inspection performed by:		
Item	Date	Information	
1			
2			
3			
4			
5			
6			
7			
8			
9			
10			

Pre-Maintenance **Procedures**

A CAUTION

If you leave the key in the starter switch, someone could accidently start the engine and seriously injure you or other bystanders.

Remove the key from the starter switch before you do any maintenance.

Raising the Sprayer

Whenever running the engine for routine maintenance and/or engine diagnostics, the rear wheels of the sprayer should be 25 mm (1 inch) off the ground with the rear axle supported on jack stands.

A DANGER

A sprayer on a jack may be unstable and slip off the jack, injuring anyone beneath it.

- Always remove the key from the starter switch before getting off the sprayer.
- Block the tires when the sprayer is on a jack.
- Support the machine with jack stands.

The jacking point at the front of the sprayer is under the front axle, directly under the leaf springs (Figure 95).





Figure 95

1. Front jacking points

The jacking point at the rear of the sprayer is on the rear side where the boom supports are located (Figure 96).



1. Rear jacking points

Accessing the Engine

Removing the Forward Heat Shield

- Engage the parking brake, shut off the spray pump, shut off the engine, and remove the key.
- Raise the front and back of the machine and support it with jack stands.
- Remove the hardware that secures the front, forward heat shield to the chassis and remove the shield.





Figure 97

g525978

Installing the Forward Heat Shield

1. Align the rear flange of the forward heat shield over the forward flange of the rear heat shield.



- 1. Front of the machine
- 2. Hex-head bolts and washers
- 3. Rear flange (forward heat shield)
- 4. Forward flange (rear heat shield)
- 2. Align the holes in the forward heat shield with the threaded holes in the chassis.
- 3. Assemble the forward heat shield to the machine with the previously removed hardware.
- 4. Torque the bolts to 1978 to 2542 N·cm (175 to 115 in-lb).
- 5. Remove the jack stands and lower the machine.

Removing the Undercarriage Shroud

1. Remove the hardware that secures the rear of the undercarriage shroud to the chassis of the machine.





Figure 99

2. Remove the 4 flange locknuts (5/16 inch) from the bolts and carriage bolt that secure the mounting tabs of the undercarriage shroud to the engine-mount brackets of the machine.

Note: Do not remove the bolts from the machine. Retain the flange locknuts.



- Engine mount
- 4. Flange locknuts (5/16 inch)
- Bolt—shown for clarity: do 5. Front of the machine not remove
- 3. Mounting tabs (undercarriage shroud)
- Move the mounting tabs off of the bolts that secure the undercarriage shroud to the engine-mount brackets.

Installing the Undercarriage Shroud

- 1. Align the undercarriage shroud to the bottom chassis of the machine.
- Move the mounting tabs of the undercarriage shroud over the bolts and carriage bolt at the engine-mount brackets of the machine.
- Assemble the undercarriage shroud to the engine-mount brackets and bolts with the previously removed 4 flange locknuts (5/16 inch).
- Align the holes in the rear part of the undercarriage shroud with the holes in the chassis.
- 5. Assemble the rear part of the undercarriage shroud to the chassis with the previously removed 5 flange-head bolts (5/16 x 7/8 inch) and 5 washers (5/16 inch).
- Torque the nuts and bolts to 1129 to 1582 N·cm (100 to 140 in-lb).

Removing the Seat-Base-Access **Panel**

Remove the 2 flanged-head bolts that secure the seat-base-access panel to the seat base.




Figure 101

- Seat-base-access panel
- 3. Hole (seat base)
- Flanged-head bolt
- Remove the seat-base-access panel from the machine.

Installing the Seat-Base-Access Panel

- 1. Align the holes in the seat-base-access panel with the holes in the seat base.
- Assemble the seat-base-access panel to the seat base with the previously removed 2 flanged-head bolts.

Torque the bolts to 1975 to 2542 N·cm (175 to 225 in-lb).

Lubrication

Greasing the Spray Pump

Service Interval: Every 50 hours—Lubricate the pump.

Every 50 hours/Yearly (whichever comes first)

Grease Type: Mobil XHP 461.

1. Wipe the 2 remote grease fitting clean (Figure




Figure 102

- Back of the machine
- 3. Grease point (2)
- Spray pump
- Pump grease into the remote grease fitting (Figure 102).
- Wipe off the excess grease.

Greasing the Steering and Suspension


Service Interval: Every 50 hours—Grease the steering and suspension.

Every 50 hours/Yearly (whichever comes first)


Grease Type: No. 2 lithium grease. Toro Premium All-Purpose Grease is available from your authorized Toro distributor.

- Steering cylinder—2 grease fittings at each rod end of the cylinder
- Steering rod—2 grease fittings at each rod end
- Spindle pivot—2 grease fittings at each side of the machine
- Wipe the grease fittings clean (Figure 103 and Figure 104).
- Pump grease into the grease fittings (Figure 103 and Figure 104).
- Wipe off excess grease.

Note: The grease fittings positions are illustrated in Figure 103.



Grease fitting



There are 2 fittings at each front wheel.

Grease fittings

Greasing the Boom Hinges

Service Interval: Every 100 hours

Important: If you wash the boom hinges with water, remove all water and debris from the hinge assembly and apply fresh grease.

Grease Type: No. 2 lithium grease.

- Wipe the grease fittings clean so that foreign matter cannot be forced into the bearing or bushing.
- Pump grease into the bearing or bushing at each fitting (Figure 105).




Figure 105 Right Boom

- 1. Grease fitting
- 3. Wipe off excess grease.
- 4. Repeat the procedure for each boom pivot.

Greasing the Actuator-Rod Bearings

Service Interval: Every 400 hours/Yearly (whichever comes first)

Grease Type: No. 2 lithium grease.

- 1. Lower the outer spray sections to the spray position.
- 2. Remove the hairpin from the clevis pin (Figure 106).
- 3. Lift up on the section, remove the clevis pin, and slowly lower the section to the ground (Figure 106).
- 4. Inspect the clevis pin for damage, and replace it if necessary.




Figure 106

- 1. Actuator
- 2. Actuator rod
- 4. Hairpin
- 5. Clevis pin
- 3. Boom-pivot-pin housing
- 5. Swivel the rod-end bearing and apply grease into the bearing (Figure 107).

Note: Wipe off excess grease.




Figure 107 Right Boom

g002015

- 1. Grease the rod-end bearing
- 6. Lift the spray section to align the pivot with the actuator rod.
- 7. While supporting the spray section, insert the clevis pin through both boom pivot and actuator rod (Figure 106).
- With the pin in place, release the spray section and secure the clevis pin with the hairpin removed previously.

9. Repeat steps 2 through 8 to the actuator-rod bearing at the other side of the machine.

Engine Maintenance


Engine Safety

Shut off the engine before checking the oil or adding oil to the crankcase.

Checking the Air Cleaner

Service Interval: Before each use or daily Service the air cleaner more frequently if operating conditions are extremely dusty or sandy.

- 1. Engage the parking brake, shut off the spray pump, shut off the engine, and remove the key.
- Tilt the passenger seat forward and align the prop rod into the detent in the prop-rod-guide slot.
- 3. Clean the dust cap and air-cleaner body (Figure 108).



- 1. Dust cap
- 2. Latch (dust cap)
- 3. Air-filter element
- 4. Air-cleaner body
- 5. Dust valve
- 4. Check the air-cleaner body for damage that could cause an air leak (Figure 108).

Note: Replace the dust cap and air-cleaner body if either is damaged.

- 5. Squeeze the dust valve to clear it of dirt, dust, and debris (Figure 108).
- 6. Loosen the 2 latches that secure the dust cap to the air-cleaner body.

 Check the air-filter element for excessive accumulation of dust, dirt, and debris (Figure 108).

Note: Do not clean the air-filter element if it is dirty; replace the air-filter element if it is dirty.

8. Install the dust cap onto the air-cleaner body and secure the cap with the 2 latches (Figure 108).

Note: Ensure that the dust valve aligns between the 5 to 7 o'clock position when viewed from the end.

9. Lower the passenger seat.

Replacing the Air-Filter Element

Service Interval: Every 100 hours Replace the air-filter element more often in dusty, dirty conditions.

 If you are installing a new filter, inspect the new air-filter element for shipping damage, including the sealing end of the filter.

Important: Do not install a damaged filter.

- 2. Clean the dust cap and air-cleaner body (Figure 108).
- 3. Lift the coolant-overflow tank up and off the tank-support bracket (Figure 109).




Figure 109

g03254

- 1. Coolant-overflow tank
- 2. Tank-support bracket
- 3. Latch (dust cap)
- 4. Dust cap

- 5. Air-filter element
- 6. Dust valve (5 to 7 o'clock position)
- 7. Pressure-relief hose
- 8. Tank-vent hose
- 4. Loosen the 2 latches that secure the dust cap to the air-cleaner body (Figure 109).
- 5. Gently slide the old filter element out of the air-cleaner body to reduce the amount of dust dislodged.

Note: Avoid knocking the filter element against the air-cleaner body.

- Clean the inside of the dust cap, air-cleaner body, and dust valve with a damp rag (Figure 108 and Figure 109).
- 7. Insert the air-filter element into the air-cleaner body (Figure 109).

Note: Ensure that the filter is seated in the air-cleaner body properly by applying pressure to the outer rim of the filter element when you install it. Do not press on the flexible center part of the filter.

Install the cover onto the air-cleaner body and secure the cover with the 2 latches (Figure 109).

Note: Ensure that the dust valve is aligned between the 5 to 7 o'clock position when viewed from the end (Figure 109).

9. Align the coolant-overflow tank to the tank-support bracket and seat the tank firmly (Figure 109).

Important: Ensure that the pressure-relief hose is routed forward and down, and the tank-vent hose is routed rearward as shown in Figure 109.

10. Lower the passenger seat.

Engine-Oil Specification

- Oil type: API service classification SL or higher.
- Oil viscosity: refer to the engine oil viscosity table below.

Engine Oil Viscosity Table

Ambient temperature range	Oil viscosity
Above 25°C (77°F)	SAE30, SAE10W-30, or SAE15W-40
0°C to 25°C (32°F to 77°F)	SAE20 or SAE10W-30
0°C to 20°C (32°F to -4°F)	SAE10W or SAE10W-30

Toro Premium Engine Oil is available from your distributor in either 15W40 or 10W30 viscosity. Refer to the *Parts Catalog* for part numbers.

Checking the Engine Oil


Service Interval: Before each use or daily Check the engine oil level before you start the engine for the first time.

Note: The best time to check the engine oil is when the engine is cool, before it has been started for the day. If the engine was operated, allow the oil to drain back down to the sump for at least 10 minutes before checking.

The engine is shipped with oil in the crankcase; however, the level of oil must be checked before you first start the engine and after you have run it.

- 1. Position the machine on a level surface.
- 2. Remove the dipstick, located under the passenger seat, and wipe it with a clean rag (Figure 110).

Note: Insert the dipstick into the tube and make sure it is seated fully. Remove the dipstick and check the oil level.



- I. Low
- 2. Full
- 3. High

- 4. Oil-filler cap
- 5. Dip stick

 If the oil level is low, remove the filler cap from the valve cover (Figure 110) and pour oil into the filler neck until the oil level is up to the Full mark on the dipstick.

Note: Add the oil slowly and check the level often during this process. Do not overfill.

- Install the oil-filler cap (Figure 110).
- 5. Install the dipstick firmly in place (Figure 110).

Changing the Engine Oil Filter

Service Interval: After the first 50 hours

Every 200 hours Change the filter more often when operating the machine under heavy load or in high temperatures.


- Remove the forward heat shield; refer to Removing the Forward Heat Shield (page 57).
- 2. Raise the seats.

A CAUTION

Components under the seat will be hot if the sprayer has been running. If you touch hot components, you may be burned.

Allow the sprayer to cool before performing maintenance or touching components under the hood.

3. Align a drain pan under the engine oil filter (Figure 111).



- 1. Drain plug
- 2. Engine oil filter
- Remove the old oil filter (Figure 111).

Note: Dispose of the used oil filter at a certified recycling center.

- 5. Wipe clean the surface of the oil filter adapter of the engine with a rag.
- Fill the oil filter with the specified oil.

Note: Allow the filter element to saturate with oil.

- 7. Apply a thin coat of the specified oil to the rubber gasket on the replacement oil filter.
- Install the oil filter to the filter adapter and turn the oil filter clockwise until the rubber gasket contacts the filter adapter, then tighten the filter an additional 1/2 turn (Figure 111).

Note: Do not overtighten the oil filter.

Wipe clean any residual oil.

Engine-Oil Quantity

5.1 L (5.4 US qt) with the filter; refer to Engine-Oil Specification (page 64)

Changing the Engine Oil

Service Interval: After the first 50 hours


Every 200 hours Change the oil more often when operating the machine under heavy load or in high temperatures.

- 1. Align a drain pan under the drain plug (Figure 111).
- 2. Remove the drain plug (Figure 111) and allow the oil to drain completely.

Note: Check the drain plug seal for wear and damage; replace the seal if it is worn or damaged.

Note: Dispose of the used oil at a certified recycling center.

- 3. Install the drain plug into the drain port of the engine oil pan and tighten the plug to 33 to 37 N·m (24 to 27 ft-lb).
- 4. Tilt the passenger seat forward and align the prop rod into the detent in the prop-rod-guide slot.
- 5. Remove the oil-filler cap from the filler neck of the valve cover of the engine (Figure 112) and slowly pour approximately 80% of the specified amount of oil into the filler neck.



1. Low

4. Oil-filler cap

2. Full

5. Dipstick

- 3. High
- 6. Remove the dipstick and check the oil level in the engine (Figure 112).
- 7. Slowly add additional specified oil to bring the oil level to the full mark on the dipstick (Figure 112).

Important: Overfilling the engine with oil may cause damage to the engine.

- 8. Install the oil-filler cap into the filler neck and the dipstick into the dipstick tube (Figure 112).
- 9. Start the engine and check for oil leaks.
- 10. Shut off the engine, wait 2 to 3 minutes, remove the dipstick, and check the oil level in the engine.

Note: If needed, remove the oil-filler cap, add the specified oil to bring the oil level to the full mark on the dipstick, and install the oil-filler cap.


 Install the dipstick, engine heat shield, and tilt the seats down.

Checking the PCV Valve

Service Interval: Every 1,000 hours

- 1. Tilt the driver's seat forward and align the proprod into the detent in the prop-rod-guide slot.
- 2. Remove the PCV valve from the fitting of the valve cover (Figure 113).

Note: Do not separate the hose from the PCV valve.



- 1. Front of the machine
- 2. Hose (crankcase ventilation)
- 3. PCV valve
- Valve-cover fitting
- 3. Shake the PCV valve.

Note: If the internal restrictor of the valve rattles, the PCV valve is serviceable; if the internal restrictor is not free to rattle when shaken, replace the PCV valve (Figure 113).

- 4. Insert the PCV valve until it is fully seated in the seal for the valve-cover fitting (Figure 113).
- 5. Lower the operator's seat.

Performing Yearly Engine Maintenance

Service Interval: Every 400 hours/Yearly (whichever comes first)

Complete all yearly maintenance procedures specified in the **engine owner's manual**.

Fuel System Maintenance

A DANGER

Under certain conditions, fuel and fuel vapors are highly flammable and explosive. A fire or explosion from fuel can burn you and others and can cause property damage.

- Use a funnel and fill the tank outdoors, in an open area, when the engine is off and is cold. Wipe up any spilled fuel.
- Do not fill the fuel tank completely full.
 Add fuel to the fuel tank until the level is 25
 mm (1 inch) below the bottom of the filler
 neck. This empty space in the tank allows
 the fuel to expand.
- Never smoke when handling fuel, and stay away from an open flame or where fuel fumes may be ignited by a spark.
- Store fuel in a clean, safety-approved fuel container and keep the cap in place.

Checking the Fuel Line and Connections

Service Interval: After the first 50 hours

Every 400 hours/Yearly (whichever comes first)

Inspect the lines and fittings for deterioration, damage, or loose connections.

Note: If you find any fuel leaks, repair the fuel component(s) before operating the machine.

Bleeding the Fuel System

Use this procedure after you have serviced the fuel filter or ran the engine out of fuel, and the engine does not start.

- 1. Ensure that you have 1/2 tank of fuel in the fuel tank.
- 2. Insert the key into the starter switch and rotate it to the ON position.
- 3. Rotate the key to the OFF position.
- 4. Attempt to start the engine.
- 5. If the engine does not start, repeat steps 2 and 3 several times and then attempt to start the engine.

Note: Repeat step 5 until the engine starts.

Servicing the Fuel Filter

Service Interval: Every 400 hours

Removing the Fuel Pump Cover

- 1. Engage the parking brake, stop the spray pump, stop the engine, and remove the key.
- 2. At the fuel tank, remove the 4 screws (#10 x 3/4 inch) that secure the cover to the top of the fuel tank, and remove the cover (Figure 114).




Figure 114

- 1. Screws (#10 x 3/4 inch)
- 3. Fuel tank

a323402

2. Cover

Removing the Carbon Canister

- 1. Engage the parking brake, stop the spray pump, stop the engine, and remove the key.
- 2. At the fuel tank, remove the 4 screws (#10 x 3/4 inch) that secure the carbon-canister bracket to the top of the fuel tank (Figure 115).





Figure 115

- 1. Screw (#10 x 3/4 inch)
- 3. Fuel tank
- 2. Carbon-canister bracket
- 3. Loosen the 2 hose clamps that secure the hoses to the fittings of the carbon canister (Figure 116).



- 1. Hose clamps
- 4. Separate the hoses from the fittings (Figure 117).




Figure 117

- 5. Remove the hose clamps from the hoses (Figure 117).
- 6. Remove the carbon canister from the fuel tank (Figure 117).

Removing the Fuel Pump and Sending Unit

 Disconnect the 2-socket connector of the machine-wiring harness from the 2-pin connector of the fuel pump/sending unit; disconnect the 2-pin connector of the machine-wiring harness from the 2-socket connector of the fuel pump/sending unit (Figure 118).




Figure 118

g323401

- 2-socket connector (machine—wiring harness)
- 2. 2-pin connector (fuel pump/sending unit)
- 3. 2-pin connector (machine-wiring harness)
- 4. 2-socket connector (fuel pump/sending unit)
- 5. Nut (fuel pump/sending unit)
- Seal
- 7. Fitting (fuel pump)
- 8. Fuel-hose coupling
- Slide the locking sleeve of the fuel-hose coupling away from the fitting of the fuel pump/sending unit and remove the coupling and hose from the fitting (Figure 118).

Note: Clean up any fuel that flows from the hose coupling or fuel-pump fitting.

- Rotate the nut for the fuel pump/sending unit counterclockwise and remove the nut and seal (Figure 118)
- 4. Carefully lift and rotate the fuel pump/sending unit out of the neck of the fuel tank (Figure 119).

Important: Use caution when handling the fuel pump/sending unit to avoid damaging the arm for the float of the sending unit.




Figure 119

- 1. Fuel-tank neck
- 2. Arm (sending-unit float)
- 3. Pickup tube (fuel filter)
- 4. Fuel pump/sending unit
- 5. Filter
- 6. Float

Replacing the Fuel Filter

1. Remove the pickup tube of the fuel filter from the fitting of the fuel pump (Figure 120).

Note: Discard the fuel filter.




Figure 120

- 1. Fitting (fuel pump)
- 2. Float arm (full position)
- 3. Pickup tube
- 4. Float arm (empty position)

g028351

- 5. Fuel filter (short leg)
- 6. Fuel filter (long leg)
- 2. Align the pickup tube of the new fuel filter with the fitting of the fuel pump (Figure 120).
- 3. Align the long leg of the fuel filter with float when the float arm is in the empty position (Figure 120).
- 4. Insert the fuel-pump fitting into the pickup tube until the fitting is fully seated (Figure 120).

Installing the Fuel Pump and Sending Unit

1. Support the float arm and pickup tube together and slip the float and fuel filter into the opening in the fuel tank (Figure 119).

Important: Ensure that the float and the long leg of the filter are pointing forward in the tank and the fitting at the top of the fuel pump points 90° toward the centerline of the machine.

- 2. Seat the fuel pump/sending unit into the opening in the tank (Figure 119 and Figure 120).
- 3. Install the seal and nut over the fuel pump/sending and onto the neck of the fuel tank and tighten the nut hand tight (Figure 119).
- 4. Connect the coupling on the fuel hose to the fitting of the fuel pump (Figure 119).

Note: Ensure that the locking sleeve of the fuel-hose coupling secures the coupling to the pump fitting.

- Connect the 2-socket connector of the machine-wiring harness to the 2-pin connector of the fuel pump/sending unit; Connect the 2-pin connector of the machine-wiring harness to the 2-socket connector of the fuel pump/sending unit (Figure 119).
- 6. Rotate the starter switch to the ON position and check the fuel-hose coupling for leaks.

Note: If the coupling leaks, rotate the starter switch to the OFF position, remove the key, remove the coupling, check the coupling and fitting for dirt or damage, and install the hose and coupling onto the fitting.

Note: Repair any fuel leaks before proceeding to the next step.

Installing the Fuel Pump Cover

 Assemble the cover to the tank (Figure 121) with the 4 screws (#10 x 3/4 inch) that you removed in step 2 of Removing the Fuel Pump Cover (page 67).




Figure 121

- 1. Screws (#10 x 3/4 inch) 3. Fuel tank
- 2. Cover
- 2. Torque the screws to 113 N·cm (10 in-lb).

Installing the Carbon Canister

1. Align the fuel tank hoses through the grommets of the carbon-canister bracket (Figure 122).





Figure 122

g323414

a323402

- 2. Assemble the hose clamps over the hoses (Figure 122).
- 3. Assemble the hoses onto the fittings of the carbon canister (Figure 122).
- 4. Secure the hoses to the fittings with the clamps (Figure 123)



- Hose clamps
- 5. Align the holes in the carbon-canister bracket with the holes in the fuel tank (Figure 124).




Figure 124

- 1. Screw (#10 x 3/4 inch)
- 3. Fuel tank
- 2. Carbon-canister bracket
- 6. Assemble the bracket to the tank (Figure 124) with the 4 screws (#10 x 3/4 inch).
- 7. Torque the screws to 113 N·cm (10 in-lb).

Draining the Fuel Tank

Service Interval: Every 400 hours/Yearly (whichever comes first)

Drain and clean the fuel tank if the fuel system becomes contaminated or if you plan to store the machine for an extended period. When cleaning the fuel tank, use fresh, clean fuel to flush out the tank.

 Transfer the fuel from the tank into an approved fuel container using a siphon pump. Transfer the fuel from the machine before you pour any remaining fuel in the tank through the fill spout, and into a fuel container.

Note: If you decide to remove the fuel tank, you will need to disconnect the fuel hose and electrical connectors from the fuel pump and sending unit; refer to Removing the Fuel Pump and Sending Unit (page 68).

- 2. Flush the tank with fresh, clean fuel, if necessary.
- 3. Replace the fuel filters; refer to Replacing the Fuel Filter (page 69).
- 4. Install the tank if you removed it in step 1.

Note: If you removed the fuel tank, you will need to connect the fuel hose and electrical connectors to the fuel pump and sending unit; refer to Installing the Fuel Pump and Sending Unit (page 70).

5. Fill the tank with fresh, clean fuel.


Electrical System Maintenance

Electrical System Safety

- Disconnect the battery before repairing the machine. Disconnect the negative terminal first and the positive last. Connect the positive terminal first and the negative last.
- Charge the battery in an open, well-ventilated area, away from sparks and flames. Unplug the charger before connecting or disconnecting the battery.
- Wear protective clothing and use insulated tools.

Replacing the Fuses

The fuse block for the electrical system is located beneath the operator's seat.






Figure 125

g526068

- Tec Logic
- Tec power
- 3. AutoSteer
- Ignition
- 5. Tec power
- Boom control
- 7. GeoLink

- 8. Work light
- 9. Tec power
- 10. Cruise control
- 11. InfoCenter
- 12. Boom and headlight
- 13. USB power
- 14. Tank spray

Servicing the Battery

Always keep the battery clean and fully charged. Use a paper towel to clean the battery and battery box. If the battery terminals are corroded, clean them with a solution of 4 parts water and 1 part baking soda. Apply a light coating of grease to the battery terminals to prevent corrosion.

Voltage: 12 V with 690 cold cranking amps at 0°F (-18°C)

Removing the Battery

- Position the sprayer on a level surface, engage the parking brake, shut off the spray pump, shut off the engine, and remove the key.
- Remove the battery cover and disconnect the negative (black) ground cable from the battery post (Figure 126).




Figure 126

- Battery cover
 - Strap
- 3. Buckle

g014029

A WARNING

Incorrect battery cable routing could damage the sprayer and cables, causing sparks. Sparks can cause the battery gasses to explode, resulting in personal injury.

- Always disconnect the negative (black) battery cable before disconnecting the positive (red) cable.
- Always connect the positive (red) battery cable before connecting the negative (black) cable.

A WARNING

Battery terminals or metal tools could short against metal sprayer components causing sparks. Sparks can cause the battery gasses to explode, resulting in personal injury.

- When removing or installing the battery, do not allow the battery terminals to touch any metal parts of the sprayer.
- Do not allow metal tools to short between the battery terminals and metal parts of the sprayer.
- Always keep the battery strap in place to protect and secure the battery.
- Disconnect the positive (red) cable from the battery post.
- Remove the battery.

Installing the Battery

- 1. Set the battery on the battery box so that the battery posts are away from the sprayer.
- Connect the positive (red) cable to the positive (+) battery post and the negative (black) cable to the negative (-) battery post using the bolts and nuts.
- 3. Slide the insulator boot over the positive battery post.
- Install the battery cover and secure it with the strap that you removed previously (Figure 126).

Important: Always keep the battery retainer in place to protect and secure the battery.

Charging the Battery

Important: Always keep the battery fully charged. This is especially important to prevent battery damage when the temperature is below 32°F (0°C).

- 1. Remove the battery from the chassis; refer to Removing the Battery (page 72).
- Connect a 3 to 4 A battery charger to the battery posts and charge the battery at a rate of 3 to 4 A for 4 to 8 hours (12 V).

Important: Do not overcharge the battery.

3. Install the battery in the chassis; refer to Installing the Battery (page 73).

Storing the Battery

If you are storing the machine for more than 30 days, remove the battery and charge it fully. Either store it on a shelf or on the machine. Disconnect the battery cables if the battery is stored on the machine. Store the battery in a cool atmosphere to avoid quick deterioration of the charge in the battery. To prevent the battery from freezing, ensure that it is fully charged.

Drive System Maintenance

Inspecting the Wheels/Tires

Service Interval: After the first 8 hours—Torque the wheel-lug nuts.

Every 100 hours—Torque the wheel-lug nuts.

Every 100 hours—Inspect the condition and wear of the tires.

Torque the lug nuts at the front wheels to 75 to 102 N·m (55 to 75 ft-lb) and the lug nuts at the rear wheels to 95 to 122 N·m (75 to 90 ft-lb).

Operating accidents such as hitting curbs can damage a tire or rim and disrupt wheel alignment, so inspect tire condition after an accident.


Gearbox Specification

SAE 85W-140

0.62 L (21 fl oz)

Checking the Gearbox Oil

Service Interval: Every 400 hours



With the machine on a level surface, position a wheel so that the fill plug is at the highest (12 o'clock) position and the drain plug is at the lowest (6 o'clock) position.




Figure 128

- 1. Fill plug (12 o'clock position)
- 2. Check plug
- Drain plug (6 o'clock position)

Remove the check plug.

You should see the lubricant level at the bottom of the threads in the check-plug hole.




Figure 129

Check plug

2. Check-plug hole

Check the O-rings of the check plug for the damage.

If the O-ring is damaged, replace it.

If the lubricant level is low, remove the fill plug and add the specified lubricant until it begins to flow out of the check-plug hole.




Figure 130

Fill plug

- 3. Check plug
- 2. Fill-plug hole
- Check the O-rings of the fill plug for the damage. If the O-ring is damaged, replace it.
- Install the fill plug and the check plug. 6.
- 7. Repeat the above steps on the other side of the machine.


Changing the Gearbox Oil

Service Interval: After the first 50 hours

Every 800 hours or yearly, whichever comes first.

Draining the Gearbox Oil


- With the machine on a level surface, position a wheel so that the fill plug is at the highest (12 o'clock) position and the drain plug is at the lowest (6 o'clock) position.
- Place a drain pan under the hub of the planetary-gear drive, remove the drain plug, fill plug, and the check plug, and allow the lubricant to drain completely.



- Figure 131
- Fill plug

g238948

- Fill-plug hole
- Check-plug hole
- 4. Drain-plug hole
- Drain plug
- Check plug
- 3. Examine the drain and fill plugs for metal shavings.
 - If fill drain and fill plugs are covered with metal shavings, repair the planetary-gear drive.
- Check the O-rings of the drain plug, fill plug, and the check plug for the damage.
 - If the O-ring(s) is damaged, replace it.
- Install the drain plug.
- 6. Place a drain pan under the brake housing, remove the drain plug, and allow the lubricant to drain completely.



- Drain hole (brake housing) 2. Drain plug
- 7. Install the drain plug in the brake housing.

Filling the Gearbox

Through the fill-plug hole, slowly add the specified gear oil.

You should see the lubricant level at the bottom of the threads in the check-plug hole.

Important: If the planetary-gear drive fills before the specified lubricant quantity is added, wait 1 hour or install the plugs, and move the machine approximately 3 m (10 feet) to distribute the lubricant through the brake system. Then, remove the plugs and add the remaining lubricant.

- Allow the lubricant level to settle for 10 minutes, check the lubricant level, and add lubricant as needed to raise the level to the bottom of the threads in the check-plug hole.
- Install the fill plug and check plug. 3.
- Repeat the steps on the other side of the machine.

Adjusting the Front Wheel Toe-In

Service Interval: Every 200 hours/Yearly (whichever comes first)

You should measure 0 to 3 mm (0 to 1/8 inch) between the front centerline of the tires and the back centerline of the tires.

- Check and fill all tires; refer to Checking the Tire Air Pressure (page 33).
- Measure the distance between of the front tires at the axle height at the front and rear of the front tires (Figure 133).

Note: The distance between the front of the tires should be 0 to 3 mm (0 to 1/8 inch) less than the distance between the back side of the front tires.




Figure 133

- 1. Tire center line—back
- 3. Axle center line
- 2. Tire center line-front

If the measurement does not fall within the specified range, loosen the jam nuts at both ends of the tie rod (Figure 134).




Figure 134

1. Jam nut

2. Tie rod

- Rotate the tie rod to move the front of the tire inward or outward.
- 5. Tighten the tie rod jam nuts when the adjustment is correct.
- Ensure that the steering wheel rotates an equal amount in both directions.

g002247

Cooling System Maintenance

Cooling System Safety

- Swallowing engine coolant can cause poisoning; keep out of reach from children and pets.
- Discharge of hot, pressurized coolant or touching a hot radiator and surrounding parts can cause severe burns.
 - Always allow the engine to cool at least 15 minutes before removing the radiator cap.
 - Use a rag when opening the radiator cap, and open the cap slowly to allow steam to escape.
- Do not operate the machine without the covers in place.
- Keep your fingers, hands, and clothing clear of the rotating fan and drive belt.

Coolant Specifications

5.5 L (5.8 US qt)

The coolant reservoir is filled at the factory with a 50/50 solution of water and ethylene glycol base extended-life coolant. Check the coolant level before you first start the engine and daily thereafter.

The following commercially available coolants or a manufacturer-specified equivalent meeting the long-life coolant specification:

Extended-Life Coolant Products

Coolants meeting technical standards ASTM D3306 or D4985, or SAE J1034, J814, or 1941.

Important: Do not rely on the color of the coolant to identify the difference between conventional (IAT) and extended-life (OAT) coolant types.

Coolant manufacturers may dye extended-life coolant (OAT) in one of the following colors: red, pink, orange, yellow, blue, teal, violet, and green.

Coolant Types

Coolant Types (cont'd.)

Ethylene-Glycol Coolant Type	Corrosion Inhibitor Type	Service Interval
Extended-life antifreeze	Organic-acid technology (OAT)	5-years
Conventional antifreeze (green)	Inorganic-acid technology (IAT)	2-years

Note: When adding coolant to the machine, you will not damage the cooling system by mixing conventional (IAT) antifreeze with extended-life (OAT) antifreeze. However, mixing antifreeze types degrades the long life/extended life attribute of the OAT formulation.

Important: The service interval of conventional (IAT) and extended-life (OAT) blended-coolant mixture—at any ratio—lasts as long as the coolant with the shortest service interval: 2 years.

Checking the Coolant Level

Service Interval: Before each use or daily Check the level of coolant in the radiator and the expansion tank at the beginning of each day before starting the engine.

A CAUTION

If the engine has been running, the coolant may be hot and pressurized. If you open the radiator cap when the coolant is hot, it could spray out and severely burn you or bystanders.

Allow the engine to cool for at least 15 minutes before opening the radiator cap.

Important: Do not add coolant to an overheated engine until the engine has fully cooled. Adding coolant to an overheated engine may crack the engine block.

- 1. Position the sprayer on a level surface.
- 2. Engage the parking brake, shut off the spray pump, shut off the engine, and remove the key.
- Carefully remove the radiator cap and the expansion-tank cap.




Figure 135

- 1. Radiator cap
- 2. Expansion tank
- 3. Expansion-tank cap
- 4. Full-line mark
- 4. Check the coolant level in the radiator and in the expansion tank.

Note: The radiator should be filled to the top of the filler neck and the expansion tank filled to the Full mark on the tank.

5. If the coolant level is low, remove the expansion-tank cap and the radiator cap, and fill the expansion tank to the Full mark and the radiator to the top of the filler neck.

Important: Do not overfill the expansion tank.

Important: Do not use water only or an alcohol/methanol-based coolant.


6. Install the radiator cap and the expansion-tank cap.

Changing the Coolant

Service Interval: Every 400 hours/Yearly (whichever comes first)—Check the coolant (as directed by the manufacturer) and change if necessary.

Owner provided equipment: a handheld coolant thermometer

- 1. Position the sprayer on a level surface, engage the parking brake, shut off the spray pump, shut off the engine, and remove the key.
- 2. Wait until the engine is cool, then remove the radiator cap.
- 3. Place a large drain pan under the radiator.
- 4. Open the drain valve and drain the coolant into the pan.



- 1. Drain valve
- 5. Close the drain valve.
- 6. Remove the radiator cap.
- 7. Slowly fill the radiator with coolant to approximately 2.5 cm (1 inch) below the sealing surface of the cap.

Note: Use enough coolant to fill the engine and the system lines. This allows the coolant to expand without it overflowing while the engine is warming up.

- 8. Start the engine with the cap loose on the radiator.
- 9. Allow the engine to warm up until the thermostat opens.

Note: The engine thermostat should open when the hand-held thermometer indicates the

- coolant temperature is between 79° to 88°C (175° to 190°F).
- Once the coolant has warmed up, top off the coolant level to the sealing surface of the cap and tighten the cap.
- Open the expansion-tank cap and fill the tank with coolant to the Cold level.
- Check the coolant levels after several engine 12. startup and shut-down cycles.


Note: Add coolant to the radiator and expansion tank as needed.

Brake Maintenance

Adjusting the Brakes

If the brake pedal travels more than 2.5 cm (1 inch) before you feel resistance, adjust the brakes as follows:

- 1. Position the sprayer on a level surface, shut off the spray pump, shut off the engine, and remove
- 2. Engage the parking brake.
- Put blocks under the wheels to prevent the machine from rolling.
- Release the parking brake.
- Loosen the front jam nuts on the brake cables under the front end of the sprayer (Figure 137).



- 1. Front jam nuts
- 2. Rear jam nuts
- Tighten the rear jam nuts equally until the brake pedal moves between 1 to 2 cm (1/2 to 1 inch) before you feel resistance (Figure 137).

Important: Ensure that you tighten both rear nuts equally so that the threaded ends of the brake cables in front of the front nuts are the same length.

Tighten the front jam nuts.

Belt Maintenance

Servicing the Alternator Belt

Service Interval: After the first 8 hours


Every 100 hours

Check the condition and tension of the alternator/cooling fan belt. Replace the belt as necessary.

- Position the sprayer on a level surface, engage the parking brake, shut off the spray pump, shut off the engine, and remove the key.
- 2. Check the alternator-belt tension by depressing the belt midway between the alternator and the crankshaft pulleys with 10 kg (22 lb) of force.

Note: The belt should deflect 10 to 12 mm (0.39 to 0.47 inches). If the belt deflection is too much, go to step 3. If the belt tension is correct, you may skip the remainder of this procedure and resume operating the sprayer.

3. Loosen the bolt at the pivot point of the alternator; loosen the bolt that secures the alternator to the slotted brace (Figure 138).



- Figure 138
- 1. Alternator belt
- 3. Alternator

2. Brace

- 4. Bolts
- Insert a pry bar between the alternator and the engine and carefully pry on the alternator outward.

- 5. When you achieve the proper tension, tighten the alternator and the bolts to secure the adjustment.
- 6. Tighten the locknut to secure the adjustment.

Hydraulic System Maintenance

Hydraulic System Safety

- Seek immediate medical attention if fluid is injected into skin. Injected fluid must be surgically removed within a few hours by a doctor.
- Safely relieve all pressure in the hydraulic system before performing any work on it.
- Ensure that all hydraulic-fluid hoses and lines are in good condition and all hydraulic connections and fittings are tight before applying pressure to the hydraulic system.
- Keep your body and hands away from pinhole leaks or nozzles that eject high-pressure hydraulic
- Use cardboard or paper to find hydraulic leaks.

Hydraulic Fluid **Specifications**

The reservoir is filled at the factory with high-quality hydraulic fluid. Check the level of the hydraulic fluid before you first start the engine and daily thereafter; refer to Checking the Hydraulic Fluid (page 81).

Recommended hydraulic fluid: Toro PX Extended Life Hydraulic Fluid; available in 19 L (5 US gallon) pails or 208 L (55 US gallon) drums.

Note: A machine using the recommended replacement fluid requires less frequent fluid and filter changes.

Alternative hydraulic fluids: If Toro PX Extended Life Hydraulic Fluid is not available, you may use another conventional, petroleum-based hydraulic fluid having specifications that fall within the listed range for all the following material properties and that it meets industry standards. Do not use synthetic fluid. Consult with your lubricant distributor to identify a satisfactory product.

Note: Toro does not assume responsibility for damage caused by improper substitutions, so use products only from reputable manufacturers who will stand behind their recommendation.

High Viscosity Index/Low Pour Point Anti-wear Hydraulic Fluid, ISO VG 46

Material Properties:

Viscosity, ASTM D445

cSt @ 40°C (104°F) 44 to 48

High Viscosity Index/Low Pour Point Anti-wear Hydraulic Fluid, ISO VG 46 (cont'd.)

Viscosity Index ASTM D2270 140 or higher

Pour Point, ASTM D97 -37°C to -45°C (-34°F

to -49°F)

Industry Specifications: Eaton Vickers 694 (I-286-S,

M-2950-S/35VQ25 or

M-2952-S)

Note: Many hydraulic fluids are almost colorless, making it difficult to spot leaks. A red dye additive for the hydraulic fluid is available in 20 ml (0.67 fl oz) bottles. A bottle is sufficient for 15 to 22 L (4 to 6 US gallons) of hydraulic fluid. Order Part No. 44-2500 from your authorized Toro distributor.

Important: Toro Premium Synthetic Biodegradable Hydraulic Fluid is the only synthetic biodegradable fluid approved by Toro. This fluid is compatible with the elastomers used in Toro hydraulic systems and is suitable for a wide-range of temperature conditions. This fluid is compatible with conventional mineral oils, but for maximum biodegradability and performance, the hydraulic system should be thoroughly flushed of conventional fluid. The oil is available in 19 L (5 US gallon) pails or 208 L (55 US gallon) drums from your authorized Toro distributor.

Checking the Hydraulic **Fluid**

Service Interval: Before each use or daily Check the level of the hydraulic fluid before the engine is first started and daily thereafter.

Important: If the fluid becomes contaminated, contact an authorized Toro distributor to have the system flushed.

Contaminated fluid looks milky or black when compared to clean fluid.

- Position the sprayer on a level surface, engage the parking brake, shut off the spray pump, shut off the engine, and remove the key.
- Clean the area around the hydraulic-fluid-tank dipstick cap and remove it (Figure 139).




Figure 139

- 1. Hydraulic-fluid tank
- 3. Dipstick cap

a014217

2. Vent

Important: Be very careful not to get dirt or other contaminants into the opening when checking the fluid.

- 3. Wipe the dipstick clean with a cloth and replace it completely in the tank.
- 4. Remove the dipstick from the filler neck and check the fluid level (Figure 140).

Note: The fluid level should be at the lower mark on the dipstick when the fluid is cold.




Figure 140

1. Dipstick

2. Safe-operating range

G014218

g014218

- If the fluid is low, fill the tank with the specified hydraulic fluid to raise the level to the lower mark; refer to Hydraulic Fluid Specifications (page 81).
- 6. Install the dipstick cap into the tank and secure.

Replacing the Hydraulic Filters

Service Interval: Every 1,000 hours—If you are using the recommended hydraulic fluid, replace the hydraulic filter.

Every 800 hours—If you are not using the recommended hydraulic fluid or have ever

filled the reservoir with an alternative fluid, replace the hydraulic filter.

A WARNING

Hot hydraulic fluid can cause severe burns.

Allow the hydraulic fluid to cool before performing any maintenance to the hydraulic system.

Important: You may void the warranty on some components if you use any other filter.

Use the Toro replacement filter (See your *Parts Manual* for the correct part number.)

- 1. Position the sprayer on a level surface, engage the parking brake, shut off the spray pump, shut off the engine, and remove the key.
- 2. Locate the 2 hydraulic filters on the machine (Figure 141 and Figure 142).

Note: 1 filter is below the hydraulic-fluid tank and the other filter is located at the rear of the machine on the frame.

• Forward filter—below the hydraulic tank.




Figure 141

- 1. Hydraulic tank
- Forward filter
- Rear filter—located on the machine frame.




Figure 142

g01379

- 1. Rear filter
- 2. Rear wheels
- 3. Clean the area around the filter-mounting area.
- 4. Place a drain pan under the filter.
- 5. Remove the filter.

Dispose of the used filter at a certified recycling center.

- 6. Lubricate the new filter gasket with clean hydraulic fluid; refer to Hydraulic Fluid Specifications (page 81).
- 7. Wipe clean the filter-mounting area with a rag.
- 8. Thread the filter on until the gasket contacts the mounting plate, then tighten the filter an additional 1/2 turn.
- 9. Start the engine, set the throttle at fast idle, and let the engine run 3 to 5 minutes to purge air from the hydraulic system.
- 10. Shut off the engine, check the hydraulic-fluid level, and check for leaks; refer to Checking the Hydraulic Fluid (page 81).

Hydraulic-Fluid Quantity

54 L (14.3 US gallons); refer to Hydraulic Fluid Specifications (page 81)

Changing the Hydraulic Fluid

Service Interval: Every 2,000 hours—If you are using the recommended hydraulic fluid, change the hydraulic fluid.

Every 800 hours—If you are not using the recommended hydraulic fluid or have ever filled the reservoir with an alternative fluid, change the hydraulic fluid.

A WARNING

Hot hydraulic fluid can cause severe burns.

Allow the hydraulic fluid to cool before performing any maintenance to the hydraulic system.

Important: You may void the warranty on some components if you use any other fluid.

- 1. Replace the hydraulic-fluid filters; refer to Replacing the Hydraulic Filters (page 82).
- Clean the area around a hydraulic-hose fitting on the bottom of the hydraulic-fluid tank (Figure 143).




Figure 143

1. Hydraulic tank

2. Hydraulic hose and fitting

- 3. Place a large drain pan under the hydraulic tank fittings.
- 4. Remove the hose fitting from the tank, allowing the fluid to drain into the pan (Figure 143).

Dispose of the used fluid at a certified recycling center.

- 5. Install the hose and fitting to the tank and tighten it securely.
- 6. Fill the hydraulic reservoir with approximately 53 L (14 US gallons) of specified hydraulic fluid or equivalent; refer to Hydraulic Fluid Specifications (page 81).
- 7. Start the engine, set the throttle at fast idle, and let the engine run 3 to 5 minutes to purge air from the hydraulic system.
- 8. Shut off the engine, check the hydraulic-fluid level, and check for leaks; refer to Checking the Hydraulic Fluid (page 81).

Sprayer System Maintenance

Inspecting the Hoses

Service Interval: Every 200 hours—Inspect all hoses and connections for damage and proper attachment.

Every 400 hours/Yearly (whichever comes first)—Inspect the O-rings in the valve assemblies and replace them if necessary.


Examine each hose in the spray system for cracks, leaks, or other damage. At the same time, inspect the connections and fittings for similar damage. Replace any hoses and fittings if damaged.



Service Interval: Every 400 hours


Note: Determine the appropriate suction filter mesh size that you need for your job; refer to Selecting a Suction Filter (page 35).

- 1. Park the machine on a level surface, engage the parking brake, shut off the pump, shut off the engine, and remove the key.
- 2. At the top of the sprayer tank, remove the retainer that secures the hose fitting attached to the large hose from the filter housing (Figure 144).



- 1. Suction hose
- 2. Retainer
- 3. Remove the hose and hose fitting from the filter housing (Figure 144).
- 4. Remove the old suction filter from the filter housing in the tank (Figure 145).

Note: Discard the old filter.



- 1. Screen vane
- 2. Suction filter
- 5. Install the new suction filter into the filter housing.


Note: Ensure that the filter is fully seated.

6. Align the hose and hose fitting to the filter housing at the top of the tank, and secure the fitting and housing with the retainer that you removed in step 2.

Changing the Pressure Filter

Service Interval: Every 400 hours

- 1. Move the machine to a level surface, shut off the spray pump, shut off the engine, and remove the key.
- 2. Align a drain pan under the pressure filter (Figure 146).



- 1. Filter head
- 2. O-ring (bowl)
- 3. Filter element
- 4. Bowl
- 5. O-ring (drain plug)
- 6. Drain plug
- 3. Rotate the drain plug counterclockwise and remove it from the bowl of the pressure filter (Figure 146).

Note: Allow the bowl to drain completely.

- 4. Rotate the bowl counterclockwise and remove it from its filter head (Figure 146).
- Remove the old pressure-filter element (Figure 146).

Note: Discard the old filter.

 Check the O-ring for the drain plug (located inside the bowl) and the O-ring for the bowl (located inside the filter head) for damage and wear (Figure 146).

Note: Replace any damaged or worn O-rings for the plug, bowl, or both.

7. Install the new pressure-filter element into the filter head (Figure 146).

Note: Ensure that the filter element is firmly seated into the filter head.

- 8. Install the bowl onto the filter head and tighten by hand (Figure 146).
- Install the plug into the bowl and tighten by hand (Figure 146).

Changing the Nozzle Filter

Note: Determine the appropriate nozzle filter mesh size that you need for your job; refer to Selecting a Nozzle-Tip Filter (Optional) (page 37).

- Park the machine on a level surface, engage the parking brake, shut off the sprayer pump, shut off the engine, and remove the key.
- 2. Remove the nozzle from the spray turret (Figure 147).




Figure 147

1. Spray turret

3. Nozzle

a209504

2. Nozzle filter

3. Remove the old nozzle filter (Figure 147).

Note: Discard the old filter.

4. Install the new nozzle filter (Figure 147).

Note: Ensure that the filter is fully seated.

5. Install the nozzle onto the spray turret (Figure 147).

Adjusting the Booms to Level

The following procedure can be used to adjust the actuators on the center boom to keep the left and right booms at level.

- Extend the booms to the spray position.
- 2. Remove the cotter pin from the pivot pin (Figure 148).




Figure 148

1. Actuator

- Cotter
 Pin
- 2. Actuator rod
- 3. Boom-pivot pin housing
- 3. Lift up on the boom and remove the pin (Figure 148), and slowly lower the boom to the ground.
- 4. Inspect the pin for any damage, and replace it if necessary.
- 5. Hold the actuator rod at the flats of the rod using a wrench, then loosen the jam nut (Figure 149).




Figure 149

- Flat on the actuator rod
- 2. Jam nut
- 3. Rod end
- 4. Jam nut loosened
- 5. Rod end adjusted
- 6. Rod end position for assembly
- 7. Jam nut tightened to lock new position

g014220

6. Turn the rod end in the actuator rod to shorten or lengthen the extended actuator to the desired position (Figure 149).

Note: You must turn the rod end in half or complete revolutions so that you can assemble the rod to the boom.


- 7. Tighten the jam nut to secure the actuator and rod end.
- Raise the boom to align the pivot with the actuator rod.
- 9. While holding the boom, insert the pin through both boom pivot and rod end (Figure 148).
- 10. With the pin in place, release the boom and secure the pin with the cotter previously removed.
- 11. Repeat the procedure for the other actuator rod if necessary.

Inspecting the Nylon Pivot Bushings

Service Interval: Every 400 hours/Yearly (whichever comes first)

1. Park the machine on a level surface, engage the parking brake, shut off the pump, shut off the engine, and remove the key.

- 2. Extend the outer-boom sections to the spray position and support the boom sections using stands or straps and lifting equipment.
- 3. Remove the bolt and nut that secure the pivot pin, and remove the pin (Figure 150).



- 1. Nylon bushings
- 2. Pivot bracket
- 3. Flange locknut
- 4. End channel (center frame)
- 5. Flange bolt
- 6. Pivot pin
- 4. Remove the boom and pivot bracket assembly from the end channel of the center frame to access the nylon bushings.
- Remove and inspect the nylon bushings from the front and back sides of the pivot bracket (Figure 150).

Note: Replace any worn or damaged bushings.

- 6. Lubricate the nylon bushings with a small amount of oil, and install the bushings into the pivot bracket (Figure 150).
- 7. Align the holes in the pivot bracket with the holes in the end channel (Figure 150).
- 8. Install the pivot pin and secure it with the flange bolt and flange locknut removed in step 3.
- Repeat steps 2 through 8 for the other outer-boom section.

Pump Maintenance

Inspecting the Pump

Service Interval: Every 400 hours/Yearly (whichever comes first)—Inspect the pump diaphragms and replace if necessary (see an authorized

Toro distributor).

Every 400 hours/Yearly (whichever comes first)—Inspect the pump check valves and replace if necessary (see an authorized Toro distributor).

Note: The following machine components are considered parts subject to consumption through use unless found defective and are not covered by the warranty associated with this machine.

Have an authorized Toro distributor check the following internal pump components for damage:

- Pump diaphragms
- Pump check valves assemblies

Replace any components, if necessary.

Cleaning

Wash the machine as needed using water alone or with a mild detergent. You may use a rag when washing the machine.

Important: Do not use brackish or reclaimed water to clean the machine.

Note: Do not use power-washing equipment to wash the machine. Power-washing equipment may damage the electrical system, loosen important decals, or wash away necessary grease at friction points. Avoid excessive use of water near the control panel, engine, and battery.

Important: Do not wash the machine with the engine running. Washing the machine with the engine running may result in internal engine damage.

Cleaning the **Radiator-Cooling Fins**

Service Interval: Every 200 hours—Clean the radiator fins.

Important: Do not spray water into a hot engine compartment, as it may damage the engine.

- Position the sprayer on a level surface, engage the parking brake, shut off the spray pump, shut off the engine, and remove the key.
- Tilt the driver and passenger seats forward and align the prop rod into the detent in the prop-rod-guide slot.
- Allow the cooling system to cool. 3.
- Remove the seat-base-access cover; refer to Removing the Seat-Base-Access Panel (page
- Using a soft brush and low-pressure compressed air, clean the fins of the radiator.

Note: Clean the radiator fins more often if needed. Check all coolant hoses and replace any that are worn, leaking, or damaged.

- 6. Lower the driver and passenger seats.
- Install the seat-base-access cover; refer to Installing the Seat-Base-Access Panel (page 59).

Cleaning the Flow Meter

Service Interval: Every 200 hours/Yearly (whichever comes first) (more often when using wettable powders).

- Thoroughly rinse and drain the entire spraying system.
- Remove the flow meter from the sprayer and flush it with clean water.
- Remove the retainer ring on the upstream side (Figure 151).




Figure 151

- Downstream hub (with keyway up)

Flange (flow-meter body)

- Retaining ring
- Downstream arrow (flow-meter body)
- 5. Upstream
- Rotor/magnet

- 7. Upstream hub and bearing (with keyway up)
- 8. Turbine stud
- Wire-harness clamp
- Flange-head screw
- 11. Sensor assembly
- Clean the turbine and the turbine hub to remove metal filings and any wettable powders.
- Inspect the turbine blades for wear.

Note: Hold the turbine in your hand and spin it. It should spin freely with little drag. If it does not, replace it.

- 6. Assemble the flow meter.
- Use a low pressure (50 kPa or 5 psi) air jet to ensure that the turbine spins freely.

Note: If the turbine does not spin freely, loosen the hex stud on the bottom of the turbine hub by 1/16 of a turn until it does spins freely.

Storage

Storage Safety

- Before you leave the operator's position, do the following:
 - Park the machine on a level surface.
 - Shut off the spray pump.
 - Engage the parking brake.
 - Shut off the engine and remove the key (if equipped).
 - Wait for all movement to stop.
 - Allow the machine to cool before adjusting, servicing, cleaning, or storing it.
- Do not store the machine or fuel container where there is an open flame, spark, or pilot light, such as on a water heater or other appliance.

Preparing the Machine for Storage

Short-Term Storage

(Less than 30 days)

Cleaning the Exterior of the Machine

Important: Do not use brackish or reclaimed water to clean the machine.

- 1. Park the machine on a level surface; engage the parking brake; shut off the spray pump and the engine; remove the key; and wait for all movement to stop before leaving the machine.
- 2. Clean the dirt and grime from the entire machine, including the outside of the cylinder-head fins and blower housing of the engine.

Important: You can wash the machine with mild detergent and water. Do not use high-pressure water to wash the machine. Pressure washing may damage the electrical system or wash away necessary grease at friction points. Avoid excessive use of water, especially near the control panel, lights, engine, and the battery.

Preparing to Condition the Sprayer

- Move the machine to the drain pad area, engage the parking brake, shut off the spray pump, shut off the engine, remove the key, and wait for all movement to stop before leaving the operator's position.
- 2. Drain the fresh-water tank and leave the tank spigot open.
- 3. Drain the sprayer tank as completely as possible.
- 4. Prepare rust inhibiting, non-alcohol based, RV antifreeze solution; refer to Preparing the Conditioner (page 51).
- 5. Start the engine and lower the outer booms sections.

Conditioning the Sprayer

- 1. Run the spray pump for a few minutes to circulate the RV antifreeze throughout the spray system and any installed spray accessories.
- 2. Turn the left, center, and right section switches to the ON position.
- 3. Turn the master section switch to the On position and spray out the nozzle until the RV anti-freeze is visible.
- 4. Turn the master section switch to the OFF position.
- 5. Turn the pump switch to the OFF position.
- Use the boom-section lift switches to raise the outer boom sections.

Raise the boom sections until they have moved completely into boom-transport cradle forming the "X" transport position and the lift cylinders are fully retracted.

Note: Make sure that the lift cylinders are fully retracted to prevent actuator rod damage.

- 7. Shut off the engine.
- 8. Drain the sprayer tank as completely as possible.

Long-Term Storage

(Longer than 30 days)

Move the machine in a clean, dry storage area.

Perform the following procedures found in Short-Term Storage:

- Cleaning the exterior of the machine.
- Preparing to condition the sprayer.
- · Conditioning the sprayer.

In addition, perform the procedures that follow:

Check the air pressure in the tires.

- Check the brakes.
- Check and tighten all bolts, nuts, and screws.

Note: Repair or replace any parts that are worn or damaged.

- Paint all scratched or bare metal surfaces (paint is available from your authorized Toro distributor).
- Clean the agitation valve and the 10 section valves.
- Grease the sprayer.
- Check the condition of all spray hoses.

Note: Replace any hoses that are worn or damaged.

- Tighten all hose clamps and fittings.
- Check the air cleaner.
- Change the engine-oil filter and oil.
- Drain the fuel tank.
- Prepare fuel with fuel stabilizer according to the manufacturer's instructions, and add it to the fuel tank.

Start the engine and run it at idle speed for 5 minutes.

- Secure all the fuel-system fittings.
- Remove the battery.

Note: Do not connect the battery cables to the battery posts during storage.

- · Check the electrolyte level.
- Fully charge the battery.

Important: The battery must be fully charged to prevent it from freezing and being damaged at temperatures below 32°F (0°C). A fully charged battery maintains its charge for about 50 days at temperatures lower than 4°C (40°F). If the temperatures will be above 4°C (40°F), check the water level in the battery and charge it every 30 days.

Troubleshooting

Troubleshooting the Engine and Vehicle

Problem	Possible Cause	Corrective Action
The starter does not rotate the engine.	The electrical connections are corroded or loose.	Check the electrical connections for good contact.
	 A fuse is blown or loose. The battery is discharged. A broken starter or starter solenoid. 	 Correct or replace fuse. Charge or replace the battery. Contact your authorized Toro distributor.
	There are seized internal engine components.	Contact your authorized Toro distributor.
The engine cranks but does not start.	1. The fuel tank is empty.	1. Fill the tank with fresh fuel.
	Dirt, water, or stale fuel is in the fuel system.	Drain and flush the fuel system; add fresh fuel.
	Clogged fuel line.	Clean or replace.
	4. The run relay is not energized.	Contact your authorized Toro distributor.
	5. The starter switch is broken.	Contact your authorized Toro distributor.
The engine starts but does not keep	The fuel-tank vent is restricted.	Replace the fuel cap.
running.	Dirt or water is in the fuel system.	Drain and flush the fuel system; add fresh fuel.
	3. The fuel filter is clogged.	Replace the fuel filter.
	4. A fuse is blown or loose.	Correct or replace the fuse.
	5. The fuel pump is broken.	Contact your authorized Toro distributor.
	There are loose wires or poor connections.	Check and tighten wire connections.
	7. The cylinder-head gasket is broken.	Contact your authorized Toro distributor.
The engine runs but knocks or misses.	Dirt, water, or stale fuel in the fuel system.	Drain and flush the fuel system; add fresh fuel.
	There are loose wires or poor connections.	Check and tighten wire connections.
	3. The engine is overheating.	3. See "The engine overheats" below.
The engine does not idle.	The fuel-tank vent is restricted.	Replace the fuel cap.
	Dirt, water, or stale fuel is in the fuel system.	Drain and flush the fuel system; add fresh fuel.
	3. The fuel pump is broken.	Contact your authorized Toro distributor.
	4. The engine has low compression.	Contact your authorized Toro distributor.
	5. The air-filter element is dirty.	Replace the air-filter element.

Problem	Possible Cause	Corrective Action
The engine overheats.	The crankcase-oil level is incorrect.	1. Fill or drain to the Full mark.
	2. The coolant level is low.	Check the coolant level and replenish it as needed.
	The engine is operated under excessive load.	3. Reduce load; use lower ground speed.
	The air-intake screens are dirty.	Clean with the air-intake screens with every use.
	 The cooling fins and air passages under the engine-blower housing and/or the rotating-air-intake screen are plugged. 	Clean the cooling fins and air passages with every use.
The engine loses power.	The crankcase-oil level is incorrect.	1. Fill or drain to the Full mark.
	2. The air-cleaner element is dirty.	Replace the air-cleaner element.
	Dirt, water, or stale fuel is in the fuel system.	Drain and flush the fuel system; add fresh fuel.
	4. The engine is overheated.	4. See "The engine overheats" above.
	The vent hole in the fuel-tank-vent fitting is plugged.	5. Replace the fuel cap.
	6. The engine has low compression.	Contact your authorized Toro distributor.
There is abnormal vibration or noise.	The engine mounting bolts are loose.	Tighten the engine mounting bolts.
	2. There is a problem with the engine.	Contact your authorized Toro distributor.
The machine does not operate or is sluggish in either direction because the engine bogs down or stalls.	1. The parking brake is set.	Release the parking brake.
The machine does not operate in either direction.	The parking brake was not released or the parking brake is not releasing.	Release the parking brake or check the linkage.
	2. The transmission is broken.	Contact your authorized Toro distributor.
	The control linkage needs adjustment or replacement.	Contact your authorized Toro distributor.
	The drive shaft or wheel hub key has been damaged.	Contact your authorized Toro distributor.

Troubleshooting the Spray System

Problem	Possible Cause	Corrective Action
A spray section does not spray.	The electrical connection on the section valve is dirty or disconnected.	Turn the valve off manually. Disconnect the electrical connector on the valve and clean all leads, then connect it.
	2. There is a blown (open) fuse.	Check the fuses and replace them as necessary.
	3. There is a pinched hose.	3. Repair or replace the hose.
	 A section bypass is improperly adjusted. 	Adjust the section bypass.
	5. There section valve is damaged.	Contact your authorized Toro distributor.
	6. The electrical system is damaged.	Contact your authorized Toro distributor.
A spray section does not turn off.	1. The valve is damaged.	Disassemble the spray section valve; refer to the section Cleaning the Section Valves. Inspect all parts and replace any that are damaged.
A spray section valve is leaking.	An O-ring is deteriorated.	Disassemble the valve and replace the seals using the Valve Repair Kit; contact your authorized Toro distributor.
	2. A valve seat is worn or damaged.	Remove the valve actuator and replace the valve seals and seat using the Valve Repair Kit; contact your authorized Toro distributor.
The pressure drops when you turn on a spray section.	The section-bypass valve is improperly adjusted.	Adjust the section-bypass valve.
	There is an obstruction in the section-valve body.	Remove the inlet and outlet connections to the section valve and remove any obstructions.
	3. A nozzle filter is damaged or clogged.	Remove and inspect all nozzles.
The spray nozzle(s) drip when the section switch(es) is shut off	Debris has accumulated between the nozzle body and the check-valve diaphragm.	Clean the nozzle body and diaphragm; refer to Cleaning the Nozzle Body and Check-Valve Diaphragm.
The sprayer pressure drops while spraying.	The suction filter screen is clogging or clogged.	Remove and clean or replace the suction filter.

Notes:

California Proposition 65 Warning Information

What is this warning?

You may see a product for sale that has a warning label like the following:



WARNING: Cancer and Reproductive Harm—www.p65Warnings.ca.gov.

What is Prop 65?

Prop 65 applies to any company operating in California, selling products in California, or manufacturing products that may be sold in or brought into California. It mandates that the Governor of California maintain and publish a list of chemicals known to cause cancer, birth defects, and/or other reproductive harm. The list, which is updated annually, includes hundreds of chemicals found in many everyday items. The purpose of Prop 65 is to inform the public about exposure to these chemicals.

Prop 65 does not ban the sale of products containing these chemicals but instead requires warnings on any product, product packaging, or literature with the product. Moreover, a Prop 65 warning does not mean that a product is in violation of any product safety standards or requirements. In fact, the California government has clarified that a Prop 65 warning "is not the same as a regulatory decision that a product is 'safe' or 'unsafe.'" Many of these chemicals have been used in everyday products for years without documented harm. For more information, go to https://oag.ca.gov/prop65/faqs-view-all.

A Prop 65 warning means that a company has either (1) evaluated the exposure and has concluded that it exceeds the "no significant risk level"; or (2) has chosen to provide a warning based on its understanding about the presence of a listed chemical without attempting to evaluate the exposure.

Does this law apply everywhere?

Prop 65 warnings are required under California law only. These warnings are seen throughout California in a wide range of settings, including but not limited to restaurants, grocery stores, hotels, schools, and hospitals, and on a wide variety of products. Additionally, some online and mail order retailers provide Prop 65 warnings on their websites or in catalogs.

How do the California warnings compare to federal limits?

Prop 65 standards are often more stringent than federal and international standards. There are various substances that require a Prop 65 warning at levels that are far lower than federal action limits. For example, the Prop 65 standard for warnings for lead is 0.5 μg/day, which is well below the federal and international standards.

Why don't all similar products carry the warning?

- Products sold in California require Prop 65 labelling while similar products sold elsewhere do not.
- A company involved in a Prop 65 lawsuit reaching a settlement may be required to use Prop 65 warnings for its products, but other companies
 making similar products may have no such requirement.
- The enforcement of Prop 65 is inconsistent.
- Companies may elect not to provide warnings because they conclude that they are not required to do so under Prop 65; a lack of warnings for a
 product does not mean that the product is free of listed chemicals at similar levels.

Why does Toro include this warning?

Toro has chosen to provide consumers with as much information as possible so that they can make informed decisions about the products they buy and use. Toro provides warnings in certain cases based on its knowledge of the presence of one or more listed chemicals without evaluating the level of exposure, as not all the listed chemicals provide exposure limit requirements. While the exposure from Toro products may be negligible or well within the "no significant risk" range, out of an abundance of caution, Toro has elected to provide the Prop 65 warnings. Moreover, if Toro does not provide these warnings, it could be sued by the State of California or by private parties seeking to enforce Prop 65 and subject to substantial penalties.

