



Mid-Size Mower
ProLine Gear 17 HP with 52in Side Discharge
Mower
Model No. 30438—Serial No. 240000001 and Up

Operator's Manual



Warning



CALIFORNIA

Proposition 65 Warning

The engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.

Important This engine is not equipped with a spark arrester muffler. It is a violation of California Public Resource Code Section 4442 to use or operate this engine on any forest-covered, brush-covered or grass-covered land. Other states or federal areas may have similar laws.

This spark ignition system complies with Canadian ICES-002.

Ce système d'allumage par étincelle de véhicule est conforme à la norme NMB-002 du Canada.

The enclosed Engine Owner's Manual is supplied for information regarding The U.S. Environmental Protection Agency (EPA) and the California Emission Control Regulation of emission systems, maintenance and warranty.

Keep this engine Owner's Manual with your unit. Should this engine Owner's Manual become damaged or illegible, replace immediately. Replacements may be ordered through the engine manufacturer.

Contents

	Page
Introduction	3
Safety	3
Safe Operating Practices	3
Toro Mower Safety	4
Slope Chart	7
Safety and Instruction Decals	9
Safety and Instruction Decals	11
Gasoline and Oil	15
Recommended Gasoline	15
Using Stabilizer/Conditioner	15
Filling the Fuel Tank	15
Check Engine Oil Level	15
Set Up	16
Loose Parts	16
Removing the Shipping Bracket	17
Installing the Handle Assembly	17
Installing the Fuel Tank	18
Checking and Adjusting the Shift Lever Plate	19
Installing the Control Rods	20

	Page
Installing the Hairpin Cotter Pins and Spacers	21
Operation	22
Think Safety First	22
Controls	22
Parking Brake and Neutral Lock	23
Starting and Stopping the Engine	23
Operating Mower Blade Control (PTO)	24
The Safety Interlock System	24
Driving Forward or Backward	25
Stopping the Machine	25
Transporting Machines	26
Using the Side Discharge	26
Adjusting the Height-of-Cut	26
Adjusting the Gage Wheels	26
Adjusting the Handle Height	27
Using the Mid-Size Weight	28
Maintenance	29
Recommended Maintenance Schedule	29
Servicing the Air Cleaner	30
Servicing the Engine Oil	31
Servicing the Spark Plugs	32
Cleaning the Cooling System	33
Greasing and Lubrication	33
Checking the Tire Pressure	35
Servicing the Fuse	35
Adjusting the Electric Clutch	35
Servicing the Fuel Tank	36
Servicing the Fuel Filter	36
Adjusting the Traction Drive Belt Tension	37
Servicing the Brakes	37
Checking and Adjusting the Control Rods	38
Servicing the Cutting Blades	39
Correcting the Mower Quality of Cut	40
Frame Set Up	41
Checking the Deck Front-to-Rear Pitch	42
Changing the Deck Front-to-Rear Pitch	42
Checking the Deck Side-to-Side Leveling	43
Changing the Side-to-Side Leveling	43
Matching Height of Cut	43
Replacing the Traction Drive Belt	44
Replacing the Transmission Belt	44
Replacing the Mower Belt	45
Replacing the PTO Drive Belt	45
Replacing the Caster Wheel Fork Bushings	46
Caster Wheel and Bearings Service	47
Replacing the Grass Deflector	47
Wiring Diagram	48
Cleaning and Storage	49
Troubleshooting	49

Introduction

Read this manual carefully to learn how to operate and maintain your product properly. The information in this manual can help you and others avoid injury and product damage. Although Toro designs and produces safe products, you are responsible for operating the product properly and safely.

You may contact Toro directly at www.Toro.com for product and accessory information, help finding a dealer, or to register your product.

Whenever you need service, genuine Toro parts, or additional information, contact an Authorized Service Dealer or Toro Customer Service and have the model and serial numbers of your product ready. Figure 1 illustrates the location of the model and serial numbers on the product.




Figure 1

1. Location of the model and serial numbers

Write the product model and serial numbers in the space below:

Model No. _____

Serial No. _____

This manual identifies potential hazards and has special safety messages that help you and others avoid personal injury and even death. **Danger**, **Warning**, and **Caution** are signal words used to identify the level of hazard. However, regardless of the hazard, be extremely careful.

Danger signals an extreme hazard that *will* cause serious injury or death if you do not follow the recommended precautions.

Warning signals a hazard that *may* cause serious injury or death if you do not follow the recommended precautions.

Caution signals a hazard that may cause minor or moderate injury if you do not follow the recommended precautions.

This manual uses two other words to highlight information.

Important calls attention to special mechanical information and **Note:** emphasizes general information worthy of special attention.

Safety

Note: The addition of attachments made by other manufacturers that do not meet American National Standards Institute certification will cause noncompliance of this machine.

Improper use or maintenance by the operator or owner can result in injury. To reduce the potential for injury, comply with these safety instructions and always pay attention to the safety alert ▲ symbol, which means CAUTION, WARNING, or DANGER—“personal safety instruction.” Failure to comply with the instruction may result in personal injury or death.

Safe Operating Practices

The following instructions are from ANSI standard B71.4—1999.

Training

- Read the Operator’s Manual and other training material. If the operator(s) or mechanic(s) can not read English it is the owner’s responsibility to explain this material to them.
- Become familiar with the safe operation of the equipment, operator controls, and safety signs.
- All operators and mechanics should be trained. The owner is responsible for training the users.
- Never let children or untrained people operate or service the equipment. Local regulations may restrict the age of the operator.
- The owner/user can prevent and is responsible for accidents or injuries occurring to himself or herself, other people or property.

Preparation

- Evaluate the terrain to determine what accessories and attachments are needed to properly and safely perform the job. Only use accessories and attachments approved by the manufacturer.
- Wear appropriate clothing including hard hat, safety glasses and hearing protection. Long hair, loose clothing or jewelry may get tangled in moving parts.
- Inspect the area where the equipment is to be used and remove all objects such as rocks, toys and wire which can be thrown by the machine.

- Use extra care when handling gasoline and other fuels. They are flammable and vapors are explosive.
 - Use only an approved container
 - Never remove gas cap or add fuel with engine running. Allow engine to cool before refueling. Do not smoke.
 - Never refuel or drain the machine indoors.
- Check that operator's presence controls, safety switches and shields are attached and functioning properly. Do not operate unless they are functioning properly.

Operation

- Never run an engine in an enclosed area.
- Only operate in good light, keeping away from holes and hidden hazards.
- Be sure all drives are in neutral and parking brake is engaged before starting engine. Only start engine from the operator's position.
- Be sure of your footing while using this machine, especially when backing up. Walk, don't run. Never operate on wet grass. Reduced footing could cause slipping.
- Slow down and use extra care on hillsides. Be sure to travel side to side on hillsides. Turf conditions can affect the machine's stability. Use caution while operating near drop-offs.
- Slow down and use caution when making turns and when changing directions on slopes.
- Never raise deck with the blades running.
- Never operate with the PTO shield, or other guards not securely in place. Be sure all interlocks are attached, adjusted properly, and functioning properly.
- Never operate with the discharge deflector raised, removed or altered, unless using a grass catcher.
- Do not change the engine governor setting or overspeed the engine.
- Stop on level ground, disengage drives, engage parking brake (if provided), shut off engine before leaving the operator's position for any reason including emptying the catchers or unclogging the chute.
- Stop equipment and inspect blades after striking objects or if an abnormal vibration occurs. Make necessary repairs before resuming operations.
- Keep hands and feet away from the cutting unit.
- Look behind and down before backing up to be sure of a clear path.
- Keep pets and bystanders away.

- Slow down and use caution when making turns and crossing roads and sidewalks. Stop blades if not mowing.
- Be aware of the mower discharge direction and do not point it at anyone.
- Do not operate the mower under the influence of alcohol or drugs.
- Use care when loading or unloading the machine into or from a trailer or truck.
- Use care when approaching blind corners, shrubs, trees, or other objects that may obscure vision.

Maintenance and storage

- Disengage drives, set parking brake, stop engine and remove key or disconnect spark plug wire. Wait for all movement to stop before adjusting, cleaning or repairing.
- Clean grass and debris from cutting unit, drives, mufflers, and engine to help prevent fires. Clean up oil or fuel spillage.
- Let engine cool before storing and do not store near flame.
- Shut off fuel while storing or transporting. Do not store fuel near flames or drain indoors.
- Park machine on level ground. Set parking brake. Never allow untrained personnel to service machine.
- Use jack stands to support components when required.
- Carefully release pressure from components with stored energy.
- Remove spark plug wire before making any repairs.
- Use care when checking blades. Wrap the blade(s) or wear gloves, and use caution when servicing them. Only replace blades. Never straighten or weld them.
- Keep hands and feet away from moving parts. If possible, do not make adjustments with the engine running.
- Keep all parts in good working condition and all hardware tightened. Replace all worn or damaged decals.

Toro Mower Safety

The following list contains safety information specific to Toro products and other safety information you must know.

This product is capable of amputating hands and feet and throwing objects. Always follow all safety instructions to avoid serious injury or death.

This product is designed for cutting and recycling grass or, when equipped with a grass bagger, for catching cut grass. Any use for purposes other than these could prove dangerous to user and bystanders.

General Operation

- Be sure the area is clear of other people before mowing. Stop the machine if anyone enters the area.
- Do not touch equipment or attachment parts which may be hot from operation. Allow to cool before attempting to maintain, adjust or service.
- Use only Toro-approved attachments. Warranty may be voided if used with unapproved attachments.
- Check carefully for overhead clearances (i.e. branches, doorways, electrical wires) before operating under any objects and do not contact them.

Slope Operation


All slopes and ramps require extra caution. If you feel uneasy on a slope, do not mow it.

- Remove obstacles such as rocks, tree limbs, etc. from the mowing area.
- Watch for holes, ruts or bumps. Tall grass can hide obstacles.
- Use caution near drop-offs, ditches, or embankments. The machine could suddenly turn over if a wheel goes over the edge of a cliff or ditch, or if an edge caves in.
- Use extra care with grass catchers or other attachments. These can change the stability of the machine.
- Keep all movement on slopes slow and gradual. Do not make sudden changes in speed or direction.
- Mow slopes side to side.
- Do not mow slopes greater than 15 degrees.

Service

- Never store the machine or fuel container inside where there is an open flame, such as near a water heater or furnace.
- Keep nuts and bolts tight, especially the blade attachment bolts. Keep equipment in good condition.
- Never tamper with safety devices. Check safety systems for proper operation before each use.
- Use only genuine replacement parts to ensure that original standards are maintained.
- Check brake operation frequently. Adjust and service as required.

Slope Chart



Safety and Instruction Decals



Safety decals and instructions are easily visible to the operator and are located near any area of potential danger. Replace any decal that is damaged or lost.



43-8480




93-1122



66-1340



67-5360



68-8340



95-2814



98-0776




98-3256



98-4387

1. Warning—wear hearing protection.



104-8186



104-8569



105-4111

ANTI-SCALP ROLLER ADJUSTMENT

FOR MAXIMUM DECK FLOTATION,
PLACE ROLLERS IN POSITIONS SHOWN.
TURN ENGINE OFF BEFORE
MAKING ROLLER ADJUSTMENTS.

- ————— 1.0"/25mm
- ————— 1.75"/44mm
- ————— 2.5"/63mm


106-5532

106-5532



106-0699

CHECK SERVICE REFERENCE AID




106-5511



105-4146

HEIGHT OF CUT PINS ADJUSTMENT

- POSITION ALL PINS IN SAME HEIGHT OF CUT HOLE
- TURN ENGINE OFF BEFORE ADJUSTING DECK CUTTING HEIGHT
- NOTE: HEIGHT IS BASED ON USING ONE FRONT SPACER AND ONE REAR SPACER ON ADJUSTMENT PINS
- ADD ONE ADDITIONAL SPACER TO INCREASE CUTTING HEIGHT 1/4 INCH
- NOTE: REFER TO OPERATOR'S MANUAL FOR ADDITIONAL HEIGHT OF CUT ADJUSTMENT.




106-0635



106-5501

1. Choke 2. Fast 3. Continuous variable setting 4. Slow



106-5514

1. Keep bystanders a safe distance from the machine.

2. Do not allow bystanders to be hit by thrown objects.

3. Do not operate the mower with the deflector up or removed.

4. Stop the engine and pick up debris before operating.

5. Cutting of hand or foot, mower.

6. Engine—stop

7. Engine—run

8. Hour meter

9. To park, move the controls as illustrated.

10. To drive, move the controls as illustrated.

11. To place the machine in neutral, move the controls as illustrated.

12. Power take-off (PTO)

Gasoline and Oil

Recommended Gasoline

Use UNLEADED Regular Gasoline suitable for automotive use (85 pump octane minimum). Leaded regular gasoline may be used if unleaded regular is not available.

Important Never use methanol, gasoline containing methanol, or gasohol containing more than 10% ethanol because the fuel system could be damaged. Do not mix oil with gasoline.

Danger	
<p>In certain conditions, gasoline is extremely flammable and highly explosive. A fire or explosion from gasoline can burn you and others and can damage property.</p> <ul style="list-style-type: none">• Fill the fuel tank outdoors, in an open area, when the engine is cold. Wipe up any gasoline that spills.• Never fill the fuel tank inside an enclosed trailer.• Do not fill the fuel tank completely full. Add gasoline to the fuel tank until the level is 1/4 to 1/2 inch (6 to 13 mm) below the bottom of the filler neck. This empty space in the tank allows gasoline to expand.• Never smoke when handling gasoline, and stay away from an open flame or where gasoline fumes may be ignited by a spark.• Store gasoline in an approved container and keep it out of the reach of children. Never buy more than a 30-day supply of gasoline.• Always place gasoline containers on the ground away from your vehicle before filling.• Do not fill gasoline containers inside a vehicle or on a truck or trailer bed because interior carpets or plastic truck bed liners may insulate the container and slow the loss of any static charge.• When practical, remove gas-powered equipment from the truck or trailer and refuel the equipment with its wheels on the ground.• If this is not possible, then refuel such equipment on a truck or trailer from a portable container, rather than from a gasoline dispenser nozzle.• If a gasoline dispenser nozzle must be used, keep the nozzle in contact with the rim of the fuel tank or container opening at all times until fueling is complete.	
!	!

Warning
<p>Gasoline is harmful or fatal if swallowed. Long-term exposure to vapors can cause serious injury and illness.</p> <ul style="list-style-type: none">• Avoid prolonged breathing of vapors.• Keep face away from nozzle and gas tank or conditioner opening.• Keep gas away from eyes and skin.

Using Stabilizer/Conditioner

Use a fuel stabilizer/conditioner in the machine to provide the following benefits:

- Keeps gasoline fresh during storage of 90 days or less. For longer storage it is recommended that the fuel tank be drained.
- Cleans the engine while it runs
- Eliminates gum-like varnish buildup in the fuel system, which causes hard starting

Important Do not use fuel additives containing methanol or ethanol.

Add the correct amount of gas stabilizer/conditioner to the gas.

Note: A fuel stabilizer/conditioner is most effective when mixed with fresh gasoline. To minimize the chance of varnish deposits in the fuel system, use fuel stabilizer at all times.

Filling the Fuel Tank

1. Shut the engine off and set the parking brake.
2. Clean around fuel tank cap and remove the cap. Add unleaded regular gasoline to fuel tank, until the level is 1/4 to 1/2 inch (6 to 13 mm) below the bottom of the filler neck. This space in the tank allows gasoline to expand. Do not fill the fuel tank completely full.
3. Install fuel tank cap securely. Wipe up any gasoline that may have spilled.

Check Engine Oil Level

Before you start the engine and use the machine, check the oil level in the engine crankcase; refer to Checking Oil Level, page 28.

Set Up

Note: Determine the left and right sides of the machine from the normal operating position.

Loose Parts

Note: Use the chart below to identify parts for assembly.

Step	Description	Qty.	Use
1	No parts needed	–	Removing the shipping bracket
2	Handle assembly Flanged bolt, 3/8 x 1 inch Flange nut, 3/8 inch	1 4 4	Installing the handle assembly
3	Fuel tank with studs installed Locknut, 5/16 inch Bolt, 5/16 x 7/8 inch Lock washer, 5/16 inch Washer, 5/16 inch Spring Hose clamp	1 2 2 2 4 2 1	Installing the fuel tank
4	No parts needed	–	Checking and adjusting the shift lever
5	Clevis pin Washer Hairpin cotter pin	2 2 2	Installing the control rods
6	Hairpin cotter pin Spacers	2 6	Installing the hairpin cotter pins and spacers
7	Oil drain hose	1	Use for draining the engine oil
8	Operator's Manual Engine Operator's Manual Parts Catalog Safety Video Registration card	1 1 1 1 1	Read before operating machine Read before operating machine Watch before operating machine Fill out and return to Toro

Step

1

Removing the Shipping Bracket

Parts needed for this step:

None

Procedure

1. Remove the center gage wheel nut, 2 large washers, angle bracket and 1 small washer (Fig. 2). Discard the 2 large washers and the angle bracket.




Figure 2

1. Center Gage Wheels and Spacer	3. Large washer—discard
2. Nut	4. Angle bracket—discard
	5. Small washer

2. Install the center gage wheels with the previously removed bolt, small washer and nut (Fig. 3).




Figure 3

1. Center Gage Wheels and Spacer	3. Bolt
2. Nut	4. Washer
	5. Spacer

Step

2


Installing the Handle Assembly

Parts needed for this step:

Qty.	Part
1	Handle assembly
4	Bolt, 5/16 X 7/8 inch
4	Lock nut, 5/16 inch

1. Align handle with upper mounting holes in rear frame (Fig. 4).
2. Secure the handle at each upper mounting hole with a flange bolt (3/8 x 1 inch) and flange nut (Fig. 4).
3. Select the low position for the lower mounting hole (Fig. 4).
4. Secure the handle at each lower mounting hole with a flange bolt (3/8 x 1 inch) and flange nut (Fig. 4).

Note: The handle position can be adjusted to match the operator's height preference.



m-6591

Figure 4

1. Upper handle	5. Upper mounting hole
2. Rear frame	6. Lower mounting holes
3. Flange nut, 3/8 inch	7. Low position
4. Flange bolt, 3/8 x 1 inch	8. High position

Note: Handle assembly must be installed before fuel tank is installed.

Step
3

Installing the Fuel Tank

Parts needed for this step:

Qty.	Part
1	Fuel tank with studs installed
2	Bolt, 5/16 X 7/8 inch
2	Lock nut, 5/16 inch
4	Washer, 5/16 inch
1	Hose clamp
2	Lock washer, 5/16 inch
2	Spring

Procedure

1. Align fuel tank with the top of the rear frame (Fig. 5).
2. Secure the right side of the fuel tank to the rear frame with 2 bolts (5/16 x 7/8 inch), lock washers (5/16 inch) and washers (5/16 inch) (Fig. 5).
3. Secure the left side of the fuel tank to the rear frame with 2 studs, washers (5/16 inch), springs and locknuts (5/16 inch) (Fig. 5).

Note: Tighten left side of the fuel tank until it is completely tight and then unscrew locknut one full turn. This will allow the spring to work.




Figure 5

1. Bolt, 5/16 x 7/8 inch
 2. Lock washer, 5/16 inch
 3. Washer, 5/16 inch
 4. Stud
 5. Spring
 6. Locknut

Note: Remove the plastic cap from the fuel fitting before installing the fuel line.

- Slide the hose clamp onto the fuel line (Fig. 6).
- Push the fuel line onto the fuel tank connection and secure it with a hose clamp (Fig. 6).




Figure 6

1. Fuel line
 2. Hose clamp
 3. Fuel fitting

Step

4

Checking and Adjusting the Shift Lever Plate

Parts needed for this step:

None

Procedure

- Shift lever to second gear and check alignment of lever in slot of shifter lever plate. The clearance between top and bottom of the shift lever should be equal (Fig. 8).
- If clearance is not correct, remove lever and bend it slightly to adjust (Fig. 8).




Figure 7

1. Shift lever
 2. Shift lever plate
 3. Rubber seal washer
 4. Square hole washer
 5. Spring washer
 6. Locknut, 3/8 inch

Note: Do not bend lever while attached to transmission shaft or damage may occur.

- Shift lever to neutral and check alignment of lever in slot of shifter lever plate. The clearance on the sides of shift lever should be equal (Fig. 8).
- If clearance is not correct, loosen shift lever plate and adjust it side-to-side. Tighten the shift lever plate.




Figure 8

1. Shift lever, 2nd gear
 2. Shift lever plate
 3. Shift lever, neutral
 4. Equal distance

Step 5

Installing the Control Rods

Parts needed for this step:

Qty.	Part
2	Control rods
2	Cotter pin
2	Clevis Pin
2	Washer
2	Hairpin cotter pin

Procedure

1. Install control rods into the bell cranks and secure them with the hairpin cotters (Fig. 9).

Note: Install rod fittings so the clevis pin is above the control rod, as shown in Figure 9.





Figure 9

1. Control rod
2. Bell crank
3. Hairpin cotter

2. Place the clevis pin into the upper part of the control rods, drive lever and neutral/parking brake locks (Fig. 10).
3. Install the hairpin cotter pins between the drive levers and neutral/parking brake locks and into the clevis pins (Fig. 10).




m-7669

Figure 10

1. Control rod	4. Clevis pin
2. Drive lever	5. Handle
3. Hairpin cotter	6. Neutral/parking brake lock

4. Loosen the turn buckle wing nut (Fig. 11).



m-6592

Figure 11

1. Turnbuckle	3. Control rod
2. Wing nut	

5. Adjust the control rod length by rotating the turnbuckle until there is 3/16 to 1/4 inch (5 to 6mm) clearance between the control rod end and the bottom of the neutral/parking brake lock slot with the drive lever in the drive position (Fig. 12).
6. Tighten the wing nut to prevent the turnbuckle from turning (Fig. 11).
7. Check the drive adjustment by squeezing the drive levers firmly and then releasing. If the 3/16 to 1/4 inch (5 to 6mm) adjustment has changed, adjust as necessary.
8. Check the parking brake. Refer to Servicing the Brakes on page 34.




Figure 12

m-6582

1. Handle
2. Neutral/Parking brake lock
3. 3/16 inch to 1/4 inch (5 mm to 6 mm) clearance
4. Drive lever
5. Drive position
6. Control Rod

m-7584





Figure 13

1. Hairpin cotter
2. Spacer
3. Height-of-cut post (rear shown)

3. On the opposite side of the muffler, install unused spacers onto front and rear height-of-cut pins and insert the hairpin cotter pins (Fig. 14).



m-6505

Figure 14

1. Hairpin cotter
2. Unused spacers
3. Height-of-cut post (front shown)

Step

6

Installing the Hairpin Cotter Pins and Spacers

Parts needed for this step:

Qty.	Part
2	Hairpin cotter pin
6	Spacers

Procedure

Unused height-of-cut spacers may be stored on posts and retained by a hairpin cotter.

Note: Make sure there is at least one spacer used on each height-of-cut post.

1. Remove the existing rear hairpin cotter pins from the rear height-of-cut posts.
2. Install a spacer onto both rear height-of-cut posts and install the hairpin cotter pins.

Operation

Note: Determine the left and right sides of the machine from the normal operating position.

Think Safety First

Carefully read all the safety instructions and decals in the safety section. Knowing this information could help you, your family, pets or bystanders avoid injury.

The use of protective equipment for eyes, hearing, feet and head is recommended.




Figure 15

1. Caution

2. Wear hearing protection

Controls

Become familiar with all the controls (Fig. 16) before you start the engine and operate the machine.

Throttle Control – The throttle control has three positions: **Choke**, **Fast** and **Slow**.

Operator Presence Control (OPC) levers – OPC levers are used in conjunction with deck engagement switch (PTO) to release blade brake and engage clutch to drive mower blades. Release OPC levers to disengage mower blades.

Power Take Off Switch (PTO) – This pull switch is used in conjunction with the blade control bail to engage the clutch to drive the mower blades.

Gear Shift Lever – Transmission has five forward speeds, neutral and reverse, and has an in-line shift pattern.

Important Do not shift while unit is moving, as transmission damage may occur.

Drive levers – Shift to desired gear and release drive levers to engage traction operation and squeeze them back to disengage the drive. Squeeze right side of drive lever to turn right and left side to turn left.

Neutral lock and Parking brake locks – Squeeze drive levers back and move locks to the rear for neutral lock. Squeeze drive levers back and move locks to the front for parking brake lock.

Ignition Switch – This switch is used in conjunction with recoil starter and has two positions: **Run** and **Off**.

Recoil Starter – Pull recoil starter handle to start engine (not shown in Figure 16).

Fuel Shut-off Valve – Close fuel shut-off valve when transporting or storing mower.




Figure 16

1. Throttle control	5. Drive levers
2. Operator Presence Control levers (OPC)	6. Neutral lock and parking brake locks
3. Power take off switch (PTO)	7. Ignition switch
4. Gear shift lever	8. Handle
	9. Fuel shut-off valve

Parking Brake and Neutral Lock

Always set the parking brake when you stop the machine or leave it unattended.

Setting the Parking Brake

1. Squeeze the drive levers back to the grip (Fig. 17).
2. Place thumbs on the upper part of the locks and rotate them forward (Fig. 17).
3. Release the drive levers.





Figure 17

1. Handle	4. Drive lever
2. Neutral/Parking brake lock	5. Full speed forward position
3. Park position	6. Grip



m-7559

Figure 18

1. Handle	4. Drive lever
2. Neutral/Parking brake lock	5. Full speed forward position
3. Park position	6. Grip

Releasing the Parking Brake

1. Squeeze the drive levers back to the grip.
2. Place thumbs on the upper part of of locks and rotate them rearward until in forward speed slot.

Setting the Neutral Lock

1. Squeeze the drive levers back to the grip (Fig. 18).
2. Place thumbs on the upper part of of locks and rotate them rearward (Fig. 18).

Releasing the Neutral Lock

1. Squeeze the drive levers back to the grip.
2. Place thumbs on the upper part of of locks and rotate them forward until in forward speed slot.

Starting and Stopping the Engine

Starting

1. Make sure spark plug wire(s) are installed on spark plug(s) and fuel valve is open.
2. Move the shift lever to neutral, set the parking brake, and turn ignition key to the Run position.
3. Move the throttle control to the Choke position before starting a cold engine.

Note: A warm or hot engine usually does not require any choking. To start a warm engine, move throttle control to the Fast position.

4. Grasp recoil starter handle firmly and pull out until positive engagement results; then pull handle vigorously to start engine and allow rope to recoil slowly.

Important Do not pull recoil rope to its limit or let go of the starter handle when rope is pulled out because rope may break or recoil assembly may be damaged.

Stopping

1. Move the throttle lever to the Slow position (Fig. 19).
2. Let engine idle for 30 to 60 seconds before turning the ignition key to off.
3. Set the parking brake.
4. Turn the ignition key to the Off position (Fig. 19).




Figure 19

1. Throttle lever 2. Ignition key

Important Make sure fuel shut off valve is closed before transporting or storing machine, as fuel leakage may occur. Before storing the machine, pull the wire off the spark plug(s) to prevent possibility of accidental starting.

Operating Mower Blade Control (PTO)

The power take off switch (PTO) in conjunction with the Operator Presence Control (OPC) levers engage and disengage power to the electric clutch and mower blades.

Engaging the Mower Blades (PTO)

1. To engage blade, squeeze the Operator Presence Control (OPC) levers against handle grips (Fig. 20).
2. Pull blade switch (PTO) up and release. Hold the Operator Presence Control (OPC) levers against handle grip.
3. Repeat procedure to engage mower blades if OPC levers are released.




Figure 20

1. Handle
2. Operator Presence Control levers (OPC)
3. Power take off switch (PTO)

Disengaging the Mower Blades (PTO)

1. Release Operator Presence Control (OPC) levers to disengage blades (Fig. 20). This will also kill the engine.

The Safety Interlock System



Caution



If safety interlock switches are disconnected or damaged the machine could operate unexpectedly causing personal injury.

- Do not tamper with the interlock switches.
- Check the operation of the interlock switches daily and replace any damaged switches before operating the machine.

Understanding the Safety Interlock System

The safety interlock system is designed to prevent the engine from starting unless:

- The power take off switch (PTO) is off.
- The machine is shifted into neutral.

The safety interlock system is designed to kill the engine when:

- The Operator Presence Control (OPC) levers are released while the machine is in gear and/or the mower is engaged.
- The machine is shifted into gear without holding OPC levers.

- The power take off switch (PTO) is pulled on without holding the OPC levers.

Testing the Safety Interlock System

Test the safety interlock system before each use of the machine. If the safety system does not operate as described, have an Authorized Service Dealer repair the safety system immediately.

1. Set the parking brake and place shift lever in neutral. Start the engine; refer to Starting and Stopping the Engine, page 20.
2. Without holding the Operator Presence Control (OPC) levers, pull the power take off switch (PTO) up. **The engine should kill.**
3. Release the power take off switch (PTO).
4. With engine running, hold down the OPC levers. Pull the power take off switch (PTO) up and then release. The clutch should engage and **the mower blades begin rotating.**
5. Release the OPC levers. **The engine should kill.**
6. With the engine running and holding the OPC levers down, move shift lever into a gear. Release the OPC levers. **The engine should kill.**
7. If all the above conditions are not met have an Authorized Service Dealer repair the safety system immediately.

Driving Forward or Backward

The throttle control regulates the engine speed as measured in rpm (revolutions per minute). Place the throttle control in the **Fast** position for best performance.

Driving Forward

1. To go forward, move the shift lever to a forward gear.
2. Release the parking brake; refer to [Releasing the Parking Brake, page 20](#).
3. Slowly release the drive levers to move forward (Fig. 21).

To go straight, release drive levers equally (Fig. 21).

To turn, squeeze the drive lever on the side and direction you want to turn (Fig. 21).




Figure 21

1. Drive lever
2. Gear shift lever

m=6581

Driving Backward

Note: To drive backward, the machine may need to be assisted by pulling the machine backwards.

1. To go backward, move the shift lever to the reverse gear.
2. Release the parking brake; refer to *Releasing the Parking Brake*, page 20.
3. Slowly release the drive levers together to move rearward (Fig. 21).

Stopping the Machine

1. To stop the machine, squeeze the drive levers back to the grips to engage brakes.
2. Move neutral/brake locks into the park position. Refer to Setting the Parking Brake on page 20.
3. Shift transmission into neutral.
4. Turn the ignition key to Off.

Note: Remember to remove the key from the ignition switch if you leave the machine.



Caution



Children or bystanders may be injured if they move or attempt to operate the machine while it is unattended.

Always remove the ignition key and set the parking brake when leaving the machine unattended, even if just for a few minutes.

Transporting Machines

Use a heavy-duty trailer or truck to transport the machine. Ensure that the trailer or truck has all necessary lighting and marking as required by law. Please carefully read all the safety instructions. Knowing this information could help you, your family, pets or bystanders avoid injury.

To transport the machine:

- Set the brake and block wheels.
- Securely fasten the machine to the trailer or truck with straps, chains, cable, or ropes.
- Secure a trailer to towing vehicle with safety chains.

Using the Side Discharge

This mower has a hinged grass deflector that disperses clippings to the side and down toward the turf.



Danger



Without the grass deflector, discharge cover, or complete grass catcher assembly mounted in place, you and others are exposed to blade contact and thrown debris. Contact with rotating mower blade(s) and thrown debris will cause injury or death.

- Never remove the grass deflector from the mower because the grass deflector routes material down toward the turf. If the grass deflector is ever damaged, replace it immediately.
- Never put your hands or feet under the mower.
- Never try to clear discharge area or mower blades unless you release the bail and the power take off (PTO) is off. Rotate the ignition key to Off. Also remove the key and pull the wire off the spark plug(s).

Adjusting the Height-of-Cut

The height-of-cut can be adjusted from 1 to 4-1/2 inch (25 to 114 mm) in 1/4 inch (6 mm) increments. Adjustment is done by relocating four hairpin cotter pins in different hole location and by adding or removing spacers.



Note: All height-of-cut pins need at least one spacer or damage can occur to bushing if none are used.

Note: All height-of-cut pins can use only two spacers maximum.

1. Select hole in height-of-cut post and number of spacers corresponding to the height-of-cut desired (Fig. 22).
2. Using lift handle, raise side of deck and remove hairpin cotter (Fig. 22).
3. Add or remove spacers if needed and then align holes and insert hairpin cotter (Fig. 22).

Note: Spare height-of-cut spacers may be stored on posts and retained by a hairpin cotter.

Important All four hairpin cotter pins must be in the same hole location and with the correct number of spacers for a level cut.



m-6365

Figure 22

1. Carrier Frame	4. Spacers
2. Hairpin Cotter	5. Back height-of-cut post
3. Front height-of-cut post	

Adjusting the Gage Wheels

The gage wheels need to be adjusted in the proper hole location for each height-of-cut position. There needs to be 3/8 inch (10 mm) minimum clearance above the ground.

1. After adjusting height-of-cut, check the gage wheels so that there is a minimum of 3/8 inch (10 mm) clearance above the ground (Figures 23, 24, and 25).
2. If adjustment is needed, remove the bolt, washer(s) and nut (Figures 23, 24, and 25).
3. Select a hole position so the gage wheels are a minimum of 3/8 inch (10 mm) off the ground (Figures 23, 24, and 25).
4. Install the bolt, spacers, washers and nut (Figures 23, 24, and 25).




Figure 23

1. Gage wheel
2. Nut
3. Washer

m-6471





Figure 24

1. Gage wheel
2. Nut
3. Bolt
4. Washer
5. Spacer
6. Bushing spacer

m-7677



m-7678

Figure 25

1. Center Gage Wheels and Spacer
2. Nut
3. Bolt
4. Washer
5. Spacer

m-7678

Adjusting the Handle Height

The handle position can be adjusted to match the operator's height preference.

1. Remove hairpin cotter, washer and clevis pin securing control rod fitting to idler bracket (Fig. 26).




Figure 26

1. Upper handle
2. Rear frame
3. Flange nut, 3/8 inch
4. Flange bolt, 3/8 x 1 inch
5. Upper mounting hole
6. Lower mounting holes
7. Low position
8. High position

m-6591

2. Loosen the upper flange bolts (3/8 x 1 inch) and flange nut securing handle to rear frame (Fig. 26).
3. Remove the lower flange bolts (3/8 x 1 inch) and flange nuts securing handle to rear frame (Fig. 26).
4. Pivot handle to desired operating position and install lower flange bolts (3/8 x 1 inch) and flange nuts into mounting holes. Tighten all flange bolts.
5. Adjust the control rods. Refer to Installing the Control Rods on page 17.

6. Check the parking brake adjustment; refer to Checking the Brakes, page 34.

Using the Mid-Size Weight

This machine includes a weight installed in the rear position (Fig. 27).

- The weight mounted in the **rear** position is **recommended**, except when a Tru-Trak® Sulky is installed.
- The weight mounted in the back position, must be removed when the when a Tru-Trak® Sulky is installed.





Figure 27

1. Weight mounted in rear position	3. Washer
2. Capscrew	4. Nut

Maintenance

Note: Determine the left and right sides of the machine from the normal operating position.

Recommended Maintenance Schedule

Maintenance Service Interval	Maintenance Procedure
Each Use	<ul style="list-style-type: none">• Engine Oil—check level• Safety System—check• Brake—check• Engine—clean outside• Mower Housing—clean
After first 8 Hours	<ul style="list-style-type: none">• Engine Oil—change
8 Hours	<ul style="list-style-type: none">• Mower Housing—clean• Caster Wheels—grease• Caster Pivot—grease• Cutting Blades—check
25 Hours	<ul style="list-style-type: none">• Foam Air Cleaner—clean¹
40 Hours	<ul style="list-style-type: none">• Tires—check pressure• PTO Belt Idler Arm—grease
50 Hours	<ul style="list-style-type: none">• Belts—check• Paper Air Cleaner—clean¹
100 Hours	<ul style="list-style-type: none">• Engine Oil—change¹• Spark Plug(s)—check• Electric Clutch—adjust• Engine—clean outside
200 Hours	<ul style="list-style-type: none">• Fuel Filter—replace• Engine Oil Filter—change (200 hours or every other oil change)• Paper Air Cleaner—replace
250 Hours	<ul style="list-style-type: none">• Transmission Couplings—grease¹
400 Hours	<ul style="list-style-type: none">• Wheel Bearings—grease¹
At storage or 400 Hours	<ul style="list-style-type: none">• Chipped Surfaces—paint• Perform all maintenance procedures listed above before storage

¹More often in dusty, dirty conditions.

Important Refer to your engine operator's manual for additional maintenance procedures.



Caution



If you leave the key in the ignition switch, someone could accidentally start the engine and seriously injure you or other bystanders.

Remove the key from the ignition and disconnect the spark plug wire from the spark plug(s) before you do any maintenance. Set the wire aside so that it does not accidentally contact the spark plug.

Servicing the Air Cleaner

Service Interval/Specification

Foam element: Clean it after every 25 operating hours.


Paper element: Clean it after every 50 operating hours.
Replace it after every 200 operating hours or yearly, which ever comes first.

Note: Service the air cleaner more frequently (every few operating hours) if the operating conditions are extremely dusty or sandy.

Important Do not oil the foam or paper element.

Removing the Foam and Paper Elements

1. Disengage the PTO and set the parking brake.
2. Stop the engine, remove the key, and wait for all moving parts to stop before leaving the operating position.
3. Clean around the air cleaner to prevent dirt from getting into the engine and causing damage (Fig. 28).
4. Unscrew the cover knob and remove the air cleaner cover (Fig. 28).
5. Unscrew the 2 wing nuts and remove the air cleaner assembly (Fig. 28).
6. **Carefully** pull the foam element off the paper element (Fig. 28).



m-7452

Figure 28

1. Engine	4. Foam element
2. Cover	5. Paper element
3. Wing nut	6. Cover knob

Cleaning the Foam Element

1. Wash the foam element in liquid soap and warm water. When the element is clean, rinse it thoroughly.
2. Dry the element by squeezing it in a clean cloth.

Important Replace the foam element if it is torn or worn.

Cleaning the Paper Element

Important Never clean the paper element with pressurized air or liquids, such as solvent, gas, or kerosene.

1. Lightly tap the element on a flat surface to remove dust and dirt (Fig. 28).
2. Inspect the element for tears, an oily film, and damage to the rubber seal.
3. Replace the paper element if it is damaged, or cannot be cleaned thoroughly.

Installing the Foam and Paper Elements

Important To prevent engine damage, always operate the engine with the complete foam and paper air cleaner assembly installed.

1. Carefully slide the foam element onto the paper air cleaner element (Fig. 28).
2. Place the air cleaner assembly onto the air cleaner base and secure it with the nut (Fig. 28).
3. Place the air cleaner cover into position and tighten the cover knob (Fig. 28).

Servicing the Engine Oil

Service Interval/Specification

Change the engine oil:

- After the first 8 operating hours
- After every 100 operating hours


Note: Change the oil more frequently when the operating conditions are extremely dusty or sandy.

Oil Type: Detergent oil (API service SF, SG, SH, or SJ)

Crankcase Capacity: 58 ounces (1.7 liter) with the filter removed; 51 ounces (1.5 liter) without the filter removed

Viscosity: Refer to the table below


USE THESE SAE VISCOSITY OILS



Checking the Engine Oil Level

1. Park the machine on a level surface.
2. Disengage the PTO and set the parking brake.
3. Stop the engine, remove the key, and wait for all moving parts to stop before leaving the operating position.

4. Clean around the oil dipstick (Fig. 29) so that dirt cannot fall into the filler hole and damage the engine.



m-7449

Figure 29

1. Oil dipstick
2. Filler tube
5. Unscrew the oil dipstick and wipe the end clean (Fig. 29).
6. Slide the oil dipstick fully into the filler tube, **but do not thread onto tube** (Fig. 29).
7. Pull the dipstick out and look at the end. If the oil level is low, slowly pour only enough oil into the filler tube to raise the level to the **Full** mark.

Important Do not overfill the crankcase with oil and run the engine; engine damage can result.

Changing the Oil

1. Start the engine and let it run five minutes. This warms the oil so it drains better.
2. Park the machine so that the drain side is slightly lower than the opposite side to assure the oil drains completely.
3. Disengage the PTO and set the parking brake.
4. Stop the engine, remove the key, and wait for all moving parts to stop before leaving the operating position.
5. Slide the drain hose over the oil drain valve.
6. Place a pan below the drain hose. Rotate oil drain valve to allow oil to drain (Fig. 31).
7. When oil has drained completely, close the drain valve.
8. Remove the drain hose (Fig. 31).

Note: Dispose of the used oil at a recycling center.




Figure 30

1. Oil drain valve 2. Drain hose




Figure 31

1. Oil drain plug

9. Slowly pour approximately 80% of the specified oil (refer to Service Interval/Specification, page 28) into the filler cap (Fig. 29).
10. Check the oil level; refer to Checking the Engine Oil Level, page 28.
11. Slowly add the additional oil to bring it to the **Full** mark.

Changing the Oil Filter

Replace the oil filter every 200 operating hours or every other oil change.

Note: Change the oil filter more frequently when the operating conditions are extremely dusty or sandy.

1. Drain the oil from the engine; refer to Changing the Oil, page 28.
2. Remove the old filter (Fig. 32).




Figure 32

1. Oil filter 2. Adapter

3. Apply a thin coat of new oil to the rubber gasket on the replacement filter (Fig. 32).
4. Install the replacement oil filter to the filter adapter, turn the oil filter clockwise until the rubber gasket contacts the filter adapter, then tighten the filter an additional 3/4 turn (Fig. 32).
5. Fill the crankcase with the proper type of new oil; refer to Servicing the Engine Oil, page 28.
6. Run the engine for about 3 minutes, stop the engine, and check for oil leaks around the oil filter.
7. Check the engine oil level and add oil if needed.

Servicing the Spark Plugs

Service Interval/Specification

Check the spark plugs after every 100 operating hours. Ensure that the air gap between the center and side electrodes is correct before installing the spark plug. Use a spark plug wrench for removing and installing the spark plugs and a gapping tool/feeler gauge to check and adjust the air gap. Install a new spark plugs if necessary.

Type: Champion® RCJ-8Y or equivalent
Air Gap: 0.030 inch (0.75 mm)

Removing the Spark Plugs

1. Disengage the PTO and set the parking brake.
2. Stop the engine, remove the key, and wait for all moving parts to stop before leaving the operating position.
3. Disconnect the wires from the spark plugs (Fig. 33).




Figure 33

1. Spark-plug wire/spark plug
4. Clean around the spark plugs to prevent dirt from falling into the engine and potentially causing damage.
5. Remove the spark plugs and the metal washers.

Checking the Spark Plugs

1. Look at the center of the spark plugs (Fig. 34). If you see light brown or gray on the insulator, the engine is operating properly. A black coating on the insulator usually means that the air cleaner is dirty.




Figure 34

1. Center electrode insulator	3. Air gap (not to scale)
2. Side electrode	

Important Always replace the spark plugs when it has a black coating, worn electrodes, an oily film, or cracks.

2. Check the gap between the center and side electrodes (Fig. 34). Bend the side electrode (Fig. 34) if the gap is not correct.

Installing the Spark Plugs

1. Install the spark plugs and the metal washer. Ensure that the air gap is set correctly.

2. Tighten the spark plugs to 16 ft-lb (22 N•m).
3. Connect the wires to the spark plugs (Fig. 33).

Cleaning the Cooling System

Clean the air intake screen from grass and debris before each use.

Check and clean cooling fins and engine shrouds every 100 hours or yearly, whichever comes first.

1. Disengage the PTO and set the parking brake.
2. Stop the engine, remove the key, and wait for all moving parts to stop before leaving the operating position.
3. Remove the air intake screen, recoil starter and fan housing.
4. Clean the debris and grass from the engine parts.
5. Install air intake screen, recoil starter and fan housing.




Figure 35

1. Air intake screen	4. Bolt
2. Fan housing	5. Nut
3. Recoil starter	

Greasing and Lubrication

Service Interval/Specification

Grease with No. 2 general purpose lithium base or molybdenum base grease.

How to Grease

1. Disengage the PTO and set the parking brake.

2. Stop the engine, remove the key, and wait for all moving parts to stop before leaving the operating position.
3. Clean the grease fittings with a rag. Make sure to scrape any paint off the front of the fitting(s).
4. Connect a grease gun to the fitting. Pump grease into the fittings until grease begins to ooze out of the bearings.
5. Wipe up any excess grease.

Where to Add Grease

1. Lubricate the grease fittings as shown on the Check Service Reference Aid decal (Fig. 36).




Figure 36

Lubricating the Caster and Wheel Bearings

1. Lubricate the front wheel bearings and front spindles (Fig. 37).
2. Raise the rear of the machine and use jack stands to support the machine.
3. Remove the rear wheel and tire assembly.
4. Remove rear wheel grease cap. Lubricate the rear wheel bearing (Fig. 37).
5. Install the grease cap.
6. Install the rear wheel and tire assembly.

Note: Make sure the rear wheel grease caps are removed before lubricating rear wheels.




Figure 37

m-6367

Lubricating the Transmission Couplers

1. Lubricate the transmission couplers located in the back of the machine (Fig. 38).




Figure 38

Greasing the PTO Drive Belt Idler and Deck Belt Idler

1. Grease the idler pulley pivots (Fig. 39).

Note: You will have to remove the carrier covers to access the grease fitting for the deck.




Figure 39

Checking the Tire Pressure

Service Interval/Specification

Maintain the air pressure in the front and rear tires as specified. Check the pressure at the valve stem after every 40 operating hours or monthly, whichever occurs first (Fig. 40). Check the tires when they are cold to get the most accurate pressure reading.

Rear Tire Pressure: 12–14 psi (83–97 kPa)

Caster Tire Pressure: 25–30 psi (172–207 kPa)




Figure 40

1. Rear Tire

2. Caster tire

Servicing the Fuse

Service Interval/Specification

The electrical system is protected by a fuse. It requires no maintenance. If the fuse blows check component or circuit for malfunction or short. To replace fuse, pull out on the fuse (Fig. 41) and push in new fuse.




Figure 41

1. Fuse, 10 amp blade type

Adjusting the Electric Clutch

The clutch is adjustable to ensure proper engagement and proper braking. Check adjustment after every 100 hours of operation.

1. To adjust the clutch, tighten or loosen the lock nuts on the flange studs (Fig. 42).
2. Check adjustment by inserting a feeler gauge thru the slots next to the studs (Fig. 42).
3. The proper disengaged clearance between the clutch plates is 0.012–0.024 inch (0.30–0.60 mm). It will be necessary to check this clearance at each of the three slots to ensure the plates are parallel to each other.




Figure 42

1. Adjusting nut
2. Slot
3. Feeler gauge

5. Install the fuel line onto the fuel filter. Slide the hose clamp close to the valve to secure the fuel line.




Figure 43

1. Fuel shut-off valve
2. Clamp

Servicing the Fuel Tank



Danger



In certain conditions, gasoline is extremely flammable and highly explosive. A fire or explosion from gasoline can burn you and others and can damage property.

- Drain gasoline from the fuel tank when the engine is cold. Do this outdoors in an open area. Wipe up any gasoline that spills.
- Never smoke when draining gasoline, and stay away from an open flame or where a spark may ignite the gasoline fumes.

Draining the Fuel Tank

1. Park the machine on a level surface, to assure fuel tank drains completely. Then disengage the power take off (PTO), set the parking brake, and turn the ignition key to **off**. Remove the key.
2. Close the fuel shut-off valve at the fuel tank (Fig. 43).
3. Squeeze the ends of the hose clamp together and slide it up the fuel line away from fuel filter (Fig. 43).
4. Pull the fuel line off the fuel filter (Fig. 43). Open the fuel shut-off valve and allow the gasoline to drain into a gas can or drain pan.

Note: Now is the best time to install a new fuel filter because the fuel tank is empty. Refer to Replacing the Fuel Filter; page 33.

Servicing the Fuel Filter

Service Interval/Specification

Replace the fuel filter after every 200 operating hours or yearly, whichever occurs first.

Replacing the Fuel Filter

Never install a dirty filter if it is removed from the fuel line.

Note: Note how the fuel filter is installed.

Note: Wipe up any spilt fuel.

1. Disengage the PTO and set the parking brake.
2. Stop the engine, remove the key, and wait for all moving parts to stop before leaving the operating position.
3. Close fuel shut-off valve at fuel tank (Fig. 43).
4. Squeeze the ends of the hose clamps together and slide them away from the filter (Fig. 44).
5. Remove the filter from the fuel lines.
6. Install a new filter and move the hose clamps close to the filter.
7. Open fuel shut-off valve at fuel tank (Fig. 43).
8. Check for fuel leaks and repair if needed.




Figure 44

1. Hose clamp
2. Fuel line
3. Filter

m-7545




Figure 45

1. Position A, New belt
2. Position B, Low belt wear
3. Position C, Medium belt wear
4. Position D, Most severe belt wear
5. Spring
6. Adjustment bolt, In position A

m-6595

Adjusting the Traction Drive Belt Tension

It may be necessary to increase the drive belt tension as the belt wears.

1. Stop engine and remove spark plug wire(s).
2. Disengage neutral/brake locks and release drive levers to lower spring force.
3. Remove drive spring from adjustment bolt assembly (Fig. 45).
4. Remove the adjustment bolt assembly (Fig. 45).
5. Locate the adjustment bolt assembly into the desired tension position as follows.
 - Position **A** – New belt
 - Position **B** – Low belt wear
 - Position **C** – Medium belt wear
 - Position **D** – Most severe belt wear

Note: Do not over extend the spring. The spring length should not exceed 7-5/8 inches with the parking brake engaged (Fig. 45).

6. Install adjustment bolt assembly and spring.
7. Repeat for opposite side.

Servicing the Brakes

Service Interval/Specification

Before each use, check brakes on both a level surface and slope.

Always set the parking brake when you stop the machine or leave it unattended. If the parking brake does not hold securely, an adjustment is required.

Checking the Brake

1. Park the machine on a level surface, disengage the PTO.
2. Stop the engine, remove the key, and wait for all moving parts to stop before leaving the operating position.
3. Push the neutral/brake lock forward to set the brake.
4. Rear wheels must lock when you try to push the machine forward or backward. Adjustment is required if the wheels turn and do not lock. Refer to Adjusting the Brake on page 34.
5. Release the brake and move neutral/brake lock to the neutral position. Move the machine lightly, approximately 1/2 in. (13 mm). Wheels should rotate freely.
6. If both conditions are met, no adjustment is required.


Adjusting the Brakes

The brake lever is on the upper control bar (Fig. 16). If the parking brake does not hold securely, an adjustment is required.

Note: For the initial adjustment, adjust the wing nut until it is 1-1/4 inches from the top of the rod (Fig. 46).

1. Park the machine on a level surface, disengage the PTO, and set the parking brake.
2. Stop the engine, remove the key, and wait for all moving parts to stop before leaving the operating position.
3. Check the brake before you adjust it; refer to Checking the Brakes, page 34.
4. Release the parking brake; refer to Releasing the Parking Brake, page 20.
5. To adjust the brake remove the hair pin cotter and washer from the bell crank and trunnion (Fig. 46).
6. Rotate the wing nut clockwise to increase the braking pressure.
7. Rotate the wing nut counterclockwise to decrease the braking pressure.
8. Install the trunnion into the hole for the brake rod (Fig. 46). Tighten the wing nut.
9. Secure trunnion to brake lever with washer and hair pin cotter (Fig. 46).
10. Check the brake operation again; refer to Checking the Brake, page 34.

Important With the parking brake released, the rear wheels must rotate freely when you push the mower. If brake action and free wheel rotation cannot be achieved contact your service dealer immediately.



m-6596

Figure 46

1. Hairpin cotter	6. Hole for brake rod
2. Washer	7. Initial adjustment— 1-1/4 inch (32 mm)
3. Trunnion	8. Rod
4. Bell crank	
5.	

Checking and Adjusting the Control Rods

It may be necessary to adjust the the control rods as the traction drive belt wears. Adjustment is required before the upper control rod contacts the lower end of the neutral/parking brake slot during operations (Fig. 47).

To adjust the control rods. Refer to Installing the Control Rods on page 17.





Figure 47

m-6582

1. Handle
2. Neutral/Parking brake lock
3. 3/16 inch to 1/4 inch (5 mm to 6 mm) clearance
4. Drive lever
5. Drive position slot
6. Control Rod

2. Inspect the blades, especially the curved area (Fig. 48). If you notice any damage, wear, or a slot forming in this area (item 3 in Fig. 48), immediately install a new blade.




m-151

Figure 48

1. Cutting Edge
2. Curved Area
3. Wear/slot Forming

Servicing the Cutting Blades

To ensure a superior quality of cut, keep the blades sharp. For convenient sharpening and replacement, you may want to keep extra blades on hand.



Before Inspecting or Servicing the Blades


Park the machine on a level surface, disengage the blade control bail and set the parking brake. Turn the ignition key to **off**. Remove the key and disconnect the spark plug wire(s) from the spark plug(s).

Inspecting the Blades

1. Inspect the cutting edges (Fig 48). If the edges are not sharp or have nicks, remove and sharpen the blades. Refer to Sharpening the Blades on page 37.


Checking for Bent Blades

1. Rotate the blades until the ends face forward and backward (Fig. 49). Measure from a level surface to the cutting edge, position A, of the blades (Fig. 50). Note this dimension.



m-1078

Figure 49




MEASURE FROM
CUTTING EDGE TO A
LEVEL SURFACE

m-2539

Figure 50

2. Rotate the opposite ends of the blades forward.

- Measure from a level surface to the cutting edge of the blades at the same position as in step 1. The difference between the dimensions obtained in steps 1 and 2 must not exceed 1/8 inch (3 mm). If this dimension exceeds 1/8 inch (3 mm), the blade is bent and must be replaced. Refer to Removing the Blades, and Installing the Blades on page 37.



Removing the Blades

Blades must be replaced if a solid object is hit, if the blade is out of balance or is bent. To ensure optimum performance and continued safety conformance of the machine, use genuine TORO replacement blades. Replacement blades made by other manufacturers may result in non-conformance with safety standards.

- Hold the blade end using a rag or thickly-padded glove. Remove the blade bolt, blade stiffener, washer, and blade from the spindle shaft (Fig. 51).




Figure 51

1. Sail Area of Blade	4. Blade Bolt
2. Blade	5. Blade stiffener
3. Blade spindle	6. Flat washer

Sharpening the Blades

- Use a file to sharpen the cutting edge at both ends of the blade (Fig. 52). Maintain the original angle. The blade retains its balance if the same amount of material is removed from both cutting edges.



Figure 52

- Sharpen at original angle

- Check the balance of the blade by putting it on a blade balancer (Fig. 53). If the blade stays in a horizontal position, the blade is balanced and can be used. If the blade is not balanced, file some metal off the end of the sail area only (Fig. 51). Repeat this procedure until the blade is balanced.




Figure 53

- Blade
- Balancer

Installing the Blades

- Install the blade onto the spindle shaft (Fig. 51).

Important The sail part of the blade must be pointing upward, toward the inside of the mower to ensure proper cutting (Fig. 51).

- Install the blade stiffener, flat washer and blade bolt (Fig. 51). Torque the blade bolt to 85–110 ft-lb (115–140 N•m).

Correcting the Mower Quality of Cut

If one deck blade cuts lower than the other, correct as follows.

Note: Tire air pressure is critical in these procedures. Make sure all tires have correct pressure.

- Disengage the PTO and set the parking brake.

2. Stop the engine, remove the key, and wait for all moving parts to stop before leaving the operating position. Disconnect the spark plug wire(s) from the spark plug(s).
3. Adjust the tire pressure in all tires to specifications on page 32.
4. Check that the blades and spindle shafts are not bent. Refer to Checking for Bent Blades on page 36.
5. Set the height-of-cut to the 4 inch (101.6 mm) position. Refer to Adjusting the Height-Of-Cut in the Operation section.
6. Perform steps in the following sections Frame Set Up, Checking Front-to-Rear Pitch and Checking Side-to-Side Leveling.

Frame Set Up

Checking Carrier Frame and Deck Alignment

1. Disengage the PTO and set the parking brake.
2. Stop the engine, remove the key, and wait for all moving parts to stop before leaving the operating position.
3. Place a long straight edge on top of the engine deck as shown in figure 54.
4. At the carrier frame cross tube, measure location A height (Fig. 54). This measurement must be 1-5/16 inch (33 mm), plus or minus a 1/4 inch (6 mm).
5. If the height at location A is not correct, adjustment is needed.
6. Loosen the carrier frame mounting bolts on both sides of the machine (Fig. 54).
7. Align the carrier frame and engine deck to match 1-5/16 inch (33 mm), plus or minus a 1/4 inch (6 mm) at location A (Fig. 54).
8. Tighten the carrier frame mounting bolts on both sides of the machine.




Figure 54

1. Carrier Frame	4. Location A, 1-5/16 inch (33 mm) ±1/4 inch (6 mm)
2. Top of engine deck	5. Straight edge
3. Carrier frame mounting bolts	6. Carrier frame cross tube

Checking Engine Deck Height

1. Disengage the PTO and set the parking brake.
2. Stop the engine, remove the key, and wait for all moving parts to stop before leaving the operating position.
3. Adjust the tire pressure in all tires to specifications on page 32.
4. Measure engine deck height at location A (Fig. 55).
5. Measure engine deck height at location B (Fig. 55).
6. If the height at location A and B are not the same, change tire pressure slightly to make them the same.




Figure 55

1. Back view of machine	4. Same height at locations A and B
2. Top of engine deck	
3. Tires	

Checking Carrier Frame Front-to-Rear Pitch

The carrier frame must have a pitch of a 1/4 inch (6 mm) over the length of 24 inches (61 cm) on the carrier frame (Fig. 56).

1. Measure out 24 inches (61cm) on the carrier frame (Fig. 56).
2. Measure carrier frame height at location **A** (Fig. 56).
3. Measure carrier frame height at location **B** (Fig. 56).
4. The height at location **A** must be a 1/4–3/8 inch (6 mm–10 mm) lower than location **B** (Fig. 56).
5. If the carrier frame is not correct, move caster spacers to make it a 1/4–3/8 inch (6–10 mm) pitch (Fig. 56). Move spacers from top or bottom to make the correct pitch.
6. The tire pressure may also be adjusted slightly to make a 1/4 inch (6 mm) pitch.




Figure 56

1. Caster Wheel	4. Height at locations A and B
2. Carrier Frame	5. Caster spacers
3. 1/4–3/8 inch (6 mm–10 mm) pitch over 24 inch (61 cm) length	

Checking Carrier Frame Side-to-Side

1. Disengage the PTO and set the parking brake.
2. Stop the engine, remove the key, and wait for all moving parts to stop before leaving the operating position.
3. Adjust the tire pressure in all tires to specifications on page 32.
4. Measure carrier frame height at location **A** (Fig. 57).

5. Measure carrier frame height at location **B** (Fig. 57).
6. If the carrier frame height is not the same move spacers from top or bottom of caster wheel, to make it level. The tire pressure may also be adjusted slightly to make it level.




Figure 57

1. Caster Wheel	4. Same height at locations A and B
2. Carrier Frame	5. Caster spacers
3. Front height-of-cut pins	

Checking the Deck Front-to-Rear Pitch

1. Check the tire pressure on both deck and traction unit.
2. Position one blade front-to-rear (Fig. 58). Measure at **C** and **D** locations (Fig. 58) from a level surface to the cutting edge of the blade tips (Fig. 59).
3. The mower blade should be **1/4 inch (6 mm) lower in front at C than in the rear at D**. Rotate blades and repeat for other blades. If it is not correct, proceed to Changing the Deck Front-to-Rear Pitch.




Figure 58




Figure 59

Changing the Deck Front-to-Rear Pitch

Changing the front-to-rear pitch is done by adjusting the front height-of-cut posts.

Changing the Deck Front-to-Rear Pitch by Adjusting Front Height-of-Cut Posts

1. To change the front-to-rear pitch, the front height-of-cut posts can be adjusted (Fig. 60).
2. To raise the front of the deck, loosen jam nut and rotate the front pin clockwise (Fig. 60).
3. To lower the front of the deck, loosen jam nut and rotate the front pin counter clockwise (Fig. 60).




Figure 60

4. Position the blades front-to-rear (Fig. 58). Measure at **C** and **D** locations (Fig. 58) from a level surface to the cutting edge of the blades (Fig. 59).
5. Check the side-to-side leveling of the cutting unit.
6. Tighten the jam nuts (Fig. 60).

Checking the Deck Side-to-Side Leveling

1. Check the tire pressure on both deck and traction unit.
2. Position the blades side-to-side (Fig. 61). Measure at **A** and **B** locations (Fig. 61) from a level surface to the cutting edge of blade tips (Fig. 62).
3. The difference between measurements **A** and **B** should be no more than 1/4 inch (6 mm).




Figure 61




Figure 62

Changing the Side-to-Side Leveling

Changing the side-to-side leveling is done by adjusting tire pressure.

Changing the Side-to-Side Leveling with Tire Pressure

1. Change the tire pressure on both deck and traction unit. Do this to the corresponding side that needs adjustment.
2. Recheck the front-to-rear pitch and side to side leveling of the cutting unit.

Matching Height of Cut

1. Check the tire pressure on both deck and traction unit.
2. Set the height-of-cut to the 4 inch (101.6 mm) position following the height-of-cut decal.
3. With the machine on level surface, position one blade front-to-rear (Fig. 63). Measure at A and from level surface to the cutting edge of the blade tips (Fig. 64).
4. The measurement should be 4 inch (101.6 mm).




Figure 63




Figure 64

5. If it does not measure correctly, add air pressure in rear tires to raise height-of-cut
6. If it does not measure correctly, decrease air pressure in rear tires to lower height-of-cut.
7. Check carrier frame front-to-rear pitch.

Replacing the Traction Drive Belt

Service Interval/Specification

Check all belts after every 50 operating hours or monthly, whichever occurs first. Look for cracks, wear, and signs of overheating.

1. Remove the top capscrew securing idler support and idler bracket to rear frame (Fig. 65).
2. Loosen bottom two mounting screws enough to allow belt to pass between drive pulley and idler support (Fig. 65).

3. Raise the wheel off the ground, to allow the belt to be removed, and remove the belt.
4. Install a new belt.
5. Install the top capscrew securing the idler support and idler bracket to the rear frame (Fig. 65).
6. Tighten the bottom two mounting screws enough to allow the belt to pass between the drive pulley and idler support (Fig. 65).




Figure 65

1. Top capscrew	4. Bottom capscrew
2. Idler bracket	5. Traction drive belt
3. Idler support	

Replacing the Transmission Belt

1. Disengage the PTO and set the parking brake.
2. Stop the engine, remove the key, and wait for all moving parts to stop before leaving the operating position.
3. Remove PTO drive belt. Refer to Replacing the PTO Drive Belt on page 42.
4. Raise the front of the machine and hold with jack stands.
5. Disconnect clutch wire connector from wire harness.
6. Disconnect clutch retainer from the engine deck (Fig. 66).
7. Unhook tension spring from side of frame (Fig. 66).
8. Loosen pivot bolt enough to remove traction belt from the drive pulley and clutch.
9. Install new belt around clutch and drive pulley.
10. Torque pivot bolt to 35-40 ft-lb (47-54 N·m). Install tension spring between idler arm and frame bracket (Fig. 66).
11. Install clutch retainer to the engine deck (Fig. 66).

12. Connect clutch wire connector to wire harness.

13. Install PTO drive belt.




Figure 66

1. Transmission belt	5. Clutch wire connector
2. Idler pulley	6. Pivot bolt
3. Clutch retainer	7. Drive pulley
4. Tension spring	8. Engine deck

Replacing the Mower Belt

Squealing when the belt is rotating, blades slipping when cutting grass, frayed belt edges, burn marks and cracks are signs of a worn deck belt. Replace the deck belt if any of these conditions are evident.

1. Stop the engine, remove the key and disconnect the spark plug wire(s) from the spark plug(s).
2. Remove the knobs and rubber washers holding the carrier frame cover and remove the carrier frame cover.
3. Remove the knobs and rubber washers holding the belt covers to the cutting unit and remove the belt covers.
4. Remove the PTO drive belt. Refer to Replacing the PTO Drive Belt on page 42.
5. Disconnect the idler arm spring to relieve tension on the idler arm and idler pulley, then remove the worn deck belt (Fig. 67).
6. Install the new deck belt around the two outside spindle pulleys, the idler pulley, and in the lower groove of the center spindle pulley (Fig. 67).
7. Connect the idler arm spring (Fig. 67).
8. Reinstall the PTO drive belt. Refer to Replacing the PTO Drive Belt page 42.
9. Adjust deck belt guide an 1/8 inch (3 mm) from belt (Fig. 67).
10. Reinstall the deck covers onto the cutting unit, then reinstall and tighten the knobs.

11. Install the carrier frame cover onto the cutting unit, then install and tighten the hand knobs.




Figure 67

1. Deck belt	4. PTO drive Belt
2. Idler arm spring	5. Center Spindle Pulley
3. Outside pulley	6. Deck belt guide

Replacing the PTO Drive Belt

Squealing when the belt is rotating, blades slipping when cutting grass, frayed belt edges, burn marks and cracks are signs of a worn drive belt. Replace the drive belt if any of these conditions are evident.

1. Stop the engine, remove the key and disconnect the spark plug wire(s) from the spark plug(s).
2. Remove the knobs holding the carrier frame cover and remove the carrier frame cover.
3. Remove the knobs and rubber washers holding the belt covers to the top of the cutting unit and remove the belt covers.
4. Remove the idler spring from idler arm. Remove the drive belt from the PTO engagement pulley and the center spindle pulley (Fig. 68).
5. Remove the worn drive belt (Fig. 68).
6. Install the new drive belt onto the PTO engagement pulley and the top groove of the center spindle pulley (Fig. 68).
7. Install belt onto idler pulley and then install idler spring (Fig. 68).
8. Adjust PTO drive belt guides an 1/8 inch (3 mm) from belt (Fig. 68).
9. Install the belt covers onto the cutting unit, then install and tighten the knobs.
10. Install the carrier frame cover onto the cutting unit, then install and tighten the hand knobs.




Figure 68

1. PTO engagement pulley	4. Center Spindle Pulley
2. PTO drive belt idler	5. PTO Drive belt guide
3. PTO drive Belt	6. Idler Spring




Figure 69

1. Locking Pin	3. Carrier frame mounting tube
2. Spacers (locate as required)	4. Caster wheel fork

Replacing the Caster Wheel Fork Bushings

The caster wheel forks are mounted in bushings pressed into the top and bottom of the carrier frame mounting tubes. To check the bushings, move the caster forks back and forth and side-to-side. If a caster fork is loose, the bushings are worn and must be replaced.

1. Raise the cutting unit so the caster wheels are off the floor, then block up the front of the mower with jack stands.
2. Remove the locking pin and spacer(s) from the top of the caster wheel fork (Fig. 69).
3. Pull the caster wheel fork out of the mounting tube, leaving the spacer(s) on the bottom of the fork. Remember the location of the spacers on each fork to ensure correct installation, and to maintain a level deck.

4. Insert a pin punch into the mounting tube and carefully drive out the bushings (Fig. 70). Clean the inside of the mounting tube.
5. Grease the inside and outside of the new bushings. Use a hammer and flat plate to carefully drive the bushings into the mounting tube.
6. Inspect the caster wheel fork for wear and replace if necessary (Fig. 69).
7. Slide the caster wheel fork through the bushings in the mounting tube. Replace the spacer(s) onto the fork and secure with the retaining ring (Fig 69).

Important The inside diameter of the bushings may collapse slightly when installed. If the caster wheel fork does not slide into the new bushings, ream both bushings to an inside diameter of 1.126 inch (29 mm).

8. Grease the fitting on the carrier frame mounting tube using No. 2 general purpose lithium base or molybdenum base grease.




Figure 70

1. Mounting Tube	2. Bushing
------------------	------------

Caster Wheel and Bearings Service

The caster wheels rotate on a roller bearing supported by a spanner bushing. If the bearing is kept well lubricated, wear will be minimal. Failure to keep the bearing well lubricated will cause rapid wear. A wobbly caster wheel usually indicates a worn bearing.

1. Remove the locknut and wheel bolt holding the caster wheel to the caster fork (Fig. 71).
2. Remove one bushing, then pull the spanner bushing and roller bearing out of the wheel hub (Fig. 71).
3. Remove the other bushing from the wheel hub and clean any grease and dirt from the wheel hub (Fig. 71).
4. Inspect the roller bearing, bushings, spanner bushing and inside of the wheel hub for wear. Replace any defective or worn parts (Fig. 71).




Figure 71

- 1. Locknut
- 2. Wheel Bolt
- 3. Bushing
- 4. Spanner Bushing
- 5. Roller Bearing

5. To assemble, place one bushing into the wheel hub. Grease the roller bearing and spanner bushing and slide them into the wheel hub. Place the second bushing into the wheel hub (Fig. 71).
6. Install the caster wheel into the caster fork and secure with the wheel bolt and locknut. Tighten the locknut until the spanner bushing bottoms against the inside of the caster forks (Fig. 71).
7. Grease the fitting on the caster wheel.

Replacing the Grass Deflector



Warning



An uncovered discharge opening could allow the lawn mower to throw objects in the operator's or bystander's direction and result in serious injury. Also, contact with the blade could occur.

Never operate the lawn mower unless you install a cover plate, a mulch plate, or a grass chute and catcher.

1. Remove the locknut, bolt, spring and spacer holding the deflector to the pivot brackets (Fig. 72). Remove damaged or worn grass deflector.
2. Place spacer and spring onto grass deflector. Place the **L** end of spring behind deck edge.

Note: Make sure the **L** end of spring is installed behind deck edge before installing the bolt as shown in figure 72.

3. Install bolt and nut. Place the **J** hook end of spring around grass deflector (Fig. 72).

Important The grass deflector must be able to rotate. Lift the deflector up to the full open position and ensure that it rotates into the full down position.






Figure 72

- 1. Bolt
- 2. Spacer
- 3. Locknut
- 4. Spring
- 5. Spring installed
- 6. Grass Deflector
- 7. **L** end of spring, place behind deck edge before installing bolt
- 8. **J** hook end of spring

Wiring Diagram



Cleaning and Storage

1. Disengage the power take off (PTO), set the parking brake, and turn the ignition key to **off**. Remove the key.
2. Remove grass clippings, dirt, and grime from the external parts of the entire machine, especially the engine. Clean dirt and chaff from the outside of the engine's cylinder head fins and blower housing.

Important You can wash the machine with mild detergent and water. Do not pressure wash the machine. Avoid excessive use of water, especially near the shift lever plate, and engine.

3. Check the brake; refer to Servicing the Brake, page 34.
4. Service the air cleaner; refer to Servicing the Air Cleaner, page 27.
5. Grease the machine; refer to Greasing and Lubrication, page 30.
6. Change the crankcase oil; refer to Servicing the Engine Oil, page 28.
7. Check the tire pressure; refer to Tire Pressure, page 32.
8. For long-term storage (more than 90 days) add stabilizer/conditioner additive to fuel in the tank.

- A. Run engine to distribute conditioned fuel through the fuel system (5 minutes).
- B. Stop engine, allow to cool and drain the fuel tank; refer to Draining the Fuel Tank, page 33, or operate engine until it stops.
- C. Restart engine and run until it stops. Repeat, on Choke until engine will not restart.
- D. Dispose of fuel properly. Recycle as per local codes.

Note: Do not store stabilizer/conditioned gasoline over 90 days.

9. Remove the spark plug(s) and check its condition; refer to Servicing the Spark Plug Service, page 29. With the spark plug(s) removed from the engine, pour two tablespoons of engine oil into the spark plug hole. Now use the starter to crank the engine and distribute the oil inside the cylinder. Install the spark plug(s). Do not install the wire on the spark plug(s).
10. Check and tighten all bolts, nuts, and screws. Repair or replace any part that is damaged or defective.
11. Paint all scratched or bare metal surfaces. Paint is available from your Authorized Service Dealer.
12. Store the machine in a clean, dry garage or storage area. Remove the key from the ignition switch and keep it in a memorable place. Cover the machine to protect it and keep it clean.

Troubleshooting

PROBLEM	POSSIBLE CAUSES	CORRECTIVE ACTION
Engine will not start, starts hard, or fails to keep running.	<ol style="list-style-type: none">1. Fuel tank is empty.2. Choke is not ON.3. Air cleaner is dirty.4. Spark plug wire is loose or disconnected.5. Spark plug is pitted, fouled, or gap is incorrect.6. Dirt in fuel filter.7. Dirt, water, or stale fuel is in fuel system.8. Shift lever plate out of adjustment.	<ol style="list-style-type: none">1. Fill fuel tank with gasoline.2. Move throttle lever to choke position.3. Clean or replace air cleaner element.4. Install wire on spark plug.5. Install new, correctly gapped spark plug.6. Replace fuel filter.7. Contact Authorized Service Dealer.8. Adjust shift lever plate to match shift lever neutral position.

PROBLEM	POSSIBLE CAUSES	CORRECTIVE ACTION
Engine loses power.	<ol style="list-style-type: none"> 1. Engine load is excessive. 2. Air cleaner is dirty. 3. Oil level in crankcase is low. 4. Cooling fins and air passages under engine blower housing are plugged. 5. Spark plug is pitted, fouled, or gap is incorrect. 6. Vent hole in fuel cap is plugged. 7. Dirt in fuel filter. 8. Dirt, water, or stale fuel is in fuel system. 	<ol style="list-style-type: none"> 1. Reduce ground speed. 2. Clean air cleaner element. 3. Add oil to crankcase. 4. Remove obstruction from cooling fins and air passages. 5. Install new, correctly gapped spark plug. 6. Clean or replace the fuel cap. 7. Replace fuel filter. 8. Contact Authorized Service Dealer.
Engine overheats.	<ol style="list-style-type: none"> 1. Engine load is excessive. 2. Oil level in crankcase is low. 3. Cooling fins and air passages under engine blower housing are plugged. 	<ol style="list-style-type: none"> 1. Reduce ground speed. 2. Add oil to crankcase. 3. Remove obstruction from cooling fins and air passages.
Machine does not drive.	<ol style="list-style-type: none"> 1. Shift lever is in NEUTRAL. 2. Traction belt is worn, loose or broken. 3. Traction belt is off pulley. 4. Broken or missing idler spring. 5. Traction control rod contacting the end of the neutral/parking brake slot 	<ol style="list-style-type: none"> 1. Move shift lever to a drive gear position. 2. Change Belt. 3. Change Belt. 4. Replace spring 5. Adjust the traction control rod
Abnormal vibration.	<ol style="list-style-type: none"> 1. Cutting blade(s) is/are bent or unbalanced. 2. Blade mounting bolt is loose. 3. Engine mounting bolts are loose. 4. Loose engine pulley, idler pulley, or blade pulley. 5. Engine pulley is damaged. 6. Blade spindle bent. 	<ol style="list-style-type: none"> 1. Install new cutting blade(s). 2. Tighten blade mounting bolt. 3. Tighten engine mounting bolts. 4. Tighten the appropriate pulley. 5. Contact Authorized Service Dealer. 6. Contact Authorized Service Dealer.

PROBLEM	POSSIBLE CAUSES	CORRECTIVE ACTION
Uneven cutting height.	1. Blade(s) not sharp. 2. Cutting blade(s) is/are bent. 3. Mower is not level. 4. Underside of mower is dirty. 5. Tire pressure is incorrect. 6. Blade spindle bent.	1. Sharpen blade(s). 2. Install new cutting blade(s). 3. Level mower from side-to-side and front-to-rear. 4. Clean the underside of the mower. 5. Adjust tire pressure. 6. Contact Authorized Service Dealer.
Blades do not rotate.	1. PTO Drive belt is worn, loose or broken. 2. PTO Drive belt is off pulley. 3. Deck belt is worn, loose or broken. 4. Deck belt is off pulley. 5. Broken or missing idler spring.	1. Install new drive belt. 2. Install drive belt and check adjusting shafts and belt guides for correct position. 3. Install new deck belt. 4. Install deck pulley and check the idler pulley, idler arm and spring for correct position and function. 5. Replace idler spring



LCE

The Toro Total Coverage Guarantee

A Limited Warranty

Conditions and Products Covered

The Toro Company and its affiliate, Toro Warranty Company, pursuant to an agreement between them, jointly promise to repair the listed Toro Products if defective in materials or workmanship. The following time periods apply from the date of purchase:

<u>Products</u>	<u>Warranty Period</u>
• All Products	1 year
• All Spindles	2 years parts and labor; third year, parts only
• Engines/Hydraulic Systems* on the following: Outfront and Mid-Mount Z's ProLine Mid-Size Mowers Groundsmaster® Riding Mowers Backpack Blowers	2 years
• Deck Shells (36"-72") on the following: ProLine Mid-Size Mowers Mid-Mount Z's	2 years
• Electric Clutch on 500 Series Mid-Mount Z's	2 years

This warranty includes the cost of parts and labor, but you must pay transportation costs.

This warranty applies to:

- Outfront and Mid-Mount Z's
- ProLine Mid-Size Mowers
- Groundsmaster Riding Mowers
- Turf Maintenance Equipment
- Debris Management Equipment

* Some engines used on Toro LCE Products are warranted by the engine manufacturer.

Instructions for Obtaining Warranty Service

If you think that your Toro Product contains a defect in materials or workmanship, follow this procedure:

1. Contact any Toro Authorized or Master Service Dealer to arrange service at their dealership. To locate a dealer convenient to you, access our website at www.Toro.com. U.S. Customers may also call 800-348-2424.
2. Bring the product and your proof of purchase (sales receipt) to the Service Dealer.

If for any reason you are dissatisfied with the Service Dealer's analysis or with the assistance provided, contact us at:

LCB Customer Service Department
Toro Warranty Company
8111 Lyndale Avenue South
Bloomington, MN 55420-1196
888-577-7466 (U.S. customers)
877-484-9255 (Canada customers)

Owner Responsibilities

You must maintain your Toro Product by following the maintenance procedures described in the operator's manual. Such routine maintenance, whether performed by a dealer or by you, is at your expense.

Items and Conditions Not Covered

There is no other express warranty except for special emission system coverage on some products. This express warranty does not cover the following:

- Cost of regular maintenance service or parts, such as filters, fuel, lubricants, tune-up parts, blade sharpening, brake and clutch adjustments.
- Any product or part which has been altered or misused or required replacement or repair due to normal wear, accidents, or lack of proper maintenance.
- Repairs necessary due to improper fuel, contaminants in the fuel system, or failure to properly prepare the fuel system prior to any period of non-use over three months.
- Pickup and delivery charges.

All repairs covered by this warranty must be performed by an Authorized Toro Service Dealer using Toro approved replacement parts.

General Conditions

Repair by an Authorized Toro Service Dealer is your sole remedy under this warranty.

Neither The Toro Company nor Toro Warranty Company is liable for indirect, incidental or consequential damages in connection with the use of the Toro Products covered by this warranty, including any cost or expense of providing substitute equipment or service during reasonable periods of malfunction or non-use pending completion of repairs under this warranty.

Some states do not allow exclusions of incidental or consequential damages, or limitations on how long an implied warranty lasts, so the above exclusions and limitations may not apply to you.

All implied warranties of merchantability (that the product is fit for ordinary use) and fitness for use (that the product is fit for a particular purpose) are limited to the duration of the express warranty.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Countries Other than the United States or Canada

Customers who have purchased Toro products exported from the United States or Canada should contact their Toro Distributor (Dealer) to obtain guarantee policies for your country, province, or state. If for any reason you are dissatisfied with your Distributor's service or have difficulty obtaining guarantee information, contact the Toro importer. If all other remedies fail, you may contact us at Toro Warranty Company.