



Count on it.

Form No. 3484-121 Rev A

Parts Catalog

TRX-300 Trencher

Model No. 22984—Serial No. 421100000 and Up



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Frame Assembly..... 4

Control Tower and Fuel Tank Assembly 6

Track Assembly 8

Brake Linkage Assembly..... 10

Engine and Muffler Assembly..... 12

Hydraulic Assembly 14

Valve Assembly No. 145-3263..... 16

Valve Inlet Section Assembly No. 139-1337 18

Valve Inlet Section Assembly No. 139-1338 20

Series Valve Section Assembly No. 139-1339 22

Parallel Valve Section Assembly No. 139-1344 24

Series Valve Section Assembly No. 139-1345 26

Parallel Valve Section Assembly No. 139-1346 28

Outlet Section Assembly No. 139-1347 30

Oil Cooler Assembly 32

Trencher Head and Lift Assembly 34

Hydraulic Cylinder Assembly No. 137-3827 36


Control Assembly 38

Electrical Assembly 40

Wire Harness Assembly No. 137-7624..... 42

Attachments and Accessories 44


Frame Assembly



Frame Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	137-7628	1	Main Frame ASM	8	140-1146	5	Nut-Clip, U
1:2	100-4650	1	Decal-Warning	9	137-7623-05	1	Plate-Cover, Front
1:3	93-7814	2	Decal-Danger	10	33105-040	3	Screw-HHF
1:4	93-6686	1	Decal-Oil, HYD	11	140-1144	5	Nut-Push
1:6	138-7103	1	Decal-Intellitrench	12	323-12	1	Screw-HH
2	114-3075	1	Sight Glass ASM	13	32128-40	2	Nut-Flange
2:1	237-79	1	O-Ring	14	119-5106-01	1	Cover-Rear
3	354-120	1	Fitting-Elbow, 90	15	108-1531	2	Screw-HHF
3:1	237-79	1	O-Ring	16	119-5091-01	1	Bracket-Tank
4	114-3039	1	Filter-Tank, In	17	117-6417	1	Pad-Foam
5	104-7201	2	Nut-HF, NI	18	321-5	2	Screw-HH
6	1-523420	1	Bumper	19	133-7659	1	Plug ASM W/Magnet
7	32128-33	1	Nut-HF	19:1	237-79	1	O-Ring


Control Tower and Fuel Tank Assembly



Control Tower and Fuel Tank Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
2	137-4119	1	Cap-Fuel, Ratcheting	21	256-257	2	Bushing-Nyliner
3	137-3795	1	Cover-Handle, Traction	22	105-1217	1	Decal
3:2	138-7107	1	Decal-Traction	23	119-4042	2	Nut-HF, NI
4	3234-11	10	Screw-HHF	24	85-6750	1	Spring-Control
5	137-7654-01	1	Plate-Cover, Access	25	119-5086-01	1	Bracket-Cover, Tank
6	137-7641	1	Bar-Reference	26	133-8062	1	Decal-Spark Arrestor
7	3290-307	1	Pin-Cotter	28	138-7154	1	Decal-Fuse
8	88-7200	1	Washer-Flat	29	137-3799	1	Cover-Control
9	114-8727	1	Rod-Interlock	29:2	138-7106	1	Decal-Panel, Control
10	95-1726	4	Screw-Taptite	30	120-7359	1	Tank-Fuel
11	3234-5	3	Screw-HHF	30:1	103-2605	1	Fitting-Fuel, Bulkhead
12	3234-47	2	Screw-HHF	31	114-0284	1	Grommet
13	119-4041	2	Nut-HF	32	119-3547	1	Valve-Vent, Fuel
14	32128-40	8	Nut-Flange	33	104-7050	1	Tube-Manual
15	137-3794	1	Control Tower ASM	34	104-7048	1	Cap-Housing
15:2	137-3839	1	Decal-Side, LH	35	2412-120	2	Clamp-R
15:4	107-8495	1	Decal-Brake, Parking	36	3269-17	2	Rivet-Pop
15:5	139-1271	1	Decal-Brake, Parking	37	94-2413	5	Nut-U
16	137-7652-05	1	Plate-Reverse [blk-Txt]	39	139-1259-05	1	Guard-Tower
17	114-1337	2	Spacer-Spring	40	105-4886	2	Nut-Tinnerman
18	98-8425	1	Spring-Torsion, LH	41	107-3154	2	Nut-Push
19	137-7695	1	Spring-Torsion	42	139-1288-05	1	Spacer-Cover
20	323-11	2	Screw-HH	43	3234-17	4	Screw-HHF

Track Assembly




Track Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	114-2993-05	1	RH Track Frame ASM	16	32128-49	4	Nut-HHF
2	138-3139	12	Tensioner Wheel ASM	17	114-3091	2	Bar-Thread
2:1	138-7118	1	Wheel-Track	18	117-6426-05	2	Wheel-Drive (Machined)
2:2	120-5378	1	Bearing-Ball	19	106-8159	2	Nut-Hex Jam Lck
3	106-7585	12	Gasket-Bogie	20	112-4816	2	Track-Rubber
4	327-4	12	Screw-HH	21	137-3866	2	Wheel Motor ASM
5	106-7557	12	Cap-Wheel, Bearing	21:1	161-7208	1	Seal Kit
6	106-7595	12	Ring-Snap, Internal	21:1:1	161-7209	1	Seal, Grease ●
7	114-3077-05	2	Tensioner-Track, (Machined)	21:1:2	161-7210	1	Shell, Bearing ●
8	3256-26	4	Washer-Flat	21:1:3	161-7211	3	O-Ring ●
9	325-8	4	Screw-HH	21:1:4	161-7212	1	Shaft Seal (HP) ●
10	3296-45	4	Nut-Hex	21:1:5	161-7213	2	Back-Up Ring ●
11	112-4874	2	Screw-HH, TAP	21:1:6	161-7214	1	O-Ring ●
12	3217-11	2	Nut-Hex	22	340-6	4	Fitting-Straight
13	325-10	8	Screw-HH	22:1	237-30	1	O-Ring
14	114-2992-05	1	LH Track Frame ASM	22:2	237-80	1	O-Ring
15	3234-6	10	Screw-HHF	23	3296-23	8	Nut-Lock, NI

● Not illustrated

Brake Linkage Assembly




Brake Linkage Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	1-633131	1	Yoke-Linkage, Brake
2	7-0030	1	Screw-Shoulder, HH
3	27-7211	1	Screw-Shoulder
4	28-0540	1	Bolt-Shoulder
5	132-4749	1	Grip-Lever
6	67-1450	1	Spring-Idler
7	119-4041	1	Nut-HF
8	114-2975	1	Link-Mounting

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
9	114-8629	1	Bolt-Shldr
10	121-6240-05	1	Brake Bar ASM [blk-Txt]
11	121-6242-05	1	Brake Handle ASM
12	121-6243	1	Rod-Threaded
13	121-6245-05	1	Plate-Brake
14	3219-3	3	Nut-Hex
15	3296-47	2	Nut-Lock,NI
16	32128-20	1	Nut-HF

Engine and Muffler Assembly



Engine and Muffler Assembly (continued)


<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	161-9428	1	Engine-Kohler, Ps-Ecv749-3077 ■
2	3256-21	2	Washer-Flat
3	110-5547	1	Lever-Control
4	137-7691	1	Shield-Heat
5	115-6488	1	Clamp
6	115-6494	1	Screw-Pan
7	115-6495	1	Nut-Hex
8	109-0295	1	Hose-Fuel
9	2412-98	4	Clamp-Hose
10	138-7138	1	Muffler-Kohler
11	139-1310-05	1	Guard-Muffler [blk-Txt]
12	131-0604	1	Guard-Foil
13	1-603770	1	Valve-Fuel
14	109-0304	1	Hose-Fuel
15	3290-134	2	Screw
16	120-4578	2	Nut-HF
17	32128-20	3	Nut-HF
18	322-6	3	Screw-HH

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
19	233-42	1	Knob
20	115-1211	1	Cable-Control
21	116-5316	1	Oil Drain Hose ASM
21:2	353-508	1	Plug-HH ●
21:2:1	237-42	1	O-Ring
22	138-3101-05	1	Bracket-Muffler
23	32128-26	5	Nut-HF
24	322-3	5	Screw-HH
25	32144-102	4	Screw-HWH
26	104-7201	3	Nut-HF, NI
27	3234-4	1	Screw-HHF
28	2412-106	1	Clamp-R
29	321-4	2	Screw-HH
30	139-1335-05	1	Bracket-Guard, Muffler
31	121-0780	1	Hose-Fuel
35	138-7139	1	Manifold-Kohler
36	2112-11	1	Clamp-Muffler
37	139-1322	1	Guard-Foil

● Torque to 24-26 ft-lb

■ Obtain parts from www.kohlerplus.com


Hydraulic Assembly



Hydraulic Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	117-6306	1	Hydraulic Motor ASM	27	100-4860	1	Bracket-Clamp
2	340-6	2	Fitting-Straight	28	99-5648	2	Sleeve-Protective
2:1	237-30	1	O-Ring	30	87-8170	1	Fitting-90
2:2	237-80	1	O-Ring	30:1	237-80	1	O-Ring
3	325-6	2	Screw-HH	31	2412-129	2	Clamp-Hose
4	94-8105	6	Clamp-Tube	32	93-5023	1	Spacer
5	137-7630	1	Pump-HYD	33	130-8775	1	Fitting-HYD
6	144-7474	2	Hose ASM-HYD	33:1	237-80	1	O-Ring
7	137-7634-05	1	Pump-Mount [blk-Txt]	33:2	237-30	2	O-Ring
8	138-7126	2	Fitting-STR	34	145-3263	1	Valve ASM
8:1	237-81	1	O-Ring	35	340-98	3	Fitting-Elbow, 90 DEG
9	354-79	2	Cap-Dust	35:1	237-79	1	O-Ring
10	324-4	2	Screw-HH	35:2	237-30	1	O-Ring
11	340-101	3	Fitting-HYD, 45 DEG	36	138-7100	1	Hub-Flex (1.125" Shaft)
11:1	237-30	1	O-Ring	36:1	105-4068	2	Screw-Set, Cphs
11:2	237-79	1	O-Ring	37	340-157	1	Fitting-HYD, Tee
12	322-11	3	Screw-HH	37:1	237-79	1	O-Ring
13	3334-945	11	Tie-Cable	37:2	237-30	2	O-Ring
14	114-2933	1	Coupler-Flex	39	144-7470	2	Hose ASM-HYD
14:1	105-4068	1	Screw-Set, Cphs	40	137-7698	1	HYD Tube ASM
15	93-8827	1	Coupler-Spider	41	137-3724	1	HYD Tube ASM
16	608006	1	Key-Square	42	161-6877	1	Hose ASM-HYD
17	32128-20	4	Nut-HF	43	144-7472	1	Hose ASM-HYD
18	138-7128	1	Hose-Suction, HYD	44	68-9410	3	Screw-HHF
19	2412-130	2	Clamp-Hose	45	99-6160	2	Fitting-Elbow, 90 Long
20	115-4064	1	Sleeve-Protective	45:1	237-30	1	O-Ring
21	144-7473	2	Hose ASM-HYD	45:2	237-79	1	O-Ring
22	3290-379	1	Tie-Cable	46	137-3736-05	1	Bracket-Hose Support
23	322-4	2	Screw-HH	47	100-5616	2	Fitting
24	69-9761	3	Plate-Cover	48	2412-36	2	Clamp-Hose
25	322-10	1	Screw-HH	49	137-3733	1	Hose-Cooler
26	340-87	2	Fitting-Elbow, 45 DEG	50	114-3042	1	Hose-Breather
26:1	237-22	1	O-Ring	51	68-6150	1	Breather
26:2	237-42	1	O-Ring	52	3253-7	2	Washer-Lock

Valve Assembly No. 145-3263




LEVER BOX GASKET SERVICE

Valve Assembly No. 145-3263 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	139-1337	1	Section-Inlet
2	139-1338	1	Section-Inlet
3	139-1339	1	Section-Valve, Series
4	139-1340	1	Block-Manifold
5	139-1341	1	Valve-Directional, Unloading
6	139-1342	1	Valve-Relief
7	139-1343	1	Plug-Orifice
8	139-1344	1	Section-Valve, Parallel
9	139-1345	1	Section-Valve, Series
10	139-1346	1	Section-Valve, Parallel

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
11	139-1347	1	Section-Outlet
12	139-1348	5	Screw-HSH
13	139-1349	3	Screw-HSH
14	131-3807	5	Plug
15	131-3806	1	Plug
16	140-1100	4	Plug-Expansion
17	140-1101	12	O-Ring
18	145-3264	1	Screw-HSH
19	161-7271	4	Gasket Seal

Valve Inlet Section Assembly No. 139-1337




Valve Inlet Section Assembly No. 139-1337 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	140-1102	1	Inlet
2	132-6039	1	Valve-Relief

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
3	140-1103	1	Plug
4	140-1104	1	Plug

Valve Inlet Section Assembly No. 139-1338




Valve Inlet Section Assembly No. 139-1338 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	140-1102	1	Inlet
2	132-6039	1	Valve-Relief

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
3	140-1103	1	Plug
4	140-1104	1	Plug


Series Valve Section Assembly No. 139-1339



Series Valve Section Assembly No. 139-1339 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	140-1109	1	Section-Working	2	140-1105	1	Valve-Spool
1:1	140-1114	6	O-Ring	3	140-1110	1	Kit-Control
1:2	106-7719	2	Seal-Valve	4	140-1107	1	Lever-Valve
1:3	140-1116	2	Seal-Valve	5	140-1108	2	Plug
1:4	140-1117	2	Seal-Valve				


Parallel Valve Section Assembly No. 139-1344



Parallel Valve Section Assembly No. 139-1344 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	140-1115	1	Section-Working	2	140-1105	1	Valve-Spool
1:1	140-1114	6	O-Ring	3	140-1106	1	Kit-Control
1:2	106-7719	2	Seal-Valve	4	140-1107	1	Lever-Valve
1:3	140-1116	2	Seal-Valve	5	140-1108	2	Plug
1:4	140-1117	2	Seal-Valve				

Series Valve Section Assembly No. 139-1345




Series Valve Section Assembly No. 139-1345 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	140-1118	1	Section-Working
1:1	140-1114	6	O-Ring
1:2	106-7719	2	Seal-Valve
1:3	140-1116	2	Seal-Valve
1:4	140-1117	2	Seal-Valve

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
2	140-1107	1	Lever-Valve
3	140-1108	2	Plug
4	140-1105	1	Valve-Spool
5	140-1106	1	Kit-Control


Parallel Valve Section Assembly No. 139-1346



Parallel Valve Section Assembly No. 139-1346 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	140-1115	1	Section-Working	2	140-1105	1	Valve-Spool
1:1	140-1114	6	O-Ring	3	140-1106	1	Kit-Control
1:2	106-7719	2	Seal-Valve	4	140-1107	1	Lever-Valve
1:3	140-1116	2	Seal-Valve	5	140-1108	2	Plug
1:4	140-1117	2	Seal-Valve				


Outlet Section Assembly No. 139-1347



Outlet Section Assembly No. 139-1347 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	140-1112	1	Cover-Outlet
2	140-1111	1	Plug
3	140-1114	6	O-Ring


Oil Cooler Assembly



Oil Cooler Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	3290-379	3	Tie-Cable	10	119-4633-01	1	Cover-Cooler
2	115-9240-01	1	Mount-Cooler	11	32104-95	4	Screw-HWH
3	120-7390	2	Fan	12	138-3131	1	Hose-Return
4	321-3	8	Screw-HH	13	AU112950	1	Protector-Hose
5	104-7201	12	Nut-HF, NI	14	115-5103	4	Screw-HHF
6	26-4840	4	Spacer-Pin, Mounting	15	119-4041	4	Nut-HF
7	131-0642	4	Plate-Support, Clamp	16	322-11	4	Screw-HH
8	131-0733	8	Clamp	17	2412-129	2	Clamp-Hose
9	117-6320	1	Cooler-Oil				

Trencher Head and Lift Assembly




Trencher Head and Lift Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	137-3827	1	Hydraulic Cylinder ASM
2	117-6423	1	Trencher Head ASM
2:2	99-9952	2	Decal-Danger
3	120-7352	2	Pin-Pivot
4	321-18	2	Screw-HH
5	104-7201	2	Nut-HF, NI
6	302-5	4	Fitting-Grease
7	121-4571	1	Spacer-Pivot
8	104-9216	2	Washer-Hardened
9	117-6327	1	Bolt-HH
10	3296-53	1	Nut-Lock, NI
11	302-34	1	Fitting-Lube
12	115-1279-05	1	Bracket-Shield
13	322-5	8	Screw-HH
14	119-4041	11	Nut-HF
15	322-23	1	Screw-HH
16	3256-3	4	Washer-Flat
17	117-6317	1	Shield-Dirt
18	115-4001-05	1	Plate-Strap,Shield
19	117-6316-05	1	Bar-Clamp
20	115-4049	2	Screw-HSH
21	106-8871	1	Bearing-Ball

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
22	114-2955	1	Seal-Grease
23	117-6308	1	Shaft-Trencher
24	112-4979	1	Spacer
25	111199	1	Bearing-Ball
26	114-2956	1	Lockwasher-Bearing
27	88-1450	1	Locknut-Bearing
28	117-6315	1	Collar-Splined
29	104-1964	1	Sprocket-Trencher
30	3274-4	6	Screw-HSH
31	137-3737-05	1	Trencher Auger ASM (Welded)
32	325-13	1	Screw-HH
33	117-3479	2	Washer-Saddle
34	3296-23	1	Nut-Lock, NI
36	340-77	1	Fitting-Elbow, 90 DEG
36:1	237-22	1	O-Ring
36:2	237-42	1	O-Ring
37	115-4081	1	Valve-Check
37:1	237-42	1	O-Ring
37:2	237-22	1	O-Ring
38	147-6707	2	Decal-Lift, Tie Down

Hydraulic Cylinder Assembly No. 137-3827




Hydraulic Cylinder Assembly No. 137-3827 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	140-3110	1	Kit-Seal
2	138-7141	1	Nut-Hex

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
3	138-7142	1	Head-Cylinder
4	138-7143	1	Piston


Control Assembly



Control Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	140-5764-05	1	Handle-Traction, LH [blk-Txt]	20	95-4256	1	Spring-Compression
2	139-1306	1	Lever-Lift	21	137-3061	2	Bolt-CARR
3	137-7651	1	Lever-Auxiliary	24	139-1307	4	Grip
4	137-7649	1	Lever-Drive, Chain	26	107-3395	1	Washer-Hardened
5	138-3168	1	Grip	27	140-5765-05	1	Handle-Traction, RH [blk-Txt]
6	112-2738	1	Spring-Torsion	28	139-1314	2	Damper
7	233-21	1	Knob	29	139-1321	2	Spring-Compression
8	3296-42	1	Nut-Lock, NI	30	139-1323	2	Washer-Spcl
9	3256-16	1	Washer-Flat	31	139-1299-05	1	Bracket-Damper
10	33114-035	4	Screw-HH	32	139-1316	1	Rod-Damper
11	33024-00	4	Nut-Lock, NI	33	139-1315	2	Stud-Ball
12	256-257	1	Bushing-Nyliner	34	3245-3	2	Screw-Set, Hs
13	138-3123-05	1	Plate-Bushing	35	3218-1	2	Nut-Jam
14	322-4	4	Screw-HH	36	104-7201	4	Nut-HF, NI
15	119-4041	6	Nut-HF	37	140-1122	2	Fitting-Clevis
16	116-1393	2	Bushing	38	3256-23	1	Washer-Plain
17	138-3124	1	Bracket-Lever	39	140-5767	1	Bracket-Valve
18	138-7163	1	Rod-Lockout	40	68-9410	1	Screw-HHF
19	3272-4	1	Pin-Cotter				


Electrical Assembly



Electrical Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	137-7624	1	Harness-Wire	15:2	122-0633	1	Washer-Locking
2	99-7430	2	Relay-Mini	15:3	122-0632	1	Nut-Fixing
3	100-1268	1	Switch-Plunger	17	32105-13	4	Screw-HWH
4	138-3133	1	Cable-Battery, Negative	18	138-3114-05	1	Tray-Battery [blk-Txt]
5	3296-2	4	Nut-Lock, NI	19	3234-6	2	Screw-HHF
6	120-2244	1	Hourmeter	20	32128-49	2	Nut-HHF
7	138-3104-05	1	Bracket-Electrical	21	62-4300	1	Pad-Skid, Anti
8	63-8360	1	Key-Ignition	22	104-8162	1	Battery
9	3255-7	1	Washer-Lock/EXT	24	138-3134	1	Cable-Battery, Positive
13	98-7249	1	Relay	26	322-3	2	Screw-HH
14	88-9830	1	Key Switch ASM	27	3256-2	2	Washer-Flat
14:1	3254-5	1	Washer-Lock	28	32149-1	2	Nut-Keps
14:2	218-461	1	Nut-HH	29	115-6621-05	1	Plate-Hold Down,Battery
15	122-0630	1	Red LED Indicator Lamp ASM	30	1-633651	2	Bolt-Holddown
15:1	122-0634	1	Gasket-LED	31	32103-22	2	Nut-Wing
				47	138-7155	1	Decal-Service

Wire Harness Assembly No. 137-7624



Wire Harness Assembly No. 137-7624 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	218-578	2	Fuse-Blade, 10 Amp
2	109355	2	Fuse-Blade, 15 Amp
3	109103	1	Fuse-Blade, 30 Amp

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
4	116-0053	1	Cap-Plug
11	32180-019	1	Cover-Fuse, Single
14	121-8891	1	Resistor (1.6K Ohm)

Attachments and Accessories

For 22984 — TRX-300 Trencher

Product Name	Model/Part
8in Chain Conversion Kit for 36in Soil Chain	117-3480
PX Hydraulic Fluid (5 Gal)	133-8086
PX Hydraulic Fluid (55 Gal).....	133-8087
Oil-30/10W-30 Synthetic (Quart).....	138-6053
PX Hydraulic Fluid-4 Pack (Gallon).....	138-9460
Kit-Spare Tire and Mount.....	164-1449
Crumber Kit	22477
24in X 4in Soil Chain.....	22480
24in X 4in Combination Chain	22481
24in X 4in Rock Tooth Chain.....	22482
24in X 6in Soil Chain.....	22483
24in X 6in Combination Chain	22484
24in X 6in Rock Tooth Chain.....	22485
36in X 4in Soil Chain.....	22486
36in X 4in Combination Chain	22487
36in X 4in Rock Tooth Chain.....	22488
36in X 6in Rock Tooth Chain.....	22489
36in X 6in Soil Chain.....	22490
36in X 6in Combination Chain	22491
48in x 4in Soil Chain	22492
48in x 4in Combination Chain	22493
48in x 6in Soil Chain	22494
48in x 6in Combination Chain	22495
24in X 4in Bullet Chain.....	22496
24in X 6in Bullet Chain.....	22497
36in X 4in Bullet Chain.....	22498
36in X 6in Bullet Chain.....	22499
24in Trencher Boom	22975
36in Trencher Boom	22976
48in Trencher Boom	22977
Bore Drive Attachment.....	22978
Trailer, TRX Trencher or STX Stump Grinder.....	22979
Backfill Blade	22980
Toro Red 12oz Aerosol Can	361-10
New Red Paint - Gallon	361-11
Semi-Gloss Black Spray Paint	361-9
10W30 4-Cycle Engine Oil (32oz Bottle).....	38280
Spark Arrestor Screen	94-8157

Notes:

Notes:

Notes:



Count on it.