



Super Recycler[®] Lawn Mower

Model No. 20053 - 250000001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Description	Page	Description	Page
Housing Assembly	 3	Air Cleaner Assembly Briggs and Stratton	
Housing Assembly No. 108-4750	 4	125K02-0189-E1	 12
Height-Of-Cut Assembly	 5	Governor Assembly Briggs and Stratton	
Engine Assembly	 6	125K02-0189-E1	 13
Handle Assembly	 7	Muffler and Fuel Tank Assembly Briggs and Stratton	
Cylinder Assembly Briggs and Stratton		125K02-0189-E1	 14
125K02-0189-E1	 8	Blower Housing Assembly Briggs and Stratton	
Crankshaft Assembly Briggs and Stratton		125K02-0189-E1	 15
125K02-0189-E1	 9	Starter Assembly Briggs and Stratton	
Crankcase Assembly Briggs and Stratton		125K02-0189-E1	 16
125K02-0189-E1	 10	Engine Gasket Set Assembly Briggs and Stratton	
Carburetor Assembly Briggs and Stratton		125K02-0189-E1	 17
125K02-0189-E1	 11	Carburetor Overhaul Kit and Gasket Set Assemblies Briggs and Stratton	
		125K02-0189-E1	 18


Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

AR. as required	HWHTF. hex washer head thread forming
ASM. assembly	HYD. hydraulic
BBC. Blade Brake Clutch	INC. incorporated
CARR. carriage	LH. left hand
DEG. degrees	NI. nylon insert
EXT. external	NPTF. national pipe thread fine
FH. flat head	PPH. phillips pan head
GA. gauge	PPHTF. phillips pan head thread forming
HF. hex flange	PRH. phillips round head
HH. hex head	PTH. phillips truss head
HHF. hex head flange	PTO. power take off
HHFTF. hex head flange thread forming	RH. right hand
HJ. hex jam	ROPS. roll over protection system
HLH. hex lag head	SFH. slotted fillister head
HOC. height-of-cut	SHH. slotted hex head
HSBH. hex socket button head	SHWH. slotted hex washer head
HSFH. hex socket flat head	SPH. slotted pan head
HSH. hex socket head	SQH. square head
HWH. hex washer head	


Footnotes

- ❶ Obtain parts from your local Briggs & Stratton dealer ❷ For use only on Models with BBC




Housing Assembly

Ref	Part No.	Qty.	Description				
1	105-1323	1	Rear Door ASM				
1:2	105-1295	1	Decal-Warning				
2	49-2040	6	Screw-TAP				
3	3290-337	1	Nut-Speed				
4	107-7493	2	Plate-Support, Door				
5	107-7490	1	Plug-Mulch				
6	105-3032	1	Spring-Door, Rear				
7	107-7496	1	Shield-Trailing				
9	107-7494	1	Cover-Belt				
10	107-7499	1	Rod-Support, Door				
11	107-3717	1	Discharge Door ASM				
11:2	107-0795	1	Latch-Door				
11:3	107-7456	1	Cap-Door				
11:4	107-7461	1	Screw-Plastite				
12	3229-11	2	Screw-CARR				
13	99-5293	1	Spring-Torsion				
14	99-5291	1	Rod-Cover				
15	99-5292	1	Bracket-Cover				
16	108-3753	1	Chute-Discharge, Side				
17	32128-32	2	Nut-HHF				
18	108-4750	1	Housing ASM				
21	107-7495	1	Tunnel-Discharge				




Height-Of-Cut Assembly

Ref	Part No.	Qty.	Description				
1	92-1057	4	Bolt-Shoulder				
2	107-3708	4	Wheel ASM				
2:1	27-6250	2	Bushing				
3	107-7498	4	Screw-Shoulder, HOC				
4	107-7492	4	Arm-Pivot				
5	107-7491	4	Spring Arm				
6	105-3042	4	Knob-Lever, HOC				
7	603773	8	Nut				
8	49-2040	12	Screw-TAP				
9	107-7484	2	Spacer-Pivot				
10	107-7478	4	Plate-HOC				
11	40-1940	4	Washer				
12	2844	2	Washer				
13	52-2480	2	Spacer-Wheel				
15	3256-24	2	Washer-Flat				
17	108-4840	1	Decal				




Engine Assembly

Ref	Part No.	Qty.	Description				
1	105-8579	1	Bolt-Blade				
2	105-6848-03	1	Accelerator-Blade				
3	106-3987	1	Blade Driver ASM				
4	106-3999	1	Spacer-Driver				
7		1	Engine-Briggs And Stratton, 125K02-0189-E1				
8	2210-316	1	Stop-Rope				
9	104-7577-03	1	Shield-Muffler				
10	32144-1	3	Screw-Taptite				
11	107-7489-03	1	Shield-Grass				
12	95-1727	3	Screw-Taptite				
14	108-8130	1	Decal-Recoil				
15	108-3759-03	1	Blade-Bagging				
15	108-3762-03	1	Blade-Recycling				
17	108-4841	1	Decal				



Handle Assembly

Ref	Part No.	Qty.	Description				
1	105-6800-03	1	Bail-Brake				
3	92-4095	2	Screw-Handle				
4	108-8107	1	Cable-Brake				
5	3256-1	1	Washer-Flat				
6	3296-73	1	Nut-Lock, NI				
7	107-3844	2	Washer				
9	106-6805	1	Guide-Cable				
10	107-7476-05	1	Handle-Lower				
11	106-4161	4	Knob-Handle				
12	92-2260	2	Screw-Handle				
13	701243	4	Screw-HWH, TAP				
14	55-9670	2	Washer				
15	27-6600	4	Spacer-Coupling				
16	107-3780-03	2	Support-Handle				
17	107-3781-05	1	Handle-Upper				
18	106-8330	1	Guide-Rope				
19	107-0757	1	Stop-Pivot				
20	3255-8	2	Washer-Lock				




Cylinder Assembly

Briggs and Stratton 125K02-0189-E1

Ref	Part No.	Qty.	Description
❶1	697322	1	Cylinder ASM
❷2	399269	1	Bushing/Seal Kit
❸3	299819	1	Seal-Oil (Magneto Side)
❹5	691160	1	Head-Cylinder
❺7	692249	1	Gasket-Head, Cylinder
❻8	695250	1	Breather ASM
❼9	699472	1	Gasket-Breather
❽10	691125	1	Screw (Breather Side)
❾11	691781	1	Tube-Breather
❿13	690912	1	Screw (Cylinder Head)
⓫50	497465	1	Manifold-Intake
⓬51	272199	1	Gasket-Intake
⓭54	691650	1	Screw (Intake Manifold)
⓮306	690450	1	Shield-Cylinder
⓯307	690345	1	Screw (Cylinder Shield)
⓰337	802592	1	Plug-Spark
⓱383	89838	1	Wrench-Plug, Spark
⓲404	690272	1	Washer (Governor Crank)
⓳584	697734	1	Cover-Passage, Breather
⓴585	691879	1	Gasket-Passage, Breather
⓵615	690340	1	Retainer-Shaft, Governor
⓶616	698801	1	Crank-Governor
⓷635	66538	1	Boot-Plug, Spark
⓸684	690345	1	Screw (Breather Passage Cover)


Ref	Part No.	Qty.	Description
❶718	690959	1	Pin-Locating
❷869	691155	1	Seat-Valve (Intake)
❸870	690380	1	Seat-Valve (Exhaust)
❹871	262001	1	Bushing-Guide (Exhaust)
❺871	63709	1	Bushing-Guide (Intake)
❻1019	494256	1	Label Kit
❼1058	275177	1	Manual-Owner's
⓫1330	270962	1	Manual-Repair



Crankshaft Assembly


Briggs and Stratton 125K02-0189-E1

Ref	Part No.	Qty.	Description				
❶ 16	696009	1	Crankshaft				
❶ 24	222698	1	Key				
❶ 25	790359	1	Piston ASM (Standard)				
❶ 25	791326	1	Piston ASM (.020In Oversize)				
❶ 26	790360	1	Ring Set (Standard)				
❶ 26	791324	1	Ring Set (.020In Oversize)				
❶ 27	691866	1	Lock-Pin, Piston				
❶ 28	499423	1	Pin-Piston				
❶ 28	298908	1	Pin-Piston (.005In Undersize)				
❶ 29	499424	1	Rod-Connecting				
❶ 32	691664	1	Screw (Connecting Rod)				
❶ 32A	695759	1	Screw (Connecting Rod)				
❶ 33	262651	1	Valve-Exhaust				
❶ 34	262652	1	Valve-Intake				
❶ 35	691270	1	Spring-Valve (Intake)				
❶ 36	691270	1	Spring-Valve (Exhaust)				
❶ 40	692194	1	Retainer-Valve				
❶ 45	690548	1	Tappet-Valve				
❶ 741	790345	1	Gear-Timing				
❶ 868	697338	1	Seal-Valve				



Crankcase Assembly
Briggs and Stratton 125K02-0189-E1


Ref	Part No.	Qty.	Description				
❶4	493279	1	Sump–Engine				
❶12	692232	1	Gasket–Crankcase				
❶15	691680	1	Plug–Drain, Oil				
❶20	399781	1	Seal–Oil				
❶22	691092	1	Screw (Engine Sump)				
❶43	691997	1	Slinger–Governor/Oil				
❶46	691449	1	Camshaft				
❶48	696276	1	Short Block				
❶287	690940	1	Screw (Dipstick Tube)				
❶523	499621	1	Dipstick				
❶524	692296	1	Seal-Tube, Dipstick				
❶525	495265	1	Tube-Dipstick				
❶842	691031	1	Seal-O Ring (Dipstick Tube)				
❶847	692047	1	Dipstick/Tube ASM				



Carburetor Assembly

Briggs and Stratton 125K02-0189-E1


Ref	Part No.	Qty.	Description				
❶ 95	691636	1	Screw (Throttle Valve)				
❶ 97	696565	1	Shaft-Throttle				
❶ 104	691242	1	Pin-Hinge, Float				
❶ 117	498978	1	Jet-Main (Standard)				
❶ 118	497466	1	Main Jet (High Altitude)				
❶ 125	498170	1	Carburetor				
❶ 127	694468	1	Plug-Welch				
❶ 130	696564	1	Valve-Throttle				
❶ 133	398187	1	Float-Carburetor				
❶ 134	398188	1	Needle/Seat Kit				
❶ 137	693981	1	Gasket-Bowl, Float				
❶ 163	272653	1	Gasket-Cleaner, Air				
❶ 276	271716	1	Washer-Sealing				
❶ 365	692524	1	Screw (Carburetor)				
❶ 617	270344	1	Seal-O Ring (Intake Manifold)				
❶ 633	691321	1	Seal (Choke/Throttle Shaft)				
❶ 975	493640	1	Bowl-Float				



Air Cleaner Assembly


Briggs and Stratton 125K02-0189-E1

Ref	Part No.	Qty.	Description
❶ 163	272653	1	Gasket—Cleaner, Air
❶ 425	690670	1	Screw (Air Cleaner Cover)
❶ 443	692523	1	Screw (Air Cleaner Primer Base)
❶ 445	491588	1	Filter—Cartridge, Air Cleaner
❶ 529	691923	1	Grommet
❶ 966	496116	1	Base—Primer, Air Cleaner
❶ 968	692298	1	Cover—Cleaner, Air
❶ 976	694395	1	Primer—Carburetor



Governor Assembly
Briggs and Stratton 125K02-0189-E1


Ref	Part No.	Qty.	Description				
❶188	693399	1	Screw (Control Bracket)				
❶202	691829	1	Link–Governor, Mechanical				
❶209	691292	1	Spring–Governor				
❶222	791128	1	Bracket–Control				
❶227	690783	1	Lever–Control, Governor				
❶333	802574	1	Armature–Magneto				
❶334	691061	1	Screw (Magneto Armature)				
❶356	692390	1	Wire–Stop				
❶505	691251	1	Nut (Governor Control Lever)				
❶562	691119	1	Bolt (Governor Control Lever)				
❶621	692310	1	Switch–Stop				
❶668	493823	1	Spacer				
❶745	691648	1	Screw (Brake)				
❶851	493880	1	Terminal–Plug, Spark				
❶922	691831	1	Spring–Brake				
❶923	691994	1	Brake ASM				



Muffler and Fuel Tank Assembly


Briggs and Stratton 125K02-0189-E1

Ref	Part No.	Qty.	Description				
❶ 81	691740	1	Lock-Screw, Muffler				
❶ 187	691050	1	Line-Fuel (Cut To Required Length)				
❶ 190	690940	1	Screw (Fuel Tank)				
❶ 300	692038	1	Muffler				
❶ 601	95162	1	Clamp-Hose				
❶ 613	691340	1	Screw (Muffler)				
❶ 670	692294	1	Spacer-Tank, Fuel				
❶ 676	493871	1	Deflector-Muffler				
❶ 677	690661	1	Screw (Muffler Deflector)				
❶ 957	692046	1	Cap-Tank, Fuel				
❶ 972	699374	1	Tank-Fuel				
❶ 1059	692311	1	Screw/Washer Kit				




Blower Housing Assembly Briggs and Stratton 125K02-0189-E1

Ref	Part No.	Qty.	Description				
① 23	692315	1	Flywheel				
① 37	694086	1	Guard–Flywheel				
① 78	691108	1	Screw (Flywheel Guard)				
① 304	493293	1	Housing–Blower				
① 305	691108	1	Screw (Blower Housing)				
① 324	695161	1	Cup/Screen ASM				
① 332	690662	1	Nut (Flywheel)				
① 363	19069	1	Puller–Flywheel				
① 921	790036	1	Cover–Housing, Blower				
① 969	691138	1	Screw (Blower Housing Cover)				
① 1036	790411	1	Label–Emission				



Starter Assembly
Briggs and Stratton 125K02-0189-E1



Ref	Part No.	Qty.	Description				
❶55	691421	1	Housing–Starter, Rewind				
❶58	791362	1	Rope–Starter (Cut To Required Length)				
❶65	690837	1	Screw (Rewind Starter)				
❶456	692299	1	Plate–Friction, Pawl				
❶459	281505	1	Ratchet–Pawl				
❶592	690800	1	Nut (Rewind Starter)				
❶597	691696	1	Screw (Pawl Friction Plate)				
❶608	791363	1	Starter–Rewind				
❶689	691855	1	Spring–Friction				
❶1210	498144	1	Pulley/Spring ASM (Pulley)				
❶1211	498144	1	Pulley/Spring ASM (Spring)				



Engine Gasket Set Assembly

Briggs and Stratton 125K02-0189-E1

Ref	Part No.	Qty.	Description				
① 3	299819	1	Seal—Oil (Magnetos Side)				
① 7	692249	1	Gasket—Head, Cylinder				
① 12	692232		Gasket—Crankcase				
① 20	399781	1	Seal—Oil (PTO Side)				
① 51	272199	1	Gasket—Intake				
① 163	272653	1	Gasket—Cleaner, Air				
① 358	497316	1	Gasket Set—Engine				
① 524	692296	1	Seal—Oil (Dipstick Tube)				
① 585	691879	1	Gasket—Passage, Breather				
① 617	270344	1	Seal—O Ring (Intake Manifold)				
① 668	493823	1	Spacer				
① 842	691031	1	Seal—O Ring (Dipstick)				



**Carburetor Overhaul Kit and Gasket Set Assemblies
Briggs and Stratton 125K02-0189-E1**

Ref	Part No.	Qty.	Description				
❶ 104	691242	1	Pin-Hinge, Float				
❶ 121	498260	1	Carburetor Overhaul Kit				
❶ 127	694468	1	Plug-Welch				
❶ 134	398188	1	Needle/Seat Kit				
❶ 137	693981	1	Gasket-Bowl, Float				
❶ 163	272653	1	Gasket-Cleaner, Air				
❶ 276	271716	1	Washer-Sealing				
❶ 617	270344	1	Seal-O Ring (Intake Manifold)				
❶ 633	691321	1	Seal (Choke/Throttle Shaft)				
❶ 977	498261	1	Gasket Set-Carburetor				

NOTES

