



**Groundsmaster® 4000-D**  
**Groundsmaster Traction Unit**

Model No. 30410—Serial No. 250000001 and Up

**Operator's Manual**



English (EN, GB)



## Warning



### CALIFORNIA

#### Proposition 65 Warning

**Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.**

# Contents

	Page
Introduction .....	3
Safety .....	3
Safe Operating Practices .....	3
Toro Mower Safety .....	5
Sound Pressure Level .....	7
Sound Power Level .....	7
Vibration Level .....	7
Safety and Instruction Decals .....	7
Specifications .....	12
Traction Unit Specifications .....	12
Cutting Unit Specifications .....	13
Measurements .....	13
Setup .....	14
Loose Parts .....	14
Installing the Seat, Seat Belt, and Manual Tube .....	14
Greasing the Machine .....	14
Before Operating .....	15
Checking the Engine Oil .....	15
Checking the Cooling System .....	16
Filling the Fuel Tank .....	16
Checking the Hydraulic Fluid .....	17
Checking the Planetary Gear Drive Oil .....	17
Checking the Rear Axle Lubricant .....	18
Checking the Rear Axle Gear Box Lubricant .....	18
Checking the Tire Pressure .....	19
Checking the Torque of the Wheel Nuts or Bolts .....	19
Adjusting the Height-of-Cut .....	19
Adjusting the Skids .....	22
Adjusting the Cutting Unit Rollers .....	22
Correcting Mismatch Between Cutting Units .....	23
Operation .....	25
Controls .....	25
Starting and Stopping the Engine .....	27
Checking the Interlock Switches .....	27
Pushing or Towing the Machine .....	28
Jacking Points .....	29
Tie Downs .....	29
Operating Characteristics .....	29
Operating Tips .....	30
Maintenance .....	31
Recommended Maintenance Schedule .....	31
Daily Maintenance Checklist .....	32
Service Interval Chart .....	33
Greasing the Bearings and Bushings .....	33
Servicing the Air Cleaner .....	37
Servicing the Engine Oil and Filter .....	38
Servicing the Fuel System .....	38
Bleeding Air from the Injectors .....	39
Servicing the Engine Cooling System .....	40
Servicing the Alternator Belt .....	40
Adjusting the Throttle .....	41
Servicing the Spark Arrestor Muffler .....	41
Changing the Hydraulic Fluid .....	41
Replacing the Hydraulic Filters .....	42
Checking the Hydraulic Lines and Hoses .....	42
Hydraulic System Test Ports .....	42
Adjusting the Cutting Unit Flow Control .....	44
Adjusting the Traction Pedal Linkage .....	44
Adjusting the Service Brakes .....	45
Changing the Planetary Gear Drive Oil .....	45
Changing the Rear Axle Lubricant .....	46
Checking the Rear Wheel Toe-In .....	47
Activating, Charging, and Connecting the Battery .....	47
Battery Care .....	48
Fuses .....	49
Adjusting the Transport Latch .....	49
Pivoting (Tilting) the Front Cutting Unit Upright .....	49
Pivoting the Front Cutting Unit Down .....	50
Re-tensioning the Cutting Unit Drive Belts .....	50
Adjusting the Cutting Unit Pitch .....	51
Servicing the Castor Arm Bushings .....	52
Servicing the Castor Wheels and Bearings .....	52
Checking for a Bent Blade .....	53
Removing and Installing the Cutter Blade(s) .....	53
Inspecting and Sharpening the Cutter Blade(s) .....	53
Correcting Cutting Unit Mismatch .....	54
Replacing the Drive Belt .....	54
Electrical Schematic .....	56
Hydraulic Schematic .....	57
Preparing for Seasonal Storage .....	58
The Toro General Commercial Products Warranty ..	60

# Introduction

Read this manual carefully to learn how to operate and maintain your product properly. The information in this manual can help you and others avoid injury and product damage. Although Toro designs and produces safe products, you are responsible for operating the product properly and safely.

Whenever you need service, genuine Toro parts, or additional information, contact an Authorized Service Dealer or Toro Customer Service and have the model and serial numbers of your product ready. The numbers can be found on a plate that is mounted on the left side of the operator platform, behind the footrest.

Write the product model and serial numbers in the space below:

**Model No.** \_\_\_\_\_

**Serial No.** \_\_\_\_\_

This manual identifies potential hazards and has special safety messages that help you and others avoid personal injury and even death. **Danger**, **Warning**, and **Caution** are signal words used to identify the level of hazard. However, regardless of the hazard, be extremely careful.

**Danger** signals an extreme hazard that *will* cause serious injury or death if you do not follow the recommended precautions.

**Warning** signals a hazard that *may* cause serious injury or death if you do not follow the recommended precautions.

**Caution** signals a hazard that may cause minor or moderate injury if you do not follow the recommended precautions.

This manual uses two other words to highlight information.

**Important** calls attention to special mechanical information and **Note:** emphasizes general information worthy of special attention.

## Safety

**This machine meets or exceeds CEN standard EN 836:1997, ISO standard 5395:1990, and ANSI B71.4-1999 specifications in effect at the time of production.**

**Improper use or maintenance by the operator or owner can result in injury. To reduce the potential for injury, comply with these safety instructions and always pay attention to the safety alert  symbol, which means**

**CAUTION, WARNING, or DANGER—“personal safety instruction.” Failure to comply with the instruction may result in personal injury or death.**

## Safe Operating Practices

The following instructions are from the CEN standard EN 836:1997, ISO standard 5395:1990, and ANSI standard B71.4-1999.

### Training

- Read the Operator’s Manual and other training material carefully. Be familiar with the controls, safety signs, and the proper use of the equipment.
- Never allow children or people unfamiliar with these instructions to use the mower. Local regulations may restrict the age of the operator.
- Never mow while people, especially children, or pets are nearby.
- Keep in mind that the operator or user is responsible for accidents or hazards occurring to himself or herself, other people, or property.
- Do not carry passengers.
- All drivers and mechanics should seek and obtain professional and practical instruction. The owner is responsible for training the users. Such instruction should emphasize:
  - the need for care and concentration when working with ride-on machines;
  - control of a ride-on machine sliding on a slope will not be regained by the application of the brake. The main reasons for loss of control are:
    - insufficient wheel grip;
    - being driven too fast;
    - inadequate braking;
    - the type of machine is unsuitable for its task;
    - lack of awareness of the effect of ground conditions, especially slopes;
    - incorrect hitching and load distribution.

### Preparation

- While mowing, always wear substantial footwear, long trousers, hard hat, safety glasses, and ear protection. Long hair, loose clothing or jewelry may get tangled in moving parts. Do not operate the equipment when barefoot or wearing open sandals.

- Thoroughly inspect the area where the equipment is to be used and remove all objects which may be thrown by the machine.
- **Warning**—fuel is highly flammable. Take the following precautions:
  - Store fuel in containers specifically designed for this purpose.
  - Refuel outdoors only and do not smoke while refuelling.
  - Add fuel before starting the engine. Never remove the cap of the fuel tank or add fuel while the engine is running or when the engine is hot.
  - If fuel is spilled, do not attempt to start the engine but move the machine away from the area of spillage and avoid creating any source of ignition until fuel vapors have dissipated.
  - Replace all fuel tank and container caps securely.
- Replace faulty silencers/mufflers.
- Before using, always visually inspect to see that the blades, blade bolts, and cutting assembly are not worn or damaged. Replace worn or damaged blades and bolts in sets to preserve balance.
- On multi-bladed machines, take care as rotating one blade can cause other blades to rotate.
- Evaluate the terrain to determine what accessories and attachments are needed to properly and safely perform the job. Only use accessories and attachments approved by the manufacturer.
- Check that operator's presence controls, safety switches, and shields are attached and functioning properly. Do not operate unless they are functioning properly.

## Operation

- Do not operate the engine in a confined space where dangerous carbon monoxide fumes can collect.
- Mow only in daylight or in good artificial light.
- Before attempting to start the engine, disengage all blade attachment clutches, shift into neutral, and engage the parking brake. Only start the engine from the operator's position. Use seat belts, if provided.
- Remember there is no such thing as a safe slope. Travel on grass slopes requires particular care. To guard against overturning:
  - Do not stop or start suddenly when going up or downhill.
  - Engage the clutch slowly, always keep the machine in gear, especially when travelling downhill.

- The machine speed should be kept low on slopes and during tight turns.
- Stay alert for humps and hollows and other hidden hazards.
- Never mow across the face of the slope, unless the machine is designed for that purpose.
- Stay alert for holes in the terrain and other hidden hazards.
- Use care when pulling loads or using heavy equipment.
  - Use only approved drawbar hitch points.
  - Limit loads to those you can safely control.
  - Do not turn sharply. Use care when reversing.
  - Use counterweight(s) or wheel weights when suggested in the operator's manual.
- Watch out for traffic when crossing or near roadways.
- Stop the blades from rotating before crossing surfaces other than grass.
- When using any attachments, never direct discharge of material toward bystanders nor allow anyone near the machine while in operation.
- Never operate the machine with damaged guards, shields, or without safety protective devices in place. Be sure all interlocks are attached, adjusted properly, and functioning properly.
- Do not change the engine governor settings or overspeed the engine. Operating the engine at excessive speed may increase the hazard of personal injury.
- Before leaving the operator's position:
  - Stop on level ground.
  - Disengage the power take-off and lower the attachments.
  - Change into neutral and set the parking brake.
  - Stop the engine and remove the key.
- Disengage drive to attachments, stop the engine, and disconnect the spark plug wire(s) or remove the ignition key:
  - before clearing blockages;
  - before checking, cleaning, or working on the machine;
  - after striking a foreign object. Inspect the machine for damage and make repairs before restarting and operating the equipment. Torque all the spindle pulley nuts to 130–150 ft-lbs.;
  - if the machine starts to vibrate abnormally (check immediately).

- Disengage drive to attachments when transporting or not in use.
- Stop the engine and disengage drive to attachment:
  - before refuelling;
  - before making height adjustment unless adjustment can be made from the operator's position.
- Reduce the throttle setting before stopping engine and, if the engine is provided with a fuel shut-off valve, turn the fuel off at the conclusion of mowing.
- Never raise deck with the blades running.
- Keep hands and feet away from the cutting units.
- Look behind and down before backing up to be sure of a clear path.
- Slow down and use caution when making turns and crossing roads and sidewalks.
- Do not operate the mower under the influence of alcohol or drugs.
- Use care when loading or unloading the machine into a trailer or truck.
- The operator shall turn on flashing warning lights, if provided, whenever traveling on a public road, except where such use is prohibited by law.

## Maintenance and Storage

- Keep all nuts, bolts, and screws tight to be sure the equipment is in safe working condition.
- Never store the equipment with fuel in the tank inside a building where fumes may reach an open flame or spark.
- Allow the engine to cool before storing in any enclosure and do not store near flame.
- To reduce the fire hazard, keep the engine, silencer/muffler, battery compartment, cutting units, drives, and fuel storage area free of grass, leaves, or excessive grease. Clean up oil or fuel spillage.
- Replace worn or damaged parts for safety.
- If the fuel tank has to be drained, do this outdoors.
- On multi-bladed machines, take care as rotating one blade can cause other blades to rotate.
- When machine is to be parked, stored, or left unattended, lower the cutting units unless a positive mechanical lock is provided.
- Disengage drives, lower the cutting units, move traction pedal to Neutral, set parking brake, stop engine and remove key and disconnect spark plug wire. Wait for all movement to stop before adjusting, cleaning or repairing.


- Shut off fuel while storing or transporting. Do not store fuel near flames.
- Park machine on level ground. Never allow untrained personnel to service machine.
- Use jack stands to support components when required.
- Carefully release pressure from components with stored energy.
- Disconnect battery or remove spark plug wire before making any repairs. Disconnect the negative terminal first and the positive last. Reconnect positive first and negative last.
- Use care when checking blades. Wrap the blades or wear gloves, and use caution when servicing them. Only replace blades. Never straighten or weld them.
- Keep hands and feet away from moving parts. If possible, do not make adjustments with the engine running.
- Charge batteries in an open well ventilated area, away from spark and flames. Unplug charger before connecting or disconnecting from battery. Wear protective clothing and use insulated tools.

## Toro Mower Safety

The following list contains safety information specific to Toro products or other safety information that you must know that is not included in the CEN, ISO, or ANSI standards.

This product is capable of amputating hands and feet and throwing objects. Always follow all safety instructions to avoid serious injury or death.

Use of this product for purposes other than its intended use could prove dangerous to user and bystanders.



## Operation

- Before operating a machine with ROPS (roll over protection system), be certain that the seat belts are attached and the seat is latched to prevent the seat from pivoting forward.
- Know how to stop the machine and engine quickly.
- Do not operate the machine while wearing tennis shoes or sneakers.

- Wearing safety shoes and long pants is advisable and required by some local ordinances and insurance regulations.
- Keep hands, feet, and clothing away from moving parts and the mower discharge area and underside of the mower while the engine is running.
- Fill fuel tank until level is 1 in. (25 mm) below the bottom of the filler neck. Do not overfill.
- Check the safety interlock switches daily for proper operation. If a switch should fail, replace the switch before operating the machine. After every two years, replace all interlock switches in the safety system, **regardless** if they are working properly or not.
- Check carefully for overhead clearances (i.e. branches, doorways, electrical wires) before driving under any objects and do not contact them.
- Do not mow in reverse unless absolutely necessary.
- Reduce speed when making sharp turns.
- If a steep slope must be ascended, back up the hill and drive forward down the hill, keeping the machine in gear.
- If you cannot back up a slope or if you feel uneasy on it, do not mow it.
- Avoid starting or stopping on a slope. If tires lose traction, disengage the blades and proceed slowly straight down the slope. Avoid raising the side cutting units on a slope.
- Avoid turning on slopes. If you must turn, turn slowly and gradually downhill, if possible.
- When operating the machine on slopes, banks, or near drop offs, always have the ROPS installed.
- When operating a machine with a ROPS, always use a seat belt.
- Be certain that the seat belt can be released quickly if the machine is driven or rolls into a pond or water.
- Watch for traffic when near or crossing roads. Always yield the right-of-way.
- Do not mow near drop-offs, ditches, or embankments. The machine could suddenly turn over if a wheel goes over the edge of a cliff or ditch, or if an edge caves in.
- Do not mow on wet grass. Reduced traction could cause sliding.
- Do not try to stabilize the machine by putting your foot on the ground.
- Use extra care with other attachments. These can change the stability of the machine.

- Turn off the blades when not mowing.

## Maintenance and Storage

- Do not touch equipment or attachment parts which may be hot from operation. Allow to cool before attempting to maintain, adjust, or service.
- Never store the machine or fuel container inside where there is an open flame, such as near a water heater or furnace.
- Keep nuts and bolts tight, especially the blade attachment bolts. Keep equipment in good condition.
- Make sure all hydraulic line connectors are tight and all hydraulic hoses and lines are in good condition before applying pressure to the system.
- Keep your body and hands away from pin hole leaks or nozzles that eject hydraulic fluid under high pressure. Use paper or cardboard, not your hands, to search for leaks. Hydraulic fluid escaping under pressure can have sufficient force to penetrate the skin and cause serious injury. If fluid is injected into the skin it must be surgically removed within a few hours by a doctor familiar with this form of injury or gangrene may result.
- If the engine must be running to perform a maintenance adjustment, keep hands, feet, clothing, and any parts of the body away from the cutting units, attachments, and any moving parts. Keep everyone away.
- Check brake operation frequently. Adjust and service as required.
- Battery acid is poisonous and can cause burns. Avoid contact with skin, eyes, and clothing. Protect your face, eyes, and clothing when working with a battery.
- Battery gases can explode. Keep cigarettes, sparks, and flames away from the battery.
- The engine must be shut off before checking the oil or adding oil to the crankcase.
- If major repairs are ever needed or if assistance is desired, contact an Authorized Toro Distributor.
- To make sure of optimum performance and continued safety certification of the machine, use only genuine Toro replacement parts and accessories. Replacement parts and accessories made by other manufacturers could be dangerous, and such use could void the product warranty.

## Sound Pressure Level

This unit has an equivalent continuous A-weighted sound pressure level at the operator ear of 89 dBA, based on measurements of identical machines per Directive 98/37/EC and amendments.

## Sound Power Level

This unit has a guaranteed sound power level of 105 dBA/1 pW, based on measurements of identical machines per Directive 2000/14/EC and amendments.

## Safety and Instruction Decals



Safety decals and instructions are easily visible to the operator and are located near any area of potential danger. Replace any decal that is damaged or lost.



**106-6764**

1. To start the engine, move the traction pedal to Neutral, press the brake pedal, move the throttle lever to Fast, turn the ignition key to On, and then turn the ignition key to Start; read the *Operators Manual*.
2. To stop the engine, move the throttle lever to slow, disengage the PTO, set the parking brake, wait 5 minutes, turn the ignition key to Stop, and remove the key; read the *Operators Manual*.
3. Read the *Operators Manual*.
4. To engage the PTO, pull up on the PTO switch and move it forward.
5. To disengage the PTO, move the PTO switch back.
6. To switch the transmission to high speed, raise the attachment lift and switch the speed control to High.


## Vibration Level

### Hand-Arm

This unit does not exceed a vibration level of 2.5 m/s<sup>2</sup> at the hands based on measurements of identical machines per ISO 5349 procedures.


### Whole Body

This unit does not exceed a vibration level of 0.5 m/s<sup>2</sup> at the posterior based on measurements of identical machines per ISO 2631 procedures.



**93-7275**

1. Read the operator's manual.
2. Do not use starting aids.




**93-7272**

1. Cutting/dismemberment hazard—stay away from moving parts.




**104-4163**

1. Explosion hazard
2. No fire, open flames, or smoking.
3. Caustic liquid/chemical burn hazard
4. Wear eye protection
5. Read the *Operator's Manual*.
6. Keep bystanders a safe distance from the battery.




104-8336




100-6578

1. Stay away from moving parts.
2. Do not operate with cutting unit covers removed.




104-8323




106-6752

1. Warning—read the *Operator's Manual*.
2. Warning—lock the parking brake, stop the engine, and remove the ignition key before leaving the machine.
3. Warning—wear the seat belt when seated in the operator's position.
4. Cutting hazard of hand or foot—stay away from moving parts.
5. Tipping hazard—lower the cutting unit when driving down slopes; do not drive on slopes greater than 15 degrees.
6. Thrown object hazard—keep bystanders a safe distance from the machine.




**106-6753**

1. Thrown object hazard—keep bystanders a safe distance from the machine.
2. Cutting/dismemberment hazard of hand or foot, mower blade—stay away from moving parts.




**93-7818**

1. Danger—read the operator's manual for blade torque specification.



**106-6755**

1. Engine coolant under pressure
2. Explosion hazard—read the *Operator's Manual*.
3. Warning—do not touch the hot surface.
4. Warning—read the *Operator's Manual*.




**106-6754**

1. Do not touch the hot surface, and keep bystanders a safe distance from the machine.
2. Cutting/dismemberment hazard, fan and entanglement hazard, belt—stay away from moving parts




**104-8324**

1. Raise cutting units
1. Lower cutting units




**106-2046**

1. Engage	6. Low	11. Silencer switch	16. Continuous variable setting
2. Power Take-off (PTO)	7. Lock	12. Press the button	17. Slow
3. Disengage	8. Flow divider	13. Key switch	18. Engine coolant temperature
4. High	9. Unlock	14. Engine—preheat	reset switch
5. Transmission	10. Cruise control (optional)	15. Fast	




**104-2277**

- To lock the parking brake, latch the pedals together, apply the brake pedals, and pull up on the knob.
- To unlock the parking brake, step on the brake pedals.
- Parking brake lock
- Read the operator's manual.
- Press for optional headlights.
- Press down on the lever to tilt the steering wheel.




**100-5622**

- Height of cut adjustment




**100-5624**

- Height of cut adjustment




**104-3578**

1. Height of cut adjustment



**100-5623**

1. Low height of cut adjustment
2. High height of cut adjustment




**100-5693**

1. Height of cut adjustment




**104-8325**

1. Lock/unlock the cutting unit service lock.




**100-5694**

1. Height of cut adjustment



**104-3579**

1. Low height of cut adjustment
2. High height of cut adjustment



**104-3599**

1. Do not step here.
2. Traction pedal
3. Traction—forward
4. Traction—reverse
5. Danger—shut off PTO prior to raising the cutting units.
6. Danger—do not operate the cutting units when they are in the raised position.

# Specifications

## Traction Unit Specifications

Engine	Kubota, four-cycle, four cylinder, 134 in. <sup>3</sup> displacement, water-cooled turbo diesel engine. Rated 58 hp @ 2600 RPM, 23:1 compression ratio. Low idle—1500 RPM, high idle—2800 RPM. Oil capacity is 8 qt. (7.6 l) with filter.
Cooling system	Capacity is 2-3/4 gallons (10.4 l) of 50/50 mixture of ethylene glycol anti-freeze.
Fuel system	Electric fuel pump. Replaceable inline filter and spin-on fuel filter/water separator. Capacity is 19 gallons (72 l) of #2 diesel fuel.
Hydraulic system	Reservoir capacity is 8 gallons (30 l). Two replaceable spin-on filter elements.
Traction system	Servo-controlled hydrostatic system driving planetary gear reduction front wheel drives. Foot pedal control of forward/reverse ground speed. Rear drive axle coupled to hydrostatic transmission for full time 4-wheel drive when in Mow position. A Roll Over Protective Structure (ROPS) and seat belt are standard.
Ground speed	Mow: 0–8 MPH (0–12.8 km/h) Transport: 0–15 MPH (0–24 km/h)
Tires	Front: 26x12.00–12, 6-ply, tubeless turf tire Rear: 20x10.00–10, 6-ply, tubeless turf tire Front and back tire pressure is 25–30 psi (172–207 kPa).
Diagnostic system	Test ports for traction system, cutting unit drive system, lift/counterbalance, lift/relief, steering circuits, and charge pressure are located near individual components.
Steering system	Automotive type, full power
Brakes	Internal multiple wet disc brakes
Electrical system	12 volt, 110 minute reserve capacity (DIN) battery and 40 amp. alternator. Negative ground. Battery type group 24.
Interlock system	Prevents engine from starting unless traction pedal is in neutral and PTO is disengaged. If the operator leaves seat with the traction pedal depressed and the PTO engaged, after one second the PTO will disengage and if the operator is not back in the seat within 2 seconds the engine will stop. Engine will stop if machine comes out of neutral with parking brake set.
Gauges, indicator lights, and audible warning systems	Fuel gauge, engine coolant temperature gauge, hour meter, indicator lights for high engine coolant temperature, low engine oil pressure, glow plugs and charging. Audible warning for low engine oil pressure and high engine temperature.
Controls	Steering wheel, tilt adjustment, ignition switch, PTO switch, throttle control, traction pedal, mow/transport speed selector switch, flow divider switch, brakes (for turning or traction assist), parking brake pedal lock, and cutting unit lift/lower levers

## Cutting Unit Specifications

Front cutting unit	62 in. (157 cm) width of cut, 3 blades. Cutting unit can be tipped and latched for maintenance.
Side cutting units	
Height of cut	1–5 in. (25–177 mm) adjustable in 1/2 in. (13 mm) increments. Front cutting unit adjustment is achieved by changing spacers on castor wheels and length of support chains. Side cutting unit adjustment is achieved by adding or removing an equal number of spacers from the castor forks, positioning the castor wheel axles in the high or low height-of-cut holes in the castor forks and securing the pivot arms to the selected height-of-cut bracket holes.
Construction	Housing is made of 12 gauge steel and reinforced with channels and plates.
Cutter drive	One hydraulic motor per cutting unit. Each motor powers one spindle directly while remaining spindles are driven by a B section v-belt. Spindle shafts are supported by two externally sealed, greaseable, tapered roller bearings. All blades, spindles and belts are interchangeable.
Blades	Seven 21-3/4 in. long, 1/4 in. thick, heat-treated steel
Suspension and castor wheels	Front cutting unit has two front castors, consisting of 8 in. pneumatic wheel and tire assembly with sealed ball bearings. Rear of cutting unit is suspended from lift arms with adjustment for cutting unit rake. Hydraulic counter balance and lift system designed integral with cutting unit for maximum flotation and traction. Side cutting units have two front fixed castors and one rear castor consisting of 8 in. pneumatic wheel and tire assembly with sealed ball bearings. Inside rear of cutting unit is suspended by a spring and damper system. Hydraulic counter balance and lift system designed integral with cutting unit for maximum flotation and traction.
Anti-scalp features	Anti-scalp cup located on each blade. Anti-scalp rollers. Adjustable skid on each end of cutting unit.
Cutting unit covers	Steel and plastic covers

**Note:** Specifications subject to change without notice.

## Measurements

Width of cut	
overall	132 in. (335 cm)
front cutting unit	62 in. (157 cm)
side cutting unit	42 in. (107 cm)
front and one side cutting unit	97 in. (246 cm)
Overall width	
cutting units down	136 in. (345 cm)
cutting units up (transports)	72 in. (183 cm)

Overall length	135 in. (342 cm)
Height	55 in. (140 cm)
Height with ROPS	81 in. (206 cm)
Ground clearance	6-1/2 in. (17 cm)
Wheel tread (to center of tire)	
front	45 in. (114 cm)
rear	47 in. (119 cm)
Wheel base	55-1/2 in. (141 cm)
Weight (with cutting units and fluids)	3860 lb. (1751 kg)

# Setup

**Note:** Determine the left and right sides of the machine from the normal operating position.

## Loose Parts

**Note:** Use this chart as a checklist to ensure that all parts necessary for assembly have been received. Without these parts, total setup cannot be completed. Some parts may have already been assembled at the factory.

Description	Qty.	Use
Seat belt	1	
Capscrew	2	Installing the seat belt
Washer	2	
Manual tube	1	
R-clamp	2	Installing the manual tube
EEC certificate	1	
Parts catalog	1	
Pre-delivery inspection sheet	1	
Operator's manual	2	Read before operating the machine.
Engine manual	1	
Operator Video	1	View before operating machine

## Installing the Seat, Seat Belt, and Manual Tube

The machine is shipped without the seat assembly. A Premium Seat, Model No. 30622 and a Premium Suspension, Model No. 30621, must be purchased and installed.

1. Mount the manual tube to the seat suspension with the 2 R-clamps included in loose parts.
2. Install the seat belt to each side of the seat with a bolt and lock washer, supplied in loose parts.


**Important** Make sure that the seat switch wire is connected to the seat switch connector on the harness.

3. Slide the seat completely forward and backward to ensure proper operation and that seat switch wires and connectors are not pinched or do no contact any moving parts.

## Greasing the Machine

Before the machine is operated, it must be greased to ensure proper lubricating characteristics; refer to Greasing the Bearings and Bushings. Failure to properly grease the machine will result in premature failure of critical parts.

# Before Operating



## Checking the Engine Oil

The engine is shipped with oil in the crankcase; however, the oil level must be checked before and after the engine is first started.

The crankcase capacity is 8 qt. (7.6 l) with the filter.

Use high-quality engine oil that meets the following specifications:

API Classification Level Required: CH-4, CI-4 or higher.

Preferred oil: SAE 15W-40 (above 0°F)

Alternate oil: SAE 10W-30 or 5W-30 (all temperatures)

Toro Premium Engine oil is available from your distributor in either 15W-40 or 10W-30 viscosity. See the parts catalog for part numbers.

1. Park the machine on a level surface. Unlock the engine cover latches.
2. Open the engine cover.
3. Remove the dipstick, wipe it clean, install the dipstick into the tube, and pull it out again. The oil level should be up to the FULL mark (Fig. 1).




Figure 1

4. If the oil is below the FULL mark, remove the fill cap (Fig. 2) and add oil until the level reaches the FULL mark. **Do not overfill.**





Figure 2

1. Oil fill cap
5. Install the oil fill cap and dipstick.
6. Close the engine cover and secure it with the latches.

## Checking the Cooling System

Check level of coolant at the beginning of each day. Capacity of system is 2-3/4 gal. (10.4 l).

1. Carefully remove the radiator cap and expansion tank cap (Fig. 3).



2. Check the coolant level in the radiator. The radiator should be filled to the top of the filler neck and the expansion tank filled to the FULL mark.



Figure 3

1. Expansion tank

3. If the coolant is low, add a 50/50 mixture of water and ethylene glycol anti-freeze. **Do not use water only or alcohol/methanol base coolants.**
4. Install the radiator cap and expansion tank cap.

## Filling the Fuel Tank

The capacity of the fuel tank is 19 gallons (72 l).

1. Remove the fuel tank cap (Fig. 4).
2. Fill the tank to about 1 inch (25 mm) below the top of the tank, not the filler neck, with No. 2 diesel fuel. Then install the cap.




Figure 4

1. Fuel tank cap

## Danger

Under certain conditions, diesel fuel and fuel vapors are highly flammable and explosive. A fire or explosion from fuel can burn you and others and can cause property damage.

- Use a funnel and fill the fuel tank outdoors, in an open area, when the engine is off and is cold. Wipe up any fuel that spills.
- Do not fill the fuel tank completely full. Add fuel to the fuel tank until the level is 1/4 to 1/2 in. (6 to 13 mm) below the bottom of the filler neck. This empty space in the tank allows the fuel to expand.
- Never smoke when handling fuel, and stay away from an open flame or where fuel fumes may be ignited by a spark.
- Store fuel in a clean, safety-approved container and keep the cap in place.

## Checking the Hydraulic Fluid

The machine's reservoir is filled at the factory with approximately 8 U.S. gallons (13.2 l) of high quality hydraulic fluid. **Check the level of the hydraulic fluid before the engine is first started and daily thereafter.** The recommended replacement fluid is:

### Toro Premium All Season Hydraulic Fluid

(Available in 5 gallon pails or 55 gallon drums. See parts catalog or Toro distributor for part numbers.)

Alternate fluids: If the Toro fluid is not available, other fluids may be used provided they meet all the following material properties and industry specifications. We do not recommend the use of synthetic fluid. Consult with your lubricant distributor to identify a satisfactory product. Note: Toro will not assume responsibility for damage caused by improper substitutions, so use only products from reputable manufacturers who will stand behind their recommendation.

### High Viscosity Index/Low Pour Point Antiwear Hydraulic Fluid, ISO VG 46

#### Material Properties:

Viscosity, ASTM D445	cSt @ 40°C 44 to 48
	cSt @ 100°C 7.9 to 8.5

Viscosity Index ASTM D2270 140 to 160

Pour Point, ASTM D97 -34°F to -49°F

#### Industry Specifications:

Vickers I-286-S (Quality Level), Vickers M-2950-S (Quality Level), Denison HF-0

**Note:** Many hydraulic fluids are almost colorless, making it difficult to spot leaks. A red dye additive for the hydraulic system oil is available in 2/3 oz. (20 ml) bottles. One bottle is sufficient for 4–6 gal (15–22 l) of hydraulic oil. Order part no. 44-2500 from your authorized Toro distributor.

### Biodegradable Hydraulic Fluid – Mobil 224H

#### Toro Biodegradable Hydraulic Fluid

(Available in 5 gallon pails or 55 gallon drums. See parts catalog or Toro distributor for part numbers.)

Alternate fluid: Mobil EAL 224H

This is vegetable-oil based biodegradable oil tested and approved by Toro for this model. This fluid is not as resistant to high temperatures as standard fluid, so install an oil cooler if required by the operator manual and follow recommended fluid change intervals with this fluid. Contamination by mineral-based hydraulic fluids will

change the biodegradability and toxicity of this oil. When changing from standard fluid to the biodegradable type, be certain to follow the approved flushing procedure. Contact your local Toro Distributor for details.

1. Position the machine on a level surface, lower the cutting units, stop the engine, and remove the key.
2. Unlatch the seat, raise it, and engage the prop rod.
3. Clean the area around the filler neck and cap of the hydraulic tank (Fig. 5). Remove the cap from the filler neck.
4. Remove the dipstick from the filler neck and wipe it with a clean rag. Insert the dipstick into the filler neck; then remove it and check the fluid level. The fluid level should be between the two marks on the dipstick.
5. If the level is low, add the appropriate fluid to raise the level to the upper mark.
6. Install the dipstick and cap onto the filler neck.



Figure 5

1. Hydraulic tank cap

## Checking the Planetary Gear Drive Oil

Check the oil level after every 400 hours of operation or if external leakage is noted. Use high quality SAE 85W-140 wt. gear lube as a replacement.


The capacity of the system is approximately 16 oz. (0.5 l).

1. With the machine on a level surface, position the wheel so that the check/drain plug (Fig. 6) is at either the 2 or 10 o'clock position.



**Figure 6**

1. Check/drain plug
2. Remove the plug on the planetary (Fig. 6) and check the plug on the back side of the brake (Fig. 7). Oil should be at the bottom of the check plug hole on the back side of the brake.



**Figure 7**


1. Brake housing
2. Check plug

3. Add gear oil to the hole in the planetary, if necessary, to bring the oil up to the proper level. Install the plug.
4. Repeat steps 1–3 on the opposite gear assembly.

## Checking the Rear Axle Lubricant

The rear axle is shipped from the factory filled with SAE 85W-140 wt. gear lube. Check the oil level before the engine is first started and every 400 hours thereafter. The capacity is 80 oz. (2.4 l). Visually inspect for leaks daily.

1. Position the machine on a level surface.
2. Remove a check plug from one end of the axle (Fig. 8) and make sure that the lubricant is up to the bottom of the hole. If the level is low, remove the fill plug (Fig. 8) and add enough lubricant to bring the level up to the bottom of the check plug holes.



**Figure 8**


1. Check plug
2. Fill plug

## Checking the Rear Axle Gear Box Lubricant

The gear box is shipped from the factory filled with SAE 85W-140 wt. gear lube. Check the oil level before the engine is first started and every 400 hours thereafter. The capacity is 16 oz. (0.5 l). Visually inspect for leaks daily.

1. Position the machine on a level surface.

2. Remove the check/fill plug from the left side of the gear box (Fig. 9) and make sure that lubricant is up to the bottom of the hole. If the level is low, add enough lubricant to bring the level up to the bottom of the hole.



**Figure 9**

1. Gear box
2. Check/fill plug

## Checking the Tire Pressure

The tires are over-inflated for shipping. Therefore, release some of the air to reduce the pressure. The correct air pressure in the front and rear tires is 25–30 psi (172–207 kPa).

**Important** Maintain even pressure in all tires to ensure a good quality-of-cut and proper machine performance. **Do not under-inflate.**

## Checking the Torque of the Wheel Nuts or Bolts

## Warning

**Failure to maintain proper torque of the wheel nuts could result in failure or loss of wheel and may result in personal injury.**


**Torque the front wheel nuts and rear bolts to 85–100 ft.-lb. (115–136 N·m) after 1–4 hours of operation and again after 10 hours of operation. Torque every 200 hours thereafter.**

## Adjusting the Height-of-Cut

## Front Cutting Unit

The height-of-cut is adjustable from 1 to 5 inches (25 to 127 mm) in 1/2 inch (13 mm) increments. To adjust the height-of-cut on the front cutting unit, position the castor wheel axles in the upper or lower holes of the castor forks, add or remove an equal number of spacers from the castor forks, and secure the rear chain to the desired hole.

1. Start the engine and raise the cutting units so that the height-of-cut can be changed. Stop the engine and remove the key after the cutting unit is raised.
2. Position the castor wheel axles in the same holes in all castor forks. Refer to the following chart to determine the correct holes for the setting.



**Figure 10**

1. Castor wheel	4. Shims
2. Tensioning cap	5. Axle mounting holes
3. Spacers	

**Note:** When operating in 2-1/2 inch (64 mm) height of cut or higher, the axle bolt must be installed in the lower castor fork hole to prevent grass buildup between the wheel and the fork. When operating in height of cuts lower than 2-1/2

inches (64 mm) and grass buildup is detected, reverse the machines direction to pull any clippings away from the wheel/fork area.

- Remove the tensioning cap from the spindle shaft (Fig. 10) and slide the spindle out of the castor arm. Put the 2 shims (1/8 inch) onto the spindle shaft as they were originally installed. These shims are required to achieve a level across the entire width of the cutting units. Slide the appropriate number of 1/2 inch spacers (refer to the chart below) onto the spindle shaft to get the desired height-of-cut; then slide the washer onto the shaft.

Refer to the following chart to determine the combinations of spacers for the setting.




Figure 11

- Push the castor spindle through the front castor arm. Install the shims (as they were originally installed) and the remaining spacers onto the spindle shaft. Install the tensioning cap to secure the assembly.
- Remove the hairpin cotter and clevis pin securing the height-of-cut chains to the rear of the cutting unit (Fig. 12).




Figure 12

1. Height-of-cut chain      2. U-bolt

- Mount the height-of-cut chains to the desired height-of-cut hole (Fig. 13) with the clevis pin and hairpin cotter.





Figure 13

**Note:** When using 1 in. (25 mm), 1-1/2 in. (38 mm), or occasionally 2 in. (51 mm) height-of-cut, move the skids and gage wheels to the highest holes.

## Side Cutting Units

To adjust the height-of-cut on the side cutting units, add or remove an equal number of spacers from the castor forks, position the castor wheel axles in the high or low height-of-cut holes in the castor forks, and secure the pivot arms to the selected height-of-cut bracket holes.


- Position the castor wheel axles in the same holes in all of the castor forks (Fig. 14 & 16). Refer to the following chart to determine the correct hole for the setting.
- Remove the tensioning cap from the spindle shaft (Fig. 14) and slide the spindle out of castor arm. Put the two shims (1/8 inch) onto spindle shaft as they were originally installed. These shims are required to achieve a level across the entire width of the cutting units. Slide the appropriate number of 1/2 inch spacers onto the spindle shaft to get the desired height-of-cut; then slide the washer onto the shaft.



**Figure 14**

1. Castor wheel	4. Shims
2. Tensioning cap	5. Axle mounting holes
3. Spacers	


Refer to the following chart to determine the combinations of spacers for the setting.



**Figure 15**


3. Push the castor spindle through the castor arm. Install the shims (as originally installed) and the remaining spacers onto the spindle shaft. Install the tensioning cap to secure the assembly.

4. Remove the hairpin cotter and clevis pins from the castor pivot arms (Fig. 16).
5. Rotate tension rod to raise or lower pivot arm until holes are aligned with selected height-of-cut bracket holes in the cutting unit frame (Fig. 16 & 17)
6. Insert the clevis pins and install the hairpin cotters.
7. Rotate tension rod counterclockwise (finger tight) to put tension on adjustment.



**Figure 16**


1. Castor pivot arm	3. Clevis pin & hair pin cotter
2. Axle mounting holes	4. Tension rod



**Figure 17**


8. Remove the hairpin cotters and clevis pins securing the damper links to the cutting unit brackets (Fig. 18). Align the damper link holes with the selected height-of-cut bracket holes in the cutting unit frame (Fig. 19), insert the clevis pins, and install the hairpin cotters.

**Important** The damper link length should never be adjusted. The length between the hole centers should be 5-3/8 in. (13.7 cm).



**Figure 18**

1. Damper link




**Figure 19**

## Adjusting the Skids

The skids should be mounted in the lower position when operating in height of cuts greater than 2-1/2 inches (64 mm) and in the higher position when operating in height of cuts lower than 2-1/2 inches (64 mm).

Adjust the skids by removing the flange bolt and nuts, positioning them as desired, and installing the fasteners (Fig. 20).




**Figure 20**

1. Skid

## Adjusting the Cutting Unit Rollers

The cutting unit rollers should be mounted in the lower position when operating in height of cuts greater than 2-1/2 inches (64 mm) and in the higher position when operating in height of cuts lower than 2-1/2 inches (64 mm).

1. Remove the capscrew and nut securing the gage wheel to the cutting unit brackets (Fig. 21).



**Figure 21**

1. Gage wheel

2. Align the roller and spacer with the top holes in the brackets and secure them with the capscrew and nut.


## Correcting Mismatch Between Cutting Units

Due to differences in grass conditions and the counterbalance setting of the traction unit, it is advised that grass be cut and appearance checked before formal cutting is started.

1. Set all cutting units to the desired height of cut; refer to Adjusting the Height of Cut, page 19.
2. Check and adjust front and rear tractor tire pressure to 25–30 psi (172–207 kPa).
3. Check and adjust all castor tire pressures to 50 psi (345 kPa).
4. Check charge and counterbalance pressures with engine at high idle using test ports defined in Hydraulic Systems Test Ports, page 42. Adjust counterbalance setting to be 220 psi (1517 kPa) higher than charge pressure reading.
5. Check for bent blades; refer to Checking for a Bent Blade, page 53.
6. Cut grass in a test area to determine if all cutting units are cutting at the same height.
7. If cutting unit adjustments are still needed, find a flat surface using a 6 foot (2 m) or longer straight edge.
8. To ease measuring blade plane, raise the height of cut to the highest position; refer to Adjusting the Height of Cut.
9. Lower cutting units onto the flat surface. Remove the covers from the top of the cutting units
10. Loosen the flange nut, securing the idler pulley, to release the belt tension on each cutting unit.

### Front Cutting Unit Setup

Rotate blade on each spindle until the ends face forward and backward. Measure from the floor to the front tip of the cutting edge. Adjust 1/8 in. shims on front castor arm(s) to match height of cut to decal (Fig. 22); refer to Adjusting the Cutting Unit Pitch.




**Figure 22**

1. Castor wheel	4. Shims
2. Tensioning cap	5. Axe mounting holes
3. Spacers	

### Side Cutting Unit Setup

Rotate blade of each spindle until the ends face forward and backward. Measure from the floor to the front tip of the cutting edge. Adjust 1/8 in. shims on front castor arm(s) to match height of cut to decal (Fig. 23). For the outside blade spindle only, refer to Adjusting the Cutting Unit Pitch.



**Figure 23**

- 1. Front castor arm
- 2. Castor fork
- 3. Shims

Recheck measurement between outside edges of both side cutting units and inside edge of side cutting unit to outside edge of front cutting unit.

4. If inside edge is still too high, remove an additional 1/8 in. shim from bottom of front inside castor arm of the side cutting unit **and** one 1/8 in. shim from the front outside castor arm of the side cutting unit.
5. If the inside edge of the side cutting unit is too low relative to the outside edge of the front cutting unit, add one 1/8 in. shim to the bottom of the front inside castor arm on the side cutting unit. Check measurement between outside edges of both side cutting units and inside edge of side cutting unit to outside edge of front cutting unit.
6. If inside edge is still too low, add an additional 1/8 in. shim to the bottom of front inside castor arm of the side cutting unit **and** add one 1/8 in. shim to the front outside castor arm of the side cutting unit.
7. Once cutting height matches at the edges of front and side cutting units, verify that side cutting unit pitch is still 1/4 in. (6 mm). Adjust as necessary.

## Matching Height Of Cut Between Cutting Units

1. Position blade side to side on outside spindle of both side cutting units. Measure from the floor to the tip of the cutting edge on both units and compare. These numbers should be within 1/8 in. (3 mm) of each other. Make no adjustment at this time.
2. Position blade side to side on inside spindle of side cutting unit and corresponding outside spindle of front cutting unit. Measure from the floor to the tip of the cutting edge on inside edge of side cutting unit to corresponding outside edge of front cutting unit and compare. The side cutting unit measurement should be approximately 3/8" less than the front cutting unit measurement to be correct. When proper machine counterbalance is applied to the side cutting units the inside edge will lift up approximately 3/8 in. (10 mm).


**Note:** All three side cutting units castor wheels should remain on the ground with counterbalance applied.

**Note:** If adjustments need to be made to match the cut between the front and side cutting units, make the adjustments to the **side cutting units only**.

3. If the inside edge of the side cutting unit is too high relative to the outside edge of the front cutting unit, remove one 1/8 in. shim from the bottom of the front inside castor arm on the side cutting unit. (Fig. 23)

# Operation

**Note:** Determine the left and right sides of the machine from the normal operating position.



## Controls

### Traction Pedal

The traction pedal (Fig. 24) controls forward and reverse operation. Depress the top of the pedal to move forward and the bottom to move backward. Ground speed depends on how far the pedal is depressed. For no load, maximum ground speed, fully depress the pedal while the throttle is in Fast.

To stop, reduce your foot pressure on the traction pedal and allow it to return to the center position.

**Important** The speed limiter screw must stop the traction pedal before the pump reaches full stroke or damage to the pump may occur.

### Brake Pedals

Two foot pedals (Fig. 24) operate individual wheel brakes for turning assistance, parking, and to aid in obtaining better side hill traction. A latch connects the pedals for parking brake operation and transport.

### Pedal Locking Latch

The pedal locking latch (Fig. 24) connects the pedals together to engage the parking brake.


### Tilt Steering Lever

Press the lever (Fig. 24) down to tilt the steering wheel to the desired position. Then release the lever to lock the adjustment.

### Parking Brake Latch

A knob on the left side of the console actuates the parking brake lock (Fig. 24). To engage the parking brake, connect the pedals with the locking latch, push down on both

pedals, and pull the parking brake latch out. To release the parking brake, depress both pedals until the parking brake latch retracts.



**Figure 24**

1. Traction pedal	7. Engine oil pressure warning light
2. Brake pedals	8. Engine coolant temperature warning light
3. Pedal locking latch	9. Glow plug indicator light
4. Tilt steering lever	10. Temperature gauge
5. Parking brake latch	
6. Charge indicator	

### Charge Indicator

The charge indicator (Fig. 24) illuminates when the system charging circuit malfunctions.

### Engine Oil Pressure Warning Light

The light (Fig. 24) illuminates when the engine oil pressure is dangerously low.

### Engine Coolant Temperature Warning Light

The light (Fig. 24) illuminates and the engine shuts down when coolant reaches an excessively high temperature.

## Glow Plug Indicator Light

When lit, the glow plug indicator light (Fig. 24) indicates that the glow plugs are on.

## Engine Temperature Gauge

This gauge (Fig. 24) indicates the engine coolant temperature.

## Speed Limiter

Adjust the screw (Fig. 25) to limit the amount the traction pedal can be depressed in the forward direction to limit speed.

**Important** The traction pedal must contact the speed limiter before reaching the end of the pump stroke to prevent pump damage.




Figure 25

---

- 1. Speed limiter

## Lift Levers

The levers (Fig. 26) raise and lower the cutting units.

## Cutting Unit Service Lock

The cutting unit service lock (Fig. 26) locks the front cutting unit lift lever when the cutting unit is in the raised position.

## Key Switch

The key switch (Fig. 26) has three positions: Off, On/Preheat, and Start.

## PTO Switch

The PTO switch (Fig. 26) has three positions: On (engage), Neutral, and Off (disengage). Carefully lift and push the PTO switch forward to the On position to start the implement or cutting unit blades. Slowly pull the switch backward to the Off position to stop implement operation.

## Hi-Lo Speed Control

The control (Fig. 26) allows the speed range to increase for transport of the machine.

## Flow Divider Switch

Depress and hold flow divider switch (Fig. 26) to enhance traction drive performance in compromised operating conditions.




Figure 26

---

- 1. Lift lever
- 2. Front cutting unit service lock
- 3. Key switch
- 4. PTO switch
- 5. Hi-lo speed control
- 6. Flow divider switch
- 7. Cruise control (optional)
- 8. Alarm silence switch
- 9. Temperature reset switch
- 10. Hour meter
- 11. Fuel gauge
- 12. Throttle
- 13. Audible alarm
- 14. Power point

## Cruise Control (Optional)

The cruise control (Fig. 26) sets the speed of the machine.

## Fuel Gauge

The fuel gauge (Fig. 26) indicates the level of fuel in the tank.

## Hour Meter

The hour meter (Fig. 26) shows the total hours that the machine has been operated.

## Temperature Override Switch

Press and hold the reset switch (Fig. 26) to start the engine after high temperature shut down. Use only for emergency operation.

## Audible Alarm

The alarm (Fig. 26) is activated when the low engine oil pressure light illuminates or the high coolant temperature light illuminates.

## Alarm Silence Switch

This switch (Fig. 26) shuts off the audible alarm.

## Throttle Control

Move the control (Fig. 26) forward to increase the engine speed and rearward to decrease the speed.

## Power Point

The power point (Fig. 26) is used to power optional electrical accessories.

# Starting and Stopping the Engine

**Important** The fuel system will automatically bleed itself when any of the following situations occur:

- Initial start up of a new machine
- The engine has ceased running due to lack of fuel.
- Maintenance has been performed upon the fuel system components.


1. Ensure that the parking brake is set. Remove your foot from the traction pedal and ensure that it is in neutral.
2. Move the throttle control to the mid idle position.
3. Turn the ignition key to the Run position. The glow indicator will light.

4. When the glow indicator dims, turn the ignition key to the Start position. Release the key immediately when the engine starts and allow it to return to the Run position. Allow engine to warm up at mid speed (without load), then, move the throttle control to the desired position.

**Important** Do not run the starter motor more than 15 seconds at a time or premature starter failure may result. If the engine fails to start after 15 seconds, turn the key to the Off position, recheck the controls and procedures, wait 15 additional seconds, and repeat the starting procedure.

When the temperature is less than 20°F (-7°C), preheat glow plugs twice prior to initial cranking attempt. The starter motor can be run for 30 seconds on then 60 seconds off for 2 attempts.

5. When the engine is started for the first time, or after an overhaul of the engine, transmission, or axle, operate the machine in forward and reverse for one or two minutes. Also operate the lift lever and PTO lever to ensure proper operation of all parts. Turn the steering wheel to the left and right to check steering response. Then shut the engine off and check for oil leaks, loose parts, and any other noticeable difficulties.



6. To stop the engine, move the throttle control backward to the Slow position, move the PTO lever to the Off position, set the parking brake, and rotate the ignition key to Off. Remove the key from the switch to prevent accidental starting.

**Important** Allow engine to idle for 5 minutes before shutting it off after a full load operation. Failure to do so may lead to turbo-charge trouble.

## Checking the Interlock Switches

**Caution**

If safety interlock switches are disconnected or damaged the machine could operate unexpectedly causing personal injury.

- Do not tamper with the interlock switches.
- Check the operation of the interlock switches daily and replace any damaged switches before operating the machine.
- Replace switches every two years or 1500 hours, whichever occurs first, regardless of whether they are operating properly or not.

The machine has interlock switches in the electrical system. These switches are designed to stop the engine when operator gets off of the seat when the traction pedal is depressed. However, the operator may get off of the seat while the engine is running and the traction pedal is in neutral. Although the engine will continue to run if the PTO lever is disengaged and the traction pedal is released, it is strongly recommended that the engine be stopped before rising from the seat.

To check the operation of the interlock switches, perform the following procedure:

1. Drive the machine slowly to a large, relatively open area. Lower the cutting unit, stop the engine, and apply the parking brake.
2. Sit on the seat and depress the traction pedal. Try to start the engine. The engine should not crank. If the engine cranks, there is a malfunction in the interlock system that should be corrected before beginning operation.
3. Sit on the seat and start the engine. Rise from the seat and move the PTO lever to On. The PTO should not engage. If the PTO engages, there is a malfunction in the interlock system that should be corrected before beginning operation.
4. Sit on the seat, engage the parking brake and start the engine. Move the traction pedal out of the neutral position. The engine should kill. If the engine does not kill, there is a malfunction in the interlock system that should be corrected before beginning operation.

## Pushing or Towing the Machine

In an emergency, the machine can be moved forward by actuating the bypass valve in the variable displacement hydraulic pump and pushing or towing the machine. **Do not push or tow the machine for more than 1/4 mile (0.4 km).**

**Important** Do not push or tow the machine faster than 2–3 MPH (3–4.8 km/h) because internal transmission damage may occur. The bypass valve must be open whenever the machine is pushed or towed.


1. Raise the seat and remove the battery cover. The bypass valve is located in front of the battery (Fig. 27).
2. Rotate the valve 90° in either direction to open and allow oil to bypass internally. Because fluid is bypassed, the machine can be slowly moved without damaging the transmission. Note the position of the valve when opening or closing.
3. Close the bypass valve before starting the engine. However, do not exceed 5–8 ft.-lb. (7–11 N·m) torque to close the valve.



Figure 27


1. Bypass valve access hole

**Important** If the machine must be pushed or towed in reverse, the check valve in the four-wheel drive manifold must also be bypassed. To bypass the check valve, connect a hose assembly (Hose Part No. 95-8843, Coupler Fitting No. 95-0985 [Qty. 2], and Hydraulic Fitting No. 340-77 [Qty. 2]) to the reverse traction pressure test port (Fig. 28) and the reverse four-wheel drive pressure port (Fig. 29).



**Figure 28**

1. Reverse traction pressure test port



**Figure 29**

1. Reverse four-wheel drive pressure test port

## Jacking Points

- On the front of the machine on the frame on the inside of each drive tire
- On the rear of the machine at the center of the axle

## Tie Downs

- On each side of the frame by the side cutting unit lift arms
- Front center of the operator's platform
- The rear bumper

## Operating Characteristics

Practice driving the machine because it has a hydrostatic transmission and its characteristics are different than many turf maintenance machines. Some points to consider when operating the traction unit, cutting unit, or other implements

are the transmission, engine speed, load on the cutting blades or other implement components, and the importance of the brakes.

To maintain enough power for the traction unit and implement while operating, regulate the traction pedal to keep the engine RPM high and somewhat constant. A good rule to follow is to decrease the ground speed as the load on the implement increases, and increase the ground speed as the load decreases.

Therefore, allow the traction pedal to move backward as the engine RPM decreases, and depress the pedal slowly as the RPM increases. By comparison, when driving from one work area to another, with no load and cutting unit raised, have the throttle in the Fast position and depress the traction pedal slowly but fully to attain maximum ground speed.

The flow divider enhances traction drive performance in compromised operating conditions. The flow divider is for use in low speed range only. When approaching an area known to cause wheel spin, depress and hold flow divider switch until completely past the area. If a tire spins while climbing or maneuvering on slopes, depress switch and slowly drive out of area. If both a front and rear wheel spins, the steering brake can be feathered to transfer the torque from the spinning wheels to opposite front wheel.

Another characteristic to consider is the operation of the pedals that are connected to the brakes. The brakes can be used to assist in turning the machine. However, use them carefully, especially on soft or wet grass because the turf may be torn accidentally. Another benefit of the brakes is to maintain traction. For example, in some slope conditions, the uphill wheel slips and loses traction. If this situation occurs, depress the uphill turn pedal gradually and intermittently until the uphill wheel stops slipping, thus, increasing traction on the downhill wheel.

Use extra care when operating the machine on slopes. Make sure that the seat latch is properly secured and the seat belt is buckled. Drive slowly and avoid sharp turns on slopes to prevent roll overs. For steering control, the cutting cutting unit must be lowered when going downhill.



### Warning




**This product is designed to drive objects into the ground where they lose energy quickly in grass areas. However, careless operation, combined with terrain angle, ricochets, or improperly positioned safety guard can lead to thrown object injuries.**

- When a person or pet appears suddenly in or near the mowing area, *stop mowing*.
- Do not resume mowing until the area is cleared.

Before stopping the engine, disengage all controls and move the throttle to Slow. Moving the throttle to Slow reduces high engine RPM, noise, and vibration. Turn the key to Off to stop the engine.

Before transporting the machine, raise the cutting units and secure the transport latches (Fig. 30).



**Figure 30**

1. Transport latch (side cutting units)

## Operating Tips

### Mow When Grass is Dry

Mow either in the late morning to avoid the dew, which causes grass clumping, or in late afternoon to avoid the damage that can be caused by direct sunlight on the sensitive, freshly mowed grass.

### Select the Proper Height-of-Cut Setting to Suit Conditions

Remove approximately 1 in. (25 mm) or no more than 1/3 of the grass blade when cutting. In exceptionally lush and dense grass, you may have to raise the height-of-cut to the next setting.

### Mow at Proper Intervals

Under most normal conditions you will need to mow approximately every 4–5 days. But remember, grass grows at different rates at different times. This means that in order to maintain the same height-of-cut, which is a good practice, you will need to cut more frequently in early spring; as the grass growth rate slows in mid summer, cut only every 8–10 days. If you are unable to mow for an extended period due to weather conditions or other reasons, mow first with the height-of-cut at a high level; then mow again 2–3 days later with a lower height setting.

## Always Mow with Sharp Blades

A sharp blade cuts cleanly and without tearing or shredding the grass blades like a dull blade. Tearing and shredding causes the grass to turn brown at the edges which impairs growth and increases susceptibility to diseases.

## Transporting

Use the transport latches when transporting over long distances, rough terrain, or when trailering.

## After Operating

To ensure optimum performance, clean the underside of the mower housing after each use. If residue is allowed to build up in the mower housing, cutting performance will decrease.

## Cutting Unit Pitch

We recommend a blade pitch of 1/4 in. (6 mm). A pitch larger than 1/4 in. (6 mm) will result in less power required, larger clippings, and a poorer quality of cut. A pitch less than 1/4 in. (6 mm) will result in more power required, smaller clippings and a better quality of cut.

# Maintenance

## Recommended Maintenance Schedule

Maintenance Service Interval	Maintenance Procedure
After first 10 hours	<ul style="list-style-type: none"><li>Check the cutting unit drive belt tension.</li><li>Check the fan and alternator belt tension.</li><li>Torque the wheel lug nuts.</li></ul>
After first 50 hours	<ul style="list-style-type: none"><li>Change the engine oil and filter.</li><li>Check the engine RPM (at idle and full throttle).</li></ul>
Every 50 hours	<ul style="list-style-type: none"><li>Lubricate all grease fittings.</li><li>Inspect the air cleaner.</li><li>Check the battery level and cable connections.</li><li>Check the cutting unit drive belt tension.</li></ul>
Every 100 hours	<ul style="list-style-type: none"><li>Change the engine oil and filter.</li><li>Inspect the cooling system hoses.</li><li>Check the fan and alternator belt tension.</li></ul>
After first 200 hours	<ul style="list-style-type: none"><li>Change the hydraulic oil.</li><li>Change the hydraulic oil filters.</li><li>Change the front planetary gear lube.</li><li>Change the rear axle oil level.</li></ul>
Every 200 hours	<ul style="list-style-type: none"><li>Torque the wheel lug nuts.</li><li>Service the spark arrestor.</li></ul>
Every 400 hours	<ul style="list-style-type: none"><li>Service the air filter.<sup>1</sup></li><li>Change the fuel filters (fuel/water and prefilter)</li><li>Inspect the fuel lines and connections.</li><li>Check the engine RPM (at idle and full throttle)</li><li>Check the rear axle oil level.</li><li>Check the front planetary gear lube.</li></ul>
Every 800 hours	<ul style="list-style-type: none"><li>Drain and clean the fuel tank.</li><li>Change the hydraulic oil.</li><li>Change the hydraulic oil filters.</li><li>Change the front planetary gear lube.</li><li>Change the rear axle oil level.</li><li>Inspect the cutting unit drive belts.</li><li>Inspect the cutting unit castor wheel assemblies.</li><li>Inspect the side cutting unit damper.</li><li>Check the rear wheel toe-in.</li><li>Check and adjust the valve clearance.</li></ul>
Every 1500 hours or 2 years, whichever occurs first	<ul style="list-style-type: none"><li>Replace moving hoses.</li><li>Replace safety switches.</li><li>Flush the cooling system and replace fluid.</li></ul>

<sup>1</sup>If the indicator shows red

**Important** Refer to your engine operator's manual for additional maintenance procedures.

# Daily Maintenance Checklist

Duplicate this page for routine use.

Maintenance Check Item	For the week of:						
	Mon.	Tues.	Wed.	Thurs.	Fri.	Sat.	Sun.
Check the safety interlock operation.							
Check the brake operation.							
Check the engine oil and fuel level.							
Check the cooling system fluid level.							
Drain the water/fuel separator.							
Check the air filter restriction indicator.							
Check the radiator, oil cooler, and screen for debris.							
Check unusual engine noises. <sup>1</sup>							
Check unusual operating noises.							
Check the hydraulic system oil level.							
Check hydraulic hoses for damage.							
Check for fluid leaks.							
Check the tire pressure.							
Check the instrument operation.							
Lubricate all grease fittings. <sup>2</sup>							
Touch-up damaged paint.							


<sup>1</sup>Check the glow plug and injector nozzles if hard starting, excess smoke, or rough running is noted.

<sup>2</sup>immediately **after every** washing, regardless of the interval listed

## Notation for Areas of Concern

Inspection performed by:		
Item	Date	Information
1		
2		
3		
4		
5		
6		
7		
8		
9		
10		
11		
12		

## Service Interval Chart



### Caution



If you leave the key in the ignition switch, someone could accidentally start the engine and seriously injure you or other bystanders.

Remove the key from the ignition before you do any maintenance.

## Greasing the Bearings and Bushings

The machine has grease fittings that must be lubricated regularly with No. 2 General Purpose Lithium Base Grease. If the machine is operated under normal conditions, lubricate all bearings and bushings after every 50 hours of operation or immediately after every washing.

The grease fitting locations and quantities are:

### Traction Unit

- Brake shaft pivot bearings (5) (Fig. 31)
- Traction pedal pivot bushing (1) (Fig. 32)
- Front and rear axle pivot bushings (2) (Fig. 33)
- Steering cylinder ball joints (2) (Fig. 34)
- Tie rod ball joints (2) (Fig. 34)

- King pin bushings (2) (Fig. 34). The top fitting on the king pin should only be lubricated annually (2 pumps).






Figure 31



**Figure 32**



**Figure 33**



**Figure 34**

## Front Cutting Unit

- Castor fork shaft bushings (2) (Fig. 35)
- Spindle shaft bearings (3) (located under the pulley) (Fig. 36)



**Figure 35**



**Figure 36**

## Front Lift Assemblies

- Lift arm bushings (2) (Fig. 37)
- Lift cylinder bushings (4) (Fig. 37)
- Lift arm ball joints (2) (Fig. 38)



Figure 37




Figure 38

## Side Cutting Units

- Castor fork shaft bushing (1) (Fig. 39)
- Spindle shaft bearings (2 ea.) (located under the pulley)



Figure 39

## Side Lift Assemblies


- Main lift arm bushings (6) (Fig. 40 and 41),
- Bell crank pivot bushings (2) (Fig. 42)
- Rear arm bushings (4) (Fig. 42)
- Lift cylinder bushings (4) (Fig. 43)



**Figure 40**



**Figure 41**



**Figure 42**



**Figure 43**

## General Air Cleaner Maintenance

- Check the air cleaner body for damage which could cause an air leak. Replace if damaged. Check the whole intake system for leaks, damage or loose hose clamps.
- Service the air cleaner filter only when the service indicator requires it or every 400 hours (more frequently in extremely dusty or dirty conditions). Changing the air filter before it is necessary only increases the chance of dirt entering the engine when the filter is removed.
- Be sure the cover is seated correctly and seals with the air cleaner body.

## Servicing the Air Cleaner

1. Pull the latch outward and rotate the air cleaner cover counterclockwise (Fig. 44).
2. Remove the cover from the air cleaner body. Before removing the filter, use low pressure air (40 psi, clean and dry) to help remove large accumulations of debris packed between outside of primary filter and the canister. Avoid using high pressure air which could force dirt through the filter into the intake tract. This cleaning process prevents debris from migrating into the intake when the primary filter is removed.




Figure 44

1. Air cleaner indicator
2. Air cleaner latch
3. Air cleaner cover
4. Rubber outlet valve

3. Remove the primary filter (Fig. 45). Cleaning of the used element is not recommended due to the possibility of damage to the filter media. Inspect the new filter for shipping damage, checking the sealing end of the filter and the body. Do not use a damaged element. **Do not** remove the safety filter (Fig. 46).



Figure 45

1. Air cleaner primary filter




Figure 46

1. Air cleaner safety filter

**Important** Never attempt to clean the safety filter (Fig. 46). Replace the safety filter with a new one after every three primary filter services.

4. Replace the primary filter (Fig. 45).

- Insert the new filter by applying pressure to the outer rim of the element to seat it in the canister. Do not apply pressure to the flexible center of the filter.
- Clean the dirt ejection port located in the removable cover. Remove the rubber outlet valve from the cover, clean the cavity and replace the outlet valve.
- Install the cover orienting the rubber outlet valve (Fig. 44) in a downward position – between approximately 5:00 to 7:00 when viewed from the end. Secure the latch.

## Servicing the Engine Oil and Filter

Change the oil and filter initially after the first 50 hours of operation; thereafter change the oil and filter every 100 hours.

- Remove either drain plug (Fig. 47) and let the oil flow into a drain pan. When the oil stops, install the drain plug.




Figure 47

- Engine oil drain plug
- Remove the oil filter (Fig. 48). Apply a light coat of clean oil to the new filter seal before screwing it on. **Do not overtighten.**




Figure 48

- Engine oil filter
- Add oil to the crankcase; refer to Checking the Engine Oil, page 15.

## Servicing the Fuel System



### Danger



**Under certain conditions, diesel fuel and fuel vapors are highly flammable and explosive. A fire or explosion from fuel can burn you and others and can cause property damage.**

- Use a funnel and fill the fuel tank outdoors, in an open area, when the engine is off and is cold. Wipe up any fuel that spills.
- Do not fill the fuel tank completely full. Add fuel to the fuel tank until the level is 1/4 to 1/2 in. (6 to 13 mm) below the bottom of the filler neck. This empty space in the tank allows the fuel to expand.
- Never smoke when handling fuel, and stay away from an open flame or where fuel fumes may be ignited by a spark.
- Store fuel in a clean, safety-approved container and keep the cap in place.

### Fuel Tank

Drain and clean the fuel tank every 800 hours. Also, drain and clean the tank if fuel system becomes contaminated or if the machine will be stored for an extended period of time. Use clean fuel to flush out the tank.


### Fuel Lines and Connections

Check the fuel lines and connections every 400 hours or yearly, whichever comes first. Inspect them for deterioration, damage, or loose connections.

### Water Separator

Drain water or other contaminants from the water separator (Fig. 49) daily.

- Place a clean container under the fuel filter.
- Loosen the drain plug on the bottom of the filter canister (Fig. 49). Tighten the plug after draining.



**Figure 49**

1. Water Separator      2. Drain plug


Replace filter canister after every 400 hours of operation.

- A. Clean the area where the filter canister mounts.
- B. Remove the filter canister and clean the mounting surface.
- C. Lubricate the gasket on the filter canister with clean oil.
- D. Install the filter canister by hand until the gasket contacts the mounting surface; then rotate it an additional 1/2 turn.

### Replacing the Fuel Pre-Filter

Replace the fuel pre-filter (Fig. 50), located between fuel the tank and fuel pump, after every 400 operating hours or yearly, whichever occurs first.

3. Clamp both fuel lines that connect to the fuel filter so that fuel cannot drain when the lines are removed.
4. Loosen the hose clamps at both ends of the filter and pull the fuel lines off of the filter.




**Figure 50**

1. Fuel pre-filter

5. Slide the hose clamps onto the ends of the fuel lines. Push the fuel lines onto the fuel filter and secure them with the hose clamps. Be sure that the arrow on the side of the filter points toward the injection pump.

### Bleeding Air from the Injectors

1. Loosen the pipe connection to the No. 1 injector nozzle and holder assembly at the injection pump (Fig. 51).



**Figure 51**

1. No. 1 injector nozzle

2. Move the throttle to the Fast position.
3. Turn the key in the ignition switch to the Start position and watch the fuel flow around the connector. Turn the key to the Off position when solid flow is observed.
4. Tighten the pipe connector securely.
5. Repeat the procedure on the remaining nozzles.

# Servicing the Engine Cooling System

## Removing Debris

Remove debris from the oil cooler and radiator daily. Clean them more frequently in dirty conditions.

1. Turn the engine off and raise the hood. Clean the engine area thoroughly of all debris.
2. Remove the knobs (Fig. 52) securing the oil cooler to the frame.




Figure 52

1. Knobs
3. Pivot the oil cooler rearward. Clean both sides of the oil cooler and radiator area (Fig. 53) thoroughly with compressed air.

**Important** Cleaning the radiator or oil cooler with water can promote premature corrosion and damage to components.




Figure 53

1. Oil cooler
2. Radiator

4. Pivot the oil cooler back into position. Secure it to the frame with the knobs and close the hood.

## Servicing the Alternator Belt

Check the condition and tension of the belts (Fig. 54) after every 100 operating hours.

1. Proper tension will allow 3/8 in. (10 mm) deflection when a force of 10 lb. is applied on the belt midway between the pulleys.
2. If the deflection is not 3/8 in. (10 mm), loosen the alternator mounting bolts (Fig. 54). Increase or decrease the alternator belt tension and tighten the bolts. Check the deflection of the belt again to ensure that the tension is correct.




Figure 54

1. Alternator
2. Mounting bolt

## Adjusting the Throttle

Adjust the throttle cable (Fig. 55) so that the governor lever on the engine contacts the low and high speed set bolts before the throttle lever contacts the slot in the control panel.




Figure 55

1. Throttle cable

## Servicing the Spark Arrestor Muffler

Every 200 hours operation, clear the muffler of carbon buildup.

1. Remove the pipe plug from the clean-out port at the lower side of the muffler.



### Caution



**The muffler may be hot and could cause injury.**

**Be careful while working around the muffler.**

2. Start the engine. Plug the normal muffler exit with a block of wood or metal plate so that the exhaust flow will be forced out of the clean-out port. Continue to block the exit until carbon deposits cease coming out of the port.



### Caution



**Do not stand in line with the clean-out port.**

**Always wear safety glasses.**

3. Stop the engine and replace the pipe plug.

## Changing the Hydraulic Fluid

Change the hydraulic fluid after every 800 operating hours, in normal conditions. If the fluid becomes contaminated, contact your local Toro distributor because the system must be flushed. Contaminated fluid looks milky or black when compared to clean oil.

1. Turn the engine off and raise the hood.
2. Loosen the drain valve on the bottom of the reservoir and let the hydraulic fluid flow into large drain pan. Close the valve when the hydraulic fluid stops draining.
3. Fill the reservoir (Fig. 56) with approximately 8 gallons (30 l) of hydraulic fluid; refer to Checking the Hydraulic Fluid, page 17.

**Important** Use only the hydraulic fluids specified. Other fluids could cause system damage.



Figure 56

1. Hydraulic reservoir
4. Install the reservoir cap. Start the engine and use all of the hydraulic controls to distribute hydraulic fluid throughout the system. Also check for leaks; then stop the engine.
5. Check the fluid level and add enough to raise level the level to the FULL mark on the dipstick. **Do not overfill.**

## Replacing the Hydraulic Filters

Change the 2 hydraulic filters initially after the first 200 operating hours. Thereafter, change the filters after every 800 operating hours, in normal conditions.

Use Toro replacement filters (Part No. 94-2621 for the left side of the machine and 75-1310 for the right side of the machine).

**Important** Use of any other filter may void the warranty on some components.

1. Position the machine on a level surface, lower the cutting units, stop the engine, engage the parking brakes, and remove the ignition key.
2. Clean the area around the filter mounting area. Place a drain pan under the filter and remove the filter (Fig. 57).



**Figure 57**

1. Hydraulic filter (2)
3. Lubricate the new filter gasket and fill the filter with hydraulic fluid.
4. Ensure that the filter mounting area is clean. Screw the filter on until the gasket contacts the mounting plate; then tighten the filter an additional 1/2 turn.
5. Start the engine and let it run for about two minutes to purge air from the system. Stop the engine and check for leaks.

## Checking the Hydraulic Lines and Hoses

Inspect the hydraulic lines and hoses daily for leaks, kinked lines, loose mounting supports, wear, loose fittings, weather deterioration, and chemical deterioration. Make all necessary repairs before operating.

! **Warning** !

**Hydraulic fluid escaping under pressure can penetrate skin and cause injury.**

- Make sure all hydraulic fluid hoses and lines are in good condition and all hydraulic connections and fittings are tight before applying pressure to the hydraulic system.
- Keep your body and hands away from pin hole leaks or nozzles that eject high pressure hydraulic fluid.
- Use cardboard or paper to find hydraulic leaks.
- Safely relieve all pressure in the hydraulic system before performing any work on the hydraulic system.
- Seek immediate medical attention if fluid is injected into skin.

## Hydraulic System Test Ports

The test ports are used to test the pressure in the hydraulic circuits. Contact your local Toro distributor for assistance.


Test Port "A" (Fig. 58), located on the left side of the machine, is used to measure the forward traction pressure.



**Figure 58**

1. Test port "A"


Test Port "B" (Fig. 59), located on the right side of the machine, is used to measure the reverse traction pressure.



**Figure 59**

1. Test port "B"

Test Port "C" (Fig. 60), located on the left side of the machine, is used to measure the left cutting unit pressure.



**Figure 60**

1. Test port "C"


Test Port "D" (Fig. 61), located on the right side of the machine, is used to measure the right cutting unit pressure.



**Figure 61**

1. Test port "D"

Test Port "E" (Fig. 62), located under the radiator, is used to measure the four-wheel drive pressure in reverse.




**Figure 62**

1. Test port "E"

Test Port "F" (Fig. 63), located under the seat, is used to measure the lift circuit pressure.

Test Port "G" (Fig. 63), located under the seat, is used to measure the charge circuit pressure.




**Figure 63**

1. Test port "F"

2. Test port "G"

Test Port "H" (Fig. 64) is used to measure the front cutting unit circuit pressure.

Test Port "J" (Fig. 64) is used to measure the steering circuit pressure.




**Figure 64**

1. Test port "H"

2. Test port "J"

The counterbalance test port (Fig. 65) is used to adjust the pressure in the counterbalance circuit. Recommended counterbalance pressure is 470 psi (3241 kPa). To adjust

the counterbalance pressure, rotate the adjusting screw (Fig. 65) clockwise to increase the pressure or counterclockwise to decrease the pressure.




**Figure 65**

1. Counterbalance test port

2. Counterbalance adjusting screw

## Adjusting the Cutting Unit Flow Control

The flow control valve (Fig. 66) is used to adjust the rate at which the cutting unit lowers.



**Figure 66**


1. Flow control valve

## Adjusting the Traction Pedal Linkage

The traction pedal should reach full stroke at the same time it makes contact with the stop. If it does not, perform the following procedure:

1. Park the machine on a level surface, stop the engine, and lower the cutting units to the floor. Remove the ignition key.


- Check the traction pedal stop adjustment. The distance from the top of the stand to the top of the stop must be 1-1/2 in. (38 mm) (Fig. 67). Loosen the nuts and adjust, as required.



**Figure 67**

1. Traction pedal stop      2. Stand

- Loosen the jam nuts on the rod end and adjust the traction rod length (Fig. 68) so that the pedal contacts the pedal stop when the pump lever reaches full stroke. Secure the jam nuts.



**Figure 68**

1. Rod end      3. Neutral return spring assembly  
2. Traction rod      4. Jam nut

- Turn the key switch to the run position without starting the engine. Loosen the jam nut and adjust the neutral return spring assembly shaft length until the audible alarm begins to sound. Secure the jam nut.
- Turn the key switch off.

## Adjusting the Service Brakes

Adjust the service brakes when there is more than 1 in. (25 mm) of "free travel" of the brake pedal, or when the brakes do not work effectively. Free travel is the distance the brake pedal moves before braking resistance is felt.

- Disengage the locking latch from the brake pedals so that both pedals work independently of each other.
- To reduce free travel of the brake pedals, tighten the brakes:
  - Loosen the front nut on the threaded end of the brake cable.
  - Tighten the rear nut to move the cable backward until the brake pedals have 1/2 to 1 in. (13 to 25 mm) of free travel.
  - Tighten the front nuts after the brakes are adjusted correctly.

## Changing the Planetary Gear Drive Oil

Change the oil initially after first 200 hours of operation. Thereafter change the oil every 800 hours, or yearly, whichever occurs first. Use a high quality SAE 85W-140 wt. gear lube.


- With the machine on a level surface, position the wheel so that the check/drain plug (Fig. 69) is at the lowest position.



**Figure 69**

1. Check/drain plug

2. Place a drain pan under the hub, remove the plug, and allow the oil to drain.
3. When all of the oil has drained, position the wheel so that the plug hole is at the ten or two o'clock position.
4. Place a drain pan under the brake housing on the other side of the wheel (Fig. 70).
5. Remove the plug from the bottom of the housing and allow the oil to drain.
6. When all of the oil has drained, install the plug in the housing.
7. Add approximately 16 oz. (0.5 l) of high quality SAE 85W-140 wt. gear lube to the planetary fill hole (at the ten or two o'clock position) until the level is up to the bottom of the brake housing check hole. Install the plug.
8. Repeat the procedure on the opposite gear assembly.




**Figure 70**

1. Brake housing	3. Check plug
2. Drain plug	

## Changing the Rear Axle Lubricant


Change the oil initially after the first 200 hours of operation and every 800 hours of operation thereafter.

1. Position the machine on a level surface.
2. Clean the area around the 3 drain plugs, 1 on each end and 1 in the center (Fig. 71).
3. Remove the check plugs to ease in draining of the oil.
4. Remove the drain plugs and allow the oil to drain into the pans.



**Figure 71**

1. Drain plug location
5. Clean the area around the drain plug on the bottom of the gear box (Fig. 72).
6. Remove the drain plug from the gear box and allow the oil to drain into a pan. Remove the fill plug to ease in draining of the oil.



**Figure 72**


1. Drain plug
7. Add enough oil to bring the level up to the bottom of the check plug holes; refer to Checking the Rear Axle Lubricant, page 18, and Checking the Rear Axle Gear Box Lubricant, page 18.
8. Install the plugs.

## Checking the Rear Wheel Toe-In

After every 800 operating hours or annually, check the rear wheel toe-in.

1. Measure the center-to-center distance (at axle height) at the front and rear of the steering tires. The front measurement must be 1/4 in. (6 mm) less than the rear measurement.
2. To adjust, loosen the clamps at both ends of the tie rods.
3. Rotate the tie rod end to move the front of the tire inward or outward.
4. Tighten the tie rod clamps when the adjustment is correct.

## Activating, Charging, and Connecting the Battery




**Note:** If the battery is not filled with electrolyte or activated, bulk electrolyte with 1.260 specific gravity must be purchased from a local battery supply outlet and added to the battery.


1. Raise the seat and secure it with the prop rod.
2. Remove the battery cover (Fig. 73).



Figure 73

1. Battery cover
3. Remove the filler caps from the battery (Fig. 74) and slowly fill each cell until electrolyte is just above the plates.





**Figure 74**

1. Battery
4. Install the filler caps and connect a 3 to 4 amp. battery charger to the battery posts. Charge the battery at a rate of 3 to 4 amperes for 4 to 8 hours.

## Warning

Charging the battery produces gasses that can explode.

Never smoke near the battery and keep sparks and flames away from battery.

5. When the battery is charged, disconnect the charger from the electrical outlet and battery posts.
6. Remove the filler caps. Slowly add electrolyte to each cell until the level is up to the fill ring. Install the filler caps.

**Important** Do not overfill the battery. Electrolyte will overflow onto other parts of the machine and severe corrosion and deterioration will result.

7. Install the positive cable (red) to the positive (+) terminal and the negative cable (black) to the negative (—) terminal of the battery and secure them with the capscrews and nuts. Make sure that the positive (+) terminal is all of the way onto the post and the cable is positioned snug to the battery. The cable must not contact the battery cover. Slide the rubber boot over the positive terminal to prevent a possible short from occurring.

## Warning

**Battery terminals or metal tools could short against metal components causing sparks. Sparks can cause the battery gasses to explode, resulting in personal injury.**

- When removing or installing the battery, do not allow the battery terminals to touch any metal parts of the machine.
- Do not allow metal tools to short between the battery terminals and metal parts of the machine.

## Warning

**Incorrect battery cable routing could damage the machine and cables causing sparks. Sparks can cause the battery gasses to explode, resulting in personal injury.**

- Always *disconnect* the negative (black) battery cable before disconnecting the positive (red) cable.
- Always *connect* the positive (red) battery cable before connecting the negative (black) cable.

8. Coat both battery connections with Grafo 112X (skin-over) grease, Toro Part No. 505-47, petroleum jelly, or light grease to prevent corrosion. Slide the rubber boot over the positive terminal.

9. Install the battery cover.

## Battery Care

Battery type is group 24.

**Important** Before welding on the machine, disconnect the terminal connector from the alternator to prevent damage to the electrical system.

**Note:** Check the battery condition weekly or after every 50 hours of operation. Keep the terminals and the entire battery case clean because a dirty battery will discharge slowly. To clean the battery, wash the entire case with a solution of baking soda and water. Rinse with clear water. Coat the battery posts and cable connectors with Grafo 112X (skin-over) grease (Toro Part No. 505-47) or petroleum jelly to prevent corrosion.

## Fuses

There are 5 fuses in the electrical system. They are located below the operators control panel (Fig. 75 and 76).



Figure 75

1. Fuses




Figure 76

3. Move latch arm pivot in or out until rubber cushion of adjustment screw is centered under deck latch. Tighten flange nuts.




Figure 77

1. Latch arm pivot
2. Adjustment screw
3. Deck latch

4. Clearance between adjustment screw rubber (Fig. 78) cushion and deck latch should be .125". If an adjustment is required, loosen nut on adjustment screw, adjust screw until required clearance is attained and tighten nut.




Figure 78

1. Adjustment screw
2. Deck latch

## Adjusting the Transport Latch

If the transport latch (Fig. 77) has to be adjusted, adjust as follows:

1. Raise the front cutting unit fully off of the floor, set the parking brake, and stop the engine. Remove the ignition key.
2. Loosen flange nuts securing latch arm pivot to traction unit frame.


## Pivoting (Tilting) the Front Cutting Unit Upright

**Note:** Although not needed for normal maintenance procedures, the front cutting unit can be pivoted (tilted) to an upright position (Fig. 79). Should you desire to tilt the cutting unit, proceed as follows:



**Figure 79**


1. Raise the front cutting unit slightly off of the floor, set the parking brake, and stop the engine. Remove the ignition key.
2. Remove the hairpin cotter and clevis pin securing the deck transport latch to the latch plate (Fig. 80). Pivot latch toward rear of deck.



**Figure 80**

1. Transport latch      2. Latch plate

3. Remove the hairpin cotter and clevis pin securing the height-of-cut chains to the rear of the cutting unit.
4. Start the engine, slowly raise the front cutting unit, and stop the engine. Remove the ignition key.
5. Grasp the front of the cutting unit and lift it to an upright position.
6. Hold the cutting unit upright, fit the cable end over the pin on the cutting unit lift arm and secure it with the hairpin cotter (Fig. 81).



**Figure 81**

1. Cable      2. Pin

## Pivoting the Front Cutting Unit Down

1. With the help of another person, hold the cutting unit upright, remove the hairpin cotter securing the cable end, and remove the cable from the pin.
2. Pivot (tilt) the cutting unit downward.
3. Store the cable under the operator's platform.
4. Sit on the seat, start the engine, and lower the cutting unit until it is slightly off of the floor.
5. Secure the height-of-cut chains to the rear of the cutting unit.
6. Pivot transport latch upward into position and secure with clevis pin and cotter pin.


## Re-tensioning the Cutting Unit Drive Belts

Check the condition and tension of the cutting unit drive belts initially after 8 hours of operation and every 50 operating hours thereafter.

1. Loosen the nut on the idler until the pulley idler bolt can slide freely within the slot (Fig. 82).
2. The proper belt tension will be attained when a force of 45 lb. on a used belt is applied to the idler pulley (Fig. 82) when sliding it into the belt.

**Note:** When properly tensioned, the belt should deflect 3/4–7/8 in. when 10–12 lbs. of force is applied to the belt at the mid span between spindle pulley's.

3. Torque the idler nut to 60–70 ft-lbs.



**Figure 82**

1. Idler pulleys

## Adjusting the Cutting Unit Pitch


### Measuring the Cutting Unit Pitch

Cutting unit pitch is the difference in height-of-cut from the front of the blade plane to the back of the blade plane. Toro recommends a blade pitch of 1/4 in. (6 mm). That is the back of the blade plane is 1/4 in. (6 mm) higher than the front.

1. Position the machine on a level surface on the shop floor.
2. Set the cutting unit to the desired height-of-cut.
3. Rotate 1 blade so that it points straight forward.
4. Using a short ruler, measure from the floor to the front tip of the blade. Rotate the blade tip to the rear and measure from the floor to the tip of the blade.
5. Subtract the front dimension from the rear dimension to calculate the blade pitch.

### Adjusting the Front Cutting Unit

1. Loosen the jam nuts on the top or bottom of the height-of-cut chain u-bolt (Fig. 83).
2. Adjust the other set of nuts to raise or lower the rear of the cutting unit and attain the correct cutting unit pitch.
3. Tighten the jam nuts.




**Figure 83**

1. Height-of-cut chain
2. u-bolt

## Adjusting the Side Cutting Units

1. Remove the tensioning cap from the spindle shaft and slide the spindle out of the castor arm (Fig. 84). Reposition the shims, as required, to raise or lower the castor wheel until the cutting unit has the correct pitch.
2. Install the tensioning cap.



**Figure 84**

1. Castor wheel	4. Shims
2. Tensioning cap	5. Axle mounting holes
3. Spacers	

## Servicing the Castor Arm Bushings

The castor arms have bushings pressed into the top and bottom of the tube and after many hours of operation, the bushings will wear. To check the bushings, move the castor fork back and forth and from side to side. If the castor spindle is loose inside the bushings, the bushings are worn and must be replaced.

1. Raise the cutting unit so that the wheels are off of the floor. Block the cutting unit so that it cannot accidentally fall.
2. Remove the tensioning cap, spacer(s), and thrust washer from the top of the castor spindle.
3. Pull the castor spindle out of the mounting tube. Allow the thrust washer and spacer(s) to remain on the bottom of the spindle.
4. Insert a pin punch into the top or bottom of the mounting tube and drive the bushing out of the tube (Fig. 85). Also drive the other bushing out of the tube. Clean the inside of the tubes to remove dirt.




Figure 85

1. Castor arm tube      2. Bushings

5. Apply grease to the inside and outside of the new bushings. Using a hammer and flat plate, drive the bushings into the mounting tube.
6. Inspect the castor spindle for wear and replace it if it is damaged.
7. Push the castor spindle through the bushings and mounting tube. Slide the thrust washer and spacer(s) onto the spindle. Install the tensioning cap on the castor spindle to retain all parts in place.

## Servicing the Castor Wheels and Bearings

1. Remove the locknut from the capscrew holding the castor wheel assembly between the castor fork (Fig. 86) or the castor pivot arm (Fig. 87). Grasp the castor wheel and slide the capscrew out of the fork or pivot arm.




Figure 86

1. Castor wheel      3. Bearing (2)  
2. Castor fork      4. Bearing spacer




Figure 87

1. Castor wheel      3. Bearing (2)  
2. Castor pivot arm      4. Bearing spacer

2. Remove the bearing from the wheel hub and allow the bearing spacer to fall out (Fig. 86 and 87). Remove the bearing from the opposite side of the wheel hub.
3. Check the bearings, spacer, and inside of the wheel hub for wear. Replace any damaged parts.
4. To assemble the castor wheel, push the bearing into the wheel hub. When installing the bearings, press on the outer race of the bearing.
5. Slide the bearing spacer into the wheel hub. Push the other bearing into the open end of the wheel hub to captivate the bearing spacer inside the wheel hub.
6. Install the castor wheel assembly between the castor fork and secure it in place with the capscrew and locknut.

## Checking for a Bent Blade

After striking a foreign object, inspect the machine for damage and make repairs before restarting and operating the equipment. Torque all the spindle pulley nuts to 130–150 ft-lbs.

1. Position the machine on a level surface. Raise the cutting unit, engage the parking brake, put the traction pedal in neutral, put the PTO lever in the Off position, stop the engine, and remove the ignition key. Block the cutting unit to prevent it from accidentally falling.
2. Rotate the blade until the ends face forward and backward (Fig. 88). Measure from the inside of the cutting unit to the cutting edge at the front of the blade. Remember this dimension.



Figure 88

3. Rotate the opposite end of the blade forward. Measure between the cutting unit and cutting edge of the blade at the same position as in step 2. The difference between the dimensions obtained in steps 2 and 3 must not exceed 1/8 in. (3 mm). If the dimension exceeds 1/8 in. (3 mm), the blade is bent and must be replaced; refer to Removing the Cutter Blade, page 53.

## Removing and Installing the Cutter Blade(s)

The blade must be replaced if a solid object is hit, the blade is out of balance, or if the blade is bent. Always use genuine Toro replacement blades to be sure of safety and optimum performance. Never use replacement blades made by other manufacturers because they could be dangerous.

1. Raise the cutting unit to the highest position, engage the parking brake, stop the engine, and remove the ignition key. Block the cutting unit to prevent it from accidentally falling.
2. Grasp the end of the blade using a rag or thickly padded glove. Remove the blade bolt, anti-scalp cup, and blade from the spindle shaft (Fig. 89).
3. Install the blade, anti-scalp cup, and blade bolt. Tighten the blade bolt to 85–110 ft.-lb. (115–149 N·m).

**Important** The curved part of the blade must be pointing toward the inside of the cutting unit to ensure proper cutting.

**Note:** After striking a foreign object, torque all the spindle pulley nuts to 130–150 ft-lbs.




Figure 89

1. Blade bolt

2. Anti-scalp cup

## Inspecting and Sharpening the Cutter Blade(s)



### Danger



A worn or damaged blade can break, and a piece of the blade could be thrown into the operator's or bystander's area, resulting in serious personal injury or death. Trying to repair a damaged blade may result in discontinued safety certification of the product.

- Inspect the blade periodically for wear or damage.
- Never try to straighten a blade that is bent or weld a broken or cracked blade.
- Replace a worn or damaged blade.

Two areas must be considered when checking and servicing the cutter blade—the sail and the cutting edge. Both cutting edges and the sail, which is the turned up portion opposite the cutting edge, contribute to a good quality-of-cut. The sail is important because it lifts the grass up straight, thereby producing an even cut. However, the sail will gradually wear down during operation, and this condition is normal. As the sail wears down, the quality-of-cut will degrade somewhat, although the cutting edges are sharp. The cutting edge of the blade must be sharp so that the grass is cut rather than torn. A dull cutting edge is evident when the tips of the grass appear brown and shredded. Sharpen the cutting edges to correct this condition.

1. Position the machine on a level surface. Raise the cutting unit, engage the parking brake, put the traction pedal in neutral, put the PTO lever in the Off position, stop the engine, and remove the ignition key.
2. Examine the cutting ends of the blade carefully, especially where the flat and curved parts of the blade meet (Fig. 90-A). Since sand and abrasive material can wear away the metal that connects the flat and curved parts of the blade, check the blade before using the mower. If wear is noticed (Fig. 90-B), replace the blade.




Figure 90

- Examine the cutting edges of all of the blades. Sharpen the cutting edges if they are dull or nicked. Sharpen only the top of the cutting edge and maintain the original cutting angle to make sure of sharpness (Fig. 91). The blade will remain balanced if the same amount of metal is removed from both cutting edges.





Figure 91

**Note:** Remove the blades and sharpen them on a grinder. After sharpening the cutting edges, install the blade with the anti-scalp cup and blade bolt; refer to Removing and Installing the Cutter Blade(s), page 53.

## Correcting Cutting Unit Mismatch

If there is mismatch between the blades, on a single cutting unit, the grass will appear streaked when it is cut. This problem can be corrected by making sure that the blades are straight and all of the blades are cutting on the same plane.

- Using a 3 foot (1 meter) long carpenters level, find a level surface on the shop floor.
- Raise the height-of-cut to the highest position; refer to Adjusting the Height-Of-Cut, page 19.
- Lower the cutting unit onto the flat surface. Remove the covers from the top of the cutting unit.
- Loosen the flange nut securing the idler pulley to release the belt tension.
- Rotate the blades until the ends face forward and backward. Measure from the floor to the front tip of the cutting edge. Remember this dimension. Then rotate the same blade so that the opposite end is forward, and measure again. The difference between the dimensions must not exceed 1/8 in. (3 mm). If the dimension exceeds 1/8 in. (3 mm), replace the blade because it is bent. Make sure to measure all of the blades.
- Compare the measurements of the outer blades with the center blade. The center blade must not be more than 3/8 in. (10 mm) lower than the outer blades. If the center blade is more than 3/8 in. (10 mm) lower than the outer blades, proceed to step 7 and add shims between the spindle housing and the bottom of the cutting unit.
- Remove the capscrews, flat washers, lock washers, and nuts from the outer spindle in the area where the shims must be added. To raise or lower the blade, add a shim, Part No. 3256-24, between the spindle housing and the bottom of the cutting unit. Continue to check the alignment of the blades and add shims until the tips of the blades are within the required dimension.


**Important** Do not use more than three shims at any one hole location. Use decreasing numbers of shims in adjacent holes if more than one shim is added to any one hole location.

- Adjust the idler pulley and install the belt covers.

## Replacing the Drive Belt

The blade drive belt, tensioned by the stationary idler pulley, is very durable. However, after many hours of use, the belt will show signs of wear. Signs of a worn belt are: squealing when belt is rotating, blades slipping when cutting grass, frayed edges, burn marks and cracks. Replace the belt if any of these conditions are evident.

1. Lower the cutting unit to the shop floor. Remove the belt covers from the top of the cutting unit and set the covers aside.
2. Loosen the nut securing the idler pulley to the cutting unit (Fig. 82). Move the pulley away from the belt to release the belt tension.
3. Remove the bolts securing the hydraulic motor to the cutting unit (Fig. 92). Lift the motor off of the cutting unit and lay it on top of the cutting unit.



**Figure 92**


1. Hydraulic motor      2. Mounting bolts

4. Remove the old belt from around the spindle pulleys and idler pulley.
5. Route the new belt around the spindle pulleys and idler pulley assembly.
6. Position the hydraulic motor on the cutting unit after routing the belt around the pulleys. Mount the motor to the cutting unit with bolts removed in step 3.
7. The proper belt tension will be attained when a force of 60 lb., on a new belt, is applied to the idler pulley (Fig. 82) when sliding it into the belt.


**Note:** When properly tensioned, the belt should deflect 5/8–3/4 in. when 10–12 lbs. of force is applied to the belt at the mid span between spindle pulley's.

8. Torque the idler nut to 60–70 ft-lbs.

# Electrical Schematic



# Hydraulic Schematic



# Preparing for Seasonal Storage

## Traction Unit

1. Thoroughly clean the traction unit, cutting units, and the engine.
2. Check the tire pressure; refer to Checking the Tire Pressure, page 19.
3. Check all fasteners for looseness; tighten as necessary.
4. Grease or oil all grease fittings and pivot points. Wipe up any excess lubricant.
5. Lightly sand and use touch-up paint on painted areas that are scratched, chipped, or rusted. Repair any dents in the metal body.
6. Service the battery and cables as follows:
  - A. Remove the battery terminals from the battery posts.
  - B. Clean the battery, terminals, and posts with a wire brush and baking soda solution.
  - C. Coat the cable terminals and battery posts with Grafo 112X skin-over grease (Toro Part No. 505-47) or petroleum jelly to prevent corrosion.
  - D. Slowly recharge the battery every 60 days for 24 hours to prevent lead sulfation of the battery.

## Engine

1. Drain the engine oil from the oil pan and install the drain plug.
2. Remove and discard the oil filter. Install a new oil filter.
3. Refill the oil pan with 8 qt. (7.6 l) of SAE 10W-30 CD, CE, CF, CF-4, or CG-4 motor oil.
4. Start the engine and run it at idle speed for approximately two minutes.
5. Stop the engine.
6. Flush the fuel tank with fresh, clean diesel fuel.
7. Secure all of the fuel system fittings.
8. Thoroughly clean and service the air cleaner assembly.
9. Seal the air cleaner inlet and the exhaust outlet with weatherproof tape.
10. Check the anti freeze protection and add a 50/50 solution of water and ethylene glycol anti-freeze as needed for the expected minimum temperature in your area.





## The Toro General Commercial Products Warranty

### A Two-Year Limited Warranty

#### Conditions and Products Covered

The Toro Company and its affiliate, Toro Warranty Company, pursuant to an agreement between them, jointly warrant your Toro Commercial Product ("Product") to be free from defects in materials or workmanship for two years or 1500 operational hours\*, whichever occurs first. Where a warrantable condition exists, we will repair the Product at no cost to you including diagnosis, labor, parts, and transportation. This warranty begins on the date the Product is delivered to the original retail purchaser.

\* Product equipped with hour meter

#### Instructions for Obtaining Warranty Service

You are responsible for notifying the Commercial Products Distributor or Authorized Commercial Products Dealer from whom you purchased the Product as soon as you believe a warrantable condition exists.

If you need help locating a Commercial Products Distributor or Authorized Dealer, or if you have questions regarding your warranty rights or responsibilities, you may contact us at:

Toro Commercial Products Service Department  
Toro Warranty Company  
8111 Lyndale Avenue South  
Bloomington, MN 55420-1196  
952-888-8801 or 800-982-2740  
E-mail: [commercial.service@toro.com](mailto:commercial.service@toro.com)

#### Owner Responsibilities

As the Product owner, you are responsible for required maintenance and adjustments stated in your operator's manual. Failure to perform required maintenance and adjustments can be grounds for disallowing a warranty claim.

#### Items and Conditions Not Covered

Not all product failures or malfunctions that occur during the warranty period are defects in materials or workmanship. This express warranty does not cover the following:

- Product failures which result from the use of non-Toro replacement parts, or from installation and use of add-on, modified, or unapproved accessories
- Product failures which result from failure to perform required maintenance and/or adjustments
- Product failures which result from operating the Product in an abusive, negligent or reckless manner
- Parts subject to consumption through use unless found to be defective. Examples of parts which are consumed, or used up, during normal Product operation include, but are not limited to, blades, reels, bedknives, tines, spark plugs, castor wheels, tires, filters, belts, and certain sprayer components such as diaphragms, nozzles, and check valves, etc.

#### Countries Other than the United States or Canada

Customers who have purchased Toro products exported from the United States or Canada should contact their Toro Distributor (Dealer) to obtain guarantee policies for your country, province, or state. If for any reason you are dissatisfied with your Distributor's service or have difficulty obtaining guarantee information, contact the Toro importer. If all other remedies fail, you may contact us at Toro Warranty Company.

- Failures caused by outside influence. Items considered to be outside influence include, but are not limited to, weather, storage practices, contamination, use of unapproved coolants, lubricants, additives, or chemicals, etc.
- Normal "wear and tear" items. Normal "wear and tear" includes, but is not limited to, damage to seats due to wear or abrasion, worn painted surfaces, scratched decals or windows, etc.

#### Parts

Parts scheduled for replacement as required maintenance are warranted for the period of time up to the scheduled replacement time for that part.

Parts replaced under this warranty become the property of Toro. Toro will make the final decision whether to repair any existing part or assembly or replace it. Toro may use factory remanufactured parts rather than new parts for some warranty repairs.

#### General Conditions

Repair by an Authorized Toro Distributor or Dealer is your sole remedy under this warranty.

**Neither The Toro Company nor Toro Warranty Company is liable for indirect, incidental or consequential damages in connection with the use of the Toro Products covered by this warranty, including any cost or expense of providing substitute equipment or service during reasonable periods of malfunction or non-use pending completion of repairs under this warranty. Except for the Emissions warranty referenced below, if applicable, there is no other express warranty. All implied warranties of merchantability and fitness for use are limited to the duration of this express warranty.**

Some states do not allow exclusions of incidental or consequential damages, or limitations on how long an implied warranty lasts, so the above exclusions and limitations may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

**Note regarding engine warranty:** The Emissions Control System on your Product may be covered by a separate warranty meeting requirements established by the U.S. Environmental Protection Agency (EPA) and/or the California Air Resources Board (CARB). The hour limitations set forth above do not apply to the Emissions Control System Warranty. Refer to the Engine Emission Control Warranty Statement printed in your operator's manual or contained in the engine manufacturer's documentation for details.