



LCE Products

Z Master 500 Series

Gasoline Engine Models

Service Manual



ABOUT THIS MANUAL

This service manual was written expressly for Toro service technicians. The Toro Company has made every effort to make the information in this manual complete and correct.

Basic shop knowledge and mechanical/electrical skills are assumed. The Table of Contents lists the systems and the related topics covered in this manual.

The following service materials are available in addition to this service manual:

Hydrostatic Pumps:	Hydro-Gear BDP-10A/16A/21L - Service and Repair Manual Form #492-4789
Wheel Motors:	Parker/Ross Wheel Motor Service Manual Form #492-4753
Gas Engine:	Through engine manufacturer
Hydraulic Troubleshooting:	Interactive hydraulic troubleshooting and failure analysis on compact disk Form #492-4777
Electrical Troubleshooting:	Interactive electrical troubleshooting and wiring diagrams on compact disk Form #492-9143

Z Master 500 Series gasoline engine machines, model years 2004 and 2005 are covered in this manual. This manual may also be specified for use on later model products.

The hydrostatic drive system is precision machinery. Maintain strict cleanliness control during all stages of service and repair. Cover or cap all hose ends and fittings whenever they are exposed. Even a small amount of dirt or other contamination can severely damage the system.

We are hopeful that you will find this manual a valuable addition to your service shop. If you have any questions or comments regarding this manual, please contact us at the following address:

**The Toro Company
LCE Service Training Department
8111 Lyndale Avenue South
Bloomington, MN 55420**

The Toro Company reserves the right to change product specifications or this manual without notice.

THIS PAGE INTENTIONALLY LEFT BLANK.

TABLE OF CONTENTS

SAFETY INFORMATION

General Information	1-2
Think Safety First	1-2

SPECIFICATIONS

Kawasaki Liquid Cooled Product Shots	2-2
Kohler EFI Product Shots	2-3
Kohler Gas Product Shots	2-4
Kawasaki Gas Product Shots	2-5
Engines	2-6
Dimensions and Weight	2-7
Construction	2-7
Fuel System	2-7
Traction System	2-8
Deck Drive	2-8
Tires	2-8
Electrical System	2-8
Cutting Decks	2-9
General Specifications	
Greasing and Lubrication	2-10
Model and Serial Number Locations	2-11
Available Service Manuals	2-11
Torque Specifications	2-12
Standard Torque for Dry, Zinc Plated, and Steel Fasteners (Inch Series)	2-13
Standard Torque for Dry, Zinc Plated, and Steel Fasteners (Metric Fasteners)	2-14
Other Torque Specifications	
SAE Grade 8 Steel Set Screws	2-15
Thread Cutting Screws (Zinc Plated Steel)	2-15
Wheel Bolts and Lug Nuts	2-15
Thread Cutting Screws (Zinc Plated Steel)	2-15
Equivalents and Conversions	2-16
US to Metric Conversions	2-17

CHASSIS

Caster Fork Assembly Removal	3-2
Replacing the Caster Bearings	3-2
Caster Fork Assembly	3-4
Front Wheel Removal and Bearing Replacement	3-5
Fuel Tank Removal	
Left Side Fuel Tank Removal	3-6
Left Side Fuel Tank Installation	3-7
Right Side Fuel Tank Removal and Installation	3-7
Hood Assembly Removal	3-8
Hood Assembly Installation	3-8
Brake Lever Removal	3-8
Brake Lever Installation	3-10
Brake Band Removal	3-10
Brake Band Installation	3-10
Brake Shaft Removal	3-11
Brake Shaft Installation	3-13
Adjusting the Parking Brake	3-13
Deck Lift Lever Removal	3-13
Deck Lift Lever Installation	3-17

TABLE OF CONTENTS

CHASSIS cont.

Motion Control Assembly Removal	3-20
Motion Control Assembly Installation	3-22

HYDRAULIC SYSTEM

Hydrostatic Pump Removal	4-2
Hydrostatic Pump Installation	4-4
Wheel Motor Removal	4-7
Wheel Motor Installation	4-9
Adjusting the Handle Neutral	4-12
Setting the Hydraulic Pump Neutral	4-14
Setting the RH Hydraulic Pump Neutral	4-14
Setting the LH Hydraulic Pump Neutral	4-15
Adjusting the Tracking	4-16
Replacing the Pump Drive Belt	4-17
Purging the Hydraulic System	4-18
Hydraulic Flow Testing Procedure	4-18
Pushing the Machine by Hand	4-20
Changing to Machine Operation	4-21

ENGINE

Kohler Air-Cooled Engine Removal	5-2
Kohler Air-Cooled Engine Installation	5-5
Kawasaki Air-Cooled Engine Removal	5-8
Kawasaki Air-Cooled Engine Installation	5-10
28 HP Kohler EFI Air-Cooled Engine Removal	5-13
28 HP Kohler EFI Air-Cooled Engine Installation	5-19
Kohler Electronic Fuel Injection (EFI) Models	
EFI Fuel System	5-24
EFI Electrical System	5-25
27 HP Kawasaki Liquid-Cooled Engine Removal	5-26
27 HP Kawasaki Liquid-Cooled Engine Installation	5-33
Cooling Fan Assembly Removal - 27 HP Kawasaki Liquid-Cooled Engine	5-41
Cooling Fan Assembly Installation	5-43

ELECTRICAL

General	6-2
Relays	6-2
PTO Switch	6-4
Ignition Switch	6-6
Neutral Safety Switch	6-7
Park Brake Switch	6-8
Seat Switch	6-9
Seat Delay Module	6-11
Temperature Gauge Liquid-Cooled Engine Only	6-12
Temperature Sender	6-14
Hour Meter	6-14
Voltmeter Gauge	6-15
Electric PTO Clutch	6-16
Coil Resistance Measurement	6-17
Measuring Clutch Current Draw	6-17
Kohler EFI Wiring Diagram	6-18
Kohler A/C (Air Cooled) Wiring Diagram	6-19

TABLE OF CONTENTS

ELECTRICAL cont.

Kawasaki A/C (Air Cooled) Wiring Diagram	6-20
Kawasaki L/C (Liquid Cooled) Wiring Diagram	6-21

MOWER DECKS/PTO

Electric PTO Clutch Removal	7-2
Electric PTO Clutch Installation	7-4
Mower Deck Removal (52, 60, 72")	7-8
Mower Deck Installation (52, 60, 72")	7-11
Mower Spindle Removal	7-14
Mower Spindle Installation	7-15
Mower Spindle Disassembly	7-16
Mower Spindle Assembly	7-19
Replacing the Mower Belt	7-24
Adjusting the Mower Belt Tension	7-25
Leveling the Mower	
Setting up the Machine	7-27
Leveling the Mower Side-to-Side	7-28
Adjusting the Front-to-Rear Mower Pitch	7-29

TABLE OF CONTENTS

THIS PAGE INTENTIONALLY LEFT BLANK.

Safety Information	1
Specifications	2
Chassis	3
Hydraulic System	4
Engine	5
Electrical	6
Mower Decks/PTO	7

SAFETY INFORMATION

General Information

1



This symbol means WARNING or PERSONAL SAFETY INSTRUCTION - read the instruction because it has to do with your safety. Failure to comply with the instruction may result in personal injury or even death.

This manual is intended as a service and repair manual only. The safety instructions provided herein are for troubleshooting, service, and repair of the Z Master Z500 Series Zero-turn Riding Mower.

The riding mower and attachment operator's manual contain safety information and operating tips for safe operating practices. Operator's manuals are available through your Toro parts source or:

**The Toro Company
Publications Department
8111 Lyndale Avenue South
Bloomington, MN 55420**

Think Safety First

Avoid unexpected starting of engine...

Always turn off the engine and disconnect the spark plug wire(s) before cleaning, adjusting, or repair

Avoid lacerations and amputations...

Stay clear of all moving parts whenever the engine is running. Treat all normally moving parts as if they were moving whenever the engine is running or has the potential to start.

Avoid burns...

Do not touch the engine, muffler, or other components which may increase in temperature during operation, while the unit is running or shortly after it has been running.

Avoid fires and explosions...

Avoid spilling fuel and never smoke while working with any type of fuel or lubricant. Wipe up any spilled fuel or oil immediately. Never remove the fuel cap or add fuel when the engine is running. Always use approved labeled containers for storing or transporting fuel and lubricants.

Avoid asphyxiation...

Never operate an engine in a confined area without proper ventilation.

Avoid injury from batteries...

Battery acid is poisonous and can cause burns. Avoid contact with skin, eyes, and clothing. Battery gases can explode. Keep cigarettes, sparks, and flames away from the battery.

Avoid injury due to inferior parts...

Use only original equipment parts to ensure that important safety criteria are met.

Avoid injury to bystanders...

Always clear the area of bystanders before starting or testing powered equipment.

Avoid injury due to projectiles...

Always clear the area of sticks, rocks, or any other debris that could be picked up and thrown by the powered equipment.

Avoid modifications...

Never alter or modify any part unless it is a factory approved procedure.

Avoid unsafe operation...

Always test the safety interlock system after making adjustments or repairs on the machine. Refer to the Electrical section in this manual for more information.

Safety Information 1

Specifications 2

Chassis 3

Hydraulic System 4

Engine 5

Electrical 6

Mower Decks/PTO 7

SPECIFICATIONS

Kawasaki Liquid Cooled Product Shots

2



Fig 001

DSC-2861a



Fig 003

DSC-3792a



Fig 002

DSC-2860a



Fig 004

DSC-2864a

SPECIFICATIONS

Kohler EFI Product Shots



Fig 005

DSC-2865b



Fig 007

DSC-2867a



Fig 006

DSC-2866a



Fig 008

DSC-2868a

SPECIFICATIONS

Kohler Gas Product Shots

2



Fig 009

DSC-2870a



Fig 011

DSC-2875a



Fig 010

DSC-2869a



Fig 012

DSC-2874a

SPECIFICATIONS

Kawasaki Gas Product Shots



Fig 013

DSC-2877a



Fig 015

DSC-2880a



Fig 014

DSC-2879a



Fig 016

DSC-2882a

SPECIFICATIONS

Engines

Output	Make	High Idle	Low Idle	Charging Coil
20 HP (14.9kW)	Kohler OHV V-Twin Air Cooled	3750 +50/-100 RPM	1500 RPM	15 AMP
23 HP (17.2 kW)	Kohler OHV V-Twin Air Cooled	3750 +50/-100 RPM	1500 RPM	15 AMP
25 HP (18.6 kW)	Kawasaki OHV V-Twin Air Cooled	3750 +50/-100 RPM 3000 \pm 100 Int'l	1500 RPM	13 AMP
27 HP (20.1 kW)	Kohler OHV V-Twin Air Cooled	3750 +50/-100 RPM	1500 RPM	15 AMP
27 HP (20.1 kW)	Kawasaki OHV V-Twin Liquid Cooled	3750 +50/-100 RPM	2250 RPM	30 AMP
28 HP (20.8 kW)	Kohler OHV V-Twin EFI Air-Cooled	3750 +50/-100 RPM	1500 RPM	25 AMP

SPECIFICATIONS

Dimensions and Weight

Model	Weight	ROPS Height		Width		
		Folded	Upright	Deck	Deflector	Length
23 hp Kohler/52" TF Deck	1140 lbs (517kg)	53" (134cm)	72" (183cm)	53.7" (136cm)	68" (173cm)	79.5" (202cm)
23 hp Kohler/60" TF Deck	1215 lbs (551kg)	53" (134cm)	72" (183cm)	61.7" (157cm)	76" (193cm)	81.5" (207cm)
25 hp Kawasaki/60" TF Deck	1215 lbs (551kg)	53" (134cm)	72" (183cm)	61.7" (157cm)	76" (193cm)	81.5" (207cm)
27 hp Kohler/52" TF Deck	1176 lbs (533kg)	53" (134cm)	72" (183cm)	53.7" (136cm)	68" (173cm)	79.5" (202cm)
27 hp Kohler/60" TF Deck	1215 lbs (551kg)	53" (134cm)	72" (183cm)	61.7" (157cm)	76" (193cm)	81.5" (207cm)
27 hp Kohler/72" TF Deck	1280 lbs (583kg)	53" (134cm)	72" (183cm)	73.6" (187cm)	88" (223cm)	84.5" (215cm)
27 hp Kawasaki LC/60"TF Deck	1330 lbs (603kg)	53" (134cm)	72" (183cm)	61.7" (157cm)	76" (193cm)	81.5" (207cm)
27 hp Kawasaki LC/72"TF Deck	1395 lbs (633kg)	53" (134cm)	72" (183cm)	73.6" (187cm)	88" (223cm)	84.5" (215cm)
28 hp Kohler EFI/60" TF Deck	1254 lbs (569kg)	53" (134cm)	72" (183cm)	61.7" (157cm)	76" (193cm)	81.5" (207cm)
28 hp Kohler EFI/72" TF Deck	1319 lbs (598kg)	53" (134cm)	72" (183cm)	73.6" (187cm)	88" (223cm)	84.5" (215cm)

Construction

Frame Assembly	Consists of front and rear frames bolted together
Front Frame	Welded 2 x 2 x .188 structural steel tube
Rear Frame	Welded tube and fabricated steel

Fuel System

Tanks	Dual fuel tanks containing large fill necks and vented caps Mounted above the drive wheels
Capacity	12 gallons (45.4l) [6 gallons per tank]
Check Valve	In-line check valves (Selector valve on EFI units)
Fuel Filter	40 micron, replaceable in-line filter

SPECIFICATIONS

Traction System

Hydraulic Pumps	Twin Hydro-Gear BDP/PJ Series variable displacement hydrostatic with shock valves
Pump Drive	Self-tensioning belt drive
Wheel Motors	Twin Parker-Ross Torqmotor™ positive displacement with 1.25 inch heavy duty tapered shafts
Ground Speeds	Infinitely variable: Forward: 0 - 10 mph (16.1 km/hr) Reverse: 0 - 6.3 mph (10.1 km/hr)
Release Valves	Contained in pumps. Allow unit to be moved without engine running
Hydraulic Fluid	Mobil 1, 15W50 (Synthetic motor oil)
System Capacity	2.1 quarts (2.0l)

Deck Drive

Clutch	Warner® Electromagnetic “Mag-Stop” with 200 ft-lb. (271 Nm) rating
Type	Mule drive from engine to deck
Take-Up	Spring-loaded idler system

Tires

Rear Drive Tires	4-ply with “Turf Master” tread 24” x 12.0” – 12 [Models with 62” or 72” deck] 23” x 9.5” – 12 [Models with 52” deck]
Front Caster Tires	4-ply with smooth tread 13” x 6.5” – 6
Tire Pressure	13 psi (90 kpa)

Electrical System

Voltage	12 volt, negative ground
Battery Type	BCI group U1
Fuses	Blade Type

Cutting Decks

Configuration	Side discharge, mid-mounted rotary with three blades.
Construction	7 gauge, high strength 50,000 psi steel, 5-1/2" deep, advanced, super flow system, welded construction. 3/8" steel discharge reinforcement plate doubles as bagger attachment point.
Discharge	Right hand as viewed from operator seat. Rubber chute, spring biased down toward operating position. Adjustable flow control baffle.
Blade Tip Speed	18,000 + ft/min at high idle 152cm mower – 4600.7 m/min @3000 RPM
Height of Cut	Adjustable from the seat with range 1.5" – 5" in 1/4" increments (3.8cm - 12.7cm)
Deck Suspension	Deck suspended from machine by four lift chains, and attached to rear wheel supports by two struts.
Belt Covers	16-gauge, formed steel covers. Attached with swell latches.
Gauge Wheels	52" Cutting Deck – Five adjustable gauge wheels to reduce scalping: three on front of deck (one on left-hand side and two in center) and two on rear of deck (left and right sides). Wheels have four adjustment positions.
	60", 72", and 152cm Cutting Decks – Six adjustable gauge wheels to reduce scalping: four on front of deck (one each left-hand and right-hand sides, and two center) and two on rear of deck (left and right sides). Wheels have four positions.
Lubrication Fittings:	
Front Castor Pivots	2 removable plugs (1 per side) for periodic lubrication.
Front Castor Wheels	2 fittings (1 per side).
Lift Assembly	5 fittings.
Mule Drive Idler	1 fitting.
Brake Arms	2 fittings (1 per side).
Rear Deck Struts	2 fittings (1 per side).
Deck Spindles	3 fittings (1 per spindle).
Hydraulic Pump Drive Tensioner	1 fitting.

SPECIFICATIONS

Model and Serial Number Location	The unit model and serial number plate is located on the right hand side of the unit, below the right side motion control lever (Fig. 019).
----------------------------------	---



Fig 019

DSC-2351




Fig 020

configuration

Engine Model and Serial Number Identification:	Consult the appropriate engine manufacture's service literature for the location and translation of the engine model and serial number information.
Hydrostatic Pumps Model and Serial Number:	The label above (Fig. 020), is located on the pump housing. It identifies the model and configuration of the BDP pump.

Available Service Manuals

Hydrostatic Pumps:	Hydro-Gear BDP-10A/16A/21L – Service and Repair Manual Form # 492-4789
Wheel Motors:	Parker/Ross Wheel Motor Service Manual Form # 492-4753
Engine:	Engine manufacturer
Hydraulic Troubleshooting:	Interactive hydraulic troubleshooting and failure analysis on compact disk Form #492-4777
Electrical Troubleshooting:	Interactive electrical troubleshooting and wiring diagrams on compact disk Form #492-9143

SPECIFICATIONS

Torque Specifications

Recommended fastener torque values are listed in the following tables. For critical applications, as determined by Toro, either the recommended torque or a torque that is unique to the application is clearly identified and specified in the service manual.

These torque specifications for the installation and tightening of fasteners shall apply to all fasteners which do not have a specific requirement identified in the service manual. The following factors shall be considered when applying torque: cleanliness of the fastener, use of a thread sealant (Loctite), degree of lubrication on the fastener, presence of a prevailing torque feature, hardness of the surface underneath of the fastener's head, or similar condition which affects the installation.

As noted in the following tables, torque values should be **reduced by 25% for lubricated fasteners** to achieve the similar stress as a dry fastener. Torque values may also have to be reduced when the fastener is threaded into aluminum or brass. The specific torque value should be determined based on the aluminum or brass material strength, fastener size, length of thread engagement, etc.

The standard method of verifying torque shall be performed by marking a line on the fastener (head or nut) and mating part, then back off fastener 1/4 of a turn. Measure the torque required to tighten the fastener until the lines match up.

Fastener Identification




Figure A

Inch Series Bolts and Screws	
(A) Grade 1	(C) Grade 8
(B) Grade 5	




Figure B

Metric Bolts and Screws	
(A) Class 8.8	(B) Class 10.9

SPECIFICATIONS

2

Standard Torque for Dry, Zinc Plated, and Steel Fasteners (Inch Series)

Thread Size	Grade 1, 5, & 8 with Thin Height Nuts	SAE Grade 1 Bolts, Screws, Studs, & Sems with Regular Height Nuts (SAE J995 Grade 2 or Stronger Nuts)		SAE Grade 5 Bolts, Screws, Studs, & Sems with Regular Height Nuts (SAE J995 Grade 2 or Stronger Nuts)		SAE Grade 8 Bolts, Screws, Studs, & Sems with Regular Height Nuts (SAE J995 Grade 2 or Stronger Nuts)	
	In-lb	In-lb	N-cm	In-lb	N-cm	In-lb	N-cm
# 6 - 32 UNC	10 ± 2	13 ± 2	147 ± 23	15 ± 2	170 ± 20	23 ± 2	260 ± 20
# 6 - 40 UNF				17 ± 2	190 ± 20	25 ± 2	280 ± 20
# 8 - 32 UNC	13 ± 2	25 ± 5	282 ± 30	29 ± 3	330 ± 30	41 ± 4	460 ± 45
# 8 - 36 UNF				31 ± 3	350 ± 30	43 ± 4	31 ± 3
# 10 - 24 UNC	18 ± 2	30 ± 5	339 ± 56	42 ± 4	475 ± 45	60 ± 6	674 ± 70
#10 - 32 UNF				48 ± 4	540 ± 45	68 ± 6	765 ± 70
1/4 - 20 UNC	48 ± 7	53 ± 7	599 ± 79	100 ± 10	1125 ± 100	140 ± 15	1580 ± 170
1/4 - 28 UNF	53 ± 7	65 ± 10	734 ± 113	115 ± 10	1300 ± 100	160 ± 15	1800 ± 170
5/16 - 18 UNC	115 ± 15	105 ± 17	1186 ± 169	200 ± 25	2250 ± 280	300 ± 30	3390 ± 340
5/16 - 24 UNF	138 ± 17	128 ± 17	1446 ± 192	225 ± 25	2540 ± 280	325 ± 30	3670 ± 340
	ft-lb	ft-lb	N-m	ft-lb	N-m	ft-lb	N-m
3/8 - 16 UNC	16 ± 2	16 ± 2	22 ± 3	30 ± 3	41 ± 4	43 ± 4	58 ± 5
3/8 - 24 UNF	17 ± 2	18 ± 2	24 ± 3	35 ± 3	47 ± 4	50 ± 4	68 ± 5
7/16 - 14 UNC	27 ± 3	27 ± 3	37 ± 4	50 ± 5	68 ± 7	70 ± 7	68 ± 9
7/16 - 20 UNF	29 ± 3	29 ± 3	39 ± 4	55 ± 5	75 ± 7	77 ± 7	104 ± 9
1/2 - 13 UNC	30 ± 3	48 ± 7	65 ± 9	75 ± 8	102 ± 11	105 ± 10	142 ± 14
1/2 - 20 UNF	32 ± 3	53 ± 7	72 ± 9	85 ± 8	115 ± 11	120 ± 10	163 ± 14
5/8 - 11 UNC	65 ± 10	88 ± 12	119 ± 16	150 ± 15	203 ± 20	210 ± 20	285 ± 27
5/8 - 18 UNF	75 ± 10	95 ± 15	129 ± 20	170 ± 15	230 ± 20	240 ± 20	325 ± 27
3/4 - 10 UNC	93 ± 12	140 ± 20	190 ± 27	265 ± 25	359 ± 34	374 ± 35	508 ± 47
3/4 - 16 UNF	115 ± 15	165 ± 25	224 ± 34	300 ± 25	407 ± 34	420 ± 35	569 ± 47
7/8 - 9 UNC	140 ± 20	225 ± 25	305 ± 34	430 ± 45	583 ± 61	600 ± 60	813 ± 81
7/8 - 14 UNF	155 ± 25	260 ± 30	353 ± 41	475 ± 45	644 ± 61	660 ± 60	895 ± 81

Note: Reduce torque values listed in the table above by 25% for lubricated fasteners. Lubricated fasteners are defined as threads coated with a lubricant such as oil, graphite, or thread sealant such as Loctite.

Note: Torque values may have to be reduced when installing fasteners into threaded aluminum or brass. The specific torque value should be determined based on the fastener size, the aluminum or base material strength, length of thread engagement, etc.

Note: The nominal torque values listed above for Grade 5 and 8 fasteners are based on 75% of the minimum proof load specified in SAE J429. The tolerance is approximately ± 10% of the nominal torque value. Thin height nuts include jam nuts.

SPECIFICATIONS

Standard Torque for Dry, Zinc, and Steel Fasteners (Metric Fasteners)

Thread Size	Class 8.8 Bolts, Screws, and Studs with Regular Height Nuts (Class 8 or Strong Nuts)		Class 10.9 Bolts, Screws, and Studs with Regular Height Nuts (Class 10 or Strong Nuts)	
M5 X 0.8	57 ± 5 in-lb	640 ± 60 N-cm	78 ± 7 in-lb	885 ± 80 N-cm
M6 X 1.0	96 ± 9 in-lb	1018 ± 100 N-cm	133 ± 13 in-lb	1500 ± 150 N-cm
M8 X 1.25	19 ± 2 ft-lb	26 ± 3 N-m	27 ± 2 ft-lb	36 ± 3 N-m
M10 X 1.5	38 ± 4 ft-lb	52 ± 5 N-m	53 ± 5 ft-lb	72 ± 7 N-m
M12 X 1.75	66 ± 7 ft-lb	90 ± 10 N-m	92 ± 9 ft-lb	125 ± 12 N-m
M16 X 2.0	166 ± 15 ft-lb	225 ± 20 N-m	229 ± 22 ft-lb	310 ± 30 N-m
M20 X 2.5	325 ± 33 ft-lb	440 ± 45 N-m	450 ± 37 ft-lb	610 ± 50 N-m

Note: Reduce torque values listed in the table above by 25% for lubricated fasteners. Lubricated fasteners are defined as threads coated with a lubricant such as oil, graphite, or thread sealant such as Loctite.

Note: The nominal torque values listed above are based on 75% of the minimum proof load specified in SAE J1199. The tolerance is approximately ± 10% of the nominal torque value. Thin height nuts include jam nuts.

Note: Torque values may have to be reduced when installing fasteners into threaded aluminum or brass. The specific torque value should be determined based on the fastener size, the aluminum or base material strength, length of thread engagement, etc.

SPECIFICATIONS

2

Other Torque Specifications

SAE Grade 8 Steel Set Screws

Thread Size	Recommended Torque	
	Square Head	Hex Socket
1/4 - 20 UNC	140 ± 20 in-lb	73 ± 12 in-lb
5/16 - 18 UNC	215 ± 35 in-lb	145 ± 20 in-lb
3/8 - 16 UNC	35 ± 10 ft-lb	18 ± 3 ft-lb
1/2 - 13 UNC	75 ± 15 ft-lb	50 ± 10 ft-lb

Wheel Bolts and Lug Nuts

Thread Size	Recommended Torque**	
7/16 - 20 UNF Grade 5	65 ± 10 ft-lb	88 ± 14 N-m
1/2 - 20 UNF Grade 5	80 ± 10 ft-lb	108 ± 14 N-m
M12 X 1.25 Class 8.8	80 ± 10 ft-lb	108 ± 14 N-m
M12 X 1.5 Class 8.8	80 ± 10 ft-lb	108 ± 14 N-m

** For steel wheels and non-lubricated fasteners.

Thread Cutting Screws (Zinc Plated Steel)

Type 1, Type 23, or Type F	
Thread Size	Baseline Torque*
No. 6 - 32 UNC	20 ± 5 in-lb
No. 8 - 32 UNC	30 ± 5 in-lb
No.10 - 24 UNC	38 ± 7 in-lb
1/4 - 20 UNC	85 ± 15 in-lb
5/16 - 18 UNC	110 ± 20 in-lb
3/8 - 16 UNC	200 ± 100 in-lb

Thread Cutting Screws (Zinc Plated Steel)

Thread Size	Threads per Inch		Baseline Torque*
	Type A	Type B	
No. 6	18	20	20 ± 5 in-lb
No. 8	15	18	30 ± 5 in-lb
No. 10	12	16	38 ± 7 in-lb
No. 12	11	14	85 ± 15 in-lb

* Hole size, material strength, material thickness and finish must be considered when determining specific torque values. All torque values are based on non-lubricated fasteners.

Conversion Factors

in-lb X 11.2985 = N-cm
ft-lb X 1.3558 = N-m

N-cm X 0.08851 = in-lb
N-m X 0.73776 = ft-lb

SPECIFICATIONS

Equivalents and Conversions

Decimal and Millimeter Equivalents

Fractions	Decimals	mm	Fractions	Decimals	mm
1/64	0.015625	0.397	33/64	0.515625	13.097
1/32	0.03125	0.794	16/32	0.53125	13.484
3/64	0.046875	1.191	35/64	0.546875	13.891
1/16	0.0625	1.588	9/16	0.5625	14.288
5/64	0.078125	1.984	37/64	0.578125	14.684
3/32	0.9375	2.381	19/32	0.59375	15.081
1/8	0.1250	3.175	5/8	0.6250	15.875
9/64	0.140625	3.572	41/64	0.640625	16.272
5/32	0.15625	3.969	21/32	0.65625	16.669
11/64	0.171875	4.366	43/64	0.671875	17.066
3/16	0.1875	4.762	11/16	0.6875	17.462
13/64	0.203125	5.159	45/64	0.703125	17.859
7/32	0.21875	5.556	23/32	0.71875	18.256
15/64	0.234375	5.953	47/64	0.734375	18.653
1/4	0.2500	6.350	3/4	0.7500	19.050
17/64	0.265625	6.747	49/64	0.765625	19.447
9/32	0.28125	7.144	25/32	0.78125	19.844
19/64	0.296875	7.541	51/64	0.796875	20.241
5/16	0.3125	7.541	13/16	0.8125	20.638
21/64	0.328125	8.334	53/64	0.828125	21.034
11/32	0.34375	8.731	27/32	0.84375	21.431
23/64	0.359375	9.128	55/64	0.859375	21.828
3/8	0.3750	9.525	7/8	0.8750	22.225
25/64	0.390625	9.922	57/64	0.890625	22.622
13/32	0.40625	10.319	29/32	0.90625	23.019
27/64	0.421875	10.716	59/64	0.921875	23.416
7/16	0.4375	11.112	15/16	0.9375	23.812
29/64	0.453125	11.509	61/64	0.953125	24.209
15/32	0.46875	11.906	31/32	0.96875	24.606
31/64	0.484375	12.303	63/64	0.984375	25.003
1/2	0.5000	12.700	1	1.000	25.400
1 mm = 0.03937 in.			0.001 in. = 0.0254 mm		

SPECIFICATIONS

U.S. to Metric Conversions

	To Convert	Into	Multiply By
Linear Measurement	Miles	Kilometers	1.609
	Yards	Meters	0.9144
	Feet	Meters	0.3048
	Feet	Centimeters	30.48
	Inches	Meters	0.0254
	Inches	Centimeters	2.54
	Inches	Millimeters	25.4
Area	Square Miles	Square Kilometers	2.59
	Square Feet	Square Meters	0.0929
	Square Inches	Square Centimeters	6.452
	Acre	Hectare	0.4047
Volume	Cubic Yards	Cubic Meters	0.7646
	Cubic Feet	Cubic Meters	0.02832
	Cubic Inches	Cubic Centimeters	16.39
Weight	Tons (Short)	Metric Tons	0.9078
	Pounds	Kilograms	0.4536
	Ounces	Grams	28.3495
Pressure	Pounds/Sq. In.	Kilopascal	6.895
Work	Foot-pounds	Newton-Meters	1.356
	Foot-pounds	Kilogram-Meters	0.1383
	Inch-pounds	Kilogram-Centimeters	1.152144
Liquid Volume	Quarts	Liters	0.9463
	Gallons	Liters	3.785
Liquid Flows	Gallons/Minute	Liters/Minute	3.785
Temperature	Fahrenheit	Celsius	1. Subtract 32° 2. Multiply by 5/9

2

SPECIFICATIONS

2

THIS PAGE INTENTIONALLY LEFT BLANK.

Safety Information	1
Specifications	2
Chassis	3
Hydraulic System	4
Engine	5
Electrical	6
Mower Decks/PTO	7

CHASSIS

Caster Fork Assembly Removal

1. Raise the front of the unit off the ground, allowing enough clearance to remove the castor fork from the bottom of the hub.
2. With a hammer and chisel, remove the top grease cap (Fig. 021).



Fig 021

mvc-1531

3. Remove the locknut (Fig. 022).



Fig 022

DSC-1532

4. Remove the Belleville washers and caster fork and wheel assembly (Fig. 023).



Fig 023

DSC-1533

Replacing the Caster Bearings

1. Remove the top tapered roller bearing (Fig. 024).



Fig 024

DSC-1534

2. Remove bottom seal and tapered roller bearing (Fig. 025).



Fig 025

DSC-1535

3. With a driver and hammer, remove both the bottom and top tapered bearing cups (Fig. 026).



Fig 026

DSC-1536

4. With a driver and hammer, install new tapered bearing cups. The bearing cups are tapered; make sure the tapered/thicker end of the cup is installed inward for the top and bottom end (Fig. 027). Tap the bearing cups in until they seat against the step in the caster hub.



Fig 027

DSC-1537

5. Pack the upper and lower tapered bearings prior to installation (Fig. 028).



Fig 028

DSC-1539

3

CHASSIS

6. Install the lower bearing and seal, with the open end of the seal facing up (Fig. 029).



Fig 029

DSC-1538

2. Install the upper bearing.
3. Install the Belleville (spring) washers as shown in (Fig. 031).

- A. Dust Cap
- B. Locknut
- C. Spring Washers




Fig 031

washers line art

Castor Fork Assembly

1. Install the castor fork into the frame (Fig. 030).



Fig 030

DSC-1533

4. Install the locknut and tighten until the spring washers are flat, then back off 1/4 turn to properly set the preload on the bearings (Fig. 032).



Fig 032

DSC-1532

- Remove the plug located on the side of the hub on the frame for the castor fork. Install a grease fitting, and pump grease into the housing until grease is passing through the upper bearing (Fig. 033).



Fig 033

DSC-1540

- Remove the grease fitting and install the grease plug.
- Install the grease cap on the caster hub (Fig. 034).



Fig 034

DSC-1541

Front Wheel Removal and Bearing Replacement

- Raise the front of the unit off the ground.
- Remove the wheel bolt from the fork (Fig. 035).



Fig 035

DSC-1543

- Remove bearing spacers and the front caster spacer. Remove the seals located on each side of the wheel and both the tapered bearings (Fig. 036).

- | | |
|-------------------|-------------------------|
| A. Bearing Spacer | D. Caster Spacer |
| B. Bearing Seal | E. Retaining wheel nut |
| C. Taper Bearing | F. Retaining wheel bolt |




Fig 036

DSC-1546

CHASSIS

4. Pack both tapered wheel bearings. Reassemble per Fig. 036. Pump grease into the wheel bearings through the grease fitting located on the rim (Fig. 037).



Fig 037

DSC-1547

Fuel Tank Removal

Left Side Fuel Tank Removal

1. Disconnect the negative battery cable from the battery. Drain the fuel tanks.
2. Remove the fuel hose clamp at the bottom of the fuel tank (Fig. 038).



Fig 038

DSC-3091

3. Remove the 4 screws retaining the control panel and control panel shield to the tank (Fig. 039).



Fig 039

DSC-3092

4. Carefully remove the control panel and control panel shield by lifting the panel and sliding toward the middle of the unit.

Note: DO NOT disconnect any cables or wiring.

5. Remove the bolt, lock washer, and nut located under the front of the fuel tank (Fig. 040).



Fig 040

DSC-3094

6. Located under the rear portion of the fuel tank, remove the 2 nuts, springs, and washers from the fuel tank studs (Fig. 041).



Fig 041

DSC-3095

Note: Rear tire removed for clarity.

7. On the inside of the frame under the rear portion of the fuel tank, remove the nut, spring, and washer from the fuel tank stud (Fig. 042).



Fig 042

DSC-3098

8. Remove the fuel tank from the frame (Fig. 043).



Fig 043

DSC-3099

3

Left Side Fuel Tank Installation

Reverse the order of removal.

Right Side Fuel Tank Removal and Installation

Follow the same procedures for the Left Side Tank Removal and Installation except skip the instructions for removing the control panel.

CHASSIS

Hood Assembly Removal

1. Unhook the two rubber latches located on the rear of the hood.
2. Remove the two hairpins, clevis pins, and washers located in the front left and right lower side of the hood (Fig. 044).



Fig 044

DSC-1579

3. Lift the hood and remove the stop lanyards located on each side of the hood. Remove the hood from the frame of the unit (Fig. 045).



Fig 045

DSC-1581

Hood Assembly Installation

Reverse the order of removal.

Brake Lever Removal

1. Release the parking brake (forward position).
2. Remove the cotter pin and clevis pin from the brake rod yoke (Fig. 046).



Fig 046

DSC-1618

3. Lift the floor pan assembly to access the brake lever shaft and cotter pin (Fig. 047).




Fig 047

DSC-1619

4. Remove the brake shaft cotter pin (Fig. 048).



Fig 048

DSC-1620

6. Using a hammer and punch, drive both brake lever control bearings from the brake pivot (Fig. 050).



Fig 050

DSC-1622

5. Slide the brake shaft out of the frame pivot bushings (Fig 049).



Fig 049

DSC-1621

7. Inspect the brake shaft and bushings for excessive wear. Replace any worn or broken components (Fig. 051).




Fig 051

DSC-1623

- A. Brake lever
- B. Bushings

- C. Cotter pin

CHASSIS

Brake Lever Installation

Reverse the order of removal

Brake Band Removal

1. Raise the left rear tire off the ground (Fig. 052).



Fig 052

DSC-1624

2. Remove the four wheel lug bolts.

3. Remove bolts, brake band retainer, spacers, and brake band (Fig. 053).




Fig 053

DSC-1626

- | | |
|------------------------|---------------|
| A. 3 Bolts | C. 3 Spacers |
| B. Brake Band Retainer | D. Brake Band |

Brake Band Installation

1. Install the brake band around the wheel hub (Fig. 054).



Fig 054

DSC-1629

2. Install the 3 bolts, brake band retainer, brake band, and spacers and tighten (Fig. 055).



Fig 055

DSC-1631

2. On the left side of the machine, remove both clevis spring pins, one from the brake rod and the other from the brake shaft (Fig. 056).



Fig 056

DSC-3100

3. Install tire assembly and the 4 wheel bolts.

Brake Shaft Removal

1. Raise the rear end of the unit and remove the right and left rear tires.

Note: To prevent the unit from rolling, block the two front tires.



Fig 057

DSC-3101

CHASSIS

4. On the right side, remove the two bolts and nuts holding the flange bearing (Fig. 058).



Fig 058

DSC-3104

6. Remove the brake shaft from the left side of the unit (Fig. 060).



Fig 060

DSC-3106

5. On the left side, remove the two bolts and nuts holding the flange bearing (Fig. 059).



Fig 059

DSC-3105

7. Inspect the brake shaft and flange bearings for excessive wear (Fig. 061).




Fig 061

DSC-3107

- A. Brake shaft
B. Flange bearings

- C. Bolts
D. Nuts

Brake Shaft Installation

Reverse the order of removal.

Adjusting the Parking Brake

Check the parking brake for proper adjustment.

1. Disengage the brake lever (lever down).
2. Measure the length of the spring. The measurement should be 2-3/4" (70mm) between the washers (Fig. 062).




Fig 062

fig. 74 m-3788

- | | |
|--------------------------|------------------------|
| 1. Brake lever | 4. Collar on brake rod |
| 2. Spring, 2-3/4" (70mm) | 5. 3/16 - 1/4" (5-7mm) |
| 3. Adjusting nuts | 6. Jam nut and yoke |

3. If an adjustment is necessary, loosen the jam nut below the spring and tighten the nut directly below the yoke (Fig. 062). Turn the nut until the correct measurement is obtained. Tighten the two nuts together and repeat on the opposite side of the unit.
4. Turn the nuts clockwise to shorten the spring length and counterclockwise to lengthen the spring.
5. Engage the parking brake, lever up.
6. Measure the distance between the trunnion roller and the collar on the brake rod. The measurement should be 3/16 - 1/4" (5 - 8mm) (Fig. 062).
7. If adjustment is necessary, loosen the jam nut directly below the yoke. Turn the bottom rod until the correct measurement is obtained (Fig. 062). Tighten the jam nut at the yoke.

3

Deck Lift Lever Removal

1. Park the machine on a level surface, disengage the blade control (PTO), and turn the ignition key to *OFF* to stop the engine. Remove the ignition key.
2. Remove the lower stop bolt from the deck lift plate (Fig. 063).



Fig 063

DSC-1647

CHASSIS

3. With the mower deck in the transport position, place a 4"x 4" block under each corner of the deck. Lower the mower deck onto the support blocks to remove the weight from the support chains (Fig. 064).



Fig 064

DSC-1648

5. Remove hex nut from RH rear deck lift assembly. Repeat procedure for LH rear deck lift assembly (Fig. 066).



Fig 066

DSC-1650

4. Loosen jam nuts on deck lift rods until deck support springs are fully extended. Repeat procedure for both deck lift rods (Fig. 065).



Fig 065

DSC-1649

6. Lower lift lever grip assembly to its lowest position. Rear deck swivel mounts should clear deck lift rods on both sides. The mower deck lift linkage should now be fully unloaded (Fig. 067).




Fig 067

DSC-1651

A. Lift Lever at lowest position

7. Remove hex bolt, nut, and lift lever bushing from the lower deck lift plate mounting location (Fig. 068).




Fig 068

DSC-1652

9. Lift the floor pan assembly to its fully opened position (Fig. 070).




Fig 070

DSC-3112

8. Loosen the top hex head flange nut at the deck lift plate mounting location. Pivot the INNER deck lift plate up and back toward the RH motion control lever (Fig. 069).



Fig 069

DSC-1653

10. Remove hex bolt, bushing, and nylock nut connecting the deck lift arm plates to the mower deck rear cross-shaft lift assembly (Fig. 071).




Fig 071

DSC-1655

CHASSIS

11. Remove retainer clip from lift lever grip assembly (Fig. 072).




Fig 072

DSC-1656

12. When removing the lift lever grip assembly, you may experience interference with the RH floor pan hinge or the front edge of the RH motion control plate, or both (Fig. 073).




Fig 073

DSC-1657

- A. RH Floor pan hinge B. RH Motion control plate

13. If the lift lever grip assembly contacts the RH floor pan hinge, loosen the RH floor pan hinge mounting hardware. Push the RH hinge upward. Re-tighten the RH floor pan hinge mounting hardware (Fig. 074).




Fig 074

DSC-1661

14. If the lift lever grip assembly contacts the RH motion control plate, tilt and hold the floor pan assembly slightly forward. Move the RH motion control lever out of the neutral lock position and push it in the full forward position. Using a tie strap or wire, tie the floor pan assembly to the motion control arm to hold the floor pan assembly in place (Fig. 075).



Fig 075

DSC-1665

15. Carefully slide the lift lever grip assembly out of its carrier frame pivot (Fig. 076).



Fig 076

DSC-1667

2. Install lift lever grip assembly into front frame pivot location (Fig. 078).



Fig 078

DSC-1670

Deck Lift Lever Installation

1. For ease of installation, make sure deck lift arm plates, bushing, and hardware are installed on the lift lever grip assembly prior to installation (Fig. 077).




Fig 077

DSC-1668

- | | |
|------------|----------|
| A. Plate | D. Bolt |
| B. Nut | E. Plate |
| C. Bushing | |

3. Install retainer clip to lift lever grip assembly (Fig. 079).



Fig 079

DSC-1672

CHASSIS

4. Install bushing into rear lift arm cross shaft (Fig. 080).




Fig 080

DSC-1674

- A. Bushing

5. Install hex bolt through deck lift plates and rear lift arm cross shaft bushing. Install nylock nut and tighten (Fig. 081).




Fig 081

DSC-1675

- A. Rear lift arm plates
- B. Hex bolt

6. Rotate deck lift plate (inner) downward until lower mounting holes line up with hole in carrier frame and deck lift plate (outer). From the outside of the frame, install hex bolt, spacer, and flanged lock nut as shown. Tighten bolt (Fig. 082).




Fig 082

DSC-1677

- A. Hex bolt
- B. Spacer
- C. Flanged locknut

7. Align rear deck mount swivels with ends of deck lift rod (Fig. 083).




Fig 083

DSC-1680

- A. Rear deck mount swivel
- B. Lift rod

8. Raise lift lever grip assembly until deck mount swivels rest against deck rod jam nuts. Install HOC pin into deck lift plate height of cut holes that correspond to the 3" (7.62cm) HOC position (Fig. 084).




Fig 084

DSC-1681

- A. Rear deck mount swivel B. HOC Pin

9. Install lower "stop" bolt through inner and outer deck lift plates. Install nylock nut and tighten until hex nut and bolt are seated firmly against the deck lift plates. DO NOT over-tighten or deck lift plates will deform inward causing HOC pin assembly to bind (Fig. 085).



Fig 085

DSC-1682

10. Install Hex nut on end of deck lift rod. Tighten against deck mount swivel. Repeat procedure for opposite side deck lift rod (Fig. 086).




Fig 086

DSC-1683

11. Raise mower deck to the transport position. Remove support blocks. Check deck level adjustment (refer to Mower Deck Leveling page 7-27). Readjust compression spring length by turning front nut. Spring should be compressed to a length of 11-1/2" (29.2cm) between washers. Lock the front nut into position by tightening the spring jam nut (Fig. 087).




Fig 087

DSC-1685

CHASSIS

12. Untie the floor pan assembly and lower. Return motion control lever to its neutral locked position.

Motion Control Assembly Removal

1. Remove both floor pan assembly hinge bolts (Fig. 088).



Fig 088

DSC-1686

2. Remove floor pan assembly (Fig. 089).



Fig 089

DSC-1689

3. Remove (4) pocket mounting bolts (Fig. 090).




Fig 090

DSC-3108

4. Remove pocket (Fig. 091).



Fig 091

DSC-3109

5. Remove the two bolts retaining the lever assembly to the control arm shaft (Fig. 092).



Fig 092

DSC-2062

7. Disconnect neutral switch wire harness from neutral switch (Fig. 094).




Fig 094

DSC-3110

6. Disconnect Motion Control Dampener from motion control assembly (Fig. 093).




Fig 093

DSC-1695

8. Remove bolt and nut that retains the ball joint to the motion control (Fig. 095).




Fig 095

DSC-3111

CHASSIS

9. Remove the cotter pin and clevis pin through the adjustable yoke for the neutral return bolt (Fig. 096).



Fig 096

DSC-2064

11. Remove the two bolts and nuts that retain the flange bearing on the outside of the motion control (Fig. 098).



Fig 098

DSC-2067

10. Remove the two bolts and nuts that retain the flange bearing on the inside of the motion control (Fig. 097).



Fig 097

DSC-2066

12. Remove the motion control from the frame (Fig. 099).



Fig 099

DSC-2068

Motion Control Assembly Installation

Reverse the order of removal.

Safety Information	1
Specifications	2
Chassis	3
Hydraulic System	4
Engine	5
Electrical	6
Mower Decks/PTO	7

HYDRAULIC SYSTEM

Hydrostatic Pump Removal

Note: Cleanliness is a key factor in a successful repair of any hydrostatic system. Thoroughly clean all exposed surfaces prior to any type of maintenance. Cleaning all parts by using a solvent wash and air drying is usually adequate. As with any precision equipment, all parts must be kept free of foreign material and chemicals. Protect all exposed sealing areas and open cavities from damage and foreign material.

Upon removal, all seals, O-rings, and gaskets should be replaced. During installation, lightly lubricate all seals, O-rings and gaskets with clean petroleum jelly prior to installation.

This procedure shows the LH Hydrostatic Pump being removed. Use these same procedures to remove the RH Hydrostatic Pump.

1. Disconnect the negative and then the positive battery cable from the battery.
2. Using compressed air, clean the area around the hydrostatic pump to make sure it is free from any dirt and debris.
3. Remove the seat prop rod from the seat and the frame (Fig. 100).



Fig 100

DSC-2986

4. Lift the engine shield. Using a pry bar, relieve the spring tension on the idler assembly and remove the pump drive belt (Fig. 101).



Fig 101

DSC-2991

5. Loosen the two square head set-screws located on the pump sheave and remove the pulley (Fig. 102).



Fig 102

DSC-2993

HYDRAULIC SYSTEM

6. Remove bolt, washer, and nut located between ball joint and control arm that retains the tracking link rod to the hydro control arm (Fig. 103).

Note: It may be necessary to move the hydro lever forward in order to remove the bolt.



Fig 103

DSC-2994

8. Remove the hose clamp around the case drain hydraulic hose, located on the left side of the hydrostatic pump (Fig. 105).



Fig 105

DSC-2998

- A. Case drain hose clamp

7. Remove the two high pressure hydraulic lines, located at the bottom of the hydrostatic pump (Fig. 104).

Note: Cap the hose and the fitting to prevent entry of dirt and debris. Mark or tag one of the hoses to ensure correct reassembly.



Fig 104

DSC-2996

9. Remove the pump suction hydraulic line, located on top of the hydrostatic pump (Fig. 106).



Fig 106

DSC-2999

HYDRAULIC SYSTEM

10. Loosen and remove the two bolts and nuts retaining the hydrostatic pump to the frame (Fig. 107).



Fig 107

DSC-3000

Note: Engine shield removed for clarity.

Hydrostatic Pump Installation

Note: As a reminder, prior to connecting the hydraulic lines, the O-rings should be replaced with new ones and lightly lubricated with petroleum jelly.

1. Install the hydrostatic pump to the frame. Install and tighten the two bolts and nuts (Fig. 109).



Fig 109

DSC-3000

11. Remove the hydrostatic pump from the frame (Fig. 108).



Fig 108

DSC-3002

2. Install the pump suction hydraulic line, located on top of the hydrostatic pump, that comes from the hydraulic filter (Fig. 110).



Fig 110

DSC-2999

12. For service work on the pump refer to the Hydro-Gear BDP10A/16A/21L Service Manual, form #492-4789.

HYDRAULIC SYSTEM

3. Install the case drain hose and hose clamp onto the pump case drain fitting, located around the left side of the hydrostatic pump (Fig. 111).



Fig 111

DSC-2998

5. Install the bolt, washer, and nut between the ball joint and control arm to secure the tracking link rod to the hydro control arm (Fig. 113). Tighten the bolt and nut.




Fig 113

DSC-2994

4. Install the two high pressure hydraulic lines, located at the bottom of the hydrostatic pump (Fig. 112).



Fig 112

DSC-2996

6. Install the key in the hydrostatic pump shaft.

Note: Before installing the pulley, replace the set screws. The end of the set screws have a knurled cup point for retention and must not be re-used.

4

HYDRAULIC SYSTEM

Apply some anti-seize compound to the shaft (Fig. 114). Install the pulley to the shaft.



Fig 114

DSC-3066

8. Using a pry bar, release the spring tension on the idler assembly and install the pump drive belt (Fig. 116).




Fig 116

DSC-3068

Note: The engine shield has been removed for clarity.

7. Align the outer edge of the hydrostatic pump pulley, using a straight edge, to the outer edge of the engine drive pulley (Fig. 115). Tighten the two set screws once alignment is achieved.




Fig 115

DSC-3067

A. Pump pulley

B. Engine pulley



Fig 117

DSC-2986

HYDRAULIC SYSTEM

10. Install the battery positive and then the negative cable to the battery.
11. Check the hydraulic fluid in the reservoir tank. Add oil if necessary. Air will need to be purged in the system. Follow procedures on Purging the Hydraulic System, page 4-18.
12. Check the neutral adjustment. Follow procedures on Adjusting the Handle Neutral, page 4-12.

Wheel Motor Removal

This procedure is the same for both the right and left wheel motors.

1. Disconnect the battery negative cable.
2. Raise the rear wheels of the machine off the ground and support frame with jackstands. Remove the rear wheel (Fig. 118).



Fig 118

DSC-3069

3. Apply the parking brake and remove the cotter pin from the wheel motor output shaft (Fig. 119).



Fig 119

DSC-3070

4. Loosen and remove nut securing hub to the wheel motor output shaft (Fig. 120).



Fig 120

DSC-3071

4

HYDRAULIC SYSTEM

5. Remove the 3 bolts securing the brake band to the actuator (Fig. 121).



Fig 121

DSC-3072

7. Install wheel puller on to the hub and remove the hub from motor output shaft (Fig. 123).

Note: Toro Wheel Puller, P/N TOR 4097, is available through SPX (formerly OTC) 1-800-533-0492.



Fig 123

DSC-3074

6. Remove the brake band from the hub (Fig. 122).



Fig 122

DSC-3073

8. Clean any dirt or debris away from the hydraulic line fittings. Remove the hydraulic lines.

Note: Make sure to cap the fittings and hoses to prevent dirt from entering the hydraulic system (Fig. 124).



Fig 124

DSC-3075

HYDRAULIC SYSTEM

9. Remove the front two wheel motor bolts, lock washers, spacers, and nuts (Fig. 125).



Fig 125

DSC-3076

11. Remove the back two bolts, lock washers, spacers, and nuts and remove the wheel motor from the frame (Fig. 127).



Fig 127

DSC-3078

10. Swing the brake linkage forward out of the way of the wheel motor. It may be necessary to loosen the back two bolts to remove the spacers (Fig. 126).



Fig 126

DSC-3077

12. For service work on the wheel motor refer to the Parker/Ross Service Manual, Form #492-4753.

Wheel Motor Installation

Note: As a reminder, prior to connecting the hydraulic lines, the O-rings should be replaced with new ones and lightly lubricated with petroleum jelly.

HYDRAULIC SYSTEM

Note: There are two different spacers used on the wheel motors (Fig. 128). The short spacers are used in the front of the wheel motors (with the brake linkage) and the long spacers are used to retain the back of the wheel motor.



Fig 128

DSC-3079

- A. Front Spacer (short) B. Back Spacer (long)

1. Install wheel motor in the frame. Loosely install the back two bolts, long spacers, lock washers and nuts (Fig. 129).



Fig 129

DSC-3080

2. Align the brake linkage with the two front bolt holes (Fig. 130).



Fig 130

DSC-3081

3. Install the two bolts, short spacers, lock washers, and nuts through the wheel motor, brake linkage and the frame (Fig. 131).



Fig 131

DSC-3082

HYDRAULIC SYSTEM

4. Torque the bolts to 80 to 90 ft-lbs. (108 to 122 Nm) (Fig. 132).



Fig 132

DSC-3085

5. Install and tighten the two hydraulic lines to the wheel motor (Fig. 133).



Fig 133

DSC-3086

6. Install wheel hub assembly, making sure the woodruff key is in place (Fig. 134).

Note: It is recommended to replace the wheel hub assembly prior to installation.



Fig 134

DSC-3087

7. Install the nut on the wheel motor shaft, DO NOT tighten (Fig. 135).



Fig 135

DSC-3088

4

HYDRAULIC SYSTEM

8. Install spacers, brake band retainer, and brake band around the wheel hub and tighten all three retainer bolts (Fig. 136).



Fig 136

DSC-3089

9. Engage the parking brake, torque the wheel hub nut to 125 ft-lbs. (169 Nm) (Fig. 137). Install the cotter key through the nut and motor wheel shaft.

Note: Re-torque nut at 100 hours, and every 500 hours thereafter. Washer 1-523157 can be added under nut to keep cotter pin engaged with nut castellations.



Fig 137

DSC-3090

10. Check the park brake and adjust park brake if necessary. Refer to Adjusting the Parking Brake, page xxx.
11. Install rear wheel and wheel lug nuts and tighten.
12. Reconnect the battery negative cable to the battery.
13. Check the hydraulic fluid in the reservoir tank. Add oil if necessary. Air will need to be purged in the system. Follow the procedures on Purging the Hydraulic System, page 4-18.

Adjusting the Handle Neutral

If motion control levers do not align, or move easily into the console notch, adjustment is required. Adjust each lever, spring and rod separately.

Note: Motion control levers must be installed correctly. See Installing the Motion Control Levers in the set up instructions.

1. Disengage the PTO, move the motion control levers to the neutral locked position and set the parking brake.
2. Stop the engine, remove the key, and wait for all moving parts to stop before leaving the operating position.
3. Unlatch the seat and tilt the seat forward.
4. Begin with either the left or right motion control lever.

HYDRAULIC SYSTEM

5. Move the lever to the neutral position but not locked (Fig. 138).




Fig 138

fig. 59 m-6278

- | | |
|-----------------------|----------------|
| 1. Clevis pin in slot | 7. Spring |
| 2. Nut against yoke | 8. Pivot shaft |
| 3. Adjustment bolt | 9. Yoke |
| 4. Pump rod | 10. Locknut |
| 5. Double nuts | 11. Ball joint |
| 6. Jam nuts | |
6. Pull lever back until the clevis pin (on arm below pivot shaft) just begins to contact the end of the slot (just beginning to put pressure on the spring) (Fig. 138).

7. Check where the control lever is relative to notch in console (Fig. 139). It should be centered allowing lever to pivot outward to the neutral lock position.




Fig 139

fig 58 m-6282

- | | |
|----------------------------|---------------------|
| 1. Neutral locked position | 3. Neutral position |
| 2. Control lever | |
8. Check where the control lever is relative to notch in console (Fig. 139). It should be centered allowing lever to pivot outward to the neutral lock position.
 9. If adjustment is needed, loosen the nut and jam nut against the yoke (Fig. 138).
 10. Apply slight rearward pressure on the motion control lever, turn the head of the adjustment bolt in the appropriate direction until the control lever is centered in neutral lock position (Fig. 139).
- Note: Keeping rearward pressure on the lever will keep the pin at the end of the slot and allow the adjustment bolt to move the lever to the appropriate position.**
11. Tighten the nut and jam nut (Fig. 138).
 12. Repeat on the opposite side of the machine.

HYDRAULIC SYSTEM

Setting the Hydraulic Pump Neutral

Note: Adjust handle neutral before making the following adjustment. See Adjusting the Handle Neutral, page 4-12.

Note: This adjustment must be made with the drive wheels turning.

1. Raise the frame and block up the machine so drive wheels can rotate freely (Fig. 140).



Fig 140

DSC-3114

2. Slide the seat fully forward, unlatch the seat and tilt the seat forward. Disconnect the prop rod for the seat.

3. Disconnect the electrical connector at the switch, located between the frame cross member and the hydraulic tank. Temporarily install a jumper wire across the terminals in the wiring harness connector (Fig. 141).



Fig 141

DSC-3116

Setting the RH Hydraulic Pump Neutral

1. Start the engine, open the throttle half way and release the park brake.

Note: The motion control lever must be in neutral while making any adjustments.

HYDRAULIC SYSTEM

2. Adjust the pump rod length by rotating the knob, in the appropriate direction, until the wheel is still or slightly creeping in reverse (Fig. 142).




Fig 142

DSC-3117

3. Move motion control lever forward and reverse, then back to neutral. Wheel must stop turning or slightly creep in reverse.
4. Open engine throttle to fast. Make sure wheel remains stopped or slightly creeps in reverse, adjust if necessary.

Setting the LH Hydraulic Pump Neutral

1. Loosen the locknuts at the pump ball joint on the motion control rod (Fig. 143).



Fig 143

DSC-3118

2. Start the engine, open the engine throttle half way and release the parking brake.

Note: Motion control lever must be in neutral while making any adjustments.

Note: The front nut on the pump rod has left-hand threads.

HYDRAULIC SYSTEM

3. Adjust pump rod length by rotating the double nuts in the appropriate direction, until wheel is still or slightly creeps in reverse (Fig. 144).



Fig 144

DSC-3120

Adjusting the Tracking

The right hand pump has a knob for adjusting the tracking (Fig. 145).



Fig 145

DSC-3117

4

4. Move the motion control lever forward and reverse, then back to neutral. The wheel must stop turning or slightly creep in reverse.
5. Open the throttle to fast. Make sure the wheel remains stopped or slightly creeps in reverse; readjust if necessary.
6. Tighten the locknuts at the ball joints.
7. After both pump neutrals are set, shut off the machine.
8. Remove the jumper wire from the wiring harness connector and reconnect to the seat switch.
9. Reinstall the prop rod and lower the seat into position.
10. Remove the jack stands.

Important: Adjust the handle neutral and hydraulic pump neutral before adjusting the tracking. Refer to Adjusting the Handle Neutral on page 4-12 and Setting the Hydraulic Pump Neutral page 4-14.

1. Push both control levers forward the same distance (Fig. 146). The machine should travel in a straight line. If not, proceed to step 2.



Fig 146

DSC-3121

HYDRAULIC SYSTEM

2. Stop the machine and set the parking brake.
3. Unlatch the seat and tilt the seat forward to access the tracking knob.

Note: Determine the left and right sides of the machine from normal operating position.

4. To make the machine go right, turn the knob towards the right side of the machine (Fig. 147).




Fig 147

fig. 57 m-6280

- | | |
|--------------------------------|---------------------------------|
| 1. Pump rod | 3. Tracking knob |
| 2. Turn this way to track left | 4. Turn this way to track right |
-
5. To make the machine go left, turn the knob towards the left side of the machine (Fig. 147, above).
 6. Repeat this adjustment until the tracking is correct.

Replacing the Pump Drive Belt

1. Pull the spring loaded idler down and remove traction belt from the engine and hydro pump pulleys (Fig. 148). Remove belt between the pulleys.



Fig 148

DSC-3122

4

2. Install new belt around engine and hydro pump pulleys (Fig. 149).




Fig 149

pump belt routing

3. Pull spring loaded idler down and align below traction belt. Release pressure on spring loaded idler.

HYDRAULIC SYSTEM

Purging the Hydraulic System

The traction system is self bleeding, however, it may be necessary to bleed the system if fluid is changed or after work is performed on the system.

1. Raise the machine so the wheels are off the ground and supported with jack stands (Fig. 150).



Fig 150

DSC-3123

2. Start the engine and run at low idle speed. Slowly engage the motion control lever. If the wheel does not rotate immediately, it may be necessary to spin the wheel by hand to start purging air that is trapped in the system (Fig. 151).



Fig 151

DSC-3124

3. When the wheel begins to spin on its own, keep it engaged until the wheel drives smoothly (minimum 2 minutes).
4. Check the hydraulic fluid level and add fluid as required to maintain proper level.
5. Repeat this procedure on the opposite wheel.

Hydraulic Flow Testing Procedure

Note: Cleanliness is a key factor in successful flow testing of the hydraulic system. Thoroughly clean all exposed surfaces prior to any type of maintenance. Cleaning all parts by using a solvent wash and air drying is usually adequate. As with any precision equipment, all parts must be kept free of foreign material and chemicals. Protect all exposed sealing areas and open cavities from damage and foreign material.

Flow tester P/N 70661, contact your DSM to order.

1. Lift the back of the unit so the rear tires (left and right) is off the ground. Place jack stands under the rear frame to support the unit. Remove the rear tire; in this case the left rear tire is being removed (Fig. 152).

Note: Be careful not to place jack stands near any moving parts or areas not capable of supporting the weight of the machine.



Fig 152

DSC-3125

HYDRAULIC SYSTEM

2. Clean any dirt or debris away from the hydraulic line fittings. Remove the hydraulic lines. Make sure you mark which hydraulic line goes to which fitting on the wheel motor. If the hydraulic lines are reversed, the motor will operate in the opposite direction.

Note: Make sure you cap the fittings to prevent dirt from entering the system (Fig. 153).



Fig 153

DSC-3126

3. Connect the hydraulic hose fittings to the hydraulic flow tester and tighten the fittings (Fig. 154). If the flow tester is bidirectional, make sure to connect hoses correctly.



Fig 154

DSC-3128

4. Check the hydraulic reservoir and fill as needed with Mobil 1, 15w50 oil.
5. Disconnect the electric PTO clutch from the wiring harness to prevent accidental engagement of the mower deck.
6. Disconnect the seat switch from the harness. Temporarily install a jumper wire across the harness (Fig. 155). Move the seat back to the operating position.



Fig 155

DSC-3116

7. Verify the restrictor valve on the hydraulic flow tester is in the fully "Opened" position.
8. Start the machine. Run the unit for approximately 5 minutes to warm the oil in the hydrostatic pumps.
9. Release the parking brake and bring both levers to the inside neutral position. Run the engine at full RPM.
10. Stroke the left hand hydrostatic lever fully forward. Very slowly, rotate the "T" handle of the adjustable flow tester restrictor valve until the pressure gauge reaches 300 psi (21 bar). Record the measured flow (gallons/liters per minute).

HYDRAULIC SYSTEM

11. With the unit at full engine throttle speed, slowly rotate the "T" handle of the flow tester restrictor valve clockwise until the pressure gauge reads approximately 1000 to 1200 psi (69 to 83 bar).

CAUTION: DO NOT operate the machine for extended period of time at high pressure.

12. Record the difference or "flow droop" of the pump. For the Hydro-Gear BDP 10A and BDP 12 pump, maximum allowable "flow droop" is 1.5 gpm. Any droop greater than 1.5 gpm (6.8 liters/min) is considered unacceptable and the pump should be replaced barring any other potential causes.
13. Return the motion control lever to neutral position and return the levers to the neutral locked position. Engage the parking brake. Slow the engine speed to idle and turn the ignition switch to the OFF position.
14. Disconnect the hydraulic flow tester from the hydraulic lines.
- 4 15. Re-connect the hydraulic lines to the wheel motor. Tighten fittings.
16. Check the hydraulic reservoir and fill as necessary to the "Hot" level mark, see, Checking the Hydraulic Fluid page 2-10.
17. Re-install the left rear tire and lower the unit to the ground. Remove the temporary jumper cable for the seat and reconnect the seat switch. Reconnect the connector for the electric PTO clutch.

Pushing the Machine by Hand

Important: Always push the machine by hand. Never tow the machine because hydraulic damage may occur.

1. Disengage the power take off (PTO) and turn the ignition key to OFF. Move the levers to the neutral position and apply the parking brake.
2. Rotate the by-pass valves counterclockwise 1 turn to push. This allows hydraulic fluid to by-pass the pump enabling the wheels to turn (Fig. 156).



Fig 156

DSC-3130

Important: Do not rotate the by-pass valves more than 1 turn or the valves can come out of the body and cause fluid to run out.

3. Disengage the parking brake before pushing.

Changing to Machine Operation

1. Rotate the bypass valves clockwise 1 turn to operate the machine (Fig. 157).

Note: Do not over-tighten the by-pass valves.



Fig 157

DSC-3130

Note: The machine will not drive unless the by-pass valves are turned in.

HYDRAULIC SYSTEM

THIS PAGE INTENTIONALLY LEFT BLANK.

4

Safety Information	1
Specifications	2
Chassis	3
Hydraulic System	4
Engine	5
Electrical	6
Mower Decks/PTO	7

ENGINE

Kohler Air-Cooled Engine Removal

1. Remove the battery negative cable from the battery.
2. Remove the bolt, spacer, spring, and nut on the top of the air cleaner bracket (Fig. 158).



Fig 158

DSC-2956

3. Remove the air cleaner hose on the engine (Fig. 159).



Fig 159

DSC-2957

4. Remove the air cleaner end cap and slide the air cleaner assembly out of the bracket (Fig. 160).



Fig 160

DSC-2958

5. Loosen the clamps and remove the throttle and choke cable from the engine control levers (Fig. 161).




Fig 161

DSC-2959

A. Throttle Cable

B. Choke Cable

6. Remove the tie strap securing the choke/throttle cables to the bracket located on the valve cover (Fig. 162).



Fig 162

DSC-2961

8. With a pry bar, relieve spring tension on the idler assembly and remove pump drive belt (Fig. 164).



Fig 164

DSC-2963

7. Turn the fuel shut off valve OFF. Remove the fuel line hose clamp at the engine and remove the fuel line (Fig. 163).




Fig 163

DSC-2962

A Fuel Valve

B Fuel Line

9. Remove two red cables from the starter solenoid (Fig. 165).



Fig 165

DSC-2964

ENGINE

10. Remove the blue wire from the starter solenoid (Fig. 166).



Fig 166

DSC-2965

12. Unplug the electric PTO clutch harness from the clutch. Remove the tie strap holding the clutch wire to the PTO stop rod (Fig. 168).



Fig 168

DSC-2966

11. Unplug the engine wiring harness from the main electrical harness (Fig. 167).



Fig 167

DSC-2970

13. Remove the mower drive belt from the electric PTO clutch, refer to Replacing the Mower Belt page 7-24.

14. Remove the 4 engine mounting bolts, spring washers, and nuts.

Note: The front left engine mount has two ground cables (Fig. 169).



Fig 169

DSC-2967

15. Connect lift chains/straps to the engine lift brackets. Raise the engine from the frame of the unit (Fig. 170).



Fig 170

DSC-2969

3. Install the mower drive belt around the electric PTO clutch; refer to Replacing the Mower Belt page 7-24.
4. Plug the electric PTO clutch harness into the clutch (Fig. 172). Secure the clutch wire to the PTO stop rod with a tie strap.



Fig 172

DSC-2966

Kohler Air-Cooled Engine Installation

1. Lower the engine to the frame of the unit.
2. Install the engine with 4 mounting bolts, spring washers, and nuts.

Note: The front left engine mounting bolt has the two ground cables (Fig. 171). Tighten the bolts.



Fig 171

DSC-2967

5. Connect the blue wire to the starter solenoid terminal as shown (Fig. 173).



Fig 173

DSC-2965

ENGINE

6. Attach the two red cables to the starter solenoid (Fig. 174).



Fig 174

DSC-2964

8. Install the fuel line to the engine and install a hose clamp. Turn the fuel shut off valve to the ON position (Fig. 176).




Fig 176

DSC-2971

A Fuel Valve

B Fuel Line Clamp

7. Install hydrostatic pump drive belt, using a pry bar to relieve the tension on the spring loaded idler pulley (Fig. 175).



Fig 175

DSC-2963

9. Install the throttle and choke cables to the throttle linkage. Position the throttle lever so it is approximately 1/2" (12.7mm) from the full throttle position. Make sure the choke lever is pushed down to the OFF position. Then tighten both cable clamps (Fig. 177).




Fig 177

DSC-2959

A Throttle Cable

B Choke Cable

10. Secure the throttle and choke cables to the bracket located on the engine valve cover with a tie strap (Fig. 178).



Fig 178

DSC-2972

12. Install the bolt, spacer, spring, and nut on the top of the air cleaner bracket and tighten (Fig. 180).



Fig 180

DSC-2956

11. Install the air cleaner assembly through the air cleaner assembly bracket and install the air cleaner end cap (Fig. 179).



Fig 179

DSC-2958

13. Install the hose to the engine and tighten the hose clamp (Fig. 181).



Fig 181

DSC-2957

14. Install the battery negative cable to the battery.
15. Test operate engine; adjust choke and throttle cables as required. Check engine low and high idle are to specification.

ENGINE

Kawasaki Air-Cooled Engine Removal

1. Remove the battery negative cable from the battery.
2. Remove the air cleaner cover (Fig. 182).

Note: This engine has a standard air cleaner cover. If engine is equipped with a heavy duty air cleaner assembly, remove the complete air cleaner assembly.



Fig 182

DSC-2973

3. Loosen the throttle and choke cable clamps and disconnect both cables (Fig. 183).




Fig 183

DSC-2975

A. Choke Cable

B. Throttle Cable

4. On the right side of the engine, next to the engine oil filter, is the oil pressure sending unit. Remove the wire from the sending unit (Fig. 184).



Fig 184

DSC-2976

5. Disconnect the electric PTO clutch wire from the clutch (Fig. 185).



Fig 185

DSC-2977

6. Remove the tie strap securing the electric PTO clutch wire to the PTO stop bracket.
7. Remove the mower drive belt from the electric PTO clutch; refer to Replacing the Mower Belt page 7-24.
8. Remove the red heavy gauge wire from the solenoid to the engine starter (Fig. 186).



Fig 186

DSC-2978

9. Disconnect three wires going from the main harness to the engine (Fig. 187).

- Violet wire to the Regulator/Rectifier
- White wire to the Engine Magneto wire
- Pink wire to the Fuel Solenoid




Fig 187

DSC-2980

- A. Violet Wire
- B. White Wire
- C. Pink Wire

10. Turn the fuel shut-off OFF. Remove the fuel line clamp at the engine and remove the fuel line (Fig. 188).




Fig 188

DSC-2981

- A Fuel Valve
- B Fuel Line Clamp

ENGINE

11. With a pry bar, relieve tension on the spring loaded idler and remove the pump drive belt (Fig. 189).



Fig 189

DSC-2982

13. Connect a lift chain to the lift points on the engine. Raise the engine from the frame (Fig. 191).



Fig 191

DSC-2984

12. Remove the 4 engine bolts, spring washers, and nuts mounting the engine to the frame. There are two ground wires located on the left front engine mount bolt (Fig. 190).



Fig 190

DSC-2983

Kawasaki Air-Cooled Engine Installation

1. Lower the engine to the frame of unit.
2. Install the engine with 4 mounting bolts, spring washers, and nuts.

Note: The front left engine mounting bolt has two ground cables (Fig. 192). Tighten the bolts.



Fig 192

DSC-2983

3. Install the mower drive belt around the electric PTO clutch, refer to Replacing the Mower Belt page 7-24.
4. Plug the electric PTO clutch harness into the clutch (Fig. 193). Secure the clutch wire to the PTO stop rod with a tie strap.



Fig 193

DSC-2977

5. Connect the three wires going from the main harness to the engine (Fig. 194).

- Violet wire to the Regulator/Rectifier
- White wire to the Engine Magneto wire
- Pink wire to the Fuel Solenoid




Fig 194

DSC-2980

- | | |
|----------------|--------------|
| A. Violet Wire | C. Pink Wire |
| B. White Wire | |

6. Install the red heavy gauge wire from the solenoid to the engine starter (Fig. 195).



Fig 195

DSC-2978

ENGINE

7. Install the fuel line to the engine and tighten the hose clamp. Turn the fuel shut off valve ON (Fig. 196).




Fig 196

DSC-2985

A Fuel Valve

B Fuel Line Clamp

8. Plug the wire into the oil pressure sending unit located next to the engine oil filter (Fig. 197).



Fig 197

DSC-2976

9. Connect the throttle and choke cables to the engine control linkage. Position the throttle control in the idle position. Make sure the choke lever is pushed down to the "Off" position when connecting the cable. Tighten both cable clamps (Fig. 198).




Fig 198

DSC-2975

A Choke Cable

B Throttle Cable

10. Install the hydrostatic pump drive belt, using a pry bar to release the tension on the spring loaded idler pulley (Fig. 199).



Fig 199

DSC-2982

11. Install the engine air cleaner cover on the engine (Fig. 200).

Note: This unit has a standard air cleaner assembly.



Fig 200

DSC-2973

2. Loosen the hose clamp on the air intake hose (Fig. 201).




Fig 201

DSC-2883

12. Install the battery negative cable to the battery.
13. Test operate engine; adjust choke and throttle cables as required. Check engine low and high idle are to specification.

28 HP Kohler EFI Air-Cooled Engine Removal

Note: If welding on an EFI equipped machine, be sure to disconnect the negative ground cable on the battery and disconnect the ECU.

1. Disconnect the negative battery cable from the battery.



Fig 202

DSC-2884

ENGINE

4. Remove the air cleaner cap and slide the air cleaner assembly out of the air cleaner bracket (Fig. 203).



Fig 203

DSC-2885

6. Remove the tie strap securing the throttle cable to the bracket on the valve cover (Fig. 205).



Fig 205

DSC-2887

5. Remove the fuel line clamp located on the engine fuel rail and remove hose (Fig. 204).



Fig 204

DSC-2886

7. Remove the throttle cable from the engine throttle linkage (Fig. 206).



Fig 206

DSC-2888

8. Remove the tie strap securing the fuel pump and electric clutch harness to the AC voltage wires coming from the stator (Fig. 207).



Fig 207

DSC-2889

9. Unplug the electric clutch harness from the electric clutch (Fig. 208).



Fig 208

DSC-2891

10. Remove the tie strap securing the electric PTO wires to the electric PTO clutch stop (Fig. 209).



Fig 209

DSC-2909

11. Remove the mower deck drive belt.

Note: Refer to Mower Deck Removal page 7-8.

12. Using a pry bar, release tension on the Hydro pump drive belt. Remove the hydro drive pump belt (Fig. 210).




Fig 210

DSC-2892

ENGINE

13. Remove the 3 red wires located at the starter solenoid (Fig. 211).



Fig 211

DSC-2894

15. Remove the ground cables located on the lower left side of the base of the engine (Fig. 213). One bolt goes into the side of the engine block and the other is the engine mounting bolt and nut.




Fig 213

DSC-2901

14. Remove the blue wire from the starter solenoid (Fig. 212).



Fig 212

DSC-2895

16. Disconnect the engine harness connector from the main wiring harness (Fig. 214).




Fig 214

DSC-2903

17. Remove the wire clamp bolted to the frame, located on the left side of the engine (Fig. 215).



Fig 215

DSC-2904

- Next, remove the multi-pin connector from the ECU (Fig. 217).



Fig 217

DSC-2908

18. Remove the wire connector located at the bottom of the ECU (Electronic Control Unit). First, remove the red retainer clip (Fig. 216).



Fig 216

DSC-2907

19. Remove the wire clip located on the side of the ECU that retains the test plug connector (Fig. 218).



Fig 218

DSC-2910

ENGINE

20. Remove the two fuse holders, located in front of the ECU unit (Fig. 219).




Fig 219

hidden fuses

22. Unplug the tan wire connector (Fig. 221).



Fig 221

DSC-2915

21. Unplug the left and center relay from their connectors. Remove 2 bolts and nuts retaining the connectors to the frame (Fig. 220).




Fig 220

DSC-2912

23. Remove the remaining 3 bolts, washer, and nuts retaining the engine to the frame (Fig. 222). Raise the engine out of the frame.



Fig 222

DSC-2916

28 HP Kohler EFI Air-Cooled Engine Installation

1. Lower the engine to the frame. Install 2 bolts, washers, and nuts on the right side of the engine. On the left side, mount only the bolt, washer, and nut to the rear engine mount. Tighten the bolts.
2. Connect the two tan wires, one from the engine harness and the other from the main harness (Fig. 223).
3. Install the two left relays to the frame using two bolts and washers (Fig. 224). Plug the remaining two relays into the harness.




Fig 223

DSC-2915



Fig 224

DSC-2912

4. Install the two fuse holders in front of the ECU control box (Fig. 225).




Fig 225

hidden fuses

ENGINE

5. Install the clamp holding the test plug connector to the side of the ECU control (Fig. 226).



Fig 226

DSC-2910

7. Install the wire connector to the bottom of the ECU (Fig. 228).



Fig 228

DSC-2908

6. Install a tie strap around the electric PTO harness and the PTO electric clutch stop rod (Fig. 227).



Fig 227

DSC-2917

- Install the red retainer clip on the wire connector (Fig. 229).



Fig 229

DSC-2907

8. Install the wire clamp to the frame on the left side of the engine (Fig. 230).



Fig 230

DSC-2904

10. Install the two sets of ground wires on the left side of the engine as shown (Fig. 232).



Fig 232

DSC-2901

9. Connect the engine harness connector to the main harness (Fig. 231).




Fig 231

DSC-2903

11. Install the blue wire to the starter solenoid terminal (Fig. 233).



Fig 233

DSC-2895

A. Main harness to engine connector

ENGINE

12. Install three red wires to the starter solenoid stud (Fig. 234).



Fig 234

DSC-2894

13. Install the hydro pump drive belt, using a pry bar to relieve the spring tension on the idler pulley (Fig. 235).




Fig 235

DSC-2892

14. Install the mower deck drive belt around the electric PTO clutch. Refer to Replacing the Mower Belt page 7-24.

15. Install the PTO clutch harness to the PTO clutch (Fig. 236).



Fig 236

DSC-2891

16. Secure the fuel pump and the electric clutch harness to the AC voltage wires coming from the stator with a tie strap (Fig. 237).



Fig 237

DSC-2918

17. Install the throttle cable to the engine throttle linkage. Make sure the throttle contacts the stop with the throttle control lever in the full speed position. Tighten throttle housing clamp (Fig. 238).




Fig 238

DSC-2888

18. Fasten the throttle cable to the engine lift bracket using a tie strap (Fig. 239).




Fig 239

DSC-2919

19. Install the fuel line to the engine fuel rail. Tighten the fuel line clamp (Fig. 240).



Fig 240

DSC-2920

20. Slide the air cleaner assembly into the air cleaner bracket (Fig. 241).



Fig 241

DSC-2885

ENGINE

21. Install the air cleaner assembly and air cleaner cap. Install the bolt, spacer, spring and nut to the air filter bracket. Tighten the bolt (Fig. 242).



Fig 242

DSC-2884

22. Install the air intake hose and tighten the hose clamp (Fig. 243).




Fig 243

DSC-2883

Kohler Electronic Fuel Injection (EFI) Models

EFI Fuel System

For engine specific service or diagnostics procedures, consult the engine manufacture's service manual.

The following are the locations of components which are EFI related but mounted to the unit's chassis.

1. The fuel pressure regulator and fuel pump are located in the back of the unit, under the right side of the chassis, next to the mower idler pulleys (Fig. 244).




Fig 244

DSC-2948

A. Fuel Pressure
Regulator

B. Fuel Pump

23. Install the battery negative cable on the battery.
24. Test operate engine; adjust throttle cable as required. Check engine low and high idle are to specification.

2. High pressure fuel filter is located under the seat behind the hydraulic reservoir (Fig. 245).



Fig 245

DSC-2951

3. Dual flow fuel valve is located under the seat, mounted to the frame (Fig. 246).



Fig 246

DSC-2952

EFI Electrical System

1. The electronic control unit (ECU) is located next to the engine starter, on the left rear side, mounted to the frame (Fig. 247).




Fig 247

DSC-2950

A. ECU unit

B. ECU test plug

2. The Transient Voltage Suppression (TVS) diode is located on the left side of the engine, next to the starter. (Fig. 248).




Fig 248

DSC-2953

ENGINE

The purpose of the TVS diode is to protect the ECU unit from any high voltage spikes in the electrical system, typically associated with the engagement and disengagement of the PTO clutch (Fig. 249).



Fig 249

DSC-2955

3. Remove the right and left hair pins, washers and clevis pins securing the hood. Remove the hood assembly (Fig. 251).




Fig 251

DSC-2802

27 HP Kawasaki Liquid-Cooled Engine Removal

1. Disconnect the negative and then the positive battery cable and remove the battery from the unit.
2. Unlatch and open the engine hood. Remove the bumper guard from the frame (Fig. 250).



Fig 250

DSC-2800

4. Remove 4 bolts, washers, and nuts retaining the engine shield. Remove the engine shield (Fig. 252).



Fig 252

DSC-2803

5. Remove the air deflector (Fig. 253).



Fig 253

DSC-2804

7. Drain the engine coolant through the engine drain port, located on the engine block, next to the engine oil filter (Fig. 255).



Fig 255

DSC-2806

6. Using a pry bar, relieve the idler pulley spring tension and remove the pump drive belt (Fig. 254).



Fig 254

DSC-2805

8. Remove the tie strap from the overflow hose located next to the radiator cap (Fig. 256).



Fig 256

DSC-2807

ENGINE

9. Remove the radiator inlet hose located on the right side of the radiator (Fig. 257).



Fig 257

DSC-2808

11. Unplug the wire connector for the cooling fan (Fig. 259).



Fig 259

DSC-2812

10. Remove the radiator outlet hose, located on the left rear of the radiator (Fig. 258).




Fig 258

DSC-2809

12. Remove the 3 bolts, washers, and nuts retaining the fan mounting plate (Fig. 260).




Fig 260

DSC-2810

13. Remove the 2 bolts, washers, and nuts on the right and left side of the fan mounting plate (Fig. 261).



Fig 261

DSC-2813

15. Remove the hose clamp from the air cleaner assembly (Fig. 263).



Fig 263

DSC-2815

14. Remove the fan mounting plate and radiator (Fig. 262).



Fig 262

DSC-2814

16. Remove two bolts, washers, and nuts retaining the air cleaner assembly to the left side radiator brace (Fig. 264).

Note: This allows better access to the battery bolt and nut.



Fig 264

DSC-2817

ENGINE

17. Unplug the two relays from the relay connectors. Remove the two bolts and nuts retaining the connectors to the right hand side plate (Fig. 265).



Fig 265

DSC-2818

19. Remove the two bolts and nuts on the right side of the machine used to hold the top rib to the right side radiator brace (Fig. 267). Remove the corresponding bolts and nuts on the left hand side.



Fig 267

DSC-2819

18. Remove the clamp and hose, located under the coolant overflow tank (Fig. 266).



Fig 266

DSC-2825

20. Remove two bolts and nuts retaining the top and bottom ribs and the bottom strap guard located on the right side (Fig. 268). Remove the corresponding bolts and nuts on the left hand side.



Fig 268

DSC-2823

21. Remove the two bolts and nuts retaining the rear radiator mount to the frame (Fig. 269).



Fig 269

DSC-2824

23. Loosen the clamps and remove the choke and throttle cables from the engine linkage (Fig. 271).




Fig 271

DSC-2827

A. Choke Cable

B. Throttle Cable

22. Remove the rear support assembly from the frame (Fig. 270).



Fig 270

DSC-2826

24. Release the belt tension on the mower drive belt and remove belt around the electric PTO clutch, follow procedures for Replacing the Mower Belt page 7-24.

25. Disconnect the plug for the electric PTO clutch (Fig. 272).



Fig 272

DSC-2828

ENGINE

26. Remove the three engine ground cables located on the lower right rear of the engine (Fig. 273).



Fig 273

DSC-2829

28. Remove the 3 red wires from the starter solenoid (Fig. 275).




Fig 275

DSC-3164

27. Unplug the orange/black wire to the starter solenoid (Fig. 274).



Fig 274

DSC-3163

29. Unplug the black and white wiring connector from the wiring harness located on the right front side of the engine (Fig. 276).

Note: The other two wiring connectors do not need to be disconnected.




Fig 276

DSC-2832

30. Turn the fuel shut-off valve to the OFF position.
31. Move the hose clamp and disconnect the fuel line on top of the engine (Fig. 277).




Fig 277

DSC-2833

- A. Hose clamp B. Fuel line

32. Remove the 4 bolts and spring washers retaining the engine to the frame. The engine mounting bolts are located under the engine in tapped holes in the engine block.
33. Remove the engine from the frame (Fig. 278).



Fig 278

DSC-2836

27 HP Kawasaki Liquid-Cooled Engine Installation

1. Lower the engine on to the frame. Install 4 bolts and spring washers through the frame and into the base of the engine. Tighten the bolts.
2. Connect the gas line on top of the engine and install the hose clamp (Fig. 279).



Fig 279

DSC-2833

3. Turn the fuel shut-off valve to the ON position.
4. Reconnect the black and white wiring connector located on the right front side of the engine (Fig. 280).



Fig 280

DSC-2832

ENGINE

5. Install the 3 red wires to the starter solenoid post and tighten (Fig. 281).




Fig 281

DSC-3164

7. Install the 3 ground wires to the lower rear of the engine (Fig. 283).



Fig 283

DSC-2829

6. Plug the orange/black wire to the starter solenoid (Fig. 282).



Fig 282

DSC-3163

8. Plug the wiring connector to the electric PTO clutch (Fig. 284).



Fig 284

DSC-2828

9. Install the mower drive belt around the electric PTO clutch; follow the procedures for Replacing the Mower Belt page 7-24.
10. Install the choke cable to the engine linkage; make sure the choke knob is pushed all the way in before tightening down the clamp (Fig. 285). Tighten the choke cable clamp.



Fig 285

DSC-2838

11. Install the throttle cable to the engine linkage. Make sure the throttle is all the way back to the idle position. Tighten the throttle clamp (Fig. 286).



Fig 286

DSC-2839

12. Install the rear support assembly to the frame (Fig. 287).



Fig 287

DSC-2826

13. Install two bolts and nuts connecting the rear radiator mount to the frame (Fig. 288).




Fig 288

DSC-2824

ENGINE

14. Install the two bolts and nuts retaining the top and bottom strap guard located on the right side (Fig. 289). Install the corresponding bolts and nuts on the left side.



Fig 289

DSC-2823

15. Install the two bolts and nuts located on the right side holding the top rib to the right side radiator brace (Fig. 290). Install the corresponding bolts and nuts on the left hand side. Tighten all of the bolts and nuts.



Fig 290

DSC-2819

16. Install the hose and clamp, located under the coolant overflow tank (Fig. 291).



Fig 291

DSC-2825

17. Install two bolts and nuts securing the relays connectors to the right side plate (Fig. 292). Plug the two relays into the connectors.



Fig 292

DSC-2818

18. Install two bolts, washers, and nuts retaining the air cleaner assembly to the left side radiator brace (Fig. 293).

Note: Leave the air filter and air cleaner cover off until after you fill the coolant reservoir bottle.



Fig 293

DSC-2817

19. Install the hose clamp on the air cleaner assembly (shown with air filter cover on) (Fig. 294).



Fig 294

DSC-2815

20. Install the fan mounting plate and radiator (Fig. 295).



Fig 295

DSC-2814

21. Install the 2 bolts and washers on the right and left side of the fan mounting plate (Fig. 296).



Fig 296

DSC-2840

ENGINE

22. Install 3 bolts, washers, and nuts to the rear of the fan mounting plate (Fig. 297). Tighten all 7 bolts and nuts.



Fig 297

DSC-2841

24. Install the radiator outlet hose clamp located on the left rear of the radiator (Fig. 299).




Fig 299

DSC-2809

23. Connect the wiring for the cooling fan (Fig. 298).



Fig 298

DSC-2812

25. Install the radiator inlet hose and clamp located on the right side of the radiator (Fig. 300).



Fig 300

DSC-2808

26. Install the overflow hose next to the radiator cap with a tie strap (Fig. 301).



Fig 301

DSC-2853

27. Add a 50-50 mix of water and coolant to the radiator (Fig. 302) and the overflow bottle (Fig. 303). Fill to the line indicator of the overflow bottle.




Fig 302

DSC-2854



Fig 303

DSC-2855

28. Install the air filter and air cleaner cover.
29. With a suitable pry bar, relieve the spring tension on the idler pulley spring and install the hydraulic pump drive belt (Fig. 304).



Fig 304

DSC-2805

ENGINE

30. Install the air deflector (Fig. 305).



Fig 305

DSC-2804

32. Install the engine hood assembly with 2 clevis pins, washers, and hair pins (Fig. 307).




Fig 307

DSC-2802

31. Install the engine shield with 4 bolts, washers, and nuts and tighten (Fig. 306).



Fig 306

DSC-2803

33. Install the rear bumper guard (Fig. 308).



Fig 308

DSC-2800

34. Install the battery and connect the positive and then the negative battery cable.

35. Test operate engine; adjust choke and throttle cables as required. Check engine low and high idle are to specification. Add coolant as needed; check system for leaks.

Cooling Fan Assembly Removal - 27 HP Kawasaki Liquid-Cooled Engine

1. Disconnect the negative battery cable.
2. Unlatch and open the engine hood. Remove the right and left hair pins located on the hood. Remove the hood assembly (Fig. 309).



Fig 309

DSC-2800

3. Remove four bolts, washers, and nuts retaining the rear engine shield. Remove the engine shield (Fig. 310).



Fig 310

DSC-2803

4. Remove the crossbar located across the front of the radiator (Fig. 311).



Fig 311

DSC-2844

- A. Crossbar support

5. Unplug the wire connector for the cooling fan (Fig. 312).



Fig 312

DSC-2812

ENGINE

6. Drain the engine coolant through the engine drain bolt located on the engine block next to the engine oil filter (Fig. 313).




Fig 313

DSC-2806

8. Remove the radiator inlet hose, located on the right side of the radiator (Fig. 315).



Fig 315

DSC-2808

7. Remove the tie strap around the overflow hose located next to the radiator cap (Fig. 314).



Fig 314

DSC-2807




Fig 316

DSC-2809

10. There are 6 bolts and washers located under the radiator retaining the radiator to the fan mounting plate. Remove all 6 bolts and washers. Remove the radiator (Fig. 317).



Fig 317

DSC-2845

11. Remove the 4 bolts, washers, and nuts retaining the fan assembly to the fan mounting plate assembly (Fig. 318).




Fig 318

DSC-2847

12. Before removing the fan assembly, remove two clamps located on the upper engine air duct. Remove the engine air intake duct (Fig. 319).



Fig 319

DSC-2848

Note: Fan removed for clarity.

13. Remove the fan assembly through the front opening of the radiator support (Fig. 320).



Fig 320

DSC-2849

Cooling Fan Assembly Installation

Reverse the order of removal.

THIS PAGE INTENTIONALLY LEFT BLANK.

Safety Information	1
Specifications	2
Chassis	3
Hydraulic System	4
Engine	5
Electrical	6
Mower Decks/PTO	7

ELECTRICAL

GENERAL

Note: Interactive Electrical Troubleshooting CD, Form #492-9143 is also available.

RELAYS

Purpose

There are as many as three relays in a Z500 air-cooled or liquid cooled gas machine depending on model.

Relays have 4 functions in the Z500 gas machine:

1. Start Relay
2. Kill Relay
3. Fan Relay (liquid cooled gas only)
4. Fuel Pump Relay (Kohler EFI engine)

- 1. Start Relay:** If all conditions of the safety system are met, the start relay will activate allowing current to flow to the starter solenoid when the ignition is in the “start” position.
- 2. Kill Relay:** If any of the conditions of the safety circuit are not met during operation the kill relay is de-energized which will ground the ignition coil.
- 3. Fan Relay:** Activates when the ignition switch is in the “run” position, energizing the cooling fan (Liquid cooled machines only).
- 4. Fuel Pump Relay:** (Kohler EFI engine): Activates when the ignition switch is in the “run” position, providing 12VDC to the fuel pump, fuel injectors and ignition coils.

The Fuel Pump Relay is part of the Kohler engine electrical system. Refer to the Kohler engine service manual for more detailed service information.

For reference purposes, Fuel Pump Relay wiring terminal connections are listed below.

Terminal #	Connection
30	Battery Voltage
85	Ignition Switch Voltage
86	ECU-Controlled Ground
87	Feed to Ignition Coils, Fuel Pump and Injectors
87a	Not Used

Location

Air-Cooled Engine Models: Two relays located on the left side of the unit, between the engine and the frame (Fig. 321).




Fig 321

DSC-3159

A. Start Relay (left)

B. Kill Relay (right)

Air-Cooled EFI Engine Model: Three relays located on the left side of the unit, between the engine and the frame (Fig. 322).




Fig 322

DSC-3161

A. Fuel Pump Relay (left)

C. Start Relay (right)

B. Kill/Safety Relay (middle)

Liquid-Cooled Engine Model: Three relays located on the right rear radiator support arms, next to the ROPS (Fig. 323).




Fig 323

DSC-3162

- A. Fan Relay (toward front) C. Kill Relay (back)
B. Start Relay (middle)

How It Works

A relay is an electrically actuated switch (Fig. 324).



Fig 324

DSC-2517

1. Coil: Terminals 85 and 86 are connected to an internal coil. Applying 12 volts to either terminal energizes the coil turning it into an electromagnet.
2. Switch: Terminals 30, 87, and 87a are actually part of a single pole, double throw (SPDT) switch. Terminal 30 is the common lead. The switch is spring loaded so that terminals 30 and 87a are connected when the relay is not energized. When the relay is energized, the magnetic field overcomes the spring loaded switch and connects terminals 30 and 87 (Fig 325).




Fig 325

relay pin diagram

ELECTRICAL

Testing

1. Disconnect the relay from the harness.
2. Verify the coil resistance between terminals 85 and 86 with a multimeter (ohms setting). Resistance should be from 70 to 90 ohms. There should be continuity between terminals 87a and 30 (Fig. 326).




Fig 326

relay pin diagram

5. Disconnect voltage and multimeter leads from relay terminals (Fig. 327).




Fig 327

xl relay

Relay not energized.

PTO SWITCH

Purpose

The PTO (Power Take Off) switch is typically used to activate the Electric PTO Clutch and to function as part of the safety interlock system.

3. Connect multimeter (ohms setting) leads to relay terminals 30 and 87. Ground terminal 86 and apply +12 VDC to 85. The relay should make and break continuity between terminals 30 and 87 when 12 VDC is applied and removed from terminal 85.
4. Connect multimeter (ohms setting) leads to relay terminals 30 and 87a. Apply +12VDC to terminal 85. With terminal 86 still grounded, the relay should break and make continuity between terminals 30 and 87a as 12 VDC is applied and removed from terminal.

Location

The PTO switch is located in the control panel on the left side of the operator (Fig. 328).



Fig 328

DSC-3150

How It Works

When the PTO switch is activated, mechanical connections are made between various terminals. One terminal is connected to the wire that goes directly to the electric clutch. When the PTO is pulled out to the “ON” position, voltage flows to the electric clutch which causes it to engage. When the switch is pushed in to the “OFF” position, current flows through the PTO switch to the Park Brake switch to complete the safety circuit to start the unit.

Testing

1. Disengage the PTO, set the parking brake, and turn the ignition to the “OFF” position. Remove the key.
2. Remove the 4 screws holding the control panel to the fuel tank.
3. Disconnect the wiring harness from the PTO switch.
4. Press in the locking tabs, on each side of the switch, and pull the switch out of the control panel.
5. Verify that there is continuity between the appropriate terminals in the ON and OFF positions (Fig. 329).




Fig 329

PTO switch test gas

Continuity? Y = Yes N = No

6. Replace the switch if your test results do not correspond with those given in Figure 329, above.
7. Mount the PTO switch back into the control panel and reinstall the wiring harness.

ELECTRICAL

IGNITION SWITCH

Purpose

The ignition switch provides the proper switching for the starter, accessories, and safety circuits.

Location

The ignition switch is located on the control panel, to the left side of the operator (Fig. 330).



Fig 330

DSC-3150

How It Works

Detents inside the switch give it 3 positions: OFF, RUN, and START. The START position is spring loaded so the cylinder automatically returns to RUN once the key is released (Fig. 331).




Fig 331

mvc-166

Ignition Switch

- B = Battery voltage “in”
- S = Starting Circuit
- I = Safety Circuit, Gauges and Start Circuit
- A = Alternator/Charge Circuit
- Y = Safety and Start Circuit
- X = Safety/Start/Delay Module

Testing

1. Disconnect the switch from the wiring harness
2. Verify that continuity exists between the terminals listed for the switch position. Verify that there is NO continuity between terminals not listed for the switch position.

OFF	No continuity between terminals
RUN	Continuity – B I A and XY
START	Continuity – B I S

NEUTRAL SAFETY SWITCH

Purpose

Used to ensure the motion control handles are in neutral to start the unit. It is activated by moving the motion control handles to the neutral position (handles in the out position).

Location

To gain access to the neutral safety switches, the front pocket has to be removed. There are 2 neutral switches, one for the right motion control handle and one for the left motion control handle (Fig. 332).



Fig 332

DSC-2524

This single pole plunger (normally open) type switch has two terminals. When the motion control handles are in the neutral position (handles in the out position), it pushes on the plunger, closing the contact, and connecting the terminals (Fig. 333).



Fig 333

DSC-2527

Testing

1. Disconnect the switch from the wiring harness.
2. Using a VOM or test light, check first to ensure there is no continuity between the terminals, plunger out.
3. With the plunger pushed in, there should be continuity between the terminals.

ELECTRICAL

PARK BRAKE SWITCH

Purpose

The purpose of the brake switch is to ensure the machine is in neutral and the parking brake is applied before attempting to start the machine.

Location

The park brake switch is located on the left side of the operators below the left motion control handle (Fig. 334).




Fig 334

DSC-2525

How It Works

In the start position it is used to ensure the park brake is "ON". At the same time it allows current to flow through for the safety circuit. When the park brake is released in the "OFF" position it bypasses both neutral switches as long as the operator is in the seat thereby maintaining current for the safety circuit (Fig. 335).



Fig 335

DSC-2528

Testing

1. Disconnect the switch from the wiring harness.

2. Using a multimeter, follow the procedures listed below (Fig. 336).




Fig 336 brake switch

Plunger <u>Not</u> Depressed	Plunger Depressed
A/B Terminals – Closed Circuit – Continuity	A/B Terminals – Open Circuit – No Continuity
C/D Terminals – Open Circuit – No Continuity	C/D Terminals – Closed Circuit – Continuity

SEAT SWITCH

Purpose

The switch is in the safety circuit. If the engine is running and the operator vacates the seat with either the PTO engaged or the parking brake off, the engine will shut down.

Note: With a delay module in the system, there will be a slight delay before the engine shuts down after the operator vacates the seat.

Location

The seat switch is fastened to the bottom of seat base on all models equipped with deluxe suspension seats (Fig. 337).



Fig 337 DSC-2555

ELECTRICAL

For all models equipped with a standard seat, the seat switch is located between the frame cross-member and the rear of the hydraulic oil tank (Fig. 338).



Fig 338

DSC-3151

How It Works

When the seat is vacated, the switch is open and there should be NO continuity between the two terminals. When the seat is occupied, the switch closes and there should be continuity between the two terminals. (Deluxe suspension seat switch shown) (Fig. 339).



Fig 339

DSC-2556

(Standard seat switch shown.) (Fig. 340)



Fig 340

DSC-3154

Testing

1. Disconnect the switch from the wiring harness.
2. Using a VOM or test light, check first to ensure there is no continuity between either terminal, plunger out.
3. With the plunger pushed in, there should be continuity between the terminals.

Note: This procedure applies to both standard seat and deluxe suspension seat switches.

SEAT DELAY MODULE

Purpose

When operating the unit on rough terrain, if the operator should come off the seat momentarily, the seat delay module will temporarily delay the engine shutting down.

Location

The seat delay module is located under the control console behind the console pocket (Fig. 341).




Fig 341

DSC-3156

How It Works

The seat delay module circuit board is made up with several different electrical components such as transient voltage suppressor, capacitor, transistors, carbon film resistors, diodes and a relay. The components work together to allow any short term voltage interruption in the seat switch and supplies temporary voltage to the safety circuit to keep the engine running (Fig. 342).



Fig 342

DSC-2532

Testing

1. Raise the seat and disconnect the seat switch. Install a jumper wire in place of the seat switch (Fig. 343).



Fig 343

DSC-3157

ELECTRICAL

2. Remove the 4 bolts to the pocket. Remove the pocket.
3. Connect a VOM positive lead to the violet wires on the module (Fig. 344). Connect the negative lead to the battery negative terminal.



Fig 344

DSC-3158

TEMPERATURE GAUGE Liquid-Cooled Engine Only

Purpose

The purpose of the temperature gauge is to monitor the engine coolant temperature.

Location

The temperature gauge is located on the left side of the operator on the control panel (Fig. 345).



Fig 345

DSC-2550

4. While sitting in the seat, follow the procedure below to test the delay module function.
 1. Disengage the parking brake.
 2. Pull the right and left motion control levers out of the neutral position.
 3. Turn the ignition key to the RUN position.
 4. The meter should read approximately 12 volts DC.
 5. Lift off the seat or disconnect one of the seat jumper wire leads. The meter should hold around 12 volts and then read 0 volts DC after approximately 1 to 3 seconds. This test shows the delay module is working.
5. If you do not get 12 volts DC at the violet wire when turning the ignition switch to the RUN position, verify the following:
 1. 12VDC at the Tan wire terminal.
 2. 12VDC at the Brown wire terminal.
 3. 0 VDC at the Gray wire terminal.
 4. If all these conditions are met, replace the seat delay module.

How It Works

When the engine coolant temperature increases the sending unit resistance decreases, which causes the needle on the water temperature gauge to increase (Fig. 346).



Fig 346

DSC-2549

Testing

Time-efficient testing is not possible. See information under Temperature Sender, page 6-14.

Back side of the Temperature Gauge with terminal and wire locations (Fig. 347).

- S Terminal – Yellow/Red Wire (to the Temperature Sender)
- G Terminal – Black Wire (Ground)
- I Terminal – Orange Wire (I Terminal of the Ignition Switch)




Fig 347

DSC-2551

ELECTRICAL

TEMPERATURE SENDER

Purpose

The temperature sender is a temperature-dependent variable resistor. As the coolant temperature increases the internal resistance decreases. This causes a change in voltage applied to the water temperature gauge, which indicates a higher temperature.

Location

The temperature sender is located on the right side of the engine, just below the exhaust header pipe to the muffler.

How It Works

When the water temperature increases the internal resistance decreases which will cause the water temperature gauge to increase (Fig. 348).



Fig 348

DSC-2548

Testing

It is not practical to test the sender in a shop environment. If the gauge is not reading at all, temporarily ground the lead at the sender. If the meter reads full scale, the ground wire and gauge are OK and the sender is bad. If the gauge does not respond, check for 12 VDC at gauge and continuity of the ground lead. If OK, the gauge is bad. Erratic readings can be either the gauge or sender. Replace the sender first, when diagnosing.

HOUR METER

Purpose

The hour meter keeps track of the actual unit running hours or the time that the ignition key switch is in the RUN position.

Location

Raise the seat; the hour meter is located on the left side of the operator on the lower portion of the control panel (Fig. 349).



Fig 349

DSC-2559

How It Works

Since a normal clock might be affected by variations in voltage and current, the hour meter is made up of an electric “winder” and a mechanical clock movement. When power is applied, a coil is energized to wind the movement. The movement unwinds in about 2 seconds. As it finishes its rotation, it re-energizes the coil so that the cycle can start over (Fig. 350).



Fig 350

DSC-2560

Testing

Verify that 12 volts DC is present across the two terminals when the ignition key is in the RUN position. If so, and the meter is not running, replace the meter. If 12 volts is not present, check the connections. The meter is a permanently sealed unit and is not repairable.

VOLTMETER GAUGE

Purpose

This gauge indicates the voltage across the battery.

Location

The voltmeter is located to the left side of the operator, on the control panel (Fig. 351).



Fig 351

DSC-2563

How It Works

The meter movement is proportional to the voltage level across the two terminals of the battery. This is accomplished by placing a resistor in parallel with the meter.

ELECTRICAL

Testing

1. Remove the control panel from the tank by removing 4 screws.
2. With a VOM, place the negative probe to the battery negative cable. Turn the ignition key to the RUN position.
3. Place the positive probe of the meter to the I (orange wire) terminal. You should read the DC battery voltage level on the meter.
4. Move the positive probe of the meter to the G (black wire) terminal. You should get 0 volts DC on the meter.
5. If you DO NOT get the above readings, replace the voltmeter.

Location

The electric clutch is located on the PTO end of the crankshaft (Fig. 352).



Fig 352

DSC-2552

ELECTRIC PTO CLUTCH

Purpose

The electric clutch controls the engagement and disengagement of the Power Take Off (PTO) pulley.

How It Works

The PTO clutch is composed of three major components; the field, the clutch plate, and the friction plate. The clutch plate always turns with the engine. The field is a coil of wire wound around an iron core, which acts like an electromagnet when power is applied.

The friction plate is the only piece that can slide inward and outward on the crankshaft axis. It is spring loaded away from contact with the clutch plate. When the clutch is not energized, the clutch plate rests against the brake material opposite the clutch plate. When energized the friction plate is drawn into the clutch plate magnetically and the two rotate as one component.

Testing

If the electric PTO clutch does not engage or is suspect as the cause of an electrical problem in the PTO circuit, use the following troubleshooting steps to determine whether the clutch has failed or another electrical problem exists.

Coil Resistance Measurement

1. Disengage the PTO, set the parking brake, turn the ignition to the "off" position and remove the ignition key.
2. Disconnect the clutch wire.
3. Set the multimeter or volt/ohm meter to check resistance (ohms).
4. Connect the meter lead wires to the clutch wires as shown (Fig. 353).



Fig 353

DSC-2553

5. The meter should read between approximately 2-4 ohms (meter readings may vary). If the reading is above or below these readings, the field has failed and needs to be replaced. If the reading falls between 2-4 ohms, measure clutch current draw.

Measuring Clutch Current Draw

1. Disengage the PTO, set the parking brake, turn the ignition key to OFF, and remove the key.
2. Loosen 4 bolts and remove the rear bumper plate loosening 4 bolts.
3. Disconnect the electric PTO clutch wire connector.
4. Set the multi meter to check amps (10 amp scale).
5. Connect the positive meter lead to the tractor terminal (1) of the clutch harness (Fig. 354).




Fig 354

diag 3-7


6. Connect the negative meter lead to the corresponding wire terminal (3) (Fig. 354, above).
7. Connect a short jumper lead from terminal (2) to terminal (4) (Fig. 354, above).
8. Turn the ignition switch to the "RUN" position. Turn the PTO switch to the "ON" position.
9. If the meter is 3.5 amps or above, the system is functioning properly. If the meter reading is below 3.5 amps, check the electrical system for problems (i.e., the battery, ignition switch, PTO switch, or wiring harness may be malfunctioning).

6

6-18




Kohler A/C (Air Cooled)




ELECTRICAL

Kawasaki A/C (Air Cooled)



6-21



THIS PAGE INTENTIONALLY LEFT BLANK.

Safety Information	1
Specifications	2
Chassis	3
Hydraulic System	4
Engine	5
Electrical	6
Mower Decks/PTO	7

MOWER DECKS/PTO

Electric PTO Clutch Removal

The electric PTO clutch removal and installation are similar on both the air cooled engine models and the liquid cooled model. The only difference is the clutch guard removal. The figure below points to the bolts that need to be removed in both units (Fig. 355). The procedure shows an air-cooled unit.




Fig 355

DSC-3131

- A. Top strap bolts B. Clutch guard bolts

On the Kawasaki liquid cooled models, remove 6 bolts to access the clutch (Fig. 356).



Fig 356

DSC-3794

This procedure is on the Air Cooled Engine Models and follows the same procedure for the Liquid Cooled Engine Model.

1. Loosen and remove 2 bolts and nuts located on the clutch guard (Fig. 357).



Fig 357

DSC-3131

2. Remove the right and left top bolt and nut on the top strap guards to remove the clutch guard from the unit (Fig. 358).



Fig 358

DSC-3134

MOWER DECKS/PTO

3. Disconnect the electric PTO clutch connector from the clutch (Fig. 359).



Fig 359

DSC-3135

5. Loosen the two nuts located on the idler plate to relieve tension on the belt (Fig. 361).




Fig 361

DSC-3137

4. Lift the floor pan and remove the right side mower belt cover (Fig. 360).



Fig 360

DSC-3136

6. Slip the mower drive belt off the right mower spindle pulley (Fig. 362).



Fig 362

DSC-3138

7

MOWER DECKS/PTO

7. Remove the belt from the electric PTO clutch (Fig. 363).



Fig 363

DSC-3139

9. Remove the electric PTO clutch from the engine crankshaft (Fig. 365).



Fig 365

DSC-3141

8. Remove the electric PTO clutch bolt (Fig. 364).



Fig 364

DSC-3140

Electric PTO Clutch Installation

1. Apply anti-seize compound to the engine crankshaft (Fig. 366).



Fig 366

DSC-3142

MOWER DECKS/PTO

2. Install the electric PTO clutch to the engine crankshaft (Fig. 367).



Fig 367

DSC-3141

4. Install the mower drive belt around the electric PTO clutch pulley (Fig. 369).



Fig 369

DSC-3144

3. Apply medium strength threadlocking material to the bolt. Install the bolt and two spring washers to the crankshaft. Torque the bolt to 65 ft. lbs (88.13 Nm) (Fig. 368).



Fig 368

DSC-3143

5. Check and make sure the mower drive belt is in the grooves of the two idler pulleys located under the electric PTO clutch (Fig. 370).




Fig 370

DSC-3145

A. Idler pulley

B. Stationary idler

7

MOWER DECKS/PTO

6. Route the belt around all of the mower deck pulleys and install the belt around the right side mower spindle pulley (Fig. 371).



Fig 371

DSC-3146

7. Install a 1/2" ratchet and extension, into the square hole in the idler plate (Fig. 373).



Fig 373

DSC-3147

Important: Check the amount of twist in the belt between the pulleys. Make sure it is only what is specified in Figure 372.




Fig 372

fig. 70 m-6825

- | | |
|------------------------|-------------------------|
| 1. Clutch | 4. Belt guide |
| 2. Mower belt | 5. Mower spindle pulley |
| 3. 1/4 turn belt twist | 6. Mower idler pulley |

8. Rotate the mower idler plate toward the front of the mower deck until light contact is made between the rear idler arm and the rubber stop (Fig. 374).




Fig 374

DSC-3148

- | | |
|------------------------------------|--------------------|
| 8. Direction to rotate idler plate | B. Idler plate nut |
|------------------------------------|--------------------|

MOWER DECKS/PTO

9. Tighten the pivot bolt on the idler plate once the adjustment is achieved (Fig. 375).



Fig 375

DSC-3149

10. Connect the PTO clutch connector to the clutch (Fig. 376).



Fig 376

DSC-3135

11. Install the right belt cover on the mower deck.
12. Install the right and left top strap guards, with the clutch guard to the unit (Fig. 377).



Fig 377

DSC-3134

13. Install and tighten the two bolts and nuts on the top strap guards and the two bolts in the clutch guard (Fig. 378).




Fig 378

DSC-3131

A. Top strap bolts

B. Clutch guard bolts

MOWER DECKS/PTO

Mower Deck Removal (52, 60, 72")

1. Lift the floor pan and remove the right hand belt cover (Fig. 379).



Fig 379

DSC-3136

2. Loosen the two nuts located on the idler plate to relieve tension on the mower drive belt (Fig. 380).




Fig 380

DSC-3137

A. Idler plate bolt

3. Slip the mower drive belt off the right mower spindle pulley (Fig. 381).



Fig 381

DSC-3138

4. Remove the belt around the electric PTO clutch pulley and the two rear idler pulleys (Fig. 382).



Fig 382

DSC-3139

Note: Clutch guard removed for clarity.

MOWER DECKS/PTO

5. Raise the mower deck to the transport position. Install a 4 x 4 wood block under the right side of the mower deck. Lower the deck to relieve tension on the lift chains on the right side (Fig. 383).



Fig 383

DSC-2623

6. Remove the front and rear lift chains from the mower deck (Fig. 384).



Fig 384

DSC-2631

7. Remove the bolt and nut holding the right rear strut pin into the strut assembly (Fig. 385).



Fig 385

DSC-2632

8. Remove the strut pin from the strut assembly and remove the assembly from the mower deck (Fig. 386).



Fig 386

DSC-2633

MOWER DECKS/PTO

Tie strap the strut assembly up so it will be out of the way of the mower deck when sliding it out under the frame. Remove the 4 x 4 block of wood from the right side of the deck and allow the deck to rest on the floor.

9. Raise the deck to transport position. Install a 4 x 4 wood block under the left side of the mower deck. Lower the mower deck until it rests on the block of wood to relieve tension on the lift chains (Fig. 387).



Fig 387

DSC-2635

10. Push the lift handle to the lowest HOC position to overcome the tension of the lift assist springs. Use the hitch pin above the lift handle to lock the handle in the down position (Fig. 388).



Fig 388

DSC-2636

11. Follow steps 5 through 8 on the left side of the mower deck.
12. Remove the 4 x 4 wood block from under the left side of the mower deck and lower the deck to the floor.

MOWER DECKS/PTO

13. Turn the right front wheel so the caster fork is angled forward. This will allow more clearance to slide the mower deck from under the frame (Fig. 389).



Fig 389

DSC-2637

14. Slide the mower out the right side of the unit (Fig. 390).



Fig 390

DSC-2638

Mower Deck Installation (52, 60, 72")

1. Slide the mower deck under the unit.
2. Install a 4 x 4 block of wood under the left side of the mower deck (Fig. 391).



Fig 391

DSC-2635

3. Install the strut pin through the strut assembly. Install the bolt and nut retaining the strut pin (Fig. 392).



Fig 392

DSC-2639

MOWER DECKS/PTO

4. Install the rear and front chains to the mower deck (Fig. 393).



Fig 393

DSC-2640

11. Install the belt around the electric PTO clutch pulley (Fig. 394).



Fig 394

DSC-3139

Note: Clutch guard removed for clarity.

5. Remove the hitch pin on the lift handle and raise the mower in the transport position.
6. Install a 4 x 4 wood block under the right side of the mower deck.
7. Lower the mower deck down on the wood block.
8. Install the strut pin in the strut assembly. Install and tighten the bolt and nut.
9. Install the rear and front lift chains to the mower.
10. Raise the mower deck and remove the wood block.

12. Check and make sure the mower drive belt is in the grooves of the two idler pulleys located under the electric PTO clutch (Fig. 395).




Fig 395

DSC-3145

A. Idler pulley

B. Stationary idler

MOWER DECKS/PTO

13. Route the belt around all of the mower deck pulleys and install the belt around the right side mower spindle pulley (Fig. 396).



Fig 396

DSC-3146

14. Install a 1/2" socket ratchet and extension, in the square hole in the idler plate (Fig. 398).



Fig 398

DSC-3147

Important: Check the amount of twist in the belt between the pulleys. Make sure it is only what is specified in Fig. 397 below.




Fig 397

fig. 70 m-6825

- | | |
|------------------------|-------------------------|
| 1. Clutch | 4. Belt guide |
| 2. Mower belt | 5. Mower spindle pulley |
| 3. 1/4 turn belt twist | 6. Mower idler pulley |

15. Rotate the mower idler plate toward the front of the mower deck until light contact is made between the idler arm and the rubber stop (Fig. 399).




Fig 399

DSC-3148

- | | |
|------------------------------------|--------------------|
| 8. Direction to rotate idler plate | B. Idler plate nut |
|------------------------------------|--------------------|

MOWER DECKS/PTO

16. Tighten the pivot bolt on the idler plate once the adjustment is achieved (Fig. 400).



Fig 400

DSC-3149

5. Lift the floor pan and remove the right side mower belt cover (Fig. 401).



Fig 401

DSC-3136

17. Install the right belt cover on the mower deck.

6. Loosen the two nuts located on the idler plate to relieve tension on the belt (Fig. 402).

Mower Spindle Removal

This applies to removing any of the three mower spindles. This procedure shows removing the right side spindle.

1. Either use a hoist or the Z Stand to raise the front of the mower deck.
2. Chock or block the drive wheels.
3. Disconnect the battery negative cable.
4. Lower the mower deck to the lowest position.



Fig 402

DSC-3137

MOWER DECKS/PTO

7. Slip the mower drive belt off the left mower spindle pulley (Fig. 403).



Fig 403

DSC-3138

8. Remove three bolts retaining the pulley to the pulley hub (Fig. 404).



Fig 404

DSC-2662

9. Raise the mower deck to the transport position.
10. Remove the mower blade from the spindle assembly.
11. Remove the 6 bolts and nuts from the spindle assembly. Remove the spindle assembly (Fig. 405).



Fig 405

DSC-2666

Mower Spindle Installation

Reverse the order of mower spindle removal.

MOWER DECKS/PTO

Mower Spindle Disassembly

1. Remove the nut and washer (Fig. 406).



Fig 406

DSC-2669

2. Remove the pulley hub and square key (Fig. 407).



Fig 407

DSC-2670

3. Remove the bearing shield (Fig. 408).



Fig 408

DSC-2671

4. Remove the spindle housing from the spindle shaft assembly (Fig. 409).



Fig 409

DSC-2672

MOWER DECKS/PTO

5. Remove the seal spacer from the top of the spindle housing (Fig. 410).



Fig 410

DSC-2673

7. Remove the top oil seal from the spindle housing (Fig. 412).



Fig 412

DSC-2675

6. Remove the seal spacer from the bottom of the spindle housing (Fig. 411).



Fig 411

DSC-2674

8. Remove the tapered roller bearing from the top of the spindle housing (Fig. 413).



Fig 413

DSC-2676

7

MOWER DECKS/PTO

9. Remove the spindle spacer (Fig. 414).



Fig 414

DSC-2677

10. Remove the split ring (Fig. 415).



Fig 415

DSC-2678

11. Turn the spindle housing over and remove the oil seal from the bottom of the spindle housing (Fig. 416). Note the orientation of the lower oil seal. The open end of the seal faces outwards to help relieve pressure from over-greasing the spindle assembly.




Fig 416

DSC-2679

12. Remove the tapered roller bearing from the bottom of the spindle assembly (Fig. 417).



Fig 417

DSC-2680

MOWER DECKS/PTO

13. Using a hammer and a driver with a square edge, drive both the top and bottom bearing races out of the spindle housing (Fig. 418).



Fig 418

DSC-2681

14. Remove the large spacer in the spindle housing (Fig. 419).



Fig 419

DSC-2682

15. This view shows the 2 bearing races and the large spacer in the spindle housing (Fig. 420). Note the internal snap ring in the housing, it is not necessary to remove when installing new bearing races and the spacer.




Fig 420

DSC-2684

A. Bearing race

B. Spacer

Mower Spindle Assembly

1. Install the spacer through the top of the spindle housing (Fig. 421).



Fig 421

DSC-2688

MOWER DECKS/PTO

2. Using a press, install the upper bearing race into the spindle housing (Fig. 422).

Note: The wider inside diameter of the bearing race should be facing up to accept the tapered bearing.



Fig 422

DSC-2689

3. Turn the spindle housing over and install the lower bearing race with a press (Fig. 423).

Note: The wider inside diameter of the bearing race should be facing up to accept the tapered bearing.



Fig 423

DSC-2690

4. Pack the tapered bearing with #2 grease and install the tapered bearing (Fig. 424).



Fig 424

DSC-2691

5. Install the lower seal (Fig. 425).

Note: The open lip of the seal should be facing outward.



Fig 425

DSC-2692

MOWER DECKS/PTO

- Using a seal driver, drive or press the seal on the lower end of the spindle housing until the seal is flush with the outer edge of the housing (Fig. 426).



Fig 426

DSC-2693

- Install the inner spacer to the spindle assembly (Fig. 428).



Fig 428

DSC-2700

- Turn the spindle assembly over and install the split ring spacer (Fig. 427).



Fig 427

DSC-2699

- Pack the tapered bearing with #2 grease and install the tapered bearing (Fig. 429).



Fig 429

DSC-2694

7

MOWER DECKS/PTO

10. Install the seal. Press it flush with the top of the housing (Fig. 430).

Note: The open lip of the seal faces inward.



Fig 430

DSC-2696

12. Lower the spindle housing over the spindle shaft (Fig. 432).



Fig 432

DSC-2703

11. Install the bearing shield and the seal spacer onto the spindle shaft (Fig. 431).



Fig 431

DSC-2702

13. Install the seal spacer on the top of the spindle housing (Fig. 433).



Fig 433

DSC-2704

MOWER DECKS/PTO

14. Install the bearing shield (Fig. 434).



Fig 434

DSC-2705

16. Install the pulley hub on the spindle shaft (Fig. 436).




Fig 436

DSC-2707

15. Install the square key onto the spindle shaft (Fig. 435).



Fig 435

DSC-2706

17. Install the heavy washer and nut on the top of the spindle shaft (Fig. 437).

Note: The cup side of the washer should be facing down toward the pulley hub.



Fig 437

DSC-2708

7

MOWER DECKS/PTO

18. Torque the top nut to 100 to 120 ft. lbs. (Fig. 438).



Fig 438

DSC-2709

3. Remove the belt covers (Fig. 439).




Fig 439

fig. 71 m-6824

1. Belt cover

2. Latch

Replacing the Mower Belt

Squealing when the belt is rotating, blades slipping when cutting grass, frayed belt edges, burn marks and cracks are signs of a worn mower belt. Replace the mower belt if any of these conditions are evident.

1. Disengage the PTO, move the motion control levers to the neutral locked position and set the parking brake.
2. Stop the engine, remove the key, and wait for all moving parts to stop before leaving the operating position.

4. Loosen the nut securing the idler plate and move the idler plate to relieve the belt tension on the idler pulley, then remove the worn mower belt (Fig. 440).




Fig 440

fig. 73 m-6826

1. Mower idler plate
2. Square hole

3. Ratchet or breaker bar
4. Idler plate bolt

5. Install the new mower belt around the mower spindle pulleys, mower idler pulley, into the belt guides, into rear idler arm assembly, and the clutch (Fig. 441).




Fig 441

fig. 70 m-6825

- | | |
|------------------------|-------------------------|
| 1. Clutch | 4. Belt guide |
| 2. Mower belt | 5. Mower spindle pulley |
| 3. 1/4 turn belt twist | 6. Mower idler pulley |

Important: Check the amount of twist in the belt between the pulleys. Make sure it is only what is specified in Figure 441.

6. Adjust the belt tension, refer to Adjusting the Mower Belt Tension, page 7-25.
7. Install the belt covers and close the latches (Fig. 439).

Adjusting the Mower Belt Tension

1. Disengage the PTO, move the motion control levers to the neutral locked position and set the parking brake.
2. Stop the engine, remove the key, and wait for all moving parts to stop before leaving the operating position.
3. Raise the mower to the transport position.

Important: Check the amount of twist in the belt between the pulleys. Make sure it is only what is specified (Fig. 441).

Important: Check and make sure the belt is installed into both the front and rear belt guides (Fig. 442).




Fig 442

fig. 72 m-4417

- | | |
|-------------------|------------------------|
| 1. Center bolt | 3. Left support plate |
| 2. Alignment hole | 4. Spring loaded idler |

MOWER DECKS/PTO

4. Check the belt tension. The spring loaded idler center bolt needs to be near the top alignment hole in left support plate (light contact with the rubber stop) (Fig. 443).




Fig 443

fig. 72 m-4417

- | | |
|-------------------|------------------------|
| 1. Center bolt | 3. Left support plate |
| 2. Alignment hole | 4. Spring loaded idler |

9. Check the distance from the rubber stop and the arm of the spring loaded idler pulley when the idler plate is tightened. Light contact should be made between the idler arm and the rubber stop (Fig. 444).




Fig 444

fig. 74 m-6825

- | | |
|--------------------------------|---------------------|
| 1. Spring loaded idler pulley | 4. Idler pulley arm |
| 2. Top alignment hole | 5. Belt |
| 3. 0 to 1/4 in. gap (0 to 6mm) | 6. Rubber bumper |

5. If adjustment is required, loosen the mower idler plate and adjust it (Fig. 440).
6. Insert a ratchet or breaker bar into the square hole in the mower idler plate to adjust the tension (Fig. 440).
7. To increase belt tension, rotate the mower idler plate until resistance is felt and rotation stops. Do not go past when it stops (Fig. 440).
8. Tighten the idler plate bolts (Fig. 440).

10. Adjust the belt tension and the idler plate, if necessary, and tighten all hardware securely (Fig. 445).




Fig 445

fig. 73 m-6826

- | | |
|----------------------|---------------------------|
| 1. Mower idler plate | 3. Ratchet or breaker bar |
| 2. Square hole | 4. Idler plate bolt |

11. If the mower idler plate contacts the end of the adjustment slot and more belt tension is required, a small change to the right side fixed idler can create more belt tension adjustment (Fig. 446).




Fig 446

fig. 75 m-3746

- | | |
|----------------|--------------------|
| 1. Fixed idler | 2. Adjustment slot |
|----------------|--------------------|

Leveling the Mower

Setting up the Machine

1. Position mower on a flat surface.
2. Disengage the PTO, move the motion control levers to the neutral locked position and set the parking brake.
3. Stop the engine, remove the key, and wait for all moving parts to stop before leaving the operating position.
4. Check the tire pressure of all four tires. If needed, adjust to 13 psi (90 kPa).
5. Lower the mower to the 3 inch (76mm) height-of-cut position.
6. Inspect the four chains. The chains need to have tension.
 - If one rear chain is loose, lower (loosen the front support arm on the same side. Refer to Adjusting the Front-to-Rear Mower Pitch on page 7-29.
 - If one front chain is loose, raise (tighten) the front support arm for that chain. Refer to Front-to-Rear Mower Pitch on page 7-29.

MOWER DECKS/PTO

Leveling the Mower Side-to-Side

1. Position the right blade side-to-side (Fig. 447).




Fig 447

fig. 65 m-1078

2. Measure the right blade at the B location (Fig. 447), from a level surface to the cutting edge of the blade tips (Fig. 448).




Fig 448

fig. 66 m-2539

3. Record this measurement. This measurement needs to be 3-1/8 to 3-1/4 inches (7.9 to 8.3cm).
4. Position the left blade side-to-side refer to Fig. 447.
5. Measure the left blade at the C location (Fig. 447) from level surface to cutting edge of the blade tips (Fig. 448).
6. Record this measurement. The measurement needs to be 3-1/8 to 3-1/4 inches (7.9 to 8.3cm).
7. If the measurement at positions B or C are not correct, loosen the bolt attaching the rear chain support arm (Fig. 449).




Fig 449

fig. 67 m-6830

- | | |
|---------------------|----------------------|
| 1. Rear chain | 5. Adjustment bolt |
| 2. Rear support arm | 6. Front swivel |
| 3. Bolt | 7. Front support arm |
| 4. Jam nut | |

8. Loosen the jam nut under the rear support arm and adjust the adjustment bolt to get a measurement of 3-1/8 to 3-1/4 inches (7.9 to 8.3cm).

Note: It is recommended that both sides of the mower are adjusted the same distance.

9. Tighten the jam nut under the rear support arm and tighten the bolt securing the chain to the rear support arm.

Adjusting the Front-to-Rear Mower Pitch

1. Position the right blade front-to-rear (Fig. 450).




Fig 450

fig. 68 m-1078

2. Measure the right blade at the A location (Fig. 450) from a level surface to the cutting edge of the blade tip (Fig. 451).




Fig 451

fig. 69 m-2539

3. Record the measurement.
4. Measure the right blade at the B location (Fig. 450), from a level surface to the cutting edge of the blade tip (Fig. 451).
5. Record this measurement.
6. The mower blade should be a 1/4 to 3/8 inch (6 to 10mm) lower at position A than at position B (Fig. 450). If it is not correct, proceed to the following steps.

Note: Both of the front swivels need to be adjusted the same amount to maintain equal chain tension.

7. Loosen the front swivel jam nuts, at the front of the right and left swivels, approximately a 1/2 inch (13mm) (Fig. 452).




Fig 452

fig. 70 m-6831 rev

- | | |
|-------------------|----------------------|
| 4. Front swivel | 6. Lift nut |
| 5. Swivel jam nut | 7. Front support arm |



Z Master 500 Series
Gasoline Engine Models
Service Manual

MOWER DECKS/PTO

8. Adjust the lift nuts on both the left and the right side of the machine to achieve 1/4 to 3/8 inch (6 to 10mm) lower in front A than in the rear at B (Fig. 453).




Fig 453

fig. 70 m-6831

- | | |
|---|----------------------|
| 1. 11-1/2" (29.2cm)
between the large
washers | 4. Front swivel |
| 2. Front nut | 5. Swivel jam nut |
| 3. Spring jam nut | 6. Lift nut |
| | 7. Front support arm |
| | 8. Large washer |
-
9. Tighten both swivel jam nuts against the front swivel to lock the height.
 10. Check to make sure there is equal tension on chains and adjust again if needed.