



NEW HOLLAND ..

MZ19H Riding Mower

Model No. 725057036 - T04ZD0001 and up.

Model No. 94802 - T04ZD0001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Description	Page	Description	Page
Front Frame Assembly	 3	Valve and Camshaft Assembly Kawasaki FH580V-AS13	 20
Height-of-Cut Handle and Plate Assembly	 4	Lubrication Equipment Assembly Kawasaki FH580V-AS13	 21
Main Frame Assembly	 5	Cooling Equipment Assembly Kawasaki FH580V-AS13	 22
Fuel Tank and Control Pod Assembly	 6	Electric Equipment Assembly Kawasaki FH580V-AS13	 23
Parking Brake Assembly	 7	Control Equipment Assembly Kawasaki Model FH580V-AS13	 24
Motion Control Assembly	 8	Carburetor Assembly Kawasaki FH580V-AS13	 25
Hydro and Belt Drive Assembly	 9	Air Filter and Muffler Assembly Kawasaki FH580V-AS13	 26
LH Hydro Transaxle Assembly No. 107-1709	 10	Fuel Tank and Fuel Valve Assembly Kawasaki FH580V-AS13	 27
RH Hydro Transaxle Assembly No. 107-1708	 12	Starter Assembly Kawasaki FH580V-AS13	 28
Engine and Clutch Assembly	 14	Label Assembly Kawasaki FH580V-AS13	 29
Electrical System Assembly	 15		
52in Deck Assembly	 16		
52in Deck Belt Drive and Lift Assembly	 17		
Cylinder and Crankcase Assembly Kawasaki FH580V-AS13	 18		
Piston and Crankshaft Assembly Kawasaki FH580V-AS13	 19		


Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

AR. as required	HYD. hydraulic
ASM. assembly	LH. left hand
BBC. blade brake clutch	NI. nylon insert
CARR. carriage	NPTF. national pipe thread fine
DEG. degrees	PFH. phillips flat head
EXT. external	PPH. phillips pan head
FH. flat head	PPHTF. phillips pan head thread forming
GA. gauge	PRH. phillips round head
HD. heavy-duty	PTH. phillips truss head
HF. hex flange	PTO. power-take-off
HH. hex head	RH. right hand
HHF. hex head flange	ROPS. roll-over protection system
HHFTF. hex head flange thread forming	SFH. slotted fillister head
HJ. hex jam	SHH. slotted hex head
HLH. hex lag head	SHWH. slotted hex washer head
HOC. height-of-cut	SPH. slotted pan head
HSBH. hex socket button head	SQH. square head
HSFH. hex socket flat head	SRH. slotted round head
HS. hex socket head	STD. standard
HWH. hex washer head	TAP. self tapping
HWHTF. hex washer head thread forming	TTH. torx truss head

Footnotes


- ❶ Not illustrated
- ❷ Not serviced separately
- ❸ Obtain parts from your local Kawasaki dealer.



Front Frame Assembly


Ref	Part No.	Qty.	Description
1	100-7357-04	1	Carrier Frame ASM
2	32128-23	2	Nut-HF
3	107-7342	2	Front Wheel And Tire ASM
3:1	105-1943	1	Tire
3:2	302-5	1	Fitting-Grease
3:3	232-27	1	Stem-Valve
3:5	114-1640	2	Bushing-Flange
①3:99	93-4244	1	Tube-Inner (W/Valve)
4	100-7363-04	2	Caster Fork ASM
5	325-22	2	Screw-HH
6	302-5	2	Fitting-Grease
7	1-303514	4	Bearing-Flanged
8	1-513338	2	Washer-Flat
9	32151-103	2	Ring-Snap
10	107-7338	1	Emblem-Logo
11	66-9300	4	Screw-HF
12	104-3639	1	Pad-Skid, Anti
13	100-7386-03	1	Floorpan
14	3230-28	6	Screw-CARR
15	104-3640	1	Pad-Skid, Anti
16	3296-39	12	Nut-Lock, NI
17	323-7	12	Screw-HH
18	98-5975	24	Washer-Belleville
19	3296-29	6	Nut-Lock, NI

Ref	Part No.	Qty.	Description
20	104-3667	2	Spanner-Wheel
21	302-19	2	Fitting-Grease
22	104-8076	2	Washer
23	61-9780	2	Cap-Hub
24	3256-23	6	Washer-Flat



Height-of-Cut Handle and Plate Assembly


Ref	Part No.	Qty.	Description				
1	3290-357	3	Nut-HHF, Whiz				
2	32151-103	1	Ring-Snap				
3	302-5	1	Fitting-Grease				
4	104-3678	1	Pin-Hitch				
5	100-7335-04	1	Lift Plate ASM				
6	1-413088	1	Bushing-Lever, Lift				
7	323-8	1	Screw-HH				
8	1-806005	1	Pin-Hair				
9	323-6	1	Screw-HH				
10	323-13	1	Screw-HH				
11	104-3641	1	Decal-Deck Height, Outer				
12	100-7384-04	1	Plate-Lift, Deck				
13	1-633082	1	Bushing-Lever, Lift				
14	104-8032	1	Decal-Deck Height, Inner				
15	3296-39	1	Nut-Lock, NI				
16	1-806003	2	Pin-Hair				
17	1-652023-03	1	Lever-Lift				
18	1-633295	1	Grip-Lever, Lift				
19	1-652027-03	1	Arm-Deck, Lift				
20	1-633325	1	Spring-Compression				
21	3256-24	1	Washer-Flat				
22	1-633068	2	Arm-Lift, Deck				
23	283-2	2	Pin-Clevis				
24	32128-21	1	Nut-HF				



Main Frame Assembly


Ref	Part No.	Qty.	Description
1	104-8040-03	1	Console
2	104-8057-03	2	Bracket-Pivot
3	107-7378	1	Decal-Danger
5	322-4	6	Screw-HH
6	104-8049	4	Screw-CARR
7	107-7381	2	Decal-Control, Motion
8	92-6986	2	Bolt-Shoulder
9	106-2240	2	Knob
10	3256-23	32	Washer-Flat
11	32128-25	6	Nut-HF
12	237-124	1	Grommet
13	5-4460	2	Washer-Pivot
14	322-5	14	Screw-HH
15	105503	2	Bushing
16	104-8058-03	1	Pan-Seat
17	107-7324	1	Seat ASM W/Arm Rests
19	100-7376-04	1	RH Bracket ASM
20	100-7368-04	1	LH Bracket ASM
21	107-2549-04	1	Frame-Rear
22	100-7332-03	1	Rod-Support, Rear
23	3296-29	22	Nut-Lock, NI
24	105-6987-03	1	Bracket
25	92-6750	2	Spacer-Nylon
27	105-1854	1	Cover-Conduit

Ref	Part No.	Qty.	Description
28	107-2473	1	Decal-Service
29	105-1853	2	Clamp-Hose
31	322-3	4	Screw-HH
32	92-7054	2	Spring-Compression
33	701178	2	Cap-Protector
34	109989	2	Spacer-Nylon



Fuel Tank and Control Pod Assembly


Ref	Part No.	Qty.	Description				
1	107-7371	1	Fuel Tank ASM				
1:2	46-6560	1	Bushing				
1:3	104048	1	Valve-Fuel				
2	107-7372	1	Tank-Console				
3	3256-23	8	Washer-Flat				
4	3253-4	4	Washer-Lock				
5	322-3	4	Screw-HH				
7	2412-98	2	Clamp				
9	104-8060	1	Hose-Fuel				
10	88-3980	1	Gas Cap ASM				
10:3	88-4010	1	Gasket-Cap, Gas				
11	1-633023	4	Stud				
12	1-633349	4	Spring-Tank, Fuel				
13	3296-47	4	Nut-Lock, NI				
14	107-7375	1	Cable-Throttle				
15	104-3664-03	1	Panel-Control				
16	3250-14	4	Screw-PPH				
18	107-7376	1	Decal-Panel, Control				
19	105-1854	1	Cover-Conduit				
20	614249	1	Strap-Tie				



Parking Brake Assembly

Ref	Part No.	Qty.	Description
1	323-4	5	Screw-HH
2	98-5975	1	Washer-Belleville
3	3296-29	4	Nut-Lock, NI
4	100-7346-03	1	Handle-Brake, Park
5	1-633268	1	Grip-Lever, Brake
6	1-633102	2	Bearing-Flange, Side
7	1-303007	1	Washer
8	3290-357	4	Nut-HHF, Whiz
9	32151-48	1	E-Ring
10	100-7318	1	Brake Shaft ASM
11	3272-10	4	Pin-Cotter
12	104-3675	2	Bracket-Spring, Brake
13	104-8046	1	Rod-Brake, Upper
14	3256-24	4	Washer-Flat
15	104-3670-03	1	Shaft-Brake
16	88-4730	2	Clamp-Pivot, HOC
17	322-3	4	Screw-HH
18	1-806003	2	Pin-Hair
19	1-808280	2	Pin-Clevis
20	1-303105	2	Yoke-Adjustable
21	3219-2	2	Nut-Hex
22	104-3674	2	Rod-Brake, Upper
23	38-4520	2	Spring
24	3256-23	2	Washer-Flat


Ref	Part No.	Qty.	Description
25	3296-4	2	Nut-Lock



Motion Control Assembly

Ref	Part No.	Qty.	Description
1	1-403180	2	Screw-HH
2	1-653316	2	Pin-Damper
3	3256-23	10	Washer-Flat
4	32120-35	2	Ring-Retaining, EXT
5	103-2913	2	Damper-Control, Motion
6	1-633102	4	Bearing-Flange, Side
7	100-7341	1	Bracket-Motion Control, LH
8	100-7340	1	Bracket-Motion Control, RH
9	3296-4	2	Nut-Lock
11	323-9	2	Screw-HH
12	32128-20	10	Nut-HF
13	100-7311	2	Pivot ASM
14	100-7313	2	Pivot Plate ASM
15	1-603735	2	Bushing-Flanged
16	1-603807	2	Spring-Return, Neutral
17	3256-2	2	Washer-Flat
18	3220-2	2	Nut-Jam
19	1-303105	2	Yoke-Adjustable
20	1-808280	2	Pin-Clevis
21	3272-5	2	Pin-Cotter
22	3290-357	6	Nut-HHF, Whiz
23	103-0631	1	LH Lever ASM
23:1	1-633257	1	Grip-Control, Motion
24	103-0632	1	RH Lever ASM


Ref	Part No.	Qty.	Description
24:1	1-633257	1	Grip-Control, Motion
25	103-0407	2	Arm-Shaft, Control
26	323-6	4	Screw-HH
27	98-5975	4	Washer-Belleville
28	3296-39	2	Nut-Lock, NI
29	323-4	6	Screw-HH
30	322-5	8	Screw-HH
31	3219-2	4	Nut-Hex
32	1-543017	6	Balljoint-RH
33	1-633152	2	Balljoint-LH
34	1-804524	2	Nut
35	1-603737	2	Bolt-Return, Neutral
36	100-7336	2	Washer
37	933156	2	Pin-Roll
38	302-11	2	Fitting-Lube, 45 DEG
39	104-3606	1	Linkage-Lower, RH
40	104-3607	1	Linkage-Lower, LH
41	104-3605	2	Linkage-Upper
42	32128-25	6	Nut-HF



Hydro and Belt Drive Assembly


Ref	Part No.	Qty.	Description
1	107-1709	1	Hydro-LH
2	107-1708	1	Hydro-RH
3	100-7317-03	1	Plate-Hydro, Lower
4	3296-29	13	Nut-Lock, NI
5	323-13	1	Screw-HH
6	3256-4	3	Washer-Flat
7	1-603044	1	Bushing
8	3256-1	2	Washer-Flat
9	32128-20	1	Nut-HF
10	55-9420	1	Bolt-Eye
11	104-3614	1	Idler Arm ASM
11:2	1-513034	2	Sleeve-Bearing
12	104-8005	1	Spacer
13	1-603414	1	Spring-Extension
14	1-603496	1	Bushing-Idler
15	1-603843	1	Pulley-Idler
16	104-3668	1	Rod-RH
17	302-40	1	Fitting-Grease
18	323-10	1	Screw-HH
19	104-3630	1	Pulley-Idler
20	104-3622	1	Belt-V
21	32128-21	3	Nut-HF
22	104-8033-03	1	Guard-Fan, LH
23	98-5975	1	Washer-Belleville

Ref	Part No.	Qty.	Description
24	104-8008	1	Decal-Transport
25	3256-23	24	Washer-Flat
26	1-806003	2	Pin-Hair
27	323-9	1	Screw-HH
28	104-3669	1	Rod-LH
29	107-7379	2	Wheel And Tire ASM
29:1	105-1945	1	Tire
29:3	232-27	1	Stem-Valve
●29:99	105-4070	1	Tube-Inner
30	242-50	8	Nut-Lug
31	104-8013-03	1	Guard-Fan, RH
32	322-13	12	Screw-HH




LH Hydro Transaxle Assembly No. 107-1709

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	107-1700	1	Main Housing Kit	35	105-1872	2	Nut
2	105-1868	1	Housing-Lower	36	104-2116	1	Stud
3	105-1869	1	Center Section Kit ASM	37	105-1873	1	Puck-Friction
4	92-6543	1	Seal-Lip	38	94-6925	1	Plate-Bypass
5	104-2104	1	Spacer	39	94-1914	1	Actuator-Bypass
6	94-1902	1	Ring-Wire, Retaining	40	92-6545	1	Seal-Lip
7	94-1903	1	Ring-Retaining	41	104-2117	1	Arm-Bypass
8	94-1904	1	Bearing-Shaft, Ball	42	936109	1	Ring-Retaining
10	94-1907	1	Swashplate-Variable	43	94-1927	2	Pin
11	94-6922	1	Bearing-Thrust	44	94-6926	3	Bolt
12	104-5067	1	Shaft-Input	46	105-1874	1	Filter
13	105-1870	1	Cover-Back	49	105-1875	1	Nut-Lock
14	94-1936	1	Spring-Block	50	104-2120	21	Screw
15	104-2106	1	Cylinder Block ASM	51	105-1876	1	Gear-Bevel, 14T
19	5-4460	1	Washer-Pivot	52	105-1877	1	Gear-Bevel, 19T
21	94-1913	1	Cylinder Block ASM	53	105-1878	1	Gear-Bevel, 53T
24	94-1937	1	Washer-Block, Thrust	54	105-1879	1	Shaft-Motor
25	94-6923	1	Bearing-Thrust	55	105-1880	1	Shaft-Brake
26	104-5311	2	Bearing-Ball	56	105-1881	1	Shaft-Axle
27	104-5307	1	Ring-Retaining	58	104-5310	2	Seal-Lip
30	94-1910	1	Guide-Slot	60	105-1882	1	Plug-Side Seal
31	104-2112	1	Trunnion ASM	62	105-1883	1	Ring-Axle, Retaining
33	92-6544	1	Seal-Lip	63	105-1884	1	Ring-Retaining
34	105-1871	1	Arm-Control	64	105-1885	1	Bearing-Ball



LH Hydro Transaxle Assembly No. 107-1709 (continued)


Ref	Part No.	Qty.	Description
65	105-1886	1	Bearing-Ball
66	105-1887	1	Seal
67	104-5309	1	Ring-Retaining
68	105-1888	2	Ring-Retaining, Axle
70	105-1889	1	LH Brake Arm ASM
73	105-1890	1	Disc-Brake
81	105-1891	1	Bushing-Axle
82	105-1892	1	Bushing-Axle
83	107-1701	1	Cap Vent ASM
99	107-1702	1	Breather Kit
❶100	104-2147	1	Sealant
107	105-1894	1	Hub ASM
108	105-1895	1	Nut
120	104-1754	1	Pulley
123	107-1703	1	Screw-HHF
126	105-1898	2	Ring-Retaining
❶134	105-1899	1	Seal Kit
136	105-1927	1	Fan
137	105-1928	1	Fan Pulley Kit
138	107-1704	1	Hose/Fitting ASM
141	107-1705	1	Washer
142	107-1706	1	Washer
143	107-1707	1	Cover-Brake, Plastic



RH Hydro Transaxle Assembly No. 107-1708


Ref	Part No.	Qty.	Description
1	107-1700	1	Main Housing Kit
2	105-1868	1	Housing-Lower
3	105-1869	1	Center Section Kit ASM
4	92-6543	1	Seal-Lip
5	104-2104	1	Spacer
6	94-1902	1	Ring-Wire, Retaining
7	94-1903	1	Ring-Retaining
8	94-1904	1	Bearing-Shaft, Ball
10	94-1907	1	Swashplate-Variable
11	94-6922	1	Bearing-Thrust
12	104-5067	1	Shaft-Input
13	105-1870	1	Cover-Back
14	94-1936	1	Spring-Block
15	104-2106	1	Cylinder Block ASM
19	5-4460	1	Washer-Pivot
21	94-1913	1	Cylinder Block ASM
24	94-1937	1	Washer-Block, Thrust
25	94-6923	1	Bearing-Thrust
26	104-5311	2	Bearing-Ball
27	104-5307	1	Ring-Retaining
30	94-1910	1	Guide-Slot
31	104-2112	1	Trunnion ASM
33	92-6544	1	Seal-Lip
34	105-1871	1	Arm-Control

Ref	Part No.	Qty.	Description
35	105-1872	2	Nut
36	104-2116	1	Stud
37	105-1873	1	Puck-Friction
38	94-6925	1	Plate-Bypass
39	94-1914	1	Actuator-Bypass
40	92-6545	1	Seal-Lip
41	104-2117	1	Arm-Bypass
42	936109	1	Ring-Retaining
43	94-1927	2	Pin
44	94-6926	3	Bolt
46	105-1874	1	Filter
49	105-1875	1	Nut-Lock
50	104-2120	21	Screw
51	105-1876	1	Gear-Bevel, 14T
52	105-1877	1	Gear-Bevel, 19T
53	105-1878	1	Gear-Bevel, 53T
54	105-1879	1	Shaft-Motor
55	105-1880	1	Shaft-Brake
56	105-1881	1	Shaft-Axle
58	104-5310	2	Seal-Lip
60	105-1882	1	Plug-Side Seal
62	105-1883	1	Ring-Axle, Retaining
63	105-1884	1	Ring-Retaining
64	105-1885	1	Bearing-Ball




RH Hydro Transaxle Assembly No. 107-1708 (continued)

Ref	Part No.	Qty.	Description
65	105-1886	1	Bearing-Ball
66	105-1887	1	Seal
67	104-5309	1	Ring-Retaining
68	105-1888	2	Ring-Retaining, Axle
70	105-1910	1	RH Brake Arm ASM
73	105-1890	1	Disc-Brake
81	105-1891	1	Bushing-Axle
82	105-1892	1	Bushing-Axle
83	107-1701	1	Cap Vent ASM
99	107-1702	1	Breather Kit
❶100	104-2147	1	Sealant
107	105-1894	1	Hub ASM
108	105-1895	1	Nut
120	105-1896	1	Pulley
123	107-1703	1	Screw-HHF
126	105-1898	2	Ring-Retaining
❶134	105-1899	1	Seal Kit
136	105-1927	1	Fan
137	105-1928	1	Fan Pulley Kit
138	107-1704	1	Hose/Fitting ASM
141	107-1705	1	Washer
142	107-1706	1	Washer
143	107-1707	1	Cover-Brake, Plastic



Engine and Clutch Assembly


Ref	Part No.	Qty.	Description				
1	3212-12	1	Screw-HH				
2	112843	1	Washer				
3	104-3624	1	Clutch				
4	100-7314	1	Pump Drive Pulley ASM				
5	5-7280	1	Key				
6	322-7	4	Screw-HH				
8	62-7190	4	Spacer-Steel				
11		1	Engine-Kawasaki, FH580V-As13				
11:1	100-6467	1	Muffler				
11:2	100-6468	1	Clamp-Muffler				
17	323-4	2	Screw-HH				
19	104-3613-03	1	Stop-Clutch				
20	98-5023	1	Bumper				
21	32128-21	2	Nut-HF				
22	32128-25	4	Nut-HF				
29	106-7022	1	Tube-Drain, Oil				



Electrical System Assembly


Ref	Part No.	Qty.	Description
1	104-2491	1	Battery-Dry
2	88-9830	1	Key Switch ASM
2:1	3254-5	1	Washer-Tooth
2:2	218-461	1	Nut-HH
3	700918	1	Key
4	93-9999	1	Switch-PTO
5	86-4690	1	Switch-Interlock
6	65-7410	2	Switch-Pole, Single
7	105-6959	1	Switch-Seat
8	106-8245	1	Solenoid
9	56-7670	1	Wire ASM
10	106-8269	1	Cable-Battery, Red
11	93-0324	1	Cable
12	1-633181	3	Plate-Tapped
13	32144-8	6	Screw-PPHTF
14	32149-2	2	Nut-Keps
15	3256-22	2	Washer-Flat
16	32144-1	3	Screw-Taptite
17	321-4	2	Screw-HH
18	32128-33	3	Nut-HF
19	98-7249	1	Relay
20	46-8560	2	Screw-HHF
21	105-6968	2	Screw-Seat, Switch
22	107-2504	1	Harness-Wire

Ref	Part No.	Qty.	Description
23	28-8080	1	Boot-Terminal
24	93-3190	1	Boot-Insulator, Terminal
25	104-2466	1	Holddown-Battery
26	99-7420	1	Plug-Hole
27	93-3190	1	Boot-Insulator, Terminal



52in Deck Assembly


Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	107-7380	1	Deck - 52"	20	68-2730	4	Wheel-Gage
1:2	99-3943	1	Decal-Routing, Belt	22	323-16	1	Screw-HH
1:3	98-3798	1	Decal-Wheel, Gage	24	32144-41	18	Screw-Taptite
1:4	92-7108	1	Decal-Danger	25	3230-18	5	Screw-CARR
1:5	92-7109	1	Decal-Caution	26	99-8079	1	Deflector / Decal ASM
2	107-1739	3	Spindle ASM	26:2	92-7108	1	Decal-Danger
2:1	107-1739	1	Housing-Spindle	26:3	93-1122	1	Decal-Danger
2:2	100-1048	2	Bearing-Ball	27	3211-15	2	Screw-HH
2:3	62-3661	1	Spacer-Bearing	28	3296-5	2	Nut-Lock
2:4	80-4380	1	Spacer	29	67-2150-03	1	Baffle
6	80-4341	3	Shaft	30	1-373034	4	Washer
7	80-4360	3	Shield-Bearing	31	46-8560	5	Screw-HHF
8	107-1741-03	3	Blade	32	3230-18	4	Screw-CARR
9	107-1743-03	3	Ring-Support, Deck	33	3296-29	14	Nut-Lock, NI
10	107-1740	3	Pulley And Hub ASM	34	29-4820	1	Roller
11	80-0510-03	3	Stiffener-Blade	35	3290-357	8	Nut-HHF, Whiz
12	3290-465	3	Washer-Belleville	36	98-5975	4	Washer-Belleville
13	26-0671	3	Screw-Blade	37	106-2217	1	Belt-V
14	3219-6	3	Nut-Hex	38	94-2500	1	Tube-Spacer, Wheel
15	104-3685-03	1	Cover - Belt, LH	39	3296-39	1	Nut-Lock, NI
16	104-3684-03	1	Cover - Belt, RH	40	322-2	5	Screw-HH
17	29-5590-03	2	Bracket-Pivot				
18	40-6230	2	Spring				
19	99-2842	4	Spacer				



52in Deck Belt Drive and Lift Assembly

Ref	Part No.	Qty.	Description
1	1-613098	2	Pulley-Idler
2	3256-24	3	Washer-Flat
3	98-5975	3	Washer-Belleville
4	323-6	3	Screw-HH
5	3296-39	2	Nut-Lock, NI
6	3217-7	1	Nut-Hex
7	94-2547	1	Bolt-Eye
8	105-6992	1	Spring-Extension
9	1-809107	2	Washer-Hardened
10	1-603384	1	Bushing-Pivot, Idler
11	105-7010	1	Idler Arm ASM
11:2	1-513034	2	Sleeve-Bearing
12	99-8912	1	Pulley-Idler, Flat
13	1-806005	8	Pin-Hair
14	100-7338	4	Clevis
15	104-3634	4	Pin-Clevis
16	3220-5	4	Nut-Jam
17	104-8047	4	Rod-Trunion
18	1-800805	1	Screw-HH
19	104-8037-03	1	Plate-Bolt, Retainer
20	104-3699-04	2	Link-HOC, Adjusting
21	3256-26	12	Washer-Flat
22	3296-16	2	Nut-Lock, NI
23	46-6290	1	O-Ring


Ref	Part No.	Qty.	Description
24	3256-1	2	Washer-Flat
25	95-2747	1	Fitting-Washout
26	3229-1	2	Screw-CARR
27	95-3270	1	Connector-Hose
28	3272-10	4	Pin-Cotter
29	302-19	1	Fitting-Grease



Cylinder and Crankcase Assembly


Kawasaki FH580V-AS13

Ref	Part No.	Qty.	Description				
❶11004	11004-7010	2	Gasket-Head				
❶11008	11008-6042	1	Head-Cylinder				
❶11008A	11008-7009	1	Head-Cylinder				
❶11022	11022-7003	2	Case-Rocker				
❶11060	11060-7001	2	Gasket-Case, Rocker				
❶11060A	11060-7008	1	Gasket-Cover, Crankcase				
❶11061	11061-7001	1	Gasket-Breather				
❶13271	13271-7016	1	Plate				
❶14091	14091-7006	1	Cover				
❶49015	49015-6253	1	Cover-Crankcase				
❶49109	49109-7002	1	Element-Breather				
❶49120	49120-7023	1	Crankcase				
❶92033	92033-7003	2	Ring-Snap				
❶92043	92043-7001	6	Pin				
❶92049	92049-7001	4	Seal-Oil, R V C2 (6X11X10.2)				
❶92049A	92049-7005	1	Seal-Oil, S O (8X14X5 H S)				
❶92049B	92049-7010	0	Seal-Oil, Sd (35X48X8 R Hs)				
❶92049C	92049-7011	1	Seal-Oil, S D (35X62X8 L H S)				
❶92066	92066-7002	1	Plug				
❶130	130B0612	4	Bolt-Flanged (6X12)				
❶130A	130B0640	4	Bolt-Flanged (6X40)				
❶130B	130T0850	17	Bolt-Flanged (8X50)				
❶130C	130T0875	2	Bolt-Flanged (8X75)				
❶172	172G0818	4	Bolt-Stud (8X18)				




Piston and Crankshaft Assembly Kawasaki FH580V-AS13

Ref	Part No.	Qty.	Description				
③13001	13001-7010	2	Piston-Engine				
③13002	13002-7001	2	Pin-Piston				
③13008	13008-6060	2	Ring Set-Piston				
③13031	13031-7036	1	Crankshaft				
③13251	13251-7010	2	Connecting Rod ASM				
③92033	92033-7005	4	Ring-Snap				
③92151	92151-7017	4	Bolt (6X35)				




Valve and Camshaft Assembly
Kawasaki FH580V-AS13

Ref	Part No.	Qty.	Description				
❶12004	12004-7003	2	Valve-Intake				
❶12005	12005-7003	2	Valve-Exhaust				
❶12009	12009-7001	4	Retainer-Spring, Valve				
❶12011	12011-2056	8	Collet				
❶12016	12016-7001	4	Arm-Rocker				
❶12032	12032-7001	4	Tappet				
❶13070	13070-7001	2	Guide				
❶13070A	13070-7004	1	Guide				
❶13116	13116-2057	4	Rod-Push				
❶13271	13271-7007	1	Plate				
❶13271A	13271-7021	0	Plate-Governor				
❶42036	42036-7009	1	Sleeve				
❶49078	49078-7001	4	Spring-Valve, Engine				
❶49118	49118-7004	1	Camshaft				
❶92009	92009-2341	4	Screw				
❶92015	92015-2253	4	Nut				
❶92033	92033-7001	2	Ring-Snap				
❶92140	92140-7002	6	Ball				
❶92145	92145-7001	1	Spring				
❶92153	92153-7019	4	Bolt				
❶92200	92200-7001	1	Washer				



Lubrication Equipment Assembly
Kawasaki FH580V-AS13


Ref	Part No.	Qty.	Description				
③13107	13107-7009	1	Shaft				
③13271	13271-7017	1	Plate				
③14075	14075-7009	1	Cap ASM				
③16154	16154-2053	1	Rotor-Pump (In)				
③16154A	16154-2054	1	Rotor-Pump (Out)				
③49065	49065-2078	1	Filter-Oil				
③49065A	49065-7004	1	Filter-Oil				
③49116	49116-7001	1	Valve ASM				
③59051	59051-7011	1	Gear-Spur				
③59071	59071-7008	1	Joint				
③59231	59231-7005	1	Filler				
③92043	92043-7003	2	Pin				
③92055	92055-7002	1	O-Ring (6Mm)				
③92066	92066-7003	1	Plug				
③92066A	92066-7007	1	Plug				
③92140	92140-7003	1	Ball				
③92145	92145-7002	1	Spring				
③92210	92210-7012	1	Nut				
③130	130B0612	3	Bolt-Flanged (6X12)				
③670	670D2016	3	O-Ring (16Mm)				



Cooling Equipment Assembly

Kawasaki FH580V-AS13


Ref	Part No.	Qty.	Description				
❸13270	13270-7007	1	Plate				
❸14037	14037-7020-9H	1	Screen				
❸23062	23062-7010	1	Bracket				
❸49089	49089-7002	1	Shroud-Engine				
❸49089A	49089-7032	1	Shroud-Engine				
❸49089B	49089-7034	1	Shroud-Engine				
❸55020	55020-7004	1	Guard				
❸59041	59041-7010	1	Fan				
❸59066	59066-7002	1	Housing-Fan				
❸92004	92004-7006	2	Stud				
❸92026	92026-7007	1	Spacer				
❸92153	92153-7007	3	Bolt				
❸92153A	92153-7008	1	Bolt				
❸92210	92210-0003	4	Nut				
❸130	130B0612	5	Bolt-Flanged (6X12)				
❸130A	130B0616	2	Bolt-Flanged (6X16)				
❸130B	130B0625	2	Bolt-Flanged (6X25)				
❸130C	130B0816	1	Bolt-Flanged (8X16)				
❸311	311B0600	2	Nut-Hex (6Mm)				



Electric Equipment Assembly

Kawasaki FH580V-AS13


Ref	Part No.	Qty.	Description				
③21171	21171-7013	2	Ignition Coil ASM				
③21066	21066-7011	1	Regulator-Voltage				
③21193	21193-7007	1	Flywheel ASM				
③26030	26030-7001	1	Harness				
③26031	26031-7002	1	Harness				
③59031	59031-7001	1	Coil-Charging				
③92004	92004-7009	2	Stud				
③92009	92009-2308	1	Screw				
③92066	92066-7002	1	Plug				
③92070	92070-7003	2	Plug-Spark (R C J 8 Y, Solid)				
③92072	92072-7003	2	Band				
③92151	92151-2097	1	Bolt (12X30)				
③92200	92200-7002	1	Washer				
③130	130B0620	2	Bolt-Flanged (6X20)				
③224	224B0520	4	Screw-Pan (5X20)				
③311	311B0600	2	Nut-Hex (6Mm)				
③510	510A5100	1	Key-Woodruff				



Carburetor Assembly



Kawasaki FH580V-AS13

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
11061	11061-7004	2	Gasket-Insulator	92093	92093-2100	1	Seal
11061A	11061-7009	1	Gasket-Chamber	92093A	92093-7003	1	Seal
11061B	11061-7010	0	Gasket-Screw	92145	92145-7015	1	Spring
11061C	11061-7018	1	Gasket-Cleaner, Air	130	130B0635	4	Bolt-Flanged (6X35)
11061D	11061-7019	0	Gasket	172	172G0685	2	Bolt-Stud
13107	13107-7018	1	Shaft	214	214B0510	1	Screw-Pan (5X10)
15003	15003-7081	1	Carburetor ASM				
16014	16014-7004	1	Screw-Air, Pilot				
16020	16020-7003	1	Chamber-Float				
16025	16025-7006	1	Valve-Throttle				
16030	16030-7003	1	Valve-Float				
16031	16031-7002	1	Float				
16041	16041-7016	1	Shaft-Choke, Carburetor				
16041A	16041-7018	1	Shaft-Throttle, Carburetor				
16073	16073-7007	1	Insulator				
16186	16186-7004	1	Choke Valve ASM				
21188	21188-7002	1	Solenoid				
39076	39076-7001	1	Limiter				
49121	49121-7004	1	Nozzle-Main				
59076	59076-7001	1	Manifold-Intake				
92009	92009-2083	2	Screw				
92009A	92009-2349	1	Screw				
92063	92063-7037	1	Jet-Main (No. 105)				
92081	92081-2234	1	Spring				



Air Filter and Muffler Assembly Kawasaki FH580V-AS13

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
③11010	11010-7013	1	Air Filter ASM	③317	317R0800	4	Nut-Hex, Small (8Mm)
③11013	11013-7001	1	Element-Filter, Air	③461	461F0800	4	Washer-Spring (8Mm)
③11013A	11013-7002	1	Element-Filter, Air				
③11038	11038-7006	1	Air Filter Case ASM				
③11038A	11038-7011	1	Air Filter Case ASM				
③11050	11050-7006	1	Bracket				
③11051	11051-7005-9H	1	Bracket				
③11060	11060-7021	2	Gasket-Muffler				
③13270	13270-7008	1	Plate				
③18049	18049-7001	1	Pipe-Exhaust				
③27012	27012-7001	2	Hook-Filter, Air				
③49070	49070-7015	1	Muffler				
③59071	59071-7014	2	Joint				
③92015	92015-1193	2	Nut				
③92072	92072-7008	1	Band				
③92170	92170-7002	1	Clamp				
③92191	92191-7001	1	Tube				
③92210	92210-7004	1	Nut				
③130	130B0612	2	Bolt-Flanged (6X12)				
③130A	130B0816	2	Bolt-Flanged (8X16)				
③232	232B0514	2	Screw-Pan				
③233	233B0416	1	Screw (4X16)				
③311	311B0400	1	Nut-Hex (4Mm)				



Label Assembly

Kawasaki FH580V-AS13

Ref	Part No.	Qty.	Description
③56033	56033-7002	1	Label-Manual
③56070	56070-7001	1	Label-Warning
③56080	56080-7020	1	Label-Brand

NOTES

NOTES



NEW HOLLAND ..