


**TORO**<sup>®</sup>

MODEL NO. 22040-390001 &amp; UP

**PARTS  
CATALOG****PROLINE 21"  
RECYCLER<sup>®</sup> Mower**


C-0660

**HOUSING ASSEMBLY**

Ref. No.	Part No.	Description	No. Used
1	61-8300	Pivot Arm Assembly	2
2	49-8770	Quadrant - Front R.H.	1
3	49-2040	Screw - Thread Forming	8
4	14-9499	Housing - Commercial (Incl. Ref. #7, 53, & 55)	1
5	32144-111	Screw - Pan Hd.	6
6	92-1730	Kicker	1
7	39-5770	Decal - Danger	1
8	46-6810	Screw - Thread Forming	1
9	82-9150	Chute - Discharge	1
10	3256-22	Washer - Flat	2
11	71-9350	Bracket - Spring	1
12	46-6811	Screw - Thread Forming	1
13	76-4660	Spring	1
14	80-3770	Retainer - Door	1
15	77-0200	Door Assembly	1
16	76-4570	Plate - Latch	1
17	46-8090	Screw - Self Tapping	2

Ref. No.	Part No.	Description	No. Used
18	321-7	Screw - Hex Hd. Cap	2
19	3296-42	Nut - Lock	10
20	77-0500	Plug - Discharge (Incl. Ref. #21, 22, & 25)	1
21	76-4640	Latch - Plug	1
22	76-4650	Grip - Latch	1
23	92-1750	Kicker	1
24	3290-378	Tie - Cable	1
25	3295-35	Rivet	1
26	37-7260	Screw - Special	2
27	74-1770	Cover - Belt	1
28	52-2620	Label - Grease	1
29	46-7030	Retainer - Cable	1
30	74-1970	Decal - Traction Drive	1
31	74-1741	Bracket - Traction Adj.	1
32	32144-70	Screw - Thread Forming	1
33	49-8740	Quadrant - Rear L.H.	1
*	49-8750	Quadrant - Rear R.H.	1

\*Not Illustrated




C-0660

## HOUSING ASSEMBLY (Continued)

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
34	33-3208	Rod - Shield	1	48	257-3	Washer - Pivot	2
35	44-0580	Shield - Rear Safety	1	49	32152-2	Nut - Lock	2
37	25-7740	Knob - Arm	2	50	40-1940	Washer - Hardened	4
38	66-7560	Spring Arm Ass'y - Front	2	51	3296-6	Nut - Lock	2
39	27-6232	Screw - Pivot	2	52	49-8760	Quadrant - Front L.H.	1
40	53-7740	Tire	2	53	92-1796	Decal - Recycler	1
41	52-2410	Hub - Support Bearing	2	54	92-1720	Kicker	1
42	52-2440	Spacer - Bearing	2	55	71-1280	Decal - Safety Instructions	1
43	52-2450	Bearing - Wheel	4	56	71-9370	Decal - Danger Covers	1
44	53-7780	Plate - Wheel Half	4	*	53-7720	Wheel & Tire Assembly (Incl. Ref. #19, 40-44, & 47)	2
45	323-13	Screw - Hex Hd. Cap	2				
46	52-2480	Spacer - Wheel	2				
47	321-2	Screw - Hex Hd. Cap	8				

\*Not Illustrated




C-0661

## ENGINE ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	71-1260	Decal - Pro Line	1	15	46-7910	Pulley - Driver	1
2	61-8062	Engine - Complete	1	16	27-6300	Key - Square	1
3	77-0040	Decal - Recoil	1	17	52-2190	Spacer - Retainer, Blade	1
4	81-0090	Gasket	1	18	3254-6	Washer - Internal Tooth	3
5	44-3172	Hose - Primer	1	19	32144-70	Screw - Thread Forming	3
6	63-9330	Body - Air Cleaner	1	20	91-2256	Blade	1
7	3256-16	Washer	1	21	92-1599	Stiffener - Blade	1
8	51-2690	Screw - Hex. Flange Hd.	1	22	26-0670	Screw - Blade	1
9	62-3980	Sleeve	2	23	3253-22	Washer - Lock	1
10	50-7180	Nut - Lock	2	24	52-2170	Retainer - Blade	1
11	63-9380	Filter - Foam	1	25	65-5860	Protector - Crankshaft	1
12	63-9340	Cover - Air Cleaner	1	26	66-9300	Screw - Hex. Flange Hd.	4
13	44-2750	Body - Primer	1	*27		Staple	1
14	66-7460	Bulb - Primer	1				

\*Obtain Locally




C-0531

## BRAKE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	46-0790	Screw - Self Tapping	1
2	84-7820	Plate - Mounting	1
3	3290-459	Rivet	2
4	77-5260	Strap - Insulation	1
5	66-5380	Brake Plate Assembly	1
6	56-6190	Screw - Shoulder, Metric	1
7	60-9010	Strap - Ground	1

Ref. No.	Part No.	Description	No. Used
8	85-6903	Cable - Brake	1
9	66-5370	Spring - Compression	1
10	53-4690	Stop - Ground Strap	1
11	32144-112	Screw - Self Tapping	1
*	14-6009	Mounting Plate Assembly (Incl. Ref. #2-4 & 7)	1


\*Not Illustrated



T-0678

## GEAR CASE ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	52-2450	Bearing	2	22	74-1960	Lever - Shift	1
2	74-1851	Pivot Arm Assembly (Incl. Ref. #1, 3, 6 & 21)	2	23	60-8870	Yoke - Shift	1
3	48-2060	Bearing - Needle	4	24	29-9690	Washer - Flat	1
4	25-7740	Knob - Arm	2	25	46-3560	Gear - 52T	1
5	66-7561	Spring Arm Assy. - Rear	2	26	36-4770	Spacer - Gear	3
6	302-26	Fitting - Grease	2	27	29-9271	Gear - 42T	1
7	48-2170	Cap - End	2	28	42-4740	Gear - 38T	1
8	74-1890	Shaft - Output	1	29	55-8020	Retainer - Key	1
9	13-5149	Shaft - Input (Incl Ref. #13)	1	30	29-9330	Key - Shift	2
10	13-9739	Upper Case Assembly (Incl. Ref. #11 & 73)	1	31	39-6720	Sleeve	1
11	47-7270	Bearing - Needle	2	32	29-9340	Collar - Shift	1
12	36-4792	Washer - Thrust	4	33	36-4780	Washer - Flat	3
13	302-63	Fitting - Grease	1	34	55-8010	Sleeve - Gear	1
14	36-8070	V-Belt	1	35	3285-19	Pin - Groove	1
15	39-6740	Pulley	1	37	49-2040	Screw - Self Tapping	8
16	3296-5	Nut - Lock	1	39	29-9570	Bushing - Yoke	1
17	74-1750	Bracket - Traction, Engage	1	40	74-1920	Case - Lower	1
18	49-8461	Bracket - Guide, Belt	1	42	39-9680	Key	2
19	32121-99	Pin - Roll	1	43	39-9650	Spring	2
21	47-6730	Seal	4	44	49-7700	Washer - Thrust, Keyed	2
				45	62-3830	Washer - Thrust, Keyed	2
				46	39-9160	Pinion	2
				47	32151-68	Ring - Klip	4




T-0678

## GEAR CASE ASSEMBLY(Continued)

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
48	321-2	Screw - Cap, Hex. Hd.	8	65	46-3550	Gear - 14T	1
49	53-7750	Wheel - Half	2	66	46-3540	Gear - 12T	1
51	53-7740	Tire	2	67	53-7950	Shaft - Intermediate	1
52	52-2410	Hub - Support, Bearing	2	68	39-7842	Key - Square	1
53	53-7780	Plate - Wheel Half	2	69	252-103	Bearing - Closed	2
54	3296-42	Nut - Lock	8	70	32151-57	Ring - Retaining	1
55	52-2440	Spacer - Bearing	2	71	39-6660	Pinion - Bevel	1
56	52-2450	Bearing - Wheel	4	72	47-2910	Washer - Thrust	1
57	323-13	Screw - Cap, Hex. Hd.	2	73	47-7260	Seal	1
58	74-1650	Spacer - Wheel	2	74	3257-1	Key - Woodruff	2
59	74-1640	Cover - Wheel	2	75	3256-45	Washer - Flat	1
60	32152-2	Nut - Lock	2	*	74-1861	Gear Case Assembly (Incl. Ref. #3, 8-13, 15-18, 21, 23-40 & 63-74)	1
61	74-1810	Washer	2	*	74-1720	Wheel & Tire Assembly (Incl. Ref. #48-49 & 51-56)	2
62	32151-36	Ring - Retaining	2				
63	74-1760	Gear - Bevel	1				
64	39-6650	Gear - 18T	1				

\*Not Illustrated




C-0662

## HANDLE ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	92-1586	Handle	1	20	256-276	Spacer	2
2	48-2810	Rod - Bag Support	1	21	82-9950	Bracket - Control Throttle	1
3	321-15	Screw - Hex Hd. Cap	1	22	3-7501	Washer - Curved	4
4	321-13	Screw - Hex Hd. Cap	2	23	32111-7	Nut - Acorn	2
5	322-10	Screw - Hex Hd. Cap	2	24	3290-378	Tie - Cable	3
6	49-1630	Support - Spacer	2	25	3296-29	Nut - Lock	4
7	85-6903	Cable - Brake	1	26	3290-456	Washer - Flat	4
8	46-6980	Support - Cable	1	27	322-7	Screw - Hex Hd. Cap	2
9	3256-22	Washer - Flat	1	28	322-6	Screw - Hex Hd. Cap	2
10	3296-42	Nut - Lock	4	29	3-3287	Spacer	2
11	46-8081	Guide - Rope	1	30	84-8361	Latch - Handle - L.H.	1
12	77-5270	Lever - Control	1	*	84-8401	Latch - Handle - R.H.	1
13	3296-58	Nut - Lock	2	31	70-1061	Cable - Throttle	1
14	66-5350	Lever - Control	1	32	3296-47	Nut - Lock	2
15	32151-86	E-Ring	2	33	74-1791	Cable - Traction	1
17	82-2380	Decal - Traction Control	1	34	321-9	Screw - Hex Hd. Cap	1
18	61-8270	Bar - Control	1	35	27-7210	Screw - Shoulder	2
19	321-4	Screw - Hex Hd. Cap	2				

\*Not Illustrated




C-1019

## GAS TANK ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	74-2110	Bracket - Tank	1
2	77-2840	Retainer - Tank, Fuel	1
3	55-3575	Cap - Gas	1
4	82-8460	Tank - Gas	1
5	2412-95	Clamp - Fuel Line	4
6	51-3214	Hose - Fuel	1
7	3296-42	Nut - Lock	1

Ref. No.	Part No.	Description	No. Used
8	77-0520	Support - Bracket	1
9	62-7600	Decal - Fuel	1
10	51-3211	Hose - Fuel	1
11	71-9280	Filter - Fuel	1
12	84-9160	Mount - Tank, Bottom	1
13	46-8091	Screw - Hex. Washer Hd.	2
14	323-6	Screw - Cap, Hex. Hd.	2




T-1100

### GRASS BAG ASSEMBLY No. 11-5609

Ref. No.	Part No.	Description	No. Used
1	48-2840	Door - Bag, Grass	1
2	3290-422	Nut - Push, Washer Cap	2
3	33-4820	Hinge - Door, Bag	1
4	36-6910	Spring	2

Ref. No.	Part No.	Description	No. Used
5	42-4030	Frame - Bag, Upper	1
6	8-2759	Bag - Grass	1
7	42-4020	Frame - Bag	1




T-0663

## CRANKSHAFT ASSEMBLY (Model No. 47PN2-3)

Ref. No.	Part No.	Description	No. Used
1	81-2800	Crankcase/Cylinder Assy.	1
2	81-0590	Piston Ring Set	1
3	81-0620	Circlip	2
4	81-0600	Pin - Wrist	1
5	81-2140	Piston - 58mm	1
6	81-0720	Seal - Oil, Upper	1
7	81-0710	Washer - Thrust, Upper	1
8	81-0690	Bearing - Upper 20mm	1
9	81-4680	Crankshaft/Connecting Rod Assembly	1
10	81-0770	Spacer - Governor	1

Ref. No.	Part No.	Description	No. Used
11	81-0750	Bracket - Arm, Governor	1
12	81-0700	Bearing - Lower 25mm	1
13	81-0730	Washer - Thrust, Lower	1
14	81-0740	Seal - Oil, Lower	1
15	81-0540	Bolt 30mm Lg.	5
16	81-0760	Pin - Crankshaft	1
17	81-0610	Bearing - Wrist Pin	1
18	81-0570	Bolt	4
19	81-0560	Plate - Mounting	1
20	81-0520	Pin - Crankcase	2
*	12-8099	Short Block	1

\*Not Illustrated




T-0667

## MUFFLER ASSEMBLY (Model No. 47PN2-3)

Ref. No.	Part No.	Description	No. Used
1	81-1080	Gasket - Muffler	1
2	81-0200	Spark Arrester (Optional)	1
†3		Clamp	1
4	81-5690	Muffler	1
5	81-2450	Cover - Muffler	1

Ref. No.	Part No.	Description	No. Used
6	81-1100	Bolt	2
7	81-1120	Washer - Lock	2
8	81-1110	Nut	2
9	81-1150	Bolt - Self Tapping	1
10	81-1140	Screw - Phillips Hd.	2

†Obtain Locally




T-0664

## IGNITION ASSEMBLY (Model No. 47PN2-3)

Ref. No.	Part No.	Description	No. Used
1	81-5680	Screw - Cap, Hex Hd.	2
2	81-1330	Nut	1
3	81-2810	Flywheel - Magneto	1
4	81-2370	Key - Flywheel	1
5	81-2820	Coil/Ignition Assembly	1
6	81-1480	Clamp	1

Ref. No.	Part No.	Description	No. Used
7	81-0181	Spark Plug	1
8	81-2120	Guard - Spark Plug	1
9	81-2350	Bolt - Self Tapping (20mm Lg.)	2
10	81-1500	Cap Assembly - Spark Plug	1
*	41-7650	Puller - Flywheel	1

\*Not Illustrated




C-0564

## GOVERNOR ASSEMBLY (Model No. 47PN2-3)

Ref. No.	Part No.	Description	No. Used
1	81-0920	Spring - Carburetor Rod	1
2	81-5420	Governor Arm/Bolt Assy.	1
3	81-5410	Rod - Choke	1
4	81-2880	Shaft - Governor	1
5	81-2460	Spring - Lever, Choke	1
6	81-1770	Spacer - Lever, Governor	1
7	81-2850	Lever - Governor	1
8	81-1750	Washer - Lever, Choke	2
9	81-1450	Washer - Lock	1
10	81-0900	Nut	2
11	81-1840	Terminal - Kill Switch	1
12	81-1170	Bolt - Self Tapping	1
13	81-0540	Bolt	1

Ref. No.	Part No.	Description	No. Used
14	81-1830	Insulator - Kill Switch	1
15	81-2420	Bracket - Throttle	1
16	81-4530	Rivet - Kill Switch	2
17	81-2470	Spacer - Lever, Choke	1
18	81-2430	Clamp - Cable	1
19	50-0130	Bolt - Clamp, Cable	1
20	81-1710	Lever - Choke	1
21	81-1730	Bolt - Bracket, Throttle	1
22	81-0850	Seal - Shaft, Governor	1
23	81-0860	Washer	1
24	81-0870	Ring - Retaining	1
25	81-2830	Spring - Governor	1
26	81-0910	Rod - Carburetor	1




T-1102

## RECOIL ASSEMBLY (Model No. 47PN2-3)

Ref. No.	Part No.	Description	No. Used
1	81-2080	Cover - Fan, Cooling	1
2	81-2170	Cup - Pulley, Starter	1
3	81-1300	Bolt	3
4	81-1630	Handle - Recoil	1
5	81-1270	Rope	1
6	81-1210	Pulley - Rope	1
7		Retainer - Spring, Recoil	1
8	81-2100	Case - Starter	1
9	81-1280	Bolt	4
10		Spring - Recoil	1
11	81-1240	Spring - Compression	1

Ref. No.	Part No.	Description	No. Used
12	81-1220	Spring - Dog	1
13	81-1230	Dog - Starter	1
14	81-1250	Retainer - Dog	1
15	81-1260	Bolt - Shoulder	1
16	53-1340	Bolt - Self Tapping (15mm Lg.)	3
*	81-5940	Starter Assembly (Incl. Ref. #4-15)	1
*	81-2300	Spring & Retainer Assembly (Incl. Ref. #7 & 10)	1

\*Not Illustrated



C-0563

## CARBURETOR ASSEMBLY (Model No. 47PN2-3)

Ref. No.	Part No.	Description	No. Used
1	81-5450	Stud Bolt, Carburetor	2
2	81-0090	Gasket	1
3	81-0240	Valve - Choke	1
4	81-0230	Spring - Choke	1
5	81-0220	Bushing - Choke	1
6	81-2160	Screw - Choke Plate	2
7	81-1950	Shaft - Choke	1
8	81-0250	Shaft - Throttle	1
9	81-0260	Valve - Throttle	1
10	81-0270	Screw - Throttle	1
11	81-1030	Jet - Pilot #40	1
12	81-0780	Gasket - Carburetor	3
13	81-5490	Shield - Carburetor	1
14	81-2190	Insulator - Carburetor	1
15	81-2580	Spring - Idle Stop	1
16	50-0250	Screw - Idle Stop	1
17	81-2600	Pin - Float	1
18	81-4910	Needle Valve	1
19	81-1060	Jet - Main #75	1

Ref. No.	Part No.	Description	No. Used
*	81-2340	Jet - Main #72.5 High Alt. Above 6,000 Ft. (Optional)	A/R
20	81-0970	Float	1
21	81-1010	Gasket - Bowl, Float	1
22	81-5660	Bowl - Float	1
23	81-1020	Gasket - Capscrew, Bowl	1
24	81-5670	Capscrew - Bowl	1
25	81-2530	Seal	2
26	81-2540	Ring	1
27	81-2550	Packing	1
*	81-5430	Carburetor Ass'y w/Primer	1
*	81-2520	Carburetor Ass'y	1
*	12-6379	Carburetor Kit (Incl. Ref. #2, 12, 18, 21 & 23)	1
*	81-5810	Seat Kit (Incl. Valve Seat & Ref. #18)	1

\*Not Illustrated

# TORO PART NUMBER INDEX

Part No.	Description	Pg. No.	Ref. No.	Qty.	Part No.	Description	Pg. No.	Ref. No.	Qty.
3-3287	Spacer	7	29	2	48-2060	Bearing - Needle	5	3	4
3-7501	Washer - Curved	7	22	4	48-2170	Cap - End	5	7	2
8-2759	Bag - Grass	9	6	1	48-2810	Rod - Bag Support	7	2	1
12-6379	Carburetor Kit	15	*	1	48-2840	Door - Bag, Grass	9	1	1
12-8099	Short Block	10	*	1	49-1630	Support - Spacer	7	6	2
13-5149	Shaft - Input	5	9	1	49-2040	Screw - Self Tapping	5	37	8
13-9739	Upper Case Assembly	5	10	1	49-2040	Screw - Thread Forming	1	3	8
14-6009	Mounting Plate Assembly	4	*	1	49-7700	Washer - Thrust, Keyed	5	44	2
14-9499	Housing - Commercial	1	4	1	49-8461	Bracket - Guide, Belt	5	18	1
25-7740	Knob - Arm	5	4	2	49-8740	Quadrant - Rear L.H.	1	33	1
25-7740	Knob - Arm	2	37	2	49-8750	Quadrant - Rear R.H.	1	*	1
26-0670	Screw - Blade	3	22	1	49-8760	Quadrant - Front L.H.	2	52	1
27-6232	Screw - Pivot	2	39	2	49-8770	Quadrant - Front R.H.	1	2	1
27-6300	Key - Square	3	16	1	50-0130	Bolt - Clamp, Cable	13	19	1
27-7210	Screw - Shoulder	7	35	2	50-0250	Screw - Idle Stop	15	16	1
29-9271	Gear - 42T	5	27	1	50-7180	Nut - Lock	3	10	2
29-9330	Key - Shift	5	30	2	51-2690	Screw - Hex. Flange Hd.	3	8	1
29-9340	Collar - Shift	5	32	1	51-3211	Hose - Fuel	8	10	1
29-9570	Bushing - Yoke	5	39	1	51-3214	Hose - Fuel	8	6	1
29-9690	Washer - Flat	5	24	1	52-2170	Retainer - Blade	3	24	1
33-3208	Rod - Shield	2	34	1	52-2190	Spacer - Retainer, Blade	3	17	1
33-4820	Hinge - Door, Bag	9	3	1	52-2410	Hub - Support Bearing	2	41	2
36-4770	Spacer - Gear	5	26	3	52-2410	Hub - Support, Bearing	6	52	2
36-4780	Washer - Flat	5	33	3	52-2440	Spacer - Bearing	2	42	2
36-4792	Washer - Thrust	5	12	4	52-2440	Spacer - Bearing	6	55	2
36-6910	Spring	9	4	2	52-2450	Bearing	5	1	2
36-8070	V-Belt	5	14	1	52-2450	Bearing - Wheel	2	43	4
37-7260	Screw - Special	1	26	2	52-2450	Bearing - Wheel	6	56	4
39-5770	Decal - Danger	1	7	1	52-2480	Spacer - Wheel	2	46	2
39-6650	Gear - 18T	6	64	1	52-2620	Label - Grease	1	28	1
39-6660	Pinion - Bevel	6	71	1	53-1340	Bolt - Self Tapping	14	16	3
39-6720	Sleeve	5	31	1	53-4690	Stop - Ground Strap	4	10	1
39-6740	Pulley	5	15	1	53-7720	Wheel & Tire Assembly	2	*	2
39-7842	Key - Square	6	68	1	53-7740	Tire	2	40	2
39-9160	Pinion	5	46	2	53-7740	Tire	6	51	2
39-9650	Spring	5	43	2	53-7750	Wheel - Half	6	49	2
39-9680	Key	5	42		53-7780	Plate - Wheel Half	2	44	4
40-1940	Washer - Hardened	2	50	4	53-7780	Plate - Wheel Half	6	53	2
41-7650	Puller - Flywheel	12	*	1	53-7950	Shaft - Intermediate	6	67	1
42-4020	Frame - Bag	9	7	1	55-3575	Cap - Gas	8	3	1
42-4030	Frame - Bag, Upper	9	5	1	55-8010	Sleeve - Gear	5	34	1
42-4740	Gear - 38T	5	28	1	55-8020	Retainer - Key	5	29	1
44-0580	Shield - Rear Safety	2	35	1	56-6190	Screw - Shoulder, Metric	4	6	1
44-2750	Body - Primer	3	13	1	60-8870	Yoke - Shift	5	23	1
44-3172	Hose - Primer	3	5	1	60-9010	Strap - Ground	4	7	1
46-0790	Screw - Self Tapping	4	1	1	61-8062	Engine - Complete	3	2	1
46-3540	Gear - 12T	6	66	1	61-8270	Bar - Control	7	18	1
46-3550	Gear - 14T	6	65	1	61-8300	Pivot Arm Assembly	1	1	2
46-3560	Gear - 52T	5	25	1	62-3830	Washer - Thrust, Keyed	5	45	2
46-6810	Screw - Thread Forming	1	8	1	62-3980	Sleeve	3	9	2
46-6811	Screw - Thread Forming	1	12	1	62-7600	Decal - Fuel	8	9	1
46-6980	Support - Cable	7	8	1	63-9330	Body - Air Cleaner	3	6	1
46-7030	Retainer - Cable	1	29	1	63-9340	Cover - Air Cleaner	3	12	1
46-7910	Pulley - Driver	3	15	1	63-9380	Filter - Foam	3	11	1
46-8081	Guide - Rope	7	11	1	65-5860	Protector - Crankshaft	3	25	1
46-8090	Screw - Self Tapping	1	17	2	66-5350	Lever - Control	7	14	1
46-8091	Screw - Hex. Washer Hd.	8	13	2	66-5370	Spring - Compression	4	9	1
47-2910	Washer - Thrust	6	72	1	66-5380	Brake Plate Assembly	4	5	1
47-6730	Seal	5	21	4	66-7460	Bulb - Primer	3	14	1
47-7260	Seal	6	73	1	66-7560	Spring Arm Ass'y - Front	2	38	2
47-7270	Bearing - Needle	5	11	2	66-7561	Spring Arm Ass'y - Rear	5	5	2

\*Not Illustrated

# TORO PART NUMBER INDEX (Cont.)

3315-373

Part No.	Description	Pg. No.	Ref. No.	Qty.	Part No.	Description	Pg. No.	Ref. No.	Qty.
66-9300	Screw - Hex. Flange Hd.	3	26	4	81-0760	Pin - Crankshaft	10	16	1
70-1061	Cable - Throttle	7	31	1	81-0770	Spacer - Governor	10	10	1
71-1260	Decal - Pro Line	3	1	1	81-0780	Gasket - Carburetor	15	12	3
71-1280	Decal - Safety Instructions	2	55	1	81-0850	Seal - Shaft, Governor	13	22	1
71-9280	Filter - Fuel	8	11	1	81-0860	Washer	13	23	1
71-9350	Bracket - Spring	1	11	1	81-0870	Ring - Retaining	13	24	1
71-9370	Decal - Danger Covers	2	56	1	81-0900	Nut	13	10	2
74-1640	Cover - Wheel	6	59	2	81-0910	Rod - Carburetor	13	26	1
74-1650	Spacer - Wheel	6	58	2	81-0920	Spring - Carburetor Rod	13	1	1
74-1720	Wheel & Tire Assembly	6	*	2	81-0970	Float	15	20	1
74-1741	Bracket - Traction Adj.	1	31	1	81-1010	Gasket - Bowl, Float	15	21	1
74-1750	Bracket - Traction, Engage	5	17	1	81-1020	Gasket - Capscrew, Bowl	15	23	1
74-1760	Gear - Bevel	6	63	1	81-1030	Jet - Pilot #40	15	11	1
74-1770	Cover - Belt	1	27	1	81-1060	Jet - Main #75	15	19	1
74-1791	Cable - Traction	7	33	1	81-1080	Gasket - Muffler	11	1	1
74-1810	Washer	6	61	2	81-1100	Bolt	11	6	2
74-1851	Pivot Arm Assembly	5	2	2	81-1110	Nut	11	8	2
74-1861	Gear Case Assembly	6	*	1	81-1120	Washer - Lock	11	7	2
74-1890	Shaft - Output	5	8	1	81-1140	Screw - Phillips Hd.	11	10	2
74-1920	Case - Lower	5	40	1	81-1150	Bolt - Self Tapping	11	9	1
74-1960	Lever - Shift	5	22	1	81-1170	Bolt - Self Tapping	13	12	1
74-1970	Decal - Traction Drive	1	30	1	81-1210	Pulley - Rope	14	6	1
74-2110	Bracket - Tank	8	1	1	81-1220	Spring - Dog	14	12	1
76-4570	Plate - Latch	1	16	1	81-1230	Dog - Starter	14	13	1
76-4640	Latch - Plug	1	21	1	81-1240	Spring - Compression	14	11	1
76-4650	Grip - Latch	1	22	1	81-1250	Retainer - Dog	14	14	1
76-4660	Spring	1	13	1	81-1260	Bolt - Shoulder	14	15	1
77-0040	Decal - Recoil	3	3	1	81-1270	Rope	14	5	1
77-0200	Door Assembly	1	15	1	81-1280	Bolt	14	9	4
77-0500	Plug - Discharge	1	20	1	81-1300	Bolt	14	3	3
77-0520	Support - Bracket	8	8	1	81-1330	Nut	12	2	1
77-2840	Retainer - Tank, Fuel	8	2	1	81-1450	Washer - Lock	13	9	1
77-5260	Strap - Insulation	4	4	1	81-1480	Clamp	12	6	1
77-5270	Lever - Control	7	12	1	81-1500	Cap Assembly - Spark Plug	12	10	1
80-3770	Retainer - Door	1	14	1	81-1630	Handle - Recoil	14	4	1
81-0090	Gasket	15	2	1	81-1710	Lever - Choke	13	20	1
81-0090	Gasket	3	4	1	81-1730	Bolt - Bracket, Throttle	13	21	1
81-0181	Spark Plug	12	7	1	81-1750	Washer - Lever, Choke	13	8	2
81-0200	Spark Arrester (Optional)	11	2	1	81-1770	Spacer - Lever, Governor	13	6	1
81-0220	Bushing - Choke	15	5	1	81-1830	Insulator - Kill Switch	13	14	1
81-0230	Spring - Choke	15	4	1	81-1840	Terminal - Kill Switch	13	11	1
81-0240	Valve - Choke	15	3	1	81-1950	Shaft - Choke	15	7	1
81-0250	Shaft - Throttle	15	8	1	81-2080	Cover - Fan, Cooling	14	1	1
81-0260	Valve - Throttle	15	9	1	81-2100	Case - Starter	14	8	1
81-0270	Screw - Throttle	15	10	1	81-2120	Guard - Spark Plug	12	8	1
81-0520	Pin - Crankcase	10	20	2	81-2140	Piston - 58mm	10	5	1
81-0540	Bolt	13	13	1	81-2160	Screw - Choke Plate	15	6	2
81-0540	Bolt 30mm Lg.	10	15	5	81-2170	Cup - Pulley, Starter	14	2	1
81-0560	Plate - Mounting	10	19	1	81-2190	Insulator - Carburetor	15	14	1
81-0570	Bolt	10	18	4	81-2300	Spring & Retainer Assembly	14	*	1
81-0590	Piston Ring Set	10	2	1	81-2340	Jet - Main #72.5 High Alt.	15	*	A/R
81-0600	Pin - Wrist	10	4	1	81-2350	Bolt - Self Tapping	12	9	2
81-0610	Bearing - Wrist Pin	10	17	1	81-2370	Key - Flywheel	12	4	1
81-0620	Circlip	10	3	2	81-2420	Bracket - Throttle	13	15	1
81-0690	Bearing - Upper 20mm	10	8	1	81-2430	Clamp - Cable	13	18	1
81-0700	Bearing - Lower 25mm	10	12	1	81-2450	Cover - Muffler	11	5	1
81-0710	Washer - Thrust, Upper	10	7	1	81-2460	Spring - Lever, Choke	13	5	1
81-0720	Seal - Oil, Upper	10	6	1	81-2470	Spacer - Lever, Choke	13	17	1
81-0730	Washer - Thrust, Lower	10	13	1	81-2520	Carburetor Ass'y	15	*	1
81-0740	Seal - Oil, Lower	10	14	1	81-2530	Seal	15	25	2
81-0750	Bracket - Arm, Governor	10	11	1	81-2540	Ring	15	26	1

\*Not Illustrated





