



Z590-D Z Master[®] **With 72in TURBO FORCE[®] Side Discharge Mower**

Model No. 74269CP - 280000001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Description	Page	Description	Page
Front Frame Assembly	 3	Hood Assembly	 25
Caster Wheel and Z Stand Assembly	 5	Deck Connection Assembly	 26
Engine Frame, Console and Floor Pan Assembly	 6	Deck Assembly	 27
Seat and Roll-Over Protection System Assembly	 7	Deck Decal Assembly No. 112-8070	 29
Deluxe Seat Assembly No. 110-0838	 8	Pully and Bearing Assembly No. 114-0210	 30
Roll-Over Protection System Assembly No. 106-7437	 9	Spindle Assembly No. 112-8698	 31
Wheel and Brake Assembly	 10	Rubber Deflector Assembly No. 108-2792	 32
Motion Control Assembly	 11	Electrical Assembly	 33
RH Motion Control Assembly No. 109-3978	 12	Cylinder Assembly	 35
LH Motion Control Assembly No. 109-3979	 13	Crankshaft Assembly	 36
Engine Mount Assembly	 14	Cylinder Head Assembly	 37
Wheel Pump Drive Assembly	 15	Injection Pump Assembly	 38
Deck Belt Drive Assembly	 16	Camshaft Assembly	 39
Cooling Pump Drive Assembly	 17	Oil Pan Assembly	 40
Hydraulic System Assembly	 18	Gear Cover Assembly	 41
Tank and Fuel Line Assembly	 20	Gear Housing Assembly	 42
Front and Rear Engine Cover Assembly	 22	Water Pump Assembly	 43
Cooling System Assembly	 24	Manifold Assembly	 44
		Starter Motor and Alternator Assembly	 45
		Gasket Assembly	 46
		Attachments and Accessories List	 47

Part Description Abbreviations


Part descriptions in this catalog may include the following abbreviations.

AR. as required	HYD. hydraulic
ASM. assembly	LH. left hand
BBC. blade brake clutch	NI. nylon insert
CARR. carriage	NPTF. national pipe thread fine
DEG. degrees	PFH. phillips flat head
EXT. external	PPH. phillips pan head
FH. flat head	PPHTF. phillips pan head thread forming
GA. gauge	PRH. phillips round head
HD. heavy-duty	PTH. phillips truss head
HF. hex flange	PTO. power-take-off
HH. hex head	RH. right hand
HHF. hex head flange	ROPS. roll-over protection system
HHFTF. hex head flange thread forming	SFH. slotted fillister head
HJ. hex jam	SHH. slotted hex head
HLH. hex lag head	SHWH. slotted hex washer head
HOC. height-of-cut	SPH. slotted pan head
HSBH. hex socket button head	SQH. square head
HSFH. hex socket flat head	SRH. slotted round head
HSH. hex socket head	STD. standard
HWH. hex washer head	TAP. self tapping
HWHTF. hex washer head thread forming	TTH. torx truss head

Footnotes

❶ Not illustrated


❷ Not serviced separately



Front Frame Assembly


Ref	Part No.	Qty.	Description
1	110-8724	1	Frame ASM
1:2	107-1857	1	Decal-Brake, Parking
1:3	1-811010	2	Plug
1:4	302-19	5	Fitting-Grease
1:5	94-1291	2	Bushing
1:6	104-7759	1	Decal-Warning
1:7	103-1918	1	Bushing
2	3256-29	4	Washer-Flat
3	32151-103	5	Ring-Retaining, EXT
4	32151-29	2	Ring-Retaining
5	1-523157	2	Washer-Spacer
6	3296-39	8	Nut-Lock, NI
7	108-7786-01	1	RH Front Deck Lift ASM
8	323-9	2	Screw-HH
10	323-6	1	Screw-HH
12	106-9981	1	Footrest
12:2	106-7451	1	Decal
12:3	107-2112	1	Decal-Warning
13	3274-94	4	Screw-HSBH
14	1-513658	2	Bumper
15	110-5860	1	Deck Lift Handle ASM
15:1	1-633295	1	Grip-Lever, Lift
15:2	103-2083	1	Lever-Lift
15:3	103-2064	1	Arm-Lift, Deck

Ref	Part No.	Qty.	Description
15:4	1-633325	1	Spring-Compression
15:5	3296-39	1	Nut-Lock, NI
15:6	3256-24	1	Washer-Flat
16	323-29	2	Screw-HH
18	103-1918	2	Bushing
21	323-13	1	Screw-HH
22	110-0833	1	Plate-Deck Lift, Outer
22:2	107-1860	1	Decal-Height, Deck
23	1-633068	2	Arm-Lift, Deck
24	1-633082	1	Bushing-Lever, Lift
25	110-0834	1	Plate-Deck Lift, Inner
25:2	107-1861	1	Decal-Height, Deck
26	3290-357	15	Nut-HHF, Whiz
27	106-9951	1	Hitch Pin ASM
28	98-5975	12	Washer-Belleville
29	323-7	12	Screw-HH
30		2	Front Frame Spring ASM
30:1	1-633096	1	Rod-Lift, Deck
30:2	1-633441	2	Swivel-Deck Mount, Rear
30:3	3217-11	3	Nut-Hex
30:4	3218-6	3	Nut-Jam
30:5	3256-7	2	Washer-Flat
30:6	1-643015	1	Spring-Support, Deck
31	3218-2	2	Nut-Jam



Front Frame Assembly (continued)


Ref	Part No.	Qty.	Description
32	3274-18	2	Screw-HSH
33	106-8984-01	1	LH Deck Lift ASM
34	1-633080	1	Bushing-Lever, Lift



Caster Wheel and Z Stand Assembly

Ref	Part No.	Qty.	Description
1	110-5746	2	Castor Wheel ASM
1:1	1-633580	2	Seal-Bearing
1:2	1-633581	2	Spacer-Bearing
1:3	1-633585	2	Bearing-Cone, Taper
1:4	1-633959	1	Spacer-Caster, Front
1:5	110-5744	1	Wheel And Tire ASM (Semi-Pneumatic)
1:5:3	1-633584	1	Bearing-Cup
1:21	325-24	1	Screw-HH
1:22	3296-45	1	Nut-Lock, NI
3	107-1874	1	Leg ASM
3:2	106-7464	1	Decal-Z Stand
4	3290-355	1	Pin-Hair
5	100-9692-01	1	Pivot Pin ASM
6	3-6781	2	Washer-Thrust
7	283-55	1	Pin-Clevis
8	323-8	1	Screw-HH
9	100-9686-01	1	Bracket-Latch
10	3296-39	2	Nut-Lock, NI
11	283-71	1	Pin-Lynch
12	254-72	4	Bearing-Cup, Tapered
13	254-94	4	Bearing-Cone, Tapered
14	1-633508	6	Washer-Bellville
15	3296-51	2	Nut-Lock, NI


Ref	Part No.	Qty.	Description
16	103-4882	2	Cap-Grease
17	105-1647	1	Pin-Hitch, Cotterless
18	100-9385	1	Lanyard-Nylon
19	3296-42	1	Nut-Lock, NI
20	100-6547	2	Cushion-Rubber
21	108-4136-01	1	Bracket-Cradle
22	323-20	1	Screw-HH
23	321-4	1	Screw-HH
24	1-543511	2	Seal-Grease
25	103-1474-01	2	Fork-Caster
27	110-8837	1	Caster Wheel Bearing Kit
27:1	1-633581	2	Spacer-Bearing
27:2	1-633580	2	Seal-Bearing
27:3	1-633584	2	Bearing-Cup
27:4	1-633585	2	Bearing-Cone, Taper
28	103-2768	2	Guard-Seal



Engine Frame, Console and Floor Pan Assembly


Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	322-43	6	Screw-HH	20	106-7498	1	Pocket
2	3256-70	4	Washer-Flat				
3	3296-42	4	Nut-Lock, NI				
6	115-3551	1	Engine Frame ASM				
6:2	106-9989	1	Decal-Warning				
6:3	106-7492	1	Decal-Danger				
6:4	107-9866	1	Decal-Console, Top				
6:5	98-5954	2	Decal-Cover, Missing				
7	107-1865	2	R-Clamp				
8	104-7050	1	Housing-Manual				
9	3296-39	2	Nut-Lock, NI				
10	1-633964-03	1	Stop-Brake, Park				
11	323-20	2	Screw-HH				
12	323-6	2	Screw-HH				
13	115-3852	1	Floor Pan ASM				
13:2	98-4387	1	Decal-Protection, Ear				
13:3	107-1864	1	Decal-Location, Manual				
13:4	114-5879	1	Decal-Diesel, Bio-Ready				
14	3258-166	2	Screw-PRH				
15	106-7488-03	1	Hinge-Floorpan, LH				
16	3296-59	2	Nut-Lock, NI				
17	104-7048	1	Cap-Housing				
18	321-4	2	Screw-HH				
19	106-7489-03	1	Hinge-Floorpan, RH				

7




Deluxe Seat Assembly No. 110-0838

Ref	Part No.	Qty.	Description				
1	112-8355	1	Seat-Suspension				
1:1	107-1880	1	Seat Track Kit				
1:2	107-1885	1	Weight Indicator Kit				
1:3	107-1881	1	Knob Kit				
1:4	107-1883	1	Bottom Cushion Kit				
1:5	82-2190	1	Switch-Bail				
1:6	107-1887	1	Armrest Kit				
1:7	107-1884	1	Shock Absorber Kit				
1:8	112-8356	1	Cushion-Back				
4	110-0883	1	Retractable Seatbelt Kit				
4:1		1	Seatbelt-Retractable				
4:2	3212-4	2	Screw-HH				
4:3	3296-7	2	Nut-Lock				
4:99	109-6226	1	Seat Belt Extension Kit				




Roll-Over Protection System Assembly No. 106-7437

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
②1		1	Upper Tube ASM	14:11	32128-23	2	Nut-HF
2	107-2102	1	Decal-Warning, Folding ROPS	14:20	323-8	8	Screw-HH
②4		1	Tube-Support, RH	14:21	98-5975	8	Washer-Belleville
②5		1	Tube-Support, LH	14:22	3290-357	8	Nut-HHF, Whiz
6	107-3069	1	Decal-Warning, Folding ROPS (Ce)				
7	3296-73	2	Nut-Lock, NI				
9	109-2365	2	Bumper-Rubber (W/Stud)				
10	107-2101	1	Decal-ROPS				
11	103-4553	2	ROPS Fold Pin ASM				
12	110-0883	1	Retractable Seatbelt Kit				
12:2	3212-4	2	Screw-HH				
12:3	3296-7	2	Nut-Lock				
12:99	109-6226	1	Seat Belt Extension Kit				
13	109-1813	1	Seat Frame Single Latch ASM				
13:1	103-5520	1	Catch-Latch, Single				
13:2	103-5519	1	Spring-Torsion, Latch				
13:3	107-0075	1	Bushing-Latch, Seat				
13:4	109-1810-03	1	Frame-Seat, Single Latch				
13:5	3256-4	1	Washer-Flat				
13:6	3296-39	1	Nut-Lock, NI				
13:7	323-9	1	Screw-HH				
②14		1	Bag-Bolt				
14:10	325-13	2	Screw-HH				



Wheel and Brake Assembly


Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	323-4	2	Screw-HH	22	103-0590	2	Hub And Wheel ASM
2	1-633102	2	Bearing-Flange, Side	22:1	103-0589	1	Wheel Hub ASM
3	3290-357	4	Nut-HHF, Whiz	22:2	1-633926	4	Stud-Wheel
4	109-5618	8	Nut,Square Special	23	322-9	6	Screw-HH
5	87-7270	4	Washer-Thrust	24	103-0374	2	Retainer-Band, Brake
6	103-0197	1	Brake Lever And Grip ASM	25	103-0355	2	Band-Brake
6:2	1-633268	1	Grip-Lever, Brake	26	103-0384	6	Spacer
7	103-1708	1	Rod-Brake	27	302-19	2	Fitting-Grease
8	3219-3	2	Nut-Hex	28	3296-39	4	Nut-Lock, NI
9	1-633131	2	Yoke-Linkage, Brake	29	3256-4	6	Washer-Flat
10	1-808285	1	Pin-Clevis	30	1-633144	2	Pin-Trunion
11	109-5011	4	Spacer-Wheel, Short	31	3218-3	2	Nut-Jam
12	103-2399	1	Pin-Spring, Clevis	32	103-0810-03	2	Brake-Wide
13	109-5012	4	Spacer-Wheel, Long	33	103-0051	2	Spacer-Retainer, Brake
14	323-10	2	Screw-HH	34	1-808284	2	Pin-Clevis
15	3257-42	2	Key-Woodruff	35	103-1117-03	2	Linkage-Brake, Lower
16	325-20	8	Screw-HH	36	1-633454	2	Spring-Brake
17	109-3157	2	Wheel And Tire ASM	37	323-58	2	Bolt-TAP, HH
17:1	109-3156	1	Wheel	38	103-5243-03	1	Shaft-Brake
17:2	103-4963	1	Tire	39	32151-48	1	E-Ring
18	242-50	8	Nut-Lug	40	1-513140	2	Bearing-Control
19	1-806800	2	Pin-Cotter	41	3272-10	4	Pin-Cotter
20	1-809036	2	Nut-HH				
21	1-523157	2	Washer-Spacer				



Motion Control Assembly


Ref	Part No.	Qty.	Description
1	1-633102	4	Bearing-Flange, Side
3	3296-29	8	Nut-Lock, NI
4	103-1361	1	Spacer-Hydro Control, LH
5	322-12	1	Screw-HH
6	3290-357	8	Nut-HHF, Whiz
7	322-14	1	Screw-HH
8	1-403180	4	Screw-HH
9	103-5192	1	Spacer-Control, HYD
19	98-5975	4	Washer-Belleville
20	323-6	4	Screw-HH
21	108-7237	1	RH Lever ASM
21:1	106-9987	1	Grip-Control, Motion
22	108-7238	1	LH Lever ASM
22:1	106-9987	1	Grip-Control, Motion
26	322-6	4	Screw-HH
28	103-0194-03	2	Arm-Control, Hydro
29	103-5190	1	RH HYD Connect Link ASM
29:1	1-543017	1	Balljoint-RH
29:2	1-633152	1	Balljoint-LH
29:3	1-804524	2	Nut
29:5	3219-2	3	Nut-Hex
29:6	1-323245	1	Spring-Compression
30	32128-20	6	Nut-HF
31	323-4	8	Screw-HH

Ref	Part No.	Qty.	Description
32	109-2339	2	Damper-Control, Motion
33	1-803022	2	Screw-Set
34	103-3062	1	Tracking Rod ASM
34:1	1-543017	1	Balljoint-RH
34:2	103-3060	1	Knob-Tracking
34:3	1-804524	2	Nut
34:4	1-323245	2	Spring-Compression
34:5	1-633152	1	Balljoint-LH
34:7	3219-2	1	Nut-Hex
35	3217-6	4	Nut-Hex
36	109-3978	1	RH Motion Control ASM
37	109-3979	1	LH Motion Control ASM




RH Motion Control Assembly No. 109-3978

Ref	Part No.	Qty.	Description				
1	1-808280	1	Pin-Clevis				
2	103-0407	1	Arm-Shaft, Control				
3	109-3903	1	Neutral Return ASM				
3:1	1-303105	1	Yoke-Adjustable				
3:2	1-603737	1	Bolt-Return, Neutral				
3:3	1-603807	1	Spring-Return, Neutral				
3:4	109-3769	1	Bushing-Nylon, Flanged				
3:5	3219-2	3	Nut-Hex				
3:6	3230-23	1	Screw-CARR				
3:7	3256-2	1	Washer-Flat				
3:8	109-3908	1	Tab-Adjustment				
4	109-3980	1	Control-Motion, RH				
5	323-9	3	Screw-HH				
6	3272-5	1	Pin-Cotter				
7	3296-39	3	Nut-Lock, NI				



LH Motion Control Assembly No. 109-3979


Ref	Part No.	Qty.	Description				
1	1-808280	1	Pin-Clevis				
2	103-0407	1	Arm-Shaft, Control				
3	109-3903	1	Neutral Return ASM				
3:1	1-303105	1	Yoke-Adjustable				
3:2	1-603737	1	Bolt-Return, Neutral				
3:3	1-603807	1	Spring-Return, Neutral				
3:4	109-3769	1	Bushing-Nylon, Flanged				
3:5	3219-2	3	Nut-Hex				
3:6	3230-23	1	Screw-CARR				
3:7	3256-2	1	Washer-Flat				
3:8	109-3908	1	Tab-Adjustment				
4	109-3983	1	Control-Motion, LH				
5	323-9	3	Screw-HH				
6	3272-5	1	Pin-Cotter				
7	3296-39	3	Nut-Lock, NI				



Engine Mount Assembly

Ref	Part No.	Qty.	Description
1	325-10	1	Screw-HH
2	86-1990	2	Washer
3	3290-357	2	Nut-HHF, Whiz
4	103-1022	1	Isolator-Rear
5	323-5	2	Screw-HH
6	103-3908	1	Bracket-Ground
7	103-0870-03	1	Rear Engine Mount ASM
8	3296-23	1	Nut-Lock, NI
9	323-12	2	Screw-HH
10	83-1040	2	Washer-Flat
11	66-6480	2	Washer
12	103-2613	2	Isolator-Side
13	322-3	4	Screw-HH
14	33114-020	15	Screw-HH
15	103-0839-03	2	LH And RH Engine Mount ASM
16	3256-4	2	Washer-Flat
17	3296-39	3	Nut-Lock, NI
18	103-0921	1	Hose
19	2412-42	2	Clamp-Hose
20	103-0888	1	Engine-Daihatsu
21	103-2592	1	Muffler Kit
21:2	103-1385	1	Gasket-Muffler
22	98-5975	3	Washer-Belleville
23	3256-23	4	Washer-Flat


Ref	Part No.	Qty.	Description
24	322-14	3	Screw-HH
25	103-3573-03	1	Cover-Flywheel
26	3256-24	4	Washer-Flat
27	56-2150	2	Screw-HH
28	323-8	2	Screw-HH
29	103-3745	2	Ball Joint Link ASM
30	322-12	1	Screw-HH
32	32128-20	7	Nut-HF
33	103-3556-03	1	Bracket-Engine, Front
34	1-303334	3	Washer-Spring
35	33114-045	3	Screw-HH
36	93-6099	4	Washer
37	103-3568	2	Isolator-Link
38	3296-6	2	Nut-Lock
39	63-7790	2	Screw-Cap



Wheel Pump Drive Assembly

Ref	Part No.	Qty.	Description
1	103-2739	2	Key
2	103-2978	1	Pump-Hydro, LH
10:1	100-6110	1	Overhaul Seal Kit
3	32128-49	4	Nut-HHF
4	103-4467	1	Pump Idler ASM
4:20	1-513034	2	Sleeve-Bearing
5	323-4	3	Screw-HH
6	3296-39	1	Nut-Lock, NI
7	3256-4	1	Washer-Flat
8	103-0919	1	Bushing-Tightener, Pivot
9	103-2979	1	Pump-Hydro, RH
10:1	100-6110	1	Overhaul Seal Kit
10	323-12	1	Screw-HH
11	1-603413	1	Spring-Extension
12	325-5	4	Screw-HH
13	1-803050	4	Screw-Set
14	103-1471	2	Hub-Pump
15	107-7724	1	Belt-V
16	1-805005	6	Washer-Lock
17	322-2	6	Screw-HH
18	33114-020	4	Screw-HH
19	3256-23	4	Washer-Flat
20	3256-24	1	Washer-Flat
21	3290-357	4	Nut-HHF, Whiz


Ref	Part No.	Qty.	Description
22	103-1459	1	Pin-Roll
23	103-1421	1	Hub-Drive, Pump
24	103-1472	2	Sheave-Pump
25	103-4464	1	Idler-Pump
26	103-5164	1	Sheave-Engine
27	98-5975	2	Washer-Belleville
28	323-6	1	Screw-HH
29	323-16	1	Screw-HH
30	103-4463-03	1	Arm-Tightener, Pump



Deck Belt Drive Assembly


Ref	Part No.	Qty.	Description
1	103-0983	2	Sheave
2	3256-24	4	Washer-Flat
3	3290-357	7	Nut-HHF, Whiz
4	107-9851	1	LH Idler ASM
4:2	1-513034	2	Sleeve-Bearing
4:3	302-40	1	Fitting-Grease
5	3256-4	6	Washer-Flat
6	3296-39	4	Nut-Lock, NI
7	103-4011-03	1	Guard-Belt Sheave, LH
8	3231-40	2	Bolt-CARR
9	103-0984	2	Sheave
10	103-3186	1	Spacer-Bracket, Guide
11	103-4039-03	1	Guard-Belt Sheave, RH
12	107-7738	2	Belt-V
13	3231-4	2	Screw-CARR
14	323-9	4	Screw-HH
15	107-9861	1	RH Idler ASM
15:2	1-513034	2	Sleeve-Bearing
15:3	302-40	1	Fitting-Grease
16	103-1767	2	Spring-Extension
17	103-1503	4	Spacer-Tightener, Belt
18	98-5975	2	Washer-Belleville
19	323-23	1	Screw-HH
20	103-1361	2	Spacer-Hydro Control, LH

Ref	Part No.	Qty.	Description
21	103-0193	3	Spacer-Strap, Clutch
22	323-13	2	Screw-HH
23	103-0286	1	Shaft-Stub
24	33114-020	5	Screw-HH
25	109-6627	1	Clutch Kit
26	32128-20	1	Nut-HF
27	3256-3	1	Washer-Flat
28	1-613235	4	Washer
29	1-633545	2	Spacer
30	1-633630	2	Grommet-Brake
31	322-6	1	Screw-HH
32	103-0192-03	1	Strap-Clutch / Brake
33	3296-29	1	Nut-Lock, NI
34	322-12	1	Screw-HH
35	3256-23	1	Washer-Flat
36	323-16	1	Screw-HH
37	103-0919	1	Bushing-Tightener, Pivot
38	103-0040	1	Bushing-Tightener, Pivot



Cooling Pump Drive Assembly


Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	3212-6	1	Screw-HH	22	32150-1	1	Key-Square
2	1-603610	2	Washer-Spring	23	103-1338	1	Sheave-5 Rib
3	1-543610	1	Washer-Clutch	24	3246-6	2	Screw-Set, HSH
4	107-7739	1	Belt-Poly V	25	13-2840	1	Key-Square
5	103-1339	1	Sheave-5 Rib				
6	323-9	3	Screw-HH				
7	103-1422	1	Spacer-Pump Drive, Fan				
8	323-14	1	Screw-HH				
9	3256-4	3	Washer-Flat				
10	107-9879	1	Wheel Pump Tension ASM				
10:1		1	Tensioner ASM				
10:1:1	1-513034	2	Sleeve-Bearing				
10:1:2	302-40	1	Fitting-Grease				
10:2	98-5954	1	Decal-Cover, Missing				
11	1-633167	1	Sheave-Idler				
12	3256-24	1	Washer-Flat				
13	3290-357	4	Nut-HHF, Whiz				
14	1-603384	1	Bushing-Pivot, Idler				
15	1-603414	1	Spring-Extension				
16	3296-29	4	Nut-Lock, NI				
17	103-7431	1	Pump-Fan, Cooling				
18	103-1299-03	1	Plate-Mating, Fan Pump				
19	322-4	4	Screw-HH				
20	103-1575	2	Spacer-Spring, Fan Pump				



Hydraulic System Assembly

Ref	Part No.	Qty.	Description
1	108-5998	1	Fitting-HYD, Straight Tee
1:1	237-21	2	O-Ring
1:2	237-42	1	O-Ring
2	103-2173	1	Fan Case Drain Hose ASM
3	108-5999	1	Fitting-HYD, 45 Elbow
3:1	237-21	1	O-Ring
3:2	237-42	1	O-Ring
4	103-7430	1	Motor-Fan, Cooling
5	1-603990	3	Fitting-Straight
5:1	1-603920	1	O-Ring
5:2	1-603992	1	O-Ring
6	103-2157	1	Fitting-Straight
6:1	1-603923	1	O-Ring
6:2	103-1020	1	O-Ring
7	32128-20	7	Nut-HF
8	322-5	4	Screw-HH
9	322-3	2	Screw-HH
10	109-0582	1	Hydraulic Tank ASM
10:1		1	Tank-Hydraulic
10:1:1	103-1948	1	Cap-Reservoir, HYD
10:1:2	103-1949	1	Gasket-Cap
10:2	1-523552	1	Decal-Tank, HYD
11	322-4	5	Screw-HH
13	103-2155	1	Fitting-90 DEG


Ref	Part No.	Qty.	Description
13:1	1-603921	1	O-Ring
13:2	103-1020	1	O-Ring
14	108-5316	1	Fitting-Elbow, 90 DEG
14:1	237-79	1	O-Ring
15	3296-29	1	Nut-Lock, NI
16	103-2174	1	Tank Return Hose ASM
17	103-2104	1	Clamp-Hose
19	1-603991	4	Fitting-Straight
19:1	237-80	1	O-Ring
19:2	1-603992	1	O-Ring
20	103-4679	4	HYD Hose ASM
21	103-1014	2	Fitting-Elbow, 90 DEG
21:1	1-603920	1	O-Ring
22	103-2315	1	Fitting-90 DEG
22:1	1-603992	1	O-Ring
23	103-2153	2	Fitting-90 DEG
23:1	1-603920	1	O-Ring
23:2	1-603992	1	O-Ring
24	103-2159	1	Fitting-Tee
24:1	1-603920	1	O-Ring
24:2	1-603992	2	O-Ring
25	103-2156	1	Fitting-Straight
25:1	1-603921	1	O-Ring
25:2	103-1020	1	O-Ring



Hydraulic System Assembly (continued)

Ref	Part No.	Qty.	Description
27	103-1940	2	Adapter-HYD, Straight
27:1	237-79	1	O-Ring
27:2	1-603992	1	O-Ring
28	103-2172	1	Case Drain Hose ASM
30	23-9740	1	Filter-Oil
31	103-5120	1	Charge Hose ASM
31:1	103-2259	1	Head-Filter
31:2	103-5121	1	Filter Inlet Hose ASM
31:2:1	1-603920	1	O-Ring
31:3	103-2269	1	Pump Inlet Hose ASM
31:3:1	1-603920	1	O-Ring
32	1-805004	2	Washer-Lock
33	321-3	2	Screw-HH
34	1-643312	1	Clip-Loom
35	1-633396	2	Clip-Loom
36	103-2148	1	Auxillary Pump Hose ASM
37	1-323241	1	Hose-Pressure, High
38	103-3110	1	Filter-In Line, 50 Micron
39	103-2155	1	Fitting-90 DEG
39:1	1-603921	1	O-Ring
39:2	103-1020	1	O-Ring
40	103-2489	2	Motor-Wheel, HYD
41	32150-1	1	Key-Square
42	112-1768-03	1	Bracket-Tank Mount, Upper


Ref	Part No.	Qty.	Description
43	112-1778-03	1	Bracket-Tank Mount, Lower



Tank and Fuel Line Assembly

Ref	Part No.	Qty.	Description
2	115-3556	1	LH Fuel Tank Kit
2:1		1	Tank-Fuel, LH
2:1:2	103-2615	2	Fitting-Fuel, Bulkhead
2:2	114-8214	1	Biodiesel Cap ASM
3	107-7672-03	1	Bracket-Fuel Tank, LH
4	109-0273	1	Hose-Fuel
5	322-3	1	Screw-HH
6	322-9	1	Screw-HH
7	109-0289	1	Hose-Fuel
8	1-643293	6	Clamp-Hose, Fuel
9	114-8206	1	Hose-Fuel
10	110-4113	1	Hose-Fuel
11	32128-33	1	Nut-HF
12	1-643234	1	Valve-Fuel, Dual Flow
13	107-9878	1	Bracket-Valve, Fuel
13:2	107-2114	1	Decal-Valve, Fuel
14	321-3	1	Screw-HH
15	3296-47	2	Nut-Lock, NI
16	94-7564	2	Spacer
17	3296-47	6	Nut-Lock, NI
18	322-9	2	Screw-HH
19	107-7671-03	1	Bracket-Fuel Tank, RH
20	115-3555	1	RH Fuel Tank Kit
20:1		1	Tank-Fuel, RH


Ref	Part No.	Qty.	Description
20:1:2	103-2615	2	Fitting-Fuel, Bulkhead
20:2	114-8214	1	Biodiesel Cap ASM
21	1-633023	6	Stud
22	3256-23	10	Washer-Flat
23	1-633349	6	Spring-Tank, Fuel
24	3256-24	4	Washer-Flat
25	323-4	4	Screw-HH
26	110-5701	1	Hose-Fuel
27	109-0294	1	Hose-Fuel
28	110-4100	1	Hose-Fuel
29	1-303335	7	Tie-Plastic
30	115-3561	1	Control Panel ASM
30:2	115-3562	1	Decal-Control Panel
31	1-603175	1	Knob-Ball
32	1-807513	2	Bolt-CARR
33	109-2661	4	Screw-PPH
35	110-5729	1	Throttle Control Cable ASM
35:1	112-2334	1	Lever-Throttle
35:2	110-5730	1	Cable-Throttle
36	3296-2	2	Nut-Lock
37	1-643277	3	Clamp-Hose, Fuel
39	3290-357	4	Nut-HHF, Whiz
40	112-9188	1	Element-Filter, Fuel
41	110-8807	1	Bracket-Filter, Fuel



Front and Rear Engine Cover Assembly

Ref	Part No.	Qty.	Description
1	103-4855-03	1	Guard-Muffler
2	923786	4	Rivet
3	1-643189	2	Keeper-Latch, Rubber
4	3256-23	13	Washer-Flat
5	322-5	14	Screw-HH
6	107-9865	1	Rear Bumper ASM
6:2	107-9864	1	Decal-Belt Routing, Deck Drive
7	103-5157-03	1	Frame-Upper, LH Rear
8	32128-20	23	Nut-HF
9	103-4906-03	3	Bar-Mount Frame, Radiator
10	322-3	9	Screw-HH
11	3256-24	4	Washer-Flat
12	323-6	2	Screw-HH
13	323-7	2	Screw-HH
14	103-5169-03	1	Mount-Side, LH
15	103-2603-03	1	Bracket-Bottle
16	1-632986-03	2	Shackle-Hinge
17	3290-357	4	Nut-HHF, Whiz
18	103-5163-03	2	Mount-Belt Shield, Engine
19	1-323385	2	Knob-3 Prong
20	107-7709	1	Engine Belt Shield ASM
20:2		1	Strip-Shield, Belt
20:2:2	98-5954	1	Decal-Cover, Missing
21	109-2365	2	Bumper-Rubber (W/Stud)


Ref	Part No.	Qty.	Description
22	3296-42	2	Nut-Lock, NI
23	100-3815	2	Grommet-Rubber
24	107-7707	1	Engine Access Panel ASM
24:2	107-7705	1	Decal-Belt Routing, Pump
24:3	103-3276	1	Decal-Buzzer, Warning
24:4	103-5881	1	Decal-Devices, Rotating
25	103-4982-03	1	Bracket-Buzzer
26	32128-33	2	Nut-HF
27	321-4	2	Screw-HH
28	3256-22	2	Washer-Flat
29	103-5178	1	Filter-Air
30	103-1058	1	Bracket-Filter, Air
31	87-9400	1	Valve-Vacuator
32	103-1060	1	Cover-Filter, Air
33	1-643283	2	Latch-Cleaner, Air
34	103-1327	1	Filter-Air
35	103-1326	1	Filter-Air, Safety
36	2412-42	1	Clamp-Hose
37	103-5198	1	Hose-Intake
38	103-0953-03	1	Mount-Cleaner, Air
39	103-5123-03	1	RH Radiator And Ac Support ASM
40	100-2436	1	Hood
41	107-7715	1	Bar-Radiator
41:2	65-2690	1	Decal-Surface, Hot



Cooling System Assembly


Ref	Part No.	Qty.	Description
1	322-1	6	Screw-HH
2	3256-23	22	Washer-Flat
3	107-7658	1	Plate-Trim, Radiator
3:2	65-2690	2	Decal-Surface, Hot
3:3	104-2449	1	Decal-Coolant
4	1-643161	1	Cap-Radiator
5	3296-2	1	Nut-Lock
6	1-803075	1	Screw-Head, Truss
7	103-1352	1	Shield-Fill Neck, Radiator
8	107-9889	1	Radiator
9	103-0898	1	Shroud-Cooling, Engine
10	322-3	16	Screw-HH
11	107-7717	1	Fan Mounting Plate ASM
11:2	1-643253	2	Decal-Fan, Radiator
12	32128-20	10	Nut-HF
13	103-0892	1	Fan
14	3296-42	1	Nut-Lock, NI
15	109-2670	1	Hose
16	1-513762	1	Clip-Loom
17	321-6	1	Screw-HH
18	103-0113	1	Clip-Loom
19	103-0922	1	Hose-Inlet, Engine
20	1-643164	1	Cap-Tank, Overflow
21	1-513645	1	Bushing-Valve, Fuel

Ref	Part No.	Qty.	Description
22	321-2	2	Screw-HH
23	1-643259	1	Fitting-Elbow
24	1-643163	1	Tank-Overflow
25	109-2669	1	Hose
26	1-633989	4	Clamp-Hose
27	103-2505	1	Hose-Outlet, Engine
28	103-0086-03	1	Mount-Motor, Fan
29	103-4986	1	Bracket-Deflector, Air
30	322-14	2	Screw-HH
31	3256-3	4	Washer-Flat
32	103-5223	2	Spacer
33	1-513296	2	Spring-Indicator, Reverse
34	3296-29	4	Nut-Lock, NI
35	107-9853	2	Lanyard
36	1-303287	3	Tie-Plastic
37	3245-44	1	Screw-Set
38	909848	1	Screw-Set
39	322-6	2	Screw-HH
40	1-303335	2	Tie-Plastic




Hood Assembly

Ref	Part No.	Qty.	Description				
1	1-803072	17	Rivet				
2	1-633864-03	1	Screen-Radiator				
3	923786	4	Rivet				
4	1-643188	2	Latch-Rubber				
6	1-303435	5	Washer-Spring				
7	115-3560	1	Hood ASM				
7:2	107-7674	1	Decal				
7:3	114-9600	2	Decal-Low Sulfur				
8	3296-29	6	Nut-Lock, NI				
9	3256-23	8	Washer-Flat				
10	1-643108-03	1	Angle-Radiator, Bottom				
11	1-643105-03	1	Angle-Radiator, LH				
12	3256-14	2	Washer-Flat				
13	1-643186	2	Seal-Trim				
14	1-633885-03	2	Plate-Hinge, Hood				
15	322-4	2	Screw-HH				
16	1-808285	2	Pin-Clevis				
17	3256-24	4	Washer-Flat				
18	1-806003	2	Pin-Hair				
19	1-643187	2	Seal-Trim				
20	1-643107-03	1	Angle-Radiator, Top				
21	1-643106-03	1	Angle-Radiator, RH				
22	322-6	2	Screw-HH				



Deck Connection Assembly


Ref	Part No.	Qty.	Description				
1	3253-8	2	Washer-Lock				
2	3217-11	2	Nut-Hex				
3	32128-37	16	Nut-HF				
4	1-633447	4	Chain-Lift, Deck				
5	103-1898	8	Screw-HH				
6	327-28	2	Screw-HH				
7	103-1356	2	Strut ASM				
7:1	1-633029	1	Balljoint-Spherical				
7:2	3219-6	1	Nut-Hex				
7:3		1	Strut-Deck				
7:3:2	109-1380	2	Fitting-Grease				
8	3296-29	2	Nut-Lock, NI				
9	1-632199-01	2	Pin-Strut				
10	322-3	2	Screw-HH				
11		1	Deck ASM				



Deck Assembly


Ref	Part No.	Qty.	Description
1	112-8070	1	Deck Decal ASM
2	112-8667-03	1	Cover-Belt, RH
3	107-7723	1	Belt-V
4	112-8049	1	Cap-Plastic
5	3217-11	1	Nut-Hex
6	112-8666-03	1	Cover-Belt, LH
7	105-0842	1	Spacer
8	114-0210	1	Pulley And Bearing ASM
9	112-8048	1	Spacer-Flanged
10	112-8046	1	Bolt-Carriage
11	3290-357	41	Nut-HHF, Whiz
12	3256-24	13	Washer-Flat
13	1-603805	1	Pulley-Idler
14	106-3214	2	Mount-Pulley
15	110-5893-01	1	Mounting Bracket ASM
16	98-5975	2	Washer-Belleville
17	3231-2	2	Screw-CARR
18	112-8663-01	4	Spacer-Cover, Belt
19	106-3279-01	1	Plate-Skid
20	92-1624	24	Screw
21	107-7678	3	Pulley
22	98-7913	4	Tube-Spacer
23	98-7912	4	Tube-Spanner
24	1-603299	6	Roller-Scalp, Anti

Ref	Part No.	Qty.	Description
25	323-23	4	Screw-HH
26	106-7354-01	1	Mount-Wheel, LH
27	106-7355-01	1	Plate-Roller, RH
28	112-8698	3	Spindle ASM
29	105-7784-03	3	Blade-Hi Flow, 24.5 Inch
30	103-0865	3	Washer-Blade Bolt, Heavy
31	51-4060	3	Screw-Blade
32	3231-1	12	Screw-CARR
33	1-303334	4	Washer-Spring
34	3274-104	2	Screw-HSBH
35	323-12	4	Screw-HH
36	3296-29	4	Nut-Lock, NI
37	107-3138	1	Plate-Turbo
38	105-7730-01	1	Baffle ASM
39	322-50	1	Screw-HH
40	98-5967	1	Spacer-Wheel
41	105-7669-01	1	Baffle ASM
43	107-1664	2	Lever ASM
43:1	106-3239	1	Screw-Lock
43:2	107-1644	1	Cap-Lock
43:3	106-3241	1	Lever-Lock
43:4	3296-29	1	Nut-Lock, NI
44	108-2792	1	Rubber Deflector ASM
45	105-4622	1	Spacer




Deck Assembly (continued)

Ref	Part No.	Qty.	Description				
46	108-4052	1	Spring-Torsion				
47	108-4121-01	4	Bracket-Cover				
48	32144-70	4	Screw-HWHTF				
49	99-3058	4	Washer				
50	3234-11	1	Screw-HHF				
51	1-633109	2	Idler-Flat				
52	3256-4	2	Washer-Flat				
53	1-603044	1	Bushing				
54	107-9868	1	Idler Arm ASM				
54:1	103-4681	2	Sleeve-Bearing				
55	105-6992	1	Spring-Extension				
56	3231-21	1	Screw-CARR				
57	105-7699	8	Strip-Seal				
58	106-3216-01	1	Baffle-Discharge				
59	3296-39	6	Nut-Lock, NI				
60	323-28	1	Screw-HH				
61	106-6777	4	Handle-Latch, Swell				
62	106-6778	4	Bushing-Latch, Swell				
63	1-804254	4	Nut				
64	112-8051	1	Spacer-Rubber				
65	80-7710	1	Spacer-Pivot, Idler				
66	323-4	9	Screw-HH				
67	3290-455	9	Washer-Belleville				




Deck Decal Assembly No. 112-8070

Ref	Part No.	Qty.	Description				
2	107-7673	1	Decal-Routing, Belt				
3	98-5954	3	Decal-Cover, Missing				
4	107-9863	1	Decal-Check, Service				
5	68-8340	1	Decal-Torque				
6	58-6520	4	Decal-Grease				
7	107-1613	2	Decal-Grease				
8	1-403005	1	Decal-Danger				
9	105-7798	1	Decal-Scalp, Anti				
10	66-1340	1	Decal-Danger				
11	110-2068	1	Decal-Adjustment, Baffle				
12	110-2067	1	Decal-Setting, Baffle				
13	54-9220	1	Decal-Danger				
14	107-1620	1	Decal				




Pully and Bearing Assembly No. 114-0210

Ref	Part No.	Qty.	Description
2	104-6325	2	Bearing
3	112-8047	1	Spacer-Bearing
4	32120-8	1	Ring-Snap




Spindle Assembly No. 112-8698

Ref	Part No.	Qty.	Description				
1		1	Spindle Bearing ASM				
1:1		1	Housing-Spindle				
1:2	253-154	2	Seal-Oil				
1:3	71-2530	1	Bearing/Spacer Kit				
2	110-3285	1	Spindle Shaft ASM				
3	114-1161	1	Hub-Spline				
4	69-6950	1	Spacer-Shaft, Spindle				
5	3296-49	1	Nut-Lock, NI				
6	3-8514	1	Washer-Thrust				
7	302-2	1	Fitting-Grease				



Rubber Deflector Assembly No. 108-2792


Ref	Part No.	Qty.	Description				
1	3231-4	4	Screw-CARR				
2	106-3246-01	1	Deflector				
3	106-3248-03	1	Strap-Discharge				
4	108-5029	1	Deflector-Rubber				
5	108-4059-01	1	Plate-Hinge, Rear				
6	106-3253-01	1	Plate-Hinge, Front				
7	3296-39	4	Nut-Lock, NI				



Electrical Assembly


Ref	Part No.	Qty.	Description
1	103-4340	1	Harness-Wire
2	103-1349	1	Cable-Engine Negative
3	103-1159	1	Cable-Battery Negative
4	103-1160	1	Cable-Starter
5	103-4339	1	Harness-Gauge
6	106-5187	1	Battery
7	103-1227	1	Harness-Wiring, Seat
8	1-303335	11	Tie-Plastic
9	1-643275	4	Relay
10	1-803071	2	Screw
11	3296-2	8	Nut-Lock
12	103-0205	1	Alarm-Tone, Dual
13	1-643178	1	Cap-Insulator, Red
14	103-1420	1	Insulator-Starter
15	1-603727	1	Clip-Loom
16	323-6	1	Screw-HH
17	3256-24	1	Washer-Flat
18	3290-357	1	Nut-HHF, Whiz
19	33023-00	1	Nut-Lock
20	1-633396	3	Clip-Loom
21	3256-22	1	Washer-Flat
22	33113-020	1	Screw-HH
23	32144-70	1	Screw-HWHTF
24	322-3	2	Screw-HH

Ref	Part No.	Qty.	Description
25	32128-20	2	Nut-HF
26	1-643037	1	Gauge-Voltmeter
27	1-643021	1	Gauge-Temperature
28	1-633181	3	Plate-Tapped
29	1-633111	1	Switch
30	3290-500	8	Screw-PPH
31	1-513051	2	Switch-Open, Normally
32	32128-33	1	Nut-HF
33	1-323229	1	Clip-Loom
34	321-2	1	Screw-HH
35	321-4	3	Screw-HH
36	3296-42	2	Nut-Lock, NI
37	1-513762	1	Clip-Loom
38	1-816001	1	Fuse-Blade Type, 20 Amp
39	103-1368	1	Fuse-40 Amp
40	103-0949	1	Sender-Temperature
41	3256-14	2	Washer-Flat
42	103-1340	1	Insulator-Terminal, Battery
43	103-1312	2	Bolt-Holddown
44	103-1311-03	1	Holddown-Battery
45	1-543792	2	Wingnut
46	1-807513	2	Bolt-CARR
47	103-5218	1	Module-Delay, Seat
49	103-1320	1	Indicator-Led, Amber



Electrical Assembly (continued)


Ref	Part No.	Qty.	Description
50	1-513374	1	Meter-Hour
51	103-5221	1	Switch-PTO
52	104-2541	1	Switch ASM
52:1	218-461	1	Nut-HH
52:2	3254-5	1	Washer-Tooth
54	63-8360	2	Key-Ignition
55	107-9309	1	Decal-Instructions, Charging



Assemblies include all parts shown in frames.

Cylinder Assembly


Ref	Part No.	Qty.	Description				
1	107-9891	1	Cylinder ASM				
2	99-9003	1	Seal-Oil				
3	99-9008	1	Plug-Welch				
4	107-9892	1	Plug-Welch (Cam)				
5	99-9006	1	Screw-Hex				
6	99-9005	1	Screw-Hex				
7	107-9893	1	Plate-End, Rear				
8	99-9004	1	Screw-Hex				
9	99-9002	1	Bushing				
10	99-9012	1	Pin-Locating				
11	99-9013	1	Pin-Locating				
12	99-9014	1	Pin-Locating				
13	99-9022	1	Retainer-Seal				
14	99-9007	1	Stud-Metric				
16	107-9894	1	Kit-Label				
17	99-9017	1	Filter-Oil				
18	105-9337	1	Adapter-Filter, Oil				
19	103-1384	1	Manual-Engine				
20	99-9020	1	Nozzle-Oil				
21	99-9021	1	Gasket-Retainer				



Assemblies include all parts shown in frames.


Crankshaft Assembly

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	105-9339	1	Crankshaft	26	99-9046	1	Set-Bearing, Main (.010 Undersized)
3	99-9024	1	Flywheel				
4	107-9895	1	Piston ASM				
5	107-9896	1	Piston ASM (Oversize)				
6	105-9340	1	Ring Set				
7	99-9269	1	Ring Set (.010 In Oversized)				
8	99-9607	1	Lock-Pin, Piston				
9	99-9608	1	Rod-Connecting				
10	99-9030	1	Screw-Rod, Connecting				
11	99-9035	1	Washer-Thrust				
12	99-9036	1	Washer-Thrust (.005 In Oversized)				
13	99-9034	1	Nut-Hex				
14	107-9897	1	Screw-Hex				
15	99-9037	1	Pin-Locating				
16	99-9609	1	Gear-Drive				
17	99-9032	1	Screw-Hex				
20	99-9040	1	Plate-Gear, Idler				
21	99-9041	1	Pulley-Crankshaft				
22	99-9042	1	Bearing-Rod				
23	99-9043	1	Set-Bearing, Rod				
24	99-9044	1	Set-Bearing, Rod (.010 Undersized)				
25	99-9045	1	Set-Bearing, Main (Set Of 8)				




Cylinder Head Assembly

Ref	Part No.	Qty.	Description				
1	105-9341	1	Head-Cylinder				
2	107-9898	1	Gasket-Head, Cylinder				
3	105-9342	1	Tube-Breather				
4	99-9614	1	Screw-Metric				
5	99-9052	1	Cap-Fill, Oil				
6	99-9060	1	Plug-Welch				
7	99-9008	1	Plug-Welch				
8	99-9058	1	Stud-Metric				
9	99-9059	1	Stud-Metric				
10	99-9057	1	Stud-Metric				
11	99-9063	1	Washer-Seal				
12	99-9067	1	Retainer				
13	99-9054	1	Screw-Hex				
14	99-9061	1	Nut-Hex, Metric				
15	99-9101	1	Stud-Arm, Rocker				
16	99-9070	1	Bushing-Guide				
17	99-9073	1	Gasket-Cover, Rocker				
18	100-6402	1	Cover-Rocker				
19	107-9899	1	Emmision Label Kit				
20	99-9076	1	Bracket-Lifting				
21	99-9077	1	Bracket-Lifting				
22	99-9055	1	Stud-Metric				



Injection Pump Assembly

Ref	Part No.	Qty.	Description				
1	99-9622	1	Clamp-Casing				
2	99-9056	1	Screw-Hex				
3	99-9616	1	Screw-Hex				
4	99-9689	1	Gear-Drive				
5	99-9625	1	Clamp				
6	99-9626	1	Bracket-Support				
7	99-9628	1	Clamp-Swivel				
8	99-9629	1	Hose / Clamp ASM				
9	99-9630	1	Plug-Glow				
10	99-9631	1	Strap-Plug, Glow				
11	99-9632	1	Nozzle-Injector				
12	99-9633	1	Seat-Injector				
13	105-9345	1	Nut				
14	99-9690	1	Pipe-Injector, No. 1				
15	99-9634	1	Pipe-Injector, No. 2				
16	99-9635	1	Pipe-Injector, No. 3				
17	105-9334	1	Pump-Injection				
18	99-9637	1	Pipe-Return, Fuel				
19	99-9618	1	O-Ring				
20	99-9620	1	Nut-Hex, Metric				
21	99-9619	1	Nut-Hex, Metric				
22	105-9343	1	Seat-Injector				




Assemblies include all parts shown in frames.

Camshaft Assembly

Ref	Part No.	Qty.	Description
1	99-9638	1	Valve-Exhaust
2	99-9639	1	Valve-Intake
3	99-9640	1	Spring-Valve
4	99-9640	1	Spring-Valve
5	99-9084	1	Retainer-Valve
6	99-9086	1	Keeper-Valve (Set)
7	99-9087	1	Keeper-Valve (Set Of 6)
8	99-9088	1	Tappet-Valve
9	99-9097	1	Shaft-Cam
10	99-9675	1	Key-Timing
12	99-9092	1	Adjuster-Arm, Rocker
13	99-9093	1	Washer-Spacer
14	99-9094	1	Cap-Valve
15	99-9090	1	Screw-Metric
16	99-9641	1	Gear-Cam
17	99-9085	1	Screw-Metric
18	99-9096	1	Seat-Spring, Valve
19	99-9099	1	Retainer
20	99-9643	1	Seal-Valve
21	99-9103	1	Rod-Push
22	99-9104	1	Arm-Rocker
23	99-9106	1	Shaft-Arm, Rocker
24	99-9107	1	Support-Arm, Rocker
25	99-9108	1	Spring-Shaft, Rocker


Ref	Part No.	Qty.	Description
26	99-9109	1	Retainer-Camshaft
27	99-9083	1	Screw-Hex
28	99-9079	1	Washer-Flat
29	99-9091	1	Nut-Hex, Metric



Assemblies include all parts shown in frames.

Oil Pan Assembly


Ref	Part No.	Qty.	Description				
1	99-9247	1	Plug-Drain, Oil				
2	107-9908	1	Switch-Pressure, Oil				
3	99-9249	1	Washer-Seal				
4	99-9111	1	Screw-Hex				
5	99-9272	1	*obs* Dipstick				
6	99-9118	1	Tube-Dipstick				
7	99-9114	1	Nut-Hex, Metric				
8	99-9112	1	Stud-Metric				
9	99-9113	1	Nut-Hex, Metric				
10	99-9116	1	Screen-Pump, Oil				
11	99-9111	1	Screw-Hex				
12	99-9120	1	Gasket-Strainer, Oil				
13	99-9121	1	Gasket-Pan, Oil				
14	99-9241	1	Pan-Oil				



Assemblies include all parts shown in frames.


Gear Cover Assembly

Ref	Part No.	Qty.	Description				
1	107-9900	1	Seal-Oil				
2	99-9651	1	Screw-Hex				
3	99-9128	1	Screw-Hex				
4	99-9129	1	Screw-Hex				
5	99-9652	1	Gear Cover ASM				
6	99-9653	1	Gasket-Cover, Gear				
7	99-9014	1	Pin-Locating				
8	99-9114	1	Nut-Hex, Metric				



Gear Housing Assembly


Ref	Part No.	Qty.	Description				
1	99-9653	1	Gasket-Cover, Gear				
2	99-9136	1	Gasket-Cover, Gear				
3	99-9655	1	Housing-Gear				
4	99-9142	1	Valve-Relief, Oil				
5	99-9656	1	Gear-Drive				
6	99-9007	1	Stud-Metric				
7		1	Gerotor				
8	99-9137	1	Stud-Metric				
9	99-9654	1	Stud-Metric				
10	99-9135	1	Screw-Hex				
11	99-9134	1	Screw-Hex				
12	99-9133	1	Screw-Hex				



Assemblies include all parts shown in frames.

Water Pump Assembly


Ref	Part No.	Qty.	Description				
1	99-9155	1	Thermostat				
2	99-9156	1	Belt-V				
3	107-9902	1	Switch-Temperature, Water				
4	99-9159	1	Plug				
5	99-9158	1	Plug				
6	99-9163	1	Gasket-Outlet				
7	99-9164	1	Pulley-Pump				
8	99-9165	1	Housing-Outlet				
9	99-9166	1	Gasket-Housing, Inlet				
10	99-9167	1	Housing-Inlet				
11	99-9168	1	Gasket-Pump, Water				
12	99-9659	1	Pump-Water				
13	99-9004	1	Screw-Hex				
14	99-9151	1	Screw-Hex				
15	99-9153	1	Nut-Hex, Metric				
16	99-9004	1	Screw-Hex				
17	99-9152	1	Screw-Metric				



Assemblies include all parts shown in frames.

Manifold Assembly



Ref	Part No.	Qty.	Description
1	99-9661	1	Manifold-Intake
2	99-9662	1	Gasket-Intake
3	99-9004	1	Screw-Hex
4	99-9660	1	Screw-Hex
5	99-9174	1	Stud-Manifold, Exhaust
6	99-9177	1	Manifold-Exhaust
7	106-1855	1	Gasket-Exhaust
8	99-9114	1	Nut-Hex, Metric
9	99-9175	1	Nut-Hex, Metric
10	99-9176	1	Nut-Hex



Assemblies include all parts shown in frames.

Starter Motor and Alternator Assembly

Ref	Part No.	Qty.	Description
1	99-9207	1	Motor-Starter
2	99-9206	1	Nut-Hex, Metric
3	99-9209	1	Alternator
4	106-1952	1	Strap-Adjusting
5	99-9203	1	Screw-Hex
6	99-9666	1	Module
7	99-9211	1	Bracket-Support
8	99-9201	1	Screw-Hex
9	99-9205	1	Screw-Hex, Metric
10	99-9202	1	Screw-Hex
11	107-9903	1	Screw-Hex, Metric
12	99-9114	1	Nut-Hex, Metric



Assemblies include all parts shown in frames.

Gasket Assembly

Ref	Part No.	Qty.	Description
1	99-9003	1	Seal-Oil
2	107-9898	1	Gasket-Head, Cylinder
3	107-9900	1	Seal-Oil
4	99-9662	1	Gasket-Intake
5	99-9653	1	Gasket-Cover, Gear
6	99-9136	1	Gasket-Cover, Gear
7	99-9063	1	Washer-Seal
8	99-9249	1	Washer-Seal
9	107-9906	1	Gasket Set
10	99-9643	1	Seal-Valve
11	106-1855	1	Gasket-Exhaust
12	99-9073	1	Gasket-Cover, Rocker
13	107-9907	1	Valve Overhaul Kit
14	99-9163	1	Gasket-Outlet
15	99-9166	1	Gasket-Housing, Inlet
16	99-9168	1	Gasket-Pump, Water
17	99-9120	1	Gasket-Strainer, Oil
18	99-9121	1	Gasket-Pan, Oil
19	99-9021	1	Gasket-Retainer

Attachments and Accessories

For 74269CP - Z590-D Z Master, With 72in TURBO FORCE Side Discharge Mower

Product Name	Model/Part
Winter Hydraulic Filter	1-633752
Blade-Mid Flow, 24.5 Inch	105-7711-03
Blade-Lo Flow, 24.5 Inch	105-7712-03
Blade-Atomic, 24.5 Inch	105-7719-03
Blade-Recycler, 24.5 Inch	105-7778-03
72 Inch Recycler Kit	107-1612
Striping Kit	107-1630
Light Kit	107-9880
6 Pack Blade, 24.5 Inch Hi-Flow	108-1120
6 Pack Blade, 24.5 Inch Atomic	108-1126
Roller Striping Kit	108-2162
6 Pack-Blade, 24.5 Inch Mid-Flow	110-0404
6 Pack-Blade, 24.5 Inch Lo-Flow	110-0410
Hitch Kit	110-0444
Cool Top ROPS Mounted Fan	110-1996
Bimini Sunshade	110-5726
Channel Reinforcement Kit	112-8674
Wheel Spacer Kit	112-8699
Chute Gate Kit	78521
72 Inch Deck Triple Bag Assembly	78535
72 Inch Blower and Drive Kit	78539
Filter Minder Gauge	99-4664

