



DH 210 Lawn Tractor

Model No. 74582 - 280000001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Description	Page	Description	Page
Frame Assembly	 4	Grass Collector Assembly No. 106-5760	 25
Front Axle Assembly	 6	Tunnel Assembly	 26
Steering Assembly	 7	Deck Housing Assembly	 27
Hood Assembly	 8	Cutting Pan and Bag on Demand Assembly	 28
Engine Assembly	 9	Cutting Pan and Drive System Assembly	 29
Operation - Brake and Bypass Assembly	 10	Mower Lift Assembly	 31
Operation - Travel Pedal Assembly	 11	Harness Assembly	 32
Transmission Drive Assembly	 12	Electrical Switch No. 1 Assembly	 33
Control Shaft Assembly Transmission		Electrical Switch No. 2 Assembly	 34
Assembly No. 114-3155	 14	Electrical Switch No. 3 Assembly	 35
Differential Gear Assembly Transmission		Cylinder Assembly Briggs and Stratton Model	
Assembly No. 114-3155	 15	31G777-0130-E1	 36
Final Pinion Assembly Transmission		Cylinder Head Assembly Briggs and Stratton	
Assembly No. 114-3155	 16	Model 31G777-0130-E1	 37
Axle Shaft Assembly Transmission Assembly		Crankshaft Assembly Briggs and Stratton	
No. 114-3155	 17	Model 31G777-0130-E1	 38
Brake Assembly Transmission Assembly No.		Crankcase Assembly Briggs and Stratton	
114-3155	 18	Model 31G777-0130-E1	 39
Fan Pulley Assembly Transmission Assembly		Carburetor Assembly (Nikki) Briggs and	
No. 114-3155	 19	Stratton Model 31G777-0130-E1	 40
Range Shift Assembly Transmission		Governor Assembly Briggs and Stratton	
Assembly No. 114-3155	 20	Model 31G777-0130-E1	 41
Center Case Assembly Transmission		Blower Housing Assembly Briggs and Stratton	
Assembly No. 114-3155	 21	Model 31G777-0130-E1	 42
Pump Shaft Assembly Transmission		Starter Assembly Briggs and Stratton Model	
Assembly No. 114-3155	 22	31G777-0130-E1	 43
Motor Shaft Assembly Transmission		Gasket Set Briggs and Stratton Model	
Assembly No. 114-3155	 23	31G777-0130-E1	 44
Transaxle Case Assembly Transmission		Carburetor Overhaul Kit (Nikki) Briggs and	
Assembly No. 114-3155	 24	Stratton Model 31G777-0130-E1	 45
		Attachments and Accessories List	 46


Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

AR.	as required	HYD.	hydraulic
ASM.	assembly	LH.	left hand
BBC.	blade brake clutch	NI.	nylon insert
CARR.	carriage	NPTF.	national pipe thread fine
DEG.	degrees	PFH.	phillips flat head
EXT.	external	PPH.	phillips pan head
FH.	flat head	PPHTF.	phillips pan head thread forming
GA.	gauge	PRH.	phillips round head
HD.	heavy-duty	PTH.	phillips truss head
HF.	hex flange	PTO.	power-take-off
HH.	hex head	RH.	right hand
HHF.	hex head flange	ROPS.	roll-over protection system
HHFTF.	hex head flange thread forming	SFH.	slotted fillister head
HJ.	hex jam	SHH.	slotted hex head
HLH.	hex lag head	SHWH.	slotted hex washer head
HOC.	height-of-cut	SPH.	slotted pan head
HSBH.	hex socket button head	SQH.	square head
HSFH.	hex socket flat head	SRH.	slotted round head
HSH.	hex socket head	STD.	standard
HWH.	hex washer head	TAP.	self tapping
HWHTF.	hex washer head thread forming	TTH.	torx truss head


Footnotes

- | | | | |
|---|--|---|---|
| ❶ | Not serviced separately | ❷ | Obtain from your local Briggs & Stratton dealer |
| ❸ | Included in Carburetor Overhaul Kit (Ref. No. 121) | ❹ | Included in Engine Gasket Set (Ref. No. 358) |
| ❺ | Included in Valve Gasket Set (Ref. No. 1095) | ❻ | For Service of Nikki Carburetors |




Frame Assembly

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	104-2926	2	Bracket-Support, Seat	27	104-2943	18	Washer-Flat
2	42-9850	12	Washer-Lock, Spring	28	104-2944	1	Footrest ASM
4	322-3	4	Screw-HH	29	104-2945	2	Spring-Seat
5	104-2929	1	Support-Seat	30	104-2946	2	Washer-Plain
6	104-2930	2	Bolt-Carriage	31	33114-020	8	Screw-HH
7	104-2931	2	Washer-Flat	32	104-2948	6	Bolt-Carriage
8	104-2932	2	Spring-Seat	33	104-2857	2	Cap-Hub
9	104-2933	2	Spacer-Split	34	104-2951	4	Washer-Rubber
10	107-2214	1	Seat ASM	35	104-2952	8	Washer-Rubber
11	104-2934	1	Bracket	36	107-8915	1	Bracket-Seat, RH
12	104-2935	2	Bushing	37	107-8916	1	Bracket-Seat, LH
13	33023-00	2	Nut-Lock	38	104-3195	2	Screw
14	104-2936	2	Washer-Spring	39	104-3237	1	Decal-Brake, Parking
15	104-2937	2	Knob-Adj.	40	104-3238	1	Decal-Starting
16	107-8948	1	Chassis-Frame	41	104-3241	1	Decal-Operation, Hydro
18	104-2939	2	Screw-Support, Seat	42	104-3242	1	Decal-Bag To Frame
19	33094-00	9	Washer-Plain	43	104-2903	1	Decal-Instruction
20	33024-00	7	Nut-Lock	44	99-5340	1	Decal-Switch
21	104-2940	2	Screw-HSFH	45	93-7276	1	Decal-Danger
22	104-2941	2	Washer-Finish	46	60-6910	6	Screw
23	114-3247	1	Fender-Rear Body	47	104-3239	1	Decal-HOC, LH
24	33095-00	4	Washer-Flat	48	104-3240	1	Decal-HOC, RH
25	33025-00	4	Nut-Lock	49	106-8552	1	Decal-Operation
26	87-5140	12	Nut-Lock	50	107-8975	2	Decal-Tower



Frame Assembly (continued)


Ref	Part No.	Qty.	Description
52	107-8924	2	Shim-Seat
53	110-8689	1	Tank-Fuel
54	110-8691	1	Protector-Filler Neck
55	110-8697	1	Cap-Fuel, Assembly
56	110-8684	1	Bracket-Fuel, Tank
62	110-8690	2	Strip-Rubber, Fuel Tank
64	107-8950	1	Grommet
65	110-8683	1	Grommet
68	33114-030	2	Screw-HH



Front Axle Assembly


Ref	Part No.	Qty.	Description
1	33116-090	1	Screw-HH
2	33115-080	2	Screw-HH
3	104-2851	2	Spacer
4	104-2904	3	Fitting-Grease
5	104-2905	4	Washer-Flat
6	104-2891	2	Clip-Spring
7	104-2852	1	Axle-Front
8	104-2906	2	Washer-Flat
10	104-2890	2	Bushing-Axle, Front
11	104-2907	1	Nut-Self Locking
12	104-2855	1	Rod-Tie, Front Axle
13	104-2856	1	Key-Woodruff
14	33023-00	1	Nut-Lock
15	104-2857	2	Cap-Hub
16	104-2891	2	Clip-Spring
17	107-8998	2	Retainer-Cap, Hub
18	114-3241	1	Spindle-Front, Left
19	33113-045	1	Screw-HH
20	104-2862	1	Lever-Spindle, Steering
21	33025-00	6	Nut-Lock
22	114-3242	1	Spindle-Front, Right
23	106-5757	4	Washer
24	114-3240	2	Wheel-Complete
24:1	99-2336	1	Tire

Ref	Part No.	Qty.	Description
24:2	114-3243	1	Rim-Front, Complete
24:99	105293	1	Tube-Inner
24:99	110513	2	Bearing-Wheel
25	104-2876	2	Joint-Ball, Angle



Steering Assembly


Ref	Part No.	Qty.	Description				
1	33025-00	4	Nut-Lock				
2	104-2876	2	Joint-Ball, Angle				
3	106-5757	4	Washer				
4	33024-00	4	Nut-Lock				
5	33094-00	6	Washer-Plain				
6	33114-020	2	Screw-HH				
7	104-2891	1	Clip-Spring				
8	104-2877	1	Spacer-Upper				
9	104-2878	2	Bearing-Spherical				
10	104-2879	1	Spacer-Lower				
11	106-5773	1	Shaft-Steering				
12	33026-00	1	Nut-Lock				
13	33025-00	1	Nut-Lock				
14	105-1238	1	Plate-Steering				
15	104-2883	1	Gear-Sector				
16	104-2910	1	Screw-Hex				
17	104-2886	1	Link-Drag				
18	105-1239	1	Bolt-Shoulder				
19	105-1240	1	Pivot-Steering				
20	105-1241	1	Bushing				
21	33114-016	2	Screw-HH				
22	104-2865	2	Stirrups-Locking				
23	108-8892	1	Washer				



Hood Assembly

Ref	Part No.	Qty.	Description
1	107-2216	1	Support-Bumper
2	107-8988	1	Hood-Assembly
2:2	107-8913	1	Decal-Hood, RH
2:3	107-8902	1	Decal-Hood, LH
2:4	95-4248	1	Decal
2:5	107-8983	1	Lens-Headlamp, RH
2:6	107-8984	1	Lens-Headlamp, LH
3	110-8679	1	Tray-Battery
7	104-2962	1	Brace
8	33026-00	1	Nut-Lock
9	98-1471	1	Wheel-Steering
9:1	98-1468	1	Cover-Wheel, Steering
11	66-0120	1	Knob
12	87-5140	10	Nut-Lock
13	106-4166	1	Cable-Throttle And Choke
15	104-2968	1	Panel-Dash
16	114-3132	1	Brace
17	104-2971	1	Bracket
18	104-2972	1	Panel-Right
19	104-2973	1	Panel-Left
20	92-6960	2	Latch-Hood
21	33114-020	4	Screw-HH
22	104-2946	4	Washer-Plain
23	104-2974	1	Bar-Safety


Ref	Part No.	Qty.	Description
24	104-2975	1	Spring-Hood
25	107-2218	1	Guard-Muffler
26	42-9850	4	Washer-Lock, Spring
27	106-5759	4	Screw
28	106-5758	1	Washer
29	104-2980	2	Screw
31	107-8918	6	Screw
33	104-2985	6	Nut-Hex
34	107-8943	2	End Cap-Tube
36	104-3236	1	Decal-Choke/Throttle/Key
37	98-1459	1	Decal
38	104-3235	1	Decal-PTO



Engine Assembly

Ref	Part No.	Qty.	Description
1	322-3	2	Screw-HH
2	42-9850	6	Washer-Lock, Spring
3	104-3221	1	Tube-Exhaust
4	88-4410	1	Gasket-Muffler
1 2 6		1	Briggs And Stratton, 31G777-0130-E1
10	110-8692	1	Line-Fuel
11	104-3224	1	Valve-Tank, Fuel
12	104-3212	4	Clamp-Line, Fuel
13	104-3213	1	Line-Fuel
14	33024-00	4	Nut-Lock
15	33094-00	4	Washer-Plain
16	33114-035	4	Screw-HH
17	104-3222	1	Cover-Front
18	104-2931	2	Washer-Flat
19	106-5763	2	Screw
20	33094-00	4	Washer-Plain
21	33114-020	4	Screw-HH
22	106-5763	4	Screw
23	104-3229	1	Muffler
24	104-3214	1	Guard-Muffler, LH
25	104-3215	1	Guard-Muffler, RH
26	33013-00	1	Nut-Hex
27	104-3186	1	Washer-Spring


Ref	Part No.	Qty.	Description
28	33113-016	1	Screw-HH
29	106-5763	1	Screw
30	104-2931	1	Washer-Flat
32	107-4906	1	Decal-Engine
33	105-1242	1	Cover-Manifold, Exhaust
34	33093-00	1	Washer-Flat



Operation - Brake and Bypass Assembly


Ref	Part No.	Qty.	Description
1	104-2992	1	Lever-Spring
2	104-2984	1	Washer
3	104-2985	1	Nut-Hex
4	33094-00	5	Washer-Plain
5	104-2993	1	Bracket-Rod, Brake
6	108-8708	1	Cap-Bypass Lever, Hydro
7	104-2995	1	Rod-Lever, Bypass
8	104-3324	1	Lever-Bypass
9	104-3193	2	Washer
10	104-2997	1	Pin-Cotter
11	104-3018	1	Pad-Pedal
12	114-3246	1	Pedal-Brake
14	33024-00	2	Nut-Lock
15	104-3002	1	Spring-Brake
16	104-3003	1	Rod-Connecting, Brake
17	104-3004	1	Shaft-Brake
18	104-3005	1	Spring-Brake, Hand
19	104-3006	1	Lever-Brake, Hand
20	33114-020	1	Screw-HH
21	104-3007	1	Clamp-Lever, Parking Brake
22	104-3008	2	Pin-Spring
23	104-3009	1	Screw-Hex
24	104-3016	2	Pin-Cotter
25	104-3011	1	Bracket-Rod, Brake

Ref	Part No.	Qty.	Description
26	104-3012	1	Spring
27	104-3323	1	Plate-Bypass
28	104-3014	2	Stirrup
29	104-3015	1	Stirrup
30	33095-00	2	Washer-Flat
31	104-3247	1	Cap
32	106-5768	1	Washer
33	106-5769	1	Washer
34	106-5770	4	Washer
35	106-5771	1	Washer



Operation - Travel Pedal Assembly


Ref	Part No.	Qty.	Description				
1	104-3017	1	Pedal-Rear, Travel				
2	104-3018	2	Pad-Pedal				
3	114-3248	1	Pedal-Travel, Forward				
5	104-3021	1	Pad-Travel				
6	104-3022	1	Rod-Tie				
7	104-3023	1	Shaft-Diagonal				
8	104-3024	1	Link-Formed				
9	104-3025	1	Shaft-Diagonal				
10	104-3026	1	Pin				
11	33095-00	3	Washer-Flat				
12	104-3016	2	Pin-Cotter				
13	104-3027	2	Pin-Cotter				
14	104-3028	1	Spacer				
15	104-3029	1	Pin				
16	33014-00	2	Nut-Hex				
17	33114-060	1	Screw-HH				
18	104-3008	2	Pin-Spring				
19	104-3030	1	Pin-Spring				
20	104-3031	1	Washer				
21	33114-025	1	Screw-HH				



Transmission Drive Assembly


Ref	Part No.	Qty.	Description
1	104-2887	4	Pully-Idler
2	104-2888	1	V-Belt-Traction
3	114-3155	1	Transmission
4	104-2857	2	Cap-Hub
5	104-2891	2	Clip-Spring
6	104-3206	2	Washer
7	104-2892	2	Key-Square
8	104-2895	2	Spacer-Axle
9	33114-080	4	Screw-HH
10	33094-00	19	Washer-Plain
11	33024-00	14	Nut-Lock
12	33115-040	3	Screw-HH
13	33095-00	7	Washer-Flat
14	104-2896	4	Bushing-Idler
15	33025-00	5	Nut-Lock
16	104-2897	1	Spring
17	33025-00	1	Nut-Lock
18	33114-020	1	Screw-HH
19	104-2898	1	Retainer
20	104-2899	1	Key-Square
21	3212-10	1	Screw-HH
22	93-9043	1	Washer-Spring, Belleville
23	104-3334	1	Clutch-Electric
24	104-2911	1	Pulley-Engine

Ref	Part No.	Qty.	Description
25	104-2912	1	Arm-Idler
26	104-2913	1	Pulley-Idler
27	104-2896	1	Bushing-Idler
28	33115-040	1	Screw-HH
29		2	Tire And Wheel ASM
29:1	99-2994	1	Tire
29:2	107-8932	1	Wheel ASM
29:2:1		1	Rim
29:2:2	106-8596	1	Valve-Tire
30	108-8718	2	Hub-Wheel
30:1	108-8717	4	Nut-Lug
32	106-8594	1	Bracket-Right
33	106-8593	1	Bracket-Left
34	33115-045	1	Screw-HH
35	104-2925	1	Sleeve
36	104-3343	2	Plate-Reinforcing
37	104-2904	1	Fitting-Grease
38	104-3327	1	Bar ASM
39	104-3328	1	Arm-Switch
41	104-3326	1	Tenon
42	104-3329	1	Roller
45	104-3341	1	Stirrup
46	104-3014	1	Stirrup
47	104-3344	2	Screw-Thread Forming



Control Shaft Assembly
Transmission Assembly No. 114-3155


Ref	Part No.	Qty.	Description				
1	114-3181	1	Shaft-Control				
2	104-3292	1	Fulcrum-Eccentricity				
3	114-3217	1	Spring-Torsion				
4	114-3180	1	Arm-Control				
5	104-3342	1	Arm-Transaxle				
6	104-3296	1	Plate-Jerky				
7	93-0417	1	Washer				
8	114-3182	1	Pin-Cotter				
9	104-3297	1	Pin				
10	93-0411	1	Pin-Roll				
11	104-3298	2	Packing				
12	93-0420	1	Nut				



Differential Gear Assembly


Transmission Assembly No. 114-3155

Ref	Part No.	Qty.	Description
1	104-3299	1	Differential Gear Kit
2	104-3301	1	Gear-Final



Final Pinion Assembly Transmission Assembly No. 114-3155


Ref	Part No.	Qty.	Description
1	104-3302	1	Collar-Final Pinion
2	104-3303	1	Shaft-Reduction
3	104-3304	2	Washer
4	104-3305	1	Gear-Reduction
5	104-3306	1	Pinion-Final



Axle Shaft Assembly

Transmission Assembly No. 114-3155


Ref	Part No.	Qty.	Description
1	104-3307	1	Shaft-Axle, LH
2	104-3308	1	Shaft-Axle, RH
3	104-3309	2	Washer-Thrust
4	104-3310	2	Ring
5	104-3311	2	Seal
6	104-3312	2	Bushing



Brake Assembly

Transmission Assembly No. 114-3155


Ref	Part No.	Qty.	Description				
1	104-3313	1	Ring				
2	104-3314	1	Shoe-Brake				
3	104-3315	1	Arm-Brake				
4	104-3316	1	Shaft-Brake				
5	104-3317	1	Spring-Return, Brake				
6	104-3318	1	Actuator-Brake				
7	92-0767	1	Pin				
8	93-0418	2	O-Ring				
9	104-3319	2	Pin				



Fan Pulley Assembly

Transmission Assembly No. 114-3155


Ref	Part No.	Qty.	Description
1	104-3320	1	Collar-Spline
2	104-3197	1	Pulley-Transmission
3	104-3199	1	Fan- Transmission
4	104-3321	1	Washer-Lock
5	93-0387	1	E-Ring
6	104-3198	1	E-Ring



Range Shift Assembly


Transmission Assembly No. 114-3155

Ref	Part No.	Qty.	Description
1	104-3286	2	Metal-Thrust
2	104-3287	1	Plate-Swash
3	104-3288	1	Bearing
4	104-3289	1	Plate-Thrust, A
5	104-3290	1	Plate-Thrust, B




Center Case Assembly
Transmission Assembly No. 114-3155

Ref	Part No.	Qty.	Description				
1	104-3267	1	Case-Center				
2	104-3268	2	Pin-Knock				
3	104-3269	1	Plug				
4	93-0419	1	Packing				
5	104-3270	1	Pin				
6	104-3271	1	Filter				
7	104-3272	3	Bolt				
8	104-3273	2	Valve				
9	104-3274	2	Spring				
10	104-3275	2	Filter				
11	104-3257	1	Magnet				




Motor Shaft Assembly
Transmission Assembly No. 114-3155

Ref	Part No.	Qty.	Description				
1	104-3279	1	Housing				
2	104-3280	1	Bearing				
3	104-3281	1	Block-Cylinder				
4	104-3282	1	Washer				
5	104-3283	1	Shaft-Motor				
6	93-0373	1	Ring-Snap				
7	104-3284	1	Motor-Gear				
8	104-3285	1	Bearing				



Transaxle Case Assembly
Transmission Assembly No. 114-3155


Ref	Part No.	Qty.	Description				
1	104-3251	1	Transaxle Case Set				
2	104-3252	1	Housing-Upper				
3	104-3253	1	Housing-Lower				
4	104-2914	1	Tank-Reservoir, With Cap				
5	104-3254	1	Tube				
6	104-3255	2	Clamp-Miniature				
7	104-3256	1	Valve-Vent, 15				
8	104-3257	1	Magnet				
9	104-3258	1	Holder-Magnet				
10	104-3259	1	Seal-Oil				
11	93-0396	1	Spring				
12	104-3260	1	Shaft-Bypass				
13	104-3261	1	Lever-Bypass				
14	104-3262	1	Ring				
15	104-3263	1	Plug-Bore				
16	93-0360	1	Ring				
17	104-3264	1	Pin				
18	104-3265	1	Pin				
19	93-0419	2	Packing				
20	93-0361	1	Seal				
21	93-0363	14	Screw-TAP				
22	104-3266	2	Screw-TAP				



Grass Collector Assembly No. 106-5760


Ref	Part No.	Qty.	Description
1	106-5760	1	Collector ASM
2	60-6910	2	Screw
3	87-5140	22	Nut-Lock
4	104-3033	1	Spring-Coll, Interlock Switch
5	106-5761	1	Bracket-Spring
6	104-3035	1	Grip-Handle
7	107-8917	1	Lever-Dump
8	104-3037	1	Front Frame ASM
9	104-3038	1	Bag-Grass
10	104-3039	1	Support-Corner, Right
11	104-2943	8	Washer-Flat
12	87-5150	4	Bolt
13	52-6430	14	Washer
14	104-3041	10	Screw-Hex
15	104-3042	1	Support-Corner, Left
16	104-3043	1	Brace-Connecting
17	104-3044	2	Screw-Hex
18	104-3045	1	Bottom Frame ASM
19	33024-00	1	Nut-Lock
20	104-3046	2	Brace
21	33114-025	1	Screw-HH
22	104-2948	4	Bolt-Carriage
23	33114-020	2	Screw-HH
24	42-9850	2	Washer-Lock, Spring

Ref	Part No.	Qty.	Description
25	104-2946	4	Washer-Plain
26	104-3047	1	Top Frame ASM
27	104-3048	1	Handle-Lift
28	106-5762	1	Cover-Collector
29	106-5763	1	Screw
30	104-2952	6	Washer-Rubber
34	104-3242	1	Decal-Bag To Frame




Tunnel Assembly

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	106-8562	1	Tunnel	27	104-3070	1	Shield-Protective
36	104-2961	1	Screw	28	104-3336	1	Shield-Adjustable
2	104-2985	4	Nut-Hex	29	104-3335	1	Hopper-Receiving
3	104-3055	1	Plate-Support	31	104-3074	1	Overload Switch ASM
4	104-3056	1	Seal-Rubber	36	104-2961	1	Screw
6	33114-020	2	Screw-HH	37	33113-012	4	Screw-HH
7	68-9410	2	Screw-Flange	38	33023-00	4	Nut-Lock
8	104-2983	1	Screw	39	32103-28	2	Nut-Wing
9	104-3058	3	Screw-SFH	40	33093-00	6	Washer-Flat
10	104-3059	1	Cover-Switch	41	104-2948	4	Bolt-Carriage
11	104-3060	2	Bolt-Carriage	42	87-5140	4	Nut-Lock
12	104-3061	4	Screw	43	104-3243	1	Decal-Bypass, Hydro
13	104-3062	1	Support-Collector, Right	44	104-2853	1	Decal-Position, Bagging
14	104-3063	1	Support-Collector, Left	45	104-3347	2	Plate-Reinforcing
15	104-3064	1	Hitch-Tow	46	104-3348	2	Washer-Spring
17	104-3066	1	Collector Plate ASM	47	106-5772	1	Bushing
18	33095-00	8	Washer-Flat	48	106-8575	2	Screw-HH
19	33024-00	8	Nut-Lock	49	110-8688	1	Bracket-Support, Fuel Tank
20	104-3067	1	Support-Hitch, Tow				
21	104-3068	6	Screw-Hex				
23	106-8597	1	Support-Tunnel, Left				
24	106-8598	1	Support-Tunnel, Right				
25	106-8599	1	Shield-Rubber				
26	104-3069	1	Bracket-Shield, Protective				



Deck Housing Assembly


Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	33115-090	4	Screw-HH	23	106-8566	1	Shaft-Blade, Right
2	104-3080	4	Wheel-Gauge	24	106-6533	2	Stiffener-Blade
3	33025-00	4	Nut-Lock	25	106-5767	4	Washer
4	110-9071	1	Deck ASM	26	106-6530	2	Spacer
4:2	93-7824	2	Decal-Danger				
4:3	106-8563	1	Decal-Recycler				
5	104-3082	6	Nut-Lock, HF				
6	107-8992	2	Housing-Spindle				
7	33094-00	6	Washer-Plain				
8	33114-020	6	Screw-HH				
9	104-3084	2	Support-Ring				
10	104-3085	6	Bolt-HHF				
11	104-3086	1	Key				
12	106-8565	1	Shaft-Blade, Left				
13	106-5797	1	Bolt-HH, Blade				
14	106-8557	1	Blade-RH				
15	106-8558	1	Blade-LH				
16	106-5798	1	Bolt-Blade, HH				
17	106-6532	2	Washer-Blade				
18	104-3093	4	Pin-Shear, Grooved				
19	106-4185	2	Adapter-Blade				
20	104-3095	2	Ring-Locking				
21	104-6325	4	Bearing-Ball				
22	104-3097	3	Key-Square				



Cutting Pan and Bag on Demand Assembly

Ref	Part No.	Qty.	Description
1	106-8583	1	Cover-Lever, Foot
2	106-8582	1	Lever-Foot
3	100-8159	2	Screw-HSFH
4	106-8578	1	Plate-Stop
5	33023-00	7	Nut-Lock
6	33093-00	1	Washer-Flat
7	106-8581	1	Roller
8	106-8579	1	Lever-Spring
9	106-8592	1	Ring-Locking
10	106-8577	1	Bracket-Mounting
11	106-8580	1	Spring
12	48-9510	2	Nut
13	106-8585	1	Rod-Door, Mulch
14	87-5140	6	Nut-Lock
15	52-6430	6	Washer
16	87-5150	2	Bolt
17	106-8567	2	Guide
18	106-8586	1	Gasket-Door, Mulch
19	106-8575	4	Screw-HH
20	106-8587	2	Kicker
21	33123-016	2	Screw-CARR
22	107-8968	1	Door-Mulch
23	106-8573	1	Baffle-Center
24	106-8572	2	Plate-Baffel, Center


Ref	Part No.	Qty.	Description
25	106-8574	4	Screw
26	104-1451	2	Screw-TAP, PPH



Cutting Pan and Drive System Assembly


Ref	Part No.	Qty.	Description
1	104-3099	1	Lever-Engagement
2	48-9510	8	Nut
3	104-3101	1	Spring
4	57-6390	1	Nut-Jam
5	42-9850	1	Washer-Lock, Spring
6	106-8588	1	Washer-Flat
7	104-3103	1	Pulley-Idler
8	104-3104	1	Bushing
9	104-3105	1	Retainer-Belt
10	48-9540	6	Nut-Lock, Hex NI
11	33099-00	4	Washer-Flat
12	104-3107	1	Pulley-Drive
13	33105-025	1	Screw-HHF
14	107-8995	1	Shim-Arm, Idler
15	104-3109	1	Arm-Idler
16	33114-050	1	Screw-HH
17	33113-016	3	Screw-HH
18	106-8568	3	Washer-Flat
19	83-7420	3	Washer-Rubber
20	106-8591	1	Belt-Cog
21	104-3113	2	Cog Pulley ASM
22	104-3114	2	Pin-Pulley, Cog
23	33094-00	1	Washer-Plain
24	104-3115	1	Support-Pulley

Ref	Part No.	Qty.	Description
25	104-3116	2	Pulley-Cog, Drive
26	33123-016	2	Screw-CARR
27	33093-00	2	Washer-Flat
28	33023-00	2	Nut-Lock
29	33114-025	3	Screw-HH
30	104-3117	1	Plate-Anchor
31	107-8996	1	Plate-Drive, Blade
32	104-2909	1	Washer
33	33115-050	1	Screw-HH
34	104-3120	1	Bracket-Idler
35	108-8709	2	Washer-Flat
36	48-9520	1	Nut
37	104-3121	1	Pulley-Cog
38	100-1048	1	Bearing-Ball
39	104-3123	1	Ring-Locking
40	106-8589	1	Belt-Cover
41	104-3127	1	V-Belt
42	107-8941	1	Guard-Belt
43	60-6910	2	Screw
44	87-5140	2	Nut-Lock
45	107-8940	2	Bracket
46	3256-61	4	Washer-Flat
47	46-0430	2	Nut-Lock
48	107-8918	2	Screw



Cutting Pan and Drive System Assembly (continued)


Ref	Part No.	Qty.	Description
49	33096-00	2	Washer-Flat



Mower Lift Assembly






Ref	Part No.	Qty.	Description
1	104-3129	1	Grip-Handle
2	104-3130	1	Ratchet-Plate, Pivot
3	104-3131	1	Button-Plunger
4	104-3132	1	Rod-Connection
5	33024-00	3	Nut-Lock
7	33114-020	2	Screw-HH
8	114-3244	1	Gear-Segment, Deck Lift
9	104-3134	1	Spring
10	104-3135	1	Pin-Arm Lever
11	104-3136	1	Lever-Arm, Height Adj.
12	104-3137	1	Clip-Pin
13	104-2994	2	Pin-Spring
14	114-3245	1	Shaft-Deck Lift
17	33094-00	3	Washer-Plain
21	33025-00	1	Nut-Lock
22	33095-00	1	Washer-Flat
23	104-3139	1	Bolt-Eye
24	104-3140	1	Spring-Lift
25	104-3141	1	Pivot Arm ASM
27	104-3142	1	Pin-Lifting
28	33025-00	1	Nut-Lock
29	104-3016	2	Pin-Cotter
30	104-3143	4	Pin-Bent
31	104-3144	4	Pin-Hair

Ref	Part No.	Qty.	Description
32	104-3145	1	Suspension-Mower Deck, Front
33	33026-00	1	Nut-Lock
34	33016-00	1	Nut-Hex
35	104-3146	1	Holder-Front
36	104-3124	2	Washer-Flat
37	104-3147	1	Pin
38	104-3148	2	Clip-Hair Pin
41	104-3149	1	Rod-Height Adj.
42	104-3151	1	Pin-Cotter
43	34-9270	4	Washer-Hose







Harness Assembly

Ref	Part No.	Qty.	Description				
1	104-2491	1	Battery				
2	33013-00	2	Nut-Hex				
3	33113-016	2	Screw-HH				
4	114-3131	1	Clamp-Battery				
5	104-3154	2	Boot-Rubber				
6	110-8678	1	Cable-Battery, Negative				
7	33024-00	1	Nut-Lock				
8	33093-00	2	Washer-Flat				
9	3334-945	3	Tie-Cable				
10	104-3156	1	Holder- Harness, Wiring				
11	104-3157	8	Clip-Snap				
12	114-3128	1	Harness-Wire, Light				
13	114-3129	2	Bulb-Light				
15	104-3160	1	Harness-Clutch				
16	108-8753	1	Harness-Wiring				
17	104-3163	1	Cap				
18	104-3165	2	Bushing				
19	110-8677	1	Cable-Battery, Positive				
20	104-3167	2	Clip-Nylon				
21	104-3168	1	Bushing				
22	33114-020	1	Screw-HH				
23	33094-00	1	Washer-Plain				




Electrical Switch No. 1 Assembly

Ref	Part No.	Qty.	Description
1	104-3178	2	Cover-Protective
2	104-3179	3	Switch-Delta
4	104-3185	1	Switch-Omron
5	46-5780	1	Switch-Starter
5:1	3254-5	1	Washer-Tooth
5:2	218-461	1	Nut-HH
6	33113-012	2	Screw-HH
7	104-3186	2	Washer-Spring
8	33093-00	2	Washer-Flat
9	32128-32	3	Nut-HHF
10	104-3187	1	Boot-Rubber
11	104-3188	1	Lead-Starter, Electric
12	47-1910	1	Solenoid
13	104-3349	2	Screw





Electrical Switch No. 2 Assembly

Ref	Part No.	Qty.	Description				
2	93-9998	1	Switch-PTO				
3	92-6785	1	Switch-Ignition				
4	218-461	1	Nut-HH				
5	62-7770	2	Key-Ignition				
6	87-5140	2	Nut-Lock				
8	104-2978	4	Screw-Hex				
9	104-3173	2	Relay				
10	92-6705	1	Lens-Dash				
11	92-6732	1	Housing-Light, Indicator				
12	104-3191	3	Screw				
13	104-3174	3	Screw-Cap				
14	104-3175	3	Washer				
15	104-2985	3	Nut-Hex				
16	104-3176	4	Bulb				
17	104-3177	1	Buzzer				
19	104-3194	1	Decal-Dash				
20	3254-5		Washer-Tooth				



Electrical Switch No. 3 Assembly

Ref	Part No.	Qty.	Description				
1	104-3178	1	Cover-Protective				
2	99-3701	1	Module-Clutch				
3	60-6910	2	Screw				
4	52-6430	2	Washer				
5	87-5140	4	Nut-Lock				
6	104-3169	1	Circuit-Memory				
7	104-3333	1	Holder-Switch				
8	104-3190	2	Screw				
9	107-8955	1	Holder-Switch				
10	104-2980	2	Screw				
11	95-1653	1	Switch-Pole, Single				
12	104-2983	2	Screw				
13	104-2985	2	Nut-Hex				
14	104-3338	1	Switch-Delta				
15	104-3339	1	Cover-Switch				
16	104-3330	1	Switch-Delta				
17	104-3331	2	Bolt				
18	46-0430	2	Nut-Lock				
19	52-6430	2	Washer				



1058 OPERATOR MANUAL


48 SHORT BLOCK

Assemblies include all parts shown in frames

Cylinder Assembly

Briggs and Stratton Model 31G777-0130-E1


Ref	Part No.	Qty.	Description
21	793987	1	Cylinder ASM
22	399265	1	Bushing And Seal Kit
243	391086s	1	Seal-Oil (Magneto Side)
249	697109	1	Gasket-Breather
211	697113	1	Tube-Breather
248	697762	1	Short Block ASM
2306	697107	1	Shield-Cylinder
2307	691003	1	Screw (Cylinder Shield)
2337	691043	1	Spark Plug
2383	89838s	1	Wrench-Spark Plug
2404	691691	1	Washer (Governor Crank)
2521	690581	1	Shield-Cable
2552	697144	1	Bushing-Crank, Governor
2584	697112	1	Cover-Passage, Breather
2614	691620	1	Pin-Cotter
2616	692012	1	Crank-Governor
2635	691909	1	Boot-Spark Plug
2684	697157	1	Screw (Breather Passage Cover)
24691	692407	1	Seal-Shaft, Governor
2718	690959	1	Pin-Locating
21058	MS3788	1	Manual-Operator
21263	697124	1	Reed-Breather
21264	697104	1	Screw (Breather Reed)



Cylinder Head Assembly Briggs and Stratton Model 31G777-0130-E1

Ref	Part No.	Qty.	Description
25	793989	1	Head-Cylinder
247	699168	1	Gasket-Head, Cylinder
213	793988	1	Screw (Cylinder Head Gasket)
233	791934	1	Valve-Exhaust
234	791935	1	Valve-Intake
235	691279	1	Spring-Valve (Intake)
236	691279	1	Spring-Valve (Exhaust)
242	499586	1	Keeper-Valve
245	690564	1	Tappet-Valve
250	690193	1	Manifold-Intake
2551	692137	1	Gasket-Intake
254	691148	1	Screw (Intake Manifold)
2192	691986	1	Adjustor-Arm, Rocker
2238	691843	1	Cap-Valve
23617	692138	1	Seal-O Ring (Intake Manifold)
2830	691095	1	Stud-Arm, Rocker
24868	690968	1	Seal-Valve
2883	692236	1	Gasket-Exhaust
2914	691108	1	Screw (Rocker Cover)
241022	272475s	1	Gasket-Cover, Rocker
21023	791079	1	Cover-Rocker

Ref	Part No.	Qty.	Description
21026	692003	1	Rod-Push (Intake)
21026	692011	1	Rod-Push (Exhaust)
21029	691751	1	Arm-Rocker
21034	690822	1	Guide-Rod, Push










Assemblies include all parts shown in frames

Crankshaft Assembly

Briggs and Stratton Model 31G777-0130-E1

Ref	Part No.	Qty.	Description				
16	697127	1	Crankshaft				
24	222698s	1	Key-Flywheel				
25	792507	1	Piston ASM (STD)				
25	792648	1	Piston ASM (.020 O S)				
26	792649	1	Ring Set (STD)				
26	791947	1	Ring Set (.020 O S)				
27	698469	1	Lock-Pin, Piston				
28	697099	1	Pin-Piston (STD)				
29	791631	1	Ring Set (STD)				
32	791118	1	Screw (Connecting Rod)				
146	691639	1	Key-Timing				
357	691483	1	Key-Pulley, Drive				
741	697128	1	Gear-Timing				
757	793242	1	Link-Counterweight				
758	697134	1	Counterweight				
759	697392	1	Pin-Counterweight				
1270	793243	1	Plug-Counterweight, A V S				


750 

Assemblies include all parts shown in frames

Crankcase Assembly

Briggs and Stratton Model 31G777-0130-E1

Ref	Part No.	Qty.	Description				
24	697188	1	Sump-Engine				
2412	697110	1	Gasket-Crankcase				
215	690946	1	Plug-Drain, Oil				
2420	791892	1	Seal-Oil (P-T-O Side)				
222	692125	1	Screw (Engine Sump)				
243	691968	1	Slinger-Governor, Oil				
245	690564	1	Tappet-Valve				
246	793583	1	Camshaft				
2415	690283	1	Plug-Oil				
2523	699908	1	Dipstick				
24524	691032	1	Seal-O Ring (Dipstick Tube)				
2525	697085	1	Tube-Dipstick				
2750	790832	1	Screw (Oil Pump Cover)				
24842	691031	1	Seal-O Ring (Dipstick)				
24847	790443	1	Dipstick Tube ASM				
24943	690589	1	Seal-O Ring (Oil Pump Cover)				
2965	499613	1	Cover-Pump, Oil				
21017	690770	1	Screen-Pump, Oil				
21024	499054	1	Pump-Oil				
21027	492932s	1	Filter-Oil				
21035	693784	1	Shaft-Pump, Oil				




Assemblies include all parts shown in frames

Carburetor Assembly (Nikki)

Briggs and Stratton Model 31G777-0130-E1

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
2 3 51 4 5	692137	1	Gasket-Intake	2 3 987	698777	1	Seal-Shaft, Throttle
2 94	695425	1	Idle Mixture Kit	2 1127	695407	1	Screw (Float Bowl)
2 3 95	690718	1	Screw (Throttle Valve)				
2 98	695408	1	Idle Speed Kit				
2 3 104	694918	1	Pin-Hinge, Float				
2 3 105	696136	1	Valve-Float, Needle				
2 108	695419	1	Valve-Choke				
2 3 117	699457	1	Jet-Main (STD)				
2 118	699458	1	Jet-Main (High Altitude)				
2 125	792171	1	Carburetor				
2 3 127	690727	1	Plug-Welch				
2 130	699500	1	Valve-Throttle				
2 131	699501	1	Throttle Shaft Kit				
2 133	694914	1	Carburetor Float ASM				
2 135	792022	1	Tube-Transfer, Fuel				
2 3 137	698781	1	Gasket-Bowl, Float				
2 141	698778	1	Choke Shaft Kit				
2 276	695410	1	Washer-Sealing				
2 601	691038	1	Clamp-Hose				
2 3 634	698779	1	Spring And Seal ASM				
2 947	699915	1	Solenoid, Fuel				
2 958	698183	1	Valve-Shut Off, Fuel (Plastic)				
2 975	699502	1	Bowl-Float				




Assemblies include all parts shown in frames

Governor Assembly

Briggs and Stratton Model 31G777-0130-E1

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
2188	691693	1	Screw (Control Bracket)	21266	691917	1	Seal-O Ring (Intake Elbow)
2202	691841	1	Link-Governor, Mechanical	4			
2209	691795	1	Spring-Governor	21266A	697123	1	Seal-O Ring (Intake Elbow)
2216	691840	1	Link-Choke				
2222	694042	1	Bracket-Control				
2227	691374	1	Lever-Control, Governor				
2232	691842	1	Spring-Link, Governor				
2265	691024	1	Clamp-Casing				
2267	690804	1	Screw (Casing Clamp)				
2333	492341	1	Armature-Magneto				
2334	691061	1	Screw (Magneto Armature)				
2356	697089	1	Stop-Wire				
2431	697122	1	Elbow-Intake (Magneto Armature)				
2474	696457	1	Alternator				
2501	691188	1	Regulator				
2505	691251	1	Nut (Governor Control Lever)				
2526	697088	1	Screw (Regulator)				
2562	691119	1	Bolt (Governor Control Lever)				
2789	698329	1	Harness-Wiring				
2851	493880s	1	Terminal-Spark Plug				
2877	393537	1	Connector-Wire, Tri Circuit				
21059	698516	1	Screw And Washer Kit				
21119	691183	1	Screw (Alternator)				




Assemblies include all parts shown in frames

Blower Housing Assembly

Briggs and Stratton Model 31G777-0130-E1



Ref	Part No.	Qty.	Description				
223	790835	1	Flywheel				
237	697352	1	Guard-Flywheel				
273	697133	1	Screen-Rotating				
274	697897	1	Screw (Rotating Screen)				
278	691003	1	Screw (Flywheel Guard)				
2304	698402	1	Housing-Blower				
2305	697102	1	Screw (Blower Housing)				
2305A	793376	1	Screw (Blower Housing)				
2363	19203	1	Puller-Flywheel				
2445	698083	1	Filter-Cartridge, Air Cleaner				
2643	698401	1	Retainer-Filter, Air				
2668	691500	1	Spacer				
2783	693713	1	Gear-Pinion				
2823	698941	1	Screw (Muffler Adapter)				
2967	697015	1	Filter-Cleaner, Pre				
2968	699830	1	Cover-Cleaner, Air				
21005	699043	1	Fan-Flywheel				
21036		1	Label-Emissions				
21040	699852	1	Plate-Trim				
21044	698139	1	Screw (Crankshaft Extension)				
21051	691265	1	Ring-Retaining				
21070	690372	1	Screw (Flywheel Fan)				
21267	697424	1	Latch-Housing, Blower				



Starter Assembly

Briggs and Stratton Model 31G777-0130-E1

Ref	Part No.	Qty.	Description				
2309	693551	1	Motor-Starter				
2310	690323	1	Bolt (Starter Motor)				
2311	497608	1	Brush Set				
2462	691261	1	Washer (Brush Retainer)				
2503	691532	1	Strap-Starter				
2510	693699	1	Drive-Starter				
2513	692024	1	Clutch-Drive				
2544		1	Armature-Starter (For Service Order 693551)				
2579	691029	1	Nut (Brush Retainer)				
2697	690372	1	Screw (Drive Cap)				
2729	691224	1	Clip-Wire				
2783	693713	1	Gear-Pinion				
2797	693167	1	Nut (Brush Retainer)				
2801	691283	1	Cap-Drive				
2802	691286	1	Cap-End				
2803		1	Housing-Starter (For Service Order 693551)				
21051	691265	1	Ring-Retaining				
21090	691293	1	Retainer-Brush				




Assemblies include all parts shown in frames

Gasket Set

Briggs and Stratton Model 31G777-0130-E1

Ref	Part No.	Qty.	Description				
2 43	391086s	1	Seal-Oil (Magneto Side)				
2 47	699168	1	Gasket-Head, Cylinder				
2 49	697109	1	Gasket-Breather				
2 412	697110	1	Gasket-Crankcase				
2 420	791892	1	Seal-Oil (P T O Side)				
2 551	692137	1	Gasket-Intake				
4 5							
2 358	794150	1	Engine Gasket Set				
2 4524	691032	1	Seal-O Ring				
2 5617	692138	1	Seal-O Ring				
4							
2 4691	692407	1	Seal-Shaft, Governor				
2 4842	691031	1	Seal-O Ring				
2 4868	690968	1	Seal-Valve				
5							
2 4943	690589	1	Seal-O Ring (Oil Pump Cover)				
2 41022	272475s	1	Gasket-Cover, Rocker				
5							
2 1095	691581	1	Valve Gasket Set				
2 51266	691917	1	Seal-O Ring (Intake Elbow)				
4							



Assemblies include all parts shown in frames

Carburetor Overhaul Kit (Nikki)

Briggs and Stratton Model 31G777-0130-E1

Ref	Part No.	Qty.	Description				
2351	692137	1	Gasket-Intake				
45							
2395	690718	1	Screw (Throttle Valve)				
23104	694914	1	Carburetor Float ASM				
23105	696136	1	Valve-Float, Needle				
23117	699457	1	Jet-Main (STD)				
26121	699521	1	Carburetor Overhaul Kit				
23127	690727	1	Plug-Welch				
23137	698781	1	Gasket-Bowl, Float				
23617	692138	1	Seal-O Ring (Intake Manifold)				
4							
23634	698779	1	Spring And Seal ASM				
23987	698777	1	Seal-Shaft, Throttle				
231266	691917	1	Seal-O Ring (Intake Elbow)				
4							
231266A	697123	1	Seal-O Ring (Intake Elbow)				

Attachments and Accessories

For 74582 - DH 210 Lawn Tractor

Product Name	Model/Part
Rear Discharge Kit	79471

NOTES

