





MODEL NO. 73501 5902869 & UP

**PARTS
CATALOG**

WHEEL HORSE®
520-H GARDEN TRACTOR






C-2042

HOOD ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	92-9836	Plate - Logo	1
2	92-9826	Decal - Front	1
3	113968	Hood	1
5	117432	Rivet - Pop	4
6	117344	Latch - Hood	2
7	116746	Bracket - RH	1
8	5979	Bushing	2
9	105797	Ring - Retaining	2
10	116747	Bracket - LH	1
11	3229-25	Bolt - Carriage	4

Ref. No.	Part No.	Description	No. Used
12	116745	Rod - Pivot	1
13	101850	Rod - Hood Stop	1
14	3272-1	Pin - Cotter	2
15	3296-42	Nut - Lock	4
16	92-9834	Decal - Hood LH	1
*	92-9835	Decal - Hood RH	1
17	3256-22	Washer	3
18	3254-2	Washer - Internal Tooth	1
19	109495	Bezel - Headlight LH	1
20	109494	Bezel - Headlight RH	1


*Not Illustrated



C-2043

DASH AND SIDE PANELS ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	113962	Panel — RH	1	16	3296-29	Nut — Lock	11
2	32115-5	Nut — Speed	12	17	114628	Bracket — Switch	1
3	9108392	Screw	6	18	79-4890	Panel — LH	1
4	92-7295	Plate — Hoodstand, Rear (Incl. Ref. #13)	1	19	117343	Keeper — Latch	2
5	9108372	Screw — Black	8	20	117433	Rivet — RS Pop	4
6	32128-33	Nut — Lock, Flange Hd.	2	21	322-1	Screw — Hex. Hd.	2
7	117267	Panel — Dash	1	22	8830	"J"Clip	1
8	118410	Cover — Steering	1	23	322-3	Screw — Hex. Hd.	3
9	115620	Cover — Console, 5-Gage	1	24	9000369	Bolt	2
10	92-0270	Washer	4	25	78-1540	Bracket — Control, Lower	1
11	118780	Screw — Plastite	4	26	3256-23	Washer — Flat	4
12	111960	Decal — PTO Clutch	1	27	9157404	Nut — Lock	4
13	92-9838	Decal — Danger	1	28	9107922	Screw	4
14	114641	Stop — Choke	1	29	66-0120	Knob — Throttle Control	2
15	113932	Stiffener — Panel	1	30	115392	Control — Throttle	1
				31	114027	Control — Choke	1




C-2044

HOODSTAND ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	116000	Bolt – Carriage	4
2	108457	Nut – Push On	1
3	321-3	Screw – Hex. Hd.	2
4	117191	Bracket – Holder, Fuse	1
5	3296-29	Nut – Lock	1
6	9157404	Nut	2
7	116309	Bracket – Support, Battery	1
8	92-7293	Plate – Hoodstand, Top (Incl. Ref. #10)	1
9	9108372	Screw – Black	3

Ref. No.	Part No.	Description	No. Used
10	92-8946	Decal – Danger	1
11	9108392	Screw	2
12	116445	Decal – Brake, Parking	1
13	9266944	Screw – Hex. Hd.	14
14	79-5120	Hoodstand	1
15	107069	Nut – Speed	5
16	79-5130	Cover – Side, LH	1
17	322-3	Screw – Hex. Hd.	5
18	79-4020	Plate – Front	1
19	8830	"J"Clip	1




C-2046

BELT GUARD AND FOOTREST ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	3296-29	Nut - Lock	8	11	106223	Footrest - LH	1
2	92-1527	Guard - Belt	1	12	116000	Bolt - Carriage	4
3	9266944	Bolt	2	13	7456	Bracket	4
4	926671	Screw - Hex. Hd.	1	14	107069	Clip	2
5	3230-1	Bolt - Carriage	1	15	106222	Footrest - RH	1
6	109554	Bracket - Support, Guard	1	16	110635	Pad - Footrest L.H.	1
7	322-5	Screw - Hex. Hd.	2	*	110634	Pad - Footrest R.H.	1
8	3256-23	Washer - Flat	2	17	9108372	Screw	1
9	113023	Bracket - Fender	1	18	108457	Nut - Push On	1
10	518211	Bumper	2				


*Not Illustrated



SEAT, FENDER AND FENDER SUPPORTS

Ref. No.	Part No.	Description	No. Used
1	88-3220	Seat	1
2	92-0992	Screw	6
3	92-0987	Bracket - Arm R.H.	1
4	92-0988	Rest - Arm	2
5	92-0989	Screw	2
6	92-0993	Spacer - Nylon	4
7	92-0986	Bracket - Arm L.H.	1
8	92-0990	Screw	2
9	92-0991	Nut - Acorn Lock	2
10	322-4	Bolt	2
11	105503	Bushing	2
12	3296-29	Nut - Lock	2
13	9266944	Screw - Hex. Hd.	4
14	105524	Bracket - Pivot	2
15	78-2990	Plate - Seat Pivot	1
16	3296-42	Nut - Lock	2
17	111071	Bumper	2
18	9266944	Bolt - Flange	2
19	321-8	Bolt	2
20	3256-22	Washer	2


Ref. No.	Part No.	Description	No. Used
21	114343	Spring - Gas	1
22	114344	Spacer	2
23	114345	Bracket - Gas Spring	1
24	3256-23	Washer	4
25	110960	Fender	1
26	322-3	Screw - Hex. Hd.	4
27	108464	Support - LH, Fuel Tank	1
28	79-4990	Bracket - Support, Fender	1
29	106236	Support - RH, Fuel Tank	1
30	116446	Decal - Do Not Tow	1
33	322-5	Screw - Hex. Hd.	4
34	3253-4	Washer - Lock	4
35	114263	Spring - Seat	2
36	114264	Adjuster - LH (With Latch)	1
37	109989	Spacer - Nylon	4
38	9108652	Screw	4
39	114265	Slide - RH	1
*	88-3230	Kit - Armrest (Incl. Ref. # 2-9)	1



FUEL TANK AND FUEL PUMP

Ref. No.	Part No.	Description	No. Used
1	3256-4	Washer	2
2	9266974	Bolt	2
3	114012	Tank - Fuel (Incl. Ref.# 19 & 20)	1
4	113372	Gasket	1
5	113358	Sender - Fuel Level	1
6	910807	Screw	5
7	79-3180	Terminal - Ground	1
8	3253-17	Washer - Lock	5
9	55-3570	Cap - Fuel	1
10	82-1080	Clamp - Hose	6
11	71-5960	Filter - Fuel	1
12	NN10790	Line - Fuel 12"	1

Ref. No.	Part No.	Description	No. Used
13	NN10302	Line - Fuel 7"	
14	57-9080	Pump - Fuel	1
15	108898	Clamp - Corbin	2
16	59-1050	Screw - ST Pan Hd	2
17	NN10211	Cap - Fuel Fitting	1
18	NN10048	Clamp	1
19	104047	Bushing - Rubber	1
20	104048	Valve - Fuel Shut-Off	1
21	110521	Line - Fuel 53"	1
22	322-2	Bolt	3
23	3253-4	Washer - Lock	2
25	3235-22	Screw - Hex. Hd., Nylon	1



C-2051


HYDRAULIC CONTROL SYSTEM

Ref. No.	Part No.	Description	No. Used
1	114000	Valve – Hydraulic (Incl. Ref. #3–4)	1
2	3296-42	Nut	2
3	9321204	Pin – Clevis	1
4	3272-1	Pin – Cotter	2
5	78-5640	Bar – Lift	1
6	5983	Bushing	1
7	933198	Pin – Spirol	1
8	116302	Arm – Control	1
9	117328	Rod – Lift Control	1
10	321-4	Screw	1
11	116305	Bracket – Control Rod	1
12	3296-42	Nut	1
13	116634	Knob – Hydraulic Lift	1
14	3296-29	Nut	1
15	3256-23	Washer – Flat	2
16	104841	Spring	1
17	973310	"O"Ring	4
18	110125	Hose – Valve To Cylinder	1
19	102628	Fitting – Straight Adapter (Incl. Ref. #20)	1

Ref. No.	Part No.	Description	No. Used
20	973370	"O"Ring	4
21	86-9280	Tube – Hydraulic (Pressure)	1
22	3272-11	Pin – Cotter	1
23	9329974	Pin – Clevis	1
24	101699	Kit – Service, Cylinder Repair	1
25	109088	Kit – Service, Cylinder Repair	1
26	119340	Cylinder – Hydraulic (Incl. Ref. #24–25)	1
27	9202324	Washer	1
28	101757	Spacer	1
29	110124	Hose – Valve To Cylinder	1
30	106267	Grommet – Rubber	1
31	321-11	Bolt	2
32	94-1802	Tube – Hydraulic (Return)	1
33	108365	Fitting – 90° (Incl. Ref. #20)	2
*	109081	Kit – Service, Valve Repair	1
*	100571	Tie – Cable	1


*Not Illustrated

Note : In Illustration Center lines A Continue on next page



HYDROSTATIC LIFT LINKAGE


Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	3256-26	Washer	1	11	121100	Lever - Lift	1
2	9335054	Pin - Cotter	1	12	9335074	Pin - Cotter	2
3	322-5	Bolt	1	13	1121	Key - Sq.	1
4	106522	Chain - Lift	1	14	79-5700	Bellcrank	1
5	79-5720	Trunnion	1	15	102374	Pin - Pivot	1
6	3296-39	Nut	1	16	32120-47	Ring - Retaining	1
7	9335054	Pin - Cotter	1	17	6229	Bearing	1
8	106269	Bearing - Flanged	2	18	3256-23	Washer	1
9	3256-62	Washer	3	19	3296-29	Nut	1
10	32151-91	Ring - Retainer	2	20	120400	Bar - Lift	1



TRANSAXLE ASSEMBLY


Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	105763	Hub – Rear	1	15	101889	Gear – Differential Axle 24 Tooth	2
2	3243-5	Screw – Set	2	16	105876	Ring – Retaining	2
3	3218-3	Nut	2	17	101623	Gear – Differential Pinion 11 Tooth	8
4	106826	Washer – Thrust	1	18	105061	Gear – Differential Ring 43 Tooth	1
5	108362	Axle – Rear, RH Long	1	19	111199	Bearing – Ball	1
6	6449	Axle – Seal	1	20	281-10	Plug – Pipe	2
7	9416	Bearing – Needle	1	21	1532	Bearing – Needle	2
8	3296-39	Nut	3	22	937108	Key – Woodruff	1
9	106448	Tube – Filler	1	*	93-9814	Transaxle (Incl.. Ref. #23)	1
10	110768	Dipstick	1	23	88-2790	Decal – Danger	1
11	92-7298	Case – Transaxle, RH (Incl. Ref.#23)	1				
12	108881	Nut	4				
13	111196	Cap – Differential End	1				

Note : In Illustration Center lines A,B and C
Continue on next page



TRANSAXLE ASSEMBLY (Continued)

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	108361	Axle — Rear, LH Short	1	19	108357	Seal — Oil	1
2	111196	Cap — Differential End	1	20	1538	Bearing — Needle	1
3	111199	Bearing — Ball	1	21	323-26	Screw — Hex. Hd.	1
4	107374	Washer — Special	4	22	323-25	Screw — Hex. Hd.	3
5	911423	Bolt	4	23	109367	Bracket — Brake	1
6	9080356	Bolt	1	24	323-9	Screw — Hex. Hd.	1
7	111201	Case — Transaxle, LH	1	25	7956	Washer — Thrust	1
8	108312	Gasket — Case	1	26	109370	Shaft	1
9	323-15	Bolt	2	27	937099	Key — Woodruff	1
10	9080406	Bolt	1	28	108363	Pin — Dowel	2
11	9416	Bearing — Needle	1	29	109752	Gear 46 Tooth	1
12	6449	Axle — Seal	1	30	109742	Gear 20 Tooth	1
14	937108	Key — Woodruff	1	31	1532	Bearing — Needle	2
15	106826	Washer — Thrust	1	32	1518	Bearing — Needle	1
16	3243-5	Screw — Set	2	33	9547	Washer — Thrust	1
17	3218-3	Nut	2	34	109703	Gear	1
18	105763	Hub — Rear	1				




CLUTCH, BRAKE AND SPEED CONTROL LINKAGE

Ref. No.	Part No.	Description	No. Used
1	79-1350	Pedal — Brake	1
3	111383	Collar	1
4	3245-32	Screw — Set	1
6	103125	Spring — Brake Return	1
7	109372	Rod — Brake, Front	1
8	3272-11	Pin — Cotter	2
9	3296-39	Nut	1
10	3256-24	Washer	2
11	108680	Spring	1
13	106719	Drum — Brake	1
14	2844	Special Washer	1
15	323-23	Bolt	1

Ref. No.	Part No.	Description	No. Used
16	3235-22	Bolt	1
17	109371	Band — Brake	1
18	78-7740	Arm — Brake Pivot	1
19	109356	Bushing	1
20	323-9	Bolt	1
21	3296-39	Nut	1
22	3256-4	Washer	1
23	3256-6	Washer	2
24	3272-6	Pin — Cotter	2
25	1278	Washer — Shim	1
26	302-5	Fitting — Grease	1
27	9335044	Pin — Cotter	1

Note : In Illustration Center lines A Continue on next page




CLUTCH, BRAKE AND MOTION CONTROL LINKAGE

Ref. No.	Part No.	Description	No. Used
1	116635	Knob – Motion Control	1
2	78-5660	Lever – Motion Control	1
3	933198	Pin – Spirol	1
4	118660	Guide – Control	1
5	78-5631	Bracket – Control	1
6	321-4	Bolt	2
7	3296-42	Nut	4
8	3220-1	Nut	3
9	116407	Rod End	2
10	3217-5	Nut	2
11	113454	Control – Cam	1
12	100304	Spacer	2
13	110189	Rod End Asm	2
14	108904	Rod Control	1
15	32146-17	Nut	1
16	3256-22	Washer	2

Ref. No.	Part No.	Description	No. Used
17	321-9	Screw – Hex. Hd.	1
18	9114584	Bolt	2
19	100656	Bearing – Cam	1
20	32120-47	Ring – Retaining	4
21	102809	Nut – Special, Flanged	1
22	78-8500	Lever – Parking Brake	1
23	933135	Pin – Spirol	1
24	102025	Spacer	1
25	9202414	Washer	1
26	118860	Knob	1
27	323-9	Bolt	1
28	323-8	Bolt	1
29	3256-4	Washer	2
30	108717	Spacer	1
31	108716	Plate – Cam	1
32	3296-39	Nut	2

* Not Illustrated




CLUTCH, BRAKE AND MOTION CONTROL LINKAGE

Ref. No.	Part No.	Description	No. Used
33	9266944	Bolt	1
34	108496	Rod – Pivot	1
35	32120-47	Ring – Retaining	2
36	5983	Bushing	3
37	32312-94	Pin – Spirol	1
38	323-8	Screw – Hex. Hd.	1
39	112791	Pulley – Idler	1
40	78-6020	Rod – Pivot	1
41	107938	Spring	1
42	321-6	Bolt	1
43	7879	Bushing	1

Ref. No.	Part No.	Description	No. Used
44	3765	Washer – Shim	1
45	114823	Washer – Wave	2
46	322-3	Bolt	2
47	78-1540	Bracket – Control, Lower	1
48	3296-29	Nut	2
49	101853	Spring	1
50	3296-4	Nut	1
51	116321	Arm – Control	1
52	116324	Rod Assembly	1
53	83-2820	Spring	1

* Not Illustrated




HYDROSTATIC TRANSMISSION

Ref. No.	Part No.	Description	No. Used
1	9080026	Bolt	1
2	103995	Washer – Special	1
3	108393	Fan	1
4	323-25	Screw – Hex. Hd.	2
5	108329	Plate, Control	1
6	9080406	Screw – Hex. Hd.	1
7	937089	Key – Hi-Pro	1
8	108326	Spacer – Pivot, Long	1
9	100365	Washer – Spring, Disc	2
10	100305	Washer – Friction	2
11	108333	Plate – Control, Speed	1
12	100309	Bushing – Pivot, Cam	1
13	108881	Nut	2
14	3257-24	Key – Woodruff	1
15	108325	Arm – Control, Speed	1
16	3256-26	Washer – Flat	1
17	3296-45	Nut – Lock	1
18	106661	Cam – Eccentric	1
19	9080196	Screw – Hex. Hd.	1
20	322-3	Screw – Hex. Hd.	2
21	3253-4	Washer – Lock	2
22	8830	"J"Clip	1
23	3296-39	Nut – Lock	4
24	79-5270	Filter – Oil	1

Ref. No.	Part No.	Description	No. Used
25	5991	Fitting – Filter	1
26	108323	Base – Filter	1
27	281-10	Plug – Pipe	3
28	102628	Fitting – Hyd., Straight (Incl. "O"Ring)	1
*	973370	"O"Ring	1
29	79-5020	Tube	1
30	32120-64	Ring – Retaining	1
31	109751	Gear – 20 Teeth	1
32	108366	Spacer – Drive, Gear	1
33	108365	Fitting – Hydraulic 90°	2
34	108319	Gasket – Pump	1
35	108368	Pump & Motor Asm, Eaton 1100-032 Before Serial No. 5902869	1
*	92-9848	Pump & Motor Asm, Eaton 1100-062 After Serial No. 5902869	1
36	108364	Fitting – Hyd., Straight	1
37	111217	Tube – Suction	1
38	108316	Pulley – Transmission Drive	1
39	108327	Spacer – Pivot, Short	1
*40	3242-2	Screw – Set	2


* Not Illustrated

EATON HYDROSTATIC TRANSMISSION # 1100-062



EATON HYDROSTATIC TRANSMISSION # 1100-062

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	56-2800	Screw – Hex. Hd. Soc.	1	29	56-3060	Pin – Dowel	1
2	56-2810	Bearing – Ball	1	30	112652	Shield – Grass	1
3	56-2820	Seal	2	31	112653	Ring – Retaining	1
4	112637	Housing – Pump Assembly (Incl. Ref. # 3)	1	33	56-3100	Screw – Soc. Hd.	6
5	56-3090	Ring – Retaining	4	34	56-3110	Roller	6
6	56-2850	Ring – Seal	1	35	56-3120	Carrier	1
7	56-2860	Plate – Pump	1	36	56-3130	Seal – Oil	1
8	56-2870	Ring – Seal	1	37	56-3140	Kit – Control Shaft	1
9	112641	Cover Assembly (Incl. Ref. #11, 36 & 37)	1	40	56-3170	Insert – Cam Ring	1
10	56-2880	Button	2	41	56-3180	Spring	2
11	56-2890	Pin – Dowel	1	43	56-3200	Body – Acc. Valve	2
12	56-2900	Pin – Drive	1	44	56-3210	Ball	2
13	56-2910	Shaft – Input	1	45	56-3220	Rotor / Ball – Motor	1
14	56-2920	Ring – Seal	1	46	56-3230	Shaft – Output	1
15	56-2930	Rotor / Ball – Pump	1	47	56-3240	Race – Motor	1
16	113136	Race – Pump	1	48	56-3250	Plug – Asm (Incl. Ref. #49)	1
17	93-9810	Ring – Cam	1	49	56-3260	"O" Ring	1
18	56-2950	Piston	2	50	93-9811	Body Assembly	1
19	56-2960	Ring – Back Up	2	52	112666	Bearing – Output Before Serial No. 5902869	1
20	56-2970	"O" Ring	2	*	112602	Bearing – Output After Serial No. 5902868	1
21	56-2980	Pin – Coil	1	53	56-3290	Ring – Retaining	1
22	56-2990	Pintle Assembly (Incl. Ref. #1, 18-21, 23-29 41, 43 & 44)	1	56	56-2940	Ring – Cam (Incl. Ref. #16-17)	1
23	56-3000	Ring – Retaining	2	*	56-3310	Kit – Seal, Overhaul (Incl. Ref. # 3, 6, 8, 14, 19, 20, 36, & 49)	1
24	56-3010	Ball	2	*	93-9812	Body Assembly (Incl. Ref. # 3, 33, 46-50. 52, 53 & 57)	1
25	56-3020	Body – Check Valve	2				
26	56-3030	Ball	1				
27	56-3040	Spring – Relief Valve	1				
28	56-3050	Plug – Relief Valve	1				




FRONT AXLE AND STEERING

Ref. No.	Part No.	Description	No. Used
1	3296-39	Nut	2
2	6216	Pin & Plate	1
3	6472	Bearing - Flanged	1
4	323-6	Bolt	2
5	3272-11	Pin - Cotter	1
6	9150324	Nut	1
7	3256-26	Washer	1
8	78-1481	Pinion	1
9	9202624	Washer	1
10	3296-39	Nut	4
11	323-9	Bolt	6
12	92-0995	Shaft - Upper Steering	1
13	237-69	"O"Ring	1
14	78-0370	Insert - Logo	1

Ref. No.	Part No.	Description	No. Used
15	76-1420	Steering Wheel (Incl. Ref. #14)	1
16	32121-111	Pin - Spirol	1
17	109189	Flange - Bearing	1
18	5210	Washer - Shim	6
19	3272-21	Pin - Cotter	1
20	78-1450	Shaft	1
21	1481	Fitting - Grease, 45°	2
22	78-1411	Support - Steering	1
23	3272-22	Pin - Cotter	1
24	9202164	Washer	1
25	78-1531	Shim 0.010	3
26	88-3240	Block - Bearing	1
27	9080376	Bolt	2


*Not ILLUSTRATED



FRONT AXLE AND STEERING (Continued)

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
28	302-16	Fitting - Grease	1	39	302-5	Fitting - Grease	4
29	3272-7	Pin - Cotter	4	40	112771	Tie Rod End - Thread LH (Incl. Ref. #30)	2
30	915031	Nut	4	41	112764	Spindle - Front, RH	1
31	9202424	Spacer	4	*	112765	Spindle - Front, LH	1
32	78-1490	Shaft - Lower Steering	1	42	32151-29	Ring - Retaining	2
33	322-1	Bolt	1	43	116823	Axle - Front	1
34	3253-4	Washer - Lock	1	44	9548	Washer - Thrust	4
35	112772	Tie Rod End - Thread RH (Incl. Ref. #30)	2	45	9865	Bearing - Thrust	2
36	3220-11	Nut	2	46	302-5	Fitting - Grease, Straight	2
37	112773	Tube	2	47	5618	Ring - Retaining	1
38	112775	Nut - Thread LH	2	48	3254-8	Washer - Lock	1

*Not ILLUSTRATED




C-2056

FRAME AND HITCH ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	8616	Spring	2
2	105797	Ring – Retaining	8
3	101751	Rod – Front Hitch Lock	1
4	3296-39	Nut – Lock	9
5	3231-25	Bolt – Carriage	3
6	92-8747	Decal – Attach-A-Matic	2
7	102644	Plate – Mid Hitch	2
8	8830	Clip	1
9	78-2680	Frame	1
10	9038	Grip	1

Ref. No.	Part No.	Description	No. Used
11	323-44	Screw – Hex. Hd.	6
12	105316	Cap – Lock Rod	2
13	117930	Latch – Mid Hitch	1
14	101711	Housing – Front Hitch	1
15	83-6520	Rod – Lock	1
16	101017	Lock	1
17	101750	Rod	1
18	93-1613	Latch – Front Hitch	1
19	101707	Lock	1




C-2218

REAR HITCH ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	323-5	Screw — Hex. Hd.	4
2	3253-21	Washer — Lock	4
3	5618	Ring — Retaining	2
4	105269	Shaft — Drawbar Hitch	1
5	9791204	Spacer	2

Ref. No.	Part No.	Description	No. Used
6	106634	Pin — Hitch	1
7	3256-26	Washer — Flat	1
8	9335054	Hairpin — Cotter	1
9	1644	Hitch — Drawbar	1




C-

ENGINE AND EXHAUST

Ref. No.	Part No.	Description	No. Used
1	94-1803	Deflector - Air	1
2	115783	Shield - Muffler	1
3	114888	Screw	6
4	12-3270	Screw - Hex. Hd.	3
5	114216	Cover - Exhaust, Rear	1
6	116471	Muffler	1
7	8830	Clip	1
8	79-5220	Engine - 20HP Toro Power Plus P220G-I 10955D Before Serial No. 5902947	1
*	94-1811	Engine - 20HP Toro Power Plus P220G-I 10955G After Serial No. 5902947	1
9	114764	Elbow 90°	1

Ref. No.	Part No.	Description	No. Used
10	323-7	Screw - Hex. Hd.	4
11	3253-21	Washer - Lock	4
12	3217-7	Nut	4
13	3296-39	Nut	4
14	116609	Plate - Engine	1
15	288-4	Cap	1
16	114763	Pipe	1
17	114636	Nipple	1
18	3256-24	Washer - Flat	4
19	323-8	Screw - Hex. Hd.	4
20	57-9210	Gasket - Exhaust	2
21	114215	Cover - Exhaust, Front	1
22	3253-4	Washer - Lock	4
23	322-3	Screw - Hex. Hd.	4




BLOWER HOUSING

Ref. No.	Part No.	Description	No. Used
1	92-0920	Housing – Cylinder Air, LH	1
2	82-1600	Screw – Cap Hex Fl. Hd.	2
3	59-0580	Clamp – Wire, Alternator	1
4	59-0980	Screw – Tapping, Wash. Hd.	2
5	59-0830	Washer – Flat	2
6	59-0970	Screw – Tapping, Fl. Hd.	2
8	82-1540	Screw – Hex. Washer Hd.	1
7	71-6220	Clip – Wire	1
9	59-1080	Screw – Cap Hex. Fl. Hd.	4
10	71-6080	Bracket – Lift	2

Ref. No.	Part No.	Description	No. Used
12	92-0921	Housing – Cylinder Air, RH	1
15	59-0980	Screw – Tapping, Fl. Hd.	4
16	59-0820	Washer – Flat	4
17	NN10769	Housing – Blower	1
18	82-0620	Guard – Stationary	1
19	118530	Plate – Toro Logo	1
20	82-1590	Screw – Pan Hd. Taptite	4
21	59-1100	Screw – Lock Hd.	2
22	NN10832	Bracket – Governor Adjust	1


ENGINE CYLINDER BLOCK



ENGINE CYLINDER BLOCK

Ref. No.	Part No.	Description	No. Used
1	92-0900	Block - Cylinder (Short)	1
2	57-9760	Washer - Flat, Copper	1
3	57-8470	Plunger - Bypass Valve	1
4	59-0280	Spring - Bypass Valve	1
5	59-0910	Screw - Cap Hex Hd.	1
6	71-5790	Spring - Valve	4
7	71-5800	Washer - Valve Spring	4
8	NN10082	Lock - Valve Spring	8
9		Tappet - Valve	
9	57-8450	Standard	4
9	59-0260	.002" Oversize	4
10	82-0540	Tube - Breather	1
11	57-8580	Baffle - Breather Tube	1
12	82-0530	Clamp - Tube, Breather	1
13	82-0570	"O" Ring - Cap, Breather	1
14	82-0560	Screen - Tube, Breather	2
15	82-0550	Cap & Valve - Breather	1
16	82-1480	Screw - Tapping Round Hd.	1
17	71-5830	Cap - Valve	4
18	57-8280	Gasket - Valve Cover	2
19	NN10370	Screw - Cap Hex Hd.	2
20	57-9740	Washer - Flat, Copper	2
21	NN10821	Cover - Valve	1
22	59-0820	Washer - Flat	1
23	71-6180	Seal - Intake Valve	2
24	71-6250	Guide - Valve, Exhaust	2
24	71-6260	Guide - Valve, Intake	2
25	57-9690	Plug - Welch, Camshaft	1
26	59-0730	Pin - Drive, Bearing Stop	4
27	57-8010	Gasket - Bearing Plate	1
28	57-8170	Shim - Crankshaft .005"	A/R
29		Bearing - Crankshaft, Rear (Incl. Ref. #35)	
29	57-8050	Standard	1
29	59-0020	.002" Undersize	1
29	57-8060	.010" Undersize	1
29	59-0030	.020" Undersize	1
29	59-0040	.030" Undersize	1
30	82-0020	Plate - Bearing, Rear	1
31	57-9590	Seal - Oil, Crankshaft Rear	1
32	59-0880	Screw - Cap Flanged Hd.	5
33	3253-5	Washer	5
33	82-1310	Washer - Lock	5
34	3247-4	Setscrew - Socket Hd.	2
35	57-8160	Washer - Thrust	2
36		Insert - Valve Seat, Intake	
36	59-0050	Standard	2
36	59-0080	.010" Oversize	2
37	71-5770	Valve - Intake	2

Ref. No.	Part No.	Description	No. Used
38	57-8330	Gasket - Cylinder Head	2
39	79-6280	Head - Cylinder	2
39	59-0180	Side - Right	1
39	71-5810	Side - Left	1
40	57-9770	Washer - Flat	18
41	59-0900	Screw - Cap Hex Hd	18
42		Piston (Incl. Ref. #48-49)	
42	82-1800	Standard	2
42	92-0902	.010" Oversize	2
42	92-0903	.020" Oversize	2
42	92-0904	.030" Oversize	2
43		Rod - Connecting (Incl. Ref. #44 & 47)	
43	57-8420	Standard	2
43	57-8430	.010" Undersize	2
43	57-8440	.020" Undersize	2
43	59-0250	.030" Undersize	2
44	57-8410	Bolt - Connecting Rod	4
45	71-5780	Valve - Exhaust	2
46		Insert - Valve Seat, Exhaust	
46	59-0100	Standard	2
46	59-0110	.002" Oversize	2
46	59-0120	.005" Oversize	2
46	59-0130	.010" Oversize	2
46	59-0140	.025" Oversize	2
47	57-9790	Nut	4
48	57-9720	Ring - Retaining	4
49	71-6310	Pin - Piston	2
50		Kit - Ring, Piston	
50	92-0905	Standard	2
50	92-0906	.005" Oversize	2
50	92-0907	.010" Oversize	2
50	92-0908	.020" Oversize	2
50	92-0909	.030" Oversize	2
51	59-0290	Tube - Oil, Cylinder Block	1
52		Bearing - Crankshaft, Front, Flanged	
52	57-8020	Standard	1
52	57-9360	.002" Undersize	1
52	57-8030	.010" Undersize	1
52	57-9800	.020" Undersize	1
52	59-0010	.030" Undersize	1
53	59-0750	Pin - Alignment, Gear Cover	2
54	57-8480	Pump - Oil	1
55	82-1340	Washer - Flat	2
56	82-1370	Screw - Hex. Hd.	2
57	71-6290	Kit - Gasket Complete	1
58	57-8460	Gasket Kit - Oil Pump	1
59	57-8000	Bearing - Camshaft	2




C-2073

STARTER

Ref. No.	Part No.	Description	No. Used
1	79-6580	Screw - Hex. Hd.	2
2	57-9770	Washer - Flat	2
3	71-6040	Starter - Solenoid Shift, (Code 33AT)	1
4	62-2760	Kit - Hardware, Starter (Incl. (2) Solenoid Mtg Screws, 2 Thru Bolts, Armature Shims, Pinion Collar, & Retaining Ring)	1
5	NN10929	Kit - Mounting Bracket (Incl. Ref. #13)	1
6	NN10886	Seal - Dust	1
7	72-3940	Assembly - Clutch, Starter (Incl. Pinion Gear)	1

Ref. No.	Part No.	Description	No. Used
8	62-2770	Kit - Shift Lever, Starter (Incl. Lever, Wear Plate & Rubber Plug)	1
9	72-3930	Kit - Solenoid, Starter (Incl. Solenoid & Spring Plunger)	1
10	NN10930	Cap - Starter, Solenoid	1
11	92-9535	Nut	1
12	62-2760	Kit - Bushing, Starter (Incl. Rear Cap with Bushing & Front Bushing)	1
13	62-2740	Kit - Brush, Starter (Incl. (2) Negative & (1) Positive Brushes)	1




C-2062

BLOWER SCREEN & RING

Ref. No.	Part No.	Description	No. Used
1	57-8150	Screw - Cap Hex Hd.	1
2	82-1320	Washer - Flat	1
3	59-0810	Washer - Flat	1
4	79-6440	Screen - Air Inlet	1
5	71-5920	Flywheel (Incl. Ref. #6)	1

Ref. No.	Part No.	Description	No. Used
6	57-8180	Gear - Ring	1
7	71-6190	Key - Flywheel	1
8	71-6340	Screw	6




C-2063

CAMSHAFT & CRANKSHAFT

Ref. No.	Part No.	Description	No. Used
1	57-9090	Ring - Retaining	1
2	57-9130	Hub - Governor Cup	1
3	59-0450	Cup - Governor	1
4	57-9640	Ball - Governor	5
5	57-8210	Gear - Camshaft (Incl. Gear, Spacer, & Plate)	1
6	57-8230	Washer - Thrust, Special	1
7	59-0400	Pin - Center	1
8	57-9660	Key - Woodruff	1


Ref. No.	Part No.	Description	No. Used
9	71-6320	Camshaft (Incl. Ref. #7)	1
10	92-0911	Sleeve - Bearing	1
11	NN10773	Crankshaft (Incl. Ref. #15)	1
12	57-8130	Gear - Crankshaft	1
13	57-8140	Washer - Gear	1
14	57-9710	Ring - Retaining	1
15	57-9660	Key - Crankshaft Gear	1



C-2064

OIL FILL TUBE, BRACKET & BASE

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	82-1560	Screw – Pan Hd.	1	9	71-6170	Seal – Oil Fill Tube	1
2	79-6460	Bracket – Fill Tube	1	10	82-1130	Plug – Sq. Hd.	2
3	82-1700	Nut – Speed Type U	1	11	NN10448	Tube – Oil Fill	1
4	57-8490	Cup – Intake, Oil Pump	1	12	57-9610	"O"Ring	1
5	57-8090	Gasket – Oil Base	1	13	NN10159	Cap & Indicator – Oil Fill (Incl. Ref. #12)	1
6	82-1310	Washer – Flat	4				
7	NN10379	Screw – Cap Hex Hd.	4				
8	71-5730	Base – Oil (Incl. Ref. #10)	1				




C-2065

OIL FILTER AND LOW OIL PRESSURE CUT-OFF SWITCH

Ref. No.	Part No.	Description	No. Used
1	79-6470	Gasket - Oil Filter Adapter	1
2	82-0500	Adapter - Oil Filter	1
3	57-9750	Washer - Flat	2
4	NN10373	Screw - Cap Hex Hd.	2
5	92-0912	Elbow - Street 45°	1


Ref. No.	Part No.	Description	No. Used
6	NN10824	Switch - Low Oil Pressure	1
7	NN10143	Filter - Oil	1
8	82-0680	Filter - Gasket Oil	1
9	NN10894	Drain - Oil Filter	1
10	82-1510	Screw - Hex. Hd.	2



C-2066

GEARCASE & IGNITION CONTROLS

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	59-0950	Screw - Mach. Pan Hd.	2	16	82-1660	Washer - Int. Tooth Lock	2
2	59-0420	Yoke - Governor Shaft	1	17	NN10394	Screw - Hex Washer Hd.	2
3	NN10826	Shaft & Arm - Governor	1	18	59-0590	Terminal - Stator Leads	2
4	57-9730	Clip - Retaining, Control Rod To Governor Shaft	1	19	92-0967	Stator	1
5	57-9570	Seal - Oil, Governor Shaft	1	20	82-1500	Screw - Machine, Hex Hd.	3
6	57-9650	Bearing - Governor Shaft	1	21	57-9550	Clamp - Vacuum Port Cap	1
7	57-9630	Bearing - Ball, Gov. Shaft	1	22	59-0370	Cap - Vacuum Port	1
8	NN10895	Gasket - Gearcase Mtg.	1	23	59-0360	Tube - Vacuum Port	1
9	59-0740	Pin - Dowel, Governor	1	24	57-9750	Washer - Flat	5
10	3253-2	Washer - Lock	3	25	NN10545	Screw - Hex. Hd.	4
11	59-1080	Screw - Cap Hex. Wash. Hd.	1	26	57-9580	Seal - Oil, Crankshaft	1
12	57-9430	Regulator - Voltage 20 Amp	1	27	NN10825	Kit - Gearcase	1
13	82-1000	Body - Terminal Conn. Kit (Incl. Ref. #18)	2			(Incl. Ref. #1-3, 5-7, 9, 21-23 & 26)	1
14	71-6380	Control - Ignition	1	28	59-1130	Nut - Hex.	1
15	71-6410	Insulator - Ignition, Module	1	29	59-0790	Stud - Gear Cover	1




C-2067

IGNITION – ELECTRONIC

Ref. No.	Part No.	Description	No. Used
1	71-5990	Cover - Plunger, Ignition	1
2	82-1340	Washer - Flat	2
3	82-1360	Screw - Hex. Hd.	2
4	71-6440	Nut - Hex. Flange Hd. (Negative Terminal)	1
5	71-6430	Nut - Hex. Flange Hd. (Positive Terminal)	1
6	NN10545	Screw - Hex. Washer Hd.	2
7	71-6000	Coil - Battery Ignition (Incl. Ref. #4-5)	1

Ref. No.	Part No.	Description	No. Used
8	57-9340	Plug - Spark	2
9	NN10253	Cable - Spark Plug	2
10	71-6060	Clip - Wire (Attach To #1 Spark Plug Wire)	1
11	71-6220	Clip - Wire	2
12	71-6460	Screw - Hex Washer Hd.	1
13	71-6010	Rotor - Ignition	1
14	79-6490	Gasket - Plate	1




AIR CLEANER

Ref. No.	Part No.	Description	No. Used
1	NN10774	Element – Air Cleaner	1
2	NN10176	Wrapper – Element	1
3	79-6510	Spacer – Stud	1
4	92-0913	Nut – Wing	1
5	82-1670	Knob	1
6	NN10446	Cover – Air Cleaner Before Serial No. 5902947	1
*	94-1840	Cover – Air Cleaner After Serial No. 5902946	1
7	79-6520	Spacer – Rubber	1
8	82-0650	Cover – Element	1
9	82-1550	Screw – Hex. Washer Hd.	2
10	92-0915	Screw – Machine Hex. Hd.	2

Ref. No.	Part No.	Description	No. Used
11	79-6330	Housing – Air Cleaner	1
12	79-6340	Support – Air Cleaner	1
13	NN10390	Screw – Hex. Washer Hd.	1
14	59-1180	Capacitor	1
15	3253-5	Nut – Hex. Washer Hd.	1
16	71-6140	Grommet – Rubber	1
17	NN10187	Tube – Air Intake	1
18	NN10239	Fitting – Barbed	1
19	NN10190	Gasket	1
20	NN10132	Nut	1
21	82-1080	Clamp	1
22	NN10447	Hose	1


* Not Illustrated



GOVERNOR

Ref. No.	Part No.	Description	No. Used
1	72-3900	Screw - Tapping Hex Hd.	1
2	57-9190	Clamp - Cable	1
3	NN10508	Bracket - Cable	1
4	59-0830	Washer - Flat	2
5	59-1030	Screw - Tapping Hex. Hd.	1
6	59-0430	Spring - Idle Setting	1
7	79-6370	Arm - Governor Control Without Swivel	1
8	57-9100	Spring - Governor	1
9	57-9120	Bushing - Control Arm	1
10	79-6420	Adapter - Governor Arm	1
11	NN10357	Screw	1
12	59-1050	Screw - Self Tap. Fl. Hd.	1
13	NN10932	Spring - Governor	1

Ref. No.	Part No.	Description	No. Used
14	59-0720	Pin - Cotter	1
15	201270	Washer	1
16	57-9120	Swivel - Throttle Lever	1
17	72-3890	Screw - Hex. Hd.	1
18	82-1370	Screw - Hex. Hd.	1
19	82-1620	Washer - Lock	1
20	59-0830	Washer - Flat	1
21	201256	Link - Governor Control	1
22	79-6400	Bushing - Gov. Control	1
23	79-6390	Bracket - Gov. Control	1
24	57-9190	Clamp - Cable	1
25	59-1010	Screw - Self Tap. Fl. Hd.	1
26	201327	Screw	3




C-2069

INTAKE MANIFOLD

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	82-1120	Hose – Breather	1			NOT REPAIRABLE	
2	82-1080	Clamp – Hose 1/2" Dia.	2	+	94-1843	Kit – Float (Incl. Float & Gasket) After Serial No. 5902946	1
2	82-1090	Clamp – Hose .44" Dia.	1	+	94-1848	Jet – High (Fixed Main) After Serial No. 5902946	1
3	82-1070	Fitting – Barbed	1	+	94-1844	Kit – Repair (Accelecrator Pump) After Serial No. 5902947	1
4	NN10362	Washer – Flat	1	11	82-0850	Gasket – Carb/Manifold	1
5	57-9620	"O"Ring	1	12	NN10375	Screw – Hex. Hd.	4
6	57-9700	Clip – Retaining, Control Rod To Carburetor	1	13	82-1350	Washer – Flat	6
7	NN10227	Rod – Governor Control	1	14	92-0918	Manifold – Intake	1
8	NN10877	Spring – Governor Rod	1	15	NN10545	Screw – Hex. Hd.	2
9	57-9730	Clip – Retaining	1	16	71-5980	Gasket – Manifold To Block	2
10	62-2790	Assembly – Carburetor Before Serial No. 5902947 (Incl. Ref. #5 & 11)	1	17	82-1540	Screw – Hex. Washer Hd.	1
+	94-1847	Kit – Carburetor Low Emissiions After Serial No. 5902946 (Flange Gaskets)	1	18	NN10306	Hose – Fuel	1
				19	71-6220	Clip – Wire	1

+ Not Illustrated
NOT REPAIRABLE




C-2070

CARBURETOR ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	NN10811	Kit – Shaft, Throttle (Incl. Valve Setscrew, Air Filter, & Throttle Valve)	1
2	82-0780	Kit – Repair (Incl. Screw & Plug Package, Gasket Package, Float Valve, Idle Adj. Needle & Spring, Mounting Gaskets & Idle Limit Cap)	1
3	62-2800	Kit – Float (Incl. Float, Pin & Valve) Before Serial No 5902947	1
4	72-3860	Kit – Shaft, Choke	


Ref. No.	Part No.	Description	No. Used
5	72-3870	(Incl. Choke Valve, Valve Setscrew, & Air Filter) Kit – Lever, Choke (Incl. Choke Lever Ring, Choke Spring, & Choke Collar)	1
6	NN10859	Jet – Idle	1
7	57-9050	Jet – Power	1
8	NN10858	Jet – Power, Fixed, Optional (High Altitude Application) Before Serial No. 5902947	1
9	82-0850	Gasket – Carb. Mounting	2



C-2071

CHOKE CONTROL (FRONT PULL)

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	59-0470	Bracket - Choke Cable	1	7	NN10830	Plug - Cap	1
2	72-3880	Screw - Cap Flange Hd.	1	8	72-3890	Screw - Machine, Hex. Hd.	1
3	57-9180	Link - Choke	1	9	NN10656	Swivel - Choke Lever	1
4	57-9190	Clip - Choke Cable	1	10	59-0720	Pin - Cotter	1
5	72-3900	Screw - Flange Hd.	1	11	NN10511	Lever - Choke	1
6	92-0916	Screw - Shoulder	1	12	59-0850	Washer - Flat	1




C-2050

DRIVE BELT AND PULLEYS

Ref. No.	Part No.	Description	No. Used
1	323-6	Bolt	2
2	3253-21	Washer - Lock	2
3	108393	Fan	1
4	103995	Washer - Special	1
5	9080026	Bolt	1
7	108316	Pulley - Transmission Drive	1


Ref. No.	Part No.	Description	No. Used
8	937089	Key - Woodruff	1
9	114895	Belt - Drive	1
10	3246-2	Setscrew	2
11	7443	Pulley - Engine Drive	1
12	105453	Key	1



WHEELS AND TIRES

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	114428	Logo – Hub Cap 12"	2	12	114427	Logo – Hub Cap 8"	2
3	116971	Tire – Turf Trac, Rear 23 X 10.5-12	2	13	3272-12	Pin – Cotter	2
5	110680	Wheel – Rear	2	14	9202254	Washer	2
6	5108	Stem – Valve	4	15	109500	Fitting – Grease	2
7	83-2720	Bolt – Lug	10	16	117287	Wheel – Front (Incl. Item 15 & Qty. 2 of Item 8)	2
8	112821	Cup – Bearing	2	17	93-9807	Seal	2
9	112823	Bearing	2	18	112824	Spacer	2
10	32136-5	Nut – Slotted	2	19	116867	Tire – Turf Trac, Front 12 X 7.5-8	2
11	112825	Cap – Dust	2				

*Not Illustrated




C-2075

PTO CLUTCH & CONTROL

Ref. No.	Part No.	Description	No. Used
1	9038	Grip	1
2	32151-11	Ring - Retaining	1
3	5666	Bushing - Nyliner	1
4	5983	Bushing	1
5	3765	Washer - Shim	1
6	3272-10	Pin - Cotter	3
7	9335054	Pin - Cotter, Hair	1
8	323-7	Screw - Hex. Hd.	1
9	110669	Plate - PTO	1
10	110656	Trunnion	1
11	3253-3	Washer - Lock	2
12	113874	Bracket - Engine	1
13	104859	Spacer	1
14	3296-39	Nut - Lock	1
15	6659	Retainer	2
16	114881	Assembly - Plate	1
17	9080026	Bolt - Nylok	4
18	6658	Race - Bearing	1
19	6663	Seal - Oil	1
20	6662	Bearing - Needle	1

Ref. No.	Part No.	Description	No. Used
21	103478	Housing - Clutch	1
22	32120-72	Ring - Snap, External	2
23	109842	Bearing - Ball	1
24	32120-62	Ring - Snap, Internal	1
25	102872	Shaft - PTO	1
26	9335064	Pin - Cotter, Hair	1
27	106695	Ring - Push-On	1
28	3256-27	Washer - Flat	1
29	933274	Pin - Spirol	1
30	111314	Pin - Locking	1
31	113107	Clevis	1
32	113108	Rod - Housing, PTO	1
33	3229-25	Bolt - Carriage	2
34	110665	Assembly - Brake, PTO	1
35	3256-22	Washer - Flat	2
36	3218-1	Nut - Jam	2
37	111052	Rod - Clutch, PTO	1
38	103125	Spring	1
39	111234	Lever - Clutch, PTO	1

BATTERY & HEADLIGHTS ASSEMBLY




BATTERY & HEADLIGHTS ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	3296—42	Nut — Lock	5
2	3253—3	Washer — Lock	2
3	3256—22	Washer — Flat	4
4	321—4	Screw — Hex. Hd.	2
5	32103—22	Nut — Wing	2
6	113010	Rod — Battery Hold Down	1
7	109553	Cover — Terminal	1
8	113925	Cable — Battery, Pos.	1
9	113969	Hook — Battery Hold Down	2
10	114720	Tube — Drain	1
11	NN10274	Switch — High Engine Temp	1
12	94—1845	Switch — Low Oil Pressure	1
13	114052	Harness — Headlight	1
14	NN10278	Connector — Male	1
15	109357	Connector — Female	1
16	3023	Clip — Small	1

Ref. No.	Part No.	Description	No. Used
17	9266714	Bolt — Hex	2
18	109459	Clamp	2
19	8830	Clip	1
20	100571	Tie — Cable	A/R
21	102881	Headlight	2
22	71—6220	Clip	1
23	82—1540	Screw	1
24	NN10425	Washer — Int. Tooth	1
25	NN10279	Contact — Socket	1
26	NN10281	Connector — Male	1
27	94—1846	Harness — Engine Wiring	1
28	106948	Tray — Battery	1
29	115877	Battery — 280 CCA	1
30	114210	Cable — Battery, Ground	1
*	3290—378	Tie — Cable	7

*Not Illustrated

ELECTRICAL SYSTEM




ELECTRICAL SYSTEM

Ref. No.	Part No.	Description	No. Used
1	78-0030	Voltmeter (Incl. Ref. #2-4)	1
2	78-0080	Bracket - Mounting	2
3	3255-25	Washer - Lock	2
4	3217-27	Nut - Hex.	A/R
6	92-9844	Switch - Light	1
7	9109482	Screw	4
8	9157324	Nut - Elastic	6
9	78-0100	Bracket - Mounting	2
10	79-0450	Lamp - .938" Long	4
11	79-2660	Gauge - Vacuum (Incl. Ref. #3-4 & 9)	1
12	943021	Elbow	1
13	105076	Fitting - Straight	1
14	950154	Clamp - Corbin	1
15	114270	Sensor - Air Cleaner	1
16	114767	Clamp	1
17	114633	Terminal	12
18	114632	Connector - Male	1
19	79-2130	Board - Light Circuit	1
20	3256-21	Washer - Flat	2
21	3253-15	Washer - Lock	2
22	9107834	Screw	2
23	62-7770	Key - Padded Ignition	2
24	101884	Nut - Special	1
25	9201604	Washer - Lock	1
27	111216	Switch - Ignition (Incl. Ref. #24-25)	1
28	105302	Connector Body - Ignition Switch (Ref. Item #49)	1


Ref. No.	Part No.	Description	No. Used
29	3250-31	Screw (Optional)	4
30	105202	Base - Taillight w/Bulb	2
31	3254-1	Washer - Lock	4
32	3296-27	Nut	4
33	3023	Clip - Speed	2
34	109045	Bulb - Light (HD #193)	2
35	112564	Lens - Taillight	2
36	38-1420	Switch - Seat	1
37	113193	Switch - Trans. Oil Temp	1
38	111332	Switch - Interlock Snap	2
39	111498	Connector	4
40	115230	Switch - Clutch	1
41		Connector - Relay	3
42	116397	Relay	3
47	120930	Body - Fuse (Ref. Item #49)	1
48	114594	Fuse - 10 Amp, ATO or ATO	1
	109101	Fuse - 20 Amp, ATO or ATO	1
	NN10277	Fuse - 30 Amp, ATO or ATO	1
49	79-3630	Assembly - Wire Harness	1
50	78-3320	Bracket - Mounting	1
51	78-0020	Hourmeter (Incl. Ref. #3-4 & 49)	1
52	78-0060	Tachometer (Incl. Ref. #1, 3-4 & 52)	1
53	78-0090	Bracket - Mounting	1
54	78-0040	Gauge - Fuel (Incl. Ref. #2-4)	1
*	117257	Tie - Snap In	1

*Not Illustrated

WIRING DIAGRAM



DECALS



DECALS

Ref. No.	Part No.	Description	No. Used
1	92-9835	Decal - Hood RH	1
2	92-9834	Decal - Hood LH	1
3	111960	Decal - PTO Clutch	1
4	92-9827	Decal - Rear Fender	1
5	92-9826	Decal - Front Hood	1
6	118530	Plate - Toro Logo	1
7	119230	Decal - Front Panel	1
8	92-8946	Decal - Danger	1
9	92-9833	Decal - 520 Hydro	2
10	111926	Decal - Electrical System	1
11	92-8749	Decal - Unidrive	1

Ref. No.	Part No.	Description	No. Used
12	92-8747	Decal - Attach-A-Matic	1
13	116446	Decal - Do Not Tow	1
14	116445	Decal - Parking Brake	1
15	76-1340	Decal - Made in U.S.A.	1
16	92-9838	Decal - Danger	1
17	88-3200	Decal - Maintenance	1
18	118560	Decal - Power Plus	1
19	88-2790	Decal - Danger	1
20	92-9836	Plate - Wheel Horse Logo	1
21	78-8350	Decal - Indicator Lights	1

TORO PART NUMBER INDEX

3317—890

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
1121	Key — Sq.	9 13 1	101850	Rod — Hood Stop	2 13 1
1278	Washer — Shim	12 25 1	101853	Spring	14 49 1
1481	Fitting — Grease, 45°	18 21 2	101884	Nut — Special	44 24 1
1518	Bearing — Needle	11 32 1	101889	Gear — Differential Axle	10 15 2
1532	Bearing — Needle	10 21 2	102025	Spacer	13 24 1
1532	Bearing — Needle	11 31 2	102374	Pin — Pivot	9 15 1
1538	Bearing — Needle	11 20 1	102628	Fitting — Hyd., Straight	15 28 1
1644	Hitch — Drawbar	21 9 1	102628	Fitting — Straight Adapter	8 19 1
2844	Special Washer	12 14 1	102644	Plate — Mid Hitch	20 7 2
3023	Clip — Small	42 16 1	102809	Nut — Special, Flanged	13 21 1
3023	Clip — Speed	44 33 2	102872	Shaft — PTO	40 25 1
3765	Washer — Shim	40 5 1	102881	Headlight	42 21 2
3765	Washer — Shim	14 44 1	103125	Spring	40 38 1
5108	Stem — Valve	39 6 4	103125	Spring — Brake Return	12 6 1
5210	Washer — Shim	18 18 6	103478	Housing — Clutch	40 21 1
5618	Ring — Retaining	21 3 2	103995	Washer — Special	15 2 1
5618	Ring — Retaining	19 47 1	103995	Washer — Special	38 4 1
5666	Bushing — Nyliner	40 3 1	104047	Bushing — Rubber	7 19 1
5979	Bushing	2 8 2	104048	Valve — Fuel Shut—Off	7 20 1
5983	Bushing	40 4 1	104841	Spring	8 16 1
5983	Bushing	8 6 1	104859	Spacer	40 13 1
5983	Bushing	14 36 3	105061	Gear — Differential Ring	10 18 1
5991	Fitting — Filter	15 25 1	105076	Fitting — Straight	44 13 1
6216	Pin & Plate	18 2 1	105202	Base — Taillight w/Bulb	44 30 2
6229	Bearing	9 17 1	105269	Shaft — Drawbar Hitch	21 4 1
6449	Axle — Seal	10 6 1	105302	Connector Body — Ignition	44 28 1
6449	Axle — Seal	11 12 1	105316	Cap — Lock Rod	20 12 2
6472	Bearing — Flanged	18 3 1	105453	Key	38 12 1
6658	Race — Bearing	40 18 1	105503	Bushing	6 11 2
6659	Retainer	40 15 2	105524	Bracket — Pivot	6 14 2
6662	Bearing — Needle	40 20 1	105763	Hub — Rear	10 1 1
6663	Seal — Oil	40 19 1	105763	Hub — Rear	11 18 1
7443	Pulley — Engine Drive	38 11 1	105797	Ring — Retaining	20 2 8
7456	Bracket	5 13 4	105797	Ring — Retaining	2 9 2
7879	Bushing	14 43 1	105876	Ring — Retaining	10 16 2
7956	Washer — Thrust	11 25 1	106222	Footrest — RH	5 15 1
8616	Spring	20 1 2	106223	Footrest — LH	5 11 1
8830	"J"Clip	4 19 1	106236	Support — RH, Fuel Tank	6 29 1
8830	"J"Clip	15 22 1	106267	Grommet — Rubber	8 30 1
8830	"J"Clip	3 22 1	106269	Bearing — Flanged	9 8 2
8830	Clip	22 7 1	106448	Tube — Filler	10 9 1
8830	Clip	20 8 1	106522	Chain — Lift	9 4 1
8830	Clip	42 19 1	106634	Pin — Hitch	21 6 1
9038	Grip	40 1 1	106661	Cam — Eccentric	15 18 1
9038	Grip	20 10 1	106695	Ring — Push—On	40 27 1
9416	Bearing — Needle	10 7 1	106719	Drum — Brake	12 13 1
9416	Bearing — Needle	11 11 1	106826	Washer — Thrust	10 4 1
9547	Washer — Thrust	11 33 1	106826	Washer — Thrust	11 15 1
9548	Washer — Thrust	19 44 4	106948	Tray — Battery	42 28 1
9865	Bearing — Thrust	19 45 2	107069	Clip	5 14 2
100304	Spacer	13 12 2	107069	Nut — Speed	4 15 5
100305	Washer — Friction	15 10 2	107374	Washer — Special	11 4 4
100309	Bushing — Pivot, Cam	15 12 1	107938	Spring	14 41 1
100365	Washer — Spring, Disc	15 9 2	108312	Gasket — Case	11 8 1
100571	Tie — Cable	8 * 1	108316	Pulley — Transmission Drive	38 7 1
100571	Tie — Cable	42 20A/R	108316	Pulley — Transmission Drive	15 38 1
100656	Bearing — Cam	13 19 1	108319	Gasket — Pump	15 34 1
101017	Lock	20 16 1	108323	Base — Filter	15 26 1
101623	Gear — Differential Pinion	10 17 8	108325	Arm — Control, Speed	15 15 1
101699	Kit — Service, Cylinder	8 24 1	108326	Spacer — Pivot, Long	15 8 1
101707	Lock	20 19 1	108327	Spacer — Pivot, Short	15 39 1
101711	Housing — Front Hitch	20 14 1	108329	Plate, Control	15 5 1
101750	Rod	20 17 1	108333	Plate — Control, Speed	15 11 1
101751	Rod — Front Hitch Lock	20 3 1	108357	Seal — Oil	11 19 1
101757	Spacer	8 28 1	108361	Axle — Rear, LH Short	11 1 1

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
108362	Axle — Rear, RH Long	10 5 1	111383	Collar	12 3 1
108363	Pin — Dowel	11 28 2	111498	Connector	44 39 4
108364	Fitting — Hyd., Straight	15 36 1	111926	Decal — Electrical System	46 10 1
108365	Fitting — Hydraulic 90°	15 33 2	111960	Decal — PTO Clutch	46 3 1
108366	Spacer — Drive, Gear	15 32 1	111960	Decal — PTO Clutch	3 12 1
108368	Pump & Motor Asm, Eaton	15 35 1	112564	Lens — Taillight	44 35 2
108393	Fan	15 3 1	112602	Bearing — Output After	17 * 1
108393	Fan	38 3 1	112637	Housing — Pump Assembly	17 4 1
108457	Nut — Push On	4 2 1	112641	Cover Assembly	17 9 1
108457	Nut — Push On	5 18 1	112652	Shield — Grass	17 30 1
108464	Support — LH, Fuel Tank	6 27 1	112653	Ring — Retaining	17 31 1
108496	Rod — Pivot	14 34 1	112666	Bearing — Output Before	17 52 1
108680	Spring	12 11 1	112764	Spindle — Front, RH	19 41 1
108716	Plate — Cam	13 31 1	112765	Spindle — Front, LH	19 * 1
108717	Spacer	13 30 1	112771	Tie Rod End — Thread LH	19 40 2
108881	Nut	10 12 4	112772	Tie Rod End — Thread RH	19 35 2
108881	Nut	15 13 2	112773	Tube	19 37 2
108898	Clamp — Corbin	7 15 2	112775	Nut — Thread LH	19 38 2
108904	Rod Control	13 14 1	112791	Pulley — Idler	14 39 1
109045	Bulb — Light (HD #193)	44 34 2	112821	Cup — Bearing	39 8 2
109081	Kit — Service, Valve	8 * 1	112823	Bearing	39 9 2
109088	Kit — Service, Cylinder	8 25 1	112824	Spacer	39 18 2
109101	Fuse — 20 Amp, ATO or ATC44	1	112825	Cap — Dust	39 11 2
109189	Flange — Bearing	18 17 1	113010	Rod — Battery Hold Down	42 6 1
109356	Bushing	12 19 1	113023	Bracket — Fender	5 9 1
109357	Connector — Female	42 15 1	113107	Clevis	40 31 1
109367	Bracket — Brake	11 23 1	113108	Rod — Housing, PTO	40 32 1
109370	Shaft	11 26 1	113136	Race — Pump	17 16 1
109371	Band — Brake	12 17 1	113193	Switch — Trans. Oil Temp.	44 37 1
109372	Rod — Brake, Front	12 7 1	113358	Sender — Fuel Level	7 5 1
109459	Clamp	42 18 2	113372	Gasket	7 4 1
109494	Bezel — Headlight RH	2 20 1	113454	Control — Cam	13 11 1
109495	Bezel — Headlight LH	2 19 1	113874	Bracket — Engine	40 12 1
109500	Fitting — Grease	39 15 2	113925	Cable — Battery, Pos.	42 8 1
109553	Cover — Terminal	42 7 1	113932	Stiffener — Panel	3 15 1
109554	Bracket — Support, Guard	5 6 1	113962	Panel — RH	3 1 1
109703	Gear	11 34 1	113969	Hook — Battery Hold Down	42 9 2
109742	Gear 20 Tooth	11 30 1	114012	Tank — Fuel	7 3 1
109751	Gear — 20 Teeth	15 31 1	114027	Control — Choke	3 31 1
109752	Gear 46 Tooth	11 29 1	114052	Harness — Headlight	42 13 1
109842	Bearing — Ball	40 23 1	114210	Cable — Battery, Ground	42 30 1
109989	Spacer — Nylon	6 37 4	114215	Cover — Exhaust, Front	22 21 1
110124	Hose — Valve To Cylinder	8 29 1	114216	Cover — Exhaust, Rear	22 5 1
110125	Hose — Valve To Cylinder	8 18 1	114263	Spring — Seat	6 35 2
110189	Rod End Asm	13 13 2	114264	Adjuster — LH (With Latch)	6 36 1
110521	Line — Fuel 53	7 21 1	114265	Slide — RH	6 39 1
110634	Pad — Footrest R.H.	5 * 1	114270	Sensor — Air Cleaner	44 15 1
110635	Pad — Footrest L.H.	5 16 1	114343	Spring — Gas	6 21 1
110656	Trunnion	40 10 1	114344	Spacer	6 22 2
110665	Assembly — Brake, PTO	40 34 1	114345	Bracket — Gas Spring	6 23 1
110669	Plate — PTO	40 9 1	114427	Logo — Hub Cap 8	39 12 2
110680	Wheel — Rear	39 5 2	114594	Fuse — 10 Amp, ATO or ATC44	48 1
110768	Dipstick	10 10 1	114628	Bracket — Switch	3 17 1
110960	Fender	6 25 1	114632	Connector — Male	44 18 1
111052	Rod — Clutch, PTO	40 37 1	114633	Terminal	44 17 12
111071	Bumper	6 17 2	114636	Nipple	22 17 1
111196	Cap — Differential End	11 2 1	114641	Stop — Choke	3 14 1
111196	Cap — Differential End	10 13 1	114709???	Hood 113967 ???????	2 3 1
111199	Bearing — Ball	11 3 1	114720	Tube — Drain	42 10 1
111199	Bearing — Ball	10 19 1	114763	Pipe	22 16 1
111201	Case — Transaxle, LH	11 7 1	114764	Elbow 90°	22 9 1
111217	Tube — Suction	15 37 1	114767	Clamp	44 16 1
111234	Lever — Clutch, PTO	40 39 1	114823	Washer — Wave	14 45 2
111314	Pin — Locking	40 30 1	114881	Assembly — Plate	40 16 1
111332	Switch — Interlock Snap	44 38 2	114888	Screw	22 3 6

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

3317—890

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
114895	Belt — Drive	38 9 1	937099	Key — Woodruff	11 27 1
115230	Switch — Clutch	44 40 1	937108	Key — Woodruff	11 14 1
115392	Control — Throttle	3 30 1	937108	Key — Woodruff	10 22 1
115620	Cover — Console, 5—Gage	3 9 1	943021	Elbow	44 12 1
115783	Shield — Muffler	22 2 1	950154	Clamp — Corbin	44 14 1
115877	Battery — 280 CCA	42 29 1	973310	"O" Ring	8 17 4
116000	Bolt — Carriage	4 1 4	973370	"O" Ring	15 * 1
116000	Bolt — Carriage	5 12 4	973370	"O" Ring	8 20 4
116302	Arm — Control	8 8 1	9000369	Bolt	3 24 2
116305	Bracket — Control Rod	8 11 1	9080026	Bolt	15 1 1
116309	Bracket — Support, Battery	4 7 1	9080026	Bolt	38 5 1
116321	Arm — Control	14 51 1	9080026	Bolt — Nylok	40 17 4
116324	Rod Assembly	14 52 1	9080196	Screw — Hex. Hd.	15 19 1
116397	Relay	44 42 3	9080356	Bolt	11 6 1
116407	Rod End	13 9 2	9080376	Bolt	18 27 2
116445	Decal — Brake, Parking	4 12 1	9080406	Bolt	11 10 1
116445	Decal — Parking Brake	46 14 1	9080406	Screw — Hex. Hd.	15 6 1
116446	Decal — Do Not Tow	46 13 1	9107834	Screw	44 22 2
116446	Decal — Do Not Tow	6 30 1	9107922	Screw	3 28 4
116471	Muffler	22 6 1	9108372	Screw	5 17 1
116609	Plate — Engine	22 14 1	9108372	Screw — Black	3 5 8
116634	Knob — Hydraulic Lift	8 13 1	9108372	Screw — Black	4 9 3
116635	Knob — Motion Control	13 1 1	9108392	Screw	3 3 6
116745	Rod — Pivot	2 12 1	9108392	Screw	4 11 2
116746	Bracket — RH	2 7 1	9108652	Screw	6 38 4
116747	Bracket — LH	2 10 1	9109482	Screw	44 7 4
116823	Axle — Front	19 43 1	9114584	Bolt	13 18 2
116867	Tire — Turf Trac, Front	39 19 2	9150324	Nut	18 6 1
116971	Tire — Turf Trac, Rear	39 3 2	9157324	Nut — Elastic	44 8 6
117191	Bracket — Holder, Fuse	4 4 1	9157404	Nut	4 6 2
117257	Tie — Snap In	44 * 1	9157404	Nut — Lock	3 27 4
117267	Panel — Dash	3 7 1	9201604	Washer — Lock	44 25 1
117287	Wheel — Front	39 16 2	9202164	Washer	18 24 1
117328	Rod — Lift Control	8 9 1	9202254	Washer	39 14 2
117343	Keeper — Latch	3 19 2	9202324	Washer	8 27 1
117344	Latch — Hood	2 6 2	9202414	Washer	13 25 1
117432	Rivet — Pop	2 5 4	9202424	Spacer	19 31 4
117433	Rivet — RS Pop	3 20 4	9202624	Washer	18 9 1
117930	Latch — Mid Hitch	20 13 1	9266714	Bolt — Hex	42 17 2
118410	Cover — Steering	3 8 1	9266944	Bolt	5 3 2
118530	Plate — Toro Logo	23 19 1	9266944	Bolt	14 33 1
118530	Plate — Toro Logo	46 6 1	9266944	Bolt — Flange	6 18 2
118560	Decal — Power Plus	46 18 1	9266944	Screw — Hex. Hd.	4 13 14
118660	Guide — Control	13 4 1	9266944	Screw — Hex. Hd.	6 13 4
118780	Screw — Plastite	3 11 4	9266974	Bolt	7 2 2
118860	Knob	13 26 1	9321204	Pin — Clevis	8 3 1
119230	Decal — Front Panel	46 7 1	9329974	Pin — Clevis	8 23 1
119340	Cylinder — Hydraulic	8 26 1	9335044	Pin — Cotter	12 27 1
120400	Bar — Lift	9 20 1	9335054	Hairpin — Cotter	21 8 1
120930	Body — Fuse	44 47 1	9335054	Pin — Cotter	9 2 1
121100	Lever — Lift	9 11 1	9335054	Pin — Cotter	9 7 1
201256	Link — Governor Control	34 21 1	9335054	Pin — Cotter, Hair	40 7 1
201270	Washer	34 15 1	9335064	Pin — Cotter, Hair	40 26 1
201327	Screw	34 26 3	9335074	Pin — Cotter	9 12 2
518211	Bumper	5 10 2	9791204	Spacer	21 5 2
910807	Screw	7 6 5	111216	Switch — Ignition	44 27 1
911423	Bolt	11 5 4	12—3270	Screw — Hex. Hd.	22 4 3
915031	Nut	19 30 4	NN10048	Clamp	7 18 1
926671	Screw — Hex. Hd.	5 4 1	NN10082	Lock — Valve Spring	25 8 8
933135	Pin — Spirol	13 23 1	NN10132	Nut	33 20 1
933198	Pin — Spirol	13 3 1	NN10143	Filter — Oil	30 7 1
933198	Pin — Spirol	8 7 1	NN10159	Cap & Indicator — Oil Fill	29 13 1
933274	Pin — Spirol	40 29 1	NN10176	Wrapper — Element	33 2 1
937089	Key — Hi—Pro	15 7 1	NN10187	Tube — Air Intake	33 17 1
937089	Key — Woodruff	38 8 1	NN10190	Gasket	33 19 1

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
NN10211	Cap - Fuel Fitting	7 17 1	56-2980	Pin - Coil	17 21 1
NN10227	Rod - Governor Control	35 7 1	56-2990	Pintle Assembly (Inc. Ref. #1,1722	1
NN10239	Fitting - Barbed	33 18 1	56-3000	Ring - Retaining	17 23 2
NN10253	Cable - Spark Plug	32 9 2	56-3010	Ball	17 24 2
NN10274	Switch - High Engine Temp	42 11 1	56-3020	Body - Check Valve	17 25 2
NN10277	Fuse - 30 Amp, ATO or ATC44	1	56-3030	Ball	17 26 1
NN10278	Connector - Male	42 14 1	56-3040	Spring - Relief Valve	17 27 1
NN10279	Contact - Socket	42 25 1	56-3050	Plug - Relief Valve	17 28 1
NN10281	Connector - Male	42 26 1	56-3060	Pin - Dowel	17 29 1
NN10302	Line - Fuel 7	7 13	56-3090	Ring - Retaining	17 5 4
NN10306	Hose - Fuel	35 18 1	56-3100	Screw - Soc. Hd.	17 33 6
NN10357	Screw	34 11 1	56-3110	Roller	17 34 6
NN10362	Washer - Flat	35 4 1	56-3120	Carrier	17 35 1
NN10370	Screw - Hex. Hd.	25 19 2	56-3130	Seal - Oil	17 36 1
NN10373	Screw - Hex. Hd.	30 4 2	56-3140	Kit - Control Shaft	17 37 1
NN10375	Screw - Hex. Hd.	35 12 4	56-3170	Insert - Cam Ring	17 40 1
NN10379	Screw - Hex. Hd.	29 7 4	56-3180	Spring	17 41 2
NN10390	Screw - Hex. Washer Hd.	33 13 1	56-3200	Body - Acc. Valve	17 43 2
NN10394	Screw - Hex Washer Hd.	31 17 2	56-3210	Ball	17 44 2
NN10425	Washer - Int. Tooth	42 24 1	56-3220	Rotor / Ball - Motor	17 45 1
NN10446	Cover - Air Cleaner	33 6 1	56-3230	Shaft - Output	17 46 1
NN10447	Hose	33 22 1	56-3240	Race - Motor	17 47 1
NN10448	Tube - Oil Fill	29 11 1	56-3250	Plug - Asm	17 48 1
NN10508	Bracket - Cable	34 3 1	56-3260	"O"Ring	17 49 1
NN10511	Lever - Choke	37 11 1	56-3290	Ring - Retaining	17 53 1
NN10545	Screw - Hex. Hd.	35 15 2	56-3310	Kit - Seal, Overhaul	17 * 1
NN10545	Screw - Hex. Hd.	31 25 4	57-8000	Bearing - Camshaft	25 59 2
NN10545	Screw - Hex. Washer Hd.	32 6 2	57-8010	Gasket - Bearing Plate	25 27 1
NN10656	Swivel - Choke Lever	37 9 1	57-8020	Standard	25 52 1
NN10769	Housing - Blower	23 17 1	57-8030	.010 Undersize	25 52 1
NN10773	Crankshaft	28 11 1	57-8050	Standard	25 29 1
NN10774	Element - Air Cleaner	33 1 1	57-8060	.010 Undersize	25 29 1
NN10790	Line - Fuel 12	7 12 1	57-8090	Gasket - Oil Base	29 5 1
NN10811	Kit - Shaft, Throttle	36 1 1	57-8130	Gear - Crankshaft	28 12 1
NN10821	Cover - Valve	25 21 1	57-8140	Washer - Gear	28 13 1
NN10825	Kit - Gearcase	31 27 1	57-8150	Screw - Hex. Hd.	27 1 1
NN10830	Plug - Cap	37 7 1	57-8160	Washer - Thrust	25 35 2
NN10832	Bracket - Governor Adjust	23 22 1	57-8170	Shim - Crankshaft .005	25 28A/R
NN10858	Jet - Power, Fixed, Optional	36 8 1	57-8180	Gear - Ring	27 6 1
NN10859	Jet - Idle	36 6 1	57-8210	Gear - Camshaft	28 5 1
NN10877	Spring - Governor Rod	35 8 1	57-8230	Washer - Thrust, Special	28 6 1
NN10886	Seal - Dust	26 6 1	57-8280	Gasket - Valve Cover	25 18 2
NN10894	Drain - Oil Filter	30 9 1	57-8330	Gasket - Cylinder Head	25 38 2
NN10895	Gasket - Gearcase Mtg.	31 8 1	57-8410	Bolt - Connecting Rod	25 44 4
NN10929	Kit - Mounting Bracket	26 5 1	57-8420	Standard	25 43 2
NN10930	Cap - Starter, Solenoid	26 10 1	57-8430	.010 Undersize	25 43 2
NN10932	Spring - Governor	34 13 1	57-8440	.020 Undersize	25 43 2
38-1420	Switch - Seat	44 36 1	57-8450	Standard	25 9 4
55-3570	Cap - Fuel	7 9 1	57-8460	Gasket Kit - Oil Pump	25 58 1
56-2800	Screw - Hex. Hd. Soc.	17 1 1	57-8470	Plunger - Bypass Valve	25 3 1
56-2810	Bearing - Ball	17 2 1	57-8480	Pump - Oil	25 54 1
56-2820	Seal	17 3 2	57-8490	Cup - Intake, Oil Pump	29 4 1
56-2850	Ring - Seal	17 6 1	57-8580	Baffle - Breather Tube	25 11 1
56-2860	Plate - Pump	17 7 1	57-9050	Jet - Power	36 7 1
56-2870	Ring - Seal	17 8 1	57-9080	Pump - Fuel	7 14 1
56-2880	Button	17 10 2	57-9090	Ring - Retaining	28 1 1
56-2890	Pin - Dowel	17 11 1	57-9100	Spring - Governor	34 8 1
56-2900	Pin - Drive	17 12 1	57-9120	Bushing - Control Arm	34 9 1
56-2910	Shaft - Input	17 13 1	57-9120	Swivel - Throttle Lever	34 16 1
56-2920	Ring - Seal	17 14 1	57-9130	Hub - Governor Cup	28 2 1
56-2930	Rotor / Ball - Pump	17 15 1	57-9180	Link - Choke	37 3 1
56-2940	Ring - Cam	17 56 1	57-9190	Clamp - Cable	34 2 1
56-2950	Piston	17 18 2	57-9190	Clamp - Cable	34 24 1
56-2960	Ring - Back Up	17 19 2	57-9190	Clip - Choke Cable	37 4 1
56-2970	"O"Ring	17 20 2	57-9210	Gasket - Exhaust	22 20 2

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

3317-890

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
57-9340	Plug - Spark	32 8 2	59-0850	Washer - Flat	37 12 1
57-9360	.002 Undersize	25 52 1	59-0880	Screw - Flanged Hd.	25 32 5
57-9430	Regulator - Voltage 20 Amp	31 12 1	59-0900	Screw - Hex. Hd.	25 41 18
57-9550	Clamp - Vacuum Port Cap	31 21 1	59-0910	Screw - Hex. Hd.	25 5 1
57-9570	Seal - Oil, Governor Shaft	31 5 1	59-0950	Screw - Mach. Pan Hd.	31 1 2
57-9580	Seal - Oil, Crankshaft	31 26 1	59-0970	Screw - Tapping, Fl. Hd.	23 6 2
57-9590	Seal - Oil, Crankshaft Rear	25 31 1	59-0980	Screw - Tapping, Fl. Hd.	23 15 4
57-9610	"O"Ring	29 12 1	59-0980	Screw - Tapping, Wash. Hd.	23 4 2
57-9620	"O"Ring	35 5 1	59-1010	Screw - Self Tap. Fl. Hd.	34 25 1
57-9630	Bearing - Ball, Gov. Shaft	31 7 1	59-1030	Screw - Tapping Hex. Hd.	34 5 1
57-9640	Ball - Governor	28 4 5	59-1050	Screw - ST Pan Hd.	7 16 2
57-9650	Bearing - Governor Shaft	31 6 1	59-1050	Screw - Self Tap. Fl. Hd.	34 12 1
57-9660	Key - Crankshaft Gear	28 15 1	59-1080	Screw - Hex. Hd. Fl. Hd.	23 9 4
57-9660	Key - Woodruff	28 8 1	59-1080	Screw - Hex. Hd. Wash. Hd.	31 11 1
57-9690	Plug - Welch, Camshaft	25 25 1	59-1100	Screw - Lock Hd.	23 21 2
57-9700	Clip - Retaining, Control	35 6 1	59-1130	Nut - Hex.	31 28 1
57-9710	Ring - Retaining	28 14 1	59-1180	Capacitor	33 14 1
57-9720	Ring - Retaining	25 48 4	62-2740	Kit - Brush, Starter	26 13 1
57-9730	Clip - Retaining	35 9 1	62-2760	Kit - Bushing, Starter	26 12 1
57-9730	Clip - Retaining, Control Rod	31 4 1	62-2760	Kit - Hardware, Starter	26 4 1
57-9740	Washer - Flat, Copper	25 20 2	62-2770	Kit - Shift Lever, Starter	26 8 1
57-9750	Washer - Flat	30 3 2	62-2790	Assembly - Carburetor	35 10 1
57-9750	Washer - Flat	31 24 5	62-2800	Kit - Float	36 3 1
57-9760	Washer - Flat, Copper	25 2 1	62-7770	Key - Padded Ignition	44 23 2
57-9770	Washer - Flat	26 2 2	66-0120	Knob - Throttle Control	3 29 2
57-9770	Washer - Flat	25 40 18	71-5730	Base - Oil	29 8 1
57-9790	Nut	25 47 4	71-5770	Valve - Intake	25 37 2
57-9800	.020 Undersize	25 52 1	71-5780	Valve - Exhaust	25 45 2
59-0010	.030 Undersize	25 52 1	71-5790	Spring - Valve	25 6 4
59-0020	.002 Undersize	25 29 1	71-5800	Washer - Valve Spring	25 7 4
59-0030	.020 Undersize	25 29 1	71-5810	Side - Left	25 39 1
59-0040	.030 Undersize	25 29 1	71-5830	Cap - Valve	25 17 4
59-0050	Standard	25 36 2	71-5920	Flywheel	27 5 1
59-0080	.010 Oversize	25 36 2	71-5960	Filter - Fuel	7 11 1
59-0100	Standard	25 46 2	71-5980	Gasket - Manifold To Block	35 16 2
59-0110	.002 Oversize	25 46 2	71-5990	Cover - Plunger, Ignition	32 1 1
59-0120	.005 Oversize	25 46 2	71-6000	Coil - Battery Ignition	32 7 1
59-0130	.010 Oversize	25 46 2	71-6010	Rotor - Ignition	32 13 1
59-0140	.025 Oversize	25 46 2	71-6040	Starter - Solenoid Shift,	26 3 1
59-0180	Side - Right	25 39 1	71-6060	Clip - Wire	32 10 1
59-0250	.030 Undersize	25 43 2	71-6080	Bracket - Lift	23 10 2
59-0260	.002 Oversize	25 9 4	71-6140	Grommet - Rubber	33 16 1
59-0280	Spring - Bypass Valve	25 4 1	71-6170	Seal - Oil Fill Tube	29 9 1
59-0290	Tube - Oil, Cylinder Block	25 51 1	71-6180	Seal - Intake Valve	25 23 2
59-0360	Tube - Vacuum Port	31 23 1	71-6190	Key - Flywheel	27 7 1
59-0370	Cap - Vacuum Port	31 22 1	71-6220	Clip	42 22 1
59-0400	Pin - Center	28 7 1	71-6220	Clip - Wire	23 7 1
59-0420	Yoke - Governor Shaft	31 2 1	71-6220	Clip - Wire	32 11 2
59-0430	Spring - Idle Setting	34 6 1	71-6220	Clip - Wire	35 19 1
59-0450	Cup - Governor	28 3 1	71-6250	Guide - Valve, Exhaust	25 24 2
59-0470	Bracket - Choke Cable	37 1 1	71-6260	Guide - Valve, Intake	25 24 2
59-0580	Clamp - Wire, Alternator	23 3 1	71-6290	Kit - Gasket Complete	25 57 1
59-0590	Terminal - Stator Leads	31 18 2	71-6310	Pin - Piston	25 49 2
59-0720	Pin - Cotter	37 10 1	71-6320	Camshaft	28 9 1
59-0720	Pin - Cotter	34 14 1	71-6340	Screw	27 8 6
59-0730	Pin - Drive, Bearing Stop	25 26 4	71-6380	Control - Ignition	31 14 1
59-0740	Pin - Dowel, Governor	31 9 1	71-6410	Insulator - Ignition, Module	31 15 1
59-0750	Pin - Alignment, Gear Cover	25 53 2	71-6430	Nut - Hex. Flange Hd.	32 5 1
59-0790	Stud - Gear Cover	31 29 1	71-6440	Nut - Hex. Flange Hd.	32 4 1
59-0810	Washer - Flat	27 3 1	71-6460	Screw - Hex Washer Hd.	32 12 1
59-0820	Washer - Flat	23 16 4	72-3860	Kit - Shaft, Choke	36 4 1
59-0820	Washer - Flat	25 22 1	72-3870	Kit - Lever, Choke	36 5 1
59-0830	Washer - Flat	34 4 2	72-3880	Screw - Flange Hd.	37 2 1
59-0830	Washer - Flat	23 5 2	72-3890	Screw - Hex. Hd.	34 17 1
59-0830	Washer - Flat	34 20 1	72-3890	Screw - Machine, Hex. Hd.	37 8 1

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
72-3900	Screw - Flange Hd.	37 5 1	82-0550	Cap & Valve - Breather	25 15 1
72-3900	Screw - Tapping Hex. Hd.	34 1 1	82-0560	Screen - Tube, Breather	25 14 2
72-3930	Kit - Solenoid, Starter	26 9 1	82-0570	"O"Ring - Cap, Breather	25 13 1
72-3940	Assembly - Clutch, Starter	26 7 1	82-0620	Guard - Stationary	23 18 1
76-1340	Decal - Made in U.S.A.	46 15 1	82-0650	Cover - Element	33 8 1
76-1420	Steering Wheel	18 15 1	82-0680	Filter - Gasket Oil	30 8 1
78-0020	Hourmeter	44 51 1	82-0780	Kit - Repair	36 2 1
78-0030	Voltmeter	44 1 1	82-0850	Gasket - Carb. Mounting	36 9 2
78-0040	Gauge - Fuel	44 54 1	82-0850	Gasket - Carb/Manifold	35 11 1
78-0060	Tachometer	44 52 1	82-1000	Body - Terminal Conn. Kit	31 13 2
78-0080	Bracket - Mounting	44 2 2	82-1070	Fitting - Barbed	35 3 1
78-0090	Bracket - Mounting	44 53 1	82-1080	Clamp	33 21 1
78-0100	Bracket - Mounting	44 9 2	82-1080	Clamp - Hose	7 10 6
78-0370	Insert - Logo	18 14 1	82-1080	Clamp - Hose 1/2 Dia.	35 2 2
78-1411	Support - Steering	18 22 1	82-1090	Clamp - Hose .44 Dia.	35 2 1
78-1450	Shaft	18 20 1	82-1120	Hose - Breather	35 1 1
78-1481	Pinion	18 8 1	82-1130	Plug - Sq. Hd.	29 10 2
78-1490	Shaft - Lower Steering	19 32 1	82-1310	Washer - Flat	29 6 4
78-1531	Shim 0.010	18 25 3	82-1310	Washer - Lock	25 33 5
78-1540	Bracket - Control, Lower	3 25 1	82-1320	Washer - Flat	27 2 1
78-1540	Bracket - Control, Lower	14 47 1	82-1340	Washer - Flat	32 2 2
78-2680	Frame	20 9 1	82-1340	Washer - Flat	25 55 2
78-2990	Plate - Seat Pivot	6 15 1	82-1350	Nut	26 11 1
78-3320	Bracket - Mounting	44 50 1	82-1350	Washer - Flat	35 13 6
78-5631	Bracket - Control	13 5 1	82-1360	Screw - Hex. Hd.	32 3 2
78-5640	Bar - Lift	8 5 1	82-1370	Screw - Hex. Hd.	25 56 2
78-5660	Lever - Motion Control	13 2 1	82-1370	Screw - Hex. Hd.	34 18 1
78-6020	Rod - Pivot	14 40 1	82-1480	Screw - Tapping Round Hd.	2516 1
78-7740	Arm - Brake Pivot	12 18 1	82-1500	Screw - Machine, Hex Hd.	31 20 3
78-8350	Decal - Indicator Lights	46 21 1	82-1510	Screw - Hex. Hd.	30 10 2
78-8500	Lever - Parking Brake	13 22 1	82-1540	Screw	42 23 1
79-0450	Lamp - .938 Long	44 10 4	82-1540	Screw - Hex. Washer Hd.	23 8 1
79-1350	Pedal - Brake	12 1 1	82-1540	Screw - Hex. Washer Hd.	35 17 1
79-2130	Board - Light Circuit	44 19 1	82-1550	Screw - Hex. Washer Hd.	33 9 2
79-2660	Gauge - Vacuum	44 11 1	82-1560	Screw - Pan Hd.	29 1 1
79-3180	Terminal - Ground	7 7 1	82-1590	Screw - Pan Hd. Taptite	23 20 4
79-3630	Assembly - Wire Harness	44 49 1	82-1600	Screw - Hex. Hd. Fl. Hd.	23 2 2
79-4020	Plate - Front	4 18 1	82-1620	Washer - Lock	34 19 1
79-4890	Panel - LH	3 18 1	82-1660	Washer - Int. Tooth Lock	31 16 2
79-4990	Bracket - Support, Fender	6 28 1	82-1670	Knob	33 5 1
79-5020	Tube	15 29 1	82-1700	Nut - Speed Type U	29 3 1
79-5120	Hoodstand	4 14 1	82-1800	Standard	25 42 2
79-5130	Cover - Side, LH	4 16 1	83-2720	Bolt - Lug	39 7 10
79-5220	Engine - 20HP Toro Power	22 8 1	83-2820	Spring	14 53 1
79-5270	Filter - Oil	15 24 1	83-6520	Rod - Lock	20 15 1
79-5700	Bellcrank	9 14 1	86-9280	Tube - Hydraulic (Pressure)	8 21 1
79-5720	Trunnion	9 5 1	88-2790	Decal - Danger	46 19 1
79-6280	Head - Cylinder	25 39 2	88-2790	Decal - Danger	10 23 1
79-6330	Housing - Air Cleaner	33 11 1	88-3200	Decal - Maintenance	46 17 1
79-6340	Support - Air Cleaner	33 12 1	88-3220	Seat	6 1 1
79-6370	Arm - Governor Control	34 7 1	88-3230	Kit - Armrest	6 * 1
79-6390	Bracket - Gov. Control	34 23 1	88-3240	Block - Bearing	18 26 1
79-6400	Bushing - Gov. Control	34 22 1	92-0270	Washer	3 10 4
79-6420	Adapter - Governor Arm	34 10 1	92-0900	Block - Cylinder (Short)	25 1 1
79-6440	Screen - Air Inlet	27 4 1	92-0902	.010 Oversize	25 42 2
79-6460	Bracket - Fill Tube	29 2 1	92-0903	.020 Oversize	25 42 2
79-6470	Gasket - Oil Filter Adapter	30 1 1	92-0904	.030 Oversize	25 42 2
79-6490	Gasket - Plate	32 14 1	92-0905	Standard	25 50 2
79-6510	Spacer - Stud	33 3 1	92-0906	.005 Oversize	25 50 2
79-6520	Spacer - Rubber	33 7 1	92-0907	.010 Oversize	25 50 2
79-6580	Screw - Hex. Hd.	26 1 2	92-0908	.020 Oversize	25 50 2
82-0020	Plate - Bearing, Rear	25 30 1	92-0909	.030 Oversize	25 50 2
82-0500	Adapter - Oil Filter	30 2 1	92-0911	Sleeve - Bearing	28 10 1
82-0530	Clamp - Tube, Breather	25 12 1	92-0912	Elbow - Street 45°	30 5 1
82-0540	Tube - Breather	25 10 1	92-0913	Nut - Wing	33 4 1

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

3317-890

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
92-0915	Screw - Machine Hex. Hd.	33 10 2	321-4	Screw	8 10 1
92-0916	Screw - Shoulder	37 6 1	321-4	Screw - Hex. Hd.	42 4 2
92-0918	Manifold - Intake	35 14 1	321-6	Bolt	14 42 1
92-0920	Housing - Cylinder Air, LH	23 1 1	321-8	Bolt	6 19 2
92-0921	Housing - Cylinder Air, RH	23 12 1	321-9	Screw - Hex. Hd.	13 17 1
92-0967	Stator	31 19 1	321-11	Bolt	8 31 2
92-0986	Bracket - Arm L.H.	6 7 1	322-1	Bolt	19 33 1
92-0987	Bracket - Arm R.H.	6 3 1	322-1	Screw - Hex. Hd.	3 21 2
92-0988	Rest - Arm	6 4 2	322-2	Bolt	7 22 3
92-0989	Screw	6 5 2	322-3	Bolt	14 46 2
92-0990	Screw	6 8 2	322-3	Screw - Hex. Hd.	4 17 5
92-0991	Nut - Acorn Lock	6 9 2	322-3	Screw - Hex. Hd.	15 20 2
92-0992	Screw	6 2 6	322-3	Screw - Hex. Hd.	22 23 4
92-0993	Spacer - Nylon	6 6 4	322-3	Screw - Hex. Hd.	3 23 3
92-0995	Shaft - Upper Steering	18 12 1	322-3	Screw - Hex. Hd.	6 26 4
92-1527	Guard - Belt	5 2 1	322-4	Bolt	6 10 2
92-7293	Plate - Hoodstand, Top	4 8 1	322-5	Bolt	9 3 1
92-7295	Plate - Hoodstand, Rear	3 4 1	322-5	Screw - Hex. Hd.	5 7 2
92-7298	Case - Transaxle, RH	10 11 1	322-5	Screw - Hex. Hd.	6 33 4
92-8747	Decal - Attach-A-Matic	20 6 2	323-6	Bolt	18 4 2
92-8747	Decal - Attach-A-Matic	46 12 1	323-6	Bolt	38 1 2
92-8749	Decal - Unidrive	46 11 1	323-7	Screw - Hex. Hd.	22 10 4
92-8946	Decal - Danger	46 8 1	323-7	Screw - Hex. Hd.	40 8 1
92-8946	Decal - Danger	4 10 1	323-8	Bolt	13 28 1
92-9826	Decal - Front	2 2 1	323-8	Screw - Hex. Hd.	22 19 4
92-9826	Decal - Front Hood	46 5 1	323-8	Screw - Hex. Hd.	14 38 1
92-9827	Decal - Rear Fender	46 4 1	323-9	Bolt	18 11 6
92-9833	Decal - 520 Hydro	46 9 2	323-9	Bolt	12 20 1
92-9834	Decal - Hood LH	46 2 1	323-9	Bolt	13 27 1
92-9834	Decal - Hood LH	2 16 1	323-9	Screw - Hex. Hd.	11 24 1
92-9835	Decal - Hood RH	2 * 1	323-15	Bolt	11 9 2
92-9835	Decal - Hood RH	46 1 1	323-23	Bolt	12 15 1
92-9836	Plate - Wheel Horse Logo	46 20 1	323-25	Screw - Hex. Hd.	15 4 2
92-9836	Plate - Logo	2 1 1	323-25	Screw - Hex. Hd.	11 22 3
92-9838	Decal - Danger	3 13 1	323-26	Screw - Hex. Hd.	11 21 1
92-9838	Decal - Danger	46 16 1	323-44	Screw - Hex. Hd.	20 11 6
92-9848	Pump & Motor Asm, Eaton	15 * 1	3217-5	Nut	13 10 2
92-9844	Switch - Light	44 6 1	3217-7	Nut	22 12 4
93-1613	Latch - Front Hitch	20 18 1	3217-27	Nut - Hex.	44 4A/R
93-9807	Seal	39 17 2	3218-1	Nut - Jam	40 36 2
93-9810	Ring - Cam	17 17 1	3218-3	Nut	10 3 2
93-9811	Body Assembly	17 50 1	3218-3	Nut	11 17 2
93-9812	Body Assembly	17 * 1	3220-1	Nut	13 8 3
93-9814	Transaxle	10 * 1	3220-11	Nut	19 36 2
94-1802	Tube - Hydraulic (Return)	8 32 1	3229-25	Bolt - Carriage	2 11 4
94-1803	Deflector - Air	22 1 1	3229-25	Bolt - Carriage	40 33 2
94-1811	Engine - 20HP Toro Power	22 * 1	3230-1	Bolt - Carriage	5 5 1
94-1840	Cover - Air Cleaner	33 6 1	3231-25	Bolt - Carriage	20 5 3
94-1843	Kit - Float	36 * 1	3235-22	Bolt	12 16 1
94-1844	Kit - Repair (Accelerator	36 * 1	3235-22	Screw - Hex. Hd., Nylon	7 25 1
94-1845	Switch - Low Oil Pressure	42 12 1	3242-2	Screw - Set	15*40 2
94-1845	Switch - Low Oil Pressure	30 6 1	3243-5	Screw - Set	10 2 2
94-1847	Kit - Carburetor	35 * 1	3243-5	Screw - Set	11 16 2
94-1846	Harness - Engine Wiring	42 27 1	3245-32	Screw - Set	12 4 1
94-1848	Jet - High (Fixed Main)	36 * 1	3247-4	Setscrew - Socket Hd.	25 34 2
237-69	"O"Ring	18 13 1	3250-31	Screw (Optional)	44 29 4
281-10	Plug - Pipe	10 20 2	3253-2	Washer - Lock	31 10 3
281-10	Plug - Pipe	15 27 3	3253-3	Washer - Lock	42 2 2
288-4	Cap	22 15 1	3253-3	Washer - Lock	40 11 2
302-5	Fitting - Grease	12 26 1	3253-4	Washer - Lock	15 21 2
302-5	Fitting - Grease	19 39 4	3253-4	Washer - Lock	22 22 4
302-5	Fitting - Grease, Straight	19 46 2	3253-4	Washer - Lock	7 23 2
302-16	Fitting - Grease	19 28 1	3253-4	Washer - Lock	19 34 1
321-3	Screw - Hex. Hd.	4 3 2	3253-4	Washer - Lock	6 34 4
321-4	Bolt	13 6 2	3253-5	Nut - Hex. Washer Hd.	33 15 1

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
3253-5	Washer	25 33 5	3290-378	Tie - Cable	42 * 7
3253-15	Washer - Lock	44 21 2	3296-4	Nut	14 50 1
3253-17	Washer - Lock	7 8 5	3296-27	Nut	44 32 4
3253-21	Washer - Lock	21 2 4	3296-29	Nut	9 19 1
3253-21	Washer - Lock	38 2 2	3296-29	Nut	14 48 2
3253-21	Washer - Lock	22 11 4	3296-29	Nut	8 14 1
3254-1	Washer - Lock	44 31 4	3296-29	Nut - Lock	5 1 8
3254-2	Washer - Internal Tooth	2 18 1	3296-29	Nut - Lock	4 5 1
3254-8	Washer - Lock	19 48 1	3296-29	Nut - Lock	6 12 2
3255-25	Washer - Lock	44 3 2	3296-29	Nut - Lock	3 16 11
3256-4	Washer	7 1 2	3296-39	Nut	18 1 2
3256-4	Washer	12 22 1	3296-39	Nut	9 6 1
3256-4	Washer	13 29 2	3296-39	Nut	10 8 3
3256-6	Washer	12 23 2	3296-39	Nut	12 9 1
3256-21	Washer - Flat	44 20 2	3296-39	Nut	18 10 4
3256-22	Washer	13 16 2	3296-39	Nut	12 21 1
3256-22	Washer	2 17 3	3296-39	Nut	13 32 2
3256-22	Washer	6 20 2	3296-39	Nut	22 13 4
3256-22	Washer - Flat	42 3 4	3296-39	Nut - Lock	20 4 9
3256-22	Washer - Flat	40 35 2	3296-39	Nut - Lock	40 14 1
3256-23	Washer	9 18 1	3296-39	Nut - Lock	15 23 4
3256-23	Washer	6 24 4	3296-42	Nut	8 2 2
3256-23	Washer - Flat	5 8 2	3296-42	Nut	13 7 4
3256-23	Washer - Flat	3 26 4	3296-42	Nut	8 12 1
3256-23	Washer - Flat	8 15 2	3296-42	Nut - Lock	42 1 5
3256-24	Washer	12 10 2	3296-42	Nut - Lock	2 15 4
3256-24	Washer - Flat	22 18 4	3296-42	Nut - Lock	6 16 2
3256-26	Washer	9 1 1	3296-45	Nut - Lock	15 17 1
3256-26	Washer	18 7 1	32103-22	Nut - Wing	42 5 2
3256-26	Washer - Flat	21 7 1	32115-5	Nut - Speed	3 2 12
3256-26	Washer - Flat	15 16 1	32120-47	Ring - Retaining	9 16 1
3256-27	Washer - Flat	40 28 1	32120-47	Ring - Retaining	14 35 2
3256-62	Washer	9 9 3	32120-47	Ring - Retaining	13 20 4
3257-24	Key - Woodruff	15 14 1	32120-62	Ring - Snap, Internal	40 24 1
3272-1	Pin - Cotter	8 4 2	32120-64	Ring - Retaining	15 30 1
3272-1	Pin - Cotter	2 14 2	32120-72	Ring - Snap, External	40 22 2
3272-6	Pin - Cotter	12 24 2	32121-111	Pin - Spirol	18 16 1
3272-7	Pin - Cotter	19 29 4	32128-33	Nut - Lock, Flange Hd.	3 6 2
3272-10	Pin - Cotter	40 6 3	32136-5	Nut - Slotted	39 10 2
3272-11	Pin - Cotter	18 5 1	32146-17	Nut	13 15 1
3272-11	Pin - Cotter	12 8 2	32151-11	Ring - Retaining	40 2 1
3272-11	Pin - Cotter	8 22 1	32151-29	Ring - Retaining	19 42 2
3272-12	Pin - Cotter	39 13 2	32151-91	Ring - Retainer	9 10 2
3272-21	Pin - Cotter	18 19 1	32312-94	Pin - Spirol	14 37 1
3272-22	Pin - Cotter	18 23 1			

IDENTIFICATION AND ORDERING

MODEL AND SERIAL NUMBERS

The 520 H has two identification numbers; a model number and a serial number. The two numbers are stamped on a plate which is located on the main frame under the seat. In any correspondence concerning the 520H H, supply model and serial numbers to assure that correct information and replacement parts are obtained.

To order replacement parts from an Authorized TORO Service Dealer, supply the following information:

1. Model and serial number of the 520 H.
2. Part number, description, and the quantity of part(s) desired.

NOTE: Do not order by reference number if a parts catalog is being used; use the PART NUMBER.

TABLE OF CONTENTS

Description	Page	Description	Page
Hood Assembly	2	Blower Screen and Ring	27
Dash and Side Panels Assembly	3	Camshaft & Crankshaft	28
Hoodstand Assembly	4	Oil Fill Tube, Bracket & Base	29
Belt Guard and Footrest Assembly	5	Oil Filter and Low Oil Pressure Cut–Off Switch	30
Seat, Fender And Fender Supports	6	Gearcase & Ignition Controls	31
Fuel Tank And Fuel Pump	7	Ignition – Electronic	32
Hydraulic Control System	8	Air Cleaner	33
Hydrostatic Lift Linkage	9	Governor	34
Transaxle	10	Intake Manifold	35
Clutch, Brake & Speed Control Linkage	12	Carburetor Assembly	36
Clutch, Brake Motion Control Linkage	13	Choke Control (Front Pull)	37
Hydrostatic Transmission	15	Drive Belt and Pulleys	38
Eaton Hydrostatic Transmission #1100–062	16	Wheel and Tires	39
Front Axle And Steering	18	PTO Control & Clutch	40
Front & Side Hitch Assembly	20	Wiring Diagram	41
Rear Hitch Assembly	21	Battery & Headlights Assembly	42
Engine and Exhaust	22	Electrical System	44
Blower Housing	23	Decals	46
Engine Cylinder Block	24	Numerical Parts Index	47
Starter	26		

Optional Equipment

Description	Model / Part No.	Description	Model / Part No.
36" Rear Discharge Deck – Low Cut	78300	36" Tiller	79370
42" Side Discharge Deck – Low Cut	78346	Chrome Rear Hubcap w/logo	114428
48" Side Discharge Deck	78360	Tube Rear	109546
Rear Wheel Weights	81115	Tube Rear Cleat	100291
42" Rear Discharge Deck – Low Cut	78351	Tire Rear Cleat	7607
Rear Wheel Weights (Flush)	81117	Tube Front	100079
48" Dozer Blade	79350	Cleated Tire Wheel Asm LH	110933
Front Wheel Weights	81214	Cleated Tire Wheel Asm RH	110934
50" Grader Blade	79351	Wheel Rear Cleat	110677
Tire Chains	82522		
42" Single Stage Snowthrower	79360		
Clevis Hitch	85518		
44" Two Stage Snowthrower	79361		
*Auxiliary Fuel Tank	83300	Kits	
Vacuum/Blower (42" & 48" S.D. Mower Only)	79301	Front Weight	81125
Chrome Front Hubcap w/logo	114427	Recycler (42" R.D. Deck Only)	86001
		Dual Wheel	80732.D.
		Mower Only)	0701MC

* CAN NOT BE USED WITH CLEVIS HITCH OR REAR BAGGER

[illegible]