




# SERVICE/PARTS MANUAL

## MODELS: SB1600



**Mud Buggy™**

A 100% employee-owned American manufacturer



# Table of Contents

Mud Buggy

|                                           |                  |
|-------------------------------------------|------------------|
| <b>FOREWORD .....</b>                     | <b>5</b>         |
| <b>LIMITED WARRANTY .....</b>             | <b>6</b>         |
| <br><b>TECHNICAL DATA .....</b>           | <br><b>7-12</b>  |
| Machine Specifications .....              | 7                |
| Engine Specifications .....               | 8                |
| Lubrication Specifications .....          | 8                |
| Machine Sound Level Test .....            | 9                |
| Imperial Torque Chart .....               | 10               |
| Metric Torque Chart .....                 | 11               |
| Hardware Chart .....                      | 12               |
| <br><b>HEALTH &amp; SAFETY .....</b>      | <br><b>13-17</b> |
| <br><b>MAINTENANCE .....</b>              | <br><b>18-28</b> |
| Tasks .....                               | 18               |
| Know Your Buggy .....                     | 19               |
| Engine .....                              | 19               |
| Engine /Battery Policy .....              | 20               |
| Power Train/Transmission .....            | 21               |
| Chassis Lube .....                        | 22               |
| Brake Adjustment .....                    | 22               |
| Tires/Lugnuts and Hardware .....          | 23               |
| Changing Dual Wheel to Single Wheel ..... | 23               |
| Quick Release Wheel Option .....          | 23               |
| Hardware Guidelines .....                 | 23               |
| Fuel Tank .....                           | 24               |
| Cold Weather Starting .....               | 24               |
| Cleaning Machine .....                    | 24               |
| Parking/Transporting Buggy .....          | 24-25            |
| Lifting Points .....                      | 25               |
| Storage .....                             | 25-26            |
| Spring Start-Up .....                     | 26               |
| Troubleshooting .....                     | 27               |
| Service Record .....                      | 28               |

# Table of Contents

## Mud Buggy

|                                                           |                |
|-----------------------------------------------------------|----------------|
| <b>EXPLODED DIAGRAM AND PARTS LIST .....</b>              | <b>29-57</b>   |
| Frame Assembly/Cowl, Hopper, Splash Guard .....           | 30-31          |
| Engine and Pump Assembly .....                            | 32-35          |
| Wheelmotors and Brake Assembly .....                      | 36-37          |
| Brake Rods and Platform Lock Assembly .....               | 38-39          |
| Steering Assembly and Dump Platform Assembly .....        | 40-41          |
| Steering, Hydraulic Tank, Battery Assemblies .....        | 42-43          |
| Parking Brake, Hydraulic Valves and Filter Assembly ..... | 44-45          |
| Captivators, Heat Shield and Cylinder Assembly .....      | 46-47          |
| Pneumatic Tire with Standard Hubs Assembly .....          | 48-49          |
| Foam Tires and Quick Change Hubs Assembly .....           | 50-51          |
| Dump Pedal Assembly .....                                 | 52-53          |
| Option Steel Bucket Assembly .....                        | 54-55          |
| Hydraulic Diagram .....                                   | 56-57          |
| Hydraulic System Schematic .....                          | 58-59          |
| Wiring Schematic Recoil Start .....                       | 60             |
| Wiring Schematic Electric Start .....                     | 61             |
| Decal Identification .....                                | 62-63          |
| <br><b>CALIFORNIA PROPOSITION 65 WARNING .....</b>        | <br><b>IBC</b> |

# User Information

## Foreword

These instructions include:

Safety regulations  
Operating instructions  
Maintenance instructions

**These instructions have been prepared for operation on the construction site and for the maintenance engineer.**

These instructions are intended to simplify operation of the machine and to avoid malfunctions through improper operation.

Observing the maintenance instructions will increase the reliability and service life of the machine when used on the construction site and reduce repair costs and downtimes.

**Always keep these instructions at the place of use of the machine.**

**Only operate the machine as instructed and follow these instructions.**

**Observe the safety regulations as well as the guidelines of the civil engineering trade association. Observe the safety rules for operation and the pertinent regulations for the prevention of accidents.**

Stone Construction Equipment, Inc. is not liable for the function of the machine when used in an improper manner or for other than the intended purpose.

Operating errors, improper maintenance and the use of incorrect operating materials are not covered by the warranty.

The above information does not extend the warranty and liability conditions of business of Stone Construction Equipment, Inc.

1. Machine Type: \_\_\_\_\_

Machine S/N: \_\_\_\_\_

2. Engine Type: \_\_\_\_\_

Engine S/N: \_\_\_\_\_

3. VIN: \_\_\_\_\_

4. Purchase Date: \_\_\_\_\_

5. Dealer/Distributor Information:

Name: \_\_\_\_\_

Address: \_\_\_\_\_

\_\_\_\_\_

Phone #: \_\_\_\_\_

Fax #: \_\_\_\_\_

6. Battery  
Manufacturer: \_\_\_\_\_

Battery Type: \_\_\_\_\_

Battery S/N: \_\_\_\_\_

### ***Location of above information:***

1. Information on S/N tag.
2. Information on engine tag.
3. Information on S/N tag - if applicable.
4. Date you purchased machine.
5. Dealer machine was purchased from.
6. Information on battery and battery warranty card.

Stone Construction Equipment, Inc.  
P.O. Box 150, Honeoye, New York 14471  
Phone: (800) 888-9926  
Fax: (585) 229-2363

# L i m i t e d   W a r r a n t y

The Manufacturer warrants that products manufactured shall be free from defects in material and workmanship that develop under normal use for a period of 90 days for concrete vibrators and electric pumps, one year for Rhino®, Bulldog®, WolfPac Rollers™, trowels, Stompers®, saws, forward plates, engine powered pumps, Lift Jockey™, Mortar Buggy™ and 6 months for all other products from the date of shipment. The foregoing shall be the exclusive remedy of the buyer and the exclusive liability of the Manufacturer. Our warranty excludes normal replaceable wear items, i.e. gaskets, wear plates, seals, O-rings, V-belts, drive chains, clutches, etc. Any equipment, part or product which is furnished by the Manufacturer but manufactured by another, bears only the warranty given by such other manufacturer. (The Manufacturer extends the warranty period to "Lifetime" for the drum bearings and seals for the mortar mixers, and agrees to furnish, free of charge, the bearings and seals only upon receipt of the defective parts. The warranty is two years for eccentric bearings on the forward plate compactors, mortar and plaster mixer drums, trowel gearboxes and five years on the Bulldog trench roller eccentric bearings.) A Warranty Evaluation Form must accompany all defective parts. Warranty is voided by product abuse, alterations, and use of equipment in applications for which it was not intended, use of non-manufacturer parts, or failure to follow documented service instructions. The foregoing warranty is exclusive of all other warranties whether written or oral, expressed or implied. No warranty of merchantability or fitness for a particular purpose shall apply. The agents, dealer and employees of Manufacturer are not authorized to make modification to this warranty, or additional warranties binding on Manufacturer. Therefore, additional statements, whether oral or written, do not constitute warranty and should not be relied upon.

The Manufacturer's sole responsibility for any breach of the foregoing provision of this contract, with respect to any product or part not conforming to the Warranty or the description herein contained, is at its option (a) to repair, replace or refund such product or parts upon the prepaid return thereof to location designated specifically by the Manufacturer. Product returns not shipped prepaid or on an economical transportation basis will be refused (b) as an alternative to the foregoing modes of settlement - the Manufacturer's dealer to repair defective units with reimbursement for expenses, except labor, and be reviewed with the Manufacturer prior to repair. A Warranty Evaluation Form must accompany all warranty claims.

Except as set forth hereinabove and without limitation of the above, there are no warranties or other affirmations which extends beyond the description of the products and the fact hereof, or as to operational efficiency, product reliability or maintainability or compatibility with products furnished by others. In no event whether as a result of breach of contract or warranty or alleged negligence, shall the Manufacturer be liable for special or consequential damages including but not limited to: Loss of profits or revenues, loss of use of the product or any associated product, cost of capital, cost of substitute products, facilities or services or claims of customers.

No claim will be allowed for products lost or damaged in transit. Such claims should be filed with the carrier within fifteen days.

Effective September 2001.



Stone Construction Equipment, Inc. Phone: 1-800-888-9926 • 1-585-229-5141  
8662 Main Street, P. O. Box 150 Fax: 1-585-229-2363  
Honeoye, NY 14471-0150 www.stone-equip.com • e-mail: sceny@mcimail.com

# TECHNICAL DATA

## Specifications

### Stone Mud Buggy – Specifications

|                                  |                                                                                       |
|----------------------------------|---------------------------------------------------------------------------------------|
| <b>Model</b>                     | SB1600                                                                                |
| <b>Capacity (m<sup>3</sup>)</b>  | 16 Cu. Ft. (.45)                                                                      |
| <b>Weight (kg)</b>               | 1440 (655)                                                                            |
| <b>Length (cm)</b>               | 105.5 (268)                                                                           |
| <b>Width (single wheel) (cm)</b> | 33.75 (86)                                                                            |
| <b>Width (Double wheel) (cm)</b> | 46 (117)                                                                              |
| <b>Height (cm)</b>               | 45 (114,3)                                                                            |
| <b>Wheelbase (cm)</b>            | 42 (107)                                                                              |
| <b>Max. Load (kg)</b>            | 2500 (1136)                                                                           |
| <b>Tub</b>                       | Polyethylene                                                                          |
| <b>Engine (kW)</b>               | 13 hp. Honda (9,7)                                                                    |
| <b>Speed (km/h)</b>              | 6.8 mph (11)                                                                          |
| <b>Fuel Tank (l)</b>             | 7 gal. (26,5)                                                                         |
| <b>Discharge Height (cm)</b>     | 6.5 in (16.5)                                                                         |
| <b>Options</b>                   | Quick-Release<br>Removable Tires<br>Foam-filled Tires<br>Steel Drum<br>Electric Start |

# TECHNICAL DATA

## Engine & Lubrication Specs

### ENGINE SPECIFICATIONS

|                    |                                      |
|--------------------|--------------------------------------|
| Engine Type        | 13hp 4-cycle Overhead Valve (9.7 kW) |
| Engine Make        | Honda                                |
| Engine Model       | GX390                                |
| Power @ 2500 RPM   | 19.5 ft.lb. (26.5 Nm)                |
| Operating RPM      | 3900                                 |
| Battery            | 165 amp                              |
| Fuel Type          | Unleaded Gas                         |
| Fuel Tank Capacity | 7 gal (26.5 liter)                   |
| Fuel Consumption   | 1.14 gph (4.2 liter)                 |

### LUBRICATION SPECIFICATIONS

|                  | Type                         | Quantity              |
|------------------|------------------------------|-----------------------|
| Engine Crankcase | See Engine Manual            | 1.6 quarts/1.1 liter  |
| Hydraulic System | Mobilfluid 424 Hydraulic Oil | 30 quarts/28.39 liter |

# TECHNICAL DATA

## Sound Level Specs

|                                     |                                          |
|-------------------------------------|------------------------------------------|
| Machine Type:                       | Mud Buggy Material Handler               |
| Sound Level Meter Calibration Date: | February 15, 2000                        |
| Meter Type:                         | Simpson Model 886-2 Type 2               |
| Test Date:                          | September 20, 2001                       |
|                                     |                                          |
| <b>Test Conditions</b>              |                                          |
| Temperature:                        | 31 degrees Fahrenheit / 1 degree Celsius |
| Ambient Sound:                      | dba fast mode                            |
| Moisture Limit:                     | Approximately equal to 50%               |
| Engine speed:                       | 3600 rpm / 60 Hz                         |
| Test Site:                          | Honeoye, New York USA                    |
| Sound Level at Operator Position:   | 73 dba                                   |

# TECHNICAL DATA

## Imperial Torque Chart

| SAE GRADE 5<br>Coarse Thread, Zinc-Plated |          |       |
|-------------------------------------------|----------|-------|
| SIZE                                      | TORQUE   |       |
|                                           | ft. lbs. | Nm    |
| 1/4 - 20 (.250)                           | 6        | 8     |
| 5/16 - 18 (.3125)                         | 13       | 18    |
| 3/8 - 16 (.375)                           | 23       | 31    |
| 7/16 - 14 (.4375)                         | 37       | 50    |
| 1/2 - 13 (.500)                           | 57       | 77    |
| 9/16 - 12 (.5625)                         | 82       | 111   |
| 5/8 - 11 (.625)                           | 112      | 152   |
| 3/4 - 10 (.750)                           | 200      | 271   |
| 7/8 - 9 (.875)                            | 322      | 436.5 |
| 1 - 8 (1.000)                             | 483      | 655   |

| SAE GRADE 8<br>Coarse Thread, Zinc-Plated |          |     |
|-------------------------------------------|----------|-----|
| SIZE                                      | TORQUE   |     |
|                                           | ft. lbs. | Nm  |
| 1/4 - 20 (.250)                           | 9        | 12  |
| 5/16 - 18 (.3125)                         | 18       | 24  |
| 3/8 - 16 (.375)                           | 33       | 45  |
| 7/16 - 14 (.4375)                         | 52       | 70  |
| 1/2 - 13 (.500)                           | 80       | 108 |
| 9/16 - 12 (.5625)                         | 115      | 156 |
| 5/8 - 11 (.625)                           | 159      | 215 |
| 3/4 - 10 (.750)                           | 282      | 382 |
| 7/8 - 9 (.875)                            | 454      | 615 |
| 1 - 8 (1.000)                             | 682      | 925 |

| SAE GRADE 5<br>Fine Thread, Zinc-Plated |          |     |
|-----------------------------------------|----------|-----|
| SIZE                                    | TORQUE   |     |
|                                         | ft. lbs. | Nm  |
| 1/4 - 28 (.250)                         | 7        | 10  |
| 5/16 - 24 (.3125)                       | 14       | 19  |
| 3/8 - 24 (.375)                         | 26       | 35  |
| 7/16 - 20 (.4375)                       | 41       | 56  |
| 1/2 - 20 (.500)                         | 64       | 87  |
| 9/16 - 18 (.5625)                       | 91       | 123 |
| 5/8 - 18 (.625)                         | 128      | 173 |
| 3/4 - 16 (.750)                         | 223      | 302 |
| 7/8 - 14 (.875)                         | 355      | 481 |
| 1 - 12 (1.000)                          | 529      | 717 |
| 1 - 14 (1.000)                          | 541      | 733 |

| SAE GRADE 8<br>Fine Thread, Zinc-Plated |          |      |
|-----------------------------------------|----------|------|
| SIZE                                    | TORQUE   |      |
|                                         | ft. lbs. | Nm   |
| 1/4 - 28 (.250)                         | 10       | 14   |
| 5/16 - 24 (.3125)                       | 20       | 27   |
| 3/8 - 24 (.375)                         | 37       | 50   |
| 7/16 - 20 (.4375)                       | 58       | 79   |
| 1/2 - 20 (.500)                         | 90       | 122  |
| 9/16 - 18 (.5625)                       | 129      | 175  |
| 5/8 - 18 (.625)                         | 180      | 244  |
| 3/4 - 16 (.750)                         | 315      | 427  |
| 7/8 - 9 (.875)                          | 501      | 679  |
| 1 - 12 (1.000)                          | 746      | 1011 |
| 1 - 14 (1.000)                          | 764      | 1036 |

t-chrt\_i.doc

# TECHNICAL DATA

## Metric Torque Chart

### Property Class 8.8

ZINC-PLATED

| SIZE | Coarse Thread |          | Fine Thread |          |
|------|---------------|----------|-------------|----------|
|      | Nm            | ft. lbs. | Nm          | ft. lbs. |
| M6   | 9.9           | 7        | NA          | NA       |
| M8   | 24            | 18       | 25          | 18       |
| M10  | 48            | 35       | 49          | 36       |
| M12  | 83            | 61       | 88          | 65       |
| M14  | 132           | 97       | 140         | 103      |
| M16  | 200           | 148      | 210         | 155      |
| M20  | 390           | 288      | 425         | 313      |
| M24  | 675           | 498      | 720         | 531      |

### Property Class 10.9

ZINC-PLATED

| SIZE | Coarse Thread |          | Fine Thread |          |
|------|---------------|----------|-------------|----------|
|      | Nm            | ft. lbs. | Nm          | ft. lbs. |
| M6   | 14            | 10       | NA          | NA       |
| M8   | 34            | 25       | 35          | 26       |
| M10  | 67            | 49       | 68          | 50       |
| M12  | 117           | 86       | 125         | 92       |
| M14  | 185           | 136      | 192         | 142      |
| M16  | 285           | 210      | 295         | 218      |
| M20  | 550           | 406      | 600         | 443      |
| M24  | 950           | 701      | 1000        | 738      |

### Property Class 12.9


ZINC-PLATED

| SIZE | Coarse Thread |          | Fine Thread |          |
|------|---------------|----------|-------------|----------|
|      | Nm            | ft. lbs. | Nm          | ft. lbs. |
| M6   | 16.5          | 12       | NA          | NA       |
| M8   | 40            | 30       | 42          | 31       |
| M10  | 81            | 60       | 82          | 60       |
| M12  | 140           | 103      | 150         | 111      |
| M14  | 220           | 162      | 235         | 173      |
| M16  | 340           | 251      | 350         | 258      |
| M20  | 660           | 487      | 720         | 531      |
| M24  | 1140          | 841      | 1200        | 885      |

Conversion Factor: 1 ft. lb. = 1.3558 Nm

# TECHNICAL DATA

## Hardware



# HEALTH & SAFETY


## Safety Precautions

Before using this equipment, study this entire manual to become familiar with its operation. Do not allow untrained or unauthorized personnel, especially children, to operate this equipment. Use only factory authorized parts for service.

When warning decals are destroyed or missing, contact the Manufacturer immediately at 1-800-888-9926 for replacement. For the safety of yourself and others, it is imperative that the following rules are observed. Failure to do so may result in serious injury or death.

### FOLLOW SAFETY INSTRUCTIONS

Carefully read all safety messages and decals in this manual and on your machine safety signs. Keep decals in good condition. Replace missing or damaged decals. Be sure new equipment components and repair parts include the current safety signs. Replacement safety signs and decals are available through your dealer.



Learn how to operate the machine and how to use controls properly. Do not let anyone operate without instruction.

Keep your machine in proper working condition. Unauthorized modifications to the machine may impair the function and/or safety and affect machine life.

If you do not understand any part of this manual and need assistance, contact your dealer.



This notation appears before warnings in the text. It means that the step which follows must be carried out to avoid the possibility of personal injury or death. These warnings are intended to help the technician avoid any potential hazards encountered in the normal service procedures. We strongly recommend that the reader takes advantage of the information provided to prevent personal injury or injury to others.

**⚠ DANGER**

**⚠ WARNING**

**⚠ CAUTION**

### UNDERSTAND SIGNAL WORDS

A signal word – DANGER, WARNING, or CAUTION – is used with the safety-alert symbol. DANGER identifies the most serious hazards.

DANGER or WARNING safety signs are located near specific hazards. General precautions are listed on CAUTION safety signs. CAUTION also calls attention to safety messages in this manual.

# HEALTH & SAFETY

## Safety Precautions



### USE COMMON SENSE WHEN HANDLING FUELS

- Transport and handle fuel only when contained in approved safety container.
- Do not smoke when refueling or during any other fuel handling operation.
- Do not refuel while the engine is running or while it is still hot.
- If fuel is spilled during refueling, wipe it off from the engine immediately and discard the rag in a safe place.
- Do not operate the equipment if fuel or oil leaks exist - repair immediately.
- Never operate this equipment in an explosive atmosphere.



- Always use the proper size grounded extension cord, conforming to the National Electric Code and Local Ordinances.
- Inspect all extensions and electrical cords for cuts, frayed wire and broken connectors before use. Do not use cords if not in good condition.
- Do not route extension cords through standing water.
- Do not operate the equipment in standing water.
- When cleaning the equipment, never spray water on the electric motor.



### HOT SURFACES

- Avoid contact with hot exhaust systems and engines.
- Allow all components in the engine compartment to cool before performing any service work.

## **WARNING**

- Never leave equipment unattended while running.
- Be certain you can control both speed and direction before moving.
- This is a one-person buggy. Never permit riders.
- Avoid sharp turns at high speed.

# HEALTH & SAFETY


## Safety Precautions




- Never perform any work on the equipment while it is running.
- Before working on the equipment, stop the engine and disconnect the spark plug wire(s) to prevent accidental starting. On electric models, disconnect the electric cord at the equipment.
- Keep cowl closed and latched during the operation, close and latch cowl immediately after starting.
- Keep hands, clothing and jewelry away from all moving parts.
- Keep all guards in place.

---

### WEAR PROTECTIVE CLOTHING



- Wear close fitting clothing and safety equipment appropriate to the job.
- Prolonged exposure to loud noise can cause impairment or loss of hearing.
- Wear a suitable hearing protective device such as earmuffs or earplugs to protect against objectionable or uncomfortable loud noises.
- Operating equipment safely requires the full attention of the operator. Do not wear radio or music headphones while operating machine.



---

### PREPARE FOR EMERGENCIES

- Be prepared if a fire starts.
- Keep a first aid kit and fire extinguisher handy.
- Keep emergency numbers for doctors, ambulance service, hospital, and fire department near your telephone.

# HEALTH & SAFETY

## Safety Precautions

---




### Warning-Eye Protection

- Always wear splash goggles when operating equipment.



- 
- Starting fluid (ether) is highly flammable, do not use or an explosion or fire may result.



- 
- Never operate unit in a poorly ventilated or enclosed area.
  - Avoid prolonged breathing of exhaust gases.
  - Engine exhaust fumes can cause sickness or death.

# HEALTH & SAFETY

## Safety Precautions


### PRACTICE SAFE MAINTENANCE



- Understand service procedure before doing work. Keep area clean and dry.
- Never lubricate, service or adjust machine while it is moving. Keep hands, feet, and clothing from power-driven parts. Disengage all power and operate controls to relieve pressure. Lower equipment to the ground. Stop the engine. Remove the key. Allow machine to cool.
- Securely support any machine elements that must be raised for service work.
- Keep all parts in good condition and properly installed. Repair damage immediately. Replace worn or broken parts. Remove any buildup of grease, oil, or debris.
- Disconnect battery ground cable (-) before making adjustments on electrical systems or welding on machine.

---

### DISPOSE OF WASTE PROPERLY



- Improperly disposing of waste can threaten the environment and ecology. Potentially harmful waste used with equipment include such items as oil, fuel, coolant, brake fluid, filters, and batteries.
- Use leakproof containers when draining fluids. Do not use food or beverage containers that may mislead someone into drinking from them.
- Do not pour waste onto the ground, down a drain, or into any water source.
- Air conditioning refrigerants escaping into the air can damage the Earth's atmosphere. Government regulations may require a certified air conditioning service center to recover and recycle used air conditioning refrigerants.
- Inquire on the proper way to recycle or dispose of waste from your local environmental or recycling center.

---

**DECALS - FOR THE SAFETY OF YOURSELF AND OTHERS REPLACE ANY DAMAGED OR MISSING SAFETY DECALS. SEE DECAL IDENTIFICATION SECTION.**



### **IMPORTANT**

**The person attempting *any* of the following maintenance tasks must be authorized to do so and have read *and* understood *all* sections within this manual.**

# MAINTENANCE

## Know Your Buggy/Engine

### Know Your Buggy

Read and understand the owner's manual before starting the unit. Make sure you understand the purpose of every control. When operating the unit, remember the capacity it can carry and adjust speed and load for changing conditions.

**Inspect Machinery**--A daily inspection of the unit is recommended to insure all systems are in proper working orders.

**Check Travel Path**--Inspect the surface on which the unit is going to travel. Avoid soft soil, slippery spots, and water spots. Look for anything that will make you lose control.

**Machine Cleanliness**--Keep unit clean of all debris. Make sure foot stand stays clean to prevent accidents.

### ENGINE

Refer to engine manual for specific engine information.

**Oil Fill Location**--checking and filling oil is accomplished through the opening on side of engine. Fill oil until level with filler opening.

**Oil Grade and Capacity**--Engine requires 1.16 quarts/1.1 liter.

- Over 40 Degrees Fahrenheit/13 Degrees Celsius SAE 30
- Below 40 Degrees Fahrenheit/13 Degrees Celsius SAE 20

**Air Filter**--Check air filter before each use and clean after every 50 hours of service.

Clean primary (outer) element at 40 hours (after break-in period) then every 500 hours or 12 months.

Service air cleaner more frequently in dusty conditions.

**IMPORTANT:** DO NOT operate engine without the filter cover.

1. Remove air cleaner cover.
2. Remove primary (outer) element only.
3. Thoroughly clean all dirt from inside filter housing. Insert the cleaning gun into element, hold air nozzle about 1" (25.4 mm) from perforated metal retainer. Force air through filter from inside to outside and move air gun up and down pleats to remove as much dirt as possible.

**IMPORTANT:** Only a special air cleaning gun should be used. Concentrated air pressure from an ordinary nozzle may severely damage filter element. DO NOT exceed 30 PSI (2.1 bar) when cleaning filter element.

4. Inspect filter to determine if it is practical to clean or for damage after cleaning filter. If necessary, repeat step one to remove additional dirt.
  - a. Hold a bright light inside element and check carefully for holes. Discard any element that shows the smallest hole or rupture.
  - b. Be sure outer screen is not dented. Vibration would quickly wear a hole in filter.
  - c. Be sure filter gasket is in good condition. If gasket is damaged or missing, replace element.
5. Gently pat sides of element with palm of hand to loosen dirt. DO NOT tap element against a hard surface.

**Electric Start Option**--Inspect battery connections daily for cleanliness and tightness. Replace worn or frayed wires.

# MAINTENANCE

## Engine/Battery Policy

**Battery**--Battery replacement is a Crown U1-12 or equal 165 CCA battery. See Engine Specifications Section for battery requirements.

Battery vapors can explode. Keep sparks and flames away from batteries. Use a flashlight to check battery electrolyte level. Never check battery charge by placing a metal object across the posts. Use a voltmeter or hydrometer. Sulfuric acid in battery electrolyte is poisonous. It is strong enough to burn skin, eat holes in clothing, and cause blindness if splashed into eyes.

Avoid the hazard by:

- Filling batteries in a well-ventilated area.
- Wearing eye protection and rubber gloves.
- Avoid breathing fumes when electrolyte is added.
- Avoid spilling or dripping electrolyte.
- Use proper jump start procedures.

If you spill acid on yourself:

- Flush your skin with water.
- Apply baking soda or lime to help neutralize the acid.
- Flush your eyes with water for 10 - 15 minutes. Get medical attention immediately.

If acid is swallowed:

- Drink large amounts of water or milk.
  - Then drink milk of magnesia, beaten eggs, or vegetable oil.
  - Get medical attention immediately.
- Once a month check the battery condition. With engine off, check the battery for 12.5 volts with a voltmeter or check the specific gravity of the electrolyte fluid in each cell.
  - Check for proper electrolyte fluid level. Use distilled water when adding and run 30 minutes to mix. Clean battery, posts, and terminals. Disconnect battery cables before

charging to avoid damage to the electrical system.

- Once a month, check the charging system with the engine running at full speed for 13 - 14 volts with a voltmeter to ensure engine voltmeter readings are correct.
- Keep batteries clean by wiping them with a damp cloth. Keep all connections clean and tight. Remove any corrosion and wash terminals with a solution of 1 part baking soda and 4 parts water. Tighten all connections and check that the battery is securely fastened with properly installed hold downs.

**NOTE:** Coat battery terminals and connectors with a mixture of petroleum jelly and baking soda to retard corrosion.

- Keep battery fully charged, especially during cold weather. If a battery charger is used, turn charger off before connecting charger to battery. Attach POSITIVE (+) battery charger lead to POSITIVE (+) battery post. Then attach NEGATIVE (-) battery charger lead to a good ground.

### Battery Policy

Battery warranty begins when equipment is sold from Stone Construction Equipment, Inc. or a Stone dealer to a customer.

Battery warranty claims must include the unit's purchase receipt with date. Claims without purchase receipt will be based on the battery identification numbers.

Battery returns and/or adjustments are made through battery distributors.

For nearest Crown distributor call: 1-800-237-6126.

# MAINTENANCE

## Power Train/Transmission

### Power Train

See Lubrication Specifications Section. Check hydraulic oil level daily using the sight gauge located on the hydraulic tank. A 1/2- 3/4" air bubble will be seen at the top of the gauge. Keep filled to proper level with Mobil 424 Hydraulic oil or equivalent. Your local oil vendor can determine compatible oils. Mobil 424 Hydraulic Oil or equivalent should be changed every 200 hours. The Hydraulic Oil Filter needs to be changed every time the Hydraulic Oil is changed. For temperatures below 35 degrees, oil should be switched to thinner 15 weight hydraulic fluid.


For satisfactory operation, the following oil conditions apply:

- Accurate level readings can be checked only when the fluid is cold and machine is on level ground.
- If the natural color of the fluid has become black or milky, it is possible that an overheating or water contaminant problem exists.
- DO NOT mix hydraulic fluids. See Lubrications Specifications Section for hydraulic system recommendations.
- Add hydraulic oil through breather tube. Pour hydraulic oil through strainer basket into hydraulic tank.


The hydraulic drive motors are extremely reliable and will ordinarily not need maintenance or repair. If a vibration is experienced with engine running, check the coupler between the engine and the hydraulic pump. Do not make this inspection while engine is running. It will be necessary to remove the inspection cover. After adjusting and tightening the coupler, replace the inspection cover and then start engine to see if the problem has been corrected. Do not run the engine or operate the buggy with the cover removed or not firmly attached.

**CAUTION:** This breather is designed to pressurize the reservoir to 5 PSI. Loosen cap slowly to avoid injury whenever adding oil or working on the hydraulic system. Use a wrench on the hex directly under the cap.

### Transmission




The hydrostatic transmission is properly adjusted when no movement of the unit is visible.



# MAINTENANCE

## Chassis Lube/Brake Adjust



**Cylinder Points**

**Adjustment**--To adjust transmission, loose jam nut on swash plate control arm. Turn adjustment bolt in until unit stops creeping. Tighten jam nut.

### Chassis Grease/Lube Points

See Lubrication Specifications for requirements.

- **Pivot Points (2 fitting)**
- **Cylinder Pivots (2 fittings)**
- **Tub Pivots (2 fittings)**
- **Steering Pivots (1 fitting--located on steering housing)**
- **Wheel Bearings--repack bearings yearly**



**Pivot Points**

Grease weekly using a grease gun. Remove the blue protection caps before greasing and replace when finished.


**Moving Joints, Hinges, Throttle, Controls, Cables**--Lubricate with oil every 500 hours.

### Brake Adjustments

Brakes are adjusted at factory and will need to be adjusted as brake shoes wear. Check operation daily. Adjust at 25 hours then as needed.

**Service Brake Adjustment**--Brake adjustment rods need adjusting in equal amounts. Jack machine up so that front tire is off ground. Remove clevis pin from yoke. While screwing yoke, keep count of number of turns for repeating the same procedure on other side until brake is adjusted.

**Parking Brake Adjustment**--Turning the knob on the parking brake handle clockwise can make fine-tuning to the parking brakes.



**Brake Adjustment Rods**

# MAINTENANCE

## Tires, Lugnuts and Hardware/Changing Dual Wheel

### Tires, Lugnuts and Hardware

DO NOT exceed rated pressure. To ensure long tire life and safe handling check tire pressure daily. Proper inflation pressure on pneumatic filled tire is 50 lbs/(3.5 Bar).

1. Check the pressure in tires weekly using a pressure gauge. See Machine Specifications Section for tire pressure.
2. Check that all lugnuts are tight weekly using a torque of 90 in. lbs. (122 Nm). This is important on new machines or newly replaced wheels.



Figure 7

3. Inspect all hardware is tight weekly (see Torque Charts Section).

**NOTE:** When installing or replacing hardware, loctite 262 threadlocker is required to prevent loosening.

**Proper Care--**Inspect tires for cuts, slashes, or bulges. Tires with defects need to be replaced or repaired for proper handling and safety.

### Changing Dual Wheel to Single Wheel

#### Standard Machine

1. Jack machine. Apply parking brake.
2. Remove five (5) lug bolts.
3. Remove outer wheel.
4. Remove five (5) lug nuts from inner dual wheel adapter then remove adapter.
5. Replace five (5) lug nuts on inner wheel and torque to 32 ft. lbs.
6. Repeat above steps on opposite side of machine.

**Note:** Maximum payload reduced by 25% when operating machine without dual wheels.

#### Quick Release Wheel Option

1. Position machine inner wheel over 2x4 and apply parking brake.
2. Remove large tee bolt in center of wheel with crow bar (figure 7).
3. Remove outside wheel with quick-change hub attached.
4. Repeat above steps on opposite side of machine.

#### Hardware Guidelines

Shear bolts are designed to fail under predetermined loads. Always replace shear bolts with identical grade.

# MAINTENANCE

## Fuel Tank/Cold Weather Starting/ Parking & Transporting Buggy

Fasteners should be replaced with the same or higher grade. If higher grade fasteners are used, these should only be tightened to the strength of the original.

Make sure fasteners threads are clean and that you properly start thread engagement. This will prevent them from failing when tightening.

### Fuel Tank

Gasoline ONLY (see Engine Specifications Section for requirements).

Fill fuel tank at the end of each day's operation to prevent condensation in the tank.

Drain and flush fuel tank every 1,000 hours or 12 months.

Avoid storing fuel over long periods of time. If fuel is stored for more than a month prior to use or there is a slow turnover in fuel tank or supply tank, add a fuel conditioner to stabilize the fuel and prevent water condensation. Fuel conditioner also reduces fuel gelling and controls wax separation during cold weather.

Proper fuel storage is critically important. Use clean storage and transfer tanks. Periodically drain water and sediment from the bottom of the tank. Store fuel in a convenient place away from buildings.

### Cold Weather Starting

Hard starting may occur in temperatures below 35 degrees Fahrenheit. Using a lighter grade of oil in both the engine and hydraulic tank is recommended. Return oil to the proper grade when temperatures are above 35 degrees Fahrenheit.

**Hoses, Fittings and Leakage**--Check weekly for loose hose fittings, damage, and leakage--it is important to check entire machine periodically.



**Cleaning Machine**--Wash daily with warm, soapy water. Rinse off mud and dirt. Use pressurized air (30 PSI max) to blow debris. Dirt and mud build up will decrease machine performance and/or cause failures. Avoid spraying water directly on electrical components or electrical damage may occur.

## PARKING/TRANSPORTING BUGGY

**Parking on a Grade**--Parking the unit on a grade should be avoided if possible. If unit has to be parked on a grade, park it at right angles to the slope and apply the parking brake and block the wheels if necessary.

**Long Term Parking**--When unit is not in use for long period of time, tilt tub up so water, snow, and debris will not collect inside. Apply parking brake and park unit out of main traffic areas.

If buggy will be exposed to wet freezing weather for any length of time, place tub in the dump position to prevent any possibility of freezing water damaging the tub.

**Moving Machine Without Engine Power**--The unit can be moved, if the engine won't run, short distances by moving the f/r control lever to the

# MAINTENANCE

## Lifting Points/ Transporting/Storage

middle position. The transmission is also provided with a bypass valve.

**Transporting Machine**--When transporting unit, observe overall height for proper clearance of obstacles overhead. Make sure bucket is lowered and latched down. Secure unit with the proper devices and in the proper locations.



**Proper Lifting Points**--There are two ways of lifting the unit, from the side or from the front. Lifting the standing platform will allow access to the lifting tubes. Accessing the side lifting tubes is straightforward.

**Proper Tie Down Practices**--Tie unit down with proper devices. Make sure all blocking is secure.

**Proper Transportation Practices**--Always know overall height to allow proper clearance for overhead obstructions such as power lines, overhangs, and doorways when transporting unit on a high vehicle.

**Mounting/Dismounting Buggy**--Always use 'three point contact' when mounting the buggy. Three points refers to three out of four arms/legs are in

contact with buggy during mounting and dismounting. Always face the buggy whether mounting or dismounting.

**Starting Instructions**--Before starting engine, refer to engine owners' manual before you begin.

**Shut-Off**--Come to complete stop before setting parking brake. Idle engine for gradual cooling before shutting the engine off. Cycle hydraulic controls to eliminate residual pressure. Lever needs to be left in forward/reverse position. Remove ignition key on electric start models. Block wheels if on a slope or incline.

**Capacity**--Know the load capacities of your buggy and never exceed them. Buggies normally operate on uneven, unpaved, bumpy and/or inclined surfaces--adjust load accordingly.

### Storage

If equipment is taken out of operation for the Winter season or a prolonged period, follow below procedures to prevent machine or engine damage.

1. Completely clean the outside of the engine.
2. Drain the fuel system and fill it with the preservative fuel. If preservative fuel is not used, the system can be kept full with normal fuel but the fuel must be drained and discarded at the end of the storage period together with the fuel filter element(s).
3. Operate the engine until it is warm. Stop the engine and drain the lubricating oil from the oil pan.
4. Preservative fluid must be drained and the lubricating oil pan must be filled to the correct level with normal lubricating oil at the end of the storage period.

# MAINTENANCE

## Storage/Spring Start Up

### Storage (cont'd)

5. Operate the engine for a short period in order to circulate the lubricating oil.
6. Disconnect the battery. Then put the battery into safe storage in a fully charged condition. Before the battery is put into storage, protect its terminals against corrosion. Grease may be used on the terminals.
7. Remove the air filter. Seal the vent pipe of the fuel tank or the fuel filler cap with waterproof tape.

### Spring Start-Up

1. Drain engine preservative oil and fill with normal engine oil. Check engine oil level.
2. *If fuel preservative was not used*, drain and replace fuel and fuel filter.
3. Charge battery and install.
4. Check air filter.
5. Check hydraulic oil level.
6. Check hardware for looseness. If loose, tighten according to torque chart.
7. Check hoses for looseness or leaking.
8. Reacquaint yourself with Operations and Owner's Manuals.

# MAINTENANCE

## Troubleshooting

|                            |                                       |                                |
|----------------------------|---------------------------------------|--------------------------------|
| Troubleshooting Your Buggy |                                       |                                |
| Engine Lacks Power         | Fuel line plugged                     | Clean or replace               |
|                            | Dirty fuel filter                     | Clean or replace               |
|                            | Air filter dirty                      | Clean or replace               |
|                            | Worn cylinder and piston rings        | Replace                        |
| Oil Consumption            | Too much oil in crankcase             | Drain to proper level          |
|                            | Worn valve guides                     | Replace                        |
|                            | Worn cylinder and piston rings        | Replace                        |
|                            | Too much oil in crankcase             | Drain to proper level          |
|                            | Loose bolts on engine crankcase       | Tighten                        |
| Blue Smoke                 | Worn valves/valve guides              | Replace                        |
|                            | Worn cylinder and piston rings        | Replace                        |
|                            | Too much oil in crankcase             | Drain to proper level          |
|                            | Oil seal at intake valve defective    | Replace                        |
| Does Not Start             | Empty fuel tank                       | Fill tank                      |
|                            | Weak or dead battery                  | Charge or replace              |
|                            | Stop lever is engaged                 | Disengage                      |
|                            | Poor ground connection                | Tighten and/or clean terminals |
|                            | Loose wire connection in wire harness | Tighten                        |
|                            | Run/off switch is in OFF position     | Move switch to proper position |

# MAINTENANCE

## Service Record

|                                                    |                     |                    |
|----------------------------------------------------|---------------------|--------------------|
| <b>Model No.</b>                                   | <b>Machine S/N:</b> | <b>Engine S/N:</b> |
| <b>Record Hours and Dates of Maintenance Below</b> |                     |                    |
| <b>Engine Oil &amp; Filter</b>                     |                     |                    |
| <b>Hydraulic Oil, Filter &amp; Breather</b>        |                     |                    |
| <b>Air Cleaner</b>                                 |                     |                    |
| <b>Grease Fittings</b>                             |                     |                    |
| <b>Battery</b>                                     |                     |                    |
| <b>Brakes</b>                                      |                     |                    |
| <b>Valve Clearance</b>                             |                     |                    |
| <b>Engine RPMs</b>                                 |                     |                    |
| <b>Fuel Tank</b>                                   |                     |                    |
| <b>Fuel Lines</b>                                  |                     |                    |
| <b>Hydraulic Hoses/Connections</b>                 |                     |                    |
| <b>Forward/Reverse</b>                             |                     |                    |
| <b>Control Cables</b>                              |                     |                    |
| <b>Charge System</b>                               |                     |                    |
| <b>Hardware, Lugnuts</b>                           |                     |                    |


# PARTS LIST

## Exploded Views with Parts

|                                                           |              |
|-----------------------------------------------------------|--------------|
| <b>EXPLODED DIAGRAM AND PARTS LIST .....</b>              | <b>29-57</b> |
| Frame Assembly/Cowl, Hopper, Splash Guard .....           | 30-31        |
| Engine and Pump Assembly .....                            | 32-35        |
| Wheelmotors and Brake Assembly .....                      | 36-37        |
| Brake Rods and Platform Lock Assembly .....               | 38-39        |
| Steering Assembly and Dump Platform Assembly .....        | 40-41        |
| Steering, Hydraulic Tank, Battery Assemblies .....        | 42-43        |
| Parking Brake, Hydraulic Valves and Filter Assembly ..... | 44-45        |
| Captivators, Heat Shield and Cylinder Assembly .....      | 46-47        |
| Pneumatic Tire with Standard Hubs Assembly .....          | 48-49        |
| Foam Tires and Quick Change Hubs Assembly .....           | 50-51        |
| Dump Pedal Assembly .....                                 | 52-53        |
| Option Steel Bucket Assembly .....                        | 54-55        |
| Hydraulic Diagram .....                                   | 56-57        |
| Hydraulic System Schematic .....                          | 58-59        |
| Wiring Schematic Recoil Start .....                       | 60           |
| Wiring Schematic Electric Start .....                     | 61           |
| Decal Identification .....                                | 62-63        |

# PARTS LIST

## Frame Assembly Cowl, Hopper, Splash Guard



# PARTS LIST


## Frame Assembly Cowl, Hopper, Splash Guard

| ITEM | PART NO. | DESCRIPTION                       | QTY |
|------|----------|-----------------------------------|-----|
| 1    | 45165    | HOPPER MORTAR                     | 1   |
| 2    | 45240-2  | WELDMENT-SPLASH, GUARD            | 1   |
| 3    | 45925    | COWL ENGINE                       | 1   |
| 4    | 47182    | LATCH COWL                        | 4   |
| 5    | 47294    | TRIM STRIP                        | 1   |
| 6    | 80056    | NUTNY 3/8-16 ZN                   | 6   |
| 7    | 80342    | WSHR SAE 3/8 ZN                   | 6   |
| 8    | 80618    | HHCS M10 -1.25 X 25 8.8 ZN        | 2   |
| 9    | 80740    | BOLT-ELEVATOR, .375-16            | 6   |
| 10   | 80804    | WSHRL M10 SPLIT ZN                | 2   |
| 11   | 80806    | WSHR FLAT M10 X 20 ZN             | 2   |
| 12   | 81130    | SHSHB 10MM DIA X M8 THD X 12MM ZN | 4   |

NOT SHOWN  
LOCTITE 262  
AS REQUIRED

# PARTS LIST

## Engine and Pump Assembly



# PARTS LIST

## Engine and Pump Assembly

| ITEM | PART NO. | DESCRIPTION                     | QTY |
|------|----------|---------------------------------|-----|
| 1    | 23130    | VALVE ASS'Y FUEL STOP SWITCH    | 1   |
| 2    | 32432    | ADAPTOR PUMP/MOTOR              | 1   |
| 3    | 37079    | BUTTON SWITCH MOMENTARY         | 1   |
| 4    | 39612    | SWITCH MOMENTARY PUSH           | 1   |
| 5    | 45069    | RECTIFIER-ENGINE, HONDA         | 1   |
| 6    | 45093    | KEYSQ 5MM x 1.00" LONG          | 1   |
| 7    | 45102    | SPRING COMP.                    | 1   |
| 8    | 45131    | ENGINE HONDA 13HP RECOIL. START | 1   |
| 9    | 45132-2  | WELDMENT-BAR, ACTUATOR          | 1   |
| 10   | 45147    | PUMP-PISTON, 1.28CIR, 2500PSI   | 1   |
| 11   | 45153    | ENGINE_HONDA_13HP_ELEC._START   | 1   |
| 12** | 45154    | COUPLING                        | 1   |
| 13   | 45198    | CABLE THROTTLE                  | 1   |
| 14   | 45225    | WELDMENT- PLATE, MTG.           | 1   |
| 15   | 45910-2  | BRACKET SWITCH STOP FUEL        | 1   |
| 16   | 45912    | HOSE FUEL                       | 1   |
| 17   | 45913-2  | BRACKET SWITCH STOP FUEL        | 1   |
| 18   | 45920-2  | SPACER BRACKET                  | 1   |
| 19   | 55485    | TAG SWITCH ENGINE               | 1   |
| 20   | 55487    | DECAL START                     | 1   |
| 21   | 80058    | WSHRL 3/8 MED SPLIT ZN          | 4   |
| 22** | 80075    | HHCS 1/2-13 X 1-1/2 GR5 ZN      | 2   |
| 23** | 80101    | SHCS 3/8-16 X 1-1/4 BLK         | 4   |
| 24** | 80104    | HHCS 1/2-13 X 1-1/4 GR5 ZN      | 2   |
| 25   | 80117    | WSHRL 1/2 MED SPLIT ZN          | 4   |
| 26   | 80243    | NTFXJ 3/8-24 ZN                 | 1   |
| 27   | 80244    | NUTFXJ 5/16-18 ZN               | 2   |
| 28   | 80343    | WSHR SAE 1/2 ZN                 | 4   |
| 29   | 80571    | WSHR 1/4 SAE ZN                 | 2   |
| 30   | 80676    | NUTNY 1/4-20 ZN                 | 1   |
| 31   | 80743    | HHTB 5/16-18 x4 1/2 LG GR2 ZN   | 1   |
| 32*  | 80758    | HHCS M6-1 X 20 8.8 ZN           | 1   |

^ NOT SHOWN


\* LOCTITE 242

\*\* LOCTITE 262

# AS REQUIRED

# PARTS LIST

## Engine and Pump Assembly



# PARTS LIST


## Engine and Pump Assembly

|      |       |                          |   |
|------|-------|--------------------------|---|
| 33   | 80804 | WSHRL M10 SPLIT ZN       | 4 |
| 34   | 80806 | WSHR FLAT M10 X 20 ZN    | 4 |
| 35** | 80811 | HHCS M6-1 X 25 8.8 ZN    | 3 |
| 36** | 80836 | HHCS M6-1 X 16 8.8 ZN    | 1 |
| 37** | 80838 | HHCS M10-1.5 X 50 8.8 ZN | 4 |
| 38   | 80851 | NUTNY M6-1 ZN            | 3 |
| 39   | 80856 | WSHR FLAT M6 X 12 ZN     | 3 |
| 40   | 80859 | WSHRL M5 SPLIT ZN        | 1 |
| 41   | 80860 | WSHRL M6 SPLIT ZN        | 3 |
| 42** | 80926 | MSCS M4-.7 X 16 4.8 ZN   | 2 |
| 43   | 80929 | WSHRL M4 SPLIT ZN        | 2 |
| 44** | 81016 | HHCS M5-.8 X 10 8.8 ZN   | 1 |
| 45** | 81133 | HHCS 1/4-20 X 5 GR5 ZN   | 1 |

^ NOT SHOWN  
 \* LOCTITE 242  
 \*\* LOCTITE 262  
 # AS REQUIRED

# PARTS LIST

## Wheelmotors and Brake Assembly



# PARTS LIST


## Wheelmotors and Brake Assembly

| ITEM | PART NO. | DESCRIPTION                   | QTY |
|------|----------|-------------------------------|-----|
| 1    | 45144    | BRAKE DRUM                    | 2   |
| 2    | 45145    | BRAKE ACTUATOR LEFT HAND      | 1   |
| 3    | 45148    | MOTOR-GEAR ROTOR,15.9 CIR     | 2   |
| 4    | 45201-2  | WELDMENT-FRAME                | 1   |
| 5    | 45247    | BRAKE ACTUATOR RIGHT HAND     | 1   |
| 6*   | 80051    | NUTNY 1/2-13 ZN               | 8   |
| 7    | 80316    | PINCT 1/8 X 1-1/2 ZN          | 2   |
| 8    | 80891    | WSHR FLAT M12 X 28 ZN         | 8   |
| 9**  | 81113    | SCREW SHSS .500-20 CUP PT BLK | 10  |
| 10   | 81125    | KEY-WOODRUFF                  | 2   |
| 11   | 81126    | CASTLE NUT 1-20UNEF           | 2   |

^ NOT SHOWN  
\* LOCTITE 262  
\*\* LOCTITE 680  
# AS REQUIRED

# PARTS LIST

## Brake Rods and Platform Lock Assembly




# PARTS LIST

## Brake Rods and Platform Lock Assembly

| ITEM | PART NO. | DESCRIPTION                    | QTY |
|------|----------|--------------------------------|-----|
| 1    | 38561    | CLEVIS 1/4 DIA X 1/4-28        | 4   |
| 2    | 39255    | YOKE END 3/8-24                | 4   |
| 3    | 45055    | SPRING COMP.                   | 1   |
| 4    | 45056    | PIN-LOCKOUT, STEP              | 1   |
| 5    | 45105    | SPRING COMP.                   | 2   |
| 6    | 45113-2  | SHAFT_PIVOT_STEP               | 1   |
| 7    | 45211-2  | WELDMENT-PLATFORM, STEP        | 1   |
| 8    | 45216-2  | WELDMENT-PEDAL, BRAKE          | 1   |
| 9    | 45219-2  | WELDMENT-LEVER, BRAKE          | 1   |
| 10   | 45221-2  | ROD-BRAKE                      | 2   |
| 11   | 45222-2  | ROD-BRAKE, SERVICE             | 2   |
| 12   | 45231-2  | SHAFT-PIVOT-LEVER, BRAKE       | 1   |
| 13   | 45249-2  | SPACER-BRAKE                   | 2   |
| 14   | 46045    | WSHR FENDER .4 X 1.5 X .062 ZN | 2   |
| 15   | 80118    | WSHR WROT 1/2 ZN               | 2   |
| 16   | 80237    | NUTFX 1/4-28 ZN                | 4   |
| 17   | 80243    | NTFXJ 3/8-24 ZN                | 4   |
| 18   | 80316    | PINCT 1/8 X 1-1/2 ZN           | 4   |
| 19   | 80355    | WSHR SAE 5/8 ZN                | 2   |
| 20   | 80858    | WSHR FLAT M16 X 30 ZN          | 2   |
| 21   | 81042    | WSHR FLAT M10 X 30 ZN          | 2   |
| 22   | 81122    | PINSP 3/16 X 2.00 ZN           | 1   |
| 23   | 81124    | RING-SPLIT                     | 1   |

# PARTS LIST

## Steering Assembly Dump Platform Assembly



# PARTS LIST

## Steering Assembly Dump Platform Assembly

| ITEM | PART NO. | DESCRIPTION                 | QTY |
|------|----------|-----------------------------|-----|
| 1+   | 32052    | SEAL WHEEL HUB              | 2   |
| 2+   | 32233    | BEARING RLR TAPER 1.000     | 4   |
| 3    | 32333    | BEARING-PLAIN               | 1   |
| 4    | 32335    | BEARING-THRUST, BALL        | 1   |
| 5    | 32336    | SEAL-LIP                    | 1   |
| 6    | 32337    | SEAL-LIP                    | 1   |
| 7    | 34501    | KIT HUB 4 BOLT              | 2   |
| 8+   | 34573    | DUST CAP                    | 2   |
| 9+   | 39190    | LUG STUD 1/2-20 x 1 7/32 LG | 8   |
| 10   | 45054    | WASHER- FLAT, ALTER.        | 1   |
| 11   | 45073-2  | WELDMENT-SUBBASE-BIN        | 1   |
| 12   | 45096-2  | SHAFT-PIVOT-BIN             | 1   |
| 13   | 45100-2  | HOUSING-BEARING             | 1   |
| 14   | 45229-2  | STOP-STEERING               | 1   |
| 15   | 45230-2  | BUMPER-STOP, STEERING       | 2   |
| 16   | 45248-2  | WELDMENT-AXLE, STEERING     | 1   |
| 17   | 45259-2  | WELDMENT-SHAFT, STEERING    | 1   |
| 18   | 46042    | FITTING GREASE 1/4-28 ZN    | 7   |
| 19   | 47001    | CAP GREASE FITTING          | 7   |
| 20*  | 60873    | SHCS M10-1.5 X 30 12.9 BLK  | 4   |
| 21   | 80054    | NUT 3/4-16 ZN               | 2   |
| 22   | 80309    | PINSP 5/16 X 1-1/2          | 1   |
| 23   | 80316    | PINCT 1/8 X 1-1/2 ZN        | 4   |
| 24   | 80344    | WSHR SAE 3/4 ZN             | 4   |
| 25*  | 80800    | SHCS M10-1.5 X 40 12.9 BLK  | 2   |
| 26*  | 80838    | HHCS M10-1.5 X 50 8.8 ZN    | 2   |

^ NOT SHOWN


\* LOCTITE

# AS REQUIRED

+ INCLUDED WITH KIT 34501

# PARTS LIST

## Steering, Hydraulic Tank, Battery Assemblies



# PARTS LIST

## Steering, Hydraulic Tank, Battery Assemblies

| ITEM | PART NO. | DESCRIPTION                    | QTY |
|------|----------|--------------------------------|-----|
| 1    | 35321    | BATTERY 12 MONTH 165 CCA       | 1   |
| 2    | 38521    | BREATHER/FILLER HYD            | 1   |
| 3    | 38534    | SIGHT GLASS 3/4 NPT            | 1   |
| 4    | 39056    | VALVE STRAINER                 | 1   |
| 5    | 45084    | ROD-HOLDDOWN, BATTERY          | 2   |
| 6    | 45091-2  | BRACKET HOLD DOWN BATTERY      | 1   |
| 7    | 45104    | CLUTCH LEVER ASSEMBLY          | 1   |
| 8    | 45114-2  | WELDMENT-TANK-HYDRAULIC        | 1   |
| 9    | 45123    | FLANGE 2-BOLT                  | 2   |
| 10   | 45134-2  | WELDMENT-HANDLE, STEERING      | 1   |
| 11   | 45198    | CABLE, THROTTLE                | 1   |
| 12   | 45226    | BEARING AND COLLAR             | 1   |
| 13   | 45263    | GAUGE FUEL 12" DEEP            | 1   |
| 14   | 45924    | TANK FUEL                      | 1   |
| 15   | 46774    | PLUG 3/4 NPT MAGNETIC SQ HD    | 1   |
| 16   | 47125    | HANDLE-GRIP                    | 2   |
| 17   | 47244    | RBR 60 DURO 1.5 X 6.75         | 2   |
| 18 ^ | 48284    | CABLE BATTERY NEGATIVE 25 INCH | 1   |
| 19 ^ | 48359    | CABLE BATTERY POSITIVE 25 INCH | 1   |
| 20   | 80236    | NUTKP 1/4-20 ZN                | 2   |
| 21   | 80309    | PINSP 5/16 X 1-1/2             | 2   |
| 22   | 80347    | WSHR WROT 1/4 ZN               | 4   |
| 23   | 80406    | HHCS M8-1.25 X 20 8.8 ZN       | 4   |
| 24 * | 80618    | HHCS M10 -1.25 X 25 8.8 ZN     | 4   |
| 25   | 80676    | NUTNY 1/4-20 ZN                | 4   |
| 26   | 80804    | WSHRL M10 SPLIT ZN             | 4   |
| 27   | 80806    | WSHR FLAT M10 X 20 ZN          | 8   |
| 28   | 80812    | WSHRL M8 SPLIT ZN              | 4   |
| 29   | 80813    | WSHR FLAT M8 X 24 ZN           | 4   |
| 30 * | 80815    | HHCS M10-1.5 X 30 8.8 ZN       | 2   |
| 31   | 80833    | NUTNY M10-1.5 ZN               | 2   |
| 32   | 81127    | PHSMS M5-0.8 X 16 304 SST      | 2   |
| 33   | 81128    | WSHRL M5 SPLIT SST             | 2   |


^ NOT SHOWN

\* LOCTITE 262

# AS REQUIRED

# PARTS LIST

## Parking Brake, Hydraulic Valves and Filter Assembly



# PARTS LIST

## Parking Brake, Hydraulic Valves and Filter Assembly

| ITEM | PART NO. | DESCRIPTION                      | QTY |
|------|----------|----------------------------------|-----|
| 1    | 38095    | BRAKE_PARKING                    | 1   |
| 2    | 45120    | E CLIP                           | 1   |
| 3    | 45128-2  | CLEVIS-HALF, NOTCHED             | 1   |
| 4    | 45129-2  | CLEVIS-HALF, PLAIN               | 1   |
| 5    | 45149    | VALVE DIRECTIONAL                | 1   |
| 6 #  | 45150    | FILTER-RETURN, 10-GPM, 10 MICRON | 1   |
| 7    | 45160    | VALVE DIRECTIONAL                | 1   |
| 8    | 45194    | KIT HANDLE                       | 1   |
| 9    | 45199    | CABLE, BRAKE                     | 1   |
| 10   | 45299-2  | BRACKET-FILTER, OIL              | 1   |
| 11   | 45960-2  | WELD GUIDE SHAFT                 | 1   |
| 12   | 80087    | HHCS M8-1.25 X 25 8.8 ZN         | 2   |
| 13   | 80116    | WSHRL 1/4 MED SPLIT ZN           | 2   |
| 14   | 80118    | WSHR WROT 1/2 ZN                 | 1   |
| 15 * | 80148    | HHCS M8-1.25 X 65 8.8 ZN         | 1   |
| 16   | 80342    | WSHR SAE 3/8 ZN                  | 1   |
| 17   | 80347    | WSHR WROT 1/4 ZN                 | 2   |
| 18** | 80353    | HHCS 1/4-20 X 3/4 GR5 ZN         | 2   |
| 19   | 80424    | PINCT 1/8 X 3/4 ZN               | 1   |
| 20   | 80501    | NUT JAM 5/16-24 ZN               | 2   |
| 21   | 80812    | WSHRL M8 SPLIT ZN                | 6   |
| 22   | 80813    | WSHR FLAT M8 X 24 ZN             | 5   |
| 23   | 80817    | NUTNY M8-1.25 ZN                 | 1   |
| 24   | 80851    | NUTNY M6-1 ZN                    | 1   |
| 25   | 80856    | WSHR FLAT M6 X 12 ZN             | 3   |
| 26   | 80857    | WSHR FLAT M8 X 16 ZN             | 3   |
| 27   | 80860    | WSHRL M6 SPLIT ZN                | 1   |
| 28 * | 80881    | HHCS M6-1 X 50 8.8 ZN            | 1   |
| 29 * | 80883    | HHCS M8-1.25 X 50 8.8 ZN         | 3   |
| 30 * | 80944    | HHCS M8-1.25 X60 8.8 ZN          | 1   |
| 31   | 81110    | CLEVIS PIN .375 X 1.25 LG SS     | 1   |
| 32   | 81111    | HHCS M6-1 X 60 8.8 ZN            | 1   |


\* LOCTITE 262

\*\* LOCTITE 242

# INCLUDES HEAD AND ELEMENT.  
FOR ELEMENT ONLY USE P/N 47579

# PARTS LIST

## Captivators, Heat Shield and Cylinder Assembly



# PARTS LIST


## Captivators, Heat Shield and Cylinder Assembly

| ITEM | PART NO. | DESCRIPTION                     | QTY |
|------|----------|---------------------------------|-----|
| 1    | 36617    | CLAMP 1" RUBBER LOOP            | 1   |
| 2    | 45254-2  | WELDMENT- SHIELD, HEAT          | 1   |
| 3    | 46362    | CYLINDER                        | 1   |
| 4    | 47455    | CLAMP SPLIT,DUAL HOSE 21.3-21.3 | 2   |
| 5    | 47456    | COVER PLATE, DUAL HOSE          | 1   |
| 6*   | 80087    | HHCS M8-1.25 X 25 8.8 ZN        | 2   |
| 7    | 80348    | WSHR WROT 5/16 ZN               | 1   |
| 8*   | 80617    | HHCS M6-1 X 16 8.8 ZN           | 1   |
| 9    | 80812    | WSHRL M8 SPLIT ZN               | 2   |
| 10   | 80813    | WSHR FLAT M8 X 24 ZN            | 2   |
| 11   | 80856    | WSHR FLAT M6 X 12 ZN            | 1   |
| 12   | 80860    | WSHRL M6 SPLIT ZN               | 1   |
| 13*  | 81056    | HHCS 5/16-18 X 3 1/4 GR5 ZN     | 1   |

^ NOT SHOWN  
 \* LOCTITE 262  
 # AS REQUIRED

# PARTS LIST

## Pneumatic Tire with Standard Hubs Assembly



# PARTS LIST


## Pneumatic Tire with Standard Hubs Assembly

| ITEM | PART NO. | DESCRIPTION                    | QTY |
|------|----------|--------------------------------|-----|
| 1    | 34605    | WHEEL ASSEMBLY 480-8 PNEUMATIC | 2   |
| 2    | 45089-2  | HUB-WHEEL                      | 2   |
| 3    | 45241-2  | SPACER-WHEEL, 5 BOLT           | 2   |
| 4    | 45261    | WHEEL ASSEMBLY 570-8 PNEUMATIC | 4   |
| 5    | 80045    | LUGNT 1/2-20 ZN                | 8   |
| 6    | 81114    | BOLT-LUG                       | 10  |
| 7    | 81115    | NUTFX 1/2-20 ZN                | 10  |

^ NOT SHOWN  
\* LOCTITE  
# AS REQUIRED

# PARTS LIST

## Foam Tires & Quick Change Hubs Assembly



# PARTS LIST


## Foam Tires & Quick Change Hubs Assembly

| ITEM | PART NO. | DESCRIPTION                 | QTY |
|------|----------|-----------------------------|-----|
| 1    | 45080-2  | SPACER-WHEEL-MACHINE        | 2   |
| 2    | 45106-2  | WELDMENT-RELEASE-QUICK      | 2   |
| 3    | 45176    | WHEEL ASSEMBLY 480-8 W/FOAM | 2   |
| 4    | 45197    | WHEEL ASSEMBLY 570-8 W/FOAM | 4   |
| 5    | 45241-2  | SPACER-WHEEL, 5 BOLT        | 2   |
| 6    | 45242-2  | HUB-WHEEL-MACHINE           | 2   |
| 7    | 80045    | LUGNT 1/2-20 ZN             | 8   |
| 8    | 80423    | PINDL 1/2 x 1 1/4 LG        | 4   |
| 9    | 80871    | WSHRL M20 SPLIT ZN          | 2   |
| 10   | 81014    | WSHR FLAT M20 X 60 ZN       | 2   |
| 11   | 81114    | BOLT-LUG                    | 10  |
| 12   | 81115    | NUTFX 1/2-20 ZN             | 10  |

^ NOT SHOWN  
 \* LOCTITE  
 # AS REQUIRED

# PARTS LIST

## Dump Pedal Assembly



# PARTS LIST


## Dump Pedal Assembly

| ITEM | PART NO. | DESCRIPTION                | QTY |
|------|----------|----------------------------|-----|
| 1    | 32465    | PIN CLEVIS 1/4 X 1 SST     | 1   |
| 2    | 32466    | BEARING NYLINER 3/8 ID     | 2   |
| 3    | 39255    | YOKE END 3/8-24            | 2   |
| 4    | 45959    | TREAD SKID                 | 1   |
| 5    | 45960-2  | WELD GUIDE SHAFT           | 1   |
| 6    | 45963-2  | WELD PEDAL DUMP            | 1   |
| 7    | 45968-2  | ARM ACTUATOR               | 1   |
| 8    | 45971-2  | WELD SHAFT                 | 1   |
| 9    | 45973-2  | WELD MOUNT PEDAL           | 1   |
| 10   | 45974    | ROD DUMP                   | 1   |
| 11   | 80056    | NUTNY 3/8-16 ZN            | 1   |
| 12   | 80243    | NTFXJ 3/8-24 ZN            | 2   |
| 13   | 80342    | WSHR SAE 3/8 ZN            | 1   |
| 14*  | 80618    | HHCS M10 -1.25 X 25 8.8 ZN | 1   |
| 15   | 80639    | WSHRSP 1/2 ID BLK BELLEVIL | 1   |
| 16   | 80812    | WSHRL M8 SPLIT ZN          | 3   |
| 17   | 80817    | NUTNY M8-1.25 ZN           | 1   |
| 18   | 80851    | NUTNY M6-1 ZN              | 1   |
| 19   | 80856    | WSHR FLAT M6 X 12 ZN       | 2   |
| 20   | 80857    | WSHR FLAT M8 X 16 ZN       | 2   |
| 21   | 80866    | NUTFX M10-1.5 ZN           | 1   |
| 22*  | 80867    | HHCS M8-1.25 X 70 8.8 ZN   | 1   |
| 23*  | 80931    | HHCS M8-1.25 X 30 8.8 ZN   | 3   |
| 24*  | 80957    | SHSHB 1/2 X 1 BLK          | 1   |
| 25   | 81076    | PINSP 1/8 X 3/4 SS         | 1   |
| 26*  | 81111    | HHCS M6-1 X 60 8.8 ZN      | 1   |

\* LOCTITE 262

# PARTS LIST

## Option Steel Bucket Assembly




# PARTS LIST

## Option Steel Bucket Assembly

| ITEM | PART NO. | DESCRIPTION              | QTY |
|------|----------|--------------------------|-----|
| 1    | 45096-2  | SHAFT-PIVOT-BIN          | 1   |
| 2    | 45108-2  | WELDMENT HOPPER STEEL    | 1   |
| 3    | 46042    | FITTING GREASE 1/4-28 ZN | 3   |
| 4    | 47001    | CAP GREASE FITTING       | 3   |
| 5    | 80316    | PINCT 1/8 X 1-1/2 ZN     | 2   |
| 6    | 80344    | WSHR SAE 3/4 ZN          | 2   |

# PARTS LIST

## Hydraulic Diagram




# PARTS LIST

## Hydraulic Diagram

| ITEM | PART NO. | DESCRIPTION                      | QTY |
|------|----------|----------------------------------|-----|
| 1    | 46579    | FITTING HYD SEALOCK              | 2   |
| 2    | 46980    | TEE RUN 1/2 THREAD STRAIGHT      | 2   |
| 3    | 46673    | 1/2 O-RING FITTING               | 2   |
| 4    | 46587    | FTG HYD SEALOCK                  | 2   |
| 5    | 46631    | FTG HYD SEALOCK                  | 1   |
| 6    | 45172    | FTG HYD OFS 90 4 6               | 2   |
| 7    | 46581    | FTG HYD SEALOCK                  | 3   |
| 8    | 46686    | 1/4 HYD O-RING FITTING           | 1   |
| 9    | 45905    | FTG HYD HB 90 8 8                | 1   |
| 10   | 45171    | FTG HYD OFS ST 8 6               | 1   |
| 11   | 46679    | FT ST 9/16-18 11/16 ORF          | 1   |
| 12   | 45008    | CONNECTOR 3/8 THREAD             | 1   |
| 13   | 45087    | HOSE BARB 1/2 NPT STRAIGHT       | 1   |
| 14   | 46585    | FTG HYD SEALOCK                  | 4   |
| 15   | 46582    | FTG HYD SEALOCK                  | 2   |
| 16   | 45142    | HOSE HYD 8 90 8 45 8 66.25" 235° | 1   |
| 17   | 45143    | HOSE HYD 8 ST 8 45 8 60.00"      | 1   |
| 18   | 45141    | HOSE HYD 6 ST 8 45 8 20.00"      | 1   |
| 19   | 45140    | HOSE HYD 4 ST 4 90 4 38.00"      | 1   |
| 20   | 45139    | HOSE HYD 8 ST 8 90 8 17.38"      | 2   |
| 21   | 45138    | HOSE HYD 4 ST 4 90 4 81.60"      | 1   |
| 22   | 45078    | HOSE HYD 4 ST 4 90 4 101.00"     | 1   |
| 23   | 45157    | HOSE HYD 8 ST 6 ST 6 20.00"      | 1   |
| 24   | 45158    | HOSE HYD 8 16.00"                | 1   |
| 25   | 45159    | HOSE HYD 8 ST 8 90 8 12.00"      | 1   |
| 26   | 45167    | HOSE HYD 8 ST 8 45 8 30.50"      | 1   |
| 27   | 45169    | HOSE HYD 8 ST 8 45 8 29.75"      | 1   |

# PARTS LIST

## Hydraulic System Schematic



# PARTS LIST


## Hydraulic System Schematic

| ITEM | PART NO. | DESCRIPTION                   | QTY |
|------|----------|-------------------------------|-----|
| 1    | 45147    | PUMP PISTON 1.25 CIR 2500 PSI | 1   |
| 2    | 45148    | MOTOR HYD GEAR ROTOR 15.14    | 2   |
| 3    | 45149    | VALVE DIRECTIONAL MANUAL      | 1   |
| 4 +  | 45150    | FILTER ASB.                   | 1   |
| 5    | 38521    | BREATHER                      | 1   |
| 6    | 46362    | CYLINDER                      | 1   |
| 7    | 45160    | VALVE DIRECTIONAL MANUAL      | 1   |
| 8    | 45154    | COUPLING WITH INSERT          | 1   |
| 9    | 39087    | STRAINER 1" NPT               | 1   |

+ INCLUDES HEAD AND ELEMENT.  
FOR ELEMENT ONLY, USE PART NO. 47579

# PARTS LIST


## Wiring Schematic Recoil Start



MB017A





# PARTS LIST

## Wiring Schematic Electric Start



# PARTS LIST


## Decal Identification




# PARTS LIST

## Decal Identification

|   |       |                                 |   |
|---|-------|---------------------------------|---|
| 1 | 45927 | Decal Control Fwd/Rev Tilt      | 1 |
| 2 | 55200 | Decal Lift Here                 | 4 |
| 3 | 55215 | Decal Warning Pinch Point       | 2 |
| 4 | 55398 | Decal Warning Hot Surfaces      | 1 |
| 5 | 55422 | Decal Hydraulic Fluid Mobil 424 | 1 |
| 6 | 55482 | Decal Emissions Honda           | 1 |
| 7 | 55486 | Decal Push Start                | 1 |
| 8 | 55485 | Tag Switch Stop Fuel            |   |







**CALIFORNIA PROPOSITION 65 WARNING**  
Operation of this equipment and/or engine exhaust  
from this product contains chemicals known to the  
State of California to cause cancer, birth defects, or  
other reproductive harm.



***Bred Tough. Technology Born to Work.  
The Way It Ought To Be.***

Stone Construction Equipment, Inc.  
P.O. Box 150, Honeoye, New York 14471  
Phone: (800) 888-9926  
Fax: 585-229-2363  
e-mail: [sceny@mcimail.com](mailto:sceny@mcimail.com)  
[www: stone-equip.com](http://www.stone-equip.com)

A 100% employee-owned American manufacturer

© 1995 Stone Construction Equipment, Inc.  
Printed in U.S.A.