



Count on it.

Parts Catalog

Walk-Behind Rotary Broom

Model No. 23740—Serial No. 314000001 and Up

Model No. 38700—Serial No. 314000001 and Up



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

List of Abbreviations

AR: as required

ASM: assembly

BBC: blade brake control

BHTF: button head thread forming

CARR: carriage

CCW: counter clockwise

CW: clockwise

DEG: degrees

DPA: Dual Point Adjustment

ECM: electronic control module

EXT: external

FH: flat head

GA: gauge

HD: heavy-duty

HF: hex flange

HH: hex head

HHF: hex head flange

HHFTF: hex head flange thread forming

HJ: hex jam

HLH: hex lag head

HOC: height-of-cut

HSBH: hex socket button head

HSFH: hex socket flat head

HSH: hex socket head

HWH: hex washer head

HWHTF: hex washer head thread forming

HYD: hydraulic

LH: left hand

LP: Liquefied Petroleum Gas

LPG: Liquefied Petroleum Gas

NI: nylon insert

NPTF: national pipe thread fine

PFH: phillips flat head

PPH: phillips pan head

PPHTF: phillips pan head thread forming

PRH: phillips round head

PTH: phillips truss head

PTO: power-take-off

RH: right hand

ROPS: roll-over protection system

RRB: rear roller brush

SFH: slotted fillister head

SHH: slotted hex head

SHWH: slotted hex washer head

SPH: slotted pan head

SQH: square head

SRH: slotted round head

STD: standard

TAP: self tapping

TTH: torx truss head

Contents

Frame Assembly..... 4

Drive Assembly..... 6

Control Panel Assembly 8

Wheel Clutch Sprocket Assembly 10

Handle Assembly 11

Engine and Pully Assembly 12

Broom Head 13


Mounting Assembly 14

Broom Head and Frame Assembly 15

Core Assembly 16

Attachments and Accessories 17

Frame Assembly




Frame Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	323-8	1	Screw-HH	26	3272-4	1	Pin-Cotter
2	92-7104	1	Pulley-Idler	27	3256-23	1	Washer-Flat
3	107-1039	1	Bracket-Idler, Impeller	28	107-1011	1	Bellcrank-Drive
4	3296-42	1	Nut-Lock, NI	29	106-4467	1	Link-Control, Speed
5	3296-59	2	Nut-Lock, NI	30	3290-307	1	Pin-Hair
6	107-3838-03	1	Impeller Clutch ASM	31	32151-61	2	Ring-Retaining
7	120-9824	1	Bracket-Clutch, Impeller	32	256-257	2	Bushing-Nyliner
8	99-6810	1	Screw-HHF	33	106-7330-01	1	Pan-Bottom
9	108-5056	1	Bolt-Shoulder ●	34	116-7678	1	Brace-Frame
10	108-5058	1	Arm-Idler, Traction	35	107069	8	Clip
11	3-4244	1	Pulley-Idler	36	108-0031	1	Pulley-Traction
12	108-7332	1	Spring-Torsion	37	108-7307	1	Bracket-Wheel, Friction
14	3234-7	2	Screw-HHF	38	3290-340	1	Washer-Belleville
15	107-1003	1	Spring-Extension	39	3296-5	1	Nut-Lock
16	3296-76	1	Nut-Lock, NI	40	120-9832-01	1	Traction Frame ASM
17	5-4460	2	Washer-Pivot	41	32144-14	4	Screw-HWHTF
18	108-0022-01	1	Cover-Upper	42	108-2976	1	Spring-Extension
19	32144-10	13	Screw-HWH	43	3296-29	1	Nut-Lock, NI
20	108-0036	1	Bracket-Rod, Shift	44	323-29	1	Screw-HH
21	106-7268	1	Lever-Control, Traction	45	32144-4	1	Screw-HWH
22	108-0026-03	1	Shift Plate ASM	46	116-7672-03	1	Brace-Handle, LH
23	106-7345-01	1	Cover-Lower	47	116-7673-03	1	Brace-Handle, RH
24	25-5640	1	Washer	48	32144-44	4	Screw-HWH, Thread Roll
25	27-0410	1	Screw-Shoulder				

● Apply light coat of anti-seize to pivot surface.

Drive Assembly



Drive Assembly (continued)


<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1		1	RH Wheel And Tire ASM ●	20	107-8887	1	Collar-Shift, LH
1:1	107-3042	1	Tire	21	108-2975	2	Screw-HH
1:2	107-3043	1	Rim-Tire	22	107-8891	2	Washer-Thrust
1:3	232-27	1	Stem-Valve	23	3257-7	2	Key-Woodruff
2	3296-42	8	Nut-Lock, NI	24	107-8898	2	Shaft-Axle
3	119-1567	1	Wheel-Friction	25	106-4572	2	Gear-Axle, 44 Tooth
4	321-4	4	Screw-HH	26	322-17	1	Screw-HH
5	32144-10	4	Screw-HWH	27	3296-47	1	Nut-Lock, NI
6	106-4558	2	Bearing-Axle	28	106-7259	1	Tube-Axle
7	3-8664	4	Washer-Thrust	29		1	LH Wheel And Tire ASM ●
8	107-8889	4	Guide-Collar	29:1	107-3042	1	Tire
9	3256-22	6	Washer-Flat	29:2	107-3043	1	Rim-Tire
10	107-8892-03	1	Brace-Collar, Shift	29:3	232-27	1	Stem-Valve
11	107-8893	2	Spring-Extension	30	55-9370	2	Spacer-Blade, Rotor
12	108-0015	4	Washer-Flat	31	116-7908	1	Shaft-Hex ▲
13	107-8894	2	11T Gear ASM	32	106-4434	1	Trunnion-Hex
13:2	108-2973	2	Bushing-Flange	33	32121-9	2	Pin-Roll, Slotted
14	108-0016	2	Chain-Roller	34	94-8850	2	Key-Square
15	2710-6	2	Link-Connecting	35	3245-32	4	Screw-HSH
16	107-8888	1	Collar-Shift, RH	36	106-7317	2	Sprocket-8 Tooth
17	321-23	2	Screw-HH	37	108-7319	2	Retainer-Bearing
18	107-8883	1	Shaft-Intermediate ■	38	32144-14	2	Screw-HWHTF
19	3290-343	2	Pin-Hair				

● Not serviced separately

▲ Apply light coat of oil to hex portion of shaft.


■ Apply light coat of oil before assembly.

Control Panel Assembly



Control Panel Assembly (continued)


<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	106-4423	1	Knob-Shift, RH	21:2	126-0017	1	Decal-Control Panel
2	106-7278-03	1	Selector-Speed	22	32121-125	3	Pin-Spring
3	63-2650	1	Screw-Shoulder	23	107-3001	1	Spring-Tension
4	108-7313	1	Spring-Compression	24	106-4410	1	Lever-Traction
5	3290-307	2	Pin-Hair	25	105-9996	1	Rod-Lockout
6	110-3446	1	Trunnion-Rod	26	107-1043	1	Cam-Lockout
7	3256-24	3	Washer-Flat	27	3290-212	1	Washer-Spring
8	46-8092	4	Screw-Plastite	28	107-3018	4	Screw-Handle
9	105-9999	1	Knob-Shift, LH	29	120-0132	1	Cable-Traction
10	94-4496	1	Screw-PPH	30	115-5685	1	Cable-Augur
11	106-7277-03	1	Guide-Selector, Speed	31	107-8896	2	Cable-Clutch
12	32128-13	1	Nut-HHF	32	107-1005	1	Rod-Shift
13	106-7279-03	1	Mount-Selector, Speed	38	104-8300	2	Nut-Flange, NI
14	105-9980	2	Mount-Clutch, Lever	40	116-7669	1	Bracket-Lever, Broom Angle
15	3256-70	4	Washer-Flat	41	116-7670	1	Lever-Thumb, Broom Angle
16	3296-72	5	Nut-Lock, NI	42	119-6915	2	Screw-Shoulder, HSH
17	106-4505	2	Lever-Clutch	43	322-6	1	Screw-HH
18	108-2992	3	Pin-Hair	44	116-7793	1	Tube-Spacer
19	1-808265	2	Pin-Clevis	45	146319	1	Pin-Clevis
20	106-4413	1	Lever-Augur	46	126-0016	1	Decal-Toro Power Broom
21	126-0063	1	Control Panel ASM	47	1-323229	1	Clip-Loom



Wheel Clutch Sprocket Assembly

Ref.	Part Number	Qty.	Description
1	107-8886	2	Retainer-Pin, Pawl
2	107-8879	6	Pawl-Clutch
3	107-8885	6	Spring-Compression
4	107-8899	6	Pin-Dowel ●
5	107-8895	2	32T Sprocket ASM
5:2	108-2973	2	Bushing-Flange
6	107-8880	6	Support-Pawl
7	108-0035	12	Screw-Torx Button Head


● Apply light coat of oil before assembly.



Handle Assembly

Ref.	Part Number	Qty.	Description
1	116-7788	1	Panel, Control
1:2	116-7370	1	Decal-Warning
2	55-9370	2	Spacer-Blade, Rotor
3	3296-2	2	Nut-Lock, NI
4	32105-5	2	Screw
5	108-0038-03	1	Handle-Upper, RH
6	95-4453	2	Screw
7	106-4509	2	Clamp-Cable
8	87-6630	2	Washer-Plain

Ref.	Part Number	Qty.	Description
9	3296-73	2	Nut-Lock, NI
10	107-3844	4	Washer
11	104-8300	4	Nut-Flange, NI
12	108-0037-03	1	Handle-Upper, LH
13	105-9981-03	1	Handle-Lower
14	32144-14	4	Screw-HWHTF
15	3290-475	4	Washer-Belleville
16	92-2260	4	Screw-Handle



Engine and Pully Assembly

Ref.	Part Number	Qty.	Description
1		1	Engine-Kohler, Ch270 ●▲
2	3290-475	2	Washer-Belleville
3	1-303334	1	Washer-Spring
4	107-3835	1	Guide-Belt
5	116-7659-03	1	Spacer-Cover Belt
7	98-5975	1	Washer-Belleville
8	112-8139	1	Sheave-Half, Impeller ■
9	1-653332	1	Belt-Blower
10	112-8117	1	Pulley-Engine, Center ■
11	94-8812	1	V Belt-Traction
12	112-8138	1	Sheave-Half, Traction ■
13	32128-20	4	Nut-HF
14	3210-6	2	Screw-HH


Ref.	Part Number	Qty.	Description
15	116-7258-01	1	Cover-Belt
16	116-8761-01	1	Shield-Drive
17	94-2413	1	U-Nut
18	116-7431-01	1	Cover-Belt, Back
19	106-2240	1	Knob
20	3211-9	1	Screw-HH ◆
21	116-7922-01	1	Shield-Ice
22	116-8721	1	Adapter
23	01-201-4520	1	Cap
25	116-8549	1	Guard-Muffler
26	116-8505	1	Decal-Engine Fuel
29	117-2718	1	Decal-Arrester, Spark

● Not serviced separately

▲ Obtain parts from www.kohlerplus.com


◆ Use Pro-Lock, Nut Type (P/N 1-840022, .5ml tube) on threads.

■ Apply anti-seize compound in bore.



Broom Head


<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
2	62-5550	2	Decal
3	66-6140	1	Decal
7	32144-14	6	Screw-HWHTF



Mounting Assembly

Ref.	Part Number	Qty.	Description
1	116-8122	1	Frame-Broom, Mounting ASM
1:1	112-9028	1	Decal-Cover Missing
1:2	115-2903	2	Decal-Grease
2	116-8103	2	Bearing-.75 Shaft
3	3230-1	4	Bolt-CARR
4	32128-20	4	Nut-HF
5	116-8104	1	Driveline-Series
6	116-8105	1	Key-Round End
7	116-7930	1	Pulley-Impeller


Ref.	Part Number	Qty.	Description
8	3256-8	1	Washer-Flat
9	3216-7	1	Screw-HH
12	116-8106	1	Pin-Swing
13	116-8107	1	Spring-Compression
14	3290-496	6	Nut-Retainer
15	302-19	1	Fitting-Grease
16	116-7671	1	Cable-Broom Angle
17	3217-26	1	Nut-Hex
18	116-8108	1	Cap



Broom Head and Frame Assembly

Ref.	Part Number	Qty.	Description
1	116-8544	1	Frame
2	116-8546	1	Arm-Right
3	116-8545	1	Arm-Left
4	116-8543	2	Caster-Bracket
5	116-8114	1	Shaft
6	322-11	2	Screw-HH
7	3296-29	2	Nut-Lock, NI
8	116-8115	1	Gearbox-Worm
9	83-2800	1	Key-Straight
10	116-8116	2	Bearing-Flange
11	3231-2	16	Bolt-CARR
12	3256-24	16	Washer-Flat

Ref.	Part Number	Qty.	Description
13	3296-39	16	Nut-Lock, NI
14	116-8223	2	Tube-Square, Height Adjust
15	116-8117	2	Caster-Wheel
16	321-9	2	Screw-HH
17	3296-42	2	Nut-Lock, NI
18	103-3202	2	Cap
19	116-8123	1	Broom-Hood ASM
19:3	116-8140	2	Decal-Warning
20	116-8224	2	Pin, Wire Lock
21	3256-2	4	Washer-Flat
22	321-4	4	Screw-HH



Core Assembly

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	116-8119	2	Core-Broom
2	116-8120	18	Segment-Poly
3	116-8121	2	Plate-End, Retainer
4	3234-11	6	Screw-HHF

Attachments and Accessories

For 38700 Walk-Behind Rotary Broom

Product Name	Model/Part
Cab Kit.....	116-8227
Turf Caster Kit.....	116-8228
Dirt Deflector Kit.....	116-8229
Debris Box Kit.....	116-8230
Black Snow/Ice Wafers	116-8232
Yellow Turf Wafers	116-8233
Light Kit.....	116-8234
Rack Kit	116-9820
Electrical Power Kit.....	126-0023
Sprayer Boom Kit.....	126-0024

Notes:

Notes:



Count on it.