


TORO®TRACTION UNIT MODEL:
30793 – 50001 & UP**OPERATOR'S
MANUAL****GROUNDMASTER® 217D****TORO®**THIS UNIT CONFORMS
TO ANSI B71.4 - 1980

To assure maximum safety, optimum performance, and to gain knowledge of the product, it is essential that you or any other operator of the mower read and understand the contents of this manual before the engine is ever started. Pay particular attention to the SAFETY INSTRUCTIONS highlighted by this symbol —



The safety alert symbol means CAUTION, WARNING or DANGER — personal safety instruction. Failure to comply with the instruction may result in personal injury.



FOREWORD

The GROUNDMASTER® 217D was developed to satisfy the demand for a maneuverable, intermediate size, turf maintenance rotary mower. The machine has advanced concepts in engineering, design and safety; and if maintained properly, it will give excellent service.

Since the GROUNDMASTER® 217D is a high-quality product, Toro is concerned about the future use of the machine and safety of the user. Therefore, read this manual to familiarize yourself with proper set-up, operation and maintenance instructions. The major sections of the manual are:

- | | |
|------------------------|---------------------------|
| 1. Safety Instructions | 4. Operating Instructions |
| 2. Set-Up Instructions | 5. Maintenance |
| 3. Before Operating | |

The hydrostatic transmission and axle are not covered in great detail in this manual. However, service manuals are available from the respective manufacturers.

A hydrostatic axle service manual (bulletin no. 5323) can be obtained from:

Dana Corporation
P.O. Box 2229
Ft. Wayne, Indiana 46801

And a hydrostatic transmission service manual (bulletin no. 9646) and a repair manual (bulletin no. 9659) can be obtained from:

Sundstrand Corporation
2800 East 13th Street
Ames, Iowa 50010

Certain information in this manual is emphasized. DANGER, WARNING and CAUTION identify personal safety-related information. IMPORTANT identifies mechanical information demanding special attention. Be sure to read the directive because it deals with the possibility of damaging a part or parts of the machine. NOTE identifies general information worthy of special attention.

OPTIONAL SPARK ARRESTER MUFFLER

In some areas there are local, state or federal regulations requiring that a spark arrester muffler be used on the engine of this mower. If a spark arrester muffler is required, order the following parts from your local Authorized TORO Distributor.

- (1) 56-2180 Spark Arrester Muffler Assembly
- (1) 2112-11 Clamp

These parts are approved by the United States Department of Agriculture and Forestry. The approval number for the exhaust system is U49114.

When mower is used or operated on any California forest, brush or grass covered land, a working order spark arrester muffler must be used. If not, the operator is violating state law, Section 4442 Public Resources Code.

If help concerning set-up, operation, maintenance or safety is ever needed, contact the local Authorized TORO Distributor. In addition to genuine TORO replacement parts, the distributor also has optional equipment for the complete line of TORO turf care equipment. Keep your Toro all TORO. Buy genuine TORO replacement parts and accessories.

TABLE OF CONTENTS

	Page		Page
SAFETY INSTRUCTIONS	4-5	Servicing Dust Cup & Baffle	26
SAFETY AND INSTRUCTION DECALS	6	Servicing Air Cleaner Filter	27
SPECIFICATIONS	7	Inspecting Filter Element	27
LOOSE PARTS	8	ENGINE MAINTENANCE	28-33
SET-UP INSTRUCTIONS	8-9	Cleaning Radiator and Screen	28
Install Steering Wheel	8	Changing Crankcase Oil and Filter	28
Install Standard Seat	8	Servicing Fuel System	28
Install Suspension Seat	9	Bleeding Air From Injectors	30
Check Tire Pressure	9	Replacing Engine Stop Solenoid	30
BEFORE OPERATING	10-11	Servicing Engine Belts	31
Connect Battery	10	Changing Coolant in Cooling System	32
Check Crankcase Oil	10	Removing Fuel Tank from Chassis	32
Check Cooling System	10	Installing Fuel Tank	32
Check Hydraulic System Fluid	10	Servicing Optional Spark Arrestor Muffler	33
Fill Fuel Tank with Gasoline	11	ELECTRICAL MAINTENANCE	33-39
CONTROLS	12-13	Servicing Battery	33
OPERATING INSTRUCTIONS	14-16	Wiring Harness Service	33
Starting/Stopping Engine	14	Fuses	33
Priming Fuel System	14	Adjusting PTO Lever Switch	33
Checking Operation of Interlock Switches	15	Electrical Trouble Shooting	34-39
Operating Characteristics	15	WIRING DIAGRAM	39
Pushing or Towing Traction Unit	16	HYDRAULIC SYSTEM MAINTENANCE	40-42
LUBRICATION MAINTENANCE	16-17	Adjusting Transmission for Neutral	40
BRAKE MAINTENANCE	18-20	Changing Hydraulic Oil and Filter	40
Adjusting Service Brakes	18	Testing Charge Pump Flow, Implement	
Replacing Brake Return Spring	18	Relief and Charge Relief Setting	40
Replacing Parking Brake Rod Spring	19	Servicing Charge Pump, Rotor, Bearing	
Replacing Parking Brake Rack	19	and Lip Seal	41
Replacing Brake Pedal Pivot Bushings	20	Off Season Storage	42
STEERING MAINTENANCE	21-26	DRIVE SYSTEM MAINTENANCE	42-44
Removing Steering Gear	21	Removing Drive Coupling	42
Installing Steering Gear	21	Installing Drive Coupling	43
Adjusting Rear Wheel Bearings	21	Replacing PTO Drive Belt	43
Adjusting Rear Wheel Toe-In	22	Servicing PTO Brake Assembly	44
Servicing Axle Bushings	22	PRODUCT IDENTIFICATION	44
Servicing Steering Plate Bushings	23	PREPARATION FOR	
Servicing Rear Wheel Spindle Bushings	24	SEASONAL STORAGE	45
Replacing and Packing Rear Wheel		SERVICE INTERVAL CHART AND SERVICE	
Bearings	25	SPECIFICATIONS	46-47
AIR CLEANER MAINTENANCE	26-27	THE TORO PROMISE	48
General Maintenance Practices	26		

SAFETY INSTRUCTIONS



This safety alert symbol means **CAUTION, WARNING or DANGER** — “personal safety instruction”. Read and understand the instruction because it has to do with safety. Failure to comply with the instruction may result in personal injury.

The GROUNDMASTER® 217D has been tested and verified for compliance with the B71.4 - 1980 specifications of the American National Standards Institute. However, improper use or maintenance by the owner or operator of the machine can result in injury. To reduce the potential for injury, follow these safety instructions.

BEFORE OPERATING

1. Read and understand the contents of this Operator's Manual before starting and operating the machine. Become familiar with all controls and how to stop quickly. A replacement manual is available by sending complete Model and Serial Number to:

The Toro Company
8111 Lyndale Avenue South
Minneapolis, Minnesota 55420

2. Never allow children or adults unfamiliar with it's operation to operate the machine, and keep everyone, especially children and pets, away from the area of operation.

3. Remove sticks, stones, wire and any other debris or objects that might be picked up and thrown by the cutter blades.

4. Keep all shields and safety devices in place. If a shield, safety device or decal is defective or damaged, repair or replace it before operation is commenced. Also, tighten any loose nuts, bolts and screws to make sure machine is in safe operating condition.

5. Do not operate machine while wearing sandals, tennis shoes, sneakers or shorts. Also, do not wear loose fitting clothing because it could get caught in moving parts. Always wear long pants and substantial shoes. Wearing safety glasses, safety shoes and a helmet is advisable and required by some local ordinances and insurance regulations.

6. Be sure interlock switches are adjusted correctly so engine cannot be started unless traction pedal is released — neutral position — and PTO lever is in DISENGAGE position.

7. Fill fuel tank with diesel fuel before starting the engine. Avoid spilling any fuel. Since fuel is highly flammable, handle it carefully — DO NOT SMOKE.

- A. Use an approved container.
- B. Do not fill tank while engine is hot or running.
- C. Do not smoke while handling diesel fuel.
- D. Fill fuel tank outdoors and up to about one inch (25 mm) from top of the tank, not the filler neck.
- E. Wipe up any spilled fuel. Install fuel container cap and machine fuel tank cap securely before starting the engine.

WHILE OPERATING

8. Do not run the engine in a confined area without adequate ventilation. Exhaust fumes are hazardous and could possibly be deadly.

9. Maximum seating capacity is one person. Never carry passengers.

10. Sit on the seat when starting the engine and operating the machine.

11. When starting the engine:

- A. Engage parking brake.
- B. Be sure traction pedal is in neutral and PTO is in disengage position.
- C. After engine is started, release parking brake and keep foot off traction pedal. Machine must not move. If movement is evident, the neutral return mechanism is adjusted incorrectly; therefore, shut engine off and adjust until machine does not move when traction pedal is released.

12. Using the machine demands attention, and to prevent loss of control:

- A. Mow only in daylight or when there is good artificial light.
- B. Watch for holes or other hidden hazards.
- C. Do not drive close to a sand trap, ditch, creek or other hazard.
- D. Reduce speed when making sharp turns and when turning on hillsides.
- E. Avoid sudden stops and starts.
- F. Before backing up, look to the rear to be sure no one is behind the machine.
- G. Watch out for traffic when near or crossing roads. Always yield the right-of-way.

SAFETY INSTRUCTIONS

13. The grass deflector must always be installed on the cutting unit. If the cutting unit discharge area ever plugs, disengage PTO and shut engine off. Use a stick to remove the obstruction.

14. Never raise the cutting unit while the blades are rotating.

15. If the cutting blades strike a solid object or the machine vibrates abnormally, disengage PTO, move throttle to SLOW, set parking brake and shut engine off. Remove key from switch and disconnect high tension wires from spark plugs to prevent possibility of accidental starting. Check cutting unit and traction unit for damage and defective parts. Make all repairs before restarting the engine and operating the cutting unit. Make sure blades are in good condition and blade bolts are tight.

16. Cut grass slopes carefully. When going up-hill or downhill do not start or stop suddenly.

17. Do not touch engine, muffler or its adjacent shroud while engine is running or soon after it is stopped because these areas could be hot enough to cause a burn.

18. Lower the cutting unit or other attached implement to the ground and remove key from switch whenever machine is left unattended.

19. Before getting off the seat:

- A. Move traction pedal to neutral position and remove foot from pedal.
- B. Set the parking brake and disengage the PTO.
- C. Shut the engine off and remove key from ignition switch. Wait for all movement to stop before getting off the seat.

MAINTENANCE

20. Remove key from ignition switch to prevent accidental starting of the engine when servicing, adjusting or storing the machine.

21. Perform only those maintenance instructions described in this manual. If major repairs are ever needed or assistance is desired, contact an Authorized TORO Distributor.

22. To reduce potential fire hazard, keep the engine free of excessive grease, grass, leaves and accumulations of dirt.

23. Be sure machine is in safe operating condition by keeping nuts, bolts and screws tight. Check the blade mounting bolts frequently to be sure they are tight (75 to 100 ft-lb) (102 to 136 N-m).

24. If the engine must be running to perform a maintenance adjustment, keep hands, feet, clothing and other parts of the body away from the PTO shaft, cutting unit blades and other moving parts.

25. Do not overspeed the engine by changing governor settings. Maximum engine speed (with engine coupled to transmission) is 3100-3250 rpm. To ensure safety and accuracy, have an Authorized TORO Distributor check maximum engine speed with a tachometer.

26. Engine must be shut off before checking oil or adding oil to the crankcase.

27. When manufactured, the GROUNDMASTER® 217D conformed to safety standards in effect for riding mowers. Therefore, to ensure optimum performance and safety, always purchase genuine TORO® replacement parts and accessories. NEVER USE "WILL-FIT" REPLACEMENT PARTS AND ACCESSORIES MADE BY OTHER MANUFACTURERS. Using unapproved replacement parts and accessories could void the warranty of The Toro Company.



CAUTION

1. KEEP ALL SHIELDS IN PLACE.
2. BEFORE LEAVING OPERATOR'S POSITION.
 - A. MOVE TRANSMISSION TO NEUTRAL.
 - B. SET PARKING BRAKE.
 - C. DISENGAGE ATTACHMENT CLUTCH.
 - D. SHUT OFF ENGINE.
 - E. REMOVE IGNITION KEY.
3. WAIT FOR ALL MOVEMENT TO STOP BEFORE SERVICING MACHINE.
4. KEEP BYSTANDERS FROM AREAS BEING MOWED.




SAFETY AND INSTRUCTION DECALS

The following decals are installed on the machine. If any become damaged or illegible, replace it. The decal part number is listed below and in your parts catalog. Replacement can be ordered from your Authorized Toro Distributor.

EMERGENCY OFF  **LIFT CONTROL** 
FLOAT TRANSPORT RAISE

CAUTION
 DISENGAGE THE IMPLEMENT BEFORE RAISING TO TRANSPORT POSITION. DO NOT OPERATE THE IMPLEMENT IN TRANSPORT POSITION.

AROUND LIFT CONTROL LEVER (Part No. 53-8260)

1 INCH (25 MM)  **CAUTION**
 FILL FUEL TANK TO 1 INCH BELOW FILLER NECK. DO NOT OVERFILL

NEAR FUEL CAP (Part No. 27-7310)

CAUTION
 DO NOT USE STARTING FLUID.



ON AIR CLEANER TUBE (Part No. 43-6430)

CAUTION
 CHECK PERFORMANCE OF ALL INTERLOCK SWITCHES DAILY. SEE OPERATOR'S MANUAL FOR INSTRUCTION. DO NOT DEFEAT INTERLOCK SYSTEM. IT IS FOR YOUR PROTECTION.

FORWARD OF LIFT LEVER (Part No. 28-3290)

DIESEL ONLY

ALONGSIDE FUEL CAP (Part No. 52-1320)

OIL PRESSURE  **ON** 
GLOW PLUG SWITCH

FRONT OF CONTROL PANEL (Part No. 53-9160)


DANGER
 KEEP HANDS AND FEET AWAY






ON FUEL TANK (Part No. 43-8480)

CAUTION
 STOP ENGINE BEFORE ADDING FUEL OR LIFTING HOOD. FOR SERVICE INFORMATION SEE OPERATORS MANUAL. READ AND UNDERSTAND OPERATORS MANUAL BEFORE OPERATING THIS MACHINE. REPLACEMENT MANUAL AVAILABLE BY SENDING COMPLETE MODEL NUMBER TO: THE TORO CO., 8111 LYNDALE AVE. MINNEAPOLIS, MINN. 55420


RIGHT SIDE OF SEAT (Part No. 43-4290)

1 INCH (25mm)  **IMPORTANT**
 FILL RADIATOR TO 1 INCH BELOW FILLER NECK. DO NOT OVERFILL. USE 50-50 SOLUTION OF WATER AND ETHYLENE GLYCOL TYPE ANTI-FREEZE.

ALONGSIDE RADIATOR CAP (Part No. 54-7990)

 **PARKING BRAKE INSTRUCTION**  
 1. LOCK BRAKE PEDALS TOGETHER
 2. DEPRESS BRAKE PEDALS.
 3. LIFT PARKING BRAKE KNOB UNTIL BRAKE IS LOCKED
 TO UNLOCK PARKING BRAKE, DEPRESS BRAKE PEDALS

TRACTION PEDAL INSTRUCTIONS
 1. FORWARD DIRECTION
 ROCK PEDAL FORWARD AND DOWN
 2. REVERSE DIRECTION
 ROCK PEDAL REARWARD AND DOWN
 THE MORE THE PEDAL IS DISPLACED, THE FASTER THE VEHICLE SPEED

PARKING BRAKE 

AROUND STEERING COLUMN (Part No. 53-9170)

STARTING INSTRUCTIONS (SEE OPERATOR'S MANUAL)

1. Disengage power take off
2. Place traction drive pedal in neutral position.
3. Depress brake pedal.
4. Set throttle control - full open
5. Push glow plug switch to on position and preheat until the glow plug indicator turns red hot and hold on while starting.
6. Turn key to start position. To stop turn key to off position and remove key.





NOTE: ENGINE WILL SHUT OFF AUTOMATICALLY DUE TO HIGH ENGINE TEMPERATURE WHEN THIS HAPPENS.



1. Allow engine to cool.
2. Clean debris from front of radiator.
3. Check coolant level.
4. CAUTION: Coolant under pressure. Use caution when removing radiator cap to prevent burns.
5. Depress high temperature reset on dash.
5. Restart according to starting instructions.

READ AND UNDERSTAND OPERATOR'S MANUAL BEFORE OPERATING THIS MACHINE. REPLACEMENT MANUAL AVAILABLE BY SENDING COMPLETE MODEL NUMBER TO THE TORO COMPANY, 8111 LYNDALE AVE., MINNEAPOLIS, MN. 55420

CONTROL PANEL (Part No. 43-4290)

ENGAGED ← **POWER TAKE OFF** → **DISENGAGED**

   
OFF **THROTTLE** **FAST** **SLOW**

GLOW PLUG INDICATOR  **TEMP. SHUT OFF**  **PUSH TO RESET**

CAUTION
 1. KEEP ALL SHIELDS IN PLACE
 2. BEFORE LEAVING OPERATOR'S POSITION
 A. SET PARKING BRAKE
 B. DISengage P.T.O. (POWER TAKE OFF)
 C. SHUT OFF ENGINE
 D. REMOVE OPERATOR KEY
 3. WAIT FOR ALL MOVEMENT TO STOP
 4. BEFORE LEAVING MACHINE
 5. KEEP IT TIGHTENED FROM VIBRATION
 6. BEFORE REMOVAL

CONTROL PANEL (Part No. 53-9150)

SPECIFICATIONS

Engine:

Manufacturer — Mitsubishi
 Model — KE75 Type — 61TG
 Horsepower — 17 (12.7 kw) @ 3000 RPM.
 Torque — 30 lb-ft (40.7 N-m) @ 2300 RPM.
 Displacement — 46.6 cu. in. (764 cc).
 Crankcase Capacity — 3.3 qt (3.1 L).
 Governor — Mechanical.
 Governor Limit — 3100-3250 RPM.
 Idle Speed — 1700 RPM.

Air Cleaner: Donaldson heavy duty with pre-cleaner. Remote mounted.

Fuel Tank Capacity: 6 gal (22.7 L).

Electrical: Battery — 12 volt, 54 plate. 35 amp alternator with regulator/rectifier.

Drive Coupling: Transmission driven by steel shaft with flexible rubber couplings at each end.

Transmission:

Manufacturer & Type — Sundstrand hydro-static, Type U.
 Normal Charge Pressure — 70-150 psi (483-1034 kPa).
 Implement Relief Setting — 700-800 psi (4 826 - 5 516 kPa).

Hydraulic Filter: 25 micron mounted directly to transmission. Replaceable (Toro Part No. 23-2300).

Drive Axle: Manufacturer — Dana Corp., Model GT-20. Used as hydraulic reservoir with approx. 5 qt. (5.7 L) capacity. Mates directly with transmission.

Brakes: Mechanical drum type, 7 in. (17.8 cm) dia. x 1-3/4 in. (45 mm) wide. Individually controlled by two pedals connected by cable and conduit for steering assist. Pedals may be latched together for two wheel braking. Lever provided for parking brake.

Tires, Wheels, Pressure:

Wheels — demountable type.
 Front Tires — 20 x 8.00 x 10.
 Rear Tires — 15 x 6.00 x 6.
 All tires 4 ply rating, tubeless type.
 (Pressure — 10-15 psi (69-103 kPa).

Steering: 15 in. (38 cm) steering wheel. Saginaw Automotive steering gear assembly.

Main Frame: Frame is welded, formed steel, reinforced with square tubing.

Gauges: Hour/ammeter and coolant/switchgauge are mounted on steering tower console. Glow plug indicator, low oil pressure light and warning buzzer are on control console.

Controls: Throttle, PTO lever, parking brake, implement lift, ignition switch, high coolant temperature by-pass switch and glow plug switch are all hand-operated. Traction pedal and brakes are foot operated.

PTO Drive: 1 in. (25 mm) diameter, splined PTO shaft is driven by HA Section Torque Team tight-

slack V-belt directly from engine output shaft. PTO shaft clutched by pivoting PTO shaft support with spring loaded, over-center hand operated lever. PTO speed — 2235 RPM @ 3250 RPM engine speed.

Implement connection — Weasler universal joint and telescoping shaft assembly.

Lift Cylinders: Two, with 1-1/2 in. (38 mm) bore, 4 in. (102 mm) stroke.

Control Valve: Equipped with load check valves to prevent settling of implement.

Interlock Switches: Prevents engine starting if traction pedal or PTO levers are engaged. Stops engine if operator leaves seat with either traction pedal or PTO levers engaged.

Dimensions and Weight (approx):

Traction Unit	Length:	78 in. (1.96 m)
w/Standard	Width:	42 in. (1.067 m)
Seat	Height:	48 in. (1.22 m)
	Weight:	1000 lb (454 kg)

OPTIONAL EQUIPMENT:

52" Cutting Unit — Model No. 30560

52" Cutting Unit — Model No. 30555

62" Cutting Unit — Model No. 30562

Mulcher Kit — Model No. 30792. Use with Model 30562 Cutting Unit.

Mulcher Kit — Model No. 30700. Use with Model 30555 Cutting Unit.

Grass Collection System — Model No. 30557. Use with Cutting Unit Model 30555.

V-Plow — Model No. 30750.

V-Plow Mounting Kit — Model No. 30755 (Required for mounting V-Plow). Consists of push arm, attaching brackets and tire chains.

Wheel Weights — Model No. 30762. 100 lb (45.4 kg).

Rear Weight Kit — Part No. 24-5780. 70 lb (31.8 kg).

Tire Chains — Part No. 28-5470. 20 lb (9.07 kg).

Standard Seat Kit — Model No. 30764.

Deluxe Seat Kit — Model No. 30786.

48 in. (1.219 m) Snowthrower — Model No. 30570.

48 in. (1.219 m) Snowthrower Adapter Kit — Model No. 30572.

Note: The following parts are required to mount a snowthrower, V-Plow or broom to a Model 30793 traction unit.

Part No.	Description	Qty
27-4270	Lift Arm	1
27-5270	Brake Spring Strap	2
3272-12	Cotter Pin	2

LOOSE PARTS

Note: Use this chart as a checklist to make sure all parts have been received. Without these parts, total set-up cannot be completed.

DESCRIPTION	QTY.	USE
Dust Cover	1	Install on steering column.
Steering Wheel	1	Mount on steering shaft.
Cap-steering wheel	1	Install in wheel.
Roll Pin 1/4 x 2-1/2 in. (64 mm)	1	Secure steering wheel.
Cylinder Pin	2	Secure frame to lift cylinders.
Cotter Pin 3/16 x 1-1/2 in. (38 mm)	4	Secure cylinder pins.
Roll Pin	1	Secure universal shaft to implement.
Brake Springs	2	Use to mount cutting unit.
Operator's Manual	1	
Parts Catalog	1	
Registration Card	1	
Set-Up Report Card	1	

SET-UP INSTRUCTIONS



WARNING

PTO universal shaft is attached to traction unit. **DO NOT ENGAGE PTO** without first removing universal shaft or coupling it to a suitable implement.

INSTALL STEERING WHEEL

1. Move rear wheels so they point straight ahead.
2. Slide dust cover and steering wheel onto steering shaft and assure small cutout in hub, which accommodates the tab on the steering cap, points toward the seat.
3. Secure steering wheel in place with roll pin (Fig. 1).




Figure 1

1. Roll pin
2. Dust cover

4. Insert tab of steering cap into cutout in steering wheel hub. Then continue to press cap into groove in the hub.

INSTALL STANDARD SEAT

1. Aligning outside mounting holes of seat mounts with mounting holes in seat, position two (2) capscrews and lockwashers for each seat spring thru seat mounts as shown in Fig. 2. Secure each seat mount, capscrews and lockwashers to seat with two (2) capscrews and lockwashers (Fig. 2).

Note: Use forward set of tapped mounting holes in seat.




Figure 2

1. Outside mounting holes
2. Seat mounts
3. Capscrew and lockwasher

SET-UP INSTRUCTIONS

- Loosely secure seat springs to seat mounts with four (4) hex nuts as shown in Fig. 3.




Figure 3

1. Seat spring
2. Hex nuts

- Mount seat and springs to rear holes in mount plate with (2) shoulder bolts, flatwashers and locknuts (Fig. 4).

- Secure front slots of seat springs to mount plate with adjustment handles and flatwashers (Fig. 4).

Note: Be sure to use flatwashers with small I.D.

- When seat is adjusted to desirable position, tighten all fasteners.




Figure 4

1. Shoulder bolt, flatwasher, locknut
2. Adjustment handle
3. Flatwasher
4. Mount plate

INSTALL SUSPENSION SEAT

- Tip seat mount forward.
- Disengage hood latches and open the hood.
- Remove knob from lift lever.
- Remove capscrews, lockwashers and flatwashers securing seat support cover to frame. Lift seat support cover off frame.
- Unplug seat switch. Remove capscrews, lockwashers and flatwashers securing seat support to top of frame.
- Remove seat pin and spring from seat support.

- Secure olive colored spring from deluxe seat kit and pin to seat support bracket by compressing spring and inserting roll pin through pin (Fig. 5).




Figure 5

1. Plastic pin
2. Pin
3. Spring
4. Roll pin

- Reinstall seat support with capscrews, lockwashers and flatwashers. Connect seat switch.

- Slide seat support cover onto the lift lever and position the cover on the frame. Secure seat support cover in place with capscrews, lockwashers and flatwashers.

- Install knob onto lift lever.

- Unsnap rubber bellows and mount seat suspension to seat mount with (4) capscrews, lockwashers and nuts (Fig. 6).




Figure 6

1. Snaps
2. Bellows
3. Seat mount

- Resnap bellows in place.

- Slide seat onto track of suspension by releasing track latch.

CHECK TIRE PRESSURE

The tires are over-inflated for shipping. Therefore, release some of the air to reduce the pressure. Correct air pressure in front and rear tires is 10 to 15 psi (68.9 to 103.4 Kpa).

BEFORE OPERATING

CONNECT BATTERY

1. Loosen capscrew securing battery cover and open cover (Fig. 7).




Figure 7

1. Battery cover capscrew

2. Slide battery partially out of battery compartment until terminals are accessible (Fig. 8).




Figure 8

1. Positive battery cable
2. Negative battery cable

3. Connect the positive battery cable (red) to the positive post (+) of the battery. Secure with wrench, coat terminal with petroleum jelly and slide boot over terminal.
4. Connect the black ground cable to the negative (-) post of battery. Secure with wrench, coat terminal with petroleum jelly.
5. Slide battery back into battery compartment and secure cover.

CHECK CRANKCASE OIL

The engine is shipped with 3.3 qts. (3.1 L) of oil in the crankcase; however, level of oil must be checked before and after the engine is first started.

1. Position machine on a level surface.
2. Disengage hood latches and open the hood.
3. Unscrew dipstick and wipe it with a clean rag. Screw dipstick into the filler neck and make sure it is seated fully. Unscrew dipstick and check level of oil (Fig. 9). If oil level is low, add enough oil to raise level to FULL mark on dipstick. Do not overfill.

Note: If level of oil is at the ADD mark on the dipstick, add 1 pint (0.47 L) of oil to raise level to FULL. Do not overfill.

4. The engine uses any high-quality 10W-30 detergent oil having the American Petroleum Institute — API — “service classification” SF, CC or CD.

IMPORTANT: Check level of oil every 5 operating hours or daily. Initially, change oil after the first 50 hours of operation; thereafter, under normal conditions, change oil after every 100 hours of




Figure 9

1. Dipstick

operation. However, change oil more frequently when engine is operated in extremely dusty or dirty conditions.

5. Screw dipstick into filler neck.

CHECK COOLING SYSTEM

Clean debris off screen and front of radiator daily, hourly if conditions are extremely dusty and dirty; refer to Cleaning Radiator and Screen, page 27.

The cooling system is filled with a 50/50 solution of water and permanent ethylene glycol anti-freeze. Check level of coolant at beginning of each day, before starting the engine. Capacity of cooling system is approximately 6 quarts (5.7 L).

1. Carefully remove radiator cap.



CAUTION

If engine has been running, pressurized hot coolant can escape and cause burns.

2. Check level of coolant in radiator. Level of coolant must be above the core and about 1 inch (25 mm) below bottom of filler neck.
3. If coolant level is low, replenish the system. **DO NOT OVERFILL.**
4. Install radiator cap.

CHECK HYDRAULIC SYSTEM FLUID

The axle housing acts as the reservoir for the system. The machine's transmission and axle housing is filled at the factory with approximately 5 quarts (4.73 L) of SAE 10W-30 engine oil. However, check level of transmission fluid before engine is first started and daily thereafter. If oil is required, use the following:

BEFORE OPERATING

Above 32°F (0°C) — Use SAE 10W-30 engine oil. SAE 10W-40 engine oil or type A automatic transmission fluid may be used as a substitute.

Below 32°F (0°C) — Use type A automatic transmission fluid. SAE 5W-20 engine oil may be used as a substitute.

IMPORTANT: DO NOT intermix automatic transmission fluid with engine oil. DO NOT USE DEXTRON II ATF.

1. Position machine on a level surface, raise the cutting unit and stop the engine.
2. Remove dipstick cap (Fig. 10) from filler neck and wipe it with a clean rag. Screw dipstick cap finger-tight onto filler neck; then remove it and check level of fluid. If level is not within 1/2 inch (13 mm) from the groove in the dipstick (Fig. 10), add SAE 10W-30 engine oil, or, if used, automatic transmission fluid to raise level to groove mark. Do not overfill.




Figure 10

1. Dipstick 2. Filler neck

IMPORTANT: When adding transmission fluid to the hydraulic system, use a funnel with a fine wire screen — 200 mesh or finer — and make sure funnel and transmission fluid are immaculately clean. This procedure prevents accidental contamination of the hydraulic system.

3. Thread dipstick filler cap finger-tight onto filler neck. It is not necessary to tighten cap with a wrench.

FILL FUEL TANK WITH DIESEL FUEL

The engine runs on No. 1-D or 2-D automotive type diesel fuel with a minimum cetane rating of 40.

Note: Higher cetane rated fuel may be required if machine is to be used at high altitudes and low-atmospheric temperatures.

Use No. 2-D diesel fuel at temperatures above 20°F (-7°C) and No. 1-D diesel fuel below 20°F (-7°C). Use of No. 1-D diesel fuel at lower temperatures provides lower flash point and pour point characteristics, therefore easing startability and lessening chances of chemical separation of the fuel due to low temperatures (wax appearance, which may plug filters).

Use of No. 2-D diesel fuel above 20°F (-7°C) will contribute toward longer life of the pump com-

ponents. Do not use furnace oil. Furnace oils usually contain heavy cracked distillates which are not suitable for diesel engines.

Store fuel outside of buildings in a convenient location. Tipping the front of the tank up slightly will allow contaminants to collect at the lower end away from the outlet. Never empty the tank below 4 in. (10 cm) from the bottom of the tank to avoid picking up water and other contaminants that may have collected at the bottom. Either filter the remainder at the bottom through a chamois or dispose of it periodically to prevent excessive build-up of contaminants.

Keep all fuel containers free of dirt, water, scale and other contaminants. Many engine difficulties can be traced to contaminants in the fuel.

Use only metal containers for fuel storage. **DO NOT** store the fuel in a galvanized metal container. A chemical reaction will result, which will plug the filters and cause possible fuel system damage.

If possible, fill the fuel tank at the end of each day. This will prevent possible buildup of condensation inside the fuel tank, preventing possible engine damage. Allow the engine to thoroughly cool down before refueling.

1. Tip seat forward and prop it so it cannot fall accidentally. Using a clean rag, clean area around fuel tank cap.
2. Remove cap from the fuel tank and fill the 6 gallon (22.7 L) tank to within 1 inch (25 mm) from the top with diesel fuel. Install fuel tank cap tightly after filling tank.



DANGER

Because diesel fuel is flammable, caution must be used when storing or handling it. Do not fill fuel tank while engine is running, hot or when machine is in an enclosed area. Vapors may build up and be ignited by a spark or flame source many feet away. **DO NOT SMOKE** while filling the fuel tank to prevent the possibility of an explosion. Always fill fuel tank outside and wipe up any spilled diesel fuel before starting engine. Use a funnel or spout to prevent spilling diesel fuel and fill tank to about 1 inch (25 mm) below the filler neck. Store diesel fuel in a clean safety-approved container and keep the cap in place on the container. Keep diesel fuel in a cool, well-ventilated place; never in an enclosed area such as a hot storage shed. To assure volatility and to prevent contamination, do not buy more than a 6 month supply.

CONTROLS

Parking Brake (Fig. 11) — Whenever the engine is shut off, the parking brake must be engaged to prevent accidental movement of the machine. To engage the parking brake, push lock arm (Fig. 12) on right brake pedal between the left brake and its lock tab. Next, push down fully on both pedals and pull parking brake knob out; then release the pedals. To release parking brake, depress both pedals until parking brake knob retracts. Before starting the engine, however, lock arm may be disengaged from left brake pedal so both pedals work independently with each front wheel.




Figure 11

1. Parking brake
2. Temp switch/Gauge & reset
3. Ammeter/Hour meter

Ammeter/Hour meter (Fig. 11) — Ammeter shows charge rate of the battery by the alternator. When engine is running, there must always be a slight charge, unless engine is idling slowly. Needle will point to 0 when battery is fully charged. By contrast, alternator is not charging the battery when needle points to (—) negative side of ammeter, and if this happens, repair the charging system to prevent discharge of the battery. Accumulated engine operating time registers on the hour meter.

Temperature Switch/Gauge and Reset Button (Fig. 13) — The temperature switch/gauge registers the temperature of the coolant in the cooling system. If temperature of coolant gets too high the engine will shut off automatically. When this happens, rotate ignition key to OFF. Automatic shut-off of the engine usually results from debris on front of screen or radiator, which reduces air flow. After cleaning outside of screen and radiator or repairing some other damage, press the reset button and start the engine.

Service Brakes (Fig. 12) — The left and right brake pedals are connected to the left and right front wheels. Since both brakes work independently of each other, the brakes can be used to turn sharply or to increase traction if one wheel tends to slip while operating on certain slope conditions. However, wet grass or soft turf could be damaged when




Figure 12

1. Lock arm
2. Left brake
3. Right brake
4. Traction pedal

brakes are used to turn sharply. To make a "quick-stop", depress both brake pedals together.

Traction Pedal (Fig. 12) — Traction pedal has two functions: one is to make the machine move forward, the other is to make it move rearward. Using the heel and toe of the right foot, depress top of pedal to move forward and bottom of pedal to move rearward. Ground speed is proportionate to how far pedal is depressed. For maximum ground speed with no load, traction pedal must be fully depressed while throttle is in FAST position. Maximum speed forward is 8.5 mph (13.7 Km/hr) (approx), 4 mph (6.4 Km/hr) (approx) in reverse. To get maximum power under heavy load or when ascending a hill, have throttle in FAST position while depressing traction pedal slightly to keep engine rpm high. When engine rpm begins to decrease, release traction pedal slightly to allow rpm to increase.

Low Oil Pressure Light/Buzzer (Fig. 13) — If oil pressure falls below a safe level, the buzzer sounds and the light glows. Stop engine and repair before resuming operation.

PTO Lever (Fig. 13) — The PTO lever has two positions: ENGAGE and DISENGAGE. Push PTO lever fully forward to ENGAGE position to start the cutting unit blades. Pull lever rearward to DISENGAGE position to stop the blades. The only time PTO lever should be in the ENGAGE position is when cutting unit is on the turf and grass is actually being mowed.

Ignition Switch (Fig. 13) — The ignition switch, which is used to start and stop the engine, has three positions: OFF, RUN and START. Rotate key clockwise — START position — to engage starter mower. Release key when engine starts. The key will move automatically to the ON position. To shut engine off, rotate key counterclockwise to the OFF position.

CONTROLS




Figure 13

- | | |
|--------------------------------|---------------------------|
| 1. PTO lever | 4. Throttle |
| 2. Ignition switch | 5. Lift lever |
| 3. Glowplug switch & indicator | 6. Low oil pressure light |

IMPORTANT: If the switch ever must be overridden because of an emergency, the engine can be started and will continue to run while reset button is held in.

Glow Plug Switch and Indicator (Fig. 13) — Use to preheat engine cylinders before and during starting procedures. Push switch lever upward and hold while watching indicator. Indicator will glow red when sufficiently heated. Length of time necessary to preheat cylinders should be determined by atmospheric temperature; refer to Starting/Stopping Engine, page 14.

Throttle (Fig. 13) — Throttle is used to operate engine at various speeds. Moving throttle forward increases engine speed — FAST; rearward decreases engine speed — SLOW. The throttle controls the speed of the cutter blades and, in conjunction with traction pedal, controls ground speed of the engine.

Note: If ignition switch fails, move throttle to SLOW to shut engine off.

Hydraulic Lift Lever (Fig. 13) — The hydraulic lift lever has three positions: FLOAT, TRANSPORT and RAISE. To lower cutting unit to the ground, move lift lever forward into notch in seat cover — FLOAT. The FLOAT position is used for mowing and when machine is not in operation. To raise cutting unit, pull lift lever rearward to the RAISE position. After cutting unit is raised, allow lift lever to move to the TRANSPORT position. Cutting unit must be raised when driving from one work area to another.



CAUTION

Never raise cutting unit while blades are rotating because it is hazardous.

Seat Adjusting Handle — Standard Seat — To adjust seat, loosen adjusting handle and slide seat to desired position. Tighten handle to lock seat in place.

Seat Adjusting Handle — Deluxe Seat (Not Shown) — To adjust seat, move lever on right side outward, slide seat to desired position and release lever so it will lock in track.

OPERATING INSTRUCTIONS

STARTING/STOPPING ENGINE

IMPORTANT: The fuel system must be primed if any of the following situations have occurred:

- A. Initial start up of a new machine.
- B. Engine has ceased running due to lack of fuel.
- C. Maintenance has been performed upon fuel system components; i.e., filter replaced, separator serviced, etc.

Refer to Priming Fuel System, page 14.

1. Ensure parking brake is set, PTO lever is in OFF position and lift lever is in TRANSPORT or FLOAT position (Fig. 13). Remove foot from traction pedal and insure it is in neutral.
2. Move throttle control (Fig. 13) to full FAST position.
3. If atmospheric temperature is above 50° F (10° C), use starting procedures in step 5; if below 50° F (10° C), use procedures in step 4.
4. Push glow plug switch to ON position (Fig. 13) and hold until indicator glows red. Continue to hold switch in position for suggested interval and turn key in key switch to START position. Release glow plug switch after engine starts and allow key to return to RUN position. Move throttle control to SLOW position.

Note: Refer to chart indicating approximate pre-heat time suggested in various temperature ranges.

Temperature	Preheat time (sec)
20° C (68° F)	0
10° C (50° F)	0
0° C (32° F)	20
-5° C (23° F)	60
-10° C (14° F)	80
-20° C (-4° F)	100
-25° C (-13° F)	120

Note: Do not run starter motor more than 10 seconds at a time or premature starter failure may result. If engine fails to start after 10 seconds, turn key to OFF position, recheck controls and procedures, wait 10 additional seconds and repeat starter operation.

5. Turn key in key switch to START position (Fig. 13). Release key immediately when engine starts and allow it to return to RUN position. Move throttle control to SLOW position.

Note: Do not exceed 2 minutes of continuous use or glow plug may burn out prematurely.

6. When engine is started for the first time, or after overhaul of the engine, transmission or axle, operate the machine in forward and reverse for one to two minutes. Also operate the lift lever and PTO lever to assure proper operation of all parts. Turn steering wheel to the left and right to check steering response. Then shut engine off and check for oil leaks, loose parts and any other noticeable defects.



CAUTION

Shut engine off and wait for all moving parts to stop before checking for oil leaks, loose parts and other defects.

7. To stop engine, move throttle control backward to SLOW position, move PTO lever to OFF position and rotate ignition key to OFF. Remove key from switch to prevent accidental starting.

PRIMING FUEL SYSTEM

1. Unlatch and raise hood over engine.
2. Loosen screw No. 1 on top of fuel filter (Fig. 14).




Figure 14

- 1. Screw #1
- 2. Screw #2
- 3. Fuel filter
- 4. Air bleed screw

3. Turn key in ignition switch to the RUN position. Electric fuel pump will begin operation, thereby forcing air out around air bleed screw. Fuel should start to fill bowl of filter and finally begin to flow out around screw.

OPERATING INSTRUCTIONS

4. Continue until a solid stream of fuel flows out around screw. Turn screw No. 1 to closed position and open screw No. 2 (Fig. 14).

Note: If engine has stopped because of lack of fuel, it may be necessary to continue priming for several additional minutes to ensure all air is removed from system.

5. Continue until solid stream of fuel flows out around second screw. Tighten screw.

6. Open the air bleed screw on the fuel injection pump (Fig. 14 inset) with a 12 mm wrench. Tighten screw when solid stream of fuel flows out around screw. Turn key off.

CHECKING OPERATION OF INTERLOCK SWITCHES

The purpose of the safety interlock system is to prevent the engine from cranking or starting unless the traction pedal is in neutral and the PTO control lever is in the DISENGAGE position. In addition, the engine will stop if the operator gets off the seat when the PTO control is engaged or traction pedal is depressed.



CAUTION

Do not disconnect the safety switches because they are for the operator's protection. Check operation of the switches daily to be sure the interlock system is operating correctly. If a switch is defective, replace it before operating the machine. Replace the switches every 2 years to be sure of maximum safety.

1. Move PTO lever to disengage position and remove foot from traction pedal so it is fully released.

2. Rotate the ignition key to START. Engine should crank. If engine cranks, proceed to step 3. If engine does not crank, there may be a defect in the interlock system; refer to Electrical Troubleshooting, page 34.

3. Raise off the seat and engage the PTO lever while the engine is running. The engine should stop. If engine stops, the switch is operating correctly; thus, proceed to step 4. If engine does not stop, there is a defect in the interlock system; refer to Electrical Troubleshooting, page 36.

4. Raise off the seat and depress the traction pedal while engine is running and PTO lever is

disengaged. The engine should stop. If engine stops the switch is operating correctly; thus, continue operation. If engine does not stop, there is a defect in the interlock system; refer to Electrical Troubleshooting, page 36.

OPERATING CHARACTERISTICS

Practice driving the GROUNDMASTER® 217D before initial operation because it has a hydrostatic transmission and its characteristics are different than some turf maintenance machines. Some points to consider when operating the traction unit and cutting unit are the transmission, engine speed, load on the cutting blades, and the importance of the brakes.

To maintain enough power for the traction unit and cutting unit while mowing, regulate traction pedal to keep engine rpm high and somewhat constant. A good rule to follow is: decrease ground speed as the load on the cutting blades increases; and increase ground speed as load on the blades decreases. This allows the engine, working with the transmission, to sense the proper ground speed while maintaining high blade tip speed, necessary for good quality-of-cut. Therefore, allow traction pedal to move upward as engine rpm decrease, and depress pedal slowly as rpm increase. By comparison, when driving from one work area to another — with no load and cutting unit raised — have throttle in FAST position and depress traction pedal slowly but fully to attain maximum ground speed.

Another characteristic to consider is the operation of the brakes. The brakes can be used to assist in turning the machine; however, use them carefully, especially on soft or wet grass because the turf may be torn accidentally. The brakes can also be used for control of the cutting unit. The brakes can be used to great advantage to control the direction of the cutting unit when trimming along fences or similar objects. The other benefit of the brakes is to maintain traction. For example: in some slope conditions, the uphill wheel slips and loses traction. If this situation occurs, depress uphill brake pedal gradually and intermittently until the uphill wheel stops slipping; thus, increasing traction on the downhill wheel. If independent braking is not desired, engage the lever on right brake pedal with left pedal. This provides simultaneous braking at both wheels.

Before stopping the engine, disengage all controls and move throttle to SLOW. Moving throttle to SLOW reduces high engine rpm, noise and vibration. Turn key to OFF to stop the engine.

OPERATING INSTRUCTIONS

PUSHING OR TOWING TRACTION UNIT

In an emergency, the traction unit can be pushed or towed for a very short distance. However, Toro does not recommend this as standard procedure.

IMPORTANT: Do not push or tow the traction unit faster than 2 to 3 mph (3.2 to 4.8 Km/hr) because transmission may be damaged. If traction unit must be moved a considerable distance, transport it on a truck or trailer. Whenever traction unit is pushed or towed, by-pass valve must be open.

1. Unlatch and raise hood, remove knob from lift lever.
2. Remove capscrews, lockwashers and flat-washers securing seat support cover to frame.
3. Pivot seat forward and support it to prevent it from falling accidentally. Lift seat support cover off frame.
4. Depress and hold the pins located in the center of the two (2) check valve assemblies in the top of the transmission (Fig. 15) while pushing or towing the machine.




Figure 15

1. Check valve pins

5. Start engine momentarily after repairs are completed and make sure the pins are in the full disengaged (fully up) position.

IMPORTANT: Running the machine with by-pass valve open will cause the transmission to overheat.

LUBRICATION MAINTENANCE

GREASING BEARINGS AND BUSHINGS

The traction unit has grease fittings that must be lubricated regularly with No. 2 General Purpose Lithium Base Grease. If machine is operated under normal conditions, lubricate all bearings and bushings after every 25 hours of operation. Bearings and bushings must be lubricated daily when operating conditions are extremely dusty and dirty. Dusty and dirty operating conditions could cause dirt to get into the bearings and bushings, resulting in accelerated wear.

Apply a liberal coating of grease to the check valve pins once each year (Fig. 15). Also grease the bearings in the Dana axle every 500 hours, or yearly, whichever comes first (not shown). The traction unit has bearings and bushings that must be lubricated, and these lubrication points are: PTO shaft (Fig. 16); lift arm pivot bushings (Fig. 17); intermediate steering arm pivot bearings (Fig. 18); brake pivot bushings (Fig. 18); PTO shaft engaging lever bearings (Fig. 19); rear wheel spindle bushings (Fig. 21); steering plate bushings (Fig. 20); axle pin bushing (Fig. 20); PTO idler assembly bearings (Fig. 22); and engine output bearing (Fig. 73). Also apply grease to both brake cables at the drive wheel and brake pedal ends (Fig. 18).

1. Wipe grease fitting clean so foreign matter cannot be forced into the bearing or bushing.
2. Pump grease into the bearing or bushing.
3. Wipe up excess grease.




Figure 16

LUBRICATION MAINTENANCE




Figure 17




Figure 20




Figure 18

1. Apply grease to cable ends




Figure 21




Figure 19




Figure 22

BRAKE MAINTENANCE

ADJUSTING SERVICE BRAKES

Adjust the service brakes when there is more than one inch (25 mm) of "free travel" of the brake pedals, or when the brakes do not work effectively. Free travel is the distance the brake pedal moves before braking resistance is felt.

The brakes should be checked for adjustment after the first 25 hours operation and should only need adjusting after considerable use thereafter. These periodic adjustments can be performed where the brake cables connect to the bottom of the brake pedals. When the cable is no longer adjustable, the star nut on inside of the brake drum must be adjusted to move the brake shoes outward. However, the brake cables must be adjusted again to compensate for this adjustment.

1. Disengage lock arm from left brake pedal so both pedals work independently of each other.

2. To reduce free travel of brake pedals — tighten the brakes — loosen front nut on threaded end of brake cable (Fig. 23). Then tighten rear nut to move cable backward until brake pedals have 1/2 to 1 inch (13 mm to 25 mm) of free travel. Tighten front nut after brakes are adjusted correctly.




Figure 23
1. Jam nuts

3. When adjustment of brake cables cannot get free travel within 1/2 to 1 inch (13 mm to 25 mm), the star-nut inside the brake drum must be adjusted. However, before adjusting the star-nut, loosen brake cable nuts to prevent unnecessary strain on the cables.

4. Loosen five wheel nuts holding wheel and tire assembly on wheel studs.

5. Jack up machine until front wheel is off the shop floor. Use jack stands or block the machine to prevent it from falling accidentally.

6. Remove wheel nuts and slide wheel and tire assembly off studs. Rotate brake drum until adjusting slot is at top and centered over star-nut that adjusts brake shoes (Fig. 24).




Figure 24

1. Brake adjusting slot

7. Using a brake adjusting tool or screwdriver rotate star-nut (Fig. 25) until brake drum (Fig. 24) locks because of outward pressure of brake shoes (Fig. 25).




Figure 25

1. Star nut 2. Brake shoe

8. Loosen star-nut about 12 to 15 notches or until brake drum rotates freely.

9. Install wheel and tire assembly on studs with five wheel nuts. Tighten nuts to 60-80 ft-lb (81-109N·m).

10. Remove jack stands or blocking and lower machine to the shop floor.

11. Adjust the brake cables; use step 2.

REPLACING BRAKE RETURN SPRING

1. Disengage spring from slotted hole on lift arm (Fig. 26). Since spring is tensioned, retract it carefully.

2. Remove end of spring from clevis pin retaining brake strut and brake cable yoke together (Fig. 26).

3. To install new spring, slide clevis pin through yoke and strut with hole end of clevis pin facing upward. Install short end of spring into hole in clevis pin.

BRAKE MAINTENANCE

4. Using a vise grip pliers, install long end of spring through slotted hole in cutting unit suspension frame (Fig. 25).




Figure 25

1. Brake return spring
2. Slotted hole

REPLACING PARKING BRAKE ROD SPRING

1. Remove the self tapping screws holding steering tower cover in place (Fig. 27) and remove cover.




Figure 27

1. Cover

2. Screw knob and locknut off top end of the parking brake rod (Fig. 28).




Figure 28

1. Locknut
2. Parking brake rod

3. Remove capscrews securing steering gear to the tower.

4. Remove cotter pin and flatwasher from bottom end of parking brake rod (Fig. 29) and cotter pin and flatwasher holding rack (Fig. 30). Lift up on gear box and remove brake rod from rack. Remove the other flatwasher from the rod and slide rod out of hole in the steering tower.




Figure 29

1. Cotter pin and flatwasher

5. Slide defective spring off top end of parking brake rod.

6. Install new spring on parking brake rod and make sure it seats against the flatwasher. Slide top end of rod through hole in steering tower and thread locknut onto rod until nut is fully installed.

7. Slide flatwasher on bottom end of rod, lift up on gear box, slide rack towards gear box and insert rod through parking brake rack. Secure rod and rack together with flatwasher and cotter pin. Secure rack with remaining cotter pin and flatwasher.

8. Secure steering gear box to tower and install steering tower cover with self tapping screws.

REPLACING PARKING BRAKE RACK

1. Remove self tapping screws holding steering tower cover in place and remove cover. Remove capscrews securing steering gear to the tower.




Figure 30

1. Cotter pin and flatwasher

BRAKE MAINTENANCE

2. Remove cotter pin and flatwasher securing lower end of parking brake rod (Fig. 29) and cotter pin and flatwasher securing rack (Fig. 30). Lift up on gear box, slide rack outward towards gear box off the pivot pin (Fig. 30). Slide rod out of rack.

3. Lift up on gear box, slide new rack onto pivot pin, slip lower end of brake rod with flatwasher into rack and secure rack and rod with flatwashers and cotter pins.

4. Secure steering gear box to tower and install steering tower cover with self tapping screws.

REPLACING BRAKE PEDAL PIVOT BUSHINGS

The brake pedals must be held in place snugly by the brake pivot pin. Excessive movement of the brake pedal, other than brake pedal free travel, usually indicates worn bushings. To correct problem, replace the bushings.

1. Loosen brake cable jam nuts and disengage brake cables from brake pedals (Fig. 31).

2. Remove locknut from brake pivot pin (Fig. 31). Slide pivot pin out to the side so pedal can be removed.




Figure 31

- 1. Jam nuts
- 2. Locknut

3. Slide brake pedals backward and remove them through the slot in bottom of steering tower.

4. Using pin punch and hammer, drive both bushings out of brake pivot (Fig. 32). Clean inside of brake pivot to remove dirt and foreign matter.




Figure 32

5. Apply grease to the inside and outside of the new bushings. Use an arbor press to drive new bushings into both ends of the brake pivot. Bushings must be flush with ends of brake pivot.

6. Wipe brake pivot pin with a rag to remove dirt and grease. Hold left brake pedal, which can be identified by an additional welded bracket, in position and install pivot pin through side plate and brake pivot. Hold right brake pedal in position and push the pin through the brake pivot and opposite side plate. Tab end of pin (Fig. 33) must engage bottom edge of side plate to prevent pivot pin from rotating and causing wear. Install locknut on end of pivot pin to hold all parts in place.




Figure 33

- 1. Tab end of pin

7. Connect brake cables to brake pedals. Adjust the brakes; refer to Adjusting Service Brakes, page 18.

8. Lubricate brake pivot bushings through the grease fittings, using no. 2 grease.

STEERING MAINTENANCE

REMOVING STEERING GEAR

1. Remove self tapping screws holding steering tower cover in place.
2. Mark steering arm and steering gear shaft (Fig. 34) so arm can be installed in the same place when parts are assembled.




Figure 34

- | | |
|---|-----------------------|
| 1. Steering arm | 3. Nut and lockwasher |
| 2. Cotter pin and slotted nut
(lower end of arm) | 4. 5/8 in. (16 mm) |
| | 5. Steering clamp |

3. Remove cotter pin and slotted nut holding steering control rod and steering arm together (Fig. 34). Separate ball socket at end of control rod from steering arm.
4. Remove large nut and lockwasher holding steering arm on gear box shaft (Fig. 34). Use a puller to remove the arm from the shaft.
5. Loosen steering-clamp carriage bolt and lock-nut (Fig. 34) until clamp can be moved.
6. Remove capscrews and lockwashers retaining steering gear against steering tower (Fig. 35). Slide steering gear down off steering tube and away from the tower.




Figure 35

1. Capscrews and lockwashers

INSTALLING STEERING GEAR

1. Slide steering clamp onto input shaft of steering gear.
2. Insert input shaft of steering gear into steering tube and hold gear against steering tower. Secure gear in place with three capscrews and lockwashers (Fig. 35). Lock steering gear and tube together by tightening steering clamp locknut and carriage bolt.
3. Slide steering arm onto steering shaft and ensure the alignment marks — made when parts were removed — are in line. Secure arm on shaft with lockwasher and large nut (Fig. 34). Tighten nut until inside of arm is 5/8 in. (16 mm) from the steering gear, which should allow clearance for the steering linkage.
4. Slide ball socket at end of steering control rod through steering arm. Secure parts together with slotted nut and cotter pin (Fig. 34).
5. Install steering tower with self tapping screws.

ADJUSTING REAR WHEEL BEARINGS

1. Jack up rear of machine until wheel is off shop floor. Use jack stands or block the machine to prevent it from falling accidentally.
2. Remove dust cap from end of wheel spindle. Also remove cotter pin retaining slotted nut in place (Fig. 36).




Figure 36

1. Cotter pin

STEERING MAINTENANCE

3. Rotate the wheel by hand and tighten the slotted nut (Fig. 37) until the bearing binds slightly. Then, loosen nut until the nearest slot and hole in spindle line up. Reinstall the cotter pin to retain the slotted nut in place.




Figure 37

1. Slotted nut

4. Remove jack stands and lower machine to shop floor.

5. Install dust cap on end of the wheel spindle (Fig. 38).




Figure 38

1. Dust cap

ADJUSTING REAR WHEEL TOE-IN

The rear wheels should have 0 to 1/8 of an inch (3 mm) toe-in when they are straight ahead. To check toe-in, measure the center-to-center distance, at wheel hub height, in front and in back of the rear tires. If toe-in is not 0 to 1/8 of an inch (3 mm), an adjustment is required.

1. Rotate the steering wheel so rear wheels are straight ahead.

2. Loosen the jam nuts on both tie rods (Fig. 39). Adjust both tie rods until center-to-center distance (Fig. 39) at front of rear wheel is 1/8 of an inch (3 mm) less than that at back of rear wheel.

3. When toe-in of rear wheels is set correctly, tighten jam nuts against tie rods (Fig. 39).




Figure 39

SERVICING AXLE BUSHINGS

The rear axle must be held in place snugly by the axle pin. Excessive movement of the axle, which is characterized by erratic steering, usually indicates worn bushings. To correct the problem, replace the bushings.

1. Remove cotter pin and slotted nut from tie rod end that connects steering tube to steering plate (Fig. 40). Separate tie rod end from plate.




Figure 40

1. Steering tube

2. Remove large locknut from end of rear axle pin (Fig. 41).




Figure 41

1. Locknut

STEERING MAINTENANCE

3. Remove capscrew, lockwasher and flatwasher holding outside of axle pin to chassis (Fig. 42).




Figure 42

1. Rear axle pin
2. Capscrew, lockwasher and flatwasher

4. Jack up frame — just ahead of the rear wheels — until pressure is taken off the axle pin. Pull axle pin out which will release the rear axle and thrust washers from the frame.

5. Carefully roll the entire rear axle and wheel assembly out from under the machine. Set axle assembly onto the work bench.

6. Using pin punch and hammer, drive both bushings out of axle (Fig. 43). Clean inside of axle to remove dirt and foreign matter.

7. Notice groove on inside of new bushing. When it is installed, open end of groove must be to the outside of axle pivot tube. Apply grease to the inside and outside of the new bushings. Use an arbor press to drive bushings into the top and bottom of the axle pivot tube. Bushings must be flush with axle tube (Fig. 43).




Figure 43

1. Bushing
2. Axle pivot tube

8. Wipe rear axle pin with a rag to remove dirt and grease.

9. Move rear axle into position at rear of machine. Mount axle between two sections of frame with axle pin and two thrust washers (Fig. 44). The thrust washers must be positioned at ends of the axle pivot tube and between both sections of the frame. Secure axle pin in place with capscrew, lockwasher and flatwasher (Fig. 42).

Note: If more than .030" clearance is evident between frame and pivot tube, position spacer (part no. 5-1226) between pivot tube and thrust washer.




Figure 44

1. Rear axle pin 2. Washer and spacer (if required)

10. Install large locknut on end of axle pin (Fig. 41). Tighten locknut until all forward and backward movement of the axle is eliminated. However, the axle must still pivot freely.

11. Remove the jack stands and lower the machine to the shop floor.

12. Slide tie rod end at end of steering tube through steering plate, and secure parts together with slotted nut (Fig. 40). Tighten nut until it is tight and holes in nut and tie rod end line up. Then install cotter pin through nut and tie rod end.

13. Lubricate rear axle bushings through the grease fitting on rear axle (Fig. 20).

SERVICING STEERING PLATE BUSHINGS

The steering plate must fit snugly on the mounting pin. Excessive movement of the steering plate usually indicates worn bushings. To correct the problem, replace the bushings.

1. Remove cotter pin and slotted nut from tie rod end connecting steering tube to steering plate. Separate tie rod end from steering plate bracket (Fig. 45).

2. Remove cotter pins and slotted nuts from tie rod ends connecting tie rods to wheel spindle brackets. Separate tie rod ends from both spindle brackets (Fig. 45).

STEERING MAINTENANCE




Figure 45

1. Steering tube
2. Wheel spindle tie rods

3. Remove snap ring and flatwasher and slide steering plate off mounting pin on bottom of axle (Fig. 46).




Figure 46

1. Snap ring, flatwasher, and spacer (if required)

4. Using pin punch and hammer, drive both bushings out of steering plate (Fig. 47). Clean inside of steering plate to remove dirt and foreign matter. Also clean mounting pin on bottom of rear axle.

5. Notice groove on inside of new bushing. When it is installed, open end of groove must be to the outside of the steering plate tube. Apply grease to the inside and outside of the new bushings. Use an arbor press to drive bushings into top and bottom of the steering plate tube. Bushings must be flush with end of tube (Fig. 47).

6. Slide steering plate onto mounting pin on bottom of rear axle. Secure plate in place with flatwasher and snap ring (Fig. 46).




Figure 47

1. Steering plate
2. Bushing
3. Steering plate tube

Note: If more than .030" clearance is evident between steering plate tube and axle, position spacer (part no. 5-1226) between snap and flatwasher.

7. Slide tie rod ends through appropriate holes in the steering plate, and secure parts together with slotted nuts. Tighten nuts until they are tight and holes in nuts and tie rod ends line up. Install cotter pins through nuts and tie rod ends.

8. Lubricate bushings through the grease fitting on the steering plate.

SERVICING REAR WHEEL SPINDLE BUSHINGS

The rear wheel spindles must fit snugly in the rear axle. Excessive movement of the spindle in the axle indicates the bushings are probably worn and must be replaced.

1. Remove cotter pin and slotted nut from tie rod end that connects steering tube to steering plate (Fig. 40). Separate tie rod end from plate.

2. Remove large locknut from end of rear axle pin (Fig. 41).

3. Remove capscrew, lockwasher and flatwasher holding outside of axle pin to chassis (Fig. 42).

4. Jack up frame — just ahead of the rear wheels — until pressure is taken off the axle pin. Support machine with jack stands to prevent it from falling. Pull axle pin out to release the rear axle and thrust washers from the frame.

5. Carefully roll the entire rear axle and wheel assembly out from under the machine. Set axle assembly onto the work bench.

STEERING MAINTENANCE

6. Remove cotter pin and slotted nut connecting tie rod end to spindle bracket (Fig. 48). Separate tie rod end from spindle bracket.

7. Remove snap ring and thrust washer holding spindle in axle tube (Fig. 48). Slide spindle and wheel assembly out of the axle tube to expose the bushings. Make sure to account for the thrust washer on bottom of axle tube.




Figure 48

1. Snap ring, flatwasher and spacer (if required)

8. Using pin punch and hammer, drive both bushings out of axle tube (Fig. 49). Clean inside of axle tube to remove dirt and foreign matter.

9. Notice groove on inside of new bushing. When it is installed, open end of groove must face to the outside of rear axle tube. Apply grease to inside and outside of the new bushings. Using an arbor press, drive bushings into the top and bottom of the axle tube. Bushings must be flush with axle tube (Fig. 49).

10. Wipe spindle shaft with a rag to remove dirt and grease. Slide thrust washer onto shaft and push shaft through axle tube. Hold wheel and spindle shaft assembly in place and install thrust washer and snap ring onto end of spindle shaft.

Note: If more than .030" clearance is evident between axle tube and spindle bracket, position spacer (part no. 5-1226) between snap ring and flatwasher.




Figure 49

1. Rear axle 2. Bushing

11. Connect tie rod end to spindle bracket with slotted nut and cotter pin.

12. Move rear axle into position at rear of machine. Mount axle between two sections of frame with axle pin and two thrust washers (Fig. 44). The thrust washers must be positioned at ends of the axle pivot tube and between both sections of the frame. Secure axle pin in place with capscrew and lockwasher (Fig. 42).

13. Install large locknut on end of axle pin (Fig. 41). Tighten locknut until all forward and backward movement of the axle is eliminated. However, the axle must still pivot freely.

14. Remove the jack stands and lower the machine to the shop floor.

15. Connect tie rod end at end of steering tube to steering plate with slotted nut and cotter pin.

16. Lubricate wheel spindle bushings through the grease fitting on axle tube (Fig. 21).

REPLACING AND PACKING REAR WHEEL BEARINGS

Pack the rear wheel bearings with no. 2 general purpose grease after every 500 hours of operation or once a year. If operating conditions are extremely dusty and dirty, it may be necessary to pack the bearings more often.

1. Jack up rear of machine until tire is off shop floor. Support machine with jack stands to prevent it from falling.

2. Remove dust cap from end of wheel spindle. Remove cotter pin, slotted nut, and washer, and slide wheel off spindle shaft. Pull seal out of wheel hub (Fig. 50).




Figure 50

1. Seal and bearings

3. Remove bearings from wheel hub (Fig. 51). Clean the bearings in solvent and make sure they are in good operating condition. Also clean the inside

STEERING MAINTENANCE

of the wheel hub. Check the bearing cups for wear, pitting or other noticeable damage. Replace defective parts.




Figure 51

1. Seal and bearings

4. If bearing cups were removed from the wheel hub, press them into the hub until they seat against the shoulder (Fig. 52).




Figure 52

1. Bearing cup

5. Pack both bearings with grease. Install bearing into cup on inboard side of wheel hub. Lubricate inside of new lip seal and press it into the wheel hub (Fig. 50).

Note: Lip seal must be pressed in so it is flush with the end of the hub, and the lip of the seal must be toward the bearing.

6. Pack inside of wheel hub with some grease, but not full. Install remaining bearing into the bearing cup.

7. Slide wheel assembly onto spindle shaft and secure it in place with flatwasher and slotted nut (Fig. 53). Do not tighten the nut and do not install the cotter pin.




Figure 53

1. Slotted nut

8. Adjust preload on the wheel bearings; refer to Adjusting Rear Wheel Bearings, steps 3-5, page 21.

AIR CLEANER MAINTENANCE

GENERAL MAINTENANCE PRACTICES

Inspect air cleaner and hose periodically to maintain maximum engine protection and to ensure maximum service life.

1. Assure hose between air cleaner and engine is clamped securely in place. Replace the hose if it is cracked or punctured.
2. Check air cleaner body for dents and other damage which could possibly cause an air leak. Replace a damaged air cleaner body.
3. Insure dust cap is sealing around bottom of air cleaner body.
4. Mounting screws and nuts holding air cleaner in place must be tight.

5. Inlet cap must be free of obstructions.

SERVICING DUST CUP AND BAFFLE

Inspect the dust cup and rubber baffle once a week or every 50 hours operation; however, daily or more frequent inspection is required when operating conditions are extremely dusty and dirty. Never allow dust to build up closer than one inch (25 mm) from the rubber baffle.

Note: If conditions are extremely dusty and dirty, begin by checking dust cup and baffle after each day's operation to establish approximately how long an interval passes before dust cup should be emptied. Base further maintenance requirements on this figure. These conditions may be particularly prevalent if the rear discharge cutting unit is attached.

AIR CLEANER MAINTENANCE




Figure 54

1. Thumb screw 2. Dust cup

1. Loosen thumb screw until dust cup and baffle can be removed (Fig. 54). Separate dust cup and baffle (Fig. 54).

2. Dump dust out of the dust cup. After cleaning cup and baffle, assemble and reinstall both parts.

SERVICING AIR CLEANER FILTER

Service the air cleaner filter every 250 hours or more frequently in extreme dusty or dirty conditions by washing or using compressed air. Replace the element after every six cleanings (1500 hours) or annually, whichever comes first.

1. Remove and service dust cup; refer to Servicing Dust Cup and Baffle, page 26.

2. Remove wing nut w/gasket and slide filter element out of air cleaner body (Fig. 55).




Figure 55

1. Dust cup 4. Filter element
2. Baffle 5. Air cleaner body
3. Wing nut with gasket

3. Clean the element by washing it in a solution of filter cleaner (Part No. 27-7220, available from Toro) and water, or blow dirt out of filter by using compressed air.

Note: Compressed air is recommended when element must be used immediately after servicing because a washed element must be dried before it is

used. By comparison, washing the element cleans better than blowing dirt out with compressed air. Remember though, filter must be washed when exhaust soot is lodged in the filter pores.

Washing Method

IMPORTANT: Do not remove plastic fin assembly because washing removes dust from beneath fins.

- Prepare a solution of filter cleaner and water and soak filter element about 15 minutes. Refer to directions on filter cleaner carton for complete information.
- After soaking filter for 15 minutes, rinse it with clear water. Maximum water pressure must not exceed 40 psi (276 kPa) to prevent damage to the filter element.
- Dry filter element using warm, flowing air (160°F (71°C) max). or allow element to air-dry. Do not use compressed air or a light bulb to dry the filter element because damage could result.

Compressed Air Method

IMPORTANT: Do not remove plastic fin assembly because back-blowing with compressed air removes dust from beneath fins.

- Blow compressed air from inside to the outside of dry filter element. Do not exceed 100 psi (689 kPa) to prevent damage to the element.
 - Keep air hose nozzle at least one inch (25 mm) from pleated paper, and move nozzle up and down while rotating the filter element. Inspect element when dust and dirt are removed; refer to Inspecting Filter Element, page 27.
- Wipe inside of air cleaner body with a damp cloth to remove excess dust. Slide filter into air cleaner body and secure it in place with wing nut and gasket.
 - Reinstall dust cup and baffle. Move thumb screw behind air cleaner body and tighten it securely.

INSPECTING FILTER ELEMENT

- Place bright light inside filter.
- Rotate filter slowly while checking for cleanliness, ruptures, holes and tears. Replace defective filter element.
- Check fin assembly, gasket and screen for damage. Replace filter if damage is evident.

ENGINE MAINTENANCE

CLEANING RADIATOR AND SCREEN

The screen and front of the radiator must be kept clean to prevent the engine from overheating. Normally, check the screen and front of radiator daily and, if necessary, clean any debris off these parts. However, it will be necessary to check and to clean the screen each quarter hour and radiator checked every hour in extremely dusty and dirty conditions.

Note: This situation may be particularly prevalent if the rear discharge cutting unit is being used. The front of the radiator can be cleaned thoroughly by spraying with a water hose or blowing with compressed air from the fan side of the radiator. Make sure to clean out any debris that settles to the bottom of the radiator.

CHANGING CRANKCASE OIL AND FILTER

Check oil level after each days operation or each time machine is used. Change oil after every 50 hours of operation; change oil filter after first 50 hours and every 100 hours operation thereafter. However, change oil more frequently when engine is operated in dusty or sandy conditions. If possible, run engine just before changing oil because warm oil flows better and carries more contaminants than cold oil.

1. Position machine on a level surface.
2. Disengage hood latch and open the hood. Set drain pan under the housing and in line with drain plug (Fig. 56).




Figure 56
1. Oil drain plug

3. Clean area around drain plug.

4. Remove oil drain plug and allow oil to flow into drain pan. Remove and replace oil filter (Fig. 57); refer to parts catalog for part number.




Figure 57
1. Engine oil filter

5. After oil is drained, reinstall drain plug and wipe up any oil that is spilled.
6. Fill crankcase with oil; refer to Check Crankcase Oil, page 10.

SERVICING FUEL SYSTEM

Note: Refer to Fill Fuel Tank With Diesel Fuel, page 11, for proper fuel recommendations.

Fuel Tank

Drain and clean fuel tank every 400 hours operation or yearly, whichever comes first. Also, drain and clean tank if fuel system becomes contaminated or if machine is to be stored for an extended period. Use clean fuel oil to flush out the tank.

Fuel Lines and Connections

Check lines and connections every 400 hours or yearly, whichever comes first. Inspect for deterioration, damage or loose connections.

Water Separator Assembly

Visually inspect fuel condition through glass of separator daily (Fig. 58) for signs of water or other contaminants. If water is evident in the lower half of the glass, loosen hex plug (Fig. 58) at the

ENGINE MAINTENANCE

bottom of the base and allow the water to drain. Tighten the plug after draining (Fig. 58).




Figure 58

1. Water separator assembly
2. Hex plug

If separator element is thoroughly contaminated, replace the element.

1. Thoroughly clean the outside of the assembly.
 2. Press against extended tab on retaining clamp with heel of hand and lift slotted tab with fingers of the same hand to release clamp from locking slot in base.
- Note:** A screwdriver may be used along with heel of hand if additional force is required to release clamp from locking slot in base.
3. Using a clean cloth, clean the three spotfaced sealing surfaces on the base. Be sure no dirt enters locating roll pin.
 4. Install new element to base, carefully inserting roll pin into single centered outlet passage.
 5. Engage lower element tab to slot in base. Press against clamp tab with heel of hand and push locking tab into top slot in base. Ensure clamp is securely in place.

6. Since separator element had to be replaced due to contamination, the rest of the fuel system will also have to be serviced; drain and flush fuel tank, replace fuel pump filter and fuel filter assembly. Refer to Fuel Tank, Fuel Pump Filter and Fuel Filter Assembly, pages 28-30).

7. Complete priming the fuel system; refer to Priming Fuel System, page 14.

Fuel Pump Filter

Remove and replace the filter after every 400 hours operation.

1. Fuel pump is located on inner frame at right rear of engine (Fig. 59).




Figure 59

1. Fuel pump assembly
2. Drive coupling assembly
3. Fuel pump cover

2. Thoroughly clean outside of assembly.
3. Place a drain pan under fuel pump and remove cover from fuel pump with 17 mm wrench (Fig. 59). Take care not to damage wire while removing cover.
4. Pull filter out of pump body (Fig. 60).




Figure 60

1. Filter
2. Magnet

ENGINE MAINTENANCE

5. If filter is to be cleaned, wash thoroughly in cleaning solvent and blow compressed air from inside toward outside of element. Hold air nozzle at least one inch (25 mm) from filter and move up and down while rotating filter. Do not exceed 100 psi (689 kPa) to avoid filter damage.

Note: Replace the filter if there is any visible dirt which cannot be washed out.

6. Clean magnet of any residue (Fig. 50), insert filter into body and install cover (Fig. 59).

7. Inspect the two rubber gaskets; replace them if damaged.

8. Prime the fuel system; refer to Priming Fuel System, page 14.

Fuel Filter Assembly

No service can be performed on assembly. Replace complete assembly every 400 hours of operation.

1. Loosen clamps and remove lines from assembly (Fig. 61).

2. Remove filter assembly from mounting clamp (Fig. 61).




Figure 61

1. Fuel filter assembly 3. Mounting clamp
2. Hose clamps

3. Reverse procedures to install new assembly. Ensure line clamps are tight to prevent air from entering system.

4. Prime the fuel system; refer to Priming Fuel System, page 14.

BLEEDING AIR FROM INJECTORS

Note: This procedure should be used only if fuel system has been purged of air through normal priming procedures and engine still will not start; refer to Priming Fuel System, page 14.

1. Loosen the pipe connection to the No. 1 nozzle and holder assembly (Fig. 62).

2. Move throttle control to full FAST position.

3. Turn key in key switch to START position and watch fuel flow around connector. Turn key to OFF position when solid flow is observed.

4. Tighten pipe connector securely.

5. Repeat steps 1-4 on No. 2 nozzle.

REPLACING ENGINE STOP SOLENOID

If engine stop solenoid fails, replace as follows:

1. Unlatch and raise engine hood.

2. Disconnect solenoid wires from wire harness.

3. Loosen nut securing solenoid to engine and unscrew solenoid. (Use 36 mm wrench).

4. Remove gasket and nut from old solenoid and install on new solenoid (Fig. 62). Thread nut fully onto solenoid.




Figure 62

5. Remove cap from solenoid, start to thread solenoid into engine (Fig. 62).

6. Push plunger on solenoid fully in and hold (Fig. 62).

7. Rotate emergency engine stop lever to STOP position (Fig. 62).

ENGINE MAINTENANCE

8. Continue to hold solenoid plunger in and thread solenoid into engine until inner end of plunger contacts control rack of injector pump (Fig. 62). Contact will be indicated when outside end of plunger is pushed away from solenoid body.

9. When contact is indicated, discontinue threading solenoid in. Turn solenoid slowly outward until plunger again contacts solenoid body and rotate one eighth turn further out.

10. Hold solenoid body to prevent it from turning and tighten nut against engine to secure adjustment (Fig. 62). DO NOT overtighten nut or solenoid may become distorted causing it to malfunction.

11. Connect solenoid wires, install cover and lower and latch hood.

SERVICING ENGINE BELTS

Check tension of all belts initially after the first days operation and every 100 hours thereafter.

Alternator Belt

1. Unlatch and open hood.
2. Check tension by depressing belt midway between alternator and crankshaft pulleys. Belt should deflect 7/16 in. (11 mm). If deflection is incorrect, proceed to step 3. If correct, continue operation.
3. Loosen bolt securing brace to engine and bolt securing alternator to brace (Fig. 63).




Figure 63

1. Alternator belt
2. Bolts

4. Insert pry bar between alternator and engine and pry out on alternator.

5. Hold alternator in position after proper belt tension setting is achieved and tighten alternator and brace bolts to secure adjustment.

Note: Metric wrenches will be required.

Cooling Fan Belt

1. Unlatch and open hood.
2. Belt should deflect 1/4 in. (6 mm) midway between the pulleys with 5 lbf (22 N) (Fig. 64). If deflector is incorrect, proceed to step 3. If correct, proceed to step 4.




Figure 64

1. Flange nuts
2. Idler pulley

3. Loosen two flange nuts securing idler pulley bracket (Fig. 64). Push idler against belt until proper deflection is achieved and tighten flange nuts (Fig. 64).

4. Close and latch hood.

To replace belt:

1. Loosen two flange nuts securing idler pulley bracket, slide pulley away from belt and remove belt from top and bottom pulleys (Fig. 64).

2. Install new belt and adjust for proper tension. Push idler pulley against belt until belt deflects 1/4 inch. (6 mm) with 5 lbf (22 N) midway between top and bottom pulleys (Fig. 64). Tighten flange nuts to secure idler pulley adjustment (Fig. 64).

3. Close and latch hood.

ENGINE MAINTENANCE

Note: Check fan belt tension after first days operation. Readjust tension, if necessary. Follow regular maintenance check procedures thereafter.

CHANGING COOLANT IN COOLING SYSTEM

The cooling system must be filled with a 50/50 solution of water and permanent ethylene glycol anti-freeze. After every two years, drain the coolant from the radiator and engine by opening the drain cock and block plug. After coolant is drained, flush the entire system and refill it with a 50/50 solution of water and anti-freeze. Capacity of cooling system is approximately 6 quarts (5.7 l). When filling the radiator, level of coolant must be above the core and 1 inch (25 mm) below bottom of filler neck. **DO NOT OVERFILL.** Always install radiator cap securely.

REMOVING FUEL TANK FROM CHASSIS

1. Remove knob from lift lever.
2. Remove capscrews, lockwashers and flatwashers securing seat support cover to frame.
3. Pivot seat forward and support it to prevent it from falling accidentally. Lift seat support cover off frame.
4. Unplug seat switch. Remove capscrews, lockwashers and flatwashers securing seat support to top of frame (Fig. 65). Set seat support aside.




Figure 65

1. Seat support
2. Capscrew, lockwasher and flatwasher

5. Remove capscrews, lockwashers and flatwashers securing fuel tank to top of frame (Fig. 66). However, do not lift fuel tank out of chassis at this time.

6. Place drain pan below fittings on bottom of fuel tank.




Figure 66

1. Capscrew, lockwasher and flatwasher



DANGER

Since diesel fuel is highly flammable, drain it outdoors and make sure engine is cool to prevent a potential fire hazard. Wipe up any fuel that may have spilled. Do not drain near any open flame or where fumes may be ignited by a spark. Do not smoke a cigar, cigarette, or a pipe when handling diesel fuel.

7. Loosen clamps holding both fuel lines on top and bottom fuel tank fittings. Pull lines off fittings and allow fuel to flow into large fuel can.

8. Lift fuel tank up and remove it from the chassis.

INSTALLING FUEL TANK

1. Set fuel tank into position and secure it in place with capscrews, lockwashers and flatwashers (Fig. 66).

2. Push fuel lines onto fuel tank fittings. Tighten clamps to secure the lines on the fittings.



WARNING

Make sure fuel lines do not make contact with any moving parts.

3. Install seat support with capscrews, lockwashers and flatwashers. Connect seat switch (Fig. 65).

ENGINE MAINTENANCE

4. Slide seat support cover onto the lift lever and position the cover on the frame. Secure seat support cover in place with capscrews, lockwashers and flatwashers.
5. Install knob onto lift lever.
6. Fill fuel tank.
7. Check for leaks.

SERVICING OPTIONAL SPARK ARRESTOR MUFFLER

After every 100 hours of operation, clean carbon from spark arrestor muffler.

1. Open hood.
2. Remove pipe plug from cleanout port at lower side of muffler.

3. Start engine, plug the normal muffler exit with block of wood or metal plate so exhaust flow will be forced out the cleanout port. Continue to block exit until carbon deposits cease coming out port.

4. Stop engine, replace pipe plug and lower and latch hood.



CAUTION

Be careful while working near the muffler because a hot muffler can cause burns. Do not stand in line with cleanout port.

ELECTRICAL MAINTENANCE

SERVICING BATTERY

IMPORTANT: Before welding on the machine, disconnect ground cable from the battery to prevent damage to the electrical system.

Note: Check battery condition weekly or after every 50 hours of operation. Keep terminals and entire battery case clean because a dirty battery will discharge slowly. To clean the battery, wash the entire case with solution of baking soda and water. Rinse with clear water. Coat the battery posts and cable connectors with Grafo 112X (Skin-over) grease, Toro Part No. 505-47 or petroleum jelly to prevent corrosion.

WIRING HARNESS SERVICE

Prevent corrosion of wiring terminals by applying Grafo 112X (Skin-over) grease, Toro Part No. 505-47, to the inside of all harness connectors whenever the harness is replaced.

Always disconnect battery cables, ground cable (—) first, to prevent possible wiring damage from short-outs whenever working with the electrical system.

FUSES

All fuses are accessible under the control console cover (Fig. 67).

ADJUSTING PTO LEVER SWITCH

1. Visually check PTO lever to be sure it deflects switch arm when lever is in the disengaged position (Fig. 67). Back surface of PTO lever must be within 1/2 to 1-1/2 in. from end of the slot (Fig. 67). If PTO lever does not deflect switch arm, proceed to step 2.

2. To adjust the PTO lever, remove the seat cover. Loosen jam nut from PTO engaging yoke (Fig. 68).

Loosen adjusting screw until PTO lever is within 1/2 to 1-1/2 in. from end of the slot, when lever is in the disengage position (Fig. 67). This will deflect the switch arm. Tighten jam nut against yoke to lock the adjustment in place (Fig. 68). Move PTO lever to engage position and rotate locknut at top of spring until the dimension of spring, between the top and bottom flatwasher, is 3-1/4 in. (8.3 cm) (Fig. 68). Repeat step 1.




Figure 67






Figure 68


ELECTRICAL MAINTENANCE TROUBLESHOOTING

ENGINE CONTINUES TO RUN, BUT SHOULD NOT WHEN IGNITION SWITCH IS TURNED OFF.




ELECTRICAL MAINTENANCE TROUBLESHOOTING


**PROBLEM: STARTER SOLENOID CLICKS, BUT STARTER WILL NOT CRANK.
(IF SOLENOID CLICKS INTERLOCK SYSTEM IS NOT AT FAULT)**



CIRCUIT INVOLVED WITH CRANKING ENGINE




**PROBLEM: NOTHING HAPPENS WHEN START ATTEMPT IS MADE.
REFER TO CIRCUIT DIAGRAM ABOVE.**





ELECTRICAL MAINTENANCE TROUBLESHOOTING

PROBLEM: ENGINE CRANKS, BUT SHOULD NOT, WHEN P.T.O. IS ENGAGED.





PROBLEM: ENGINE STARTS BUT KILLS WITH OPERATOR ON SEAT AND TRACTION PEDAL OR P.T.O. ENGAGED. (ENGINE NOT OVERHEATED)
(ENGINE CAN BE SHUT OFF WITH IGNITION SWITCH)




CIRCUIT INVOLVED WITH PROBLEM

ELECTRICAL MAINTENANCE TROUBLESHOOTING




**PROBLEM: ENGINE CRANKS, BUT SHOULD NOT, WHEN
TRACTION PEDAL IS DEPRESSED.**




ELECTRICAL MAINTENANCE TROUBLE SHOOTING

PROBLEM: ENGINE CONTINUES TO RUN, BUT SHOULD NOT, WHEN TRACTION PEDAL IS ENGAGED WITH NO OPERATOR ON SEAT. (NEUTRAL RETURN DEVICE WORKING PROPERLY) (ENGINE CAN BE SHUT OFF WITH IGNITION SWITCH)




PROBLEM: ENGINE CONTINUES TO RUN, BUT SHOULD NOT, WHEN P.T.O. IS ENGAGED WITH NO OPERATOR ON SEAT. (ENGINE CAN BE SHUT OFF WITH IGNITION SWITCH)




ELECTRICAL MAINTENANCE TROUBLE SHOOTING

**PROBLEM: THERE IS VOLTAGE AT "S" TERM. ON STARTER
BUT STARTER WILL NOT CRANK.**



WIRING SCHEMATIC



HYDRAULIC SYSTEM MAINTENANCE

ADJUSTING TRANSMISSION FOR NEUTRAL

The machine must not creep when traction pedal is released. If it does creep, an adjustment is required.

1. Park machine on a level surface and shut engine off. Depress only the left brake pedal and engage the parking brake.
2. Jack up right front side of machine until tire is off shop floor. Support machine with jack stands to prevent it from falling accidentally.
3. Visually inspect traction linkage for possible binding condition, correct if necessary and check machine operation. If condition still exists, repeat steps 1 and 2 and proceed to step 4.
4. Loosen two locknuts securing pump plate so plate is free to move (Fig. 69).
5. Start engine and rotate pump plate (Fig. 69) in either direction until wheel ceases rotation.




Figure 69

1. Pump plate 2. Locknut (2)

6. Stop engine and tighten locknuts to secure pump plate (Fig. 69).
7. Start engine and check adjustment. Repeat adjustment, if necessary.
8. Stop the engine and release left parking brake. Remove jack stands and lower machine to the shop floor. Test drive the machine to be sure it does not creep.

CHANGING HYDRAULIC OIL AND FILTER

The hydraulic system oil and filter must be changed after the first five hours and every 250 hours of operation or yearly, whichever comes first.

1. Lower cutting unit to shop floor, set parking brake, and turn engine OFF. Block the two rear wheels.

2. Jack up both sides of the front axle and support it with jackstands.

3. Clean the area around the hydraulic oil filter and remove the filter (Fig. 70).




Figure 70

1. Filter 2. By-pass valve pins

4. Remove the tube that connects the axle housing to the transmission and allow the oil to flow into a drain pan.
5. Install new hydraulic oil filter and connect the tube between axle housing and transmission. Fill axle (reservoir) to proper level (approx. 5 qt); refer to Check Hydraulic System Fluid, page 10.
6. Start engine and check for oil leaks. Allow engine to run for about five minutes. Then shut engine off.
7. After two minutes, check level of transmission fluid; refer to Check Hydraulic System Fluid, page 10.

TESTING CHARGE PUMP FLOW, IMPLEMENT RELIEF AND CHARGE RELIEF SETTING

An in-line hydraulic tester equipped with load valve, pressure gauge and flow gauge is required. Lines and fittings for tapping into the transmission to lift valve line will also be required.

1. Before testing, check and inspect the following:
 - A. Check level of oil in axle housing; refer to Check Hydraulic System Fluid, page 10.

HYDRAULIC SYSTEM MAINTENANCE

B. Inspect control rod from traction pedal to control lever on side of transmission. Assure control rod and neutral assembly parts are not bent, binding, adjusted incorrectly or defective in any way. Repair, replace and adjust parts as conditions dictate.

C. Check hydraulic oil filter to be sure it is tight. A loose filter allows air to enter the system, resulting in foaming of the oil and excessively high operating temperature.

2. To begin testing, engage parking brake and block front wheels to prevent movement of the machine.

3. Remove seat, seat support cover and seat support and remove line from top of pump housing to lift valve from lift valve fitting (Fig. 71).

4. Install hydraulic inlet hose of test gauge into line from transmission and test gauge return line into lift valve fitting (Fig. 71).




Figure 71

- | | |
|-------------------------|----------------------------|
| 1. Tester | 4. Return line from tester |
| 2. Load valve | 5. Implement relief valve |
| 3. Inlet line to tester | |

5. Start engine and let idle for about 10 minutes so oil reaches normal operating temperature.

6. Increase engine speed to full throttle (3100 - 3250 rpm) and watch flow and pressure gauges. Slowly close load valve until flow gauge reads one (1) GPM (0.063 L/s). Pressure reading at (1) GPM (0.063 L/s) should not be lower than 500 psi (3447.5 kPa). If one (1) GPM or a minimum of 500 psi (3447.5 kPa) cannot be achieved, remove implement relief valve and examine for contamination or broken parts (Fig. 71). If no contamination or damage is evident, add one shim to assembly and repeat test.

Note: If standard gauge is used relief pressure should be 700-800 psi and charge pressure should be 70-150 psi.

If pressure and flow readings improve, add shims as necessary until reading meets specification. Add shims one at a time and check pressure after each shim is installed. Do not exceed 800 psi (5516 kPa).

If pressure remains unchanged, remove the shim and remove and inspect charge pump assembly. Refer to Servicing Charge Pump, Rotor, Bearing And Lip Seal, page 41.

7. If charge pump assembly is not defective, remove the transmission from the axle, disassemble it and repair it per instructions in the Sundstrand Service Manual. Refer to page 2 for Sundstrand Manual numbers and how to obtain them.

SERVICING CHARGE PUMP, ROTOR, BEARING AND LIP SEAL

1. Lower cutting unit to the shop floor, be sure engine is shut off and remove key from ignition switch.

2. Remove the fuel tank; refer to Removing Fuel Tank From Chassis, page 32.

3. Remove drive coupling from between the engine pulley and transmission hub; refer to Removing Drive Coupling, page 42.

4. Loosen two set screws retaining hub on pump shaft (Fig. 72). Slide hub off shaft.

5. Since two set screws hold hub on transmission pump shaft, the shaft must be checked. Remove all burrs, sharp edges and residue to prevent damage to the lip seal.

6. Set drain pan below front of transmission. Remove two capscrews and flatwashers securing charge pump housing to center section (Fig. 72). Using a seal protector, slide charge pump housing and rotor assembly off pump shaft. O-ring will probably stay in groove on inside of charge pump housing.




Figure 72

- | | |
|---------------------|--------------|
| 1. Transmission hub | 2. Set screw |
|---------------------|--------------|

HYDRAULIC SYSTEM MAINTENANCE

Note: If seal protector is not used, wrap pump shaft with wax paper or cellophane to protect the lip seal. When sliding housing and rotor assembly off pump shaft, drive pin may drop out of the pump shaft. Do not lose the pin because it is the only part that drives the rotor. Without the pin, the rotor will not rotate; thus, no "charge pressure".

7. Examine rotor assembly and inside of charge pump housing for excessive wear patterns, scratches or score marks. If a part is damaged, replace it. The two rotor parts are replaceable as an assembly only.

IMPORTANT: If the rotor assembly or charge pump housing is damaged, replace all parts. Never replace only one part because charge pump housing and rotor assembly have a definite wear-in characteristic.

8. Examine bearing in charge pump housing for damage and free rotation. If bearing is damaged, replace bearing and oil seal.

- A. If bearing is defective, pull lip seal out of housing, using an oil puller.
- B. Press needle bearing out of charge pump housing.
- C. Lubricate new bearing and lip seal with transmission oil before installation. Press needle bearing and lip seal into charge pump housing.

9. Install new O-ring into groove in charge pump housing.

10. Apply transmission oil on rotor assembly, inside of charge pump housing and face of center section.

11. Slide rotor assembly into charge pump housing. Using a seal protector for the lip seal, slide charge pump housing onto the pump shaft. Insert drive pin through hole in shaft and slide rotor onto pin so positive engagement results. Align flat side of charge pump housing with flat side of center section.

Note: In place of a seal protector, use wax paper, cellophane or similar material to wrap pump shaft. This protects lip seal from possible damage when sliding it onto the shaft.

IMPORTANT: If rounded side of charge pump is lined up with flat side of center section, the charge pump will not generate charge pressure.

12. Secure charge pump housing to center section with two capscrews and flatwashers. Tighten capscrews to 12 to 15 ft-lb (16 to 20 N·m).

13. Slide hub onto transmission shaft and retain it in place by tightening two set screws.

14. Install drive coupling between the engine pulley and transmission hub; refer to Installing Drive Coupling, page 43.

15. Install fuel tank; refer to Installing Fuel Tank, page 32.

16. Start the engine and allow it to idle for one to two minutes. Then stop the engine and check level of transmission fluid; refer to Check Hydraulic System Fluid, page 10.

OFF SEASON STORAGE

Apply a liberal amount of No. 2 General Purpose Lithium Base Grease to the two by-pass valve pins located on top of the transmission to prevent corrosion build-up which could lock the pins into the by-pass position and cause internal transmission failure (Fig. 70).

DRIVE SYSTEM MAINTENANCE

REMOVING DRIVE COUPLING

The drive coupling must be removed whenever the transmission or the engine will be removed from the chassis.

1. Remove the fuel tank; refer to Removing Fuel Tank From Chassis, page 32.

2. Remove capscrews, locknuts and spacers securing drive coupling assembly between engine hub and transmission hub (Fig. 73). Slide drive coupling assembly from between the hubs.

3. Examine the rubber coupling. Replace the coupling if it is defective.

DRIVE SYSTEM MAINTENANCE




Figure 73

1. Drive coupling
2. Capscrews, locknuts and spacers

INSTALLING DRIVE COUPLING

1. Insert small end of spacers into holes in rubber couplings. Slide two cap screws through one rubber coupling and spacers.
2. Slide two cap screws through transmission hub and install locknuts onto the cap screws (Fig. 73). Tighten cap screws and locknuts. Secure other end of rubber coupling to engine hub in the same manner.
3. Install fuel tank; refer to Installing Fuel Tank, page 32.




Figure 74

1. Belt guide bracket
2. PTO fork
3. Clevis pin
4. Capscrews

REPLACING PTO DRIVE BELT

Note: If belt stretches, pivot block may be repositioned on bracket using additional set of mounting holes. Remove cap screws, lockwashers and flatwashers securing pivot block and shim to bracket. Relocate pivot block and shim to new holes and secure to bracket with fasteners (Fig. 75).




Figure 75

1. Pivot block
2. Capscrews
3. Additional mounting holes

1. Remove the fuel tank; refer to Removing Fuel Tank From Chassis, page 32.
2. Remove the drive coupling; refer to Removing Drive Coupling, page 42.
3. Remove cap screws securing belt guide bracket to mounting flange on engine plate (Fig. 74).
4. Remove cotter pin, clevis pin and cap screws securing PTO fork (Fig. 74).
5. Remove two cap screws, and lockwashers securing bearing hub and shim to bracket (Fig. 75).
6. Move the PTO assembly until the belt can be removed from the pulleys.
7. Install new belt around the PTO shaft pulley and engine pulley. Then secure pivot block with fasteners (Fig. 75).

IMPORTANT: Engage the PTO lever to tension belt and lay a straight edge along the bottom face of the engine and PTO pulleys to check alignment (Fig. 76). If pulleys are aligned within 1/16 inch (1.6 mm), proceed to step 8. If they are not aligned within 1/16 inch (1.6 mm) loosen locking collars on PTO shaft and shift shaft and pulley until proper alignment is achieved (Fig. 76). Re-lock collars.




Figure 76

1. Locking collar
2. Loosen
3. Tighten

DRIVE SYSTEM MAINTENANCE

8. Install PTO fork with bushings, capscrews, clevis pin and cotter pin (Fig. 74).
9. Install belt guide bracket with capscrews, flatwashers, lockwashers and nuts (Fig. 74).
10. Install drive coupling between the engine and transmission pulleys; refer to Installing Drive Coupling, page 42.
11. Install the fuel tank; refer to Installing Fuel Tank, page 32.

SERVICING PTO BRAKE ASSEMBLY

1. Remove capscrews, flatwashers, lockwashers and nuts securing belt guide bracket (Fig. 74).
2. Remove carriage bolts and flange nuts securing brake assembly (Fig. 77). Inspect brake pad for excessive wear or damage. Replace if pad is worn close to the metal.
3. Install brake assembly with carriage bolts and flange nuts. Push brake pad against PTO driven pulley before tightening nuts.




Figure 77

1. Carriage bolts and flange nuts

Note: Visually inspect alignment of brake pad with pulley. Brake pad should be parallel to pulley and centered over pulley grooves.

PRODUCT IDENTIFICATION

The traction unit has two identification numbers: a model number and a serial number that are stamped into a plate. The identification plate is located near the right end of the seat hinge (Fig. 78). In any correspondence concerning the traction unit, supply the model and serial numbers to ensure correct information and replacement parts are obtained.

To order replacement parts from an Authorized TORO Distributor supply the following information:

1. Model and serial numbers of the traction unit.
2. Part number, description and quantity of parts desired.

Note: Do not order by reference number if a parts catalog is being used; use the part number.




Figure 78

1. Model and serial number

PREPARATION FOR SEASONAL STORAGE

Traction Unit

1. Thoroughly clean the traction unit, cutting unit and the engine, paying special attention to these areas:
 - radiator screen
 - underneath the cutting unit
 - under the cutting unit belt covers
 - counterbalance springs
 - P.T.O. Shaft Assembly
 - all grease fittings and pivot points
2. Check the tire pressure. Inflate all traction unit tires to 10 to 15 psi (69 to 103 kPa).
3. Remove, sharpen and balance the cutting unit's blades. Reinstall the blades and torque the blade fasteners to 75-100 ft-lb (102-136 N·m).
4. Check all fasteners for looseness; tighten as necessary.
5. Grease or oil all grease fittings, pivot points, and transmission by-pass valve pins. Wipe off any excess lubricant.
6. Ensure that the P.T.O. lever remains in the disengaged position so that the P.T.O. belt does not take a "set."
7. Lightly sand and use touch up paint on painted areas that are scratched, chipped or rusted. Repair any dents in the metal body.
8. Service the battery and cables as follows:
 - a. Remove the battery terminals from the battery posts.

- b. Clean the battery, terminals and posts with a wire brush and baking soda solution.
- c. Coat the cable terminals and battery posts with Grafo 112X skin-over grease (Toro Part Number 505-47), or petroleum jelly to prevent corrosion.
- d. Slowly recharge the battery every 60 days for 24 hours to prevent lead sulfation of the battery.

Engine

1. Drain the engine oil from the oil pan and replace the drain plug.
2. Remove and discard the oil filter. Install a new filter.
3. Refill the engine with 3.3 quarts (3.1 L) of recommended motor oil. Refer to Changing Crankcase Oil, page 28.
4. Start the engine and run at idle speed for two minutes.
5. Drain diesel fuel from the fuel tank, fuel lines, pump, filter and separator. Flush fuel tank with clean fuel and connect all fuel lines.
6. Thoroughly clean and service the air cleaner assembly.
7. Seal the air cleaner inlet and the exhaust outlet with weatherproof masking tape.
8. Check the oil filler cap and fuel tank cap to ensure they are all securely in place.

SERVICE INTERVAL CHART

Date								
Hour Meter Reading								
Service Interval	↓	Daily	5	10	25	50	75	100
Check Interlock System	Daily							
Check Engine Oil Level	Daily							
Check Transmission Oil Level	Daily							
Check Radiator and Coolant (more often when conditions are dirty)	Daily							
Check Water Separator (Visual)	Daily							
Replace Hydraulic Oil Filter (Initial)	5							
Tighten Front Wheel Nuts (Initial)	2 & 10							
Check Brakes and Lubricate Cables	25							
Check Hoses, Lines, Fittings & Pump for Leaks	25							
Check Tire Pressure (12 psi - 83 kPa)	25							
Lubricate Grease Fittings & Oil	25							
Change Engine Oil Filter (Initial)	50							
Change Engine Oil (more often when conditions are dirty)	50							
Service Air Cleaner (Dust Cup & Baffle) (more often when conditions are dirty)	50							
Check Battery	50							
Check PTO Drive Belt	50							
Change Engine Filter (Regular)	100							
Check Engine Fan Belt and Alternator	100							
Tighten Front Wheel Nuts	250							
Service Air Cleaner (Filter)	250							
Change Transmission Oil and Filter	250							
Check Steering	250							
Check Rear Wheel Toe-In	250							
Replace Fuel Filter	400							
Replace Fuel Pump Filter	400							
Check Fuel Lines and Connections	400							
Drain and Clean Fuel Tank	400							
Pack Rear Wheel Bearings	500							
Grease Transmission By-Pass Pins	500							
Replace all Interlock Switches (2 years)	1000							
Drain and Flush Cooling System (2 years)	1000							

Engine Oil: Use 10W-30 SF and CC or CD

Hydraulic System Fluid – 5 quarts (4.73 L) of SAE 10W-30 engine oil

Hydraulic Oil Filter – Toro part no. 23-2300

SERVICE INTERVAL CHART

Date								
Hour Meter Reading								
Service Interval	↓	125	150	175	200	225	250	275
Check Interlock System	Daily							
Check Engine Oil Level	Daily							
Check Transmission Oil Level	Daily							
Check Radiator and Coolant (more often when conditions are dirty)	Daily							
Check Water Separator (Visual)	Daily							
Replace Hydraulic Oil Filter (Initial)	5							
Tighten Front Wheel Nuts (Initial)	2 & 10							
Check Brakes and Lubricate Cables	25							
Check Hoses, Lines, Fittings & Pump for Leaks	25							
Check Tire Pressure (12 psi - 83 kPa)	25							
Lubricate Grease Fittings & Oil	25							
Change Engine Oil Filter (Initial)	50							
Change Engine Oil (more often when conditions are dirty)	50							
Service Air Cleaner (Dust Cup & Baffle) (more often when conditions are dirty)	50							
Check Battery	50							
Check PTO Drive Belt	50							
Change Engine Filter (Regular)	100							
Check Engine Fan Belt and Alternator	100							
Tighten Front Wheel Nuts	250							
Service Air Cleaner (Filter)	250							
Change Transmission Oil and Filter	250							
Check Steering	250							
Check Rear Wheel Toe-In	250							
Replace Fuel Filter	400							
Replace Fuel Pump Filter	400							
Check Fuel Lines and Connections	400							
Drain and Clean Fuel Tank	400							
Pack Rear Wheel Bearings	500							
Grease Transmission By-Pass Pins	500							
Replace all Interlock Switches (2 years)	1000							
Drain and Flush Cooling System (2 years)	1000							

Engine Oil: Use 10W-30 SF and CC or CD

Hydraulic System Fluid — 5 quarts (4.73 L) of SAE 10W-30 engine oil

Hydraulic Oil Filter — Toro part no. 23-2300

The Toro Promise

A ONE YEAR LIMITED WARRANTY ON COMMERCIAL PRODUCTS OTHER THAN TRIMMERS AND BLOWERS.

The Toro Company promises to repair your TORO Product if defective in materials or workmanship. The following time periods from the date of purchase apply:

Commercial Products	1 Year
Trimmers and Blowers	90 Days

The costs of parts and labor are included, but the customer pays the transportation costs on walk rotary mowers, trimmers and blowers.

If you feel your TORO product is defective and wish to rely on The Toro Promise, the following procedure is recommended:

1. Contact your Authorized TORO Distributor or Commercial Dealer (the Yellow Pages of your telephone directory is a good reference source).
2. The TORO Distributor or Commercial Dealer will advise you on the arrangements that can be made to inspect and repair your product.
3. The TORO Distributor or Commercial Dealer will inspect the product and advise you whether the product is defective and, if so, make all repairs necessary to correct the defect without an extra charge to you.

If for any reason you are dissatisfied with the distributor's analysis of the defect or the service performed, you may contact us.

Write:

TORO Commercial Products Service Department
8111 Lyndale Avenue South
Minneapolis, Minnesota 55420

The above remedy of product defects through repair by an Authorized TORO Distributor or Commercial Dealer is the purchaser's sole remedy for any defect.

THERE IS NO OTHER EXPRESS WARRANTY. ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR USE ARE LIMITED TO THE DURATION OF THE EXPRESS WARRANTY.

Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

This Warranty applies only to parts or components which are defective and does not cover repairs necessary due to normal wear, misuse, accidents, or lack of proper maintenance. Regular, routine maintenance of the unit to keep it in proper condition is the responsibility of the owner.

All warranty repairs reimbursable under the Toro Promise must be performed by an Authorized TORO Commercial Dealer or Distributor using Toro approved replacement parts.

Repairs or attempted repairs by anyone other than an Authorized TORO Distributor or Commercial Dealer are not reimbursable under the Toro Promise. In addition, these unauthorized repair attempts may result in additional malfunctions, the correction of which is not covered by warranty.

THE TORO COMPANY IS NOT LIABLE FOR INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES IN CONNECTION WITH THE USE OF THE PRODUCT INCLUDING ANY COST OR EXPENSE OF PROVIDING SUBSTITUTE EQUIPMENT OR SERVICE DURING PERIODS OF MALFUNCTION OR NON-USE.

Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

COUNTRIES OTHER THAN THE UNITED STATES OR CANADA

Customers who have purchased TORO products exported from the United States or Canada should contact their TORO Distributor (Dealer) to obtain guarantee policies for your country, province or state. If for any reason

you are dissatisfied with your Distributor's service or have difficulty obtaining guarantee information, contact the TORO importer. If all other remedies fail, you may contact us at The Toro Company.