



**Count on it.**

**Operator's Manual**

**Workman® MDX-D Utility Vehicle**

Model No. 07359—Serial No. 314000001 and Up

Model No. 07359TC—Serial No. 314000001 and Up



This machine is a utility vehicle intended to be used by professional, hired operators in commercial applications. It is primarily designed for the transport of implements used in such applications. This vehicle allows for the safe transport of an operator and one passenger in the identified seats. The bed of this vehicle is not suitable for any riders.

This product complies with all relevant European directives; for details, please see the separate product specific Declaration of Conformity (DOC) sheet.




Figure 1

1. Model and serial number location

Model No. _____
Serial No. _____

This manual identifies potential hazards and has safety messages identified by the safety alert symbol (Figure 2), which signals a hazard that may cause serious injury or death if you do not follow the recommended precautions.



Figure 2

1. Safety alert symbol

This manual uses 2 words to highlight information. **Important** calls attention to special mechanical information and **Note** emphasizes general information worthy of special attention.

**⚠ WARNING**

**CALIFORNIA  
Proposition 65 Warning**

**This product contains a chemical or chemicals known to the State of California to cause cancer, birth defects, or reproductive harm.**

**Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.**

**Important:** This engine is not equipped with a spark arrester muffler. It is a violation of California Public Resource Code Section 4442 to use or operate the engine on any forest-covered, brush-covered, or grass-covered land. Other states or federal areas may have similar laws.

The enclosed *Engine Owner's Manual* is supplied for information regarding the US Environmental Protection Agency (EPA) and the California Emission Control Regulation of emission systems, maintenance, and warranty. Replacements may be ordered through the engine manufacturer.

## Introduction

Read this information carefully to learn how to operate and maintain your product properly and to avoid injury and product damage. You are responsible for operating the product properly and safely.

You may contact Toro directly at [www.Toro.com](http://www.Toro.com) for product and accessory information, help finding a dealer, or to register your product.

Whenever you need service, genuine Toro parts, or additional information, contact an Authorized Service Dealer or Toro Customer Service and have the model and serial numbers of your product ready. Figure 1 identifies the location of the model and serial numbers on the product. Write the numbers in the space provided.

# Contents

Introduction .....	2	Servicing the Battery .....	27
Safety .....	4	Drive System Maintenance .....	29
Safe Operating Practices .....	4	Checking and Adjusting the Neutral Position .....	29
Supervisor's Responsibilities .....	4	Inspecting the Tires .....	29
Before Operating .....	4	Adjusting Front Wheel Toe-in and Camber .....	30
Operation .....	5	Inspecting the Primary Drive Clutch .....	31
Maintenance .....	6	Maintaining the Primary Drive Clutch .....	31
Sound Power .....	6	Changing the Transaxle Fluid .....	32
Sound Pressure .....	6	Cooling System Maintenance .....	32
Hand-Arm Vibration .....	6	Cleaning the Engine Cooling Areas .....	32
Whole Body Vibration .....	6	Filling the Radiator .....	32
Safety and Instructional Decals .....	7	Brake Maintenance .....	33
Setup .....	9	Inspecting the Brakes .....	33
1 Installing the Steering Wheel .....	10	Checking the Brake Fluid Level .....	33
2 Reading the Manual and Viewing the Safety		Adjusting the Parking Brake .....	34
Training Material .....	10	Belt Maintenance .....	34
Product Overview .....	11	Servicing the Drive Belt .....	34
Controls .....	11	Checking the Belt-pull Bumper .....	35
Specifications .....	13	Cleaning .....	35
Attachments/Accessories .....	13	Washing the Vehicle .....	35
Operation .....	14	Storage .....	36
Think Safety First .....	14	Schematics .....	37
Pre-starting Checks .....	14		
Checking the Engine Oil .....	14		
Checking the Brake Fluid Level .....	14		
Checking the Tire Pressure .....	14		
Adding Fuel .....	15		
Checking the Transmission Oil Level .....	16		
Starting the Engine .....	16		
Stopping the Vehicle .....	16		
Parking the Vehicle .....	16		
Operating the Cargo Box .....	16		
Breaking in a New Vehicle .....	17		
Loading the Cargo Box .....	18		
Transporting the Vehicle .....	18		
Towing the Vehicle .....	18		
Towing a Trailer .....	18		
Maintenance .....	20		
Recommended Maintenance Schedule(s) .....	20		
Daily Maintenance Checklist .....	21		
Pre-maintenance Procedures .....	22		
Maintaining the Vehicle under Special Operating			
Conditions .....	22		
Jacking up the Machine .....	22		
Accessing the Hood .....	22		
Lubrication .....	23		
Adding Grease .....	23		
Engine Maintenance .....	23		
Servicing the Air Cleaner .....	23		
Servicing the Engine Oil .....	24		
Fuel System Maintenance .....	25		
Inspecting Fuel Lines and Connections .....	25		
Replacing the Fuel Filter .....	25		
Electrical System Maintenance .....	25		
Replacing the Fuses .....	25		
Replacing the Headlights .....	25		

# Safety

Improper use or maintenance by the operator or owner can result in injury. To reduce the potential for injury, comply with these safety instructions and always pay attention to the safety alert symbol, which means **Caution, Warning, or Danger**—“personal safety instruction.” Failure to comply with the instruction may result in personal injury or death.

The machine meets the requirements of SAE J2258.

Supervisors, operators, and service persons should be familiar with the following standards and publications (the material may be obtained from the address shown):

- Flammable and Combustible Liquids Code: ANSI/NFPA 30
- National Fire Protection Association:  
ANSI/NFPA #505; Powered Industrial Trucks, National Fire Prevention Association, Barrymarch Park, Quincy, Massachusetts 02269 U.S.A.
- ANSI/ASME B56.8 Personal Burden Carriers  
American National Standards Institute, Inc., 1430 Broadway, New York, New York 10018 U.S.A.
- SAE J2258 Light Utility Vehicle  
SAE International, 400 Commonwealth Drive, Warrendale, PA 15096-0001 U.S.A.
- ANSI/UL 558; Internal Combustion Engine Powered Industrial Trucks  
American National Standards Institute, Inc., 1430 Broadway, New York, New York 10018 U.S.A.  
or  
Underwriters Laboratories, 333 Pfingsten Road, Northbrook, Illinois 60062 U.S.A.

## Safe Operating Practices

### **⚠ WARNING**

**The vehicle is an off-highway vehicle only and is not designed, equipped, or manufactured for use on public roads. Using it on a public road may result in an accident, which could seriously injure or kill you or others.**

**Do not use this vehicle on public roads.**

The Workman was designed and tested to offer safe service when operated and maintained properly. Although hazard control and accident prevention partially are dependent upon the design and configuration of the machine, these factors are also dependent upon the awareness, concern, and proper training of the personnel involved in the operation, maintenance and storage of the machine. Improper use or maintenance of the machine can result in injury or death.

This is a specialized utility vehicle designed for off-road use only. Its ride and handling will have a different feel than what drivers experience with passenger cars or trucks. So take time to become familiar with your Workman.

Not all of the attachments that adapt to the Workman are covered in this manual. See the specific *Operator's Manual* provided with each attachment for additional safety instructions. **Read these manuals.**

**To reduce the potential for injury or death, comply with the following safety instructions:**

## Supervisor's Responsibilities

- Make sure that operators are thoroughly trained and familiar with the *Operator's Manual*, and all labels on the vehicle.
- Establish your own special procedures and work rules for unusual operating conditions (e.g. slopes too steep for vehicle operation).

## Before Operating

- Operate the machine only after reading and understanding the contents of this manual. A replacement manual is available by sending complete model and serial number to: The Toro Company, 8111 Lyndale Avenue South, Minneapolis, Minnesota 55420.
- **Never** allow children to operate the vehicle. **Never** allow adults to operate it without proper instructions. Only trained and authorized persons should operate this vehicle. Make sure that all operators are physically and mentally capable of operating the vehicle.
- This vehicle is designed to carry **only you**, the operator, and **one passenger** in the seat provided by the manufacturer. **Never** carry any other passengers on the vehicle.
- **Never** operate the vehicle when under the influence of drugs or alcohol.
- Become familiar with the controls and know how to stop the engine quickly.
- Keep all shields, safety devices, and decals in place. If a shield, safety device, or decal is malfunctioning, illegible, or damaged, repair or replace it before operating the machine.
- Always wear substantial shoes. Do not operate the machine while wearing sandals, tennis shoes, or sneakers. Do not wear loose-fitting clothing or jewelry, which could get caught in moving parts and cause personal injury.
- Wearing safety glasses, safety shoes, long pants, and a helmet is advisable and required by some local safety and insurance regulations.
- Keep everyone, especially children and pets, away from the areas of operation.

- Before operating the vehicle, always check all parts of the vehicle and any attachments. If something is wrong, **stop using vehicle**. Make sure the problem is corrected before vehicle or attachment is operated again.
  - Since diesel fuel is highly flammable, handle it carefully.
    - Use an approved fuel container.
    - Do not remove the cap from the fuel tank when the engine is hot or running.
    - Do not smoke while handling fuel.
    - Fill the fuel tank outdoors and to about one inch below the top of tank (bottom of filler neck). **Do not overfill**.
    - Wipe up any spilled fuel.
  - Operate the vehicle only outdoors or in a well ventilated area.
  - Use only an approved nonmetal, portable fuel container. Static electric discharge can ignite fuel vapors in a ungrounded fuel container. Remove the fuel container from the bed of the vehicle and place it on the ground away from the vehicle before filling. Keep the nozzle in contact with the container while filling. Remove equipment from vehicle bed before filling.
  - Check the safety-interlock system daily for proper operation. If a switch should malfunction, replace the switch before operating machine.
- Use extreme caution, reduce speed, and maintain a safe distance around sand traps, ditches, creeks, ramps, any unfamiliar areas, or other hazards.
  - Watch for holes or other hidden hazards.
  - Use caution when operating the vehicle on a steep slope. Normally, travel straight up and down slopes. Reduce speed when making sharp turns or when turning on hillsides. Avoid turning on hillsides whenever possible.
  - Use extra caution when operating the vehicle on wet surfaces, at higher speeds, or with a full load. Stopping time will increase with a full load. Shift into a lower gear before starting up or down a hill.
  - When loading the bed, distribute the load evenly. Use extra caution if the load exceeds the dimensions of the vehicle/bed. Operate the vehicle with extra caution when handling off-center loads that cannot be centered. Keep loads balanced and secure to prevent them from shifting.
  - Avoid sudden stops and starts. Do not go from reverse to forward or forward to reverse without first coming to a complete stop.
  - Do not attempt sharp turns or abrupt maneuvers or other unsafe driving actions that may cause a loss of vehicle control.
  - Do not pass another vehicle traveling in the same direction at intersections, blind spots, or at other dangerous locations.
  - When dumping, do not let anyone stand behind vehicle and do not dump the load on any one's feet. Release the tailgate latch from the side of box, not from behind.
  - Keep all bystanders away. Before backing up, look to the rear and ensure that no one is behind the vehicle. Back up slowly.
  - Watch out for traffic when near or crossing roads. Always yield the right of way to pedestrians and other vehicles. This vehicle is not designed for use on streets or highways. Always signal your turns or stop early enough so other persons know what you plan to do. Obey all traffic rules and regulations.
  - Never operate the vehicle in or near an area where there is dust or fumes in the air which are explosive. The electrical and exhaust systems of the vehicle can produce sparks capable of igniting explosive materials.
  - Always watch out for and avoid low overhangs such as tree limbs, door jambs, over head walkways, etc. Make sure there is enough room over head to easily clear the vehicle and your head.
  - If ever unsure about safe operation, **stop work** and ask your supervisor.

## Operation

- The operator should keep both hands on the steering wheel, whenever possible, and the passenger should use the hand holds provided. Keep arms and legs within the vehicle body at all times. Never carry passengers in the box or on attachments. Remember your passenger may not be expecting you to brake or turn, and may not be ready.
- Never overload your vehicle. The name plate (located under the middle of the dash) shows the load limits for the vehicle. Never overfill attachments or exceed the vehicle maximum gross vehicle weight (GVW); refer to Loading the Cargo Box (page 18).
- When starting the engine:
  - Sit on operator's seat and ensure that the parking brake is engaged.
  - Keep your foot on the brake.
  - Turn ignition switch to the On position. When the glow plug indicator goes off, the engine is ready to start.
  - Turn the ignition key to the Start position.
- Using the machine demands attention. Failure to operate vehicle safely may result in an accident, tip over of the vehicle, and serious injury or death. Drive carefully. To prevent tipping or loss of control, take the following precautions:
  - Do not touch engine, transaxle, radiator, muffler or muffler manifold while engine is running or soon after

it has stopped because these areas may be hot enough to cause burns.

- If the machine ever vibrates abnormally, stop immediately, turn engine off, wait for all motion to stop and inspect for damage. Repair all damage before resuming operation.
- Before getting off the seat:
  - Stop movement of the machine.
  - Shut engine off and wait for all movement to stop.
  - Set parking brake.
  - Remove key from ignition.
- Lightning can cause severe injury or death. If lightning is seen or thunder is heard in the area, do not operate the machine; seek shelter.

## Maintenance

- Before servicing or making adjustments to the machine, stop the engine, set the parking brake, and remove the key from ignition to prevent accidental starting of the engine.
- Never work under a raised bed without placing the bed on the fully extended prop rod.
- To make sure that the entire machine is in good condition, keep all nuts, bolts, and screws properly tightened.
- To reduce the potential fire hazard, keep the engine area free of excessive grease, grass, leaves, and accumulation of dirt.
- If the engine must be running to perform a maintenance adjustment, keep hands, feet, clothing, and any parts of the body away from the engine and any moving parts. Keep everyone away.
- Do not overspeed the engine by changing the governor settings. The maximum engine speed is 3470 RPM. To ensure safety and accuracy, have an Authorized Toro Distributor check the maximum engine speed with a tachometer.
- If major repairs are ever needed or assistance is required, contact an Authorized Toro Distributor.
- To be sure of optimum performance and safety, always purchase genuine Toro replacement parts and accessories. Replacement parts and accessories made by other manufacturers could be dangerous. Altering this vehicle in any manner may affect the vehicle's operation, performance, durability or its use may result in injury or death. Such use could void the product warranty of The Toro® Company.
- This vehicle should not be modified without The Toro® Company's authorization. Direct any inquiries to The Toro® Company, Commercial Division, Vehicle Engineering Dept., 8111 Lyndale Ave. So., Bloomington, Minnesota 55420–1196. USA

## Sound Power

This unit has a guaranteed sound power level of 98 dBA, which includes an Uncertainty Value (K) of 1 dBA.

Sound power level was determined according to the procedures outlined in EN ISO 11094.

## Sound Pressure

This unit has a sound pressure level at the operator's ear of 85 dBA, which includes an Uncertainty Value (K) of 1 dBA.

Sound pressure level was determined according to the procedures outlined in EN ISO 11201.

## Hand-Arm Vibration

Measured vibration level for right hand = 1.25 m/s<sup>2</sup>

Measured vibration level for left hand = 1.36 m/s<sup>2</sup>

Uncertainty Value (K) = 0.68 m/s<sup>2</sup>

Measured values were determined according to the procedures outlined in EN 1032.

## Whole Body Vibration

Measured vibration level = 0.35 m/s<sup>2</sup>

Uncertainty Value (K) = 0.17 m/s<sup>2</sup>

Measured values were determined according to the procedures outlined in EN 1032.

# Safety and Instructional Decals



Safety decals and instructions are easily visible to the operator and are located near any area of potential danger. Replace any decal that is damaged or lost.




104-6581

1. Warning—read the *Operator's Manual*.
2. Fire hazard—before fueling, stop the engine.
3. Warning—do not operate this machine unless you are trained.
4. Tipping hazard—use caution and drive slowly while on slopes; drive slowly when turning, keep the vehicle speed under 16 MPH (26 km/h) when carrying a full or heavy load and when driving on rough terrain.
5. Falling and arm/leg injury hazards—do not carry passengers in the cargo bed and keep arms and legs inside of the vehicle at all times.



119-9727

- |  |  |
|--|--|
| <ol style="list-style-type: none"> <li>1. Horn</li> <li>2. Hour meter</li> <li>3. Headlights</li> <li>4. Engine—stop</li> <li>5. Engine—on</li> <li>6. Engine—start</li> </ol> | <ol style="list-style-type: none"> <li>7. Power point</li> <li>8. Warning—read the <i>Operator's Manual</i>.</li> <li>9. Collision hazard—do not operate the vehicle on public streets, roads, or highways.</li> <li>10. Falling hazard—do not carry passengers in the cargo bed.</li> <li>11. Falling hazard—do not allow children to operate the vehicle.</li> </ol> |
|--|--|




120-0627

1. Cutting/dismemberment hazard, fan—stay away from moving parts, keep all guards and shields in place.



115-7739

1. Falling, crushing hazard, bystanders—no riders on machine.




99-7345

1. Warning—read the *Operator's Manual*.
2. Hot surface/burn hazard—stay a safe distance from the hot surface.
3. Entanglement hazard, belt—stay away from moving parts; keep all guards in place.
4. Crushing hazard, cargo box—use the prop rod to support the cargo bed




106-6755

1. Engine coolant under pressure.
2. Explosion hazard—read the *Operator's Manual*.
3. Warning—do not touch the hot surface.
4. Warning—read the *Operator's Manual*.




99-7952

1. Choke
2. Reverse
3. Neutral
4. Forward




120-4837

1. Read the *Operator's Manual* for information on fuses.
2. Alarm/power point, 10A
3. Engine, 10A
4. Headlights, 10A
5. Machine fuse, 15A
6. Lift, 15A
7. Rear lift, 15A
8. Horn, 30A



99-7350

1. Maximum tongue weight is 50 lb (23 kg); maximum trailer weight is 400 lb (181 kg).



115-2412

1. Warning—read the *Operator's Manual*; no storage.

# Setup

## Loose Parts

Use the chart below to verify that all parts have been shipped.

Procedure	Description	Qty.	Use
<b>1</b>	Steering wheel	1	Install the steering wheel (Model 07359TC only).
<b>2</b>	Operator's Manual Engine Operator's Manual Parts Catalog Safety Training material Registration Card Predelivery Inspection Form Certificate of Quality Key	1 1 1 1 1 1 1 2	Read the Operator's Manual and view the training material before operating the machine.

**Note:** Determine the left and right sides of the machine from the normal operating position.

# 1

## Installing the Steering Wheel


### Parts needed for this procedure:

1	Steering wheel
---	----------------

### Procedure

**Note:** This procedure is only needed for Model 07359TC.

1. Release the tabs on the back of the steering wheel that hold the center cover in place. Remove the cover.
2. Remove the nut and washer from the steering shaft.
3. Slide the steering wheel and washer onto the shaft. Position the steering wheel on the shaft so that the cross beam is horizontal when the tires are pointed straight ahead and the thicker spoke of the steering wheel is downward.
4. Secure the steering wheel to the shaft with the nut (Figure 3). Torque the nut to 18-22 ft-lb (24-29 N-m).



**Figure 3**

- |                       |                  |
|-----------------------|------------------|
| 1. Steering shaft     | 5. Washer        |
| 2. Dust cover         | 6. Nut           |
| 3. Steering wheel     | 7. Cover         |
| 4. Tab slots in wheel | 8. Tabs in cover |

5. Snap the center cover in place.

# 2

## Reading the Manual and Viewing the Safety Training Material


### Parts needed for this procedure:

1	<i>Operator's Manual</i>
1	<i>Engine Operator's Manual</i>
1	<i>Parts Catalog</i>
1	Safety Training material
1	Registration Card
1	<i>Predelivery Inspection Form</i>
1	Certificate of Quality
2	Key

### Procedure

- Read the *Operator's Manual* and *Engine Operator's Manual*.
- View the safety training material.
- Fill out the registration card.
- Complete the *Predelivery Inspection Form*.
- Review the *Certificate of Quality*.

# Product Overview




G014967

Figure 4

- |                  |                            |                        |                  |
|------------------|----------------------------|------------------------|------------------|
| 1. Hood strap    | 3. Cargo box               | 5. Fuel cap            | 7. Towing tongue |
| 2. Parking brake | 4. Cargo box release lever | 6. Gear shift selector |                  |

## Controls



G008361

Figure 5

- |                                  |                                  |
|----------------------------------|----------------------------------|
| 1. Brake pedal                   | 5. Passenger handhold            |
| 2. Parking brake, center console | 6. <i>Operator's Manual</i> tube |
| 3. Steering wheel                | 7. Accelerator pedal             |
| 4. Cup holder                    |                                  |

## Accelerator Pedal

The accelerator pedal (Figure 5) gives the operator the ability to vary ground speed of the vehicle. Pressing the pedal increases ground speed. Releasing the pedal will slow the vehicle. Maximum forward speed is 26 km/h (16 mPH).

## Brake Pedal

The brake pedal is used to stop or slow the vehicle (Figure 5).

### **⚠ CAUTION**

**Brakes can become worn or can be incorrectly adjusted resulting in personal injury.**

**If brake pedal travels to within 25 mm (1 inch) of the vehicle floor board, the brakes must be adjusted or repaired.**

## Parking Brake

The parking brake is between the seats (Figure 5). Whenever the engine is shut off, you must engage the parking brake to prevent accidental movement of the vehicle. To engage the parking brake, pull back on the lever. To disengage, push the lever forward. If the vehicle is parked on a steep grade, make sure that the parking brake is applied.

## Gear-shift Selector

The gear shift selector has three positions: forward, reverse, and neutral. The engine will start and run in any of the three positions.

**Important:** Always stop the vehicle before changing gears.

## Ignition Switch

The ignition switch (Figure 6), used to start and stop the engine, has 3 positions: Off, On, and Start. Rotate the key clockwise to the Start position to activate the glow plugs. When the glow plug indicator light turns off, rotate the key counterclockwise to the On position. To shut off the engine, rotate the key counterclockwise to the Off position. Remove the key from the ignition when leaving the vehicle.




Figure 6

- |                                 |                             |
|---------------------------------|-----------------------------|
| 1. Horn button (TC Models Only) | 6. Engine-temperature light |
| 2. Hour meter                   | 7. Glow-plug Indicator      |
| 3. Light switch                 | 8. Power point              |
| 4. Battery light                | 9. Ignition switch          |
| 5. Oil light                    |                             |

## Hour Meter

The hour meter (Figure 6) indicates the total number of hours the engine has run. The hour meter starts to function whenever you turn the key switch to the On position or if the engine is running.

## Battery Light

The battery light (Figure 6) turns on for several seconds when you first start the engine. If the light remains on while the engine is running, the alternator, battery, or electrical system is damaged.

## Oil Light

The oil light warns the operator if the engine oil level drops below a safe level (Figure 6). If the light comes on and remains lit, check the oil level and add oil if necessary; refer to Servicing the Engine Oil (page 24).

**Note:** The oil light may flicker. This is normal and no action needs to be taken.

## Engine-temperature Light

If the engine temperature light is on, the engine is overheating (Figure 6). Stop the engine and allow the machine to cool down. Check the coolant level and the belts to the fan and water pump. Fill the coolant as required and replace any worn or slipping belts. If the problem persists, contact your Authorized Toro Dealer for diagnostics and repair.

## Glow-plug Indicator

The glow-plug indicator (Figure 6) will glow red when you activate the glow plugs.

## Light Switch

Toggle the switch to activate the headlights. Push to turn the lights on (Figure 6).

## Power Point

Use the power point to power 12 volt optional electrical accessories (Figure 6).

## Horn Button (TC Model only)

Press the horn button to sound the horn (Figure 6).

## Fuel Gauge

The fuel gauge (Figure 7) is on the fuel tank next to the filler cap on the operator's side of the vehicle. The gauge displays the amount of fuel in the tank.





Figure 7

- |           |                  |
|-----------|------------------|
| 1. Empty  | 4. Fuel gauge    |
| 2. Full   | 5. Fuel-tank cap |
| 3. Needle |                  |

## Passenger Handholds

The passenger handholds are located on the right side of the dash panel and at the outside of each seat (Figure 8).



**Figure 8**

1. Hip restraint

2. Passenger hand hold

## Specifications

**Note:** Specifications and design are subject to change without notice.

Base weight	Dry 590 kg (1300 lb)
Rated capacity (on level ground)	749 kg (1650 lb) total, including 90.7 kg (200 lb) operator and 90.7 kg (200 lb) passenger, load, trailer tongue weight, gross trailer weight, accessories, and attachments
Maximum gross vehicle weight (GVW) (on level ground)	1341 kg (2950 lb) total, including all of the weights listed above
Maximum cargo capacity (on level ground)	567 kg (1250 lb) total, including trailer tongue weight and gross trailer weight
Tow capacity:	
Standard hitch	Tongue weight 23 kg (50 lb) Maximum trailer weight 182 kg (400 lb)
Heavy-duty hitch	Tongue weight 45 kg (100 lb) Maximum trailer weight 363 kg (800 lb)
Overall width	150 cm (59 inches)
Overall length	299 cm (117.75 inches)
Ground clearance	25.4 cm (10 inches) at the front with no load or operator, 18 cm (7 inches) at the rear with no load or operator
Wheel base	205.7 cm (81 inches)
Wheel tread (center line to center line)	124.5 cm (49 inches) in the front, 120 cm (47-1/4 inches) in the rear
Cargo box length	116.8 cm (46 inches) inside, 132.7 cm (52-1/4 inches) outside
Cargo box width	124.5 cm (49 inches) inside, 150 cm (59 inches) at outside of the molded fenders
Cargo box height	25.4 cm (10 inches) inside
Maximum speed	26 km/h (16 mph)
Engine speed (non-adjustable)	Low idle –1250 ±50 rpm, High idle –3470 ±50 rpm

## Attachments/Accessories

A selection of Toro approved attachments and accessories is available for use with the machine to enhance and expand its capabilities. Contact your Authorized Service Dealer or Distributor or go to [www.Toro.com](http://www.Toro.com) for a list of all approved attachments and accessories.

# Operation

**Note:** Determine the left and right sides of the machine from the normal operating position.

## Think Safety First

Please carefully read all of the safety instructions and decals in the safety section. Knowing this information could help you or bystanders avoid injury.

## Pre-starting Checks

Check the following items each time you begin using the vehicle for the day:

- Check the tire pressure.

**Note:** These tires are different than car tires; they require less pressure to minimize turf compaction and damage.

- Check all fluid levels and add the appropriate amount of specified fluids, if any are found to be low.
- Check the brake pedal operation.
- Ensure that the lights are working.
- Turn the steering wheel to the left and right to check steering response.
- Check for oil leaks, loose parts, and any other noticeable malfunctions. Make sure that the engine is off and all moving parts have stopped before checking for oil leaks, loose parts, and other malfunctions.

If any of the above items are not correct, notify your mechanic or check with your supervisor before taking the vehicle out for the day. Your supervisor may want you to check other items on a daily basis, so ask what your responsibilities are.


## Checking the Engine Oil

**Service Interval:** Before each use or daily

**Note:** The engine is shipped with oil in the crankcase; however, check the oil before and after you start the engine.

Check the engine oil level before starting the engine each day.

1. Position the machine on a level surface.
2. Clean around the oil dipstick (Figure 9) so that dirt cannot fall into the hole and damage the engine.



G016858

**Figure 9**

1. Fill cap
2. Oil dipstick

3. Remove the oil dipstick and wipe the end clean.
4. Slide the oil dipstick into the filler tube fully seating it.
5. Pull the dipstick out and look at the end.

**Note:** If the oil level is low, remove the filler cap and add oil of the proper type to raise the level to, but not over, the Full mark on the dipstick. Refer to Servicing the Engine Oil (page 24), for the proper oil type and viscosity. Add the oil slowly and check the level often during this process. **Do not overfill.**

6. Install the oil dipstick firmly in place.

## Checking the Brake Fluid Level

Check the brake fluid level before you start the engine; refer to Checking the Brake Fluid Level (page 33).

## Checking the Tire Pressure

**Service Interval:** Before each use or daily

Check the tire pressure every 8 hours or daily to ensure proper levels.

The air pressure range in the front and rear tires is 55–103 kPa (8–22 psi).

The air pressure needed is determined by the payload carried. The lower the air pressure, the less the compaction, smoother the ride, and tire marks are minimized. Lower pressure should not be used for heavy payloads at high speeds.

Higher pressures should be used for heavier payloads at higher speeds. Do not exceed the maximum pressure.

# Adding Fuel

The engine runs on clean, fresh diesel fuel with a minimum cetane rating of 40. Purchase fuel in quantities that can be used within 30 days to ensure fuel freshness.

Use summer grade diesel fuel (No. 2-D) at temperatures above 20 F (-7 C) and winter grade diesel fuel (No. 1-D or No. 1-D/2-D blend) below 20 F (-7 C). Use of winter grade diesel fuel at lower temperatures provides lower flash point and pour point characteristics, allowing easier starts and lessening the chances of chemical separation of the fuel due to lower temperatures.

Use of summer grade diesel fuel above 20 F (-7 C) will contribute toward longer life of the fuel pump components.

**Important:** Never use kerosene or gasoline in place of diesel fuel. Failure to observe this caution will damage the engine.

## ⚠ DANGER

In certain conditions, fuel is extremely flammable and highly explosive. A fire or explosion from fuel can burn you and others and can damage property.

- Fill the fuel tank outdoors, in an open area, when the engine is cold. Wipe up any fuel that spills.
- Never fill the fuel tank inside an enclosed trailer.
- Do not fill the fuel tank completely full. Add fuel to the fuel tank until the level is 1 inch (25 mm) below the bottom of the filler neck. This empty space in the tank allows fuel to expand.
- Never smoke when handling fuel, and stay away from an open flame or where fuel fumes may be ignited by a spark.
- Store fuel in an approved container and keep it out of the reach of children. Never buy more than a 30-day supply of fuel.
- Do not operate without entire exhaust system in place and in proper working condition.

## ⚠ DANGER

In certain conditions during fueling, static electricity can be released causing a spark which can ignite the fuel vapors. A fire or explosion from fuel can burn you and others and can damage property.

- Always place fuel containers on the ground away from your vehicle before filling.
- Do not fill fuel containers inside a vehicle or on a truck or trailer bed because interior carpets or plastic truck bed liners may insulate the container and slow the loss of any static charge.
- When practical, remove fuel-powered equipment from the truck or trailer and refuel the equipment with its wheels on the ground.
- If this is not possible, then refuel such equipment on a truck or trailer from a portable container, rather than from a fuel dispenser nozzle.
- If a fuel dispenser nozzle must be used, keep the nozzle in contact with the rim of the fuel tank or container opening at all times until fueling is complete.

## Filling the Fuel Tank

The fuel tank capacity is approximately 6.5 gallons (24.5 l).

1. Shut the engine off and set the parking brake.
2. Clean the area around the fuel tank cap (Figure 10).




Figure 10

- |           |                  |
|-----------|------------------|
| 1. Empty  | 4. Fuel gauge    |
| 2. Full   | 5. Fuel tank cap |
| 3. Needle |                  |

3. Remove the fuel tank cap.

- Fill the tank to about 1 inch (25 mm) below the top of tank, (bottom of the filler neck). This space in the tank allows fuel to expand. **Do not overfill.**
- Install the fuel tank cap securely. Wipe up any fuel that may have spilled.

## Checking the Transmission Oil Level

**Service Interval:** Before each use or daily

The transaxle fluid level should be at the bottom of the level indicator hole (Figure 11). If it is not, fill the reservoir with the appropriate fluid; refer to Changing the Transaxle Fluid (page 32).




Figure 11

- Level indicator hole

## Starting the Engine

- Sit in the operator's seat, insert the key into the ignition switch, press down on the brake, and rotate the key clockwise to the On position.

**Note:** If the back up alarm is installed and the gear shift selector is in Reverse, the buzzer will sound to warn the operator.

- Release the parking brake.
- Once the glow plug indicator light turns off, rotate the key counterclockwise to the Start position.

**Important:** Do not attempt to push or tow the vehicle to get it started.

## Stopping the Vehicle

To stop the vehicle, remove your foot from the accelerator pedal and slowly press the brake pedal.

**Note:** Stopping distance may vary depending on the vehicle load and speed.

## Parking the Vehicle

- Engage the parking brake and rotate the ignition key to Off.
- Remove the key from the ignition switch to prevent accidental starting.

## Operating the Cargo Box

### Raising the Cargo Box

#### ⚠ WARNING

Driving the machine with the cargo box raised may cause the machine to tip or roll easier. The box structure may become damaged if you operate the machine with the box raised.

- Only operate the machine when the cargo box is down.
- After emptying the cargo box, lower it.

#### ⚠ CAUTION

If a load is concentrated near the back of the cargo box when you release the latches, the box may unexpectedly tip open injuring you or bystanders.

- Center loads in the cargo box if possible.
- Hold the cargo box down and ensure that no one is leaning over the box or standing behind it when releasing the latches.
- Remove all cargo from the box before lifting the box up to service the machine.

- Lift the latch lever that is at the either side near the forward corner of the cargo box, and lift the box up (Figure 12).
- Secure the cargo box by pulling the prop rod into the rear detent at end of the slot that is in the left frame of the machine (Figure 12).




Figure 12

- Latch lever
- Prop rod
- Detent slot

## Lowering the Cargo Box

### ⚠ WARNING

The weight of the box may be heavy. Hands or other body parts could be crushed.

Keep hands and other body parts clear when lowering the box.

1. Raise the cargo box slightly by lifting up on the latch lever (Figure 12).
2. Pull the prop rod out of the detent slot (Figure 12).
3. Lower the box until it latches into securely (Figure 12).

## Opening the Tailgate

1. Ensure that the cargo box is down and latched.
2. Lift up on the finger pulls at the back panel of the tailgate (Figure 13).




Figure 13

1. Tailgate flange (cargo box)
  2. Lock flange (tailgate)
  3. Lift up (finger pull)
  4. Rotate rearward and down
3. Align the lock flanges of the tailgate with the openings between the tailgate flanges of the cargo box (Figure 13).
  4. Rotate the tail gate rearward and down (Figure 13).

## Closing the Tailgate

### Note:

1. If you unloaded loose material such as sand, landscaping rock, or wood chips from the cargo box of the machine, some of the material that you unloaded may have lodged in the hinge area of the tailgate. Perform the following before closing the tailgate:

- A. Use your hands to remove as much of the material from the hinge area as possible.
- B. Rotate the tailgate to approximately 45° position (Figure 14).




Figure 14

- C. Using a short, shaking motion—rotate the tailgate back and forth several times (Figure 14).

**Note:** This action will help move material away from the hinge area

- D. Lower the tailgate and check the hinge areas for remaining material that is in the hinge area.

- E. Repeat steps A through D until the material is removed from the hinge area.

2. Rotate the tailgate up and forward until the lock flanges of the tailgate are flush with the tailgate pocket in the cargo box (Figure 13).

**Note:** Raise or lower the tailgate in order to align the lock flanges of the tailgate with the vertical openings between the tailgate flanges of the cargo box.

3. Lower the tailgate until it is seated in the back of the cargo box (Figure 13).

**Note:** The lock flanges of the tailgate will be fully secured by the tailgate flanges of the cargo box.

## Breaking in a New Vehicle

To provide proper performance and long vehicle life, follow these guidelines for the first 100 operating hours:

- Check the fluid and engine oil levels regularly, and be alert for indications of overheating in any component of the vehicle.
- After starting a cold engine, let it warm up for about 15 seconds before accelerating.
- Avoid hard braking situations for the first several hours of new vehicle break-in operation. New brake linings may not be at optimum performance until several hours of use has caused the brakes to become burnished (broken-in).
- Vary the vehicle speed during operation. Avoid fast starts and quick stops.

- A break-in oil for engine is not required. Original engine oil is the same type specified for regular oil changes.
- Refer to the Maintenance section for any special low hour checks.
- Check the front suspension positioning and adjust it if necessary; refer to Drive System Maintenance (page 29).




Figure 15

1. Tie down points

## Loading the Cargo Box

The capacity of the cargo box is 0.37 m<sup>3</sup> (13 ft<sup>3</sup>). The amount (volume) of material that can be placed in the box without exceeding the vehicle load ratings can vary greatly depending on the density of the material. For example, a level box of wet sand weighs 680 kg (1500 lb), which exceeds the load rating by 113 kg (250 lb). But a level box of wood weighs 295 kg (650 lb), which is under the load rating.

See the table below for load volume limits with various materials:

Material	Max. cargo box capacity (on level ground)
Gravel, dry	3/4 full (approx.)
Gravel, wet	1/2 full (approx.)
Sand, dry	3/4 full
Sand, wet	1/2 full
Wood	Full
Bark	Full
Earth, packed	3/4 full (approx.)

## Transporting the Vehicle

For moving the vehicle long distances, a trailer should be used. Make sure that the vehicle is secured to the trailer. Refer to Figure 15 and Figure 16 for the location of the tie-down points.

### ⚠ CAUTION

Loose seats may fall off of the vehicle and trailer when transporting and land on another vehicle or become an obstruction on the road.

Remove the seats or make sure that the seats are securely fastened in the detents.

## Towing the Vehicle

In case of an emergency, the vehicle can be towed for a short distance. However, we do not recommend this as a standard procedure.

### ⚠ WARNING

Towing at excessive speeds could cause a loss of steering control, resulting in personal injury.

Never tow the vehicle faster than 8 km/h (5 mph).

Towing the vehicle is a two person job. If the machine must be moved a considerable distance, transport it on a truck or trailer; refer to Towing a Trailer (page 18).

1. Remove the drive belt; refer to Replacing the Drive Belt (page 34).
2. Affix a tow line to the tongue on the front of the frame (Figure 16).
3. Put the vehicle in neutral and release the parking brake.




Figure 16

1. Towing tongue and tie down point

## Towing a Trailer

The vehicle is capable of pulling trailers. Two types of tow hitches are available for the vehicle, depending on your application. Contact your Authorized Toro Distributor for details.

When hauling cargo or towing a trailer, do not overload your vehicle or trailer. Overloading can cause poor performance or damage to the brakes, axle, engine, transaxle, steering, suspension, body structure, or tires. Always load a trailer with

60% of the cargo weight in the front of the trailer. This places approximately 10% of the Gross Trailer Weight (GTW) on the tow hitch of the vehicle.

The maximum cargo load shall not exceed 567 kg (1250 lb), including the GTW. For example, if the GTW = 181.5 kg (400 lb) then the maximum cargo load = 386 kg (850 lb)

To provide adequate braking and traction, always load the cargo box when trailering. Do not exceed the GTW or GVW limits.

Avoid parking a vehicle with a trailer on a hill. If you must park on a hill, engage the parking brake and block the trailer tires.

# Maintenance

**Note:** Determine the left and right sides of the machine from the normal operating position.

## Recommended Maintenance Schedule(s)

Maintenance Service Interval	Maintenance Procedure
After the first 8 hours	<ul style="list-style-type: none"> <li>• Check the condition of the drive belt.</li> </ul>
After the first 50 hours	<ul style="list-style-type: none"> <li>• Change the engine oil.</li> </ul>
Before each use or daily	<ul style="list-style-type: none"> <li>• Check the engine oil.</li> <li>• Check the tire pressure.</li> <li>• Check the transmission oil level.</li> <li>• Check gear shift operation.</li> <li>• Inspect the primary drive clutch.</li> <li>• Check the radiator coolant level.</li> <li>• Check the brake fluid level.</li> </ul>
Every 50 hours	<ul style="list-style-type: none"> <li>• Check the battery cable connections for wear or damage.</li> <li>• Check the battery electrolyte level.</li> </ul>
Every 100 hours	<ul style="list-style-type: none"> <li>• Grease the bearings and bushings.</li> <li>• Check the operation of the Neutral gear shift position.</li> <li>• Inspect the condition and wear of the tires.</li> <li>• Torque the wheel lug nuts to 108-122 N-m (80-90 ft-lb).</li> <li>• Check the front wheel toe-in and camber.</li> <li>• Clean the engine cooling areas (twice as often in special operating conditions; refer to Maintaining the Vehicle under Special Operating Conditions).</li> <li>• Inspect the brakes.</li> </ul>
Every 150 hours	<ul style="list-style-type: none"> <li>• Change the engine oil (twice as often in special operating conditions; refer to Maintaining the Vehicle under Special Operating Conditions).</li> <li>• Change the oil filter (twice as often in special operating conditions; refer to Maintaining the Vehicle under Special Operating Conditions).</li> </ul>
Every 200 hours	<ul style="list-style-type: none"> <li>• Replace the air filter element.</li> <li>• Clean the primary drive clutch (more often in dusty or muddy conditions).</li> <li>• Check the parking brake operation.</li> <li>• Check the condition and tension of the drive belt.</li> </ul>
Every 400 hours	<ul style="list-style-type: none"> <li>• Inspect the fuel lines and connections.</li> </ul>
Every 800 hours	<ul style="list-style-type: none"> <li>• Replace the fuel filter.</li> <li>• Change the transaxle fluid.</li> </ul>
Every 1,000 hours	<ul style="list-style-type: none"> <li>• Change the radiator coolant.</li> <li>• Change the brake fluid.</li> </ul>
Yearly	<ul style="list-style-type: none"> <li>• Complete all yearly maintenance procedures specified in the Engine Operator's Manual.</li> </ul>

**Important:** Refer to your *engine operator's manual* for additional maintenance procedures.

# Daily Maintenance Checklist

Duplicate this page for routine use.

Maintenance Check Item	For the week of:						
	Mon.	Tues.	Wed.	Thurs.	Fri.	Sat.	Sun.
Check brake and parking brake operation.							
Check gear shift/neutral operation.							
Check fuel level.							
Check engine oil level.							
Check transaxle oil level.							
Inspect air filter.							
Inspect engine cooling fins.							
Check unusual engine noises.							
Check unusual operating noises.							
Check clutch operation.							
Check tire pressure.							
Check fluid leaks.							
Check instrument operation.							
Check accelerator operation.							
Lubricate all grease fittings.							
Touch up damaged paint.							

## **⚠ CAUTION**

If you leave the key in the ignition switch, someone could accidentally start the engine and seriously injure you or other bystanders.

Remove the key from the ignition before you do any maintenance.

## **⚠ WARNING**

The bed must be raised to perform some routine maintenance.

A raised bed can fall and injure persons that are underneath it.

- Always use the prop rod to hold the bed up before working under it.
- Remove any load material from the bed before working under it.

# Premaintenance Procedures

## Maintaining the Vehicle under Special Operating Conditions

If the vehicle is subjected to any of the conditions listed below, maintenance should be performed twice as frequently.

- Desert operation
- Cold climate operation (below 50° F [10 degrees C])
- Trailer towing
- Driving time typically less than 5 minutes
- Frequent operation in dusty conditions
- Construction work
- After extended operation in mud, sand, water, or similar dirty conditions, have your brakes inspected and cleaned as soon as possible. This will prevent any abrasive material from causing excessive wear.
- Under frequent heavy duty operating conditions, lubricate all grease fittings and inspect air cleaner daily to prevent excessive wear.

## Jacking up the Machine

Whenever the engine is run for routine maintenance and/or engine diagnostics, the rear wheels of the vehicle should be 25 mm (1 inch) off the ground with the rear axle supported on jack stands.

### **▲ DANGER**

The vehicle may be unstable when using a jack. It could slip off the jack, injuring anyone beneath it.

- Do not start the engine while the vehicle is on a jack.
- Always remove the key from the ignition before getting off of the machine.
- Block the tires when the vehicle is on a jack stand.

The jacking up point at the front of the vehicle is on the front of the frame behind the towing tongue (Figure 17) The jacking up point at the rear of the vehicle is under the axle tubes (Figure 18).




Figure 17

1. Front jacking up point




Figure 18

1. Rear jacking up points

## Accessing the Hood

1. Release the rubber straps on both sides of the hood (Figure 19).




Figure 19

2. Raise the hood.
3. Lower the hood to close it and use rubber retaining straps to secure the hood.

# Lubrication

Lubricate all of the bearings and bushings every 100 hours or once a year, whichever occurs first. Grease them more frequently when using the vehicle for heavy-duty operations.


Grease Type: No. 2 general-purpose, lithium-base grease

## Adding Grease

**Service Interval:** Every 100 hours


1. Wipe the grease fitting clean so foreign matter cannot be forced into the bearing or bushing.
2. Pump grease into the bearing or bushing.
3. Wipe off excess grease.

The grease fittings are located at the 4 tie rod ends (Figure 20) and the 2 king pins (Figure 21).



**Figure 20**  
Left side shown

1. Grease fitting
2. Tie rod



**Figure 21**  
Left side shown

1. Grease fitting

# Engine Maintenance

## Servicing the Air Cleaner

Check the air cleaner body for damage which could possibly cause an air leak. Replace a damaged air cleaner body.

Ensure the cover is sealing around the air cleaner body.


Air-cleaner filter: Inspect after every 100 operating hours; replace after every 200 hours or sooner if dirty or damaged.

**Note:** Service the air cleaner more frequently (every few hours) if operating conditions are extremely dusty or sandy.

## Removing the Filter Element

1. Pull the latch outward and rotate the air cleaner cover counterclockwise (Figure 22).
2. Remove the cover from the air cleaner body.
3. Gently slide the filter out of the air-cleaner body (Figure 22) to reduce the amount of dust dislodged.

**Note:** Avoid knocking the filter against the air cleaner body.



**Figure 22**

1. Dirt-ejection port
2. Cover
3. Latch
4. Air filter

4. Inspect the filter and discard it if it is damaged.

## Installing the Filter Element

**Service Interval:** Every 200 hours

**Important:** To prevent engine damage, always operate the engine with the complete air cleaner assembly installed.

**Note:** Cleaning of the used element is not recommended due to the possibility of damage to the filter media.

1. Inspect the new filter for shipping damage, checking the sealing end of the filter and the body.

**Note:** Do not use a damaged element.

2. Insert the new filter by applying pressure to the outer rim of the element to seat it in the canister.



# Fuel System Maintenance

## Inspecting Fuel Lines and Connections

**Service Interval:** Every 400 hours


Check the fuel lines and connections every 400 operating hours or yearly, whichever occurs first. Inspect them for deterioration, damage, or loose connections.

## Replacing the Fuel Filter

**Service Interval:** Every 800 hours

Replace the fuel filter every 800 operating hours or yearly, whichever occurs first.

1. Raise the box and support it with the prop rod.
2. Place a clean container under the fuel filter.
3. Unscrew the fuel filter from the bracket (Figure 25).



G017504  
**Figure 25**

1. Fuel filter


4. Install the replacement filter by turning it until the filter contacts the top of the bracket, then tighten it an additional 3/4 of a turn.

# Electrical System Maintenance

## Replacing the Fuses

There are 7 fuses in the electrical system. They are located beneath the dash on the driver's side (Figure 26).

Alarm/Power Point	10 A
Engine	10 A
Headlights	10 A
Machine fuse	15 A
Lift	15 A
Rear lift	15 A
Horn	30 A



**Figure 26**

1. Fuse block
2. Ground block
3. Pedal assembly

## Replacing the Headlights

Before performing any maintenance set the parking brake, turn the ignition off, and remove the key.

Release the retaining straps on the hood and raise the hood to access the headlights.

## Replacing the Bulbs

### ⚠ CAUTION

The halogen bulbs become extremely hot when in operation. Handling a hot bulb can cause severe burns and personal injury.

Always allow enough time for the bulbs to cool before replacing them. Use care whenever handling the bulb.

### ⚠ CAUTION

Any surface contamination can damage the headlight bulb and lead to its failure or explosion creating a serious safety hazard.

Head light lamps should be handled without touching the clear quartz, either by using a clean paper towel or carefully holding the base.

Specification: See your *Parts Catalog*.

1. Disconnect the electrical harness from the bulb housing on the back of the lamp.
2. Remove the bulb assembly by turning it 1/4 turn counter clockwise and moving it rearward, out of the lamp housing.
3. Remove the bulb from the base taking care not to touch the halogen quartz.
4. Install a new bulb on the base.

**Note:** Use a paper towel to grasp the new bulb with handling it to avoid contaminating the surface.

5. Insert the new bulb and assembly into the headlight housing and secure by turning it 1/4 turn clockwise to lock it in place.
6. Connect the electrical harness.

## Replacing the Headlight

When removing or replacing the headlight assembly, disconnect the wiring harness to the bulb assembly if the bulb is to be removed with the lamp.

1. Remove the speed clips and washers securing the headlight in place.

**Note:** Retain all parts.

2. Remove the headlight assembly by moving it forward through the opening in the front bumper (Figure 27).




Figure 27

- |                            |                                      |
|----------------------------|--------------------------------------|
| 1. Headlight               | 4. Headlight-bulb-harness connection |
| 2. Opening in front end    | 5. Speed clip                        |
| 3. Headlight-bulb assembly | 6. Flat washer                       |

3. Install the new headlight through the opening in the bumper (Figure 27).

**Note:** Ensure that the adjustment posts are lined up with the holes in the mounting bracket in the bumper.

4. Secure the headlight assembly with the washers and speed clips removed previously.
5. Attach the headlight to the wire harness removed previously.
6. Adjust the headlights to direct the beams to the desired position.

## Adjusting the Headlights

Use the following procedure to adjust the headlight beam position whenever you replace or remove a headlight assembly.

1. Turn the ignition key to the On position and turn on the headlights.
2. At the headlight assembly, use the fasteners to pivot the headlight assembly and affect the cast beam position.

# Servicing the Battery

## WARNING

### CALIFORNIA Proposition 65 Warning

Battery posts, terminals, and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and reproductive harm.  
Wash hands after handling.

**Important:** Do not jump start the vehicle.

Always keep the battery clean and fully charged. Use a paper towel to clean the battery and battery box. If the battery terminals are corroded, clean them with a solution of 4 parts water and 1 part baking soda. Apply a light coating of grease to the battery terminals to prevent corrosion.

Voltage: 12 volt with 540 cold cranking Amps at 0 degrees F (-18 degrees C).

## Removing the Battery

1. Position the vehicle on a level surface, set the parking brake, turn the ignition off, and remove the key.
2. Locate the battery on the right side of the machine, behind the passenger seat. Remove the battery cover.
3. Disconnect the negative (black) ground cable from the battery post.

## WARNING

**Incorrect battery cable routing could damage the vehicle and cables, causing sparks. Sparks can cause the battery gasses to explode, resulting in personal injury.**

- Always disconnect the negative (black) battery cable before disconnecting the positive (red) cable.
- Always reconnect the positive (red) battery cable before reconnecting the negative (black) cable.
- Always keep the battery strap in place to protect and secure the battery.

## WARNING

**Battery terminals or metal tools could short against metal vehicle components, causing sparks. Sparks can cause the battery gasses to explode, resulting in personal injury.**

- When removing or installing the battery, do not allow the battery terminals to touch any metal parts of the vehicle.
- Do not allow metal tools to short between the battery terminals and metal parts of the vehicle.

4. Disconnect the positive (red) cable from the battery post.
5. Remove the fasteners securing the battery hold down. Remove the hold down and retain all parts.
6. Remove the battery from the holder box.

## Installing the Battery

**Service Interval:** Every 50 hours

1. Set the battery into the battery holder box so that the battery posts are away from the vehicle frame.
2. Install the battery hold down and secure it with fasteners removed previously.

**Important:** Always keep the battery hold-down in place to protect and secure the battery.

3. Connect the positive (red) cable to the positive (+) battery post and the negative (black) cable to the negative (-) battery post.
4. Slide the rubber boot over the positive battery post.
5. Install the battery cover.

## Checking the Electrolyte Level

**Service Interval:** Every 50 hours

**Note:** This procedure is only necessary for batteries in Model 07359TC.

Check the electrolyte level every 50 operating hours or, if the machine is in storage, every 30 days.

1. Locate the battery on the right side of the machine, behind the passenger seat.
2. Remove the battery cover.
3. Remove the filler caps.

**Note:** If the electrolyte is not up to the fill line, add the required amount of distilled water; refer to Adding Water to the Battery (page 28).

## **⚠ DANGER**

**Battery electrolyte contains sulfuric acid which is a deadly poison and causes severe burns.**

- **Do not drink electrolyte or allow it to contact your skin, eyes or clothing. Wear safety glasses to shield your eyes and rubber gloves to protect your hands.**
- **Fill the battery where clean water is always available for flushing the skin.**

## **Adding Water to the Battery**

**Note:** This procedure is only necessary for batteries in Model 07359TC.

The best time to add distilled water to the battery is just before you operate the machine. This lets the water mix thoroughly with the electrolyte solution.

1. Clean the top of the battery with a paper towel.
2. Remove the filler caps from the battery and slowly fill each cell with distilled water until the level is up to the fill line.

**Important: Do not overfill the battery. Electrolyte will overflow onto other parts of the vehicle and severe corrosion and deterioration will result.**

3. Replace the filler caps.

## **Charging the Battery**

**Important: Always keep the battery fully charged (1.260 specific gravity). This is especially important to prevent battery damage when the temperature is below 32 degreesF (0 degreesC).**

1. Remove the battery from the machine; refer to Removing the Battery (page 27).
2. Connect a 3 to 4 amp battery charger to the battery posts.
3. Charge the battery at a rate of 3 to 4 amp for 4 to 8 hours (12 volts).

**Note:** Do not overcharge the battery.

## **⚠ WARNING**

**Charging the battery produces gasses that can explode.**

**Never smoke near the battery and keep sparks and flames away from battery.**

4. Install the battery in the chassis; refer to Installing the Battery (page 27).

## **Storing the Battery**

If the machine will be stored for more than 30 days, remove the battery and charge it fully. Either store it on the shelf or on the machine. Leave the cables disconnected if it is stored on the machine. Store the battery in a cool atmosphere to avoid quick deterioration of the charge in the battery. To prevent the battery from freezing, make sure that it is fully charged.

# Drive System Maintenance


## Checking and Adjusting the Neutral Position

**Service Interval:** Every 100 hours

When performing routine maintenance and/or engine diagnostics, the transaxle must be shifted into neutral (Figure 28). The vehicle has a neutral position on the shift lever, which controls the neutral in the transaxle. The following steps should be taken to make sure that the neutral shift lever operates the transaxle neutral correctly:

1. Set the shift lever into the Neutral position.
2. Ensure that the neutral bracket is in the Neutral position (level to the cable mounting bracket located below the shift bracket) by turning the driven clutch (Figure 28).

**Note:** The vehicle should not roll back and forth. If it does, manually move the neutral bracket to the Neutral position.



**Figure 28**


1. Neutral bracket
2. Locknuts

3. Tighten 1 of the locknuts (Figure 28) to achieve a gap of 0.76-1.52 mm (0.03-0.06 inch).

**Note:** You must hold the threaded shaft below the bracket to tighten the locknut on top.

4. Tighten the other locknut to achieve a gap of 0.76-1.52 mm (0.03-0.06 inch).
5. Pull up on each shift cable and ensure that there is a 0.76-1.52 mm (0.03-0.06 inch) gap between the nut/washer and the neutral bracket (Figure 29).

**Note:** If there is not a gap adjust the nuts to achieve a gap of 0.76-1.52 mm (0.03-0.06 inch).



**Figure 29**

1. Neutral bracket
2. Pull up
3. Cable boot
4. 0.76-1.52 mm (0.03-0.06 inch) gap
5. Wrong, adjust to achieve a gap of 0.76-1.52 mm (0.03-0.06 inch)
6. Start the engine and shift into Forward, Reverse, and Neutral several times to ensure that the neutral bracket is operating properly.

## Inspecting the Tires

**Service Interval:** Every 100 hours—Inspect the condition and wear of the tires.

Every 100 hours—Torque the wheel lug nuts to 108-122 N-m (80-90 ft-lb).

Check the tire condition at least every 100 hours of operation. Operating accidents, such as hitting curbs, can damage a tire or rim and also disrupt wheel alignment, so inspect the tire condition after an accident.

Check the wheels to ensure that they are mounted securely. Torque the lug nuts to 108-122 N-m (80-90 ft-lb).


# Adjusting Front Wheel Toe-in and Camber

**Service Interval:** Every 100 hours/Yearly (whichever comes first)—Check the front wheel toe-in and camber.

**Important:** You will need to obtain tool number Toro6010 from your Toro Distributor to perform this procedure.

The toe-in should be 0-6 mm (0-1/4 inch) and the camber should be 0+1/2 degree, i.e., the bottom of the wheel rims angled in 2.3 mm (0.09 inch) more than the top, with the following parameters:

- Check the tire pressure to ensure that the front tires are inflated to 82 kPa (12 psi).
  - Either add weight to the driver's seat equal to the average operator who will run the machine, or have an operator sit on the seat. The weight or operator must remain on the seat for the duration of the procedure.
  - On a level surface, roll the vehicle straight back 2 to 3 m (6 to 10 ft) and then straight forward to the original starting position. This will allow the suspension to settle into the operating position.
  - Measure the toe-in with the wheels facing straight ahead.
1. To check the camber, place a 90-degree square on the ground, with the vertical edge touching the face of the tire (Figure 30).



**Figure 30**


Left, front wheel shown from the front; the angle is exaggerated for clarity

1. Measure here.
2. Measure here—should be 2.3 mm (0.09 inch) larger than the measurement at 1

2. Measure from the same part of the rim on the top and bottom of the tire to the square (Figure 30).

**Note:** The distance of the bottom measurement should be 2.3 mm (0.09 inch) larger than the top measurement. Complete the measurement on both front tires before adjusting.


3. Complete the following procedure for each tire that needs adjusting:
  - A. Using tool Toro6010, rotate the collar on the shock absorber to change the length of the spring (Figure 31).
    - If the bottom measurement was too short, reduce the length of the spring.
    - If the bottom measurement was too long, increase the length of the spring.



**Figure 31**

- |                          |                  |
|--------------------------|------------------|
| 1. Shock-absorber spring | 3. Spring length |
| 2. Collar                |                  |


- B. On a level surface, roll the vehicle straight back 2 to 3 m (6 to 10 ft) and then straight forward to the original starting position.
  - C. Repeat this procedure, starting with step 1 until the camber is set correctly for both front wheels.
4. Measure the distance between both of the front tires at the axle height at both the front and rear of the front tires (Figure 32).



**Figure 32**

- |                           |                     |
|---------------------------|---------------------|
| 1. Tire center line-back  | 3. Axle-center line |
| 2. Tire center line-front |                     |

- If the measurement does not fall within 0-6 mm (0-1/4 inch), loosen the jam nuts at both ends of the tie rods (Figure 33).



**Figure 33**

- |            |            |
|------------|------------|
| 1. Jam nut | 2. Tie rod |
|------------|------------|

- Rotate both tie rods to move the front of the tire inward or outward.
- Tighten the tie rod jam nuts when the adjustment is correct.
- Ensure that there is full travel of the steering wheel in both directions.

## Inspecting the Primary Drive Clutch

**Service Interval:** Before each use or daily

Clutch operation should be monitored daily for proper shifting. If shifting is sticky or sluggish, or the clutch does not return completely to neutral when idling, the clutch requires a simple cleaning.

**Note:** Focus debris removal in and around moving parts.

- Stop the engine, remove the key, and set the parking brake.
- Raise and latch the cargo box.
- Remove dirt and mud buildup on the clutch with water and dry the clutch immediately with compressed air to remove excess water and debris.


**Note:** Remaining debris may be removed using a fast drying contact cleaner.

## Maintaining the Primary Drive Clutch

**Service Interval:** Every 200 hours—Clean the primary drive clutch (more often in dusty or muddy conditions).

**Note:** Operating the vehicle with a dirty clutch can increase wear to internal components.

- Stop the engine, remove the key, and set the parking brake.
- Raise and latch the cargo box.
- Remove the 6 flange-head bolts securing the clutch cover.
- Set aside the cover, spacer, and spring (Figure 34).



**Figure 34**

- |                 |                     |
|-----------------|---------------------|
| 1. Clutch shaft | 4. Clutch cover     |
| 2. Spring       | 5. Flange-head bolt |
| 3. Spacer       |                     |

- Remove dirt and mud buildup with water and dry immediately with compressed air to remove excess water and debris.
- Remove any remaining debris using a fast-drying contact cleaner or brake cleaner.

**Note:** Remove the debris in and around moving parts.

- If debris or buildup exists around the belt or along the clutch shaft, use a fine abrasive pad or a similar product to remove it.
- Install the spring, clutch cover, and flange-head bolts.
- Torque the bolts to 12-13.5 N-m (105-120 in-lb).


# Changing the Transaxle Fluid

**Service Interval:** Every 800 hours

Change the transaxle fluid every 800 operating hours or yearly, whichever occurs first.

1. Position the vehicle on a level surface, set the parking brake, turn the ignition off, and remove the key.
2. Remove the drain plug from the right side of the reservoir (Figure 35), and let the fluid flow into a drain pan.
3. Install and tighten the plug when the fluid stops draining.


**Note:** Dispose of the used oil at a certified recycling center.



**Figure 35**

1. Drain plug
2. Level indicator hole

4. Fill the reservoir (Figure 36) with approximately 1-1/2 qt. (1.4 liters) of SAE 10W/30 motor oil or until the oil level is at the bottom of the level indicator hole (Figure 35).



**Figure 36**

1. Oil fill

5. Start the engine and operate it to fill the system. Recheck the oil level and replenish it, if required.

# Cooling System Maintenance

## Cleaning the Engine Cooling Areas

**Service Interval:** Every 100 hours

Clean the external surfaces of the engine every 100 operating hours or more often under extremely dusty and dirty conditions.

**Important:** Never clean the engine with pressurized water because water could contaminate the fuel system.

## Filling the Radiator

### Initial Fill/Filling after Flushing

**Service Interval:** Every 1,000 hours/Every 2 years (whichever comes first)

**Note:** Use a 50/50 mix of Ethylene Glycol and water for coolant.


1. Position the vehicle on a level surface, set the parking brake, turn the ignition off, and remove the key.

### **CAUTION**

If the engine has been running, the pressurized, hot coolant can escape and cause burns.

- Do not open the radiator cap when the engine is running.
- Allow engine to cool at least 15 minutes or until the radiator cap is cool enough to touch without burning your hand.
- Use a rag when opening the radiator cap, and open the cap slowly to allow steam to escape.

2. Remove the fill cap (Figure 37) and fill with coolant.



**Figure 37**

1. Fill cap
2. Radiator overflow tank cap

3. Replace the fill cap and remove the radiator overflow tank cap (Figure 37).

**Note:** Never leave both caps off at the same time. This will adversely affect the filling of the tank.

4. Fill with coolant to the bottom of the filler neck. **Do not overfill.** Replace the radiator overflow tank cap and clean any spills.

## Checking and Refilling the Radiator

**Service Interval:** Before each use or daily

**Note:** Use a 50/50 mix of ethylene glycol and water for coolant.

1. Position the vehicle on a level surface, set the parking brake, turn the ignition off, and remove the key.

### ⚠ CAUTION

If the engine has been running, the pressurized, hot coolant can escape and cause burns.

- Do not open the radiator cap when the engine is running.
  - Allow engine to cool at least 15 minutes or until the radiator cap is cool enough to touch without burning your hand.
  - Use a rag when opening the radiator cap, and open the cap slowly to allow steam to escape.
2. Remove the radiator overflow tank cap (Figure 37).
  3. If the coolant level is low, fill the tank with coolant to the bottom of the filler neck.

**Note:** Do not overfill.

4. Replace the radiator overflow tank cap and clean any spills.

# Brake Maintenance

## Inspecting the Brakes

**Service Interval:** Every 100 hours

Brakes are a critical safety component of the vehicle. As with all safety components, they should be closely inspected at regular intervals to ensure optimum performance and safety. The following inspections should be done every 100 hours:

- Inspect the brake shoes for wear or damage. If the lining (brake pad) thickness is less than 1.6 mm (1/16 inch), the brake shoes should be replaced.
- Inspect the backing plate and other components for signs of excessive wear or deformation. If any deformation is found, the appropriate components must be replaced.
- Check the brake fluid level; refer to Checking the Brake Fluid Level (page 33).

## Checking the Brake Fluid Level

**Service Interval:** Before each use or daily


Every 1,000 hours

The brake fluid reservoir is filled and shipped from the factory with DOT 3 brake fluid. Check the level before the engine is first started and every 8 hours or daily thereafter.

1. Park the machine on a level surface, set the parking brake, turn the ignition off, and remove the key.
2. Remove the rubber plug in the center and on top of the dash to gain access to the master brake cylinder and reservoir.
3. Look at the side of the reservoir.

**Note:** The level should be above the Minimum line (Figure 38). If the fluid level is low, clean the area around the cap, remove the cap, and fill the reservoir to above the Minimum line.

Do not overfill.



G002136


**Figure 38**

1. Brake-fluid reservoir
2. Minimum line

# Adjusting the Parking Brake

Check the parking brake adjustment every 200 hours.

1. Pry the rubber cover off the parking brake.
2. Loosen the set screw securing the knob to the parking-brake lever (Figure 39).



**Figure 39**

1. Parking-brake lever
2. Knob
3. Set screw

3. Rotate the knob until you achieve a force of 30-35 lb (133-156 N).
4. Tighten the set screw and install the rubber cover.

# Belt Maintenance

## Servicing the Drive Belt

New belts must be broken in before they will shift properly. A belt will brake in within the first 2 hours of normal operation.

## Checking the Drive Belt


**Service Interval:** After the first 8 hours

Every 200 hours

**Note:** If the unit continues to move when the engine is at low idle, the clutches may be dirty and require washing.

1. Park the machine on a level surface, shift into Neutral, set the parking brake, turn the ignition off, and remove the key.
2. Raise the bed and secure it with the prop rod.
3. Rotate and inspect the belt (Figure 40) for excessive wear or damage.

**Note:** Replace the belt if necessary.



**Figure 40**

1. Primary clutch
2. Drive belt
3. Secondary clutch

## Replacing the Drive Belt

1. Rotate and route the belt over the secondary clutch (Figure 40).
2. Remove the belt from the primary clutch (Figure 40).
3. To replace the belt, reverse the procedure.

# Checking the Belt-pull Bumper *Cleaning*

**Note:** The belt-pull bumper needs to be checked only when troubleshooting vibration, performing a rebuild, or experiencing an engine mount failure.


The belt-pull bumper (Figure 41) should maintain a gap of 2.2 mm (0.09 inches).

If the bumper is too close to the engine bracket, the belt will cause excessive vibration.

If the bumper is too far from the engine bracket, the belt will cause harmful engine stress.

To adjust the gap, loosen the 3 flange-head bolts securing the bracket to the frame and slide the bracket the appropriate distance.

Once the gap is correct, tighten the 3 flange-head bolts.



**Figure 41**

- |                   |                     |
|-------------------|---------------------|
| 1. Engine bracket | 3. Bracket          |
| 2. Bumper         | 4. Flange-head bolt |

# *Cleaning*

## Washing the Vehicle

The vehicle should be washed as needed. Use water alone or with a mild detergent. A rag may be used, however the hood will lose some of its luster.

**Important:** Pressurized water is not recommended when washing the machine. It may damage the electrical system, loosen important decals, or wash away necessary grease at friction points. Avoid excessive use of water, especially near the control panel, engine, and battery.

# Storage

1. Position the machine on a level surface, set the parking brake, stop the engine, and remove the ignition key.
2. Clean dirt and grime from the entire machine, including the outside of the engine cylinder head fins and blower housing.

**Important:** You can wash the machine with mild detergent and water. Do not use high-pressure water to wash the machine. Pressure washing may damage the electrical system or wash away necessary grease at friction points. Avoid excessive use of water, especially near the control panel, lights, engine, and the battery.


3. Inspect the brakes; refer to Inspecting the Brakes (page 33).
4. Service the air cleaner; refer to Servicing the Air Cleaner (page 23).
5. Grease the machine; refer to Lubrication (page 23).
6. Change the engine oil; refer to Servicing the Engine Oil (page 24).
7. Check the tire pressure; refer to Inspecting the Tires (page 29).
8. Flush the fuel tank with fresh, clean diesel fuel.
9. Remove the battery from the chassis, check the electrolyte level, and charge it fully; refer to Servicing the Battery (page 27).

**Note:** Do not connect the battery cables to the battery posts during storage.

**Important:** The battery must be fully charged to prevent it from freezing and being damaged at temperatures below 32 degrees F (0 degrees C). A fully charged battery maintains its charge for about 50 days at temperatures lower than 40 degrees F (4 degrees C). If the temperatures will be above 40 degrees F (4 degrees C), check the water level in the battery and charge it every 30 days.

10. Check and tighten all bolts, nuts, and screws. Repair or replace any part that is damaged.
11. Paint all scratched or bare metal surfaces.  
Paint is available from your Authorized Service Dealer.
12. Store the machine in a clean, dry garage or storage area.
13. Remove the ignition key and put it in a safe place out of the reach of children.
14. Cover the machine to protect it and keep it clean.

# Schematics



G017169

Electrical Schematic (Rev. A)

**Notes:**

## International Distributor List

<b>Distributor:</b>	<b>Country:</b>	<b>Phone Number:</b>	<b>Distributor:</b>	<b>Country:</b>	<b>Phone Number:</b>
Agrolanc Kft	Hungary	36 27 539 640	Maquiver S.A.	Colombia	57 1 236 4079
Balama Prima Engineering Equip.	Hong Kong	852 2155 2163	Maruyama Mfg. Co. Inc.	Japan	81 3 3252 2285
B-Ray Corporation	Korea	82 32 551 2076	Mountfield a.s.	Czech Republic	420 255 704 220
Casco Sales Company	Puerto Rico	787 788 8383	Mountfield a.s.	Slovakia	420 255 704 220
Ceres S.A.	Costa Rica	506 239 1138	Munditol S.A.	Argentina	54 11 4 821 9999
CSSC Turf Equipment (pvt) Ltd.	Sri Lanka	94 11 2746100	Norma Garden	Russia	7 495 411 61 20
Cyril Johnston & Co.	Northern Ireland	44 2890 813 121	Oslinger Turf Equipment SA	Ecuador	593 4 239 6970
Cyril Johnston & Co.	Republic of Ireland	44 2890 813 121	Oy Hako Ground and Garden Ab	Finland	358 987 00733
Equivier	Mexico	52 55 539 95444	Parkland Products Ltd.	New Zealand	64 3 34 93760
Femco S.A.	Guatemala	502 442 3277	Perfetto	Poland	48 61 8 208 416
ForGarder OU	Estonia	372 384 6060	Pratoverde SRL.	Italy	39 049 9128 128
G.Y.K. Company Ltd.	Japan	81 726 325 861	Prochaska & Cie	Austria	43 1 278 5100
Geomechaniki of Athens	Greece	30 10 935 0054	RT Cohen 2004 Ltd.	Israel	972 986 17979
Golf international Turizm	Turkey	90 216 336 5993	Riversa	Spain	34 9 52 83 7500
Guandong Golden Star	China	86 20 876 51338	Lely Turfcare	Denmark	45 66 109 200
Hako Ground and Garden	Sweden	46 35 10 0000	Solvvert S.A.S.	France	33 1 30 81 77 00
Hako Ground and Garden	Norway	47 22 90 7760	Spypros Stavrinides Limited	Cyprus	357 22 434131
Hayter Limited (U.K.)	United Kingdom	44 1279 723 444	Surge Systems India Limited	India	91 1 292299901
Hydroturf Int. Co Dubai	United Arab Emirates	97 14 347 9479	T-Markt Logistics Ltd.	Hungary	36 26 525 500
Hydroturf Egypt LLC	Egypt	202 519 4308	Toro Australia	Australia	61 3 9580 7355
Irrimac	Portugal	351 21 238 8260	Toro Europe NV	Belgium	32 14 562 960
Irrigation Products Int'l Pvt Ltd.	India	0091 44 2449 4387	Valtech	Morocco	212 5 3766 3636
Jean Heybroek b.v.	Netherlands	31 30 639 4611	Victus Emak	Poland	48 61 823 8369

### European Privacy Notice

#### The Information Toro Collects

Toro Warranty Company (Toro) respects your privacy. In order to process your warranty claim and contact you in the event of a product recall, we ask you to share certain personal information with us, either directly or through your local Toro company or dealer.

The Toro warranty system is hosted on servers located within the United States where privacy law may not provide the same protection as applies in your country.

**BY SHARING YOUR PERSONAL INFORMATION WITH US, YOU ARE CONSENTING TO THE PROCESSING OF YOUR PERSONAL INFORMATION AS DESCRIBED IN THIS PRIVACY NOTICE.**

#### The Way Toro Uses Information

Toro may use your personal information to process warranty claims, to contact you in the event of a product recall and for any other purpose which we tell you about. Toro may share your information with Toro's affiliates, dealers or other business partners in connection with any of these activities. We will not sell your personal information to any other company. We reserve the right to disclose personal information in order to comply with applicable laws and with requests by the appropriate authorities, to operate our systems properly or for our own protection or that of other users.

#### Retention of your Personal Information

We will keep your personal information as long as we need it for the purposes for which it was originally collected or for other legitimate purposes (such as regulatory compliance), or as required by applicable law.

#### Toro's Commitment to Security of Your Personal Information

We take reasonable precautions in order to protect the security of your personal information. We also take steps to maintain the accuracy and current status of personal information.

#### Access and Correction of your Personal Information

If you would like to review or correct your personal information, please contact us by email at [legal@toro.com](mailto:legal@toro.com).

### Australian Consumer Law

Australian customers will find details relating to the Australian Consumer Law either inside the box or at your local Toro Dealer.



# The Toro Total Coverage Guarantee

## A Limited Warranty

### Conditions and Products Covered

The Toro® Company and its affiliate, Toro Warranty Company, pursuant to an agreement between them, jointly warrant your Toro Commercial product ("Product") to be free from defects in materials or workmanship for two years or 1500 operational hours\*, whichever occurs first. This warranty is applicable to all products with the exception of Aerators (refer to separate warranty statements for these products). Where a warrantable condition exists, we will repair the Product at no cost to you including diagnostics, labor, parts, and transportation. This warranty begins on the date the Product is delivered to the original retail purchaser.

\* Product equipped with an hour meter.

### Instructions for Obtaining Warranty Service

You are responsible for notifying the Commercial Products Distributor or Authorized Commercial Products Dealer from whom you purchased the Product as soon as you believe a warrantable condition exists. If you need help locating a Commercial Products Distributor or Authorized Dealer, or if you have questions regarding your warranty rights or responsibilities, you may contact us at:

Commercial Products Service Department  
Toro Warranty Company  
8111 Lyndale Avenue South  
Bloomington, MN 55420-1196  
E-mail: commercial.warranty@toro.com

### Owner Responsibilities

As the Product owner, you are responsible for required maintenance and adjustments stated in your Operator's Manual. Failure to perform required maintenance and adjustments can be grounds for disallowing a warranty claim.

### Items and Conditions Not Covered

Not all product failures or malfunctions that occur during the warranty period are defects in materials or workmanship. This warranty does not cover the following:

- Product failures which result from the use of non-Toro replacement parts, or from installation and use of add-on, or modified non-Toro branded accessories and products. A separate warranty may be provided by the manufacturer of these items.
- Product failures which result from failure to perform recommended maintenance and/or adjustments. Failure to properly maintain your Toro product per the Recommended Maintenance listed in the *Operator's Manual* can result in claims for warranty being denied.
- Product failures which result from operating the Product in an abusive, negligent or reckless manner.
- Parts subject to consumption through use unless found to be defective. Examples of parts which are consumed, or used up, during normal Product operation include, but are not limited to, brakes pads and linings, clutch linings, blades, reels, bed knives, tines, spark plugs, castor wheels, tires, filters, belts, and certain sprayer components such as diaphragms, nozzles, and check valves, etc.
- Failures caused by outside influence. Items considered to be outside influence include, but are not limited to, weather, storage practices,

contamination, use of unapproved coolants, lubricants, additives, fertilizers, water, or chemicals, etc.

- Normal noise, vibration, wear and tear, and deterioration.
- Normal "wear and tear" includes, but is not limited to, damage to seats due to wear or abrasion, worn painted surfaces, scratched decals or windows, etc.

### Parts

Parts scheduled for replacement as required maintenance are warranted for the period of time up to the scheduled replacement time for that part. Parts replaced under this warranty are covered for the duration of the original product warranty and become the property of Toro. Toro will make the final decision whether to repair any existing part or assembly or replace it. Toro may use remanufactured parts for warranty repairs.

### Note Regarding Deep Cycle Battery Warranty:

Deep cycle batteries have a specified total number of kilowatt-hours they can deliver during their lifetime. Operating, recharging, and maintenance techniques can extend or reduce total battery life. As the batteries in this product are consumed, the amount of useful work between charging intervals will slowly decrease until the battery is completely worn out. Replacement of worn out batteries, due to normal consumption, is the responsibility of the product owner. Battery replacement may be required during the normal product warranty period at owner's expense.

### Maintenance is at Owner's Expense

Engine tune-up, lubrication cleaning and polishing, replacement of Items and Conditions Not Covered filters, coolant, and completing Recommended Maintenance are some of the normal services Toro products require that are at the owner's expense.

### General Conditions

Repair by an Authorized Toro Distributor or Dealer is your sole remedy under this warranty.

**Neither The Toro Company nor Toro Warranty Company is liable for indirect, incidental or consequential damages in connection with the use of the Toro Products covered by this warranty, including any cost or expense of providing substitute equipment or service during reasonable periods of malfunction or non-use pending completion of repairs under this warranty. Except for the Emissions warranty referenced below, if applicable, there is no other express warranty.**

All implied warranties of merchantability and fitness for use are limited to the duration of this express warranty. Some states do not allow exclusions of incidental or consequential damages, or limitations on how long an implied warranty lasts, so the above exclusions and limitations may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

### Countries Other than the United States or Canada

Customers should contact their Toro Distributor (Dealer) to obtain guarantee policies for your country, province, or state. If for any reason you are dissatisfied with your Distributor's service or have difficulty obtaining guarantee information, contact the Toro importer. If all other remedies fail, you may contact us at Toro Warranty Company.