




Count on it.

Operator's Manual

18in Dethatcher

Model No. 23513—Serial No. 314000001 and Up

Model No. 33513—Serial No. 314000001 and Up



g025335



⚠ WARNING

CALIFORNIA Proposition 65 Warning

This product contains a chemical or chemicals known to the State of California to cause cancer, birth defects, or reproductive harm.

The engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.




Figure 1

1. Location of the model and serial numbers

Model No. _____

Serial No. _____

This manual identifies potential hazards and has safety messages identified by the safety alert symbol (Figure 2), which signals a hazard that may cause serious injury or death if you do not follow the recommended precautions.



Figure 2

1. Safety alert symbol

This manual uses 2 words to highlight information.

Important calls attention to special mechanical information and **Note** emphasizes general information worthy of special attention.

Introduction

This machine dethatches turf. It is intended for small- to medium-sized lawn applications in residential and commercial properties.

Read this information carefully to learn how to operate and maintain your product properly and to avoid injury and product damage. You are responsible for operating the product properly and safely.

You may contact Toro directly at www.Toro.com for product and accessory information, help finding a dealer, or to register your product.

Whenever you need service, genuine Toro parts, or additional information, contact an Authorized Service Dealer or Toro Customer Service and have the model and serial numbers of your product ready. Figure 1 illustrates the location of the model and serial numbers on the product. Write the numbers in the space provided.

Contents

Introduction	2
Safety	3
Safe Operating Practices	3
Slope Indicator	5
Safety and Instructional Decals	6
Setup	8
Unfolding the Handle	8
Checking the Engine-Oil Level.....	8
Product Overview	8
Controls	8
Specifications	10
Attachments/Accessories.....	10
Operation	11
Checking the Engine-Oil Level.....	11
Cleaning Debris from the Machine.....	11
Adding Fuel.....	11
Starting and Stopping the Engine.....	13
Operating the Machine.....	13
Operating Tips	13
Maintenance	14
Recommended Maintenance Schedule(s)	14
Premaintenance Procedures	14
Disconnecting the Spark-Plug Wire.....	14
Engine Maintenance	15
Servicing the Air Cleaner	15
Servicing the Engine Oil.....	15
Cleaning the Sediment Cup.....	16
Servicing the Spark Plug	16
Belt Maintenance	17
Checking the Belt Tension	17
Adjusting the Belt Tension.....	17
Maintaining the Flail Blades	18
Inspecting the Flail Blades	18
Replacing the Flail Blades	18
Storage	19
Removing the Machine from Storage.....	19

Safety

Improper use or maintenance by the operator or owner can result in injury. To reduce the potential for injury, comply with these safety instructions and always pay attention to the safety alert symbol, which means *Caution*, *Warning*, or *Danger*—personal safety instruction. Failure to comply with the instruction may result in personal injury or death.

Safe Operating Practices

The following instructions are based on the ANSI B71.4—2004 standard.

Training

- Read the *Operator's Manual* and other training material. If the operator(s) or mechanic(s) cannot read English, it is the owner's responsibility to explain this material to them.
- Become familiar with the safe operation of the equipment, operator controls, and safety signs.
- All operators and mechanics should be trained. The owner is responsible for training the users.
- Never let children or untrained people operate or service the equipment. Local regulations may restrict the age of the operator.
- The owner/user can prevent and is responsible for accidents or injuries occurring to himself or herself, other people, or property.

Preparation

- Evaluate the terrain to determine what accessories and attachments are needed to properly and safely perform the job. Only use accessories and attachments approved by the manufacturer.
- Wear appropriate clothing including safety glasses and hearing protection. Long hair, loose clothing, or jewelry may get tangled in moving parts.
- Inspect the area where the equipment is to be used and remove all objects such as rocks, toys, and wire, which can be contacted by the machine.
- Use extra care when handling gasoline and other fuels. They are flammable and vapors are explosive.
 - Use only an approved container.
 - Never remove the gas cap or add fuel with the engine running.
 - Allow the engine to cool before refueling.
 - Do not smoke.
 - Never refuel or drain the machine indoors.
- Check that the operator presence controls, safety switches, and shields are attached and functioning properly. Do not operate them unless they are functioning properly.

Operation

- Never run an engine in an enclosed area.
- Only operate in good light, keeping away from holes and hidden hazards.
- Start the engine only from the operator's position.
- Never operate without the shields, covers, or other guards securely in place. Be sure all interlocks are functioning properly.
- Do not change the engine governor setting or overspeed the engine.
- Raise the flail blades, stop the machine, and stop the engine before leaving the operator's position for any reason.
- Stop the equipment and inspect the flail blades after striking an object or if an abnormal vibration occurs. Make necessary repairs before resuming operation.
- Keep hands and feet away from the flail blade area.
- Never carry passengers, and keep pets and bystanders away.
- Be alert, slow down, and use caution when making turns. Look behind and to the side before changing directions.
- Do not operate the machine while under the influence of alcohol or drugs.
- Lightning can cause severe injury or death. If lightning is seen or thunder is heard in the area, do not operate the machine; seek shelter.
- Use extreme care when loading or unloading the machine into a trailer or truck.
- Use care when approaching blind corners, shrubs, trees, or other objects that may obscure vision.
- Always be aware of obstacles that may be in the area of operation. Plan your path to avoid contact with any obstacle by you or the machine.

Slope Operation


- Do not operate near drop-offs, ditches, steep banks, or water. Wheels dropping over edges can cause rollovers, which may result in serious injury or death.
- Do not operate on slopes when grass is wet. Slippery conditions reduce traction and could cause sliding and loss of control.
- Do not make sudden turns or rapid speed changes.
- Reduce speed and use extreme caution on slopes.
- Do not operate on a slope greater than 20 degrees.
- Remove or mark obstacles such as rocks, tree limbs, etc. from the operating area.
- Watch for ditches, holes, rocks, dips, and rises that change the operating angle, as rough terrain could overturn the machine.

- Always avoid sudden starting or stopping on a slope. If tires lose traction, disengage the flail blades and proceed slowly off the slope.
- Follow the recommendations for wheel weights or counterweights to improve stability.

Maintenance and Storage

- Wait for all movement to stop before adjusting, cleaning, or repairing. Raise the flail blades, stop the machine, stop the engine, and disconnect the spark-plug wire.
- Clean grass and debris from the blades, drives, mufflers, and engine to help prevent fires. Clean up oil or fuel spills.
- Let the engine cool before storing, and do not store the machine near a flame.
- Shut off the fuel while storing or transporting the machine on trailers. Do not store fuel near flames or drain indoors.
- Park the machine on level, hard ground. Never allow untrained personnel to service it.
- Use jack stands or safety latches to support components when required.
- Carefully release pressure from components with stored energy.
- Remove the spark-plug wire before making any repairs.
- Keep hands and feet away from moving parts. If possible, do not make adjustments with the engine running.
- Keep all parts in good working condition and all hardware tightened. Replace all worn or damaged decals.
- Use only Toro-approved attachments. The warranty may be voided if the machine is used with unapproved attachments.

Slope Indicator



G011841

Figure 3


This page may be copied for personal use.

1. The maximum slope you can safely operate the machine on is **20 degrees**. Use the slope chart to determine the degree of slope of hills before operating. **Do not operate this machine on a slope greater than 20 degrees.** Fold along the appropriate line to match the recommended slope.
2. Align this edge with a vertical surface, a tree, building, fence pole, etc.
3. Example of how to compare slope with folded edge.

Safety and Instructional Decals



Safety decals and instructions are easily visible to the operator and are located near any area of potential danger. Replace any decal that is damaged or lost.




117-4979

1. Warning—stay away from moving parts; keep all guards in place.



93-7321

1. Warning—stay away from moving parts; keep all guards in place.




125-3809

1. Warning—read the *Operator's Manual*.
2. Warning—do not operate this machine unless you are trained.
3. Thrown object hazard—stop the engine and remove any debris from your path.
4. Warning—stay away from moving parts; keep all guards in place.
5. Thrown object hazard—keep bystanders away from the machine.
6. Warning—stop the engine before walking away from the machine.
7. Warning—stop the engine and disconnect the spark plug wire before performing maintenance on the machine.



125-3897

1. Warning—stay away from moving parts; keep all guards and shields in place.



127-4061

- | | |
|-------------------|---|
| 1. Cutting blades | 4. Hold the handle to start the engine. |
| 2. Fast | 5. Release the handle to stop the engine. |
| 3. Slow | |
-

Setup

Unfolding the Handle

1. Raise the handle to the operating position (Figure 4).




Figure 4

2. Slide the oval locking rings down each side of the upper handle over the lower handle (Figure 4), locking the handle sections together.

Checking the Engine-Oil Level

The machine comes from the factory with oil in the engine crankcase, however, it may be necessary to add oil (Changing the Engine Oil (page 15). Add only enough oil to raise the level to the Full mark on the dipstick; refer to Figure 11.

Product Overview




Figure 5

- | | |
|---------------------------|--------------------------|
| 1. Operator-presence bail | 4. Fuel tank |
| 2. Handle | 5. Depth-control lever |
| 3. Throttle-control lever | 6. Recoil-starter handle |

Controls




Figure 6

- | | |
|-----------------------|-------------------|
| 1. Recoil starter | 4. Choke lever |
| 2. Sediment cup | 5. Throttle lever |
| 3. Fuel shutoff valve | |

Recoil Starter

Pull the recoil starter handle to start engine (Figure 6).

Fuel Shutoff Valve

Close the fuel shutoff valve when transporting or storing the machine (Figure 6).

Choke Lever

Before starting a cold engine, move the choke lever forward. After the engine starts, regulate the choke to keep the engine running smoothly. As soon as possible, move the choke lever all the way rearward.

Note: A warm engine requires little or no choking.

Operator-Presence Bail

The operator-presence bail allows the machine to start/run.

To start the machine, hold down the operator presence bail (Figure 7). Continue to hold down the operator presence bail to allow the machine to run.




Figure 7

1. Operator-presence bail

Throttle Lever

Move the control forward to increase the engine speed, and rearward to decrease speed; refer to Figure 8.




Figure 8

- 1. Throttle lever

Depth Control Lever

The depth control lever allows you to set the depth of the flail blades in 10 cutting positions along with 1 position for transportation. To adjust the depth, remove the hairpin cotter, pull the locking pin out, and move the lever forward or rearward to the desired depth setting (Figure 9).

Important: Do not pull the lever side-to-side as this will bend it.




Figure 9

- 1. Depth-control lever
- 2. Transport-position hole
- 3. Hairpin cotter
- 4. Locking pin

Specifications

Note: Specifications and design are subject to change without notice.

Width	69.9 cm (27.5 inches)
Length (operating)	111.8 cm (44 inches)
Length (with handle stored)	86.4 cm (34 inches)
Height (operating)	94 cm (37 inches)
Height (with handle stored)	63.5 cm (25 inches)
Weight	61.2 kg (135 lbs)

Attachments/Accessories

Approved attachments and accessories are available for use with the machine to enhance and expand its capabilities. Contact an Authorized Service Dealer or Distributor or go to www.Toro.com for a list of all approved attachments and accessories.

Operation

Note: Determine the left and right sides of the machine from the normal operating position.

Checking the Engine-Oil Level

Service Interval: Before each use or daily

1. Stop the engine, disengage the flail blades, and wait for all moving parts to stop.
2. Clean around the dipstick (Figure 10) so that dirt cannot fall into the filler hole and damage the engine.

Note: Make sure that the engine is level.





Figure 10

g019540

1. Dipstick
-
3. Unscrew the dipstick and wipe the end clean (Figure 10).
 4. Insert the dipstick fully onto the filler tube. **Do not screw it in.**(Figure 10).
 5. Remove the dipstick again and look at the end. If the engine-oil level is low, slowly pour only enough oil into the filler tube to raise the level to the middle of the dipstick (Figure 11).



g019686

Figure 11

- | | |
|----------------|-------------------|
| 1. Filler tube | 4. Lower limit |
| 2. Dipstick | 5. Oil-drain bolt |
| 3. Upper limit | |

Important: Do not overfill the crankcase with engine oil and run the engine; engine damage may result.

Cleaning Debris from the Machine

Service Interval: Before each use or daily

1. Disengage the flail blades, stop the engine, and wait for all moving parts to stop.
2. Brush dirt and debris away from the air cleaner and engine openings.

Adding Fuel

Recommended Fuel:

- For best results, use only clean, fresh (less than 30 days old), unleaded gasoline with an octane rating of 87 or higher ((R+M)/2 rating method).
- **Ethanol:** Gasoline with up to 10% ethanol (gasohol) or 15% MTBE (methyl tertiary butyl ether) by volume is acceptable. Ethanol and MTBE are not the same. Gasoline with 15% ethanol (E15) by volume is not approved for use. **Never use gasoline that contains more than 10% ethanol by volume**, such as E15 (contains 15% ethanol), E20 (contains 20% ethanol), or E85 (contains up to 85% ethanol). Using unapproved gasoline may cause performance problems and/or engine damage which may not be covered under warranty.
- **Do not** use gasoline containing methanol.

- **Do not** store fuel either in the fuel tank or fuel containers over the winter unless a fuel stabilizer is used.
- **Do not** add oil to gasoline.

Important: To reduce starting problems, add fuel stabilizer to the fuel all season, mixing it with gasoline less than 30 days old; run the machine dry before storing it for more than 30 days.

Do not use fuel additives other than a fuel stabilizer/conditioner. Do not use fuel stabilizers with an alcohol base such as ethanol, methanol, or isopropanol.

⚠ DANGER

In certain conditions, gasoline is extremely flammable and highly explosive. A fire or explosion from gasoline can burn you and others and can damage property.

- Fill the fuel tank outdoors, in an open area, when the engine is cold. Wipe up any gasoline that spills.
- Never fill the fuel tank inside an enclosed trailer.
- Do not fill the fuel tank completely full. Add gasoline to the fuel tank until the level is 6 to 13 mm (1/4 to 1/2 inch) below the bottom of the filler neck. This empty space in the tank allows gasoline to expand.
- Never smoke when handling gasoline, and stay away from an open flame or where gasoline fumes may be ignited by a spark.
- Store gasoline in an approved container and keep it out of the reach of children. Never buy more than a 30-day supply of gasoline.
- Do not operate without the entire exhaust system in place and in proper working condition.

⚠ DANGER

In certain conditions during fueling, static electricity can be released, causing a spark which can ignite the gasoline vapors. A fire or explosion from gasoline can burn you and others and can damage property.

- Always place gasoline containers on the ground away from your vehicle before filling.
- Do not fill gasoline containers inside a vehicle or on a truck or trailer bed, because interior carpets or plastic truck bed liners may insulate the container and slow the loss of any static charge.
- When practical, remove gas-powered equipment from the truck or trailer, and refuel the equipment with its wheels on the ground.
- If this is not possible, then refuel such equipment on a truck or trailer from a portable container rather than from a gasoline dispenser nozzle.
- If a gasoline dispenser nozzle must be used, keep the nozzle in contact with the rim of the fuel tank or container opening at all times until fueling is complete.

Filling the Fuel Tank

1. Disengage the flail blades, stop the engine, and wait for all moving parts to stop.
2. Allow the engine to cool.
3. Clean around the fuel tank cap and remove it (Figure 12).

Note: The cap is tethered to the fuel tank.




Figure 12

4. Add unleaded gasoline to the fuel tank until the level is just inside the mesh filter basket.

Important: This space in the tank allows gasoline to expand. Do not fill the fuel tank completely full.

5. Install the fuel tank cap securely.
6. Wipe up any spilled gasoline.

Starting and Stopping the Engine

Starting the Engine

1. Turn on the fuel valve.
2. Move the choke lever to the left if you are starting a cold engine.
3. Move the throttle lever midway between the Slow (turtle) and Fast (rabbit) positions.

Note: A warm or hot engine may not require choking.

4. With one hand, hold down the operator presence bail.
5. Pull the recoil handle sharply to start the engine.
6. After the engine starts, gradually move the choke to the right.

Note: If the engine stalls or hesitates, move the choke left again until the engine warms up.

7. Move the throttle lever to desired setting.

Stopping the Engine

1. Release the operator presence bail.
2. Turn the fuel valve off.
3. Wait for all moving parts to stop.

Operating the Machine

1. Move the depth control lever to the desired setting.
2. Start the engine.
3. Push down on the handle to raise the front wheels off the ground.
4. Slowly lower the front wheels to the ground, allowing the blades to gradually work into the grass and soil.
5. When finished, release the operator presence bail, stop the engine, and raise the cutting blades to the transport setting.

Operating Tips

Dethatching

- Set the flail blades 3 to 6 mm (1/8 to 1/4 inch) into the earth (below the zero position).
- Mow yard shorter than normal mowing length before dethatching.
- Dethatch a lawn before the prime growing season.
- After dethatching, remove thatch and debris from lawn with rake.
- Use time of soil exposure to fertilize and seed lawn.
- Give lawn extra watering after dethatching.

Power Raking/Renovation

To break new ground or till an existing lawn, set the flail blades 6 to 12 mm (1/4 to 1/2 inch) into the earth (below the zero position). Allow the machine to move at its own pace through the soil, going forward and backward over the area to be leveled, or making multiple passes from different directions.

Maintenance


Recommended Maintenance Schedule(s)

Maintenance Service Interval	Maintenance Procedure
After the first 25 hours	• Change the engine oil.
Before each use or daily	• Check the engine oil level. • Clean debris from the machine. • Inspect the air cleaner elements. • Check the belt tension. If the engine is working but flails seem underpowered, check belt tension • Check the flail blades for wear or damage. • Check for loose fasteners.
Every 50 hours	• Clean the air filter elements. Clean them more frequently in dusty operating conditions.
Every 100 hours	• Change the engine oil. • Clean the sediment cup. • Inspect, clean, and adjust the spark plug; replace it if necessary.
Every 200 hours	• Replace the spark plug.
Every 300 hours	• Replace the paper air cleaner element. Replace it more frequently in dusty operating conditions.
Yearly or before storage	• Touch up chipped paint.

Premaintenance Procedures

Disconnecting the Spark-Plug Wire

Before performing any maintenance on the engine, belts, or cutting blades, disconnect the spark plug wire from the spark-plug (Figure 13).



G019426

Figure 13

1. Spark-plug wire

Engine Maintenance

Servicing the Air Cleaner

Service Interval: Before each use or daily—Inspect the air cleaner elements.

Every 50 hours—Clean the air filter elements. Clean them more frequently in dusty operating conditions.

Every 300 hours/Yearly (whichever comes first)—Replace the paper air cleaner element. Replace it more frequently in dusty operating conditions.

Important: Do not operate the engine without the air filter assembly; extreme engine damage will occur.

1. Stop the engine and wait for all moving parts to stop.
2. Disconnect the wire from the spark plug.
3. Remove the nut that secures the cover (Figure 14).




Figure 14

1. Nut
2. Cover
3. Paper element
4. Foam element

4. Remove the cover.

Note: Be careful to prevent dirt and debris from falling into the base.

5. Remove nut restraining air filter assembly.
6. Remove the foam and paper elements from the base (Figure 14).
7. Remove the foam element from the paper element (Figure 14).
8. Inspect the foam and paper elements, and replace them if they are damaged or excessively dirty.
9. If the paper element is excessively dirty, replace it.

Note: Never try to brush dirt off the paper element; brushing forces the dirt into the fibers.

10. Clean the foam element in warm, soapy water or in a **nonflammable** solvent.

Note: Do not use gasoline to clean the foam element because it could create a risk of fire or explosion.

11. Rinse and dry the foam element thoroughly.
12. Dip the foam element in clean engine oil, then squeeze out the excess oil.

Note: Excess oil in the foam element restricts the air flow through the element and may reach the paper filter and clog it.

13. Wipe dirt from the base and the cover with a moist rag.

Note: Be careful to prevent dirt and debris from entering the air duct leading to the carburetor.

14. Install the air cleaner elements and ensure that they are properly positioned.
15. Secure with nut.
16. Securely install the cover with nut.

Servicing the Engine Oil

Oil Type: Detergent oil (API service SJ or higher)

Crankcase Capacity: 37 oz (1.1 l)

Viscosity: See table below




Figure 15

g013375

Changing the Engine Oil

Service Interval: After the first 25 hours

Every 100 hours

⚠ WARNING

Oil may be hot after the engine has been run, and contact with hot oil can cause severe personal injury.

Avoid contacting the hot engine oil when you drain it.

1. Stop the engine by releasing the operator presence bail, disengage the flail blades, and wait for all moving parts to stop.

2. Disconnect the wire from the spark plug.
3. Raise the front wheels a few inches off the ground and place a pan under the drain plug to catch the oil.
4. Remove the drain plug (Figure 16).




Figure 16

1. Drain plug

5. When the oil has drained completely, lower the front wheels to the ground, replace the drain plug, and torque to 18 N·m (13 ft-lb).

Note: Dispose of the used oil at a certified recycling center.

6. Remove the dipstick and slowly pour oil into the filler hole until the oil level reaches the middle of the dipstick (Figure 11).
7. Replace and secure the dipstick.
8. Wipe up any spilled oil.
9. Connect the wire to the spark plug.

Cleaning the Sediment Cup

Service Interval: Every 100 hours

⚠ DANGER

In certain conditions, gasoline is extremely flammable and highly explosive. A fire or explosion from gasoline can burn you and others and can damage property.

- Stop the engine and keep heat, sparks, and flame away.
- Handle fuel only outdoors.
- Wipe up spills immediately.
- Do not smoke while handling fuel.

1. Stop the engine and wait for all moving parts to stop.

2. Disconnect the wire from the spark plug.
3. Move the fuel shutoff valve to the Off position.
4. Remove the sediment cup and O-ring (Figure 17).




Figure 17

1. O-ring
2. Sediment cup

5. Wash the sediment cup in a nonflammable solvent and dry it thoroughly.
 6. Place the O-ring in the fuel valve and install the sediment cup, tightening it securely.
 7. Move the fuel shut-off lever to the On position.
- If any fuel leaks, repeat this procedure and replace the O-ring.

Servicing the Spark Plug

Service Interval: Every 100 hours—Inspect, clean, and adjust the spark plug; replace it if necessary.

Every 200 hours—Replace the spark plug.

Use an **NGK BPR6ES** spark plug or equivalent.

1. Stop the engine and wait for all moving parts to stop.
2. Disconnect the wire from the spark plug.
3. Clean around the spark plug.
4. Remove the spark plug from the cylinder head.

Important: Replace a cracked, fouled, or dirty spark plug. Do not clean the electrodes because grit entering the cylinder can damage the engine.

5. Set the gap on the plug to 0.76 mm (0.030 inch) (Figure 18).




Figure 18

1. Center-electrode insulator
 2. Side electrode
 3. Air gap (not to scale)
-
6. Carefully install the spark plug by hand (to avoid cross threading) until it is hand tight.
 7. Tighten the spark plug an additional 1/2 turn if it is new; otherwise, tighten it an additional 1/8 to 1/4 turn.
- Important:** A loose spark plug can become very hot and can damage the engine; overtightening a spark plug may damage the threads in the cylinder head.
8. Connect the wire to the spark plug.

Belt Maintenance

Checking the Belt Tension

Service Interval: Before each use or daily—Check the belt tension. If the engine is working but flails seem underpowered, check belt tension

1. Stop the machine on a level surface, stop the engine, disconnect the spark-plug wire, and raise the flail blades to the highest position.
2. Remove the 4 bolts securing the belt cover to the left side of the machine and remove the cover (Figure 19).




Figure 19

1. Belt
2. Cover
3. Bolts

3. Check the tension of the belt (Figure 19).

Note: The belt should not flex more than a 12 mm (1/2 inch) with moderate finger pressure applied to the span just above the machine frame.

4. If the belt tension is loose, refer to Adjusting the Belt Tension (page 17).
5. Install belt cover before operating the machine.

Adjusting the Belt Tension

1. Stop the machine on a level surface and stop the engine by releasing the operator presence bail.
2. To tighten the belt, loosen the 4 mounting nuts securing the engine to the frame.




Figure 20

1. Mounting nuts

3. Move the engine to tighten the belt to the proper tension.
4. Secure the four mounting nuts and bolts.

Note: Torque the bolts that secure the engine to the frame 271 N-m (200 in-lb).

Maintaining the Flail Blades

Inspecting the Flail Blades

Service Interval: Before each use or daily—Check the flail blades for wear or damage.

When the flail blades are worn down and are no longer functioning properly; refer to Replacing the Flail Blades (page 18).

Important: Perform this procedure when the fuel tank is empty or nearly empty. Tip the machine forward to keep air filter up.

Replacing the Flail Blades

When the flail blades are worn down and no longer functioning properly, replace them as follows:

Important: Perform this procedure when the fuel tank is empty or nearly empty.

1. Stop the machine on a level surface, and stop the engine by releasing the operator presence bail.
2. Lower the flail blades to the lowest position.
3. Tilt the machine forward onto its nose, resting on a block of wood.

Note: It will take 2 people to tip the machine forward safely.

4. Spin the flail blade assembly.

Note: It should spin freely. If it makes a grinding noise and is halting, the bearings are worn; replace them when you replace the blades.

5. Remove the cotter pin from rod with the worn down flail (Figure 21).
6. Carefully pull out the rod to release the flails and spacers (Figure 21).
7. Replace worn down flails with new ones and discard the old flails.

Storage




Figure 21

- | | |
|----------|---------------|
| 1. Rod | 3. Spacer |
| 2. Flail | 4. Cotter pin |

- Carefully add flails and spacers to rod in the same order as they were removed.

Important: Make sure to align the rod with formed head toward the center of the machine.

- Add cotter pin to lock rod, flails, and spacers into place.

- Raise the flail blades, stop the machine, stop the engine, and disconnect the spark-plug wire.
- Remove dirt and grime from the entire machine.

Important: You can wash the machine with mild detergent and water. Do not pressure wash the machine. Avoid excessive use of water, especially near the engine.

- Service the air cleaner; refer to Servicing the Air Cleaner (page 15).
- Change the engine oil; refer to Changing the Engine Oil (page 15).
- For storage over 30 days, prepare the traction unit as follows:

- Add a petroleum based stabilizer/conditioner to fuel in the tank. Follow mixing instructions from stabilizer manufacturer (1 oz. per gallon). **Do not use an alcohol based stabilizer (ethanol or methanol).**

Note: A fuel stabilizer/conditioner is most effective when mixed with fresh gasoline and used at all times.

- Run the engine until it stops from running out of fuel.
- Choke the engine.
- Start and run the engine until it will not start again.
- Dispose of fuel properly. Recycle the fuel according to local codes.

Important: Do not store stabilizer/conditioned gasoline over 90 days.

- Check and tighten all bolts, nuts, and screws. Repair or replace any part that is damaged.
- Paint all scratched or bare metal surfaces with paint from an Authorized Service Dealer.
- Store the machine in a clean, dry garage or storage area.
- Cover the machine to protect it and keep it clean.

Removing the Machine from Storage

- Check and tighten all fasteners.
- Inspect the spark plug and replace it if it is dirty, worn, or cracked; refer to the engine *Owner's Manual*.
- Install the spark plug until it is hand-tight, then an additional 1/2 turn if it is new, otherwise, tighten it an additional 1/8 to 1/4 turn.
- Perform any needed maintenance procedures; refer to Maintenance (page 14).

5. Check the engine-oil level; refer to Checking the Engine-Oil Level (page 11).
6. Fill the fuel tank with fresh gasoline; refer to Filling the Fuel Tank (page 12).
7. Connect the wire to the spark-plug.

Notes:

Notes:

Notes:



The Toro Warranty

A limited warranty (see warranty periods below)

SWS
Turf Renovation
and
Tree Care

Conditions and Products Covered

The Toro Company and its affiliate, Toro Warranty Company, pursuant to an agreement between them, jointly warrant your Toro Products listed below to be free from defects in materials or workmanship.

This warranty covers the cost of parts and labor, but you must pay transportation costs.

The following time periods apply from the date of purchase:

Products	Warranty Period
Turf Renovation	
Walk-Behind Aerator	1 year
• Engine	2 years
Stand-On Aerator	1 year
• Battery	90 days Parts and Labor
	1 year Parts Only
• Engine	2 years
Dethatcher	1 year
• Engine	2 years
Turf Seeder	1 year
• Engine	2 years
Tree Care	
Log Splitter	1 year
• Battery	90 days Parts and Labor
	1 year Parts Only
• Engine	2 years
Stump Grinder	1 year
• Engine	2 years
Brush Chipper	1 year
• Battery	90 days Parts and Labor
	1 year Parts Only
• Engine	3 years
Walk-Behind Rotary Broom	1 year
• Engine	2 years

Where a warrantable condition exists, we will repair the Product at no cost to you including diagnosis, labor, and parts.

Instructions for Obtaining Warranty Service

If you think that your Toro Product contains a defect in materials or workmanship, follow this procedure^{***}:

1. Contact any Authorized Servicing Outlet to arrange service at their dealership. To locate one convenient to you, access our website at www.Toro.com. Select "Where to Buy" and select "Contractor" under product type. You may also call our toll free number below.
2. Bring the product and your proof of purchase (sales receipt) to them.
3. If for any reason you are dissatisfied with the Service Outlet's analysis or with the assistance provided, contact us at:

SWS Customer Care Department
Toro Warranty Company
8111 Lyndale Avenue South
Bloomington, MN 55420-1196
Toll Free: 888-384-9940

^{***}Toro Authorized Rental Customers who have purchased products directly from Toro and have signed the Toro Rental Customer Agreement have the ability to perform their own warranty work. Please visit Toro's Rental Portal for electronic warranty claim filing procedures or call the toll free number above.

Owner Responsibilities

You must maintain your Toro Product by following the maintenance procedures described in the *Operator's Manual*. Such routine maintenance, whether performed by a dealer or by you, is at your expense. Parts scheduled for replacement as required maintenance ("Maintenance Parts"), are warranted for the period of time up to the scheduled replacement time for that part. Failure to perform required maintenance and adjustments can be grounds for disallowing a warranty claim.

Items and Conditions Not Covered

Not all product failures or malfunctions that occur during the warranty period are defects in materials or workmanship. This express warranty does not cover the following:

- Product failures which result from installation and use of add-on, modified, or unapproved accessories
- Failure to perform required maintenance and/or adjustments
- Repairs necessary due to failure to follow recommended fuel procedure (consult *Operator's Manual* for more details)
 - Removing contaminants from the fuel system is not covered
 - Use of old fuel (more than one month old) or fuel which contains more than 10% ethanol or more than 15% MTBE
 - Failure to drain the fuel system prior to any period of non-use over one month
- Product failures which result from operating the product in an abusive, negligent or reckless manner
- Parts subject to consumption through use unless found to be defective. Examples of parts which are consumed, include, belts, cutters, blades, teeth, spark plugs, tires, filters, etc.
- Failures caused by outside influence include, weather, storage, contamination, lubricants, additives, or chemicals, etc.
- Normal "wear and tear" items includes painted surfaces and scratched decals, etc.
- Any component covered by a separate manufacturer's warranty
- Pickup and delivery charges

General Conditions

Repair by an Authorized Servicing Outlet or Self-Service as an Authorized Rental Customer is your sole remedy under the warranty.

Neither The Toro Company nor Toro Warranty Company is liable for indirect, incidental or consequential damages in connection with the use of the Toro Products covered by this warranty, including any cost or expense of providing substitute equipment or service during reasonable periods of malfunction or non-use pending completion of repairs under this warranty. All implied warranties of merchantability and fitness for use are limited to the duration of this express warranty. Some states do not allow exclusions of incidental or consequential damages, or limitations on how long an implied warranty lasts, so the above exclusions and limitations may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Except for the engine warranty coverage and the Emissions warranty referenced below, if applicable, there is no other express warranty. The Emissions Control System on your Product may be covered by a separate warranty meeting requirements established by the U.S. Environmental Protection Agency (EPA) or the California Air Resources Board (CARB). Refer to the California Emission Control Warranty Statement supplied with your Product or contained in the engine manufacturer's documentation for details.

Countries Other than the United States or Canada

Customers who have purchased Toro products outside the United States or Canada should contact their Toro Distributor (Dealer) to obtain guarantee policies for your country, province, or state. If for any reason you are dissatisfied with your Distributor's service or have difficulty obtaining guarantee information, contact the Toro importer. If all other remedies fail, you may contact us at Toro Warranty Company.

Australian Consumer Law: Australian customers will find details relating to the Australian Consumer Law either inside the box or at your local Toro Dealer.