

**TORO®**

MODEL NO. 30652 — 390001 &amp; UP

**OPERATOR'S  
MANUAL****52" SIDE DISCHARGE CUTTING UNIT**

PROLINE 220

**TORO**THIS UNIT CONFORMS  
TO ANSI B71.4-1990

To assure maximum safety, optimum performance, and to gain knowledge of the product, it is essential that you or any other operator of the mower read and understand the contents of this manual before the engine is ever started. Pay particular attention to the **SAFETY INSTRUCTIONS** highlighted by this symbol —



The safety alert symbol means **CAUTION, WARNING or DANGER** — personal safety instruction. Failure to comply with the instruction may result in personal injury.



# FOREWORD

The cutting unit has advanced concepts in engineering, design and safety; and if maintained properly, will give excellent service.

Since it is a high-quality product, Toro is concerned about the future use of the machine and safety of the user. Therefore, read this manual to familiarize yourself with proper set-up, operation and maintenance instructions. The major sections of the manual are:

- |                        |                     |                |
|------------------------|---------------------|----------------|
| 1. Safety Instructions | 3. Before Operating | 5. Maintenance |
| 2. Set-up Instructions | 4. Lubrication      |                |

Certain information in this manual is emphasized. DANGER, WARNING and CAUTION identify personal safety-related information. IMPORTANT identifies mechanical information demanding special attention. Be sure to read this directive because it deals with the possibility of damaging a part or parts of the machine. NOTE identifies general information worthy of special attention.

## TABLE OF CONTENTS

	Page		Page
SAFETY INSTRUCTIONS .....	2-4	CUTTING UNIT MAINTENANCE .....	12-18
SAFETY AND INSTRUCTION DECALS .....	4	Troubleshooting .....	12
SPECIFICATIONS .....	5	Separating Cutting Unit From Traction Unit ..	13
LOOSE PARTS .....	5	PTO Shaft Removal .....	13
SET-UP INSTRUCTIONS .....	6-9	Servicing Bushings in Castor Arms .....	13
Install Carrier Frame .....	6	Servicing Castor Wheel and Bearing .....	14
Install Cutting Unit .....	6	Checking For Bent Blade .....	14
Install Weight Transfer Kit .....	7	Checking Sail and Sharpening Cutter Blade ..	15
BEFORE OPERATING .....	9	Correcting Cutting Unit Mismatch .....	16
Adjusting Height-of-Cut .....	9	Replacing Grass Deflector .....	17
Adjust Gage Wheel .....	9	Adjusting Idler Pulley .....	17
Check Lubricant in Gear Box .....	9	Replacing Drive Belt .....	18
OPERATING INSTRUCTIONS .....	10	IDENTIFICATION AND ORDERING .....	19
Grass Deflector .....	10	SERVICE INTERVAL CHART .....	19
Tension Spring Adjustment .....	10	THE TORO PROMISE .....	20
LUBRICATION MAINTENANCE .....	11		

## SAFETY INSTRUCTIONS



This safety alert symbol means **CAUTION, WARNING or DANGER** — "personal safety instruction". Read and understand the instruction because it has to do with safety. Failure to comply with the instruction may result in personal injury.



### WARNING

Engine exhaust contains carbon monoxide which is an odorless, deadly poison. Carbon monoxide is also known to the State of California to cause birth defects. Do not run engine indoors or in an enclosed area.

Although hazard control and accident prevention partially are dependent upon the design and configuration of the machine, these factors are also dependent upon the awareness, concern, and proper training of the personnel involved in the operation, transport, maintenance, and storage of the machine. Improper use or maintenance of the machine can result in injury or death. To reduce the potential for injury or death, comply with the following safety instructions.

### BEFORE OPERATING

1. Read and understand the contents of this Operator's Manual before operating the machine. Become familiar with all controls and know how to stop quickly. A free replacement manual is available by sending complete Model and Serial Number to:

The Toro Company  
8111 Lyndale Avenue South  
Bloomington, Minnesota 55420-1196

# SAFETY INSTRUCTIONS

2. Never allow children to operate the machine. Do not allow adults to operate the machine without proper instruction. Only trained operators who have read this manual should operate this machine.
3. Never operate the machine when under the influence of drugs or alcohol.
4. Remove all debris or other objects that might be picked up and thrown by the cutter blades. Keep all bystanders away from the mowing area.
5. Do not operate unless all shields and safety devices are in place. If a shield, safety device or decal is defective or damaged, repair or replace it before operation is commenced. Also tighten any loose nuts, bolts and screws to assure machine is in safe operating condition.
6. Do not operate machine while wearing sandals, tennis shoes, sneakers or shorts. Also, do not wear loose fitting clothing which could get caught in moving parts. Always wear long pants and substantial shoes. Wearing safety glasses, safety shoes and a helmet is advisable and required by some local ordinances and insurance regulations.
7. Make sure interlock switches are adjusted correctly so engine cannot be started unless traction pedal is released — neutral position — and PTO lever is in DISENGAGE position.
8. Fill fuel tank with gasoline before starting the engine. Avoid spilling gasoline. Since gasoline is flammable, handle it carefully.
  - A. Use an approved gasoline container.
  - B. Do not fill tank while engine is hot or running.
  - C. Do not smoke while handling gasoline.
  - D. Fill fuel tank outdoors and up to about one inch (25 mm) from top of the tank, not the filler neck.
  - E. Wipe up any spilled gasoline.

## WHILE OPERATING

9. Do not run the engine in a confined area without adequate ventilation. Exhaust fumes are hazardous and could possibly be deadly.
10. Maximum seating capacity is one person. Never carry passengers.
11. Sit on the seat when starting the engine and operating the machine.
12. Before starting the engine:
  - A. Engage parking brake.
  - B. Ensure traction pedal is in neutral and PTO is in OFF, disengage position.
  - C. After engine is started, release parking brake and keep foot off traction pedal. Machine must not move. If movement is

evident, the neutral return mechanism is adjusted incorrectly; therefore, shut engine off and adjust until machine does not move when traction pedal is released.

13. Using the machine demands attention, and to prevent loss of control:
  - A. Mow only in daylight or when there is good artificial light.
  - B. Watch for holes or other hidden hazards.
  - C. Do not drive close to a sand trap, ditch, creek or other hazard.
  - D. Reduce speed when making sharp turns and when turning on hillsides.
  - E. Avoid sudden stops and starts.
  - F. Before backing up, look to the rear and be sure no one is behind the machine.
  - G. Watch for traffic when near or crossing roads. Always yield the right-of-way.
14. The grass deflector must always be installed and in lowest position on the side discharge cutting unit. Never operate mower without deflector or entire grass collector in place. If the cutting unit discharge area ever plugs, disengage PTO and shut engine off before removing the obstruction. This product is designed to drive objects into the ground where they lose energy quickly in grassy areas. However, don't take an injury risk! When a person or pet appears unexpectedly in or near the mowing area, STOP MOWING. Careless operation, combined with terrain angles, ricochets, or improperly positioned guards, can lead to thrown object injuries. Do not resume mowing until area is cleared.
15. Never raise the cutting unit while the blades are rotating.
16. If the cutting blades strike a solid object or the machine vibrates abnormally, disengage PTO, move throttle to SLOW, set parking brake and shut engine off. Remove key from switch to prevent possibility of accidental starting. Check cutting unit and traction unit for damage and defective parts. Repair any damage before restarting the engine and operating the cutting unit. Be sure blades are in good condition and blade bolts are tight.
17. Cut grass slopes carefully. Do not start, stop, or turn suddenly.
18. Do not touch engine or muffler while engine is running or soon after it is stopped. These areas could be hot enough to cause a burn.
19. Before getting off the seat:
  - A. Move traction pedal to neutral position and remove foot from pedal.
  - B. Set the parking brake and disengage the PTO.
  - C. Shut the engine off and remove key from ignition switch. Wait for all movement to stop before getting off the seat.

# SAFETY INSTRUCTIONS

20. Lower the cutting unit to the ground and remove key from ignition switch whenever machine is left unattended.

## MAINTENANCE

21. Remove key from ignition switch and disconnect high tension wire from spark plug to prevent accidental starting of the engine when servicing, adjusting or storing the machine.

22. Perform only those maintenance instructions described in this manual. If major repairs are ever needed or assistance is desired, contact an Authorized Toro Proline Dealer.

23. To reduce potential fire hazard, keep the engine free of excessive grease, grass, leaves and accumulations of dirt.

24. Be sure machine is in safe operating condition by keeping nuts, bolts and screws tight. Check the blade mounting bolts frequently to be sure they are tight.

25. Make sure all hydraulic line connectors are tight, and all hydraulic hoses and lines are in good condition before applying pressure to the system.

26. Keep body and hands away from pin hole leaks or nozzles that eject hydraulic fluid under high pressure. Use paper or cardboard, not hands, to search for

leaks. Hydraulic fluid escaping under pressure can have sufficient force to penetrate skin and do serious damage. If fluid is ejected into the skin it must be surgically removed within a few hours by a doctor familiar with this form of injury or gangrene may result.

27. Before disconnecting or performing any work on the hydraulic system, all pressure in system must be relieved by stopping engine and lowering implement to the ground.

28. If the engine must be running to perform a maintenance adjustment, keep hands, feet, clothing and other parts of the body away from the cutting unit blades and other moving parts.

29. Do not overspeed the engine by changing governor settings. To be sure of safety and accuracy, have an Authorized TORO Proline Dealer check maximum engine speed with a tachometer.


30. Engine must be shut off before checking oil or adding oil to the crankcase.

31. At the time of manufacture the cutting unit conformed to safety standards in effect for riding mowers. Therefore, to ensure optimum performance and safety, always purchase genuine TORO replacement parts and accessories to keep the Toro all TORO. NEVER USE "WILL-FIT" REPLACEMENT PARTS AND ACCESSORIES MADE BY OTHER MANUFACTURERS. Look for the TORO logo to assure genuineness. Using unapproved replacement parts and accessories could void the warranty of The Toro Company.

## SAFETY AND INSTRUCTION DECALS



The following decals are installed on the machine. If any become damaged or illegible, replace it. The decal part number is listed in your parts catalog. Replacement can be ordered from your Authorized Toro Proline Dealer.



ON LEFT SIDE OF CARRIER FRAME  
(Part No. 68-8360)



ON BOTH SIDES OF DECK, UNDER COVERS  
(Part No. 67-5360)



ON GEAR BOX BRACKET  
(Part No. 70-2560)




UNDER DEFLECTOR  
(Part No. 66-6380)



ON LEFT SIDE  
OF CUTTING UNIT  
UNDER COVER  
(Part No. 43-8480)



ON RIGHT AND LEFT OF CUTTING UNIT  
(Part No. 66-1340)



ON LEFT SIDE OF CUTTING UNIT  
(Part No. 68-8340)



ON DEFLECTOR  
(Part No. 54-9220)

# SPECIFICATIONS

## CUTTING UNIT:

**Width of Cut:** 51-3/4 in. (1.315 m).

**Height-of-Cut:** Adjustable from 1" to 4" (25 to 102 mm) in 1/2" (13 mm) increments.

**Blade Tip Speed:** 15,764 ft/min. @ 3300 engine RPM, 15,525 ft/min @ 3250 engine RPM.

**Cutter Blades:** Three heat treated steel blades, each 3/16 in. (4.8 mm) thick and 18 in. (457 mm) long.

**Pneumatic Wheels:** 8 in. (203 mm) dia. with grease-able roller bearings. (Inflation 20-30 P.S.I.).

**Unit Drive System:** PTO driven gear box transmits power through a "AA" section belt to all blade spindles.

Specifications and design subject to change without notice.

## Optional Equipment:

Leaf Mulcher:

52" Front Baffle Kit:

High Lift Blades:

Model 30700

Part No. 68-7210

(for Dry Conditions)

Part No. 44-5480 or

Part No. 56-2390

## Grass Collection System:

Model 30502 Blower Kit used with Model 30504 Hopper Kit.

## Phenolic Castor Wheels:

Part No. 27-1050 use with Spanner Part No. 69-8980 or order Part No. 40-0370 Castor Fork and 3/4" bolts Part No. 328-9.

# LOOSE PARTS

**Note:** Use this chart as a checklist to assure all parts have been received. Without these parts, total set-up cannot be completed.

DESCRIPTION	QTY	USE
Rear cradle	2	Mount to lift arms.
Capscrew 3/8 — 16 x 2"	6	
Spacer	2	
Flange Nut 3/8 — 16	6	
Capscrews — 1/2-13 x 1-1/2"	6	
Carrier Frame	1	
Castor Wheel Assembly	2	Install in frame.
Thrust Washer	8	Install on castor fork shafts.
Lynch Pin	2	Install in top hole of castor shafts
Clevis Pin	4	} Mount deck to Suspension Frame.
Hair Pin Cotter	4	
Mounting Bracket	1	Mount Weight Transfer Kit to traction unit.
Lock Pin Assembly	2	
Self-tapping Screw	2	
Spring Cover Assembly	1	
Clevis Pin	1	
Hair Pin Cotter	1	
Spring End — Top	1	
Extension Spring — Heavy	1	
Spring End — Lower	1	
Knee Link	1	
Capscrew, 3/8 — 16 x 2-1/4"	2	
Capscrew, 3/8 — 16 x 1.0"	2	
Shoulder Bolt	2	
Locknut, 3/8 — 16	4	
Operator's Manual	1	
Registration Card	1	
Cushion Shim	3	Leveling rubber cushions on cutting deck.

# SET-UP INSTRUCTIONS



## DANGER

Do not start the engine and engage the PTO lever when PTO shaft is not connected to cutting unit gear box because the PTO shaft will rotate with enough force to cause serious injury.

## INSTALL CARRIER FRAME

**Note:** Grease castor wheel shaft with No. 2 grease after installing and after initial operation of machine.

1. Remove Lynch Pins and two thrust washers from each castor wheel assembly. Leave two thrust washers on each shaft, insert shafts into frame, install thrust washers and Lynch pins (Fig. 1).




Figure 1

- |                          |                   |
|--------------------------|-------------------|
| 1. Castor wheel assembly | 3. Thrust washers |
| 2. Frame                 | 4. Lynch pin      |

2. Mount a rear cradle to each lift arm with (3) 3/8 - 16 x 2" capscrews, spacer and flange nuts as shown in Figure 2. Torque fasteners to 20-25 ft-lb.

3. Slide carrier frame onto lift arms aligning mounting holes. Secure each side of carrier frame to lift arms with (3) 1/2 - 13 x 1-1/2" lg. capscrews. Torque capscrews to 70-80 ft-lb. (Fig. 2).




Figure 2

- |             |                  |                |           |
|-------------|------------------|----------------|-----------|
| 1. Lift arm | 2. Carrier frame | 3. Rear cradle | 4. Spacer |
|-------------|------------------|----------------|-----------|

## INSTALL CUTTING UNIT

1. Engage parking brake, be sure traction pedal is in neutral, PTO lever is in DISENGAGED position, start engine and raise frame.

2. Stop engine, remove clevis pins and hairpins from forward and rear height-of-cut brackets (Fig. 4), install cutting unit under carrier frame, align gearcase input shaft with PTO shaft and install shaft (Fig. 3).

3. Lower frame, align PTO shaft hole with gearcase input shaft hole and install roll pin (Fig. 3).




Figure 3

- |                       |                   |
|-----------------------|-------------------|
| 1. PTO shaft          | 3. Gearcase shaft |
| 2. Bolts and locknuts | 4. Roll pin       |

4. Install clevis pins through desired height-of-cut bracket holes and frame to secure cutting unit to frame (Fig. 4). Secure all four pins with hairpins.




Figure 4

- |                      |                      |                    |
|----------------------|----------------------|--------------------|
| 1. 1 in. (25 mm)     | 4. 2-1/2 in. (64 mm) | 7. 4 in. (102 mm)  |
| 2. 1-1/2 in. (38 mm) | 5. 3 in. (76 mm)     | 8. Grass deflector |
| 3. 2 in. (51 mm)     | 6. 3-1/2 in. (89 mm) | 9. Spring hinges   |

# SET-UP INSTRUCTIONS

## INSTALL WEIGHT TRANSFER KIT

1. Fully raise the cutting deck, set the parking brake, rotate the ignition key to OFF and remove it from the ignition switch. Place blocks under the cutting deck to prevent it from falling during assembly.

**Note:** Mounting brackets must be installed in different locations, depending on the cutter deck or options (Fig. 5).




Figure 5

1. 52" side discharge deck
2. 52" side discharge w/ bagger

2. To install the mounting bracket, align the bracket with the frame mounting holes. Insert (2) 3/8 x 2-1/4" capscrews through the non-slotted bracket holes and frame mounting holes. Install locknuts and torque to 45-50 ft-lb (Fig. 6).




Figure 6

1. 3/8 x 2-1/4" capscrew (2)
2. Non-slotted hole
3. Locknut

3. Thread the top extension spring coil into the top spring end holes and the bottom extension spring coil into the bottom spring end holes (Fig. 7).

4. Mount knee link to lower spring end with wide part of knee link pointing forward and spring end stop pointing forward. Secure knee link to outer side of spring end with a shoulder bolt and locknut (Fig. 7, 8).

**IMPORTANT:** The knee link must be assembled pointing in the proper direction or spring will not pivot correctly when deck is raised.

5. Mount bottom of knee link to deck bracket with a shoulder bolt and locknut (Fig. 8, 9).

6. Align slotted holes in the spring cover (slot toward the bottom) with the mounting bracket holes. Insert lock pin assemblies into the bracket holes and secure each to the bracket with self-tapping screws (Fig. 7). Torque the screws to 20 ft-lb.




Figure 7

1. Mounting bracket
2. Spring cover
3. Lock pin assembly (2)
4. Self-tapping screw (2)
5. Extension spring
6. Top spring end
7. Bottom spring end
8. Clevis pin
9. Hair pin cotter
10. Knee link
11. Shoulder bolt (2)
12. Locknut (2)

# SET-UP INSTRUCTIONS

7. From the bottom, insert the spring and top spring end into the spring cover. Select a hole that matches the cutter deck height-of-cut hole setting; i.e., top cover hole matches highest height setting, bottom cover hole the lowest, etc. Align the top spring end hole with the selected spring cover holes and insert the clevis pin to secure the spring inside the cover (Fig. 7). Secure the clevis pin with the hair pin cotter (Fig. 7).




Figure 8

1. Wide part of knee link

8. Remove the blocks from under the cutting unit. Make final counterbalance adjustments under actual cutting conditions; refer to Tension Spring Adjustment, page 10.




Figure 9

1. Weight transfer spring
2. Spring end plate
3. Knee link bracket
4. Deck bracket
5. Flotation frame



# BEFORE OPERATING

## ADJUSTING HEIGHT-OF-CUT

The height-of-cut is adjustable from 1 to 4 inches (25 to 102 mm) in 1/2 inch (13 mm) increments by relocating four clevis pins in different hole locations in brackets at each corner of the cutting unit (Fig. 10).

**Note:** All four pins should be in identical hole locations to prevent any operating and cutting difficulties.

**Note:** If cutting unit is to be used in 1 in. (25 mm) or 1-1/2 in. (38 mm) height-of-cut setting, rear cutting unit rollers must be repositioned in the top bracket holes.

1. Remove cotter pins from roller shafts.
2. Slide shafts out of lower bracket holes, align rollers with top holes and install shafts.
3. Install cotter pins to secure assemblies.




Figure 10

- |                      |                      |                    |
|----------------------|----------------------|--------------------|
| 1. 1 in. (25 mm)     | 4. 2-1/2 in. (64 mm) | 7. 4 in. (102 mm)  |
| 2. 1-1/2 in. (38 mm) | 5. 3 in. (76 mm)     | 8. Grass Deflector |
| 3. 2 in. (51 mm)     | 6. 3-1/2 in. (89 mm) | 9. Spring hinges   |

## ADJUST GAGE WHEELS

With machine on a flat surface and height-of-cut in desired setting, gage wheels are to be positioned so they are approximately 1/4" to 3/8" above the ground.

**IMPORTANT:** It is important that gage wheels be

adjusted each time height-of-cut is changed, so that the deck will follow the contour of the ground and does not scalp the turf.

1. Remove hairpin cotter and clevis pin securing gage wheel to cutting deck.
2. Move gage wheel up or down to required setting and reinstall clevis pin and cotter pin.
3. Reposition gage wheels each time height-of-cut setting is changed.




Figure 11

1. Gage wheel

## CHECK LUBRICANT IN GEAR BOX

The gear box is designed to operate on SAE 80-90 wt. gear lube. Although the gear box is shipped with lubricant from the factory, check the level before operating the cutting unit.

1. Position machine and cutting unit on a level surface. Lower cutting unit onto level surface.
2. Remove check plug from side of gear box (Fig. 12) and make sure lubricant is up to bottom of hole. If level of lubricant is low, remove fill plug on top of gear case and add enough lubricant to bring it up to bottom of hole in side.




Figure 12

1. Filler plug    2. Check plug    3. Drain plug

# OPERATING INSTRUCTIONS

## GRASS DEFLECTOR



### CAUTION

The grass deflector (Fig. 10) is a safety device that diverts grass and other foreign objects being discharged downward. Without deflector mounted in place on the cutting unit and spring loaded hinges holding deflector in down position, the blades could hurl grass and foreign objects out the discharge opening with enough force to cause injury or property damage. If the grass deflector or spring hinges are worn, broken or damaged, repair or replace the affected part(s). Do not operate cutting unit without deflector or entire grass collector mounted on the cutting unit. Always be sure the deflector chute is in the lowest possible position.

## TENSION SPRING ADJUSTMENT

For best performance, adjust spring tension so cutting unit bounce on uneven turf is minimal and it does not ride heavily over fairly flat terrain. If scalping occurs or the cut is uneven from side to side, there may be too

much weight on the deck and weight may have to be transferred to the traction unit; i.e., increased spring tension.

By contrast, if too much weight is transferred to the traction unit, the deck will bounce excessively and the cut will be uneven. If the cutting unit does not perform properly, adjust as follows:

1. Stop the machine on a level surface, set the parking brake, fully raise the cutting unit, turn the ignition key to OFF and remove it from the ignition switch.
2. Remove the hair pin cotter from the clevis pin and remove the clevis pin. Align the top spring end hole with the new hole selected in the spring cover, insert the clevis pin and secure it with the hair pin cotter.
3. Resume operation. If further adjustments are necessary, refer to steps 1, 2.



### CAUTION

**Counterbalance spring is in tension when deck is in lowered position. Always raise deck before adjusting or removing spring.**

# LUBRICATION MAINTENANCE

## GREASE BEARINGS, BUSHINGS AND GEAR BOX

The cutting unit must be lubricated regularly. If machine is operated under normal conditions, lubricate castor bearings and bushings with No. 2 general purpose lithium grease or molybdenum base grease, after every 8 hours of operation or daily, whichever comes first. All other bearings, bushings and the gear box must be lubricated after every 50 hours of operation.

1. The cutting unit has bearings and bushings that must be lubricated, and these lubrication points are: castor spindle bushings (Fig. 13); castor wheel bearings (Fig. 13), and blade spindle bearings (Fig. 14).

2. Lower cutting unit so castor wheels are on a level surface. Be sure all height-of-cut pins are in the same hole locations. Remove check plug (Fig. 18) from side of gear box and check level of lubricant. If level of lubricant is low, remove fill plug on top of gear box and add SAE 80-90 wt. gear lube until level is up to bottom of check hole.




Figure 13




Figure 14





Figure 15

- 1. Filler plug
- 2. Check plug
- 3. Drain plug

# CUTTING UNIT MAINTENANCE TROUBLESHOOTING

**UNIT WILL NOT CUT OR CUTS POORLY**



# CUTTING UNIT MAINTENANCE

## SEPARATING CUTTING UNIT FROM TRACTION UNIT

1. Position machine on level surface, raise cutting unit, engage parking brake, be sure traction pedal is in neutral position, PTO lever is in OFF position, shut engine off and remove key from switch.



### CAUTION

Counterbalance spring is in tension when deck is in lowered position. Always raise deck before adjusting or removing springs.

2. Disconnect counterbalance from traction unit, remove lock pins from bracket, separate spring tension assembly from bracket and lay it down on the deck. Loosely secure lock pins to bracket to prevent losing them (Fig. 16).




Figure 16

- |            |                             |
|------------|-----------------------------|
| 1. Lockpin | 3. Spring tension assembly  |
| 2. Bracket | 4. Height-of-cut clevis pin |

3. Lower cutting unit, remove pins (4) from height-of-cut brackets (Fig. 17).

4. Start engine, raise cutting unit frame.

5. Stop engine and slide cutting unit away from traction unit and frame separating male and female section of PTO shaft (Fig. 17).




Figure 17

- |               |                     |
|---------------|---------------------|
| 1. Male shaft | 2. Female PTO shaft |
|---------------|---------------------|



### DANGER

Do not start the engine and engage the PTO lever when PTO shaft is not connected to gear box on cutting unit. If engine is started and PTO shaft is allowed to rotate, serious injury could result.

6. Deck suspension frame must be removed if traction unit will be used with any other accessory.

## PTO SHAFT REMOVAL

1. Jack left wheel off shop floor. Support the axle with a jackstand to prevent machine from falling accidentally.

2. Remove five wheel nuts and slide left wheel off axle to expose access hole inside of chassis (Fig. 18).

3. Push PTO lever forward until pulley and brake disengage. Align hole in PTO shaft with hole in chassis (Fig. 18).

4. Through access hole in chassis, drive roll pin out of PTO shaft and output shaft with pin punch and ball peen hammer (Fig. 18 inset).

5. Install the left wheel with five wheel nuts. Tighten nuts to 60-80 ft-lb (81-109 N·m).

6. Lower machine and remove jack.




Figure 18

1. PTO shaft

## SERVICING BUSHINGS IN CASTOR ARMS

The castor arms have bushings pressed into the top and bottom portion of the tube and after many hours of operation, the bushings will wear. To check the bushings, move castor fork back and forth and from side-to-side. If castor spindle is loose inside the bushings, bushings are worn and must be replaced.

# CUTTING UNIT MAINTENANCE

1. Raise cutting unit and block it so it cannot fall accidentally.
2. Remove lynch pin and thrust washers from top of castor spindle.
3. Pull castor spindle out of mounting tube. Allow thrust washers to remain on bottom of spindle.
4. Insert pin punch into top or bottom of mounting tube and drive bushing out of tube (Fig. 19). Also drive other bushing out of tube. Clean inside of tubes to remove dirt.




Figure 19

1. Lynch pin 2. Thrust washers

5. Apply grease to inside and outside of new bushings. Using a hammer and flat plate, drive bushings into mounting tube.
6. Inspect castor spindle for wear and replace it if damaged.
7. Push castor spindle through bushings and mounting tube. Slide spacers onto spindle. Install lynch pin through castor spindle to retain all parts in place.

**IMPORTANT:** When bushings are installed, the inside diameter may collapse slightly, and this may not allow castor spindle to be installed. If castor spindle does not slide through new bushings and mounting tube, ream both bushings to inside diameter of 1.126 inches (28.6 mm).

## SERVICING CASTOR WHEEL AND BEARING

The castor wheel rotates on a high-quality roller bearing and is supported by a spanner bushing. Even after many hours of use, provided that the bearing was kept well-lubricated, bearing wear will be minimal. However, failure to keep bearing lubricated will cause rapid wear. A wobbly castor wheel usually indicates a worn bearing.

1. Remove locknut from capscrew holding castor wheel assembly between castor fork (Fig. 20). Grasp castor wheel and slide capscrew out of fork.




Figure 20

**Note:** Account for the two thrust washers (Fig. 20).

2. Tip wheel to the side and allow spanner bushing to fall out (Fig. 20).
3. Inspect bearing, spanner bushing and wheel for wear. Replace defective parts.
4. To reassemble parts, slide spanner bushing through hub.
5. Mount castor wheel assembly and washers between the fork and secure with capscrew and locknut. Tighten capscrew and locknut until spanner housing and washers bottoms against inside of castor fork.
6. Pump more grease through grease fitting on wheel (Fig. 20) until bearing is greased thoroughly.

## CHECKING FOR BENT BLADE

1. Raise cutting unit, engage parking brake, be sure traction pedal is in neutral, PTO lever is in OFF position, stop engine and remove key from switch. Block cutting unit to prevent it from falling accidentally.

2. Rotate blade until the ends face forward and backward (Fig. 21). Measure from inside of cutting unit to cutting edge at front of blade (Fig. 21), and remember this dimension.




Figure 21

# CUTTING UNIT MAINTENANCE

3. Rotate opposite end of blade forward. Measure between the cutting unit and cutting edge of blade at the same position as in step 2. The difference between dimensions obtained in steps 2 and 3 must not exceed 1/8 of an inch (3 mm). If dimension exceeds 1/8 of an inch (3 mm), replace the blade because it is bent: refer to Removing Cutter Blade, page 15.

## REMOVING CUTTER BLADE

The blade must be replaced if a solid object is hit, the blade is out-of-balance or if the blade is bent. Always use genuine TORO replacement blades to be sure of safety and optimum performance. Never use replacement blades made by other manufacturers because they could be dangerous.



### WARNING

Do not try to straighten a blade that is bent, and never weld a broken or cracked blade. Always use a new blade to assure safety.

1. Raise cutting unit to its highest position, engage parking brake, be sure traction pedal is in neutral, PTO lever is in OFF position and shut engine off. Block cutting unit to prevent it from falling accidentally.
2. Grasp end of blade using a rag or thickly padded glove. Remove bladebolt, flatwasher, antiscalp cup and blade from spindle shaft (Fig. 22).
3. In sequence, install blade — sail facing toward cutting unit — and anti-scalp cup. Secure parts in place with bladebolt and flatwasher. Tighten cap-screw to 85-110 ft-lb.

## CHECKING SAIL AND SHARPENING CUTTER BLADE

Two areas must be considered when checking and servicing the cutter blade: one area is the sail, the other is the cutting edge. Both cutting edges and the sail, which is the turned up metal opposite the cutting edge, contribute to a good quality-of-cut. The sail is important because it pulls grass up straight, thereby producing an even cut. However,

the sail will gradually wear down during operation, and this condition is normal. As the sail wears down, the quality-of-cut will degrade somewhat, although the cutting edges are sharp. The cutting edges of the blade must be sharp so the grass is cut rather than torn. A dull cutting edge is evident when tips of the grass appear brown and shredded. Sharpen the cutting edges to correct this condition.




Figure 22

1. Raise cutting unit to its highest position, engage parking brake, be sure traction pedal is in neutral, PTO lever is in OFF position, stop engine and remove key from switch. Block cutting unit to prevent it from falling accidentally.
2. Examine cutting ends of the blade carefully, especially where the flat and curved parts of the blade meet (Fig. 23). Since sand and abrasive material can wear away the metal that connects the flat and curved parts of the blade, check the blade before using the mower. If wear is noticed (Fig. 23), replace the blade.



### DANGER

If blade is allowed to wear, a slot will form between the sail and flat part of the blade. (Fig. 23-3). Eventually, a piece of the blade may break off and be thrown from under the housing, possibly resulting in serious injury to yourself or bystander.

# CUTTING UNIT MAINTENANCE




Figure 23




Figure 24

3. Inspect cutting edges of all blades. Sharpen the cutting edges if they are dull or nicked. Sharpen only the top side of the cutting edge and maintain the original cutting angle to make sure of sharpness (Fig. 24). The blade will remain balanced if same amount of metal is removed from both cutting edges.

**Note:** Remove the blades and sharpen them on a grinder: refer to Removing Cutter Blade, steps 1 and 2, page 15. After sharpening the cutting edges, reinstall blade and anti-scalp cup with bladebolt and flatwasher. Blade sails must be on top of blade. Tighten bladebolt to 85-110 ft-lb.

4. Remove blocking from cutting unit and lower it to the ground.

## CORRECTING CUTTING UNIT MISMATCH

If one cutter blade cuts lower than the others, correct as follows:

1. Lower cutting unit onto level surface, engage parking brake, be sure traction pedal is in neutral, PTO lever is in OFF position and shut engine off.
2. Check to make sure front height-of-cut pins are resting properly on frame cushions (Fig. 27). If pins are not resting properly, place a shim or shims under cushion to raise it for proper alignment.
3. Raise height-of-cut to 4 in. (102 mm) position (Fig. 27); refer to Adjusting Height-Of-Cut, page 9.

4. Rotate blades so tips line up with one another. Tips of the adjacent blades must be within 1/8 in. (3 mm) of each other. If tips are not within 1/8 in. (3 mm) of each other, proceed to step 8 and add shims between spindle housing and bottom of cutting unit.

5. Position all three blades in the "A" position (Fig. 25) and measure from level surface to the bottom of the tip end of each blade (Fig. 26).




Figure 25




Figure 26

6. Note measurement attained at "A", rotate blades to "B" position (Fig. 25), measure distance of all blades to level surface and note dimensions (Fig. 26).

7. Rotate blades to "C" position, measure and note distance measured (Fig. 25, 26).

8. Compare measurements at various positions. All dimensions must be equal within 1/4 in. (6 mm) from one another. The difference between dimensions must not exceed 1/4 in. (6 mm). If difference exceeds 1/4 in. (6 mm), proceed to step 8 and 9 and add shims between spindle housing and bottom of cutting unit.

9. Remove capscrews and locknuts from outer spindle in the area where shims must be added. To raise or lower the blade, add a shim, Part No. 3256-24, between spindle housing and bottom of cutting unit. Continue checking alignment of blades and adding shims until tips of blades are within the required dimension. Install capscrews and locknuts and tighten to 20-27 ft-lb.

10. Equalize side to side measurements as follows:

- A. Cutting units usually operated at 1 to 2 in. (25 to 51 mm) height-of-cut should have the low side of the cutting unit raised. Remove the lynch pin securing castor wheel on low end (Fig. 25) and remove castor assembly.



# CUTTING UNIT MAINTENANCE




Figure 27




Figure 28

- B. Transfer one thrust washer from top side of castor shaft to lower side, install castor assembly and compare blade height of all blades; refer to items 3 through 6. Continue adding thrust washers if height still does not meet requirements.
- C. If cutting unit is operated at 2 to 4 in. (51 to 102 mm) height-of-cut, lower the high side of cutting unit. Remove lynch pin of castor at high end of unit and remove castor assembly (Fig. 27).
- D. Transfer one thrust washer from lower side of castor shaft to top side, install assembly and compare blade height of all blades; refer to items 3 through 6. Repeat procedure if height still does not meet requirements.
- E. If height is within specified dimension, install lynch pin, set height-of-cut to proper height and resume operation.

## REPLACING GRASS DEFLECTOR

1. Raise cutting unit to its highest position, engage parking brake, be sure traction pedal is in neutral, PTO lever is in OFF position, stop the engine and remove key from switch. Block cutting unit to prevent it from falling accidentally.
2. Remove two capscrews, locknuts and springs securing deflector mounts to pivot brackets (Fig. 28).
3. To remove the pivot brackets, remove carriage bolts and nuts (Fig. 28).

4. Reinstall pivot brackets on top of discharge opening with carriage bolts and nuts. Head of carriage bolts must be on inside of cutting unit.

5. Position deflector mounts on outside of pivot brackets and secure parts together with capscrews, locknuts and springs. Both locknuts must face each other. Tighten locknuts until they are flush against deflector pivots. Lift deflector and allow it to drop to check spring tension. Deflector must be held firmly in full downward position by spring tension. Correct if necessary.

6. Remove blocking from cutting unit and lower it to the floor.

## ADJUSTING IDLER PULLEY

The idler pulley applies force against the belt so power can be transmitted to the blade pulleys. If the idler is not tensioned against the belt with sufficient force, maximum power will not be transmitted to the pulleys. Initial tension on a new belt requires 25 to 30 ft-lb (34 to 40.7 N·m) of torque on the large nut, which applies force against the belt. As the belt wears and loosens, 20 to 25 ft-lb (27.2 to 34 N·m) of torque on the nut is required. If the idler is not adjusted to these specifications, adjustment is necessary.

1. Lower cutting unit, engage parking brake, be sure traction pedal is in neutral position, PTO lever is in OFF position, stop engine and remove key from switch.

# CUTTING UNIT MAINTENANCE

2. Unhook latches securing right hand cover to top of cutting unit. Remove cover from cutting unit.

3. Loosen two nuts securing idler plate in place (Fig. 29). Using a socket and torque wrench, tighten the idler adjusting nut (Fig. 29) until proper torque value is achieved.




Figure 29

1. Idler plate      2. Flange locknut      3. Idler adjusting nut

4. Hold the torque against the belt and tighten the two nuts so idler plate is held securely in place (Fig. 29). Release the idler adjusting nut. Install cover and secure latches.

## REPLACING DRIVE BELT

The blade drive belt, tensioned by the adjustable idler, is very durable. However, after many hours of use, the belt will show signs of wear. Signs of a worn belt are: squealing when belt is rotating, blades slipping when cutting grass, frayed edges, burn marks and cracks. Replace the belt if any of these conditions are evident.

1. Lower cutting unit to the floor, engage parking brake, be sure traction pedal is in neutral, PTO lever is in OFF position and stop the engine and remove key from switch.

2. Unhook latches securing left and right covers to top of cutting unit.

3. Loosen two nuts securing idler plate in place (Fig. 29) and remove old belt from pulleys.

4. To install new belt, the gear box base must be removed. To do this, remove four nuts holding gear box base to cutting unit.

5. Install new belt around gear box pulley, spindle pulleys and idler pulley (Fig. 30).

6. Install gear box base with nuts.

7. Using a torque wrench, adjust tension of idler pulley against the belt: refer to Adjusting Idler Pulley, page 17.




Figure 30

8. Reinstall covers and secure latches.

9. Remove blocking and lower cutting unit to the ground.

# IDENTIFICATION AND ORDERING

## MODEL AND SERIAL NUMBERS

The cutting unit has two identification numbers: a model number and a serial number. These numbers are stamped into a plate. The cutting unit identification plate is located behind the right front caster wheel (Fig. 31). In any correspondence concerning the cutting unit, supply the model and serial numbers to assure correct information and replacement parts are obtained.

To order replacement parts from an authorized TORO Proline Dealer, supply the following information:

1. Model and serial numbers of the cutting unit.

2. Part number, description and quantity of parts desired.

**Note:** Do not order by reference number if a parts catalog is being used; use the part number.




Figure 31

1. Model and serial number

## SERVICE INTERVAL CHART

Date									
Hour Meter Reading									
Service Interval	↓	Daily	10	50	100	150	200	250	300
Check Blades	Daily								
Lubricate Caster Arm Bushings	Daily								
Lubricate Caster Wheel Bearings	Daily								
Lubricate Grease Fittings	50								
Clean Cutting Unit	50								
Check Blade Drive Belts	50								
Check Gear Box Oil	50								
Change Gear Box Oil	250								

Date									
Hour Meter Reading									
Service Interval	↓	350	400	450	500	550	600	650	700
Check Blades	Daily								
Lubricate Caster Arm Bushings	Daily								
Lubricate Caster Wheel Bearings	Daily								
Lubricate Grease Fittings	50								
Clean Cutting Unit	50								
Check Blade Drive Belts	50								
Check Gear Box Oil	50								
Change Gear Box Oil	250								

## SERVICE SPECIFICATIONS:

Cutting Unit Gear Box Oil — 80-90 wt. Gear Lube



ProLine  
Products

## THE TORO TOTAL COVERAGE GUARANTEE

A One Year Limited Warranty  
(A Full Two-Year Warranty for Residential Use)

### What Is Covered By This Express Warranty?

The Toro Company promises to repair any TORO ProLine product used for commercial, institutional, or rental purposes if defective in materials or workmanship for a period of one year from the date of purchase. The cost of parts and labor are included as well as transportation within a 15 mile radius of a TORO ProLine Service Dealer.

### What Products Are Covered By This Warranty?

ProLine products covered by this warranty include the ProLine riding products and wide area walk behind mowers and their cutting decks and accessories.

### How About Residential Use?

TORO ProLine products used for residential use are covered by a full two-year warranty.

### How Do You Get Warranty Service?

Should you feel your TORO ProLine product contains a defect in materials or workmanship, contact the dealer who sold you the product or any TORO ProLine Service Dealer. The Yellow Pages of your telephone directory is a good reference source; look under TORO Commercial Service Dealers. The Service Dealer will either arrange service at his/her dealership or recommend another authorized Service Dealer who may be more convenient. You may need proof of purchase (copy of registration card, sales receipt, etc.) for warranty validation.

If for any reason you are dissatisfied with a Service Dealer's analysis of the defect in materials or workmanship or if you need a referral to a TORO ProLine Service Dealer, please feel free to contact us at the following address:

Toro Customer Service Department  
8111 Lyndale Avenue South  
Bloomington, MN 55420-1196  
612-888-8801

### What Must You Do To Keep The Warranty In Effect?

You must maintain your TORO Product by following the maintenance procedures described in the operator's manual. Such routine maintenance, whether performed by a dealer or by you, is at your expense.

### What Does This Warranty Not Cover? and

### How Does Your State Law Relate To This Warranty?

There is no other express warranty except as described above. This express warranty does not cover:

- Cost of regular maintenance service or parts, such as filters, fuel, lubricants, tune-up parts, blade sharpening, brake and clutch adjustments.
- Any product or part which has been altered or misused or required replacement or repair due to normal wear, accidents, or lack of proper maintenance.
- Repairs necessary due to improper fuel, contaminants in the fuel system, or failure to properly prepare the fuel system prior to any period of non-use over three months.
- Pickup and delivery charges for distances beyond a 15 mile radius from a TORO ProLine Service Dealer.

All repairs covered by this warranty must be performed by a TORO Service Dealer using Toro approved replacement parts.

Repair by a TORO Service Dealer is your sole remedy under this warranty.

**The Toro Company is not liable for indirect, incidental or consequential damages in connection with the use of the TORO Products covered by this warranty, including any cost or expense of providing substitute equipment or service during reasonable periods of malfunction or non-use pending completion of repairs under this warranty. Some states do not allow exclusions of incidental or consequential damages, so the above exclusion may not apply to you.**

**This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.**

### COUNTRIES OTHER THAN THE UNITED STATES OR CANADA

Customers who have purchased TORO products exported from the United States or Canada should contact their TORO Distributor (Dealer) to obtain guarantee policies for your country, province, or state. If for any reason you are dissatisfied with your Distributor's service or have difficulty obtaining guarantee information, contact the TORO importer. If all other remedies fail, you may contact us at The Toro Company.