



ProLine Mid-Size

16 HP Traction Unit

Model No. 30182 – 690001 & Up

Operator's Manual

IMPORTANT: Read this manual carefully. It contains information about your safety and the safety of others. Also become familiar with the controls and their proper use before you operate the product.

FOREWORD

The Proline mid size mowers have advanced concepts in engineering, design and safety; and if maintained properly, will give excellent service.

Since this is a high-quality product, Toro is concerned about the future use of the machine and safety of the user. Therefore, read this manual to familiarize yourself with proper set-up, operation and maintenance instructions. The major sections of the manual are:


- | | | |
|------------------------|---------------------|----------------|
| 1. Safety Instructions | 3. Before Operating | 5. Maintenance |
| 2. Set-up Instructions | 4. Operation | |

Certain information in this manual is emphasized. DANGER, WARNING and CAUTION identify personal safety related information. IMPORTANT identifies mechanical information demanding special attention. Be sure to read this directive because it deals with the possibility of damaging a part or parts of the machine. NOTE identifies general information worthy of special attention.

TABLE OF CONTENTS

	Page		Page
SAFETY INSTRUCTIONS	1-2	Replacing Fuel Filter	11
SAFETY AND INSTRUCTION DECALS	3	Replacing Spark Plugs	11
SPECIFICATIONS	3	Adjusting Choke Control	12
LOOSE PARTS	4	Adjusting Throttle Control	12
SET-UP INSTRUCTIONS	4-7	Replacing Traction Belt	12
BEFORE OPERATING	8	Adjusting Clutch	12
CONTROLS	9	Adjusting Brake	13
OPERATING INSTRUCTIONS	9	Replacing Drive Belt	13
MAINTENANCE	10-13	Cleaning Cooling System	13
Grease Wheels	10	WIRING SCHEMATIC	14
Grease Transmission Couplers	10	IDENTIFICATION AND ORDERING	14
Servicing Air Cleaner	10	ENGINE OWNER'S MANUAL	14
Changing Crankcase Oil and Filter	10	THE TORO PROMISE	15

SAFETY INSTRUCTIONS



This cutting unit has been tested and certified for compliance with the B71.4-1990 specifications of the American National Standards Institute. Although hazard control and accident prevention partially are dependent upon the design and configuration of the machine, these factors are also dependent upon awareness, concern, and proper training of the personnel involved in the operation, transport, maintenance, and storage of the machine. Improper use or maintenance of the machine can result on injury or death. To reduce the potential for injury or death, comply with the following safety instructions.

WARNING: Engine exhaust contains carbon monoxide which is an odorless, deadly poison. Carbon monoxide is also known to the State of California to cause birth defects. Do not run engine indoors or in an enclosed area.

BEFORE OPERATING

1. Read and understand the contents of this Operator's Manual before operating the machine. Become familiar with all controls and know how to stop quickly. A free replacement manual is available by sending complete Model and Serial Number to:

The Toro Company
8111 Lyndale Avenue South
Bloomington, Minnesota 55420-1196

2. Never allow children to operate the machine. Do not allow adults to operate machine without proper instruction. Only trained operators who have read this manual should operate this machine.

3. Never operate the machine when under the influence of drugs or alcohol.

4. Before attempting to start engine, shift into neutral and lock parking brake.

5. Remove all debris or other objects that might be picked up and thrown by the cutter blades. Keep all bystanders away from the mowing area.

6. Do not operate unless all shields and safety devices are in place. If a shield, safety device or decal is illegible or damaged, repair or replace it before operation is commenced. Also tighten any loose nuts, bolts and screws to assure machine is in safe operating condition.

SAFETY INSTRUCTIONS

7. Do not operate machine while wearing sandals, tennis shoes, sneakers or shorts. Also, do not wear loose fitting clothing which could get caught in moving parts. Always wear long pants and substantial shoes. Wearing safety glasses, safety shoes and a helmet is advisable and required by some local ordinances and insurance regulations.

8. Fill fuel tank with gasoline before starting the engine. Avoid spilling gasoline. Since gasoline is flammable, handle it carefully.

- A. Use an approved gasoline container.
- B. Do not fill tank while engine is hot or running.
- C. Do not smoke while handling gasoline.
- D. Fill fuel tank outdoors and up to about one inch (25 mm) from top of the tank, not the filler neck.
- E. Wipe up any spilled gasoline.

WHILE OPERATING

9. Start engine when parking brake is set, blade is disengaged, and transmission is in neutral.

10. Do not run the engine in a confined area without adequate ventilation. Exhaust fumes are hazardous and could possibly be deadly.

11. Using the machine demands attention, and to prevent loss of control:

- A. Mow only in daylight or when there is good artificial light.
- B. Watch for holes or other hidden hazards.
- C. Do not drive close to a sand trap, ditch, creek or other hazard.
- D. Reduce speed when making sharp turns and when turning on hillsides.

12. Do not operate unless grass deflector, Recycler® cover or entire grass collector is installed. The grass deflector must always be installed and in lowest position on the side discharge cutting unit. This product is designed to drive objects into the ground where they lose energy quickly in grassy areas. **However, don't take an injury risk!!** When a person or pet appears unexpectedly in or near the mowing area, **STOP MOWING**. Careless operation, combined with terrain angles, ricochets, or improperly positioned guards, can lead to thrown object injuries. Do not resume mowing until area is cleared.

13. Never raise the cutting unit while the blades are rotating.

14. If the cutting blades strike a solid object or the machine vibrates abnormally, shut the engine off. Remove spark plug wire from spark plug to prevent possibility of accidental starting. Check cutting unit and traction unit for damage and malfunctioning parts. Repair any damage before restarting the engine and operating the cutting unit. Be sure blades are in good condition and blade bolts are tight.

15. Cut grass slopes carefully. Do not start, stop, or turn suddenly.

16. Do not touch engine or muffler while engine is running or soon after it is stopped. These areas could be hot enough to cause a burn.

17. Before leaving the operator's position — behind handle or leaving mower unattended, shift transmission into NEUTRAL, apply parking brake, release control bail and shut OFF engine.

MAINTENANCE

18. Disconnect spark plug wire from spark plug to prevent accidental starting of the engine when servicing, adjusting or storing the machine.

19. If traction unit and mower must be tipped to perform maintenance or an adjustment, drain gasoline from fuel tank and oil from crankcase.

20. When driving unit forward, always use upper "Forward" traction drive handle. When backing up, always use lower "Reverse" traction drive handle.

21. To reduce potential fire hazard, keep the engine free of excessive grease, grass, leaves and accumulations of dirt.

22. Be sure machine is in safe operating condition by keeping nuts, bolts and screws tight. Check the blade mounting bolts and nuts frequently to be sure they are tightened to specification.

23. If the engine must be running to perform a maintenance adjustment, keep hands, feet, clothing and other parts of the body away from the cutting unit blades and other moving parts.

24. Do not overspeed the engine by changing governor settings. To be sure of safety and accuracy, have an Authorized TORO ProLine Service Dealer check maximum engine speed with a tachometer.

25. Engine must be shut off before checking oil or adding oil to the crankcase.

26. Allow engine to cool before storing mower in any enclosure such as a garage or storage shed. Make sure the mower fuel tank is empty if machine is to be stored in excess of 30 days. Do not store mower near any open flame or where gasoline fumes may be ignited by a spark. Always store gasoline in a safety — approved, red metal container.

27. Perform only those maintenance instructions described in this manual. If major repairs are ever needed or assistance is desired, contact an Authorized Toro ProLine Service Dealer. At the time of manufacture, the machine conformed to the safety standards in effect. To ensure optimum performance and continued safety conformance of the machine, use genuine TORO replacement parts and accessories. Replacement parts and accessories made by other manufacturers may result in non-conformance with safety standards and could void the warranty.

SAFETY AND INSTRUCTION DECALS


The following decals are installed on the machine. If any become damaged or illegible, replace it. The decal part number is listed below and in your parts catalog. Replacement can be ordered from your Authorized Toro Distributor.



ON UPPER CONTROL BAR
(Part No. 82-2290)



ON LOWER CONTROL BAR
(Part No. 82-2280)



ON CONTROL PANEL
(Part No. 82-7740)




ON CONTROL PANEL
(Part No. 71-1280)




ON PARKING BRAKE LEVER
(Part No. 52-2010)



ON REAR FRAME
(Part No. 74-0490)



ON CONTROL PANEL
(Part No. 65-3090)



ON CONTROL PLATE
(Part No. 82-7750)

SPECIFICATIONS

16 hp Briggs & Stratton Engine: four cycle, recoil start with automatic compression release, vertical shaft engine has output of 16 hp @ 3600 RPM and 26 ft-lb torque @ 2600 RPM. Displacement is 29.3 cubic inches. Crankcase oil capacity is 4 pints with filter. Fuel tank capacity is 5 gallons. Correct spark plug is Champion RC12 YC or equivalent. Spark arrester muffler.

Frame: 11 ga. formed steel box with 1 in. dia. axle with 1/4" x 4 U-strap rear frame bolted to frame.

Wheels and Tires: 6.5 x 16 pneumatic tires are mounted on welded steel wheels which have greaseable ball bearings. Recommended tire pressure is 15 psi.

Transmission: Permanently lubricated and fully enclosed gear box. In line shift pattern with 4 forward speeds, neutral and reverse.

Traction Drive Belts: A-section, V-belt with 3 in. dia. take up idler to gear box from engine. 2 rib A-section banded belt to each wheel from gear box output shafts.

Gear Drive Reduction:

- 1st gear - 7.0
- 2nd gear - 4.5
- 3rd gear - 3.5
- 4th gear - 3.0
- Rev. - 6.0

Ground Speed @ 3200 Engine rpm:

- 1st gear - 2.2 MPH
- 2nd gear - 3.5 MPH
- 3rd gear - 4.5 MPH
- 4th gear - 5.2 MPH
- Rev. - 2.5 MPH

Optional Accessories:

- Sulky attachment, Model #30122
- Sulky attachment, Model #30123
- Lift Kit Part No. 84-5010 *

Specifications and design subject to change without notice.

LOOSE PARTS

NOTE: Use this chart as a checklist to assure all parts have been received. Without these parts, total set-up cannot be completed.

DESCRIPTION	QTY.	USE
Upper handle	1	Install upper handle to frame
Flange capscrew 3/8–16 x 1" lg.	4	
Flangenut 3/8–16	4	
Shift lever	1	Install shift lever to transmission
Shift lever mounting block	1	
Plain washer (thick black)	1	
Capscrew 1/4–28 x 2" lg.	1	
Rod fitting	2	Install control rods
Clevis pin	2	
Washer	2	
Hairpin cotter	2	
Fuel tank	1	Install fuel tank and control panel
Control panel	1	
Capscrew 5/16–1/ x 7/8" lg.	4	
Lockwasher 5/16"	4	
Flatwasher 5/16"	4	
Hose clamp	2	
Exhaust deflector	1	Install on muffler
Screws (small tapping)	4	
Cable tie	1	Secure wire harness to frame
Operator's Manual	1	Read before operating machine
Parts catalog	1	
Registration card	1	Fill out and return to Toro

SET-UP INSTRUCTIONS

MOUNT FUEL TANK AND CONTROL PANEL

1. Place fuel tank onto rear frame and align mounting holes (Fig. 1).




Figure 1

1. Fuel tank
2. Rear frame
3. Control panel
4. Capscrews, lockwashers, and flatwashers
5. Slots for adjustment

2. Loosely mount control panel to bottom of rear frame and fuel tank with (4) capscrews, lockwashers, and flatwashers (Fig. 1). Do not tighten capscrews.

3. Remove cap from fuel filter. Secure fuel line to fuel filter, using the hose clamp. (Fig. 6).

INSTALL SHIFT LEVER

1. Position shift lever mounting block onto shaft on top of transmission. DO NOT remove rubber washer on transmission.

2. Insert shift lever thru slot in control panel and align mounting hole in lever with mounting block on transmission. Secure lever to transmission with 1/4–28 x 2" lg. capscrew and thick, black washer. Torque capscrew to 100–125 in – lb (Fig. 2).

SET-UP INSTRUCTIONS




Figure 2

1. Shift lever
2. Control panel
3. Mounting block
4. Capscrew and thick, black washer

3. Move shift lever to reverse and 4th gear. Control panel mounting holes are slotted to enable it to be moved from side to side (Fig. 1). Position control panel as needed to achieve full shift range. Tighten mounting screws to a maximum of 90 in.-lb. **DO NOT OVER TIGHTEN.**

INSTALL UPPER HANDLE

1. Align upper handle mounting holes with desired mounting holes in frame (upper or lower set of holes) and secure each side with (two) 3/8 - 16 x 1" lg. flange capscrews and flange nuts. Tighten capscrews to 23-27 ft.-lbs. Route cables and wire harness inside of frame (Fig. 3).




Figure 3

1. Upper handle
2. Frame
3. Wire harness
4. Cables

CONNECT THROTTLE CABLE

1. Route throttle cable around right side of engine (Fig. 4).

5

2. Move throttle lever on control panel to FAST position.
3. Hook Z-bend at end of throttle wire into throttle arm (Fig. 4).
4. Loosen cable clamp screw and insert throttle cable behind the cable clamp (Fig. 4).
5. Pull slightly on the throttle cable to remove any slack and tighten the clamp (Fig. 4).




Figure 4

1. Throttle cable
2. Z-bend hooked in throttle arm
3. Screw
4. Cable clamp
5. Choke cable
6. Z-bend hooked in choke arm
7. Screw
8. Cable clamp

CONNECT CHOKE CABLE

1. Route choke cable around left side of engine (Fig. 4).
2. Move choke lever on control panel to CHOKE position.
3. Hook Z-bend at end of choke wire into choke arm (Fig. 4).
4. Loosen cable clamp screw and insert choke cable behind the cable clamp (Fig. 4).
5. Pull slightly on the choke cable to remove any slack and tighten the clamp screw (Fig. 4).

CONNECT WIRE HARNESS

1. Route wire harness along the inside of the left handle.
2. Push the rectangular connector together (Fig. 5).
3. Route the other part of the wire harness around to the right side of the engine. Push the red wire connectors together (Fig. 6). Secure the black ground wire with the small O-ring connector to the terminal on the engine, using the #8 nut (Fig. 6). Also secure the other black ground wire with the large O-ring connector to the engine mount, using the 5/16" nut (Fig. 6).

SET-UP INSTRUCTIONS

- Secure the wire harness to the handle frame, using the cable tie (Fig. 5).




Figure 5

- Wire harness
- Rectangular connectors
- Cable tie




Figure 6

- Red wire connectors
- Black wire/small connector
- Black wire/large connector
- Fuel filter
- Hose clamp

INSTALL CONTROL RODS

- Thread a rod fitting onto each control rod approximately 2" (Fig. 7) or until upper control rod (Fig. 8) is perpendicular to ground.




Figure 7

- Control rod fitting
- Idle brackets
- Clevis pin, washer & hairpin cotter

- Mount rod fitting ends to mounting holes in idler brackets (from outside) with clevis pins, washers and hairpin cottes (Fig. 7).

- Check gap between control bar and upper handle when fully engaging wheel belts. Gap should be approximately 1 to 1-1/4" (Fig. 8).

Note: The control bar and upper handle must be parallel when in relaxed, drive and brake positions.

- Check operation. If adjustment is required, remove hairpin cotter and washer securing end of control rod to upper control bar, thread rod into or out of rod fitting to proper position and reinstall to control bar with washer and hairpin cotter.

- Brake rods should be adjusted so parking brake lever can be swung into a snug position against the upper handle while pulling back on upper control bar (Fig. 8).

SET-UP INSTRUCTIONS




Figure 8

- 1. Control rod
- 2. Upper control bar
- 3. Hairpin cotter
- 4. Parking brake lever

6. If an adjustment to brake rods is required, remove hairpin cotter and washer securing brake rod fitting to idler bracket (Fig. 9).




Figure 9

- 1. Idler bracket
- 2. Brake rod fitting
- 3. Hairpin cotter & washer
- 4. Wing nut

7. Adjust wing nut up or down on brake rod and resecure to idler bracket. Check adjustment and readjust if necessary.

Note: Make sure brake rod is installed in forward ("F") mounting hole in idler bracket.

8. Repeat procedure on opposite side if adjustment is required.

INSTALL EXHAUST DEFLECTOR

Mount exhaust deflector to muffler, using four mounting screws (Fig. 10).




Figure 10

- 1. Exhaust deflector
- 2. Screws (4)

BEFORE OPERATING

FILL CRANKCASE WITH OIL

Crankcase capacity is 56 oz. with new filter, 48 oz. if filter is not changed.

The engine does not have oil in the crankcase when it is shipped from the factory. If engine is started before oil is added to the crankcase, engine damage could result. Therefore, before engine is started for the first time:

1. Position mower on level surface.
2. Clean area around the oil dipstick to prevent foreign matter from entering the filler hole when dipstick is removed.
3. Unscrew the dipstick (Fig. 11).




Figure 11

1. Dipstick
2. Filler neck

4. Slowly pour approximately 4 pints of oil into the filler neck (Fig. 11). The engine uses any high quality detergent oil having the American Petroleum Institute —API— “service classification” SE, SF, or SG. The recommended oil to use is SAE 30 above 40°F and 10W30 or 5W40 below 40°F.

5. Wipe end of dipstick with clean rag and screw it onto the filler neck. Then unscrew the dipstick and check level of oil by reading the dipstick (Fig. 10). If level of oil is low, add only enough oil to raise level to FULL mark on dipstick. **DO NOT ADD OIL SO LEVEL RISES ABOVE FULL MARK BECAUSE ENGINE COULD BE DAMAGED WHEN IT IS STARTED.**

6. Screw dipstick onto filler neck tightly.

Note: Check level of oil after every 5 operating hours or each time the mower is used. Initially, change oil after the first 5 hours of operation; thereafter, when conditions are normal, change oil after every 50 hours of operation. However, change oil more frequently when mower is operated in dusty or dirty conditions.

CHECK TIRE PRESSURE

Tires are over inflated at the factory. Check tires and insure they are inflated to 15 psi.

FILL FUEL TANK WITH GASOLINE

THE TORO COMPANY STRONGLY RECOMMENDS THE USE OF FRESH CLEAN, UNLEADED REGULAR GRADE GASOLINE. UNLEADED GASOLINE BURNS CLEANLY, EXTENDS ENGINE LIFE, AND PROMOTES GOOD STARTING.

NOTE: NEVER USE METHANOL, GASOLINE CONTAINING METHANOL, GASOHOL CONTAINING MORE THAN 10% ETHANOL, GASOLINE ADDITIVES, PREMIUM GASOLINE, OR WHITE GAS BECAUSE THE FUEL SYSTEM COULD BE DAMAGED.

1. Clean area around fuel tank cap and remove cap from tank.
2. Fill fuel tank to about 1 inch from top of the tank, not filler neck. Install fuel tank cap securely.
3. Wipe up spilled gasoline.



DANGER

Because gasoline is flammable, caution must be used when storing or handling it. Do not fill fuel tank while engine is running, hot or when machine is in an enclosed area. Vapors may build up and be ignited by a spark or flame source many feet away. **DO NOT SMOKE** while filling the fuel tank to prevent the possibility of an explosion. Always fill fuel tank outside and wipe up any spilled gasoline before starting engine. Use a funnel or spout to prevent spilling gasoline before starting engine and fill tank to about one inch from top of tank, not filler neck. Store gasoline in a clean safety— approved container and keep the cap in place on the container. Keep gasoline in a cool, well—ventilated place; never in an enclosed area such as a hot storage shed. To assure volatility, do not buy more than a 30 day supply of gasoline. Gasoline is a fuel for internal combustion engines; therefore, do not use it for any other purpose. Since many children like the smell of gas, keep it out of their reach because the fumes are explosive and dangerous to inhale.

CONTROLS

Throttle Control (Fig. 12) – The throttle control has three positions: CHOKE, FAST and SLOW.

Deck Engagement Control Bail (Fig. 12) – Control bail used in conjunction with deck engagement switch to release blade brake and engage electromagnetic clutch to drive deck pulleys. Release bail to disengage deck pulleys.

Deck Engagement Switch (Fig. 12) – Rocker switch used in conjunction with control bail to release blade brake and engage electromagnetic clutch to drive deck pulleys.

Gear Shift Lever (Fig. 12) – Transmission has four forward speeds, neutral and reverse, and has an in-line shift pattern. Do not shift while unit is moving, as transmission damage may occur.

Upper Control Bar (Fig. 12) – Shift to desired gear and push forward on control bar to engage forward traction operation and pull back to brake. Pull right side of control bar to turn right and left side to turn left.

Lower Control Bar (Fig. 12) – Shift transmission to reverse and pull rearward on lower control bar to engage rearward traction operation.

Parking Brake Lever (Fig. 12) – Pull back on upper control bar and swing brake lever up against the upper handle.

Choke Control (Fig. 12) – Two positions: CHOKE and RUN.

Ignition Switch (Fig. 12) – Key switch is used in conjunction with recoil starter. Switch has two positions: RUN and OFF.

Recoil Starter – Pull recoil Starter handle to Start engine.

Fuel Shut-off Valve – (Under fuel tank) Close fuel shut-off valve when transporting or storing mower.




Figure 12

- | | |
|---------------------------------|------------------------|
| 1. Throttle control | 6. Lower control bar |
| 2. Deck engagement control bail | 7. Parking brake lever |
| 3. Deck engagement switch | 8. Ignition switch |
| 4. Gear shift lever | 9. Choke control |
| 5. Upper control bar | |

OPERATING INSTRUCTIONS

STARTING AND STOPPING

1. Make sure Spark plug wire is installed on spark plug and fuel shut-off valve is open.
2. Shift into neutral and turn ignition key to RUN.
3. Move throttle control to FAST position and choke control to CHOKE before starting a cold engine.

Note: A warm or hot engine usually does not require any choking. To start a warm engine, move throttle control to FAST position.

4. Grasp recoil starter handle firmly and pull out until positive engagement results; then pull handle vigorously to start engine and allow rope to rewind slowly.

IMPORTANT: Do not pull recoil rope to its limit or let go of the starter handle when rope is pulled out because rope may break or recoil assembly may be damaged.

5. When engine starts move choke control to RUN position.

6. To engage blade, squeeze deck engagement control bail against upper control bar and press rocker switch forward. Hold control bail against control bar while operating. Releasing control bail disengages deck pulleys. Repeat procedure to engage deck pulleys if control bail is released.

7. To stop engine, release control bail and control bar, shift to Neutral, move throttle to SLOW and turn ignition key to OFF. Wait for all parts to stop moving before leaving the operating position behind handle.

8. Pull wire off spark plug to prevent possibility of accidental starting before storing machine.

9. Close fuel shut off valve before transporting or storing machine because fuel may leak.

MAINTENANCE



CAUTION

To prevent accidental starting of the engine while performing maintenance, shut engine off. Also, pull both wires off spark plugs. Make sure wires do not contact plugs accidentally.

GREASE WHEELS

Lubricate the wheel bearings every 8 hours with No. 2 general purpose grease. Wipe up any excess grease.

GREASE TRANSMISSION COUPLERS

Lubricate the transmission couplers (Fig. 13) every 250 hours with No. 2 general purpose grease. Pump grease gun about 4 times. Wipe up any excess grease.




Figure 13

SERVICING AIR CLEANER

Service foam pre-cleaner every day. Replace paper cartridge after every 100 operating hours. Service the foam pre-cleaner and replace the paper cartridge more frequently when operating in extremely dusty and dirty conditions.

1. Pull out on the retaining tabs and remove the air cleaner cover (Fig. 14).




Figure 14

- | | |
|----------------------|--------------------|
| 1. Retaining tabs | 4. Paper cartridge |
| 2. Air cleaner cover | 5. Foam element |
| 3. Knob | |

2. Unscrew the knob and remove air cleaner assembly (Fig. 14).
3. Remove foam pre-cleaner by sliding it off the paper cartridge (Fig. 14).
4.
 - a. Wash foam pre-cleaner in solution of liquid soap and warm water. Squeeze foam to remove dirt. Do not twist the foam because it may tear.
 - b. Rinse foam pre-cleaner thoroughly until all soap suds are eliminated. Squeeze out excess water. Do not twist pre-cleaner.
 - c. Wrap foam pre-cleaner in a cloth and squeeze dry. Do not twist pre-cleaner.
 - d. Saturate foam pre-cleaner with engine oil. Squeeze to remove excess oil. A damp foam is desirable.
5. Clean paper cartridge by gently tapping its flat side against a flat surface. Replace the paper cartridge if it is very dirty.

IMPORTANT: Do not wash the paper element or use pressurized air, as damage will occur.

6. Install air cleaner assembly.

IMPORTANT: Always operate engine with air cleaner assembly installed or engine will be damaged.

CHANGING CRANKCASE OIL AND FILTER

1. Check level of oil before starting engine and after every 5 hours of operation. Maintain oil level at FULL mark on dipstick.

To Check Level of Oil:

- a. Position mower on level surface.
- b. Clean the area around oil dipstick so foreign matter cannot enter filler hole when dipstick is removed.
- c. Unscrew dipstick and wipe oil off with a clean rag.
- d. Screw dipstick back onto filler neck.
- e. Unscrew dipstick and check oil level. If level is low, add only enough oil to raise level to FULL mark. Do not overfill or engine damage may result.
- f. Screw dipstick back onto filler neck tightly.

2. Change oil after first 5 hours of operation; every 50 hours thereafter.

To Change Oil:

- a. Position mower on level surface. Start and run engine until the oil gets warm.
- b. Shut engine off. Place drain pan below drain plug (Fig. 15). Remove drain plug and allow all oil to flow into drain pan. Install drain plug after oil stops flowing.

MAINTENANCE

c. Remove dipstick and add oil to crankcase. Refer to Check Level of Oil, page 10. Capacity of crankcase is 4 pints when changing filter, 48 oz. when changing oil only. **DO NOT OVERFILL** because the engine may be damaged.

3. Change the oil filter after every 100 operating hours. To change filter:

a. Drain the oil from the engine crankcase, refer To Change Oil, page 10.




Figure 15
1. Drain plug

b. Remove the oil filter drain plug located at the base of the oil filter adapter (Fig. 16). Drain oil into pan.

c. Remove old filter and wipe off the filter adapter. Reinstall the filter drain plug.

d. Apply a thin coating of new oil to the rubber gasket on the new oil filter.




Figure 16
1. Drain plug
2. Oil filter

e. Install the new oil filter to the filter adapter. Tighten oil filter clockwise until the rubber gasket contacts the filter adapter, then tighten the filter an additional 1/4 turn. Fill the crankcase with fresh oil; refer to Fill Crankcase with Oil, page 8.

REPLACING FUEL FILTER

An in-line filter is in the fuel line between the fuel tank and carburetor (Fig. 6). Replace fuel filter once a year.

1. Place a drain pan under fuel filter.
2. Close fuel shut-off valve. Slide the hose clamps off the filter and separate the fuel lines from the filter (Fig. 6).



CAUTION

Since gasoline is highly flammable, drain it outdoors and make sure engine is cool to prevent a potential fire hazard. Wipe up any gasoline that may have spilled. Do not drain gasoline near any open flame or where gasoline fumes may be ignited by a spark. Do not smoke a cigar, cigarette, or a pipe when handling gasoline.

3. Install the new filter with arrow on the filter body pointing toward the carburetor.

REPLACING SPARK PLUGS

This engine has two spark plugs.

Since air gap between center and side electrodes of the spark plug increases gradually during normal operation of the engine, check condition of electrodes after every 50 operating hours. Recommended air gap is 0.040 of an inch (1.02 mm). Correct spark plug is a Champion RC 12YC.

Note: The spark plug usually lasts a long time; however, the plug should be removed and checked whenever the engine malfunctions.

1. Clean area around spark plug so foreign matter cannot fall into cylinder when spark plug is removed.
2. Pull spark plug wire off spark plug and remove plug from cylinder head.
3. Check condition of side electrode, center electrode, and center electrode insulator to assure there is no damage.

IMPORTANT: A cracked, fouled, dirty or otherwise malfunctioning spark plug must be replaced. Do not sand blast, scrape, or clean electrodes by using a wire brush because grit may eventually release from the plug and fall into the cylinder. The result is usually a damaged engine.

4. Set air gap between center and side of electrodes at 0.040 of an inch (1.02 mm) (Fig. 17). Install correctly gapped spark plug w/gasket seal, and tighten plug to 30 ft–lb (40 Nm). If torque wrench is not used, tighten plug firmly.

MAINTENANCE




Figure 17

ADJUSTING CHOKE CONTROL

The choke may need to be adjusted if the engine does not start, especially a cold engine.

Proper choke operation is dependent upon proper adjustment of the throttle control. Before adjusting the carburetor, assure the throttle control is operating properly.

1. Remove the air cleaner assembly.
2. Loosen cable clamp screw until choke cable is loose (Fig. 18).
3. Move choke lever on control panel to CHOKE position. Pull firmly on the choke cable until the choke plate inside the carburetor closes completely. Then tighten the screw to lock the adjustment.
4. Install the air cleaner assembly.




Figure 18

- | | |
|----------------|-------------------|
| 1. Screw | 3. Screw |
| 2. Choke cable | 4. Throttle cable |

ADJUSTING THROTTLE CONTROL

1. Loosen the cable clamp screw until the throttle cable is loose (Fig. 18).

2. Move throttle lever on control panel to FAST position. Pull slightly on the throttle cable and tighten the screw to lock the adjustment.

REPLACING TRACTION BELT

1. Raise the front of the machine and hold with jack stands.




Figure 19

- | | |
|--------------------|-------------------|
| 1. Traction belt | 4. Tension spring |
| 2. Idler pulley | 5. Adjusting nut |
| 3. Clutch retainer | 6. Pivot bolt |

2. Disconnect in-line wire connectors from wiring harness (Fig. 19).
3. Remove left front engine mounting bolt securing clutch retainer to frame. Unhook retainer from clutch and remove retainer (Fig. 19).
4. Unhook tension spring from side of frame (Fig. 19).
5. Loosen pivot bolt enough to remove traction belt from the drive pulley and clutch.
6. Install new belt around clutch and drive pulley.
7. Install belt around idler pulley (Fig. 19).
8. Torque pivot bolt to 35-40 ft-lb. Install tension spring between idler arm and frame bracket (Fig. 19).
9. Hook clutch retainer into clutch and secure to frame with engine mounting bolt. Torque engine mounting bolt to 170-220 in-lb.
10. Connect clutch in-line connector to wire harness.

ADJUSTING CLUTCH

The clutch is adjustable to ensure proper engagement and proper braking.

1. To adjust clutch, tighten or loosen locknuts on flange studs (Fig. 19).
2. Check adjustment by inserting feeler gauge thru slots next to flange studs.
3. The proper disengaged clearance between the clutch plates is .012 - .018 inches. It will be necessary to check this clearance at each of the three slots to ensure the plates are parallel to each other.

MAINTENANCE

ADJUSTING BRAKE

An adjustment to the brake may be required to compensate for belt stretching or brake seating.

1. To adjust brakes, refer to Install Control Rods, page 6.

REPLACING DRIVE BELT

1. Remove top capscrew securing idler support and idler bracket to rear frame (Fig. 20).




Figure 20

1. Idler bracket
2. Hairpin cotter, washer & brake rod fitting
3. Idler support
4. Top capscrew
5. Bottom capscrews


2. Loosen bottom two mounting screws enough to allow belt to pass between drive pulley and idler support (Fig. 20).

3. Raise wheel off ground enough to allow belt removal.

CLEANING COOLING SYSTEM

Clean engine cooling system after every 100 operating hours. Remove any build-up of grass, dirt or other debris from the cylinder and cylinder head cooling fins, air intake screen on flywheel end, and carburetor-governor levers and linkage. This will help insure adequate cooling and correct engine speed and will reduce the possibility of overheating and mechanical damage.

WIRING SCHEMATIC



IDENTIFICATION AND ORDERING

The mower has two identification numbers: a model number and a serial number. The two numbers are stamped into a plate that is riveted to the frame on right front corner of mower. In any correspondence concerning the mower, supply the model and serial numbers to assure that correct information and replacement parts are obtained.

To order replacement parts from an authorized TORO Distributor, supply the following information:

1. Model and serial numbers of the machine.
2. Part number, description and quantity of parts desired.

Note: Do not order by reference number if a parts catalog is being used; use the part number.

ENGINE OWNER'S MANUAL

The engine owner's manual supplied with this product contains information for California Emission Control Regulation related to emission systems, engine maintenance, and warranty. Information in the engine owner's manual should be used in place of information in this Toro operator's manual.

Keep the engine owner's manual with your product. Order a new manual from the engine manufacturer if you lose the manual or if it becomes damaged or illegible.



ProLine
Products

THE TORO TOTAL COVERAGE GUARANTEE

A One Year Limited Warranty
(A Full Two-Year Warranty for Residential Use)

What Is Covered By This Express Warranty?

The Toro Company promises to repair any TORO ProLine product used for commercial, institutional, or rental purposes if defective in materials or workmanship for a period of one year from the date of purchase. The cost of parts and labor are included as well as transportation within a 15 mile radius of a TORO ProLine Service Dealer.

What Products Are Covered By This Warranty?

ProLine products covered by this warranty include the ProLine 118, 120, 220, 616, 620, 724 riding products and wide area walk behind mowers and their cutting decks and accessories.

How About Residential Use?

TORO ProLine products used for residential use are covered by a full two-year warranty.

How Do You Get Warranty Service?

Should you feel your TORO ProLine product contains a defect in materials or workmanship, contact the dealer who sold you the product or any TORO ProLine Service Dealer. The Yellow Pages of your telephone directory is a good reference source; look under TORO Commercial Service Dealers. The Service Dealer will either arrange service at his/her dealership or recommend another authorized Service Dealer who may be more convenient. You may need proof of purchase (copy of registration card, sales receipt, etc.) for warranty validation.

If for any reason you are dissatisfied with a Service Dealer's analysis of the defect in materials or workmanship or if you need a referral to a TORO ProLine Service Dealer, please feel free to contact us at the following address:

Toro Customer Service Department
8111 Lyndale Avenue South
Bloomington, MN 55420-1196
612-888-8801

What Must You Do To Keep The Warranty In Effect?

You must maintain your TORO Product by following the maintenance procedures described in the operator's manual. Such routine maintenance, whether performed by a dealer or by you, is at your expense.

What Does This Warranty Not Cover? and

How Does Your State Law Relate To This Warranty?

There is no other express warranty except as described above. This express warranty does not cover:

- Cost of regular maintenance service or parts, such as filters, fuel, lubricants, tune-up parts, blade sharpening, brake and clutch adjustments.
- Any product or part which has been altered or misused or required replacement or repair due to normal wear, accidents, or lack of proper maintenance.
- Repairs necessary due to improper fuel, contaminants in the fuel system, or failure to properly prepare the fuel system prior to any period of non-use over three months.
- Pickup and delivery charges for distances beyond a 15 mile radius from a TORO ProLine Service Dealer.

All repairs covered by this warranty must be performed by a TORO Service Dealer using Toro approved replacement parts.

Repair by a TORO Service Dealer is your sole remedy under this warranty.

The Toro Company is not liable for indirect, incidental or consequential damages in connection with the use of the TORO Products covered by this warranty, including any cost or expense of providing substitute equipment or service during reasonable periods of malfunction or non-use pending completion of repairs under this warranty. Some states do not allow exclusions of incidental or consequential damages, so the above exclusion may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

COUNTRIES OTHER THAN THE UNITED STATES OR CANADA

Customers who have purchased TORO products exported from the United States or Canada should contact their TORO Distributor (Dealer) to obtain guarantee policies for your country, province, or state. If for any reason you are dissatisfied with your Distributor's service or have difficulty obtaining guarantee information, contact the TORO importer. If all other remedies fail, you may contact us at The Toro Company.