



Wheel Horse[®]
42'' Snowthrower
for
Classic Garden Tractors
Model No. 79360 – 7900001 & Up


Operator's Manual

IMPORTANT: Read this manual carefully. It contains information about your safety and the safety of others. Also become familiar with the controls and their proper use before you operate the product.

Introduction

We want you to be completely satisfied with your new product, so feel free to contact your local Authorized Service Dealer for help with service, genuine replacement parts, or other information you may require.

Whenever you contact your Authorized Service Dealer or the factory, always know the model and serial numbers of your product. These numbers will help the Service Dealer or Service Representative provide exact information about your specific product. You will find the model and serial number plate located in a unique place on the product as shown below.



1. Model and Serial Number Plate

For your convenience, write the product model and serial numbers in the space below.

Model No: _____
Serial No. _____

The warning system in this manual identifies potential hazards and has special safety messages that help you and others avoid personal injury, even death. DANGER, WARNING and CAUTION are signal words used to identify the level of hazard. However, regardless of the hazard, be extremely careful.

DANGER signals an extreme hazard that will cause serious injury or death if the recommended precautions are not followed.

WARNING signals a hazard that may cause serious injury or death if the recommended precautions are not followed.

CAUTION signals a hazard that may cause minor or moderate injury if the recommended precautions are not followed.

Two other words are also used to highlight information. “Important” calls attention to special mechanical information and “Note” emphasizes general information worthy of special attention.

The left and right side of the machine is determined by sitting on the seat in the normal operator’s position.

Contents

	Page		Page
Safety and Instruction Decals	2	Maintenance	18
Installation	5	Service Interval Chart	18
Loose Parts	5	Greasing and Lubrication	19
Assemble Housing	7	Adjusting Skids	20
Installing Snowthrower to Tractor	8	Reversing Scraper Blade	20
Removing the Snowthrower	11	Adjusting Drive Chain Tension	21
Operation	14	Storage	21
Operating the Power Take Off (PTO)	14	Troubleshooting	22
Attachment Lift Lever	15	Warranty	Back Cover
Attachment Power Lift	15		
Adjusting Dial-A-Height	16		
Adjusting Discharge Chute	16		
Tips for Throwing Snow	17		

Safety and Instruction Decals




Safety decals and instructions are easily visible to the operator and are located near any area of potential danger. Replace any decal that is damaged or lost.

**ON BACK OF HOUSING
LEFT SIDE
(Part No. 86-5100)**



**ON BACK OF HOUSING
(Part No. 92-8652)**



**ON BACK OF CHUTE
LEFT AND RIGHT SIDE (2)
(Part No. 63-3740)**



**ON BACK OF HOUSING
LEFT AND RIGHT SIDE (2)
(Part No. 63-2380)**



Installation

Loose Parts

Note: Use the chart below to identify parts used for assembly.

DESCRIPTION	QTY.	USE
Housing	1	Install frame and pulley
Frame with idlers	1	
Bolt 3/8–16 x 1"	4	
Locknut 3/8"	4	
Pulley	1	
Set screw 5/16–18 x 1/2"	2	
Key	1	
Tension spring	1	
Top plate	1	Install top and side plates
Side plate	2	
Carriage bolt 3/8–16 x 1"	9	
Washer 3/8"	9	
Locknut 3/8"	9	
Discharge chute-Upper	1	Install discharge chute and rotator assembly
Discharge chute-Lower	1	
Deflector shield	1	
Carriage bolt 5/16–18 x 3/4"	3	
Carriage bolt 5/16–18 x 5/8"	3	
Washer 5/16"	7	
Locknut 5/16"	7	
Rotator assembly	1	
Carriage bolt 5/16–18 x 1"	1	
Pyramidal washer 5/16"	1	

DESCRIPTION	QTY.	USE
Snowthrower assembly	1	Mount snowthrower to tractor
Lift tube	1	
Lift rod	1	
Spacer washer 3/4"	2	
Washer 5/8"	1	
Hairpin cotter-large	1	
Lift assist spring	1	
Eyebolt	1	
Locknut 3/8"	1	
Belt	1	
Crank handle	1	
Handle support	1	
Hairpin cotter-small	2	

Assemble Housing

1. Tip housing onto front and insert frame into snowthrower with angle bend up (Fig. 1). Fasten frame with (4) 3/8 x 1" bolts (heads to the outside) and (4) 3/8" locknuts.

2. Install pulley so hub is flush with end of drive shaft (Fig. 1) and secure with square key and (2) square head set screws.

IMPORTANT: Key must be located under a set screw to be retained.

3. Install tension spring between frame and idler arm (Fig. 1).




Figure 1

- | | |
|------------------|--------------|
| 1. Housing | 6. Key |
| 2. Frame | 7. Set screw |
| 3. Bolt 3/8 x 1" | 8. Spring |
| 4. Locknut 3/8" | 9. Idler arm |
| 5. Pulley hub | |

4. Rotate the housing down and position top plate outside top flange of housing. Secure with (3) 3/8 x 1" carriage bolts (heads on inside) (3) 3/8" washers and (3) 3/8" locknuts (Fig. 2).
5. Position side plates outside housing side flanges, with cutting edges parallel to side of housing, and secure with (6) 3/8 x 1" carriage bolts (heads on inside), (6) 3/8" washer and (6) 3/8" locknuts (Fig. 2).




Figure 2

- | | |
|---------------------------|-----------------|
| 1. Top plate | 4. Locknut 3/8" |
| 2. Carriage bolt 3/8 x 1" | 5. Side plate |
| 3. Washer 3/8" | 6. Cutting edge |

6. Assemble upper discharge chute section outside and on top of lower section (2) 5/16 x 5/8" with bolts (heads on inside), (2) 5/16" washers and (2) 5/16" locknuts (Fig. 3).





Figure 3

- | | |
|------------------------------|------------------|
| 1. Upper section | 4. Washer 5/16" |
| 2. Lower section | 5. Locknut 5/16" |
| 3. Carriage bolt 5/16 x 5/8" | |

7. Install discharge chute and deflector shield onto housing with (3) 5/16 x 3/4" carriage bolts (heads to inside), (3) 5/16" washers and (3) 5/16" locknuts (Fig. 4).




2241

Figure 4

- | | |
|------------------------------|------------------|
| 1. Discharge chute | 4. Washer 5/16" |
| 2. Deflector shield | 5. Locknut 5/16" |
| 3. Carriage bolt 5/16 x 3/4" | |

8. Install discharge chute rotator assembly into slot in housing with (3) 5/16 x 1" carriage bolt (head to top), (3) 5/16" pyramidal washer and (3) 5/16" locknut (Fig. 5).

9. Adjust rotator assembly so that worm gear is at right angle with chute, the teeth mesh fully and the chute turns freely. tighten locknut securely.



1280

Figure 5

- | | |
|----------------------------|------------------|
| 1. Rotator assembly | 4. Locknut 5/16" |
| 2. Carriage bolt 5/16 x 1" | 5. Worm gear |
| 3. Pyramidal washer 5/16" | |

Installing Snowthrower to Tractor

! DANGER

POTENTIAL HAZARD

- When snowthrower is attached to the tractor, without additional weight, the tractor may become unstable.


WHAT CAN HAPPEN

- Loss of traction and stability may cause loss of tractor control.

HOW TO AVOID THE HAZARD

- **NEVER** operate tractor, equipped with snowthrower, unless 100lb rear wheel weights are installed.

1. Install lift tube to housing with 5/8" flat washer and hairpin cotter (Fig. 6).




1288

Figure 6

- | | |
|----------------|-------------------------|
| 1. Lift tube | 3. Hairpin cotter—large |
| 2. Washer 5/8" | |

2. Position snowthrower on a level surface with lift tube extending rearward.
3. Open front hitch on tractor and park the tractor behind snowthrower, with lift tube between the front wheels. Disengage the power take off (PTO), set the parking brake, and turn the ignition key to "OFF" to stop the engine. Remove the key.
4. Slide snowthrower mounting frame into front hitch. Close and lock front hitch (Fig. 7).



1248


Figure 7

- | | |
|-------------------|----------------|
| 1. Mounting frame | 2. Front hitch |
|-------------------|----------------|

5. Set Dial-A-Height to the Mounting Position, and lower attachment lift all the way; refer to; Adjusting Dial-A-Height.
6. Slide lift rod into lift tube (Fig. 8). Optional 3/4" spacer washer(s) placed onto shaft of lift rod will increase lift height (Fig. 8).
7. Connect lift rod to top hole in attachment lift with hairpin cotter (Fig. 8).
8. Raise attachment lift lever to the transport position and place a block under snowthrower housing.

IMPORTANT: Check that lift tube does not contact front axle. If contact is noted, remove one or both flat spacer washers from lift rod.

9. Hook lift assist spring between frame cross rod and eyebolt (Fig. 8). Insert eyebolt through bracket on lift rod and secure with 3/8" locknut. Tighten locknut until spring is under slight tension.



m-2787

Figure 8

- | | |
|--------------------------|-------------------------|
| 1. Lift rod | 5. Hairpin cotter—small |
| 2. Spacer washer(s) 3/4" | 6. Spring |
| 3. Lift tube | 7. Eyebolt |
| 4. Attachment lift | 8. Locknut |

10. Remove the belt cover; refer to tractor Operator's Manual.
11. Remove hairpin cotters from trunnion and bottom of yoke (Fig. 9).
12. Unlatch and remove clevis pin that secures yoke assembly to clutch shaft. Pivot yoke out and forward to remove from clutch shaft and engagement plate (Fig. 9).
13. Place belt in outer pulley groove (Fig. 9).
14. Assemble yoke and engagement plate and attach clevis pin, trunnion and hairpin cotters to secure (Fig. 9).




Figure 9

- | | |
|---------------------|-----------------|
| 1. Hairpin cotter | 5. Yoke |
| 2. Trunnion | 6. Clutch shaft |
| 3. Engagement plate | 7. Outer groove |
| 4. Clevis pin | |

15. Route belt between belt guide and around idler pulleys (Fig. 10).
16. Rotate idler bracket to stretch spring and slip belt over snowthrower pulley (Fig. 10),




Figure 10

- | | |
|--|-----------------------|
| 1. Outer groove of (PTO)
power take off | 3. Belt guide |
| 2. Idler pulley | 4. Snowthrower pulley |

17. Open mid hitch and install handle support (Fig. 11). Align notch on handle with hitch rod so it does not rotate.




Figure 11

1. Handle support 2. Mid hitch

18. Slide crank handle through hole in support and secure handle to U-Joint with hairpin cotter (Fig. 12).

Note: Adjust rotor assembly if necessary so handle clears tractor hood, teeth mesh fully and chute turns freely.




Figure 12

1. Crank handle 3. U-joint
2. Support 4. Hairpin cotter—small

Removing the Snowthrower

Note: Save all hardware, washers and hairpin cotters for reuse when installing snowthrower.

1. Park the machine on a level surface, disengage the power take off (PTO), set the parking brake, and turn the ignition key to “OFF” to stop the engine. Remove the key.
2. Raise attachment lift to the transport position and place a block under snowthrower housing. Turn the Dial-A-Height knob counterclockwise, all the way, and lower the attachment to the mounting position; refer to Operation, Lowering Attachments.
3. Remove hairpin cotter at U-joint and slide crank handle out of support (Fig. 13).




Figure 13

1. Crank handle 3. U-joint
2. Support 4. Hairpin cotter—small

4. Open mid hitch and remove handle support (Fig. 14).




Figure 14

1. Handle support
2. Mid hitch

5. Rotate idler bracket to relax belt tension and slip belt off snowthrower pulley (Fig. 15),




Figure 15

1. Outer groove of (PTO) power take off
2. Idler pulley
3. Belt guide
4. Snowthrower pulley

6. Remove hairpin cotters from trunnion and bottom of yoke (Fig. 16).
7. Unlatch and remove clevis pin that secures yoke assembly to clutch shaft. Pivot yoke out and forward to remove from clutch shaft and engagement plate (Fig. 16).
8. Remove belt from pulley (Fig. 16).
9. Assemble yoke and engagement plate and attach clevis pin, trunnion and hairpin cotters to secure (Fig. 16).
10. Install the belt cover; refer to tractor Operator's Manual.




Figure 16

1. Hairpin cotter
2. Trunnion
3. Engagement plate
4. Clevis pin
5. Yoke
6. Clutch shaft
7. Pulley

11. Lower attachment lift all the way.
12. Loosen locknut on eyebolt to relax spring tension (Fig. 17). Unhook lift assist spring from frame cross rod.
13. Remove hairpin cotter to disconnect lift rod from attachment lift (Fig. 17).
14. Remove lift rod (and optional spacer washers) from lift tube (Fig. 17).




Figure 17

- | | |
|---------------------------|------------|
| 1. Lift rod | 5. Spring |
| 2. Optional spacer washer | 6. Eyebolt |
| 3. Lift tube | 7. Locknut |
| 4. Hairpin cotter-small | |

15. Open front hitch lock (Fig. 18) and remove snowthrower mounting frame from front hitch.




Figure 18

- | | |
|-------------------|----------------|
| 1. Lock | 3. Front hitch |
| 2. Mounting frame | |

16. Remove hairpin cotter and washer to disconnect lift tube from housing.




Figure 19

- | | |
|--------------|-------------------------|
| 1. Lift tube | 3. Hairpin cotter-large |
| 2. Washer | |

Note: Save all hardware, washers and hairpin cotters for reuse when installing snowthrower.

Operation

DANGER

POTENTIAL HAZARD

- When snowthrower is attached to the tractor, without additional weight, the tractor may become unstable.

WHAT CAN HAPPEN

- Loss of traction and stability may cause loss of tractor control.

HOW TO AVOID THE HAZARD

- NEVER operate tractor, equipped with snowthrower, unless 100 lb rear wheel weights are installed.

DANGER

POTENTIAL HAZARD

- Rotating auger can cut off fingers, hands or other body parts and throw objects.

WHAT CAN HAPPEN

- Contact with rotating auger and thrown debris can cause severe injury or death.

HOW TO AVOID THE HAZARD

- Stay away from the discharge and auger openings while operating the snowthrower.
- Keep your hands, feet, and any other part of your body or clothing away from concealed, moving or rotating parts.
- Use a stick, not your hand, to remove obstructions from discharge chute or auger housing.
- Before adjusting, cleaning, repairing and inspecting the snowthrower and before unclogging the discharge chute, shut off the engine and wait for all moving parts to stop. Move the power take off (PTO) to “OFF” and rotate the ignition key to “OFF.” Remove the key.


Operating the Power Take Off (PTO)

The power take off (PTO) engages and disengages power to the clutch.

While the ignition key is in “RUN” position and the power take off (PTO) is engaged, the PTO light in the Indicator Module, will be “ON”. When this light is “ON” it is a reminder; the starter will not crank

Engaging the Power Take Off (PTO)

1. Depress the clutch and brake pedals to stop the machine.
2. Push the power take off (PTO) lever forward to engage (Fig. 20).



m-2521

Figure 20

1. Engaged
2. Disengaged

Disengaging the Power Take Off (PTO)

1. Depress the clutch and brake pedals to stop the machine.
2. Pull the power take off (PTO) lever back to disengage (Fig. 20).

Attachment Lift Lever

The attachment lift lever (Fig. 21) is used to raise and lower various attachments.

Raising Attachments

1. Depress the clutch and brake pedals to stop the machine.
2. Pull attachment lift lever rearward until latch locks. In this position the lift will hold the attachment in the up, or raised position.

Lowering Attachments

1. Depress the clutch and brake pedals to stop the machine.
2. Pull attachment lift lever rearward, to release lift pressure, and push the button on top to release the latch. Move lift lever forward to lower attachment.




Figure 21

1. Lift lever
2. Button
3. Dial-A-Height

Attachment Power Lift


The attachment power lift (Fig. 22) is used to raise and lower attachments.

Raising Attachments

1. Start the engine, refer to; Starting and Stopping the Engine; in tractor Operator's Manual.
2. Pull the lift lever in the "UP" direction to raise the attachment lift (Fig. 22). This will lift and hold the attachment in the up, or raised position.

Lowering Attachments

1. Start the engine, refer to; Starting and Stopping the Engine; in tractor Operator's Manual.
2. Push the lift lever in the "DOWN" direction to lower the attachment lift (Fig. 22). This will lower the attachment lift.



m-2454

Figure 22

1. Lift lever UP
2. Lift lever DOWN

Adjusting Dial-A-Height

The Dial-A-Height control (Fig. 21) is used to limit the downward travel of the attachment. The Dial-A-Height knob is rotated to change the location of this stop, up or down.

1. Raise the attachment lift: Refer to Raising Attachments. In the raised position the Dial-A-Height knob (Fig. 21) can be rotated to change the stop location. Turn clockwise to raise and counterclockwise to lower the height of the attachment.
2. The Dial-A-Height indicator (Fig. 21) will show the change, high to low, in attachment lift height as adjustment is made.

Adjusting Discharge Chute

DANGER

POTENTIAL HAZARD

- Rotating auger can cut off fingers, hands or other body parts and throw objects.

WHAT CAN HAPPEN

- Contact with rotating auger and thrown debris can cause severe injury or death.

HOW TO AVOID THE HAZARD

- Stay away from the discharge and auger openings while operating the snowthrower.
- Keep your hands, feet, and any other part of your body or clothing away from concealed, moving or rotating parts.
- Use a stick, not your hand, to remove obstructions from discharge chute or auger housing.
- Before adjusting, cleaning, repairing and inspecting the snowthrower and before unclogging the discharge chute, shut off the engine and wait for all moving parts to stop. Move the power take off (PTO) to "OFF" and rotate the ignition key to "OFF." Remove the key.

The discharge chute can be rotated 180° side to side. The direction is controlled by turning the crank handle (Fig. 23).

The chute deflector, on top of the discharge chute, can be moved up and down to control the height and distance snow is thrown (Fig. 23).




Figure 23

1. Discharge chute
2. Crank handle
3. Chute deflector

Tips for Throwing Snow

Remove snow as soon as possible after it falls. This produces best snow removal results.

Adjust skids to match the type of surface being cleaned; refer to Adjusting Skids.

The snowthrower is designed to clean snow down to the contact surface, but there are times when the front of the snowthrower may tend to ride up. If this happens, reduce forward speed.

Discharge snow downwind whenever possible, and overlap each pass to ensure complete snow removal. If wheels slip, shift into a lower gear to reduce forward speed.

Run snowthrower for a few minutes after clearing snow so moving parts do not freeze. Engage power take off (PTO) to clear any remaining snow from inside housing.

Do not overload snowthrower by clearing snow at too fast a rate. If engine slows down, reduce forward speed.

Always use full throttle (maximum engine speed) when throwing snow.

In wet or slushy conditions, clogging of the discharge chute will be reduced by maintaining maximum engine speed and by not overloading the engine.

In some snow and cold weather conditions, some controls and moving parts may freeze. Therefore, when any control becomes hard to operate, stop the machine and wait for all moving parts to stop; then check all parts for freeze up. **DO NOT USE EXCESSIVE FORCE AND TRY TO OPERATE THE CONTROLS WHEN FROZEN.** Free all controls and moving parts before operating.

Maintenance

Service Interval Chart

Service Operation	Each Use	5 Hours	25 Hours	Storage Service	Fall Service	Notes
Grease—drive shaft bearings			X	X	X	
Oil—drive chain			X	X	X	
Belt—check for wear/cracks				X	X	
Chipped Surfaces—paint				X		
Scraper—check for wear				X	X	

CAUTION

POTENTIAL HAZARD

- If you leave the key in the ignition switch, someone could start the engine.

WHAT CAN HAPPEN

- Accidental starting of the engine could seriously injure you or other bystanders.

HOW TO AVOID THE HAZARD

- Remove the key from the ignition switch and pull the wire off the spark plug before you do any maintenance. Also push the wire aside so it does not accidentally contact the spark plug.

Greasing and Lubrication

Service Interval/Specification

Grease and oil the machine after every 25 operating hours or once a year, whichever occurs first.

Grease Type: General-purpose grease.

Oil Type: SAE 10W or 10W30.

How to Grease

1. Disengage the power take off (PTO), set the parking brake, and turn the ignition key to "OFF" to stop the engine. Remove the key.
2. Clean the grease fittings with a rag. Make sure to scrape any paint off the front of the fitting(s).
3. Connect a grease gun to the fitting. Pump grease into the fittings.
4. Wipe up any excess grease.

Where to Add Grease

1. Lubricate the drive shaft bearings (Fig. 24).




Figure 24

Oil Drive Chain

1. Disengage the power take off (PTO), set the parking brake, and turn the ignition key to "OFF" to stop the engine. Remove the key.
2. Coat the entire chain with oil and allow to penetrate each roller (Fig. 25).
3. Place a few drops of oil on discharge chute rotator shaft and discharge chute mounting (Fig. 25).
4. Wipe off excess oil.




Figure 25

- | | |
|---------------------|-----------------------------|
| 1. Drive chain | 3. Discharge chute mounting |
| 2. Rotator assembly | |

Adjusting Skids

The distance between the scraper blade and the ground is controlled by skids on each side of the housing. The height can be adjusted so the scraper blade will not catch on uneven surfaces

1. Disengage the power take off (PTO), set the parking brake, and turn the ignition key to "OFF" to stop the engine. Remove the key.
2. Move snowthrower to a level surface.
3. Loosen nuts securing skids to the housing until the skids slide up and down easily (Fig. 26).
4. Raise or lower skids equally on both sides, to obtain level scraping action, and tighten nuts (Fig. 26).

Note: On smooth, paved surfaces, scraper blade can be close to the surface. On uneven, gravel or crushed rock surfaces, adjust skids to raise scraper, to prevent catching or picking up rocks.




Figure 26

- | | |
|------------|--------|
| 1. Skid | 3. Nut |
| 2. Housing | |

Reversing Scraper Blade

The scraper blade contacts the ground preventing damage to the snowthrower housing. Periodically inspect the scraper blade for wear. When scraper becomes worn, before working surface contacts the housing, reverse the scraper blade.

1. Disengage the power take off (PTO), set the parking brake, and turn the ignition key to "OFF" to stop the engine. Remove the key.
2. Raise the attachment lift lever: Refer to Raising Attachments, and support the housing off the ground.
3. Remove nuts, washers, carriage bolts and scraper blade (Fig. 27).
4. Reverse scraper blade and install with previously removed hardware (Fig. 27).




Figure 27

- | | |
|-----------|------------------|
| 1. Nut | 3. Carriage bolt |
| 2. Washer | 4. Scraper blade |

IMPORTANT: The scraper should be higher above the pavement if the pavement surfaces on which the snowthrower will be used are cracked, rough or uneven.


Adjusting Drive Chain Tension

Check the drive chain tension after every 25 operating hours or once a year, whichever occurs first.

Adjustment as necessary to maintain proper tension.

1. Disengage the power take off (PTO), set the parking brake, and turn the ignition key to "OFF" to stop the engine. Remove the key.
2. To adjust, loosen the bolt that secures idler sprocket to left side housing. (Fig. 28).
3. Slide idler sprocket in adjustment slot until chain is snug, but not tight (Fig. 28).
4. Tighten idler sprocket securely.

IMPORTANT: Do not overtighten chain or excessive wear will occur.



1291

Figure 28

1. Idler sprocket

2. Adjustment slot

Storage

1. Before long term storage wash the machine with mild detergent and water to remove dirt and grime from the entire machine.
2. Check the condition of the scraper blade; refer to Reversing Scraper Blade, page 18.
3. Check the condition of the drive belt and chain.
4. Grease and oil the snowthrower; refer to Greasing and Lubrication, page 17.
5. Check and tighten all bolts, nuts, and screws. Repair or replace any part that is damaged or defective.
6. Paint all scratched or bare metal surfaces. Paint is available from your Authorized Service Dealer.
7. Coat inside auger housing and discharge chute with automotive wax to prevent rust and reduce the sticking of snow to these surfaces.
8. Store the machine in a clean, dry garage or storage area. Cover the machine to protect it and keep it clean.

Troubleshooting

PROBLEM	POSSIBLE CAUSES	CORRECTIVE ACTION
Snow does not discharge	<ol style="list-style-type: none"> 1. Discharge chute plugged. 2. Auger does not rotate. 3. Auger speed too low. 4. Forward speed too slow. 	<ol style="list-style-type: none"> 1. Clean chute with a stick. 2. See auger does not rotate. 3. Move throttle to "FAST". 4. Increase ground speed.
Auger does not rotate.	<ol style="list-style-type: none"> 1. Snow frozen to auger or housing. 2. Drive belt tension low. 3. Drive belt is worn, loose or broken. 4. Drive belt is off pulley. 5. Drive chain broken. 	<ol style="list-style-type: none"> 1. Scrape snow off with a stick. 2. Adjust belt tension. 3. Install new drive belt. 4. Install blade drive belt and check idler pulley and belt guides for correct position. 5. Replace or repair chain.
Abnormal vibration.	<ol style="list-style-type: none"> 1. Snow frozen to auger. 2. Drive belt off pulley. 3. Engine mounting bolts are loose. 4. Loose engine pulley, idler or snowthrower pulley. 5. Engine pulley is damaged. 	<ol style="list-style-type: none"> 1. Scrape snow off with stick. 2. Install drive belt and check idler pulley for correct position. 3. Tighten engine mounting bolts. 4. Tighten the appropriate pulley. 5. Contact Authorized Service Dealer.

