
FORM NO. 3317−872

TORO®

MODEL NO. 03531−50301 & UP

PARTS CATALOG

REELMASTER® 5300D 4WD
TRACTION UNIT



FRAME & BODY ASSEMBLY


Ref. No.	Part No.	Description	No. Used
1	62−5550	Decal − TORO	1
2	75−1420	Cover − Steering Tower	1
3	93−7579	Fender − R.H.	1
‡4	85−4730	Decal − Hydraulic Oil	1
4	93−6686	Decal − Hydraulic Oil (Europe)	1
5	65−5100	Handle	2
6	237−141	Bumper	2
7	46−8091	Screw − Cap Hex. Hd.	4
8	93−0000	Hood W.A.	1
9	93−0081	Strip − Seal	1
10	92−5549	Decal − Reelmaster® 5300D	2
11	3272−4	Pin − Cotter	2
12	93−0011	Grill − Hood	1
13	3296−42	Nut − Lock	7
14	3256−1	Washer − Flat	10
15	321−39	Screw − Cap Hex. Hd.	7

Ref. No.	Part No.	Description	No. Used
16	62−7400	Decal − TORO	1
17	63−6900	Hinge − Hood L.H.	1
*	63−6890	Hinge − Hood R.H.	1
18	3256−23	Washer − Flat	6
19	322−5	Screw − Cap Hex. Hd.	4
20	3253−4	Washer − Lock	4
21	75−0570	Cable − Hood	1
22	75−6280	Bracket − Hose	1
23	92−5751	Decal − Hood Trim L.H.	1
*	92−5752	Decal − Hood Trim R.H.	1
‡24	75−1280	Decal − Warning	1
24	93−6698	Decal − Warning (Europe)	1
‡25	93−3601	Decal − Service	1
25	93−8094	Decal − Service (Spanish)	1
25	93−8096	Decal − Service (French)	1
25	93−8095	Decal − Service (German)	1
25	93−8097	Decal − Service (Swedish)	1

‡For different language versions of this part, see International Parts Reference.

*Not Illustrated

© The TORO Company − 1995
All Rights Reserved




FRAME & BODY ASSEMBLY (Continued)

Ref. No.	Part No.	Description	No. Used
25	93−8093	Decal − Service (Italian)	1
25	93−8098	Decal − Service (Portuguese)	1
25	93−8099	Decal − Service (Norwegian)	1
25	93−7154	Decal − Service (Finnish)	1
25	93−8091	Decal − Service (Danish)	1
25	93−8092	Decal − Service (Dutch)	1
26	75−5810	W.A. − Tool Box	1
27	93−0096	Decal − A.C.E.	2
‡28	52−1320	Decal − Fuel	1
28	93−6680	Decal − Fuel (Europe)	1
29	75−3860	Fender − L.H.	1
30	322−3	Screw − Cap Hex. Hd.	4
31	3256−3	Washer − Flat	4
‡32	75−5190	Decal − No Riders	2
32	93−6689	Decal − No Riders (Europe)	2
33	3234−14	Screw − Hex. Washer Hd.	14
‡34	88−6700	Decal − ANSI (English) (For Reference Only)	1
34	93−8074	Decal − Blank (Europe)	1
35	75−0650	Tread − Footrest L.H.	1
*	75−0640	Tread − Footrest R.H.	1
36	75−1410	Panel − Floor	1

Ref. No.	Part No.	Description	No. Used
37	75−0630	Tread − Foot Center	1
38	75−1390	Panel − Access	1
39	75−0620	Tread − Foot L.H.	1
*	75−0610	Tread − Foot R.H.	1
40	322−4	Screw − Cap Hex. Hd.	2
41	93−3626	Bracket − Hose	1
42	75−6840	Knob − Knurled	4
42	3234−7	Screw − Hex. Flange Hd. (Europe)	1
43	94−3349	Assembly − Frame	1
44	74−5950	Assembly − Swell Latch	3
45	32128−33	Nut − Flange Head	3
46	3258−166	Screw − Phillips Hd.	3
47	75−6260	Cover − Tool Box	1
‡48	93−3639	Decal − Warning	1
48	93−8051	Decal − Warning (Europe)	1
49	49−2040	Screw − Hex. Washer Hd.	2
50	72−3560	Decal − 4WD	2
51	2412−107	R−Clamp	1
52	93−8744	Rivet	3
53	3234−7	Screw − Hex. Flange Hd. (Europe)	1

*Not Illustrated
‡For different language versions of this part, see International Parts Reference.



T−1044

STEERING TOWER ASSEMBLY


Ref. No.	Part No.	Description	No. Used
1	32144−26	Screw − Self−Tapping	2
2	3253−4	Washer − Lock	2
3	75−2810	Clamp − Steering Valve	1
4	75−0560	Assembly − Steering Wheel (Incl. Ref. #6−8)	1
5	68−5370	Decal − TORO	1
6	32144−21	Screw	1
7	68−5140	Cap − Steering Wheel	1
8	3220−6	Nut − Steering Wheel	1
9	233−17	Knob − Parking Brake	1
‡10	93−3139	Panel − Tower	1
10	93−6682	Panel − Tower (Europe)	1
11	3256−22	Washer − Flat	4
12	3−3251	Spring − Compression	1
13	75−1490	Rod − Parking Brake	1
14	237−22	O−Ring	5
15	3256−23	Washer − Flat	6
16	3296−20	Nut − Lock	4

Ref. No.	Part No.	Description	No. Used
17	3272−5	Pin − Cotter	3
18	75−6230	Hose − Hydraulic RT	1
19	75−6240	Hose − Hydraulic IN	1
20	63−7900	Rack − Parking Brake	1
21	3272−10	Pin − Cotter	1
22	3256−26	Washer − Flat	1
23	75−5940	Hose − Hydraulic AUX	1
24	75−6220	Hose − Hydraulic LT	1
25	75−6250	Hose − Hydraulic OUT	1
26	75−0600	Assembly − Steering Valve (Incl. Ref. #14)	1
27	21−9260	Seal − Shaft	1
28	3258−166	Screw − Phillips Hd.	2
29	3256−1	Washer − Flat	2
30	3296−42	Nut − Lock	2
31	3255−8	Washer − Lock ETLW	1
*	3290−378	Tie − Cable	3

*Not Illustrated

‡For different language versions of this part, see International Parts Reference.

3317−872




STEERING VALVE ASSEMBLY No. 75−0600

Ref. No.	Part No.	Description	No. Used
1		Ring − Seal	5
2		Ring − Valve	1
3		Plate − Valve	1
4		Spring	3
5		Pin − Alignment	9
6		Manifold − Isolation	1
7		Ring − Metering	1
8		Hex Drive Asm.	1
9		Link − Drive	1
10		Screw − Hex Socket Hd.	11
11		Seal − Commutator	1
12		Cover − Commutator	1
13		Commutator	1
14		Ring − Commutator	1
15		Stator	1
16		Rotor	1
17		Spacer − Drive Link	1
18		Plug	1
19		O−Ring	1
20		Ball	1
21		Nut − Hex	4
22		Cover − Port	1
23		O−Ring	5
24		Manifold − Port	1
25		Spring	3

Ref. No.	Part No.	Description	No. Used
26		Plate − Cover, Upper	1
27	3220−6	Nut	1
28	66−9770	Seal	1
29	66−9780	Bushing	1
30		Spacer − Bearing, Thrust	1
31		Spacer − Seal	1
33		Seal − Face	1
34		Bearing − Thrust	1
35		Plate − Drive	1
36	93−3609	Bolt − Special	4
37	66−9860	Upper Cover & Jacket	1
38	66−9870	Plate − Retaining	1
39	66−9880	Washer − Retaining Plate	1
40	66−9890	Ring − Retaining	1
41	66−9900	Shaft − Input	1
*	66−9970	Spring Kit (Incl. Ref. #4 & 25)	1
*	66−9980	Seal − Kit (Incl. Ref. #1, 11, 19, 23 & 33)	1
*	66−9990	Needle Roller Kit (Incl. Ref. #5)	1
*	75−0600	Valve − Power Steering (Incl. Ref. #1−26 & 30−36)	1

*Not Illustrated




T−1045

TRACTION & BRAKE PEDALS ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	3220−3	Nut − Jam	2
2	2411−36	Bearing − Rod End	1
3	323−9	Screw − Cap Hex. Hd.	1
4	3256−24	Washer − Flat	1
5	3272−2	Pin − Cotter	2
6	3256−22	Washer − Flat	2
7	75−6580	Cable − Pedal	1
8	75−3270	Lever − Traction Pivot	1
9	32121−6	Pin − Roll	1
10	32121−45	Pin − Roll	2
11	49−6440	Plate − Traction Pedal	1
12	74−9100	Pad − Forward	1
13	75−2970	Pedal − Traction	1
14	74−9110	Pad − Reverse	1
16	75−6510	Lever − Bracket	1
17	75−6550	Disc − Friction	1
‡18	75−6710	Decal − Fast/Slow	1
18	93−6699	Decal − Fast/Slow (Europe)	1
19	233−42	Knob	1
20	75−6490	Lever − Pedal Stop	1
21	3290−461	Washer − Belleville	1
22	3296−59	Nut − Lock	1

Ref. No.	Part No.	Description	No. Used
23	3296−29	Nut − Lock	8
24	256−236	Bearing − Flange	4
25	322−3	Screw − Cap Hex. Hd.	8
26	7−3900	Pad − Brake	2
28	63−7880	Pin − Brake Latch	1
29	63−7733	Cable − Brake L.H.	1
*	63−7732	Cable − Brake R.H.	1
30	283−58	Pin − Clevis	4
31	3256−69	Washer − Thrust	3
32	32121−16	Pin − Roll	1
33	75−1440	Pedal − Brake L.H.	1
34	256−42	Bushing − Sleeve	2
35	75−1430	Assembly − Brake Pedal R.H. (Incl. Ref. #34 & 39)	1
36	75−1470	Shaft − Brake Pedal	1
37	75−2170	Tube − Pump Control	1
38	3296−39	Nut − Lock	1
39	302−5	Fitting − Grease	1
40	3272−10	Pin − Cotter	4
41	32121−50	Pin − Roll	1
42	5−0652	Spacer	1

*Not Illustrated
‡For different language versions of this part, see International Parts Reference.




SEAT & THROTTLE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	351−78	Edging	1
2	323−4	Screw − Cap Hex. Hd.	2
3	75−4370	Bracket − Switch (Seat)	1
4	3296−54	Nut − Lock	4
5	92−8753	Magnet − Reed Switch	1
6	92−8001	Sensor − Reed Switch	1
7	3250−29	Screw − Cap Hex. Hd.	4
8	75−4360	Bracket − Switch	1
9	3296−39	Nut − Lock	3
10	93−0140	Grommet	1
11	74−0720	Tube − Manual	1
12	3256−23	Washer − Flat	8
13	3253−4	Washer − Lock	4
14	322−3	Screw − Cap Hex. Hd.	9
15	75−3400	Shaft − Seat Pivot	1
16	93−0141	Assembly − Seat Plate (Incl. Ref. #10)	1
‡17	85−4530	Decal − Danger	1
17	93−8060	Decal − Danger (Europe)	1
18	2412−93	Clamp − R	1
19	3256−24	Washer − Flat	3
20	75−3680	Rod − Seat	1
21	3272−10	Pin − Cotter	2
22	32121−38	Pin − Roll	1
23	3296−29	Nut − Lock	9
24	93−0073	Cable − Throttle	1
25	25−8640	Screw − Hex. Head	2

Ref. No.	Part No.	Description	No. Used
26	93−0021	Asm. − Throttle Cable Swivel	2
27	3296−3	Nut − Lock	3
28	93−0018	Frame − Seat	1
29	3−6657	Clamp − Cable	1
30	3253−3	Washer − Lock	1
31	321−4	Screw − Cap Hex. Hd.	2
32	66−2920	Washer − Friction	2
33	75−3430	Rod − Throttle	1
34	233−42	Knob − Throttle	1
35	3296−59	Nut − Lock	2
36	5−0838	Washer − Flat	4
37	75−5270	Spacer − Locking Knob	2
38	75−5260	Knob − Locking	2
39		Asm. − Seat Suspension	1
‡40	83−7440	Decal − Knob	1
40	93−6694	Decal − Knob (Europe)	1
‡41	85−4610	Decal − Clip	1
41	92−1128	Decal − Clip (Spanish)	1
41	92−1130	Decal − Clip (French)	1
41	92−1129	Decal − Clip (German)	1
41	92−1131	Decal − Clip (Swedish)	1
41	92−1127	Decal − Clip (Italian)	1
41	93−8057	Decal − Clip (Portuguese)	1
41	93−8086	Decal − Clip (Norwegian)	1
41	93−8087	Decal − Clip (Finnish)	1
41	93−8078	Decal − Clip (Danish)	1
41	93−8079	Decal − Clip (Dutch)	1

‡For different language versions of this part, see International Parts Reference.




SEAT & THROTTLE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
42	2412−133	Clamp − R	2
43	92−6534	Shell − Seat	1
44	92−6533	Kit − Cushion, Replacement	1
45	92−1180	Assembly − Seat	1
46	21−4191	Assembly − Belt, Seat	1
47	3253−6	Washer − Lock	2

Ref. No.	Part No.	Description	No. Used
48	3212−4	Bolt	2
49	63−9920	Decal − EEC 105	1
50	92−5524	Decal − Noise Rating, 90	1
51	2412−72	R−Clamp	1
52	93−3641	Plate − Idler, Stop	1


‡For different language versions of this part, see International Parts Reference.



SEAT SUSPENSION ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	80−4860	Pin − Clevis	1
2	75−3580	Plate − Mounting, Seat	1
3	75−3530	Spring − Compression	1
4	3256−5	Washer − Flat	1
5	3256−24	Washer	1
6	75−3540	Pin − Roll	1
7	75−3550	Bumper − Seat	2
8	76−2940	Bumper − Rubber	2
9	76−1920	Bushing − Sleeve	4
10	66−8610	Weldment − Lower	1
11	66−8560	Nut − Push	4
12	76−1910	Shaft − Pivot	2
13	82−9060	Adjuster W/Handle	1
14	76−1940	Spring − Extension	2
15	66−9290	Spacer	6
16	66−8530	Adjuster	1

Ref. No.	Part No.	Description	No. Used
17	66−8520	Bumper − Down−stop	2
18	77−2870	Weldment − Hanger	1
19	76−1930	Knob − Tension Adjustment	1
20	3256−46	Washer − Flat	1
21	32128−26	Nut − Flange	4
22	3296−44	Nut − Lock	1
23	75−3480	Weldment − Upper	1
24	3256−26	Washer − Flat	2
25	3253−6	Washer − Lock	2
26	75−3510	Bolt − Shoulder	2
27	93−3164	Cap	2
28	93−3163	Spring	2
29	93−3165	Bracket	1
30	322−6	Screw − Cap Hex. Hd.	1
31	3253−33	Washer − Lock	1
32	3217−6	Nut − Lock	1




T−1458

DIAGNOSTIC−ACE DISPLAY ASSEMBLY


Ref. No.	Part No.	Description	No. Used
‡1	85−4760	Decal − Diagnostic−ACE RM 5100D/RM 5300D V 1.0	1
1	93−8081	Decal − Diag. (Spanish)	1
1	93−8083	Decal − Diag. (French)	1
1	93−8082	Decal − Diag. (German)	1
1	93−8094	Decal − Diag. (Swedish)	1
1	93−8080	Decal − Diag. (Italian)	1
1	93−8085	Decal − Diag. (Portuguese)	1
1	93−8086	Decal − Diag. (Norwegian)	1
1	93−8087	Decal − Diag. (Finnish)	1
1	93−8078	Decal − Diag. (Danish)	1
1	93−8079	Decal − Diag. (Dutch)	1
1	93−8089	Decal − Diag. (Japanese)	1
2	85−4750	Display − Diagnostic−ACE	1

‡For different language versions of this part, see International Parts Reference.

ELECTRICAL SCHEMATIC



T−2314




CONTROL CONSOLE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	66−2940	Gauge − Fuel	1
2	85−4420	Gauge − Speedometer	1
3	3290−489	Knob − Lift Control	1
4	218−498	Nut − Hex.	4
5	74−5950	Assembly − Swell Latch	1
6	44−2210	Assembly − Warning Light (Incl. Ref. #29 & 30)	1
*	218−533	Lens − Red	1
▪		Bulb − #1815	1
7	66−2960	Cluster − Warning	1
8	63−7430	Gauge − Temperature	1
9	63−8360	Key − Ignition	1
10	218−446	Nut − Locking	1
11	218−447	Washer − E.T.L.W.	1
12	3258−166	Screw − Phillips Hd.	5
13	3256−1	Washer − Flat	5
‡14	93−3140	Panel − Control	1
14	93−6683	Panel − Control (Europe)	1
15	75−6270	Cover − Control Box	1
16	75−1010	Assembly − Toggle Switch (Incl. Ref. #4)	1
17	32105−13	Screw − Cap Hex. Hd.	4
18	3296−2	Nut − Lock	5
19	27−2360	Assembly − Ignition Switch (Incl. Ref. #9−11)	1

Ref. No.	Part No.	Description	No. Used
†20	218−573	Fuse − 5A	2
*†	218−578	Fuse − 10A	3
†21	67−7160	Block − Fuse	2
22	3296−42	Nut − Lock	4
23	93−7587	Bracket − Fuse Block	1
24	75−5740	Box − Control	1
25	85−4480	Knob	1
26	321−39	Screw − Cap Hex. Hd.	2
‡27	85−4720	Decal − Fuses	1
27	93−6695	Decal − Fuses (Europe)	1
28	75−4710	Warning Light Harness (Incl. Ref. #51 & 52)	1
*	219−17	Bulb − Light	4
29	218−536	Washer − Lock	1
30	218−535	Nut − Lock	1
31	92−5720	Controller − Electronic Note: This part must be programmed by distributor before installation.	1
32	3253−3	Washer − Lock	3
33	321−15	Screw − Cap Hex. Hd.	3
34	3256−3	Washer − Flat	3
35	322−3	Screw − Cap Hex. Hd.	2
36	3290−354	Plate − Nut	2

*Not Illustrated †Included in main wire harness assembly. ▪Obtain Locally.
‡For different language versions of this part, see International Parts Reference.

3317−872



CONTROL CONSOLE ASSEMBLY (Continued)


Ref. No.	Part No.	Description	No. Used
‡37	75−3420	Assembly − Lift Control (Incl. Ref. #3, 36 & 38−40)	1
37	93−7183	Assembly − Lift Control (Europe) (Incl. Ref. #3 & 40)	1
38	218−590	Switch − Micro	2
39	3290−93	Screw − Cap Hex. Hd.	4
40	3290−488	Boot − Lift Control	1
41	32144−1	Screw − Cap Hex. Hd.	2
42	69−4780	Clamp − Light Cluster	1
43	32105−1	Screw − Cap Hex. Hd.	1
44	85−4470	Assembly − Potentiometer (Incl. Ref. #48 & 49) Note: Replacement of this part requires recalibration of electronic controller by distributor after installation.	1
45	3273−26	Screw − Hex. Socket Hd.	2
46	32144−18	Screw − Cap Hex. Hd.	2
47	75−6820	Meter − Hour	1

Ref. No.	Part No.	Description	No. Used
48		Nut − Lock	1
49		Washer − Lock	1
50	94−4934	Decal − HOC Selector	1
50	93−1268	Decal − HOC Selector (Europe)	1
51		Nut − Lock	1
52		Washer − Lock	1
53	2412−126	Clamp−R	1
54	322−5	Screw − Cap Hex. Hd.	1
55	32128−33	Nut − Lock, Flange Hd.	3
56	94−3346	Asm. − Main Wire Harness	1
†57	85−4491	Lamp − Diagnostic	1
58	93−3625	Spring − Return, Joystick	1
*†	70−8570	Breaker − Circuit	2
*†	86−7560	Connector − Cover (3 Way)	3
*†	86−7550	Connector − Cover (2 Way)	2
*†	85−4650	Connector − Loop Back	1
*	93−1358	Software − ECU RM5300D	1
*	219−19	Bulb − Light	1


*Not Illustrated

†Included in main wire harness assembly.

HYDRAULIC SCHEMATIC



T–1144B




HYDRAULIC RESERVOIR ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	93−7488	Reservoir − Hydraulic	1
2	68−6150	Breather − Hydraulic Tank	1
3	61−2790	Screen − Filler	1
4	75−3710	Dipstick	1
5	93−7499	Gasket − Flange	1
6	93−7498	Plug − Plastic	1
7	237−101	O−Ring	1
‡8	93−7588	Cover − Tank	1
9	75−6130	Hose − Hydraulic	1
10	237−65	O−Ring	5
11	340−8	Fitting − Hydraulic Straight (Incl. Ref. #10 & 12)	2
12	237−81	O−Ring	4
13	321−23	Screw − Cap Hex. Hd.	2
14	92−9098	Manifold − Tank	1
15	3296−42	Nut − Lock	2
16	354−74	Fitting − Hydraulic Plug (Incl. Ref. #12)	1
17	75−6250	Hose − Hydraulic	1
18	2412−34	Clamp − Hose	3
19	75−5720	Hose − Hydraulic	1
20	353−682	Fitting − Hydraulic Straight	1
21	93−0119	Hose − Hydraulic	1
22	340−77	Fitting − Hydraulic 90° (Incl. Ref. #23 & 25)	1
23	237−22	O−Ring	6
24	354−73	Fitting − Hydraulic Straight (Incl. Ref. #12)	2

Ref. No.	Part No.	Description	No. Used
25	237−42	O−Ring	4
26	92−8020	Adapter − Breather	1
27	340−87	Fitting − Hydraulic 45° (Incl. Ref. #25 & 23)	1
28	75−6870	Hose − Hydraulic Suction	1
29	75−0550	Strainer − Suction	1
30	93−0077	Hose − Hydraulic	1
31	75−1300	Asm. − Hydraulic Filter Head	1
32	2412−93	Clamp − R	2
33	32144−10	Screw − Hex. Washer Hd.	2
34	75−1310	Element − Hydraulic Filter	1
35	340−139	Fitting − Hydraulic 90° (Incl. Ref. #10 & 12)	1
36	33105−025	Screw − Hex. Flange Hd.	3
37	63−8410	Washer − Flat	3
38	33105−030	Screw − Hex. Flange Hd.	6
39	240−11	Grommet	3
41	3256−24	Washer − Flat	2
42	3253−21	Washer − Lock	2
43	323−4	Screw − Cap Hex. Hd.	2
44	353−550	Fitting − Plug (Incl. Ref. #45)	1
45	237−79	O−Ring	1
46	92−9096	Assembly − Hose	1
47	340−82	Fitting − Hydraulic 90° (Incl. Ref. #23 & 25)	2
48	88−9460	Hose − Hydraulic	1

‡For different language versions of this part, see International Parts Reference.

3317−872




T−1094B

HYDRAULIC CONTROL MANIFOLD ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	237−22	O−Ring	4
2	340−18	Fitting − Hydraulic 90˚ (Incl. Ref. #1 & 9)	2
4	92−1725	Hose − Hydraulic	1
5	340−3	Fitting − Hydraulic Straight (Incl. Ref. #1 & 9)	1
6	93−3611	Asm. − Control Manifold	1
7	237−78	O−Ring	6
9	237−79	O−Ring	6
10	340−101	Fitting − Hydraulic 45˚ (Incl. Ref. #9 & 13)	2
11	354−77	Fitting − Test Port (Incl. Ref. #7)	2
12	354−79	Cap − Test Port	2
13	237−30	O−Ring	4
14	86−9190	Hose − Hydraulic	2
17	340−92	Fitting − Hydraulic Straight (Incl. Ref. #7 & 18)	2
18	237−21	O−Ring	4
19	340−13	Fitting − Hydraulic Straight (Incl. Ref. #18)	2
20	75−6640	Fitting − Hydraulic 90˚ (Incl. Ref. #7)	2

Ref. No.	Part No.	Description	No. Used
21	93−0078	Hose − Hydraulic	1
22	237−65	O−Ring	1
23	340−139	Fitting − Hydraulic 90˚ (Incl. Ref. #22 & 26)	1
24	92−1721	Hose − Hydraulic	1
25	69−4320	Fitting − Hydraulic 90˚ (Incl. Ref. #1 & 3)	1
26	237−81	O−Ring	1
27	92−1723	Hose − Hydraulic	1
28	322−3	Screw − Cap Hex. Hd.	4
29	3253−4	Washer − Lock	4
30	75−5900	Hose − Hydraulic	1
31	82−8270	Valve − Flow Control	1
32	340−143	Fitting − Hydraulic 90˚ (Incl. Ref. #7)	1
33	93−0118	Hose − Hydraulic	1
35	75−5890	Hose − Hydraulic	1
37	92−1728	Hose − Hydraulic	1
38	93−3642	Tube − Hydraulic	1
39	93−3643	Tube − Hydraulic	1




T−1503

CONTROL MANIFOLD ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	237−78	O−Ring	12
2	353−990	Plug (Incl. Ref. #1)	11
3	88−7020	Cartridge − N.O. (Use Seal Kit #75−2080)	2
4	88−9190	Solenoid − 20 Watt	6
5	237−42	O−Ring	2
6	353−989	Plug (Incl. Ref. #5)	2
7	94−2685	Cartridge − N.C. (Use Seal Kit #75−2080)	3
8	88−9200	Solenoid − 28 Watt	5
9	88−6970	Cartridge − N.O. (Use Seal Kit #75−2080)	2
10	237−79	O−Ring	1
11	340−101	Fitting − Hydraulic 45˚ (Incl. Ref. #10 & 12)	1
12	237−30	O−Ring	1
13	75−0920	Cartridge − Relief 3000 psi (Use Seal Kit #75−2080)	1
14	75−2010	Cartridge − Relief 2000 psi (Use Seal Kit #75−2080)	1
15		Body − Manifold	1
16	237−156	O−Ring	2
17	353−991	Plug (Incl. Ref. #16)	2
18	340−143	Fitting − Hydraulic 90˚ (Incl. Ref. #1)	1
19	88−6960	Cartridge − 4W/2P (Use Seal Kit #75−2090)	3
20	237−80	O−Ring	1
21	354−70	Plug (Incl. Ref. #20)	1
22	92−6315	Cartridge − N.C. (Use Seal Kit #75−2080)	1
23	94−5438	Seal − Solenoid	12
*	75−2080	Kit − Seal	10
*	75−2090	Kit − Seal	3

*Not Illustrated




FRONT HYDRAULIC MANIFOLDS

Ref. No.	Part No.	Description	No. Used
1	92−1722	Hose − Hydraulic	1
2	237−21	O−Ring	7
3	340−132	Fitting − Hydraulic 90˚ (Incl. Ref. #2 & 4)	3
4	237−78	O−Ring	7
5	321−11	Screw − Cap Hex. Hd.	2
‡6	88−0440	Decal − Floor Plate	1
6	93−6693	Decal − Floor Plate (Europe)	1
7	85−4730	Decal − Oil	1
8	38−3400	Guard − Rubber	2
9	75−5940	Hose − Hydraulic	1
10	75−5890	Hose − Hydraulic	1
11	75−5910	Hose − Hydraulic	1
12	93−0118	Hose − Hydraulic	1
13	93−0119	Hose − Hydraulic	1
14	237−22	O−Ring	2
15	340−2	Fitting − Hydraulic Straight (Incl. Ref. #14 & 16)	2

Ref. No.	Part No.	Description	No. Used
16	237−42	O−Ring	2
17	93−0139	Manifold − Hydraulic	1
18	93−0143	Cartridge − Relief 250 psi (Use Seal Kit #75−2080)	1
19	75−5300	Rod − Hose Support	2
20	49−2040	Screw − Hex. Washer Hd.	4
21	3296−42	Nut − Lock	4
22	92−9096	Hose − Hydraulic	1
23	75−1180	Manifold − Hydraulic	1
24	92−1726	Hose − Hydraulic	1
25	92−1729	Hose − Hydraulic	1
26	340−92	Fitting − Hydraulic Straight (Incl. Ref. #2 & 4)	4
27	340−77	Fitting − Hydraulic 90˚ (Incl. Ref. #14 & 16)	1
28	321−18	Screw − Cap Hex. Hd.	2

*Not Illustrated

‡For different language versions of this part, see International Parts Reference.




T−1095A

REAR HYDRAULIC MANIFOLDS

Ref. No.	Part No.	Description	No. Used
1	75−6180	Hose − Hydraulic	2
2	237−21	O−Ring	7
3	340−92	Fitting − Hydraulic Straight (Incl. Ref. #2 & 4)	4
4	237−78	O−Ring	8
5	353−512	Fitting − Hydraulic Plug (Incl. Ref. #4)	2
6	321−11	Screw − Cap Hex. Hd.	4
7	75−1180	Manifold	2
8	340−132	Fitting − Hydraulic 90˚ (Incl. Ref. #2 & 4)	1

Ref. No.	Part No.	Description	No. Used
9	93−0118	Hose − Hydraulic	2
10	32128−33	Nut − Lock	4
11	340−143	Fitting − Hydraulic 90˚ (Incl. Ref. #4)	1
12	340−13	Fitting − Hydraulic Straight (Incl. Ref. #2)	2
13	82−8270	Valve − Flow Control	1
14	75−6080	Hose − Hydraulic	1
15	75−6070	Hose − Hydraulic	1




CUTTING UNIT HYDRAULIC COMPONENTS

Ref. No.	Part No.	Description	No. Used
1	92−1724	Hose − Hydraulic	1
2	237−78	O−Ring	5
3	340−103	Fitting − Hydraulic 45˚ (Incl. Ref. #2 & 4)	5
4	237−21	O−Ring	8
5	92−1722	Hose − Hydraulic	1
6	92−1725	Hose − Hydraulic	1
7	340−18	Fitting − Hydraulic 90˚ (Incl. Ref. #18 & 19)	10
8	92−1719	Hose − Hydraulic	1
9	91−1717	Hose − Hydraulic	1
10	92−1723	Hose − Hydraulic	1

Ref. No.	Part No.	Description	No. Used
11	88−9460	Hose − Hydraulic	1
12	92−1718	Hose − Hydraulic	1
13	340−21	Fitting − Hydraulic Tee (Incl. Ref. #4)	1
14	92−1721	Hose − Hydraulic	1
15	92−1727	Hose − Hydraulic	1
16	92−1726	Hose − Hydraulic	1
17	92−1728	Hose − Hydraulic	1
18	237−79	O−Ring	10
19	237−22	O−Ring	10
20	92−1729	Hose − Hydraulic	1
21	93−1375	Motor − Hydraulic	5

3317−872




REEL MOTOR ASSEMBLY NO. 93−1375

Ref. No.	Part No.	Description	No. Used
1	354−50	Screw−Hex Socket Hd.	4
2	354−51	Washer	4
3	353−599	Pin−Dowel	2
4	93−3614	Assembly − Cover (Incl. Ref. #5)	1
†5		Bearing−Needle	5
6	93−3616	Assembly − Idler Gear	1
7	93−3617	Assembly − Drive Shaft	1
8	354−46	Ring−Seal	1

Ref. No.	Part No.	Description	No. Used
9	74−3810	Assembly − Load Plate	1
10	92−8795	Assembly − Body (Incl. Ref. #5)	1
†11		Spacer	1
†12		Seal−Shaft	1
13	32151−41	Ring − Retaining	1
14	92−8796	Pin − Dowel	2
*	92−8863	Repair Kit (Incl. Ref. #8, & 11−13)	1

*Not Illustrated



T−1884A


FUEL TANK ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	63−7610	Hose − Fuel	1
2	53−8150	Assembly − Fuel Pump (Incl. Ref. #5 & 33−34)	1
3	3296−42	Nut − Lock	2
4	3256−22	Washer − Flat	2
†5		Mount − Rubber	2
6	321−8	Screw − Cap Hex. Hd.	2
7	62−7650	Gasket − Sending Unit	1
8	63−7640	Unit − Sending	1
9	3253−15	Washer − Lock	5
10	32122−24	Screw − Round Hd.	5
11	27−5340	Hose − Fuel	1
12	2412−108	Clamp − Hose	11
13	75−4700	Hose − Fuel	1
14	354−22	Fitting − Fuel, Straight	2
15	354−20	Fitting − Fuel Tee	1
16	75−4701	Hose − Fuel	1
17	354−21	Fitting − Fuel Straight	1
18	44−2670	Hose − Fuel	1

Ref. No.	Part No.	Description	No. Used
19	66−8121	Standpipe − Elbow 90˚	1
20	46−6550	Connector − Fuel, Elbow 90˚	1
21	46−6560	Grommet	2
22	93−3102	Cap − Fuel Tank	1
23	94−3510	Assembly − Fuel Tank (Incl. Ref. #24−25)	1
24	2412−36	Clamp − Drain	1
25	304−46	Fitting − Drain	1
26	33103−025	Screw − Hex. Flange Hd.	3
27	63−8410	Washer − Flat	3
28	240−11	Grommet	3
29	63−7628	Hose − Fuel	1
30	353−781	Fitting − 90˚	2
31	321−6	Screw − Cap Hex. Hd.	2
32	63−7650	Filter − Fuel	1
33	70−8530	Wire − Fuel Pump	1
34	218−579	Wire − Fuel Pump	1
35	67−1690	Fitting − Fuel Elbow 90˚	2
36	32128−33	Nut − Lock, Flange	2

*Not Illustrated
†Not Serviced Separately

3317−872




FRONT AXLE & TRANSMISSION ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	76−8730	Decal − Bolt Torque	2
2	23−7270	Nut − Lug	10
3	232−27	Stem − Valve	2
4	3296−56	Nut − Lock	2
5	85−4350	Sensor − Gear Tooth	1
6	321−2	Screw − Cap Hex. Hd.	1
7	3253−3	Washer − Lock	1
8	32144−112	Screw − Cap Hex. Hd.	8
9	85−4330	Cover − Gear	1
10	92−5797	Gasket − Axle	1
11	85−4340	Plate − Sensor Mounting	1
12	32108−9	Screw − Machine	1
13	325−7	Screw − Cap Hex. Hd.	2
14	75−3110	Collar − Transmission	1
15	92−4808	Sleeve − Trans. Pilot	1
16	3296−23	Nut − Lock	2
‡17	77−0490	Decal − Bolt	1
17	93−6691	Decal − Bolt (Europe)	1
18	237−79	O−Ring	2
19	340−3	Fitting − Hydraulic, Straight (Incl. Ref. #18 & 20)	2
20	237−22	O−Ring	2
21	93−0076	Hose − Hydraulic	1
22	237−78	O−Ring	1
23	354−77	Fitting − Hydraulic Test Port (Incl. Ref. #22)	1

Ref. No.	Part No.	Description	No. Used
24	354−79	Cap − Test Port	1
25	237−81	O−Ring	2
26	75−4720	Fitting − Hydraulic 90˚ (Incl. Ref. #25)	1
27	2412−129	Clamp − Hose	2
28	75−6350	Hose	1
29	324−7	Screw − Cap Hex. Hd.	4
30	93−0075	Hose − Hydraulic	1
31	75−1330	Filter − Oil	1
32	323−12	Screw − Cap Hex. Hd.	2
33	3253−21	Washer − Lock	2
34	75−0012	Assembly − Transmission	1
35	3296−39	Nut − Lock	2
36	237−161	O−Ring	1
37	86−7220	Gear − Pinion	1
38	32151−62	Ring − Retaining	1
39	92−4846	Asm. − Trans. Support (Incl. Ref. #14 & 15)	1
40	354−75	Fitting − Hydraulic 90˚ (Incl. Ref. #25)	1
41	75−6340	Strainer − In−Line	1
42	354−72	Fitting − Hydraulic 45˚	1
43	42−6080	Shim − Axle	A/R
44	66−6480	Washer − Flat	4
45	3296−48	Nut − Lock	4
46	93−0084	Assembly − Front Axle	1


‡For different language versions of this part, see International Parts Reference.



FRONT AXLE & TRANSMISSION ASSEMBLY (Continued)

Ref. No.	Part No.	Description	No. Used
47	75−6850	Tube − Oil Fill	1
48	27−3710	Dipstick − Axle	1
49	323−20	Screw − Cap Hex. Hd.	2
50	3218−1	Nut − Jam	1

Ref. No.	Part No.	Description	No. Used
51	237−181	O−Ring	1
52	217−120	Rim	2
53	231−134	Tire	2




T−1315A

FRONT AXLE ASSEMBLY NO. 93−0084

Ref. No.	Part No.	Description	No. Used
1	3219−2	Nut	8
3	21−8270	Pin−Dowel	2
4	21−7720	Washer−Thrust	2
5	24−8790	Gear−Bevel, Differential	2
6	21−7690	Gear−Pinion	2
7	21−7730	Washer−Thrust	2
†8		Pinion−Drive	1
9	43−6760	Cone−Bearing, tapered	1
10	43−6750	Cup−Bearing, Tapered	1
11	92−1773	Screw−Cap, Hex Hd.	4
13	32144−112	Screw−Thread Forming	8
14	86−7230	Gear−Spur	1
15	43−6710	Diff. Adjust. Shim .003	A/R
16	43−6711	Diff. Adjust. Shim .005	A/R
17	43−6712	Diff. Adjust. Shim .010	A/R
18	43−6713	Diff. Adjust. Shim .030	A/R
19	3210−8	Screw − Cap, Hex Hd.	8
20	71−4350	Nut	1
21	83−5130	Spacer − Pinion	1
22	72−3570	Shim .094 − Diff. Adjust.	A/R
*	72−3571	Shim .096 − Diff. Adjust.	A/R
*	72−3572	Shim .098 − Diff. Adjust.	A/R
22	72−3573	Shim .100 − Diff. Adjust.	A/R

Ref. No.	Part No.	Description	No. Used
*	72−3574	Shim .102 − Diff. Adjust.	A/R
*	72−3575	Shim .104 − Diff. Adjust.	A/R
*	72−3576	Shim .106 − Diff. Adjust.	A/R
*	72−3577	Shim .108 − Diff. Adjust.	A/R
*	72−3578	Shim .110 − Diff. Adjust.	A/R
*	72−3580	Shim .112 − Diff. Adjust.	A/R
*	72−3581	Shim .114 − Diff. Adjust.	A/R
*	72−3582	Shim .116 − Diff. Adjust.	A/R
*	72−3583	Shim .118 − Diff. Adjust.	A/R
*	72−3584	Shim .120 − Diff. Adjust.	A/R
*	72−3585	Shim .125 − Diff. Adjust.	A/R
*	72−3586	Shim .127 − Diff. Adjust.	A/R
*	72−3587	Shim .129 − Diff. Adjust.	A/R
*	72−3588	Shim .131 − Diff. Adjust.	A/R
*	72−3590	Shim .133 − Diff. Adjust.	A/R
*	72−3591	Shim .135 − Diff. Adjust.	A/R
*	72−3592	Shim .137 − Diff. Adjust.	A/R
*	72−3593	Shim .139 − Diff. Adjust.	A/R
*	72−3594	Shim .141 − Diff. Adjust.	A/R
*	72−3595	Shim .143 − Diff. Adjust.	A/R
*	72−3596	Shim .145 − Diff. Adjust.	A/R
*	72−3597	Shim .147 − Diff. Adjust.	A/R

*Not Illustrated
†Not Serviced Separately




T−1315A

FRONT AXLE ASSEMBLY NO. 93−0084 (Continued)

Ref. No.	Part No.	Description	No. Used
22	72−3598	Shim .149 − Diff. Adjust.	A/R
*	72−3600	Shim .151 − Diff. Adjust.	A/R
23	254−91	Cone−Bearing	1
24	21−8390	Cup−Bearing	1
25	21−8020	Spacer−Front Pinion	1
26	93−3619	Upper Housing (Incl. Ref. #11)	1
27	254−66	Cup−Tapered Bearing	2
28	254−65	Cone−Tapered Bearing	2
†29		Gear−Ring	1
30	21−7710	Pin−Roll	1
31	21−7700	Shaft−Pinion Mate	1
32	21−7770	Screw−Drive Gear	5
33	21−7670	Case−Differential	1

Ref. No.	Part No.	Description	No. Used
34	75−0721	Housing−Lower	1
35	21−8120	Diff. Adjust. Shim .030	A/R
36	21−8110	Diff. Adjust. Shim .010	A/R
37	21−8100	Diff. Adjust. Shim .005	A/R
38	21−8090	Diff. Adjust. Shim .003	A/R
39	72−9420	Assembly − Vent Tube	1
40	83−4910	Coupler − Pinion	1
41	71−4330	Seal	1
*	93−3618	Assembly − Gear & Pinion (Incl. Ref. #8 & 29)	1
*	93−3617	Assembly − Differential (Incl. Ref. #4−10, 14−33, 35−38, 40 & 41)	1

*Not Illustrated
†Not Serviced Separately




BRAKE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	27−6862	Shaft−Axle, Flanged L.H.	1
*	27−6852	Shaft−Axle, Flanged R.H.	1
2	92−1774	Seal−Oil	2
3	21−8180	Bearing	2
4	24−9180	Lever, Brake, Parking	2
5	21−9450	Shield−Dust	2
6	43−6810	Spider−Torque	2
7	21−9430	Spring−Shoe Return, R.H.	2
8	28−0670	Seal−Oil	2
9	84−8590	Assembly − Shoe & Lining	4
10	21−9460	Retainer−Brake, Parking	4
11	242−34	Stud−Flange, Axle	10

Ref. No.	Part No.	Description	No. Used
12	21−8360	Clip−Retaining	2
13	28−0680	Drum−Brake	2
14	21−9440	Spring−Adjusting Screw	2
15	21−9390	Socket−Adjusting Screw	2
16	21−9370	Screw−Adjusting	2
17	21−9380	Nut−Pivot	2
18	43−6800	Nut−Lock	8
19	21−9420	Spring−Shoe Return, L.H.	2
21	28−0660	Screw−Cap, Hex Hd.	8
22	24−8840	Ring−Bearing, Wheel	2
*	84−8600	Set of Lined Brake Shoes	1
*	92−8775	Gasket − Kit, Liquid	1

*Not Illustrated




TRANSMISSION ASSEMBLY NO. 75−0012

Ref. No.	Part No.	Description	No. Used
1	75−0430	Ring − Retaining	1
2	75−0150	Guide − Seal	1
3	75−0410	O−Ring	1
4	75−0520	Bearing − Ball	1
5	75−0020	Housing	1
6	75−0210	O−Ring	2
7	86−7520	Asm. − Trunnion Cover R.H.	1
8	75−0230	Seal − Lip	1
9	75−0090	Screw − Cap Hex Hd.	8
10	75−0480	Pin	2
11	86−7540	Shaft − Pump	1
12	75−0390	Plate − Swash	1
13	75−0400	Plate − Thrust	2
14	75−0470	Cylinder Block Kit	2
15	75−0380	Plate − Valve	1
16	75−0500	Bearing − Needle	2
17	75−0510	Pin	1
18	75−0040	Center Section	1
19	75−0170	Plug − Straight Thread	4
20	75−0060	Plug	4
21	75−0240	O−Ring	6
22	75−0290	Spring	2
23	75−0260	Valve − Relief	4
24	75−0130	Screw − Cap Hex. Hd.	3
25	93−0097	Valve − SCR	1
26	75−0140	Spring − Conical	1
27	75−0190	Plug − Special	2

Ref. No.	Part No.	Description	No. Used
28	75−0120	Screw − Cap Hex Hd.	1
29	75−0370	O−Ring	1
30	75−0360	Gerotor	1
31	75−0350	Pin	1
32	83−4780	Housing − Charge Pump	1
33	75−0340	Bearing − Needle	1
34	75−0330	Seal − Lip	1
35	75−0110	Screw − Cap Hex Hd.	2
36	75−0180	Screw − Cap Hex Hd.	2
37	75−0320	Nipple	1
38	75−0200	Plug − Straight Thread	2
39	75−0270	Spring	1
40	75−0310	Shim	1
41	75−0070	Plug	1
42	75−0280	Spring	1
44	93−0083	Plate − Valve	1
45	75−0440	Shaft − Motor	1
46	75−0030	Gasket − Housing	1
47	75−0160	Plug − Pipe	1
48	75−0220	Pin	2
49	86−7530	Asm. − Trunnion Cover L.H.	1
50	75−0450	Collar	1
51	75−0460	Bearing − Ball	2
52	75−6930	Valve − SCR	1
53	32120−74	Ring − Retaining	1
54	75−0250	Pin − Slotted	1


*Not Illustrated



TRACTION CONTROL ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	3272−10	Pin − Cotter	1
2	3256−26	Washer − Flat	1
3	322−10	Screw − Cap Hex. Hd.	1
4	32105−21	Screw	2
6	29−6162	Switch − Neutral	1
7	75−4130	Plate − Switch	1
8	76−9430	Spring − Extension	1
9	3296−29	Nut − Lock	4
10	322−7	Screw − Cap Hex. Hd.	1
11	251−259	Bearing − Ball	2
12	75−5470	Spacer	2
13	32144−22	Screw − Cap Hex. Hd.	4
15	75−4080	Plate − Traction	1
16	85−9900	Plate − Spring Anchor	1

Ref. No.	Part No.	Description	No. Used
17	3253−4	Washer − Lock	2
18	322−3	Screw − Cap Hex. Hd.	2
19	256−113	Bushing − Flange	2
20	302−5	Fitting − Grease	1
21	92−2581	Assembly − Switch Arm (Incl. Ref. #19 & 20)	1
22	3−6498	Washer − Thrust	2
23	76−8640	Stud − Traction	1
24	3296−9	Nut − Hex.	2
25	75−4100	Control − Pump	1
26	23−2270	Bushing − Rubber	1
27	85−9910	Eyebolt	1
28	3217−6	Nut − Hex.	1




GEAR PUMP INSTALLATION ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	75−6870	Hose − Suction	1
2	2412−34	Clamp − Hose	1
3	354−78	Fitting − Hydraulic	1
4	323−12	Screw − Cap Hex. Hd.	2
5	3253−5	Washer − Lock	2
6	93−3604	Gasket	1
7	93−1396	Coupler W.A. − Trans.	1
8	75−4400	Adaptor − Transmission	1
9	237−163	O−Ring	1
10	340−4	Fitting − Hydraulic Straight (Incl. Ref. #11 & 17)	2

Ref. No.	Part No.	Description	No. Used
11	237−30	O−Ring	2
12	93−3642	Tube − Hydraulic	1
13	93−3643	Tube − Hydraulic	1
14	75−6240	Hose − Hydraulic	1
15	237−22	O−Ring	1
16	340−3	Fitting − Hydraulic Straight (Incl. Ref. #15 & 17)	1
17	237−79	O−Ring	3
18	93−1376	Assembly − Pump, Gear	1
19		O−Ring	1

3317−872




T−1935

HYDRAULIC PUMP NO. 93−1376

Ref. No.	Part No.	Description	No. Used
1		Ring − Retaining	1
2		Seal − Shaft	1
3		Flange	1
4	93−4278	Pin − Dowel	4
5		Housing	1
6		O−Ring	2
7		Gear − Idler	1
8		Gear − Drive	1
9	93−4280	Coupling	2
10		Bearing	2
11		E−Seal	2
12		Ring − Backup	2
13	93−4279	Plate − Distance	2
14		Housing	1
15		Gear − Idler	1
16		Gear − Idler	1
17	93−4283	Bolt	4

Ref. No.	Part No.	Description	No. Used
18	93−4282	Block − Valve	1
19	93−4277	Kit − Valve	1
20		Gear − Idler	1
21		Housing	1
22	93−4281	Pin − Dowel	4
*	93−4268	Kit − Flange (Incl. Ref. #1−3)	1
*	93−4269	Kit − Housing, Section 1 (Incl. Ref. #6, 7, 10−12, 14 & 15)	1
*	93−4270	Kit − Housing, Section 2 (Incl. Ref. #5−8, & 10−12)	1
*	93−4271	Kit − Housing, Section 3 (Incl. Ref. #6,10−12, 16, & 20−21)	1
*	93−4272	Kit − Individual Pieces (Incl. Ref. #2, 6, 11, & 12)	1

*Not Illustrated




RADIATOR ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	93−1374	Latch − Swell	2
2	93−0032	Hsg. W.A. − Front Screen	1
3	3234−5	Screw − Whiz Lock	6
4	93−0090	Bracket − Mount RH, Cooler	1
*4	93−0089	Bracket − Mount LH, Cooler	1
5	3269−15	Rivet − Pop	8
6	75−0930	Hook − Oil Cooler	4
7	93−0038	Support W.A. − Radiator	1
8	32128−20	Nut − Whiz	6
9	93−0030	Asm. − Cooler Mount R.H. (Incl. Ref. #4−6)	1
*	93−0071	Asm. − Cooler Mount L.H. (Incl. Ref. #*4−6)	1
10	304−46	Drain − Radiator	1
11	93−0005	Strip − Foam, Top	1
12	93−0020	Radiator	1
13	66−3240	Cap − Radiator	1
14	92−2379	Clamp − Hose	2
15	2412−34	Clamp − Hose	2
16	75−2851	Hose − Expansion Tank	1
17	3290−378	Tie − Cable	1
18	93−0023	Hose − Radiator Upper	1
19	93−0022	Shroud − Fan	1

Ref. No.	Part No.	Description	No. Used
20	3290−271	Rivet − Pop	2
‡21	76−8750	Plate − Caution	1
21	93−6681	Plate − Caution (Europe)	1
22	3256−22	Washer − Flat	4
23	321−4	Screw − Cap Hex. Hd.	7
24	93−0024	Hose − Radiator Lower	1
25	3296−42	Nut − Lock	7
26	66−3180	Tube − Vent	1
27	2412−3	Clamp − Hose	2
28	75−4701	Hose − Fuel Vent	1
29	2412−103	Clamp − R	2
30	3269−10	Washer − Back−up	7
32	3269−13	Rivet − Pop	17
33	93−0025	Shield W.A. − Radiator	1
34	32148−7	Nut − Clinch	2
35	93−3626	Bracket − Hose	1
36	322−4	Screw − Cap Hex. Hd.	2
37	93−7840	Decal − Radiator Cap (Europe)	1
38	3256−23	Washer − Flat	4
39	3253−4	Washer − Lock	4
42	63−7590	Relay − Starter	1
43	322−2	Screw − Cap Hex. Hd.	2

*Not Illustrated
‡For different language versions of this part, see International Parts Reference.




RADIATOR ASSEMBLY (Continued)

Ref. No.	Part No.	Description	No. Used
44	75−1020	Switch − Backlap (Incl. Ref. #54)	1
45	24−0760	Exchanger − Heat	1
46	93−0076	Hose − Trans. to Cooler	1
*	93−0075	Hose − Trans. to Cooler	1
47	237−22	O−Ring	2
48	340−124	Fitting − Straight	2
49	93−0077	Hose − Cooler, R.H.	1
*	93−0078	Hose − Cooler, L.H.	1
50	237−65	O−Ring	2
51	92−4999	Fitting − Hydraulic 90˚ (Incl. Ref. #50)	2

Ref. No.	Part No.	Description	No. Used
52	75−1040	Cooler − Oil	1
‡53	75−0750	Decal − Backlap	1
53	93−6684	Decal − Backlap (Europe)	1
54	218−498	Nut − Lock	2
55	75−3390	Bracket − Backlap	1
56	66−8800	Relay − Glow Plug	1
57	240−3	Grommet	2
58	93−0082	Grommet	2
59	3296−29	Nut − Lock	2
60	322−5	Screw − Cap Hex. Hd.	4

*Not Illustrated

‡For different language versions of this part, see International Parts Reference.




T−2016

FAN GUARD & FLYWHEEL SHIELD ASSEMBLY (Europe)

Ref. No.	Part No.	Description	No. Used
1	93−9933	Shield − Flywheel	1
2	321−6	Screw − Cap Hex. Hd.	4
3	3256−22	Washer − Flat	8

Ref. No.	Part No.	Description	No. Used
4	93−7182	Guard − Fan	1
5	3296−42	Nut − Lock	4

*Not Illustrated




T−1883

MUFFLER & PUMP DRIVE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	54−9040	Yoke − End	1
2	322−9	Screw − Cap Hex. Hd.	2
3	93−0047	Yoke − Shaft	1
4	93−0045	Yoke − Slip Tube	1
5	302−5	Fitting − Grease	1
6	66−9303	Screw − Cap Hex. Hd.	3
7	86−3040	Coupling − Driveshaft	1
8	43−2740	Gasket	1
9	43−2750	Nut − Lock	1
10	63−7440	Solenoid − Stop	1
11	3234−17	Screw − Cap Hex. Hd.	1
12	3256−70	Washer − Flat	2
13	93−0044	Muffler	1
*	75−6880	Screen − Spark Arrester (Optional)	1

Ref. No.	Part No.	Description	No. Used
14	3296−29	Nut − Lock	2
15	93−3423	Gasket − Muffler	1
16	42−9850	Washer − Lock	6
17	48−7930	Nut − Lock	4
18	32128−20	Nut − Flange Head	1
19	66−9302	Screw − Cap Hex. Hd.	3
21	2412−81	Clamp − R	1
20	48−7710	Screw − Cap Hex. Hd.	2
22	93−3644	Guard − Flywheel	1
23	3296−44	Nut − Lock	3
24	62−3820	Fitting − Grease	1
25	54−9180	Kit − U−Joint	1
*	93−0047	Assembly − U−Joint (Incl. Ref. 1, 3, & 24−25)	1

*Not Illustrated




ENGINE INSTALLATION ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	74−5520	Clutch − Fan	1
2	75−3780	Fan	1
3	75−6380	Shaft − Fan	1
4	32121−2	Pin − Roll	2
5	75−6390	Pulley − Fan	1
6	47−0110	Spacer − Spindle	1
7	251−318	Bearing − Ball	2
8	75−5310	Spacer − Bearing	1
9	75−4450	Hub − Fan Drive	1
10	67−1630	Spacer − Fan	1
11	323−6	Screw − Cap Hex. Hd.	2
12	321−4	Screw − Cap Hex. Hd.	1
13	3−6657	Clamp − Cable	1
14	322−3	Screw − Cap Hex. Hd.	4
15	3230−2	Bolt − Carriage	1
16	2412−4	Clamp	2
17	3256−23	Washer − Flat	6
18	322−4	Screw − Cap Hex. Hd.	2
19	93−0048	Hose − Air Cleaner	1
20	2412−92	Clamp − Hose	1
21	48−7700	Screw − Cap Hex. Hd.	1
22	3255−8	Washer − Lock	2
23	75−1360	Cable − Battery (Ground)	1

Ref. No.	Part No.	Description	No. Used
24	93−0049	Assembly − Engine	1
25	3256−78	Washer − Flat	1
26	43−5930	Washer − Lock	1
27	48−7890	Nut − Hex.	1
28	42−9850	Washer − Lock	2
29	93−0050	Bracket − Engine L.H. Rear	1
*	93−0063	Bracket − Engine R.H. Rear	1
30	93−0092	Mount − Rubber, Rear	2
31	325−4	Screw − Cap Hex. Hd.	8
32	3253−7	Washer − Lock	8
33	93−0093	Bracket − Eng. Left Rear	1
*	93−3621	Bracket − Eng. Right Rear	1
34	63−7400	Washer − Flat	4
35	3253−21	Washer − Lock	1
36	323−12	Screw − Cap Hex. Hd.	1
37	57−6390	Nut − Lock	2
38	3296−39	Nut − Lock	4
39	48−8070	Washer − Lock	10
40	42−9250	Screw − Cap Hex. Hd.	8
41	70−8220	Cable − Ground	1
43	3296−29	Nut − Lock	10
44	323−14	Screw − Cap Hex. Hd.	3
45	93−0095	Bracket − Eng. Front	2


*Not Illustrated



ENGINE INSTALLATION ASSEMBLY (Continued)

Ref. No.	Part No.	Description	No. Used
46	53−9680	Mount − Engine	2
47	322−6	Screw − Cap Hex. Hd.	8
48	93−0051	Bracket − Engine L.H. Front	1
49	3255−9	Washer − Lock E.T.L.W.	1
50	3256−24	Washer − Flat	4
51	2412−71	Clamp − R	1
52	93−0054	Bracket W.A. − Fan	1
53	27−9560	Spacer	1
54	3296−59	Nut − Lock	1
55	93−0043	Bracket − Fan Idler	1
56	93−0062	Belt − V	1

Ref. No.	Part No.	Description	No. Used
57	323−7	Screw − Cap Hex. Hd.	1
58	63−8140	Pulley − Idler	1
59	32149−1	Nut − Lock	1
60	3253−4	Washer − Lock	4
61	322−2	Screw − Cap Hex. Hd.	4
62	93−0074	Support − Cable	1
63	3296−42	Nut − Lock	1
64	42−9300	Screw − Cap Hex. Hd.	1
65	42−9600	Washer − Lock	1
66	3256−40	Washer − Flat	2




T−1892A

TIMING GEAR, PISTON, FLYWHEEL & CRANKSHAFT

Ref. No.	Part No.	Description	No. Used
1	93−3351	Gear − Pump, Injection	1
2	93−3352	Assembly − Idler, Gear (Incl. Ref. #36)	1
3	93−3364	Ball − Steel	1
4	93−3363	Assembly − Shaft, Idler (Incl. Ref. #3)	1
5	42−7190	Bushing	2
6	42−9440	Bolt W/Washer	4
7	93−3360	Cover	1
8	93−3361	Gasket − Cover	1
9	93−3365	Pin − Dowel	2
10	93−3366	Cap − Sealing	1
11	93−3356	Nut	1
12	93−3355	Washer − Spring	1
13	42−9810	Washer − Plain	1
14	93−3357	Pulley − Crankshaft	1
15	93−3359	Gear − Crankshaft	1
16	93−3370	Bearing − Con−Rod	6
17	93−3373	Bolt − Connecting	6
18	93−3374	Pin − Piston	3
19	93−3375	Ring Set − Piston	3
20	93−3596	Pipe − Oil Jet	3

Ref. No.	Part No.	Description	No. Used
22	93−3376	Piston − Std.	3
*	93−3377	Piston − O.S. 0.25	3
*	93−3378	Piston − O.S. 0.50	3
23	93−3371	Asm. − Rod, Connecting (Incl. Ref. #16, 17 & 29−30)	3
24	43−1810	Ring − Gear	1
25	93−3358	Assembly − Sub, Flywheel (Incl. Ref. #24)	1
26	54−8670	Bolt	4
27	93−3354	Crankshaft	1
28	42−7730	Key − Woodruff	2
29		Cap − Rod, Connecting	3
30	93−3372	Nut	6
31	93−3369	Cap − Sealing	2
32	93−3367	Plug − Taper	1
33	93−3368	Bolt	4
34	93−3362	Bushing − Camshaft	1
35	93−3350	Gear − Camshaft	1
36	93−3353	Bushing − Idler	1
*	93−3379	Set − Ring, Piston O.S. 0.25	3
*	93−3380	Set − Ring, Piston O.S. 0.50	3

*Not Illustrated




T−1893

CYLINDER BLOCK AND BEARING ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	56−0220	Pin − Dowel	2
2	93−3381	Cap − Sealing	2
3	67−2570	Plug − Taper	1
4	93−3382	Cap − Sealing	1
5	42−7180	Bushing	4
6	56−1230	Shaft	1
7	93−3383	Seal − Side	4
8	56−0100	Plug − Taper	1
9	93−3385	Cap − Metal	1
10	42−9210	Bolt − Cap, Bearing	8
14	93−3387	Bearing − Set Std.	1

Ref. No.	Part No.	Description	No. Used
*14	93−3597	Bearing − Set U.S. 0.25 mm	1
*	93−3388	Bearing − Set U.S. 0.50 mm	1
*	93−3389	Bearing − Set U.S. 0.75 mm	1
15	93−3386	Cap − Sealing	3
16	72−6950	Retainer	1
17	42−7200	Bushing	1
18	42−7160	Pin − Dowel	1
19	42−7170	Plug − Expansion	1
20	93−3384	Asm. − Block, Cylinder (Incl. Ref. # 2, 9, & 10. Also #31, 32, & 34 on Page 36)	1

*Not Illustrated



T−1894


VALVE, CAMSHAFT AND ROCKER ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	42−7990	Ring − Snap	2
2		Shaft − Rocker	1
3		Rocker	6
4	93−3401	Screw − Rocker	6
5	70−2970	Nut − Jam	6
6	93−3403	Bracket − Shaft, Rocker	2
7	93−3406	Spring − Rocker	2
8	93−3405	Cap − Sealing	2
9	93−3399	Bolt	1
10	93−3407	Bolt − Bracket, Rocker	3
11	93−3402	Bracket, Shaft, Rocker	1
12	93−3397	Cap − Valve	6
13	42−7860	Seal	6
14	67−3100	Retainer	6
15	92−1961	Seal	6
16	93−3396	Spring − Valve	6
17	93−3410	Bolt W/Washer	1
18	42−9820	Washer	1

Ref. No.	Part No.	Description	No. Used
19	93−3409	Bearing	1
20	42−7840	Key − Sunk	1
21	93−3408	Shaft − Pump, Fuel Inject.	1
22	93−3411	Rod − Push	6
23	42−7890	Tappet	6
24	93−3412	Camshaft	1
25	42−7730	key − Woodruff	1
26	60−7390	Plate − Thrust	1
27	67−2340	Bolt W/Washer	2
28	93−3395	Valve − Exhaust	3
29	93−3394	Valve − Inlet	3
*	93−3398	Asm. − Rocker & Shaft (Incl. Ref. #1−11)	1
*	93−3404	Assembly − Shaft (Incl. Ref. #2 & 8)	1
*	93−3400	Assembly − Rocker (Incl. Ref. #3−5)	1

*Not Illustrated

3317−872




T−1895A

OIL PAN, PUMP RELIEF VALVE

Ref. No.	Part No.	Description	No. Used
1	93−3418	Gauge − Level, Oil	1
2	42−8830	O−Ring	1
3	93−7013	Guide − Gauge, Oil Level	1
4	93−4295	Assembly − Filter, Oil	1
5	56−1310	Switch − Oil	1
6	92−1920	Plug − Drain	1
7	92−1921	Gasket − Plug, Drain	1
8		Pan − Oil	1
9	93−3422	Assembly − Pan, Oil (Incl. Ref. #6, 7, & 8)	1
10	67−2340	Bolt W/Washer	15
11	93−3414	Gasket	1
12	48−1990	Nut − Jam	1
13	93−3413	Assembly − Strainer (Incl. Ref. #12)	1
14	93−3421	Bolt	3
15	93−3420	Assembly − Pump, Oil	1
16	93−3417	Gasket	1
17	93−3416	Housing	1
18	67−2500	Plunger	1
19	42−8930	Spring	1
20	42−7290	Gasket	1
21	67−2520	Plug	1
22	93−3415	Assembly − Valve, Relief (Incl. Ref. #16−21)	1
23	93−4291	Fitting − Pump, Water	1
24	93−4296	Clamp−R	1
25	93−4290	Connector − Cooler	1
26	93−4285	Cooler − Oil, Engine	1
27	93−4297	Clamp − Hose	4
28	93−4289	Hose − Cooler, Outlet	1
29	93−4288	Fitting − Block, Engine	1
30	93−4287	O−Ring	1
31	93−4284	Spacer − Cooler, Engine	1
32	93−4286	O−Ring	1
33	93−4294	Hose − Cooler, Inlet	1
34	42−9440	Bolt w/Washer	1
35	93−4292	Tube − Cover, Spiral	1
*	93−3599	Gasket − Liquid (For Oil Pan)	1

*Not Illustrated




T−1896A

CYLINDER HEAD, MANIFOLD & COVER ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	67−4580	Bolt	2
2	60−7280	Bolt	4
3	42−9570	Stud	4
4	93−3423	Gasket	1
5	93−3424	Gasket − Cover, Rocker	1
6	42−7440	Hanger − Engine	2
7	42−7080	Cap − Sealing	5
8	93−3425	Guide − Valve, In	3
9	93−3435	Bolt W/Washer	4
10	42−7420	Cap − Oil	1
11	93−3433	Assembly − Cover, Rocker (Incl. Ref. #12)	1
12	42−7510	Pipe	1
13	93−3594	Hose − Breather	1
14	93−3426	Bolt − Head, Cylinder	11
15	93−3427	Guide − Valve	3
16	67−2570	Plug − Taper	1
17	93−3428	Assembly − Head, Cylinder (Incl. Ref. #7, 8, 15, 28 & 29)	1

Ref. No.	Part No.	Description	No. Used
18	93−3434	Gasket − Cover, Inlet	1
19	93−3598	Cap − Sealing	1
20	93−3438	Assembly − Cover, Inlet (Incl. Ref. #19)	1
21	93−3440	Pipe − Inlet	1
22	92−2143	Bolt W/Washer	5
23	93−3442	Bolt W/Washer	1
24	93−3443	Bolt W/Washer	1
25	93−3441	Gasket − Pipe, Inlet	1
26	93−3431	Gasket − Head, Cylinder	1
27	93−3432	Bolt W/Washer	2
28	93−3430	Jet − Combustion	3
29	93−3429	Cap − Sealing	1
30	93−3436	Gasket − Exhaust	1
31	93−3437	Asm. − Manifold, Exhaust	1
32	93−3595	Clip − Hose	1




T−1897

TIMING GEAR CASE

Ref. No.	Part No.	Description	No. Used
1	93−3444	Cap − Filler	1
2	93−3445	Gasket − Gear	1
3	67−2340	Bolt W/Washer	7
4	93−3446	Plate − Front	1

Ref. No.	Part No.	Description	No. Used
5	93−3447	Gasket − Plate, Front	1
6	93−3448	Case − Gear	1
7	42−7390	Seal − Oil	1
8	93−3449	Bolt	8




T−1898

WATER PUMP ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	93−3459	Bolt W/Washer	4
2	93−3458	Pulley − Pump, Water	1
3	93−3460	V−Belt	1
4	93−3456	Bolt W/Washer	3
5	93−3452	Joint	1
6	93−3451	Bolt W/Washer	2

Ref. No.	Part No.	Description	No. Used
7	93−3450	Assembly − Pump, Water (Incl. Ref. #5−6 & 8−9)	1
8	93−3453	Gasket	1
9	93−3454	Plate	1
10	93−3455	Gasket − Pump, Water	1
11	93−3457	Bolt W/Washer	1




T−1899

FUEL INJECTION PUMP ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	72−0270	Nut − Retaining	3
2	93−3503	Assembly − Nozzle	3
3	72−0280	Piece − Distance	3
4	93−3502	Pin − Pressure	3
5	93−3501	Spring − Pressure	3
6	93−3491	Washer − 1.25 mm	A/R
*	93−3492	Washer − 1.3 mm	A/R
*	93−3493	Washer − 1.35 mm	A/R
*	93−3494	Washer − 1.4 mm	A/R
*	93−3495	Washer − 1.45 mm	A/R
*	93−3496	Washer − 1.5 mm	A/R
*	93−3497	Washer − 1.55 mm	A/R
*	93−3498	Washer − 1.6 mm	A/R
*	93−3499	Washer − 1.65 mm	A/R
*	93−3500	Washer − 1.7 mm	A/R
7	93−3490	Assembly − Sub, Body	3
8	93−3480	Screw − Bleeder, Air	1
9	93−3481	Washer − Union , Pipe	1
10	93−3479	Screw − Hollow	1
11	93−3467	Assembly − Sub, Element	3
12	93−3466	Assembly − Sub, Valve	3
13	93−3465	Gasket − Delivery, Valve	3
14	93−3464	Spring − Delivery, Valve	3
15	93−3474	O−Ring	3
16	93−3463	Holder − Delivery, Valve	3
17	93−3488	Rivet	2

Ref. No.	Part No.	Description	No. Used
18	93−3487	Plate − Name	1
19	93−3478	Bolt − Washer Head	2
20	93−3477	Plate − Adjusting	2
21	93−3475	Pin − Guide, Tappet	3
22	93−3476	Plate	1
23	93−3472	Assembly − Control, Rack	1
24	93−3468	Sleeve − Control	3
25	93−3469	Seat − Spring, Upper	3
26	93−3470	Spring − Plunger	3
27	93−3473	Seat − Spring, Lower	3
28	70−3970	Plate − Shim .6 mm	A/R
*	70−4070	Plate − Shim .2 mm	A/R
*	70−4080	Plate − Shim .3 mm	A/R
*	70−4090	Plate − Shim .4 mm	A/R
*	70−4100	Plate − Shim .5 mm	A/R
*	93−3482	Plate − Shim .25 mm	A/R
*	93−3483	Plate − Shim .35 mm	A/R
*	93−3484	Plate − Shim .45 mm	A/R
*	93−3485	Plate − Shim .55 mm	A/R
*	93−3486	Plate − Shim .65 mm	A/R
29	93−3471	Assembly − Sub, Tappet	3
30	93−3462	Assembly − Sub, Housing	1
*	93−3461	Assembly − Pump, Fuel (Incl. Ref. #8−30)	1
*	93−3489	Assembly − Nozzle & Holder (Incl. Ref. #1−7)	1

*Not Illustrated




T−1900

THERMOSTAT AND ALTERNATOR MOUNT ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	93−3523	Assembly − Hose, Fuel (Incl. Ref. #20)	1
2	93−3528	Plug	1
3	93−3525	Gauge	1
4	56−2020	Bolt W/Washer	2
5	56−1360	Fitting − Outlet, Water	1
6	42−7550	Gasket	1
7	93−3524	Thermostat	1
8	93−3521	Gasket − Case, Thermostat	1
9	93−3527	Gasket	1
10	93−3526	Switch	1
11	93−3519	Assembly − Case, Therm. (Incl. Ref. #21)	1

Ref. No.	Part No.	Description	No. Used
12	93−3509	Nut	1
13	93−3510	Washer − Spring	1
14	93−3511	Washer − Plain	1
15	93−3512	Bolt − Alternator	1
16	93−3508	Plate − Adjusting	1
17	54−8660	Washer	1
18	67−4660	Bolt − Flange Head	1
19	93−3522	Bolt W/Washer	3
20	56−1400	Clip	2
21	93−3520	Pipe	1

*Not Illustrated




FUEL AND STARTER SYSTEM ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	42−9830	Washer − Seal	2
2	93−3518	Nipple − Swivel	1
3	93−3517	Bolt	4
4	67−3390	Gasket − Holder	3
5	42−8010	Shim − 0.2 mm	A/R
*	42−8020	Shim − 0.3 mm	A/R
*	42−8030	Shim − 0.4 mm	A/R
*	42−8040	Shim − 0.5 mm	A/R
*	42−8050	Shim − 0.6 mm	A/R
*	42−8060	Shim − 0.7 mm	A/R
*	42−8070	Shim − 0.8 mm	A/R
*	42−8080	Shim − 0.9 mm	A/R
*	42−8090	Shim − 1.0 mm	A/R
6	93−3507	Plate − Connection	1
7	93−3513	Pipe − Injector No.1	1
8	56−0750	Clamp A	2
9	43−2860	Bolt W/Washer	2
10	93−3514	Pipe − Injector No.2	1
11	93−3515	Pipe − Injector No.3	1
12	56−0760	Clamp B	2

Ref. No.	Part No.	Description	No. Used
13	67−3430	Nut	3
14	67−3440	Gasket − Return, Fuel	3
15	93−3516	Pipe − Leak Off, Fuel	1
16	93−3506	Plug − Glow	3
18	93−3393	Bolt	5
19	93−3390	Case − Seal, Oil	1
20	93−3392	Seal − Oil	1
21	93−3391	Gasket − Seal, Oil	1
22	93−3504	Assembly − Solenoid	1
23	43−2750	Nut	1
24	93−3505	Bracket − Starter	1
25	42−9240	Bolt W/Washer	3
26	67−2440	Bolt W/Washer	2
27	43−2580	Magnet	1
28	43−2560	Gasket	1
29	43−2550	Filter	1
30	43−2570	Gasket	1
*	53−8150	Assembly − Pump, Electric (Incl. Ref. #27−30)	1

*Not Illustrated




T−1902

GOVERNOR

Ref. No.	Part No.	Description	No. Used
1	93−3529	Assembly − Case, Governor	1
2	67−4240	Cap	1
3	93−3554	Bolt − Case, Governor	1
4	93−3553	Bolt	3
5	42−8690	Metal	1
6	93−3552	Wire	1
7	67−4180	Nut	1
8	67−4200	Nut	1
9	67−4220	Screw − Adjusting	1
10	93−3537	Spring − Torque	2
11	93−3536	Stopper	1
12	67−4210	Case	1
13	93−3535	Spring Set − Torque (Incl. Ref. #7−12)	1
14	93−3547	Spring − Rod, Tie	1
15	93−3546	Rod − Tie	1
16	93−3534	Spring − Governor	1
17	93−3542	Lever − Spring, Governor	1
18	93−3530	Pin − Spring	1

Ref. No.	Part No.	Description	No. Used
19	93−3543	Lever − Tension	1
20	42−7310	Bearing − Needle	2
21	93−3538	Spring − Start	1
22	93−3544	Lever − Governor	1
23	93−3539	Shim − Shaft, Governor	1
24	93−3545	Shaft − Governor	1
25	93−3531	O−Ring	1
26	93−3549	Shaft − Sleeve, Sliding	1
27	93−3550	Sleeve − Sliding	1
28	93−3551	Weight	1
29	93−3548	Gasket − Case, Governor	1
30	42−8810	Pin − Grooved	1
31	93−3533	Bolt − Speed Set	2
32	67−4290	Nut	2
33	93−3532	Nut − Jam	1
34	67−3260	Washer − Spring	1
35	93−3540	Lever − Speed	1
36	93−3541	Case − Governor	1




T−1903

STARTER ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	93−3576	Stopper Set	1
2	93−3567	Pinion Set (Incl. Ref. #1)	1
3	93−3556	Screw Set (Incl. Ref. #19)	1
4	93−3557	Assembly − Bracket, Front	1
5	93−3558	Assembly − Lever	1
6	93−3559	Spring Set	1
7	93−3560	Assembly − Bracket, Center	1
8	93−3561	Assembly − Switch	1
9	93−3572	Bolt Set	1
10	93−3570	Cover Set	1
11	93−3569	Gear	1
12	67−4790	Assembly − Shaft, Pinion	1
13	93−3563	Bearing − Front	1
14	93−3564	Bearing − Rear	1

Ref. No.	Part No.	Description	No. Used
15	93−3571	Assembly − Yoke	1
16	93−3573	Assembly − Holder (Incl. Ref. 20)	1
17	93−3575	Assembly − Bracket, Rear	1
18	93−3565	Bolt Set	2
19	93−3556	Screw	1
20	93−3574	Spring − Brush	4
21	93−3568	Gear Set (Incl. Ref. #11−12)	1
*	93−3566	Assembly − Shaft, Clutch (Incl. Ref. #2, 10 & 21)	1
*	93−3562	Armature Set (Incl. Ref. #13−14)	1
*	93−3555	Assembly − Starter (Incl. Ref. #1−21)	1

*Not Illustrated



T−1904


ALTERNATOR ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	93−3578	Nut − Set	1
2	93−3579	Assembly − Pulley	1
3	93−3582	Screw Set	1
4	93−3580	Bolt Set	1
5	93−3583	Bearing − Front	1
6	93−3585	Bearing − Rear	1
7	93−3584	Assembly − Rotor	1
8	93−3591	Nut − Set	1

Ref. No.	Part No.	Description	No. Used
9	93−3590	Assembly − Rectifier	1
10	93−3581	Assembly − Bracket, Front	1
11	93−3589	Brush	2
12	93−3586	Assembly − Stator	1
13	93−3588	Regulator Set	1
14	93−3587	Assembly − Bracket, Rear	1
*	93−3577	Assembly − Alternator (Incl. Ref. #1−14)	1


*Not Illustrated

OVERHAUL GASKET KIT



OVERHAUL GASKET KIT

Ref. No.	Part No.	Description	No. Used
101	93−3417	Gasket	1
102	42−7550	Gasket	1
104	67−3440	Gasket − Fuel Return	3
105	67−3390	Gasket − Holder	3
106	92−1961	Seal − Valve Stem	6
107	42−8830	O−Ring	1
108	93−3414	Gasket	1
109	93−3527	Gasket	1
110	93−3455	Gasket − Water Pump	1
111	93−3361	Gasket − Tie Rod Cover	1
112	93−3453	Gasket − Water Pump	1
113	93−3423	Gasket	1
114	93−3383	Seal − Side	4
115	93−3391	Gasket − Oil Seal Case	1
116	93−3447	Gasket − Front Plate	1
117	93−3445	Gasket − Gear	1
118	93−3441	Gasket − Inlet Pipe	1
119	93−3593	Packing − Body	1
120	93−3521	Gasket − Thermo Case	1
121	93−3548	Gasket − Governor Case	1
122	93−3431	Gasket − Cylinder Head	1
123	93−3424	Gasket − Rocker	1
124	93−3434	Gasket − Inlet Cover	1
125	93−3436	Gasket − Exhaust	1




ENGINE COMPONENTS ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	2412−42	Clamp − Hose	1
2	48−4220	Assembly − Air Cleaner (Incl. Ref. #4)	1
‡3	83−9150	Decal − Starting Fluid	1
3	93−6692	Decal − Starting Fluid (Europe)	1
‡4	27−7160	Decal − Instructions	1
4	93−8052	Decal − Instructions (Europe)	1
5	75−2851	Hose − Expansion Tank	1
6	92−2379	Clamp − Hose	1
7	63−7380	Assembly − Expansion Tank (Incl. Ref. #8)	1
8	71−1520	Cap − Expansion Tank	1
9	93−6668	Decal − Battery (Europe)	1
10	66−2330	Base − Battery	1
11	322−4	Screw − Cap Hex. Hd.	3
12		Battery (Type 26, 530 Amp.)	1

Ref. No.	Part No.	Description	No. Used
13	75−1370	Asm. − Battery Cable (+) (Incl. Ref. #14)	1
14	28−1280	Boot − Cable	1
15	323−9	Screw − Cap Hex. Hd.	1
16	3253−21	Washer − Lock	1
17	3256−24	Washer − Flat	1
18	66−2490	Clamp − Battery	1
19	32128−20	Nut − Lock	3
20	32128−33	Nut − Lock	2
21	75−4250	Bracket − Expansion Tank	1
22	321−6	Screw − Cap Hex. Hd.	2
23	2412−41	Clamp − R	1
24	75−3140	Bracket − Air Cleaner	1
25	3256−23	Washer − Flat	2
26	322−3	Screw − Cap Hex. Hd.	6
27	3296−29	Nut − Lock	4
28	3290−378	Tie − Cable	1
29	93−7276	Decal − Danger (Europe)	1

‡For different language versions of this part, see International Parts Reference.



T−0126A


AIR CLEANER ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	27−7150	Assembly − Cup	1
2	27−7140	Baffle	1
3	27−7120	Nut	1
4	27−7130	Assembly − Clamp	1
5	32107−11	Nut−Square	2
6	3258−19	Screw − Machine	2
7	27−7170	Assembly − Band (Incl. Ref. #5 & 6)	2
8	27−7110	Assembly − Element	1
9†		Housing	1

Ref. No.	Part No.	Description	No. Used
10	62−6300	Assembly − Sleeve	1
11	33−1270	Bowl	1
12	33−1260	Assembly − Cover	1
13	43−3810	Tube − Air Cleaner (Optional)	1
*	48−7430	Assembly − Pre−Cleaner (Incl. Ref. #10−12)	1
*	48−4220	Assembly − Air Filter (Incl. Ref. #1−4, 8−9)	1
*	27−7220	Air Cleaner Soap	1

*Not Illustrated
†Not Serviceable Separately

3317−872




T−1934

FUEL FILTER ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	63−8280	Head−Filter, Fuel (Incl. Ref. #2)	1
2	63−8290	Vent−Air	1
3	63−8300	Element−Spin−On (Incl. Ref. #4)	1

Ref. No.	Part No.	Description	No. Used
4	63−8310	Valve−Drain	1
*	63−8300	Assembly − Fuel Filter	1

*Not Illustrated



T−1325

REAR AXLE INSTALLATION ASSEMBLY


Ref. No.	Part No.	Description	No. Used
1	323−7	Screw − Cap Hex. Hd.	4
2	3256−24	Washer − Flat	2
3	325−5	Screw − Cap Hex. Hd.	4
4	327−2	Screw − Cap Hex. Hd.	1
5	75−1100	Support − Axle	1
6	83−5110	Stop − Axle	2
7	3296−23	Nut − Lock	4
8	3296−39	Nut − Lock	2
9	237−165	Grommet	2
10	3272−11	Pin − Cotter	1
11	323−9	Screw − Cap Hex. Hd.	2
12	83−5020	Assembly − Tube & Clamp	1
13	67−1750	Bushing − Sleeve	2
14	56−2460	Washer − Flat	2
15	83−5040	Washer	1
16	32136−13	Nut − Slotted	2
17	83−5100	Support − Cylinder	1
18	83−5150	Pin − Cylinder	1
19	32144−4	Screw − Self Tapping	1
20	237−78	O−Ring	2
21	340−132	Fitting − Hydraulic 90˚ (Incl. Ref. #20 & 22)	2
22	237−21	O−Ring	2
23	75−6220	Hose − Hydraulic	1
24	75−6230	Hose − Hydraulic	1
25	3290−378	Tie − Cable	1
26	82−6910	Screw − Cap Hex. Hd.	4
27	67−9410	Washer − Thrust	2

Ref. No.	Part No.	Description	No. Used
28	83−5030	Asm. − Hydraulic Cylinder	1
29	83−5160	Shim	2
30	48−9480	Screw − Cap Hex. Hd.	4
31	83−4930	Arm − Steering L.H.	1
32	71−4760	Seal − Tie Rod End	2
33	71−4740	Assembly − Tie Rod End (Incl. Ref. #16, 32 & 34)	2
34	302−55	Fitting − Grease	2
35	83−5180	Shim − Axle	2
‡36	70−2560	Decal − Lube	1
36	93−6697	Decal − Lube (Europe)	1
37	231−141	Tire	2
38	217−121	Rim	2
39	71−4450	Bolt − Wheel	10
40	232−35	Valve − Stem	2
41	83−7460	Spacer − Wheel	2
42	68−6823	Assembly − Axle	1
43	5−1226	Washer	2
44	75−4180	Pin − Rear Axle	1
45	3296−39	Nut − Lock	2
46	83−4950	Arm − Steering R.H.	1
47	48−9220	Washer − Flat	8
48	48−7780	Screw − Cap Hex. Hd.	8
49	302−11	Fitting − Grease	1
*	83−5010	Assembly − Tie Rod (Incl. Ref. #11, 12, 16, 32−34 & 45)	1

*Not Illustrated

‡For different language versions of this part, see International Parts Reference.

3317−872




T−1305A

REAR AXLE ASSEMBLY NO. 68−6823

Ref. No.	Part No.	Description	No. Used
1	72−5800	Bolt	8
2	72−4880	Cover	1
3	72−4890	O−Ring	1
4	251−344	Bearing − Ball	1
5	72−4960	Shim .1 mm	1
*	72−4970	Shim .15 mm	1
*	72−4980	Shim .5 mm	1
*	72−4990	Shim .8 mm	1
*	72−5000	Shim 1.0 mm	1
*	72−5010	Shim 1.2 mm	1
6		Gear − Bevel	1
7	72−5810	Bolt	8
8	72−4900	Case − Differential	1
9	72−4930	Gear − Side, Differential	1
10	72−4950	Gear − Pinion, Differential	2
11	72−5040	Washer − Gear, Diff.	1
12	72−4910	Flange − Case, Diff.	1
13	251−345	Bearing − Ball	1
14	93−3664	O−Ring	2
15	93−3665	O−Ring	2
16	83−5270	Tube − Axle, R.H.	1
17	83−5280	Axle − R.H.	1
18	251−350	Bearing − Ball	2
19	72−5360	Ring − Retaining	2
20	72−5100	Spacer	2
21	72−5090	Gear − Bevel	2

Ref. No.	Part No.	Description	No. Used
22	72−5370	Ring − Retaining	2
23	72−5130	Vent	1
24	72−4870	Case − Differential	1
25	72−5140	O−Ring	1
26	72−5150	Plug	1
27	72−5840	Gasket	1
28	72−5820	Plug	1
29	72−5160	Shim .1mm	1
*	72−5170	Shim .15 mm	1
*	72−5180	Shim .5 mm	1
*	72−5190	Shim .8 mm	1
*	72−5200	Shim 1.0 mm	1
*	72−5210	Shim 1.2 mm	1
30		Gear − Pinion	1
31	254−108	Bearing − Roller, Tapered	1
32	72−5460	O−Ring	1
33	83−5350	Case − Bearing	1
34	42−9850	Washer − Lock M8	8
35	48−9460	Bolt − Hex. Hd.	4
36	83−5360	Seal − Oil	1
37	83−5340	Nut − Bearing	1
38	83−5330	Washer − Bearing	1
39	254−109	Bearing − Roller, Tapered	1
40	72−4940	Gear − Side, Differential	1
41	83−5310	Axle − L.H.	1
42	42−9600	Washer − Lock M10	24




REAR AXLE ASSEMBLY NO. 68−6823 (Continued)

Ref. No.	Part No.	Description	No. Used
43	48−9470	Bolt − M10 x 30	24
44	83−5290	Tube − Axle, L.H.	1
45	72−5030	Pin − Dowel	2
46	72−5440	Pin −Spring	1

Ref. No.	Part No.	Description	No. Used
47	72−5020	Shaft − Pinion	1
*	83−5370	Assembly − Ring & Pinion (Incl. Ref.#6 & 30)	1

3317−872




T−0912A

REAR AXLE ASSEMBLY NO. 68−6823 (Continued)

Ref. No.	Part No.	Description	No. Used
1	93−3670	O−Ring	4
2	72−5740	Seal − Oil	2
3	251−348	Bearing − Ball	2
4	72−5720	Ring − Retaining	2
5	72−5580	Gear − Bevel	4
6	251−8	Bearing − Ball	2
7	93−3671	Pin − Dowel	4
8	93−3672	Arm − Knuckle	2
9	42−9600	Washer − Lock	28
10	48−9470	Screw − Cap, M10 x 30	4
12	251−347	Bearing − Ball	2
13	72−5790	Screw − Cap, M6 x 18	12
14	43−5930	Washer − Lock	12
15	72−5590	Retainer − Bearing	2
16	72−5630	Gasket	2
17	251−349	Bearing − Ball	2
18	72−5090	Gear − Bevel	2
19	72−5680	Spacer	2
20	72−5560	Pin − King, Knuckle	2

Ref. No.	Part No.	Description	No. Used
21	93−3668	Washer − Thrust	2
22	93−3669	Bearing − Needle	2
23	93−3666	Gear Box − Axle	2
24	72−5730	Seal − Oil	4
25	251−263	Bearing − Ball	2
26	72−5550	Cover	2
27	281−10	Plug − Socket, Hex.	2
28	48−9460	Screw − Cap, M8 x 25	20
29	42−9850	Washer − Lock, M8	28
30	72−5540	Case − Knuckle	2
31	3272−17	Pin − Cotter	2
32	72−5770	Nut − Castle	2
33	72−5660	Washer − Shaft, Wheel	2
34	72−5650	Hub − Wheel	2
35	72−5570	Shaft − Axle, Outer	2
36	72−5780	Key	2
37	281−7	Plug − Pipe, Square Hd.	2
38	93−3667	Case − Knuckle	2
39	48−7710	Screw − Cap, M8 x 20	4




T−0996

HYDRAULIC CYLINDER NO. 83−5030

Ref. No.	Part No.	Description	No. Used
†1		Assembly − Barrel	1
2	75−1210	Nut−Lock	1
3	75−1220	Piston	1
4	75−1260	Head−Internal	1
5	83−5380	Assembly − Piston Rod	1
6	75−1250	Seal Kit	1
7	302−5	Fitting − Grease	2

†Not Serviced Separately




T−1299

DRIVE SHAFT ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	3230−3	Bolt − Carriage	3
2	83−7470	Shim	2
3	83−4970	Bracket − Bearing	1
4	302−5	Fitting − Grease	2
5	76−2460	Bearing Assembly (Incl. Ref. #4 & 24−26)	1
6	3296−29	Nut − Lock	7
7	54−9090	Yoke − End	1
8	54−9180	Kit − Universal Joint	2
9	72−3420	Shaft − Slip Yoke	1
10	302−58	Fitting − Grease	1
11	83−5260	Tube − Slip Yoke	1
12	72−3440	Yoke − Shaft	1
13	253−155	Seal	2
14	71−4590	Washer − Thrust	2
15	76−4690	Axle Coupling Assembly (Incl. Ref. #6 & 19)	1
16	3253−3	Washer − Lock	6

Ref. No.	Part No.	Description	No. Used
17	3274−8	Screw − Cap Hex. Hd.	6
18	32121−34	Pin − Roll	1
19	322−8	Screw − Cap Hex. Hd.	4
20	284−3	Plug − Welch	1
21	32151−87	Ring − Retaining	1
22	71−4580	Clutch − Roller	2
23	71−4570	Housing − Clutch	1
24	3245−35	Screw − Set	1
25	251−77	Collar − Locking	1
26	251−337	Bearing − Ball	1
27	48−9460	Screw − Cap Hex. Hd.	1
28	42−9850	Washer − Lock	1
29	48−8030	Washer − Flat	1
30	3274−34	Screw − Socket Flat Hd.	1
31	83−4900	Shaft − Traction	1
*	83−5190	Drive Shaft Assembly (Incl. Ref. #7−12)	1

*Not Illustrated




FRONT LIFT ARMS ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	75−5450	Assembly − Lift Arm R.H. (Incl. Ref. #9 & 11)	1
2	49−2040	Screw − Thread Forming	8
3	237−78	O−Ring	6
4	340−132	Fitting − Hydraulic 90˚ (Incl. Ref. #3 & 5)	5
5	237−21	Seal − O−Ring	6
7	83−7480	Asm. − Hydraulic Cylinder	1
8	75−5330	Clamp − Hose	2
9	67−1750	Bushing − Sleeve	12
10	84−8320	Insert − Hinge	4
11	302−5	Fitting − Grease	6
12	92−8002	Sensor − Reed Switch	1
13	328−12	Screw − Cap Hex. Hd.	2
14	3290−336	Tie − Cable	3
15	283−6	Pin − Clevis	3
16	75−5210	Bracket − Spring Center	1
*	75−5200	Bracket − Spring R.H.	1
*	75−5220	Bracket − Spring L.H.	1
17	3272−10	Pin − Cotter	3
18	328−7	Screw − Cap Hex. Hd.	4
19	3296−51	Nut − Lock	6
20	32151−48	Ring − Retaining	3

Ref. No.	Part No.	Description	No. Used
21	282−4	Clevis − Spring	3
22	5−0743	Spring − Extension	3
23	3296−44	Nut − Lock	4
24	3256−24	Washer − Flat	3
25	3256−23	Washer − Flat	3
26	322−5	Screw − Cap Hex. Hd.	3
27	75−4550	Shaft − Center Arm Pivot	1
28	75−5890	Hose − Hydraulic	2
29	32120−93	Ring − Retaining	6
30	3−6498	Washer − Thrust	6
31	75−5350	Pin − Cylinder Rod End	3
32	75−5460	Assembly − Lift Arm L.H. (Incl. Ref. #9 & 11)	1
‡33	55−4300	Decal − Warning	3
33	93−6696	Decal − Warning (Europe)	3
34	3256−22	Washer − Flat	2
35	321−4	Screw − Cap Hex. Hd.	2
36	75−5370	Mount − Clamp	1
37	3296−42	Nut − Lock	2
38	75−5380	Bracket − Clamp	1
39	323−11	Screw − Cap Hex. Hd.	1
40	75−5420	Assembly − Lift Arm, Center (Incl. Ref. #9 & 11)	1

*Not Illustrated
‡For different language versions of this part, see International Parts Reference.

3317−872




FRONT LIFT ARMS ASSEMBLY (Continued)

Ref. No.	Part No.	Description	No. Used
41	256−115	Washer − Thrust	11
43	83−6790	Pin − Cylinder (Short)	1
44	75−3040	Assembly − Carrier Frame (Incl. Ref. #9 & 11)	1
45	3296−29	Nut − Lock	3
46	85−9880	Asm. − Hydraulic Cylinder	1
47	75−5900	Hose − Hydraulic	1
48	32104−76	Screw − Thread Forming	2
49	75−6370	Cover − Sensor	1
51	92−8754	Actuator − Reed Switch	1
52	3296−39	Nut − Lock	2
53	75−5410	Bracket − Arm	2
54	75−3010	Joint − Arm	3
55	32121−122	Pin − Roll	3
56	323−12	Screw − Cap Hex. Hd.	2
57	3256−6	Washer − Flat	6
58	3253−7	Washer − Lock	6

Ref. No.	Part No.	Description	No. Used
59	325−4	Screw − Cap Hex. Hd.	6
60	75−5910	Hose − Hydraulic	1
61	83−6780	Pin − Cylinder (Long)	2
‡62	36−3400	Decal − No Step	2
62	93−6687	Decal − No Step (Europe)	2
63	75−5300	Rod − Hose Support	1
64	340−13	Fitting − Straight (Incl. Ref. #5)	2
65	82−6490	Hose − Hydraulic	1
66	32144−14	Screw − Self Tapping	3
67	83−7490	Hydraulic Cylinder Asm.	1
68	3290−378	Tie − Cable	5
69	92−9097	Set Screw	3
70	340−143	Fitting − Hydraulic 90° (Incl. Ref. #3)	1
71	82−8270	Valve − Flow Control	1

‡For different language versions of this part, see International Parts Reference.




REAR LIFT ARMS ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	3290−336	Tie − Cable	1
2	5−0743	Spring − Counterbalance	2
3	282−4	Clevis − Spring	2
4	3272−10	Pin − Cotter	2
5	32151−48	Ring − Retaining	2
6	322−5	Screw − Cap Hex. Hd.	3
7	3256−23	Washer − Flat	10
8	75−4690	Bracket − Spring Rear R.H.	1
*	75−4650	Bracket − Spring Rear L.H.	1
9	3296−29	Nut − Lock	8
10	283−6	Pin − Clevis	2
11	75−6070	Hose − Hydraulic L.H. (Cap)	1
*	75−6080	Hose − Hydraulic L.H. (Rod)	1
12	237−78	O−Ring	4
13	340−103	Fitting − Hydraulic 45˚ (Incl. Ref. #12 & 14)	1
14	237−21	O−Ring	4
15	75−3810	Bracket − Roller	2
16	3253−4	Washer − Lock	2
17	322−6	Screw − Cap Hex. Hd.	4
18	32151−61	Ring − Retaining	4
19	75−5400	Shaft − Roller	2
20	75−5390	Roller	2

Ref. No.	Part No.	Description	No. Used
21	75−6180	Hose − Hydraulic R.H.	2
22	340−132	Fitting − Hydraulic 90˚ (Incl. Ref. #12 & 14)	3
23	75−5350	Pin − Cylinder Rod End	2
24	3−6498	Washer − Thrust	4
25	32120−93	Ring − Retaining	4
26	256−115	Washer − Thrust	8
27	67−1750	Bushing − Sleeve	8
28	93−0066	Asm. − Lift Arm Rear R.H. (Incl. Ref. #27, 29 & 38)	1
*	93−0068	Asm. − Lift Arm Rear L.H. (Incl. Ref. #27, 29 & 38)	1
29	302−5	Fitting − Grease	4
30	3256−24	Washer − Flat	4
31	3296−39	Nut − Lock	6
32	322−12	Screw − Cap Hex. Hd.	2
33	5−1096	Chain − Cutting Unit	2
34	75−4590	Rod − Pivot	2
35	325−4	Screw − Cap Hex. Hd.	4
36	93−0142	Bushing − Straight	2
37	75−4520	Spring − Torsion R.H.	1
*	75−4530	Spring − Torsion L.H.	1
38	256−287	Bushing − Flange	4

*Not Illustrated
‡For different language versions of this part, see International Parts Reference.




REAR LIFT ARMS ASSEMBLY (Continued)

Ref. No.	Part No.	Description	No. Used
39	3253−7	Washer − Lock	4
40	3256−6	Washer − Flat	4
41	75−3010	Joint − Arm	2
42	3290−378	Tie − Cable	3
43	92−9097	Set Screw	2
44	32121−122	Pin − Roll	2
‡45	55−4300	Decal − Warning	2
45	93−6696	Decal − Warning (Europe)	2
46	49−2040	Screw − Thread Forming	5
47	32151−36	Ring − Retaining	4
48	93−0079	Asm. − Hydraulic Cylinder	2
49	75−5360	Pin − Cylinder Cap End	2

Ref. No.	Part No.	Description	No. Used
50	75−5330	Clamp − Hydraulic Line	2
51	2412−107	Clamp − R (Used on left rear cutting unit lift arm only)	1
52	93−0069	Pin − Pivot	2
53	2412−104	Clamp−R	1
54	323−6	Screw − Cap Hex. Hd.	2
55	83−5170	Stop − Reel, LH	1
*	93−3640	Stop − Reel, RH	1
56	32144−49	Screw − Hex. Washer Hd.	2
57	2412−74	Clamp−R	2
58	92−5791	Spacer	2

*Not Illustrated




T−1879

HYDRAULIC CYLINDER NO. 93−0079

Ref. No.	Part No.	Description	No. Used
†1	93−3134	Assembly − Barrel	1
2	32152−10	Nut	1
†3		Uni−ring	1
4	70−2780	Piston	1
†5		O−Ring	1
†6		Seal − Rod	1
†7		O−Ring	1
†8		Backup	1

Ref. No.	Part No.	Description	No. Used
9	84−1670	Head	1
†10		Seal − Dust	1
11	84−1680	Ring − Retaining	1
12	75−3790	Clevis	1
13	302−5	Fitting − Grease	1
*	86−7330	Seal repair Kit (Incl. Ref. #3, 5−8 & 10)	1

*Not Illustrated
†Not Serviced Separately




T−1032

HYDRAULIC CYLINDER NO. 85−9880

Ref. No.	Part No.	Description	No. Used
†1		Assembly − Barrel	1
2	32152−10	Nut	1
†3		Uni−ring	1
4	70−2780	Piston	1
†5		O−Ring	1
†6		Seal − Rod	1
†7		O−Ring	1
†8		Backup	1

Ref. No.	Part No.	Description	No. Used
9	84−1670	Head	1
†10		Seal − Dust	1
11	84−1680	Ring − Retaining	1
12	75−3790	Clevis	1
13	302−5	Fitting − Grease	1
*	86−7330	Seal repair Kit (Incl. Ref. #3, 5−8 & 10)	1

*Not Illustrated
†Not Serviced Separately




T−1032

HYDRAULIC CYLINDER NO. 83−7480

Ref. No.	Part No.	Description	No. Used
†1		Assembly − Barrel	1
2	32152−10	Nut	1
†3		Uni−ring	1
4	84−1710	Piston	1
†5		O−Ring	1
†6		Seal − Rod	1
†7		O−Ring	1
†8		Backup	1

Ref. No.	Part No.	Description	No. Used
9	84−1720	Head	1
†10		Seal−Dust	1
11	84−1730	Ring − Retaining	1
12	84−1740	Clevis	1
13	302−5	Fitting − Grease	1
*	84−1760	Seal repair Kit (Incl. Ref. #3, 5−8 & 10)	1

*Not Illustrated
†Not Serviced Separately




T−1032

HYDRAULIC CYLINDER NO. 83−7490

Ref. No.	Part No.	Description	No. Used
†1		Assembly − Barrel	1
2	32152−10	Nut	1
†3		Uni−ring	1
4	70−2780	Piston	1
†5		O−Ring	1
†6		Seal − Rod	1
†7		O−Ring	1
†8		Backup	1

Ref. No.	Part No.	Description	No. Used
9	84−1670	Head	1
†10		Seal−Dust	1
11	84−1680	Ring − Retaining	1
12	75−2120	Clevis	1
13	302−5	Fitting − Grease	1
*	86−7330	Seal Repair Kit (Incl. Ref. #3, 5−8 & 10)	1

*Not Illustrated
†Not Serviced Separately



T−1959

R.O.P.S. ASSEMBLY (Optional)


Ref. No.	Part No.	Description	No. Used
1	83−7410	Roll − Bar	1
‡2	85−9980	Decal − ROPS	1
2	93−8073	Decal − ROPS (Europe)	1
‡3	83−7430	Decal − Danger	1
3	93−8050	Decal − Danger (Europe)	1
4	3256−26	Washer − Flat	9

Ref. No.	Part No.	Description	No. Used
5	3253−7	Washer − Lock	9
6	325−5	Screw − Cap Hex. Hd.	9
7	3217−9	Nut − Lock	3
*	21−4191	Assembly − Seat Belt	1
*	3212−4	Screw − Cap Hex. Hd.	2
*	3253−6	Washer − Lock	2

*Not Illustrated
‡For different language versions of this part, see International Parts Reference.

SPECIAL TOOLS

AXLE TOOL NO. *TOR859920



T−1325

Ref. No.	Part No.	Description	No. Used
1		Tool − Axle	1

*Obtain these items directly from OTC 2013 4th St. Owatonna, MN. 55060 1−800−533−0492 (in Minnesota and Canada 1−507−455−7050) Fax. 507−455−7011.

INTERNATIONAL PARTS REFERENCE
EUROPEAN PARTS KIT NO. 93–7184

DESCRIPTION	LOCATION	PART NUMBER	
		ENGLISH	EUROPEAN
Decal No Step	Lift Arms	36–3400	93–6687
Decal Diesel Only	Left Fender	52–1320	93–6680
Decal Spring Loaded	Lift Arms	55–4300	93–6696
Decal Instructions	Air Cleaner	27–7160	93–8052
Decal No Starting Fluid	Air Cleaner	83–9150	93–6692
Decal Hydraulic Oil	Right Fender & Frame	85–4730	93–6686
Decal Floor Plate	Main Frame	88–0440	93–6693
Decal Bolt	Frame	77–0490	93–6691
Cap Hydraulic Oil	Hydraulic Reservoir	93–3103	93–7160
Decal Backlap	Backlap Bracket	75–0750	93–6684
Decal Towing	Tool Box Cover	75–1280	93–6698
Decal No Riders	Fenders	75–5190	93–6689
Decal Fast/Slow	Steering Tower	75–6710	93–6699
Panel Tower	Steering Tower	93–3139	93–6682
Decal Clip	Under Seat Plate	85–4610	DANISH 92–1125 DUTCH 92–1126 ITALIAN 92–1127 SPANISH 92–1128 GERMAN 92–1129 FRENCH 92–1130 SWEDISH 92–1131 PORTUGESE 93–8057 NORWEGIAN 93–8058 FINNISH 93–8059
Decal Reels	Under Seat Plate	85–4530	93–8060
Decal Knobs	Seat Plate	83–7440	93–6694

DESCRIPTION	LOCATION	PART NUMBER	
		ENGLISH	EUROPEAN
Decal Slopes	Tool Box	93–3639	93–8057
Decal This End Down	Radiator Screen	83–7450	93–8056
Plate Warning	Fan Shroud	76–8750	93–6681
Guard Fan	Fan & Alternator Area	–	93–7182
Decal Fuses	Inside Control Box	85–4720	93–6695
Panel Console	Control Console	93–3140	93–6683
Kit Lift Control	Control Console	–	93–7183
Decal Service Instructions	Inside Tool Box	93–3601	DANISH 93–8091 DUTCH 93–8092 ITALIAN 93–8093 SPANISH 93–8094 GERMAN 93–8095 FRENCH 93–8096 SWEDISH 93–8097 PORTUGESE 93–8098 NORWEGIAN 93–8099 FINNISH 93–7154
Decal Hands/Feet	Cutting Unit Frames	67–7960	93–6688
Decal Seat Belts	R.O.P.S. Roof	83–7430	93–8050
Decal R.O.P.S.	R.O.P.S. Roof	85–9980	93–8055
Decal HOC Instructions	Under Control Console	94–4934	93–1268
Decal Diagnostic	A.C.E. Display	85–4760	DANISH 92–8078 DUTCH 93–8079 ITALIAN 93–8080 SPANISH 93–8081 GERMAN 93–8082 FRENCH 93–8083 SWEDISH 93–8084 PORTUGESE 93–8085 NORWEGIAN 93–8086 FINNISH 93–8087
Decal Lubrication	4WD Rear Axle Tube	70–2560	93–6697
Decal C.E.	Hood	–	93–7252

INTERNATIONAL PARTS REFERENCE (Continued)

JAPANESE PARTS KIT NO. 83−6880

DESCRIPTION	LOCATION	PART NUMBER	
		ENGLISH	JAPANESE
Decal No Step	Lift Arms	36−3400	84−2780
Decal Diesel Only	Left Fender	52−1320	84−2860
Decal Spring Loaded	Lift Arms	55−4300	84−2940
Decal No Starting Fluid	Air Cleaner	83−9150	84−3100
Decal Hydraulic Oil	Right Fender & Frame	85−4730	88−1980
Decal Bolt	Frame	77−0490	80−4880
Decal Backlap	Backlap Bracket	75−0750	84−3260
Decal Towing	Tool Box Cover	75−1280	84−3340
Decal No Riders	Fenders	75−5190	84−3420
Decal Fast/Slow	Steering Tower	75−6710	84−3500
Decal Clip	Under Seat Plate	85−4610	92−1124
Decal Reels	Under Seat Plate	85−4530	92−1108

DESCRIPTION	LOCATION	PART NUMBER	
		ENGLISH	JAPANESE
Decal Slopes	Tool Box	93−3639	84−3660
Decal This End Down	Radiator Screen	83−7450	84−3820
Decal Fuses	Inside Control Box	85−4720	84−4060
Panel Console	Control Console	93−3140	93−6683
Decal Service Instructions	Inside Tool Box	93−3601	92−1116
Decal Hands/Feet	Cutting Unit Frames	67−7960	84−4220
Decal Seat Belts	R.O.P.S. Roof	83−7430	84−4300
Decal HOC Instructions	Under Control Console	94−4934	94−4587
Decal Floor Plate	Main Frame	88−0440	88−1900
Decal Diagnostic	A.C.E. Display	85−4760	93−8089
Decal Knobs	Seat Plate	83−7440	84−3900

TORO PART NUMBER INDEX

Part No.	Description	Pg. No.	Ref. No.	Qty.
3−3251	Spring − Compression	3	12	1
3−6498	Washer − Thrust	28	22	2
3−6498	Washer − Thrust	63	24	4
3−6498	Washer − Thrust	61	30	6
3−6657	Clamp − Cable	35	13	1
3−6657	Clamp − Cable	6	29	1
5−0652	Spacer	5	42	1
5−0743	Spring − Counterbalance	63	2	2
5−0743	Spring − Extension	61	22	3
5−0838	Washer − Flat	6	36	4
5−1096	Chain − Cutting Unit	63	33	2
5−1226	Washer	55	43	2
7−3900	Pad − Brake	5	26	2
21−4191	Assembly − Belt, Seat	7	46	1
21−4191	Assembly − Seat Belt	69	*	1
21−7670	Case−Differential	25	33	1
21−7690	Gear−Pinion	24	6	2
21−7700	Shaft−Pinion Mate	25	31	1
21−7710	Pin−Roll	25	30	1
21−7720	Washer−Thrust	24	4	2
21−7730	Washer−Thrust	24	7	2
21−7770	Screw−Drive Gear	25	32	5
21−8020	Spacer−Front Pinion	25	25	1
21−8090	Diff. Adjust. Shim .003	25	38	A/R
21−8100	Diff. Adjust. Shim .005	25	37	A/R
21−8110	Diff. Adjust. Shim .010	25	36	A/R
21−8120	Diff. Adjust. Shim .030	25	35	A/R
21−8180	Bearing	26	3	2
21−8270	Pin−Dowel	24	3	2
21−8360	Clip−Retaining	26	12	2
21−8390	Cup−Bearing	25	24	1
21−9260	Seal − Shaft	3	27	1
21−9370	Screw−Adjusting	26	16	2
21−9380	Nut−Pivot	26	17	2
21−9390	Socket−Adjusting Screw	26	15	2
21−9420	Spring−Shoe Return, L.H.	26	19	2
21−9430	Spring−Shoe Return, R.H.	26	7	2
21−9440	Spring−Adjusting Screw	26	14	2
21−9450	Shield−Dust	26	5	2
21−9460	Retainer−Brake, Parking	26	10	4
23−2270	Bushing − Rubber	28	26	1
23−7270	Nut − Lug	22	2	10
24−0760	Exchanger − Heat	32	45	1
24−8790	Gear−Bevel, Differential	24	5	2
24−8840	Ring−Bearing, Wheel	26	22	2
24−9180	Lever, Brake, Parking	26	4	2
25−8640	Screw − Hex. Head	6	25	2
27−2360	Assembly − Ignition Switch	11	19	1
27−3710	Dipstick − Axle	23	48	1
27−5340	Hose − Fuel	21	11	1
27−6852	Shaft−Axle, Flanged R.H.	26	*	1
27−6862	Shaft−Axle, Flanged L.H.	26	1	1
27−7110	Assembly − Element	53	8	1
27−7120	Nut	53	3	1
27−7130	Assembly − Clamp	53	4	1
27−7140	Baffle	53	2	1
27−7150	Assembly − Cup	53	1	1
27−7160	Decal − Instructions	52	4	1
27−7170	Assembly − Band	53	7	2
27−7220	Air Cleaner Soap	53	*	1
27−9560	Spacer	36	53	1
28−0660	Screw−Cap, Hex Hd.	26	21	8
28−0670	Seal−Oil	26	8	2
28−0680	Drum−Brake	26	13	2
28−1280	Boot − Cable	52	14	1
29−6162	Switch − Neutral	28	6	1
33−1260	Assembly − Cover	53	12	1
33−1270	Bowl	53	11	1
36−3400	Decal − No Step	62	62	2
38−3400	Guard − Rubber	17	8	2
42−6080	Shim − Axle	22	43	A/R
42−7080	Cap − Sealing	41	7	5
42−7160	Pin − Dowel	38	18	1
42−7170	Plug − Expansion	38	19	1
42−7180	Bushing	38	5	4
42−7190	Bushing	37	5	2
42−7200	Bushing	38	17	1
42−7290	Gasket	40	20	1
42−7310	Bearing − Needle	47	20	2
42−7390	Seal − Oil	42	7	1
42−7420	Cap − Oil	41	10	1
42−7440	Hanger − Engine	41	6	2
42−7510	Pipe	41	12	1
42−7550	Gasket	45	6	1
42−7550	Gasket	51	102	1
42−7730	Key − Woodruff	37	28	2
42−7730	key − Woodruff	39	25	1
42−7840	Key − Sunk	39	20	1
42−7860	Seal	39	13	6
42−7890	Tappet	39	23	6
42−7990	Ring − Snap	39	1	2
42−8010	Shim − 0.2 mm	46	5	A/R
42−8020	Shim − 0.3 mm	46	*	A/R
42−8030	Shim − 0.4 mm	46	*	A/R
42−8040	Shim − 0.5 mm	46	*	A/R
42−8050	Shim − 0.6 mm	46	*	A/R
42−8060	Shim − 0.7 mm	46	*	A/R
42−8070	Shim − 0.8 mm	46	*	A/R
42−8080	Shim − 0.9 mm	46	*	A/R
42−8090	Shim − 1.0 mm	46	*	A/R
42−8690	Metal	47	5	1
42−8810	Pin − Grooved	47	30	1
42−8830	O−Ring	40	2	1
42−8830	O−Ring	51	107	1
42−8930	Spring	40	19	1
42−9210	Bolt − Cap, Bearing	38	10	8
42−9240	Bolt W/Washer	46	25	3
42−9250	Screw − Cap Hex. Hd.	35	40	8
42−9300	Screw − Cap Hex. Hd.	36	64	1
42−9440	Bolt W/Washer	37	6	4
42−9440	Bolt w/Washer	40	34	1
42−9570	Stud	41	3	4
42−9600	Washer − Lock	58	9	28
42−9600	Washer − Lock	36	65	1
42−9600	Washer − Lock M10	56	42	24
42−9810	Washer − Plain	37	13	1
42−9820	Washer	39	18	1
42−9830	Washer − Seal	46	1	2
42−9850	Washer − Lock	34	16	6
42−9850	Washer − Lock	35	28	2
42−9850	Washer − Lock	60	28	1
42−9850	Washer − Lock M8	56	34	8
42−9850	Washer − Lock, M8	58	29	28
43−1810	Ring − Gear	37	24	1
43−2550	Filter	46	29	1
43−2560	Gasket	46	28	1
43−2570	Gasket	46	30	1
43−2580	Magnet	46	27	1
43−2740	Gasket	34	8	1
43−2750	Nut	46	23	1
43−2750	Nut − Lock	34	9	1
43−2860	Bolt W/Washer	46	9	2
43−3810	Tube − Air Cleaner (Optional)	53	13	1
43−5930	Washer − Lock	58	14	12
43−5930	Washer − Lock	35	26	1
43−6710	Diff. Adjust. Shim .003	24	15	A/R
43−6711	Diff. Adjust. Shim .005	24	16	A/R
43−6712	Diff. Adjust. Shim .010	24	17	A/R
43−6713	Diff. Adjust. Shim .030	24	18	A/R
43−6750	Cup−Bearing, Tapered	24	10	1

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. No.	Ref. No.	Qty.
43−6760	Cone−Bearing, tapered	24	9	1
43−6800	Nut−Lock	26	18	8
43−6810	Spider−Torque	26	6	2
44−2210	Assembly − Warning Light	11	6	1
44−2670	Hose − Fuel	21	18	1
46−6550	Connector − Fuel, Elbow 90˚	21	20	1
46−6560	Grommet	21	21	2
46−8091	Screw − Cap Hex. Hd.	1	7	4
47−0110	Spacer − Spindle	35	6	1
48−1990	Nut − Jam	40	12	1
48−4220	Assembly − Air Cleaner	52	2	1
48−4220	Assembly − Air Filter	53	*	1
48−7430	Assembly − Pre−Cleaner	53	*	1
48−7700	Screw − Cap Hex. Hd.	35	21	1
48−7710	Screw − Cap Hex. Hd.	34	20	2
48−7710	Screw − Cap, M8 x 20	58	39	4
48−7780	Screw − Cap Hex. Hd.	55	48	8
48−7890	Nut − Hex.	35	27	1
48−7930	Nut − Lock	34	17	4
48−8030	Washer − Flat	60	29	1
48−8070	Washer − Lock	35	39	10
48−9220	Washer − Flat	55	47	8
48−9460	Bolt − Hex. Hd.	56	35	4
48−9460	Screw − Cap Hex. Hd.	60	27	1
48−9460	Screw − Cap, M8 x 25	58	28	20
48−9470	Bolt − M10 x 30	57	43	24
48−9470	Screw − Cap, M10 x 30	58	10	4
48−9480	Screw − Cap Hex. Hd.	55	30	4
49−2040	Screw − Hex. Washer Hd.	17	20	4
49−2040	Screw − Hex. Washer Hd.	2	49	2
49−2040	Screw − Thread Forming	61	2	8
49−2040	Screw − Thread Forming	64	46	5
49−6440	Plate − Traction Pedal	5	11	1
52−1320	Decal − Fuel	2	28	1
53−8150	Assembly − Fuel Pump	21	2	1
53−8150	Assembly − Pump, Electric	46	*	1
53−9680	Mount − Engine	36	46	2
54−8660	Washer	45	17	1
54−8670	Bolt	37	26	4
54−9040	Yoke − End	34	1	1
54−9090	Yoke − End	60	7	1
54−9180	Kit − U−Joint	34	25	1
54−9180	Kit − Universal Joint	60	8	2
55−4300	Decal − Warning	61	33	3
55−4300	Decal − Warning	64	45	2
56−0100	Plug − Taper	38	8	1
56−0220	Pin − Dowel	38	1	2
56−0750	Clamp A	46	8	2
56−0760	Clamp B	46	12	2
56−1230	Shaft	38	6	1
56−1310	Switch − Oil	40	5	1
56−1360	Fitting − Outlet, Water	45	5	1
56−1400	Clip	45	20	2
56−2020	Bolt W/Washer	45	4	2
56−2460	Washer − Flat	55	14	2
57−6390	Nut − Lock	35	37	2
60−7280	Bolt	41	2	4
60−7390	Plate − Thrust	39	26	1
61−2790	Screen − Filler	14	3	1
62−3820	Fitting − Grease	34	24	1
62−5550	Decal − TORO	1	1	1
62−6300	Assembly − Sleeve	53	10	1
62−7400	Decal − TORO	1	16	1
62−7650	Gasket − Sending Unit	21	7	1
63−6890	Hinge − Hood R.H.	1	*	1
63−6900	Hinge − Hood L.H.	1	17	1
63−7380	Assembly − Expansion Tank	52	7	1
63−7400	Washer − Flat	35	34	4
63−7430	Gauge − Temperature	11	8	1
63−7440	Solenoid − Stop	34	10	1
63−7590	Relay − Starter	31	42	1
63−7610	Hose − Fuel	21	1	1
63−7628	Hose − Fuel	21	29	1
63−7640	Unit − Sending	21	8	1
63−7650	Filter − Fuel	21	32	1
63−7732	Cable − Brake R.H.	5	*	1
63−7733	Cable − Brake L.H.	5	29	1
63−7880	Pin − Brake Latch	5	28	1
63−7900	Rack − Parking Brake	3	20	1
63−8140	Pulley − Idler	36	58	1
63−8280	Head−Filter, Fuel	54	1	1
63−8290	Vent−Air	54	2	1
63−8300	Assembly − Fuel Filter	54	*	1
63−8300	Element−Spin−On	54	3	1
63−8310	Valve−Drain	54	4	1
63−8360	Key − Ignition	11	9	1
63−8410	Washer − Flat	21	27	3
63−8410	Washer − Flat	14	37	3
63−9920	Decal − EEC 105	7	49	1
65−5100	Handle	1	5	2
66−2330	Base − Battery	52	10	1
66−2490	Clamp − Battery	52	18	1
66−2920	Washer − Friction	6	32	2
66−2940	Gauge − Fuel	11	1	1
66−2960	Cluster − Warning	11	7	1
66−3180	Tube − Vent	31	26	1
66−3240	Cap − Radiator	31	13	1
66−6480	Washer − Flat	22	44	4
66−8121	Standpipe − Elbow 90˚	21	19	1
66−8520	Bumper − Down−stop	8	17	2
66−8530	Adjuster	8	16	1
66−8560	Nut − Push	8	11	4
66−8610	Weldment − Lower	8	10	1
66−8800	Relay − Glow Plug	32	56	1
66−9290	Spacer	8	15	6
66−9302	Screw − Cap Hex. Hd.	34	19	3
66−9303	Screw − Cap Hex. Hd.	34	6	3
66−9770	Seal	4	28	1
66−9780	Bushing	4	29	1
66−9860	Upper Cover & Jacket	4	37	1
66−9870	Plate − Retaining	4	38	1
66−9880	Washer − Retaining Plate	4	39	1
66−9890	Ring − Retaining	4	40	1
66−9900	Shaft − Input	4	41	1
66−9970	Spring Kit	4	*	1
66−9980	Seal − Kit	4	*	1
66−9990	Needle Roller Kit	4	*	1
67−1630	Spacer − Fan	35	10	1
67−1690	Fitting − Fuel Elbow 90˚	21	35	2
67−1750	Bushing − Sleeve	61	9	12
67−1750	Bushing − Sleeve	55	13	2
67−1750	Bushing − Sleeve	63	27	8
67−2340	Bolt W/Washer	42	3	7
67−2340	Bolt W/Washer	40	10	15
67−2340	Bolt W/Washer	39	27	2
67−2440	Bolt W/Washer	46	26	2
67−2500	Plunger	40	18	1
67−2520	Plug	40	21	1
67−2570	Plug − Taper	38	3	1
67−2570	Plug − Taper	41	16	1
67−3100	Retainer	39	14	6
67−3260	Washer − Spring	47	34	1
67−3390	Gasket − Holder	46	4	3
67−3390	Gasket − Holder	51	105	3
67−3430	Nut	46	13	3
67−3440	Gasket − Fuel Return	51	104	3
67−3440	Gasket − Return, Fuel	46	14	3
67−4180	Nut	47	7	1
67−4200	Nut	47	8	1
67−4210	Case	47	12	1

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. No.	Ref. No.	Qty.
67−4220	Screw − Adjusting	47	9	1
67−4240	Cap	47	2	1
67−4290	Nut	47	32	2
67−4580	Bolt	41	1	2
67−4660	Bolt − Flange Head	45	18	1
67−4790	Assembly − Shaft, Pinion	48	12	1
67−7160	Block − Fuse	11	21	2
67−9410	Washer − Thrust	55	27	2
68−5140	Cap − Steering Wheel	3	7	1
68−5370	Decal − TORO	3	5	1
68−6150	Breather − Hydraulic Tank	14	2	1
68−6823	Assembly − Axle	55	42	1
69−4320	Fitting − Hydraulic 90˚	15	25	1
69−4780	Clamp − Light Cluster	12	42	1
70−2560	Decal − Lube	55	36	1
70−2780	Piston	65	4	1
70−2780	Piston	66	4	1
70−2780	Piston	68	4	1
70−2970	Nut − Jam	39	5	6
70−3970	Plate − Shim .6 mm	44	28	A/R
70−4070	Plate − Shim .2 mm	44	*	A/R
70−4080	Plate − Shim .3 mm	44	*	A/R
70−4090	Plate − Shim .4 mm	44	*	A/R
70−4100	Plate − Shim .5 mm	44	*	A/R
70−8220	Cable − Ground	35	41	1
70−8530	Wire − Fuel Pump	21	33	1
70−8570	Breaker − Circuit	12	*	2
71−1520	Cap − Expansion Tank	52	8	1
71−4330	Seal	25	41	1
71−4350	Nut	24	20	1
71−4450	Bolt − Wheel	55	39	10
71−4570	Housing − Clutch	60	23	1
71−4580	Clutch − Roller	60	22	2
71−4590	Washer − Thrust	60	14	2
71−4740	Assembly − Tie Rod End	55	33	2
71−4760	Seal − Tie Rod End	55	32	2
72−0270	Nut − Retaining	44	1	3
72−0280	Piece − Distance	44	3	3
72−3420	Shaft − Slip Yoke	60	9	1
72−3440	Yoke − Shaft	60	12	1
72−3560	Decal − 4WD	2	50	2
72−3570	Shim .094 − Diff. Adjust.	24	22	A/R
72−3571	Shim .096 − Diff. Adjust.	24	*	A/R
72−3572	Shim .098 − Diff. Adjust.	24	*	A/R
72−3573	Shim .100 − Diff. Adjust.	24	22	A/R
72−3574	Shim .102 − Diff. Adjust.	24	*	A/R
72−3575	Shim .104 − Diff. Adjust.	24	*	A/R
72−3576	Shim .106 − Diff. Adjust.	24	*	A/R
72−3577	Shim .108 − Diff. Adjust.	24	*	A/R
72−3578	Shim .110 − Diff. Adjust.	24	*	A/R
72−3580	Shim .112 − Diff. Adjust.	24	*	A/R
72−3581	Shim .114 − Diff. Adjust.	24	*	A/R
72−3582	Shim .116 − Diff. Adjust.	24	*	A/R
72−3583	Shim .118 − Diff. Adjust.	24	*	A/R
72−3584	Shim .120 − Diff. Adjust.	24	*	A/R
72−3585	Shim .125 − Diff. Adjust.	24	*	A/R
72−3586	Shim .127 − Diff. Adjust.	24	*	A/R
72−3587	Shim .129 − Diff. Adjust.	24	*	A/R
72−3588	Shim .131 − Diff. Adjust.	24	*	A/R
72−3590	Shim .133 − Diff. Adjust.	24	*	A/R
72−3591	Shim .135 − Diff. Adjust.	24	*	A/R
72−3592	Shim .137 − Diff. Adjust.	24	*	A/R
72−3593	Shim .139 − Diff. Adjust.	24	*	A/R
72−3594	Shim .141 − Diff. Adjust.	24	*	A/R
72−3595	Shim .143 − Diff. Adjust.	24	*	A/R
72−3596	Shim .145 − Diff. Adjust.	24	*	A/R
72−3597	Shim .147 − Diff. Adjust.	24	*	A/R
72−3598	Shim .149 − Diff. Adjust.	25	22	A/R
72−3600	Shim .151 − Diff. Adjust.	25	*	A/R
72−4870	Case − Differential	56	24	1
72−4880	Cover	56	2	1
72−4890	O−Ring	56	3	1
72−4900	Case − Differential	56	8	1
72−4910	Flange − Case, Diff.	56	12	1
72−4930	Gear − Side, Differential	56	9	1
72−4940	Gear − Side, Differential	56	40	1
72−4950	Gear − Pinion, Differential	56	10	2
72−4960	Shim .1 mm	56	5	1
72−4970	Shim .15 mm	56	*	1
72−4980	Shim .5 mm	56	*	1
72−4990	Shim .8 mm	56	*	1
72−5000	Shim 1.0 mm	56	*	1
72−5010	Shim 1.2 mm	56	*	1
72−5020	Shaft − Pinion	57	47	1
72−5030	Pin − Dowel	57	45	2
72−5040	Washer − Gear, Diff.	56	11	1
72−5090	Gear − Bevel	58	18	2
72−5090	Gear − Bevel	56	21	2
72−5100	Spacer	56	20	2
72−5130	Vent	56	23	1
72−5140	O−Ring	56	25	1
72−5150	Plug	56	26	1
72−5160	Shim .1mm	56	29	1
72−5170	Shim .15 mm	56	*	1
72−5180	Shim .5 mm	56	*	1
72−5190	Shim .8 mm	56	*	1
72−5200	Shim 1.0 mm	56	*	1
72−5210	Shim 1.2 mm	56	*	1
72−5360	Ring − Retaining	56	19	2
72−5370	Ring − Retaining	56	22	2
72−5440	Pin −Spring	57	46	1
72−5460	O−Ring	56	32	1
72−5540	Case − Knuckle	58	30	2
72−5550	Cover	58	26	2
72−5560	Pin − King, Knuckle	58	20	2
72−5570	Shaft − Axle, Outer	58	35	2
72−5580	Gear − Bevel	58	5	4
72−5590	Retainer − Bearing	58	15	2
72−5630	Gasket	58	16	2
72−5650	Hub − Wheel	58	34	2
72−5660	Washer − Shaft, Wheel	58	33	2
72−5680	Spacer	58	19	2
72−5720	Ring − Retaining	58	4	2
72−5730	Seal − Oil	58	24	4
72−5740	Seal − Oil	58	2	2
72−5770	Nut − Castle	58	32	2
72−5780	Key	58	36	2
72−5790	Screw − Cap, M6 x 18	58	13	12
72−5800	Bolt	56	1	8
72−5810	Bolt	56	7	8
72−5820	Plug	56	28	1
72−5840	Gasket	56	27	1
72−6950	Retainer	38	16	1
72−9420	Assembly − Vent Tube	25	39	1
74−0720	Tube − Manual	6	11	1
74−3810	Assembly − Load Plate	20	9	1
74−5520	Clutch − Fan	35	1	1
74−5950	Assembly − Swell Latch	11	5	1
74−5950	Assembly − Swell Latch	2	44	3
74−9100	Pad − Forward	5	12	1
74−9110	Pad − Reverse	5	14	1
75−0012	Assembly − Transmission	22	34	1
75−0020	Housing	27	5	1
75−0030	Gasket − Housing	27	46	1
75−0040	Center Section	27	18	1
75−0060	Plug	27	20	4
75−0070	Plug	27	41	1
75−0090	Screw − Cap Hex Hd.	27	9	8
75−0110	Screw − Cap Hex Hd.	27	35	2
75−0120	Screw − Cap Hex Hd.	27	28	1

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. No.	Ref. No.	Qty.
75−0130	Screw − Cap Hex. Hd.	27	24	3
75−0140	Spring − Conical	27	26	1
75−0150	Guide − Seal	27	2	1
75−0160	Plug − Pipe	27	47	1
75−0170	Plug − Straight Thread	27	19	4
75−0180	Screw − Cap Hex Hd.	27	36	2
75−0190	Plug − Special	27	27	2
75−0200	Plug − Straight Thread	27	38	2
75−0210	O−Ring	27	6	2
75−0220	Pin	27	48	2
75−0230	Seal − Lip	27	8	1
75−0240	O−Ring	27	21	6
75−0250	Pin − Slotted	27	54	1
75−0260	Valve − Relief	27	23	4
75−0270	Spring	27	39	1
75−0280	Spring	27	42	1
75−0290	Spring	27	22	2
75−0310	Shim	27	40	1
75−0320	Nipple	27	37	1
75−0330	Seal − Lip	27	34	1
75−0340	Bearing − Needle	27	33	1
75−0350	Pin	27	31	1
75−0360	Gerotor	27	30	1
75−0370	O−Ring	27	29	1
75−0380	Plate − Valve	27	15	1
75−0390	Plate − Swash	27	12	1
75−0400	Plate − Thrust	27	13	2
75−0410	O−Ring	27	3	1
75−0430	Ring − Retaining	27	1	1
75−0440	Shaft − Motor	27	45	1
75−0450	Collar	27	50	1
75−0460	Bearing − Ball	27	51	2
75−0470	Cylinder Block Kit	27	14	2
75−0480	Pin	27	10	2
75−0500	Bearing − Needle	27	16	2
75−0510	Pin	27	17	1
75−0520	Bearing − Ball	27	4	1
75−0550	Strainer − Suction	14	29	1
75−0560	Assembly − Steering Wheel	3	4	1
75−0570	Cable − Hood	1	21	1
75−0600	Assembly − Steering Valve	3	26	1
75−0600	Valve − Power Steering	4	*	1
75−0610	Tread − Foot R.H.	2	*	1
75−0620	Tread − Foot L.H.	2	39	1
75−0630	Tread − Foot Center	2	37	1
75−0640	Tread − Footrest R.H.	2	*	1
75−0650	Tread − Footrest L.H.	2	35	1
75−0721	Housing−Lower	25	34	1
75−0750	Decal − Backlap	32	53	1
75−0920	Cartridge − Relief 3000 psi	16	13	1
75−0930	Hook − Oil Cooler	31	6	4
75−1010	Assembly − Toggle Switch	11	16	1
75−1020	Switch − Backlap	32	44	1
75−1040	Cooler − Oil	32	52	1
75−1100	Support − Axle	55	5	1
75−1180	Manifold	18	7	2
75−1180	Manifold − Hydraulic	17	23	1
75−1210	Nut−Lock	59	2	1
75−1220	Piston	59	3	1
75−1250	Seal Kit	59	6	1
75−1260	Head−Internal	59	4	1
75−1280	Decal − Warning	1	24	1
75−1300	Asm. − Hydraulic Filter Head	14	31	1
75−1310	Element − Hydraulic Filter	14	34	1
75−1330	Filter − Oil	22	31	1
75−1360	Cable − Battery (Ground)	35	23	1
75−1370	Asm. − Battery Cable (+)	52	13	1
75−1390	Panel − Access	2	38	1
75−1410	Panel − Floor	2	36	1
75−1420	Cover − Steering Tower	1	2	1
75−1430	Assembly − Brake Pedal R.H.	5	35	1
75−1440	Pedal − Brake L.H.	5	33	1
75−1470	Shaft − Brake Pedal	5	36	1
75−1490	Rod − Parking Brake	3	13	1
75−2010	Cartridge − Relief 2000 psi	16	14	1
75−2080	Kit − Seal	16	*	10
75−2090	Kit − Seal	16	*	3
75−2120	Clevis	68	12	1
75−2170	Tube − Pump Control	5	37	1
75−2810	Clamp − Steering Valve	3	3	1
75−2851	Hose − Expansion Tank	52	5	1
75−2851	Hose − Expansion Tank	31	16	1
75−2970	Pedal − Traction	5	13	1
75−3010	Joint − Arm	64	41	2
75−3010	Joint − Arm	62	54	3
75−3040	Assembly − Carrier Frame	62	44	1
75−3110	Collar − Transmission	22	14	1
75−3140	Bracket − Air Cleaner	52	24	1
75−3270	Lever − Traction Pivot	5	8	1
75−3390	Bracket − Backlap	32	55	1
75−3400	Shaft − Seat Pivot	6	15	1
75−3420	Assembly − Lift Control	12	37	1
75−3430	Rod − Throttle	6	33	1
75−3480	Weldment − Upper	8	23	1
75−3510	Bolt − Shoulder	8	26	2
75−3530	Spring − Compression	8	3	1
75−3540	Pin − Roll	8	6	1
75−3550	Bumper − Seat	8	7	2
75−3580	Plate − Mounting, Seat	8	2	1
75−3680	Rod − Seat	6	20	1
75−3710	Dipstick	14	4	1
75−3780	Fan	35	2	1
75−3790	Clevis	65	12	1
75−3790	Clevis	66	12	1
75−3810	Bracket − Roller	63	15	2
75−3860	Fender − L.H.	2	29	1
75−4080	Plate − Traction	28	15	1
75−4100	Control − Pump	28	25	1
75−4130	Plate − Switch	28	7	1
75−4180	Pin − Rear Axle	55	44	1
75−4250	Bracket − Expansion Tank	52	21	1
75−4360	Bracket − Switch	6	8	1
75−4370	Bracket − Switch (Seat)	6	3	1
75−4400	Adaptor − Transmission	29	8	1
75−4450	Hub − Fan Drive	35	9	1
75−4520	Spring − Torsion R.H.	63	37	1
75−4530	Spring − Torsion L.H.	63	*	1
75−4550	Shaft − Center Arm Pivot	61	27	1
75−4590	Rod − Pivot	63	34	2
75−4650	Bracket − Spring Rear L.H.	63	*	1
75−4690	Bracket − Spring Rear R.H.	63	8	1
75−4700	Hose − Fuel	21	13	1
75−4701	Hose − Fuel	21	16	1
75−4701	Hose − Fuel Vent	31	28	1
75−4710	Warning Light Harness	11	28	1
75−4720	Fitting − Hydraulic 90˚	22	26	1
75−5190	Decal − No Riders	2	32	2
75−5200	Bracket − Spring R.H.	61	*	1
75−5210	Bracket − Spring Center	61	16	1
75−5220	Bracket − Spring L.H.	61	*	1
75−5260	Knob − Locking	6	38	2
75−5270	Spacer − Locking Knob	6	37	2
75−5300	Rod − Hose Support	17	19	2
75−5300	Rod − Hose Support	62	63	1
75−5310	Spacer − Bearing	35	8	1
75−5330	Clamp − Hose	61	8	2
75−5330	Clamp − Hydraulic Line	64	50	2
75−5350	Pin − Cylinder Rod End	63	23	2
75−5350	Pin − Cylinder Rod End	61	31	3
75−5360	Pin − Cylinder Cap End	64	49	2

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. No.	Ref. No.	Qty.
75−5370	Mount − Clamp	61	36	1
75−5380	Bracket − Clamp	61	38	1
75−5390	Roller	63	20	2
75−5400	Shaft − Roller	63	19	2
75−5410	Bracket − Arm	62	53	2
75−5420	Assembly − Lift Arm, Center	61	40	1
75−5450	Assembly − Lift Arm R.H.	61	1	1
75−5460	Assembly − Lift Arm L.H.	61	32	1
75−5470	Spacer	28	12	2
75−5720	Hose − Hydraulic	14	19	1
75−5740	Box − Control	11	24	1
75−5810	W.A. − Tool Box	2	26	1
75−5890	Hose − Hydraulic	17	10	1
75−5890	Hose − Hydraulic	61	28	2
75−5890	Hose − Hydraulic	15	35	1
75−5900	Hose − Hydraulic	15	30	1
75−5900	Hose − Hydraulic	62	47	1
75−5910	Hose − Hydraulic	17	11	1
75−5910	Hose − Hydraulic	62	60	1
75−5940	Hose − Hydraulic	17	9	1
75−5940	Hose − Hydraulic AUX	3	23	1
75−6070	Hose − Hydraulic	18	15	1
75−6070	Hose − Hydraulic L.H. (Cap)	63	11	1
75−6080	Hose − Hydraulic	18	14	1
75−6080	Hose − Hydraulic L.H. (Rod)	63	*	1
75−6130	Hose − Hydraulic	14	9	1
75−6180	Hose − Hydraulic	18	1	2
75−6180	Hose − Hydraulic R.H.	63	21	2
75−6220	Hose − Hydraulic	55	23	1
75−6220	Hose − Hydraulic LT	3	24	1
75−6230	Hose − Hydraulic	55	24	1
75−6230	Hose − Hydraulic RT	3	18	1
75−6240	Hose − Hydraulic	29	14	1
75−6240	Hose − Hydraulic IN	3	19	1
75−6250	Hose − Hydraulic	14	17	1
75−6250	Hose − Hydraulic OUT	3	25	1
75−6260	Cover − Tool Box	2	47	1
75−6270	Cover − Control Box	11	15	1
75−6280	Bracket − Hose	1	22	1
75−6340	Strainer − In−Line	22	41	1
75−6350	Hose	22	28	1
75−6370	Cover − Sensor	62	49	1
75−6380	Shaft − Fan	35	3	1
75−6390	Pulley − Fan	35	5	1
75−6490	Lever − Pedal Stop	5	20	1
75−6510	Lever − Bracket	5	16	1
75−6550	Disc − Friction	5	17	1
75−6580	Cable − Pedal	5	7	1
75−6640	Fitting − Hydraulic 90˚	15	20	2
75−6710	Decal − Fast/Slow	5	18	1
75−6820	Meter − Hour	12	47	1
75−6840	Knob − Knurled	2	42	4
75−6850	Tube − Oil Fill	23	47	1
75−6870	Hose − Hydraulic Suction	14	28	1
75−6870	Hose − Suction	29	1	1
75−6880	Screen − Spark Arrester	34	*	1
75−6930	Valve − SCR	27	52	1
76−1910	Shaft − Pivot	8	12	2
76−1920	Bushing − Sleeve	8	9	4
76−1930	Knob − Tension Adjustment	8	19	1
76−1940	Spring − Extension	8	14	2
76−2460	Bearing Assembly	60	5	1
76−2940	Bumper − Rubber	8	8	2
76−4690	Axle Coupling Assembly	60	15	1
76−8640	Stud − Traction	28	23	1
76−8730	Decal − Bolt Torque	22	1	2
76−8750	Plate − Caution	31	21	1
76−9430	Spring − Extension	28	8	1
77−0490	Decal − Bolt	22	17	1
77−2870	Weldment − Hanger	8	18	1
80−4860	Pin − Clevis	8	1	1
82−6490	Hose − Hydraulic	62	65	1
82−6910	Screw − Cap Hex. Hd.	55	26	4
82−8270	Valve − Flow Control	18	13	1
82−8270	Valve − Flow Control	15	31	1
82−8270	Valve − Flow Control	62	71	1
82−9060	Adjuster W/Handle	8	13	1
83−4780	Housing − Charge Pump	27	32	1
83−4900	Shaft − Traction	60	31	1
83−4910	Coupler − Pinion	25	40	1
83−4930	Arm − Steering L.H.	55	31	1
83−4950	Arm − Steering R.H.	55	46	1
83−4970	Bracket − Bearing	60	3	1
83−5010	Assembly − Tie Rod	55	*	1
83−5020	Assembly − Tube & Clamp	55	12	1
83−5030	Asm. − Hydraulic Cylinder	55	28	1
83−5040	Washer	55	15	1
83−5100	Support − Cylinder	55	17	1
83−5110	Stop − Axle	55	6	2
83−5130	Spacer − Pinion	24	21	1
83−5150	Pin − Cylinder	55	18	1
83−5160	Shim	55	29	2
83−5170	Stop − Reel, LH	64	55	1
83−5180	Shim − Axle	55	35	2
83−5190	Drive Shaft Assembly	60	*	1
83−5260	Tube − Slip Yoke	60	11	1
83−5270	Tube − Axle, R.H.	56	16	1
83−5280	Axle − R.H.	56	17	1
83−5290	Tube − Axle, L.H.	57	44	1
83−5310	Axle − L.H.	56	41	1
83−5330	Washer − Bearing	56	38	1
83−5340	Nut − Bearing	56	37	1
83−5350	Case − Bearing	56	33	1
83−5360	Seal − Oil	56	36	1
83−5370	Assembly − Ring & Pinion	57	*	1
83−5380	Assembly − Piston Rod	59	5	1
83−6780	Pin − Cylinder (Long)	62	61	2
83−6790	Pin − Cylinder (Short)	62	43	1
83−7410	Roll − Bar	69	1	1
83−7430	Decal − Danger	69	3	1
83−7440	Decal − Knob	6	40	1
83−7460	Spacer − Wheel	55	41	2
83−7470	Shim	60	2	2
83−7480	Asm. − Hydraulic Cylinder	61	7	1
83−7490	Hydraulic Cylinder Asm.	62	67	1
83−9150	Decal − Starting Fluid	52	3	1
84−1670	Head	65	9	1
84−1670	Head	66	9	1
84−1670	Head	68	9	1
84−1680	Ring − Retaining	65	11	1
84−1680	Ring − Retaining	66	11	1
84−1680	Ring − Retaining	68	11	1
84−1710	Piston	67	4	1
84−1720	Head	67	9	1
84−1730	Ring − Retaining	67	11	1
84−1740	Clevis	67	12	1
84−1760	Seal repair Kit	67	*	1
84−8320	Insert − Hinge	61	10	4
84−8590	Assembly − Shoe & Lining	26	9	4
84−8600	Set of Lined Brake Shoes	26	*	1
85−4330	Cover − Gear	22	9	1
85−4340	Plate − Sensor Mounting	22	11	1
85−4350	Sensor − Gear Tooth	22	5	1
85−4420	Gauge − Speedometer	11	2	1
85−4470	Assembly − Potentiometer	12	44	1
85−4480	Knob	11	25	1
85−4491	Lamp − Diagnostic	12	57	1
85−4530	Decal − Danger	6	17	1
85−4610	Decal − Clip	6	41	1
85−4650	Connector − Loop Back	12	*	1

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. No.	Ref. No.	Qty.
85−4720	Decal − Fuses	11	27	1
85−4730	Decal − Hydraulic Oil	1	4	1
85−4730	Decal − Oil	17	7	1
85−4750	Display − Diagnostic−ACE	9	2	1
85−4760	Decal − Diagnostic−ACE	9	1	1
85−9880	Asm. − Hydraulic Cylinder	62	46	1
85−9900	Plate − Spring Anchor	28	16	1
85−9910	Eyebolt	28	27	1
85−9980	Decal − ROPS	69	2	1
86−3040	Coupling − Driveshaft	34	7	1
86−7220	Gear − Pinion	22	37	1
86−7230	Gear−Spur	24	14	1
86−7330	Seal Repair Kit	68	*	1
86−7330	Seal repair Kit	65	*	1
86−7330	Seal repair Kit	66	*	1
86−7520	Asm. − Trunnion Cover R.H.	27	7	1
86−7530	Asm. − Trunnion Cover L.H.	27	49	1
86−7540	Shaft − Pump	27	11	1
86−7550	Connector − Cover (2 Way)	12	*	2
86−7560	Connector − Cover (3 Way)	12	*	3
86−9190	Hose − Hydraulic	15	14	2
88−0440	Decal − Floor Plate	17	6	1
88−6700	Decal − ANSI (English)	2	34	1
88−6960	Cartridge − 4W/2P	16	19	3
88−6970	Cartridge − N.O.	16	9	2
88−7020	Cartridge − N.O.	16	3	2
88−9190	Solenoid − 20 Watt	16	4	6
88−9200	Solenoid − 28 Watt	16	8	5
88−9460	Hose − Hydraulic	19	11	1
88−9460	Hose − Hydraulic	14	48	1
91−1717	Hose − Hydraulic	19	9	1
92−1127	Decal − Clip (Italian)	6	41	1
92−1128	Decal − Clip (Spanish)	6	41	1
92−1129	Decal − Clip (German)	6	41	1
92−1130	Decal − Clip (French)	6	41	1
92−1131	Decal − Clip (Swedish)	6	41	1
92−1180	Assembly − Seat	7	45	1
92−1718	Hose − Hydraulic	19	12	1
92−1719	Hose − Hydraulic	19	8	1
92−1721	Hose − Hydraulic	19	14	1
92−1721	Hose − Hydraulic	15	24	1
92−1722	Hose − Hydraulic	17	1	1
92−1722	Hose − Hydraulic	19	5	1
92−1723	Hose − Hydraulic	19	10	1
92−1723	Hose − Hydraulic	15	27	1
92−1724	Hose − Hydraulic	19	1	1
92−1725	Hose − Hydraulic	15	4	1
92−1725	Hose − Hydraulic	19	6	1
92−1726	Hose − Hydraulic	19	16	1
92−1726	Hose − Hydraulic	17	24	1
92−1727	Hose − Hydraulic	19	15	1
92−1728	Hose − Hydraulic	19	17	1
92−1728	Hose − Hydraulic	15	37	1
92−1729	Hose − Hydraulic	19	20	1
92−1729	Hose − Hydraulic	17	25	1
92−1773	Screw−Cap, Hex Hd.	24	11	4
92−1774	Seal−Oil	26	2	2
92−1920	Plug − Drain	40	6	1
92−1921	Gasket − Plug, Drain	40	7	1
92−1961	Seal	39	15	6
92−1961	Seal − Valve Stem	51	106	6
92−2143	Bolt W/Washer	41	22	5
92−2379	Clamp − Hose	52	6	1
92−2379	Clamp − Hose	31	14	2
92−2581	Assembly − Switch Arm	28	21	1
92−4808	Sleeve − Trans. Pilot	22	15	1
92−4846	Asm. − Trans. Support	22	39	1
92−4999	Fitting − Hydraulic 90°	32	51	2
92−5524	Decal − Noise Rating, 90	7	50	1
92−5549	Decal − Reelmaster® 5300D	1	10	2
92−5720	Controller − Electronic	11	31	1
92−5751	Decal − Hood Trim L.H.	1	23	1
92−5752	Decal − Hood Trim R.H.	1	*	1
92−5791	Spacer	64	58	2
92−5797	Gasket − Axle	22	10	1
92−6315	Cartridge − N.C.	16	22	1
92−6533	Kit − Cushion, Replacement	7	44	1
92−6534	Shell − Seat	7	43	1
92−8001	Sensor − Reed Switch	6	6	1
92−8002	Sensor − Reed Switch	61	12	1
92−8020	Adapter − Breather	14	26	1
92−8753	Magnet − Reed Switch	6	5	1
92−8754	Actuator − Reed Switch	62	51	1
92−8775	Gasket − Kit, Liquid	26	*	1
92−8795	Assembly − Body	20	10	1
92−8796	Pin − Dowel	20	14	2
92−8863	Repair Kit	20	*	1
92−9096	Assembly − Hose	14	46	1
92−9096	Hose − Hydraulic	17	22	1
92−9097	Set Screw	64	43	2
92−9097	Set Screw	62	69	3
92−9098	Manifold − Tank	14	14	1
93−0000	Hood W.A.	1	8	1
93−0005	Strip − Foam, Top	31	11	1
93−0011	Grill − Hood	1	12	1
93−0018	Frame − Seat	6	28	1
93−0020	Radiator	31	12	1
93−0021	Asm. − Throttle Cable Swivel	6	26	2
93−0022	Shroud − Fan	31	19	1
93−0023	Hose − Radiator Upper	31	18	1
93−0024	Hose − Radiator Lower	31	24	1
93−0025	Shield W.A. − Radiator	31	33	1
93−0030	Asm. − Cooler Mount R.H.	31	9	1
93−0032	Hsg. W.A. − Front Screen	31	2	1
93−0038	Support W.A. − Radiator	31	7	1
93−0043	Bracket − Fan Idler	36	55	1
93−0044	Muffler	34	13	1
93−0045	Yoke − Slip Tube	34	4	1
93−0047	Assembly − U−Joint	34	*	1
93−0047	Yoke − Shaft	34	3	1
93−0048	Hose − Air Cleaner	35	19	1
93−0049	Assembly − Engine	35	24	1
93−0050	Bracket − Engine L.H. Rear	35	29	1
93−0051	Bracket − Engine L.H. Front	36	48	1
93−0054	Bracket W.A. − Fan	36	52	1
93−0062	Belt − V	36	56	1
93−0063	Bracket − Engine R.H. Rear	35	*	1
93−0066	Asm. − Lift Arm Rear R.H.	63	28	1
93−0068	Asm. − Lift Arm Rear L.H.	63	*	1
93−0069	Pin − Pivot	64	52	2
93−0071	Asm. − Cooler Mount L.H.	31	*	1
93−0073	Cable − Throttle	6	24	1
93−0074	Support − Cable	36	62	1
93−0075	Hose − Hydraulic	22	30	1
93−0075	Hose − Trans. to Cooler	32	*	1
93−0076	Hose − Hydraulic	22	21	1
93−0076	Hose − Trans. to Cooler	32	46	1
93−0077	Hose − Cooler, R.H.	32	49	1
93−0077	Hose − Hydraulic	14	30	1
93−0078	Hose − Cooler, L.H.	32	*	1
93−0078	Hose − Hydraulic	15	21	1
93−0079	Asm. − Hydraulic Cylinder	64	48	2
93−0081	Strip − Seal	1	9	1
93−0082	Grommet	32	58	2
93−0083	Plate − Valve	27	44	1
93−0084	Assembly − Front Axle	22	46	1
93−0089	Bracket − Mount LH, Cooler	31	*4	1
93−0090	Bracket − Mount RH, Cooler	31	4	1
93−0092	Mount − Rubber, Rear	35	30	2
93−0093	Bracket − Eng. Left Rear	35	33	1

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. No.	Ref. No.	Qty.
93−0095	Bracket − Eng. Front	35	45	2
93−0096	Decal − A.C.E.	2	27	2
93−0097	Valve − SCR	27	25	1
93−0118	Hose − Hydraulic	18	9	2
93−0118	Hose − Hydraulic	17	12	1
93−0118	Hose − Hydraulic	15	33	1
93−0119	Hose − Hydraulic	17	13	1
93−0119	Hose − Hydraulic	14	21	1
93−0139	Manifold − Hydraulic	17	17	1
93−0140	Grommet	6	10	1
93−0141	Assembly − Seat Plate	6	16	1
93−0142	Bushing − Straight	63	36	2
93−0143	Cartridge − Relief 250 psi	17	18	1
93−1268	Decal − HOC Selector	12	50	1
93−1358	Software − ECU RM5300D	12	*	1
93−1374	Latch − Swell	31	1	2
93−1375	Motor − Hydraulic	19	21	5
93−1376	Assembly − Pump, Gear	29	18	1
93−1396	Coupler W.A. − Trans.	29	7	1
93−3102	Cap − Fuel Tank	21	22	1
93−3134	Assembly − Barrel	65	1	1
93−3139	Panel − Tower	3	10	1
93−3140	Panel − Control	11	14	1
93−3163	Spring	8	28	2
93−3164	Cap	8	27	2
93−3165	Bracket	8	29	1
93−3350	Gear − Camshaft	37	35	1
93−3351	Gear − Pump, Injection	37	1	1
93−3352	Assembly − Idler, Gear	37	2	1
93−3353	Bushing − Idler	37	36	1
93−3354	Crankshaft	37	27	1
93−3355	Washer − Spring	37	12	1
93−3356	Nut	37	11	1
93−3357	Pulley − Crankshaft	37	14	1
93−3358	Assembly − Sub, Flywheel	37	25	1
93−3359	Gear − Crankshaft	37	15	1
93−3360	Cover	37	7	1
93−3361	Gasket − Cover	37	8	1
93−3361	Gasket − Tie Rod Cover	51	111	1
93−3362	Bushing − Camshaft	37	34	1
93−3363	Assembly − Shaft, Idler	37	4	1
93−3364	Ball − Steel	37	3	1
93−3365	Pin − Dowel	37	9	2
93−3366	Cap − Sealing	37	10	1
93−3367	Plug − Taper	37	32	1
93−3368	Bolt	37	33	4
93−3369	Cap − Sealing	37	31	2
93−3370	Bearing − Con−Rod	37	16	6
93−3371	Asm. − Rod, Connecting	37	23	3
93−3372	Nut	37	30	6
93−3373	Bolt − Connecting	37	17	6
93−3374	Pin − Piston	37	18	3
93−3375	Ring Set − Piston	37	19	3
93−3376	Piston − Std.	37	22	3
93−3377	Piston − O.S. 0.25	37	*	3
93−3378	Piston − O.S. 0.50	37	*	3
93−3379	Set − Ring, Piston O.S. 0.25	37	*	3
93−3380	Set − Ring, Piston O.S. 0.50	37	*	3
93−3381	Cap − Sealing	38	2	2
93−3382	Cap − Sealing	38	4	1
93−3383	Seal − Side	38	7	4
93−3383	Seal − Side	51	114	4
93−3384	Asm. − Block, Cylinder	38	20	1
93−3385	Cap − Metal	38	9	1
93−3386	Cap − Sealing	38	15	3
93−3387	Bearing − Set Std.	38	14	1
93−3388	Bearing − Set U.S. 0.50 mm	38	*	1
93−3389	Bearing − Set U.S. 0.75 mm	38	*	1
93−3390	Case − Seal, Oil	46	19	1
93−3391	Gasket − Oil Seal Case	51	115	1
93−3391	Gasket − Seal, Oil	46	21	1
93−3392	Seal − Oil	46	20	1
93−3393	Bolt	46	18	5
93−3394	Valve − Inlet	39	29	3
93−3395	Valve − Exhaust	39	28	3
93−3396	Spring − Valve	39	16	6
93−3397	Cap − Valve	39	12	6
93−3398	Asm. − Rocker & Shaft	39	*	1
93−3399	Bolt	39	9	1
93−3400	Assembly − Rocker	39	*	1
93−3401	Screw − Rocker	39	4	6
93−3402	Bracket, Shaft, Rocker	39	11	1
93−3403	Bracket − Shaft, Rocker	39	6	2
93−3404	Assembly − Shaft	39	*	1
93−3405	Cap − Sealing	39	8	2
93−3406	Spring − Rocker	39	7	2
93−3407	Bolt − Bracket, Rocker	39	10	3
93−3408	Shaft − Pump, Fuel Inject.	39	21	1
93−3409	Bearing	39	19	1
93−3410	Bolt W/Washer	39	17	1
93−3411	Rod − Push	39	22	6
93−3412	Camshaft	39	24	1
93−3413	Assembly − Strainer	40	13	1
93−3414	Gasket	40	11	1
93−3414	Gasket	51	108	1
93−3415	Assembly − Valve, Relief	40	22	1
93−3416	Housing	40	17	1
93−3417	Gasket	40	16	1
93−3417	Gasket	51	101	1
93−3418	Gauge − Level, Oil	40	1	1
93−3420	Assembly − Pump, Oil	40	15	1
93−3421	Bolt	40	14	3
93−3422	Assembly − Pan, Oil	40	9	1
93−3423	Gasket	41	4	1
93−3423	Gasket	51	113	1
93−3423	Gasket − Muffler	34	15	1
93−3424	Gasket − Cover, Rocker	41	5	1
93−3424	Gasket − Rocker	51	123	1
93−3425	Guide − Valve, In	41	8	3
93−3426	Bolt − Head, Cylinder	41	14	11
93−3427	Guide − Valve	41	15	3
93−3428	Assembly − Head, Cylinder	41	17	1
93−3429	Cap − Sealing	41	29	1
93−3430	Jet − Combustion	41	28	3
93−3431	Gasket − Cylinder Head	51	122	1
93−3431	Gasket − Head, Cylinder	41	26	1
93−3432	Bolt W/Washer	41	27	2
93−3433	Assembly − Cover, Rocker	41	11	1
93−3434	Gasket − Cover, Inlet	41	18	1
93−3434	Gasket − Inlet Cover	51	124	1
93−3435	Bolt W/Washer	41	9	4
93−3436	Gasket − Exhaust	41	30	1
93−3436	Gasket − Exhaust	51	125	1
93−3437	Asm. − Manifold, Exhaust	41	31	1
93−3438	Assembly − Cover, Inlet	41	20	1
93−3440	Pipe − Inlet	41	21	1
93−3441	Gasket − Inlet Pipe	51	118	1
93−3441	Gasket − Pipe, Inlet	41	25	1
93−3442	Bolt W/Washer	41	23	1
93−3443	Bolt W/Washer	41	24	1
93−3444	Cap − Filler	42	1	1
93−3445	Gasket − Gear	42	2	1
93−3445	Gasket − Gear	51	117	1
93−3446	Plate − Front	42	4	1
93−3447	Gasket − Front Plate	51	116	1
93−3447	Gasket − Plate, Front	42	5	1
93−3448	Case − Gear	42	6	1
93−3449	Bolt	42	8	8
93−3450	Assembly − Pump, Water	43	7	1
93−3451	Bolt W/Washer	43	6	2

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. No.	Ref. No.	Qty.
93−3452	Joint	43	5	1
93−3453	Gasket	43	8	1
93−3453	Gasket − Water Pump	51	112	1
93−3454	Plate	43	9	1
93−3455	Gasket − Pump, Water	43	10	1
93−3455	Gasket − Water Pump	51	110	1
93−3456	Bolt W/Washer	43	4	3
93−3457	Bolt W/Washer	43	11	1
93−3458	Pulley − Pump, Water	43	2	1
93−3459	Bolt W/Washer	43	1	4
93−3460	V−Belt	43	3	1
93−3461	Assembly − Pump, Fuel	44	*	1
93−3462	Assembly − Sub, Housing	44	30	1
93−3463	Holder − Delivery, Valve	44	16	3
93−3464	Spring − Delivery, Valve	44	14	3
93−3465	Gasket − Delivery, Valve	44	13	3
93−3466	Assembly − Sub, Valve	44	12	3
93−3467	Assembly − Sub, Element	44	11	3
93−3468	Sleeve − Control	44	24	3
93−3469	Seat − Spring, Upper	44	25	3
93−3470	Spring − Plunger	44	26	3
93−3471	Assembly − Sub, Tappet	44	29	3
93−3472	Assembly − Control, Rack	44	23	1
93−3473	Seat − Spring, Lower	44	27	3
93−3474	O−Ring	44	15	3
93−3475	Pin − Guide, Tappet	44	21	3
93−3476	Plate	44	22	1
93−3477	Plate − Adjusting	44	20	2
93−3478	Bolt − Washer Head	44	19	2
93−3479	Screw − Hollow	44	10	1
93−3480	Screw − Bleeder, Air	44	8	1
93−3481	Washer − Union , Pipe	44	9	1
93−3482	Plate − Shim .25 mm	44	*	A/R
93−3483	Plate − Shim .35 mm	44	*	A/R
93−3484	Plate − Shim .45 mm	44	*	A/R
93−3485	Plate − Shim .55 mm	44	*	A/R
93−3486	Plate − Shim .65 mm	44	*	A/R
93−3487	Plate − Name	44	18	1
93−3488	Rivet	44	17	2
93−3489	Assembly − Nozzle & Holder	44	*	1
93−3490	Assembly − Sub, Body	44	7	3
93−3491	Washer − 1.25 mm	44	6	A/R
93−3492	Washer − 1.3 mm	44	*	A/R
93−3493	Washer − 1.35 mm	44	*	A/R
93−3494	Washer − 1.4 mm	44	*	A/R
93−3495	Washer − 1.45 mm	44	*	A/R
93−3496	Washer − 1.5 mm	44	*	A/R
93−3497	Washer − 1.55 mm	44	*	A/R
93−3498	Washer − 1.6 mm	44	*	A/R
93−3499	Washer − 1.65 mm	44	*	A/R
93−3500	Washer − 1.7 mm	44	*	A/R
93−3501	Spring − Pressure	44	5	3
93−3502	Pin − Pressure	44	4	3
93−3503	Assembly − Nozzle	44	2	3
93−3504	Assembly − Solenoid	46	22	1
93−3505	Bracket − Starter	46	24	1
93−3506	Plug − Glow	46	16	3
93−3507	Plate − Connection	46	6	1
93−3508	Plate − Adjusting	45	16	1
93−3509	Nut	45	12	1
93−3510	Washer − Spring	45	13	1
93−3511	Washer − Plain	45	14	1
93−3512	Bolt − Alternator	45	15	1
93−3513	Pipe − Injector No.1	46	7	1
93−3514	Pipe − Injector No.2	46	10	1
93−3515	Pipe − Injector No.3	46	11	1
93−3516	Pipe − Leak Off, Fuel	46	15	1
93−3517	Bolt	46	3	4
93−3518	Nipple − Swivel	46	2	1
93−3519	Assembly − Case, Therm.	45	11	1
93−3520	Pipe	45	21	1
93−3521	Gasket − Case, Thermostat	45	8	1
93−3521	Gasket − Thermo Case	51	120	1
93−3522	Bolt W/Washer	45	19	3
93−3523	Assembly − Hose, Fuel	45	1	1
93−3524	Thermostat	45	7	1
93−3525	Gauge	45	3	1
93−3526	Switch	45	10	1
93−3527	Gasket	45	9	1
93−3527	Gasket	51	109	1
93−3528	Plug	45	2	1
93−3529	Assembly − Case, Governor	47	1	1
93−3530	Pin − Spring	47	18	1
93−3531	O−Ring	47	25	1
93−3532	Nut − Jam	47	33	1
93−3533	Bolt − Speed Set	47	31	2
93−3534	Spring − Governor	47	16	1
93−3535	Spring Set − Torque	47	13	1
93−3536	Stopper	47	11	1
93−3537	Spring − Torque	47	10	2
93−3538	Spring − Start	47	21	1
93−3539	Shim − Shaft, Governor	47	23	1
93−3540	Lever − Speed	47	35	1
93−3541	Case − Governor	47	36	1
93−3542	Lever − Spring, Governor	47	17	1
93−3543	Lever − Tension	47	19	1
93−3544	Lever − Governor	47	22	1
93−3545	Shaft − Governor	47	24	1
93−3546	Rod − Tie	47	15	1
93−3547	Spring − Rod, Tie	47	14	1
93−3548	Gasket − Case, Governor	47	29	1
93−3548	Gasket − Governor Case	51	121	1
93−3549	Shaft − Sleeve, Sliding	47	26	1
93−3550	Sleeve − Sliding	47	27	1
93−3551	Weight	47	28	1
93−3552	Wire	47	6	1
93−3553	Bolt	47	4	3
93−3554	Bolt − Case, Governor	47	3	1
93−3555	Assembly − Starter	48	*	1
93−3556	Screw	48	19	1
93−3556	Screw Set	48	3	1
93−3557	Assembly − Bracket, Front	48	4	1
93−3558	Assembly − Lever	48	5	1
93−3559	Spring Set	48	6	1
93−3560	Assembly − Bracket, Center	48	7	1
93−3561	Assembly − Switch	48	8	1
93−3562	Armature Set	48	*	1
93−3563	Bearing − Front	48	13	1
93−3564	Bearing − Rear	48	14	1
93−3565	Bolt Set	48	18	2
93−3566	Assembly − Shaft, Clutch	48	*	1
93−3567	Pinion Set	48	2	1
93−3568	Gear Set	48	21	1
93−3569	Gear	48	11	1
93−3570	Cover Set	48	10	1
93−3571	Assembly − Yoke	48	15	1
93−3572	Bolt Set	48	9	1
93−3573	Assembly − Holder	48	16	1
93−3574	Spring − Brush	48	20	4
93−3575	Assembly − Bracket, Rear	48	17	1
93−3576	Stopper Set	48	1	1
93−3577	Assembly − Alternator	49	*	1
93−3578	Nut − Set	49	1	1
93−3579	Assembly − Pulley	49	2	1
93−3580	Bolt Set	49	4	1
93−3581	Assembly − Bracket, Front	49	10	1
93−3582	Screw Set	49	3	1
93−3583	Bearing − Front	49	5	1
93−3584	Assembly − Rotor	49	7	1
93−3585	Bearing − Rear	49	6	1

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. No.	Ref. No.	Qty.
93−3586	Assembly − Stator	49	12	1
93−3587	Assembly − Bracket, Rear	49	14	1
93−3588	Regulator Set	49	13	1
93−3589	Brush	49	11	2
93−3590	Assembly − Rectifier	49	9	1
93−3591	Nut − Set	49	8	1
93−3593	Packing − Body	51	119	1
93−3594	Hose − Breather	41	13	1
93−3595	Clip − Hose	41	32	1
93−3596	Pipe − Oil Jet	37	20	3
93−3597	Bearing − Set U.S. 0.25 mm	38	*14	1
93−3598	Cap − Sealing	41	19	1
93−3599	Gasket − Liquid	40	*	1
93−3601	Decal − Service	1	25	1
93−3604	Gasket	29	6	1
93−3609	Bolt − Special	4	36	4
93−3611	Asm. − Control Manifold	15	6	1
93−3614	Assembly − Cover	20	4	1
93−3616	Assembly − Idler Gear	20	6	1
93−3617	Assembly − Differential	25	*	1
93−3617	Assembly − Drive Shaft	20	7	1
93−3618	Assembly − Gear & Pinion	25	*	1
93−3619	Upper Housing	25	26	1
93−3621	Bracket − Eng. Right Rear	35	*	1
93−3625	Spring − Return, Joystick	12	58	1
93−3626	Bracket − Hose	31	35	1
93−3626	Bracket − Hose	2	41	1
93−3639	Decal − Warning	2	48	1
93−3640	Stop − Reel, RH	64	*	1
93−3641	Plate − Idler, Stop	7	52	1
93−3642	Tube − Hydraulic	29	12	1
93−3642	Tube − Hydraulic	15	38	1
93−3643	Tube − Hydraulic	29	13	1
93−3643	Tube − Hydraulic	15	39	1
93−3644	Guard − Flywheel	34	22	1
93−3664	O−Ring	56	14	2
93−3665	O−Ring	56	15	2
93−3666	Gear Box − Axle	58	23	2
93−3667	Case − Knuckle	58	38	2
93−3668	Washer − Thrust	58	21	2
93−3669	Bearing − Needle	58	22	2
93−3670	O−Ring	58	1	4
93−3671	Pin − Dowel	58	7	4
93−3672	Arm − Knuckle	58	8	2
93−4268	Kit − Flange	30	*	1
93−4269	Kit − Housing, Section 1	30	*	1
93−4270	Kit − Housing, Section 2	30	*	1
93−4271	Kit − Housing, Section 3	30	*	1
93−4272	Kit − Individual Pieces	30	*	1
93−4277	Kit − Valve	30	19	1
93−4278	Pin − Dowel	30	4	4
93−4279	Plate − Distance	30	13	2
93−4280	Coupling	30	9	2
93−4281	Pin − Dowel	30	22	4
93−4282	Block − Valve	30	18	1
93−4283	Bolt	30	17	4
93−4284	Spacer − Cooler, Engine	40	31	1
93−4285	Cooler − Oil, Engine	40	26	1
93−4286	O−Ring	40	32	1
93−4287	O−Ring	40	30	1
93−4288	Fitting − Block, Engine	40	29	1
93−4289	Hose − Cooler, Outlet	40	28	1
93−4290	Connector − Cooler	40	25	1
93−4291	Fitting − Pump, Water	40	23	1
93−4292	Tube − Cover, Spiral	40	35	1
93−4294	Hose − Cooler, Inlet	40	33	1
93−4295	Assembly − Filter, Oil	40	4	1
93−4296	Clamp−R	40	24	1
93−4297	Clamp − Hose	40	27	4
93−6668	Decal − Battery (Europe)	52	9	1
93−6680	Decal − Fuel (Europe)	2	28	1
93−6681	Plate − Caution (Europe)	31	21	1
93−6682	Panel − Tower (Europe)	3	10	1
93−6683	Panel − Control (Europe)	11	14	1
93−6684	Decal − Backlap (Europe)	32	53	1
93−6686	Decal − Hydraulic Oil	1	4	1
93−6687	Decal − No Step (Europe)	62	62	2
93−6689	Decal − No Riders (Europe)	2	32	2
93−6691	Decal − Bolt (Europe)	22	17	1
93−6692	Decal − Starting Fluid	52	3	1
93−6693	Decal − Floor Plate	17	6	1
93−6694	Decal − Knob (Europe)	6	40	1
93−6695	Decal − Fuses (Europe)	11	27	1
93−6696	Decal − Warning (Europe)	61	33	3
93−6696	Decal − Warning (Europe)	64	45	2
93−6697	Decal − Lube (Europe)	55	36	1
93−6698	Decal − Warning (Europe)	1	24	1
93−6699	Decal − Fast/Slow (Europe)	5	18	1
93−7013	Guide − Gauge, Oil Level	40	3	1
93−7154	Decal − Service (Finnish)	2	25	1
93−7182	Guard − Fan	33	4	1
93−7183	Assembly − Lift Control	12	37	1
93−7276	Decal − Danger (Europe)	52	29	1
93−7488	Reservoir − Hydraulic	14	1	1
93−7498	Plug − Plastic	14	6	1
93−7499	Gasket − Flange	14	5	1
93−7579	Fender − R.H.	1	3	1
93−7587	Bracket − Fuse Block	11	23	1
93−7588	Cover − Tank	14	8	1
93−7840	Decal − Radiator Cap	31	37	1
93−8050	Decal − Danger (Europe)	69	3	1
93−8051	Decal − Warning (Europe)	2	48	1
93−8052	Decal − Instructions	52	4	1
93−8057	Decal − Clip (Portuguese)	6	41	1
93−8060	Decal − Danger (Europe)	6	17	1
93−8073	Decal − ROPS (Europe)	69	2	1
93−8074	Decal − Blank (Europe)	2	34	1
93−8078	Decal − Clip (Danish)	6	41	1
93−8078	Decal − Diag. (Danish)	9	1	1
93−8079	Decal − Clip (Dutch)	6	41	1
93−8079	Decal − Diag. (Dutch)	9	1	1
93−8080	Decal − Diag. (Italian)	9	1	1
93−8081	Decal − Diag. (Spanish)	9	1	1
93−8082	Decal − Diag. (German)	9	1	1
93−8083	Decal − Diag. (French)	9	1	1
93−8085	Decal − Diag. (Portuguese)	9	1	1
93−8086	Decal − Clip (Norwegian)	6	41	1
93−8086	Decal − Diag. (Norwegian)	9	1	1
93−8087	Decal − Clip (Finnish)	6	41	1
93−8087	Decal − Diag. (Finnish)	9	1	1
93−8089	Decal − Diag. (Japanese)	9	1	1
93−8091	Decal − Service (Danish)	2	25	1
93−8092	Decal − Service (Dutch)	2	25	1
93−8093	Decal − Service (Italian)	2	25	1
93−8094	Decal − Diag. (Swedish)	9	1	1
93−8094	Decal − Service (Spanish)	1	25	1
93−8095	Decal − Service (German)	1	25	1
93−8096	Decal − Service (French)	1	25	1
93−8097	Decal − Service (Swedish)	1	25	1
93−8098	Decal − Service (Portuguese)	2	25	1
93−8099	Decal − Service (Norwegian)	2	25	1
93−8744	Rivet	2	52	3
93−9933	Shield − Flywheel	33	1	1
94−2685	Cartridge − N.C.	16	7	3
94−3346	Asm. − Main Wire Harness	12	56	1
94−3349	Assembly − Frame	2	43	1
94−3510	Assembly − Fuel Tank	21	23	1
94−4934	Decal − HOC Selector	12	50	1
94−5438	Seal − Solenoid	16	23	12
217−120	Rim	23	52	2

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. No.	Ref. No.	Qty.
217−121	Rim	55	38	2
218−446	Nut − Locking	11	10	1
218−447	Washer − E.T.L.W.	11	11	1
218−498	Nut − Hex.	11	4	4
218−498	Nut − Lock	32	54	2
218−533	Lens − Red	11	*	1
218−535	Nut − Lock	11	30	1
218−536	Washer − Lock	11	29	1
218−573	Fuse − 5A	11	20	2
218−578	Fuse − 10A	11	*	3
218−579	Wire − Fuel Pump	21	34	1
218−590	Switch − Micro	12	38	2
219−17	Bulb − Light	11	*	4
219−19	Bulb − Light	12	*	1
231−134	Tire	23	53	2
231−141	Tire	55	37	2
232−27	Stem − Valve	22	3	2
232−35	Valve − Stem	55	40	2
233−17	Knob − Parking Brake	3	9	1
233−42	Knob	5	19	1
233−42	Knob − Throttle	6	34	1
237−21	O−Ring	17	2	7
237−21	O−Ring	18	2	7
237−21	O−Ring	19	4	8
237−21	O−Ring	63	14	4
237−21	O−Ring	15	18	4
237−21	O−Ring	55	22	2
237−21	Seal − O−Ring	61	5	6
237−22	O−Ring	15	1	4
237−22	O−Ring	17	14	2
237−22	O−Ring	3	14	5
237−22	O−Ring	29	15	1
237−22	O−Ring	19	19	10
237−22	O−Ring	22	20	2
237−22	O−Ring	14	23	6
237−22	O−Ring	32	47	2
237−30	O−Ring	29	11	2
237−30	O−Ring	16	12	1
237−30	O−Ring	15	13	4
237−42	O−Ring	16	5	2
237−42	O−Ring	17	16	2
237−42	O−Ring	14	25	4
237−65	O−Ring	14	10	5
237−65	O−Ring	15	22	1
237−65	O−Ring	32	50	2
237−78	O−Ring	16	1	12
237−78	O−Ring	19	2	5
237−78	O−Ring	61	3	6
237−78	O−Ring	17	4	7
237−78	O−Ring	18	4	8
237−78	O−Ring	15	7	6
237−78	O−Ring	63	12	4
237−78	O−Ring	55	20	2
237−78	O−Ring	22	22	1
237−79	O−Ring	15	9	6
237−79	O−Ring	16	10	1
237−79	O−Ring	29	17	3
237−79	O−Ring	19	18	10
237−79	O−Ring	22	18	2
237−79	O−Ring	14	45	1
237−80	O−Ring	16	20	1
237−81	O−Ring	14	12	4
237−81	O−Ring	22	25	2
237−81	O−Ring	15	26	1
237−101	O−Ring	14	7	1
237−141	Bumper	1	6	2
237−156	O−Ring	16	16	2
237−161	O−Ring	22	36	1
237−163	O−Ring	29	9	1
237−165	Grommet	55	9	2
237−181	O−Ring	23	51	1
240−3	Grommet	32	57	2
240−11	Grommet	21	28	3
240−11	Grommet	14	39	3
242−34	Stud−Flange, Axle	26	11	10
2411−36	Bearing − Rod End	5	2	1
2412−3	Clamp − Hose	31	27	2
2412−4	Clamp	35	16	2
2412−34	Clamp − Hose	29	2	1
2412−34	Clamp − Hose	31	15	2
2412−34	Clamp − Hose	14	18	3
2412−36	Clamp − Drain	21	24	1
2412−41	Clamp − R	52	23	1
2412−42	Clamp − Hose	52	1	1
2412−71	Clamp − R	36	51	1
2412−72	R−Clamp	7	51	1
2412−74	Clamp−R	64	57	2
2412−81	Clamp − R	34	21	1
2412−92	Clamp − Hose	35	20	1
2412−93	Clamp − R	6	18	1
2412−93	Clamp − R	14	32	2
2412−103	Clamp − R	31	29	2
2412−104	Clamp−R	64	53	1
2412−107	Clamp − R	64	51	1
2412−107	R−Clamp	2	51	1
2412−108	Clamp − Hose	21	12	11
2412−126	Clamp−R	12	53	1
2412−129	Clamp − Hose	22	27	2
2412−133	Clamp − R	7	42	2
251−8	Bearing − Ball	58	6	2
251−77	Collar − Locking	60	25	1
251−259	Bearing − Ball	28	11	2
251−263	Bearing − Ball	58	25	2
251−318	Bearing − Ball	35	7	2
251−337	Bearing − Ball	60	26	1
251−344	Bearing − Ball	56	4	1
251−345	Bearing − Ball	56	13	1
251−347	Bearing − Ball	58	12	2
251−348	Bearing − Ball	58	3	2
251−349	Bearing − Ball	58	17	2
251−350	Bearing − Ball	56	18	2
253−155	Seal	60	13	2
254−65	Cone−Tapered Bearing	25	28	2
254−66	Cup−Tapered Bearing	25	27	2
254−91	Cone−Bearing	25	23	1
254−108	Bearing − Roller, Tapered	56	31	1
254−109	Bearing − Roller, Tapered	56	39	1
256−42	Bushing − Sleeve	5	34	2
256−113	Bushing − Flange	28	19	2
256−115	Washer − Thrust	63	26	8
256−115	Washer − Thrust	62	41	11
256−236	Bearing − Flange	5	24	4
256−287	Bushing − Flange	63	38	4
281−7	Plug − Pipe, Square Hd.	58	37	2
281−10	Plug − Socket, Hex.	58	27	2
282−4	Clevis − Spring	63	3	2
282−4	Clevis − Spring	61	21	3
283−6	Pin − Clevis	63	10	2
283−6	Pin − Clevis	61	15	3
283−58	Pin − Clevis	5	30	4
284−3	Plug − Welch	60	20	1
302−5	Fitting − Grease	60	4	2
302−5	Fitting − Grease	34	5	1
302−5	Fitting − Grease	59	7	2
302−5	Fitting − Grease	61	11	6
302−5	Fitting − Grease	65	13	1
302−5	Fitting − Grease	66	13	1
302−5	Fitting − Grease	67	13	1
302−5	Fitting − Grease	68	13	1
302−5	Fitting − Grease	28	20	1

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. No.	Ref. No.	Qty.
302−5	Fitting − Grease	63	29	4
302−5	Fitting − Grease	5	39	1
302−11	Fitting − Grease	55	49	1
302−55	Fitting − Grease	55	34	2
302−58	Fitting − Grease	60	10	1
304−46	Drain − Radiator	31	10	1
304−46	Fitting − Drain	21	25	1
321−2	Screw − Cap Hex. Hd.	22	6	1
321−4	Screw − Cap Hex. Hd.	35	12	1
321−4	Screw − Cap Hex. Hd.	31	23	7
321−4	Screw − Cap Hex. Hd.	6	31	2
321−4	Screw − Cap Hex. Hd.	61	35	2
321−6	Screw − Cap Hex. Hd.	33	2	4
321−6	Screw − Cap Hex. Hd.	52	22	2
321−6	Screw − Cap Hex. Hd.	21	31	2
321−8	Screw − Cap Hex. Hd.	21	6	2
321−11	Screw − Cap Hex. Hd.	17	5	2
321−11	Screw − Cap Hex. Hd.	18	6	4
321−15	Screw − Cap Hex. Hd.	11	33	3
321−18	Screw − Cap Hex. Hd.	17	28	2
321−23	Screw − Cap Hex. Hd.	14	13	2
321−39	Screw − Cap Hex. Hd.	1	15	7
321−39	Screw − Cap Hex. Hd.	11	26	2
322−2	Screw − Cap Hex. Hd.	31	43	2
322−2	Screw − Cap Hex. Hd.	36	61	4
322−3	Screw − Cap Hex. Hd.	35	14	4
322−3	Screw − Cap Hex. Hd.	6	14	9
322−3	Screw − Cap Hex. Hd.	28	18	2
322−3	Screw − Cap Hex. Hd.	5	25	8
322−3	Screw − Cap Hex. Hd.	52	26	6
322−3	Screw − Cap Hex. Hd.	15	28	4
322−3	Screw − Cap Hex. Hd.	2	30	4
322−3	Screw − Cap Hex. Hd.	11	35	2
322−4	Screw − Cap Hex. Hd.	52	11	3
322−4	Screw − Cap Hex. Hd.	35	18	2
322−4	Screw − Cap Hex. Hd.	31	36	2
322−4	Screw − Cap Hex. Hd.	2	40	2
322−5	Screw − Cap Hex. Hd.	63	6	3
322−5	Screw − Cap Hex. Hd.	1	19	4
322−5	Screw − Cap Hex. Hd.	61	26	3
322−5	Screw − Cap Hex. Hd.	12	54	1
322−5	Screw − Cap Hex. Hd.	32	60	4
322−6	Screw − Cap Hex. Hd.	63	17	4
322−6	Screw − Cap Hex. Hd.	8	30	1
322−6	Screw − Cap Hex. Hd.	36	47	8
322−7	Screw − Cap Hex. Hd.	28	10	1
322−8	Screw − Cap Hex. Hd.	60	19	4
322−9	Screw − Cap Hex. Hd.	34	2	2
322−10	Screw − Cap Hex. Hd.	28	3	1
322−12	Screw − Cap Hex. Hd.	63	32	2
323−4	Screw − Cap Hex. Hd.	6	2	2
323−4	Screw − Cap Hex. Hd.	14	43	2
323−6	Screw − Cap Hex. Hd.	35	11	2
323−6	Screw − Cap Hex. Hd.	64	54	2
323−7	Screw − Cap Hex. Hd.	55	1	4
323−7	Screw − Cap Hex. Hd.	36	57	1
323−9	Screw − Cap Hex. Hd.	5	3	1
323−9	Screw − Cap Hex. Hd.	55	11	2
323−9	Screw − Cap Hex. Hd.	52	15	1
323−11	Screw − Cap Hex. Hd.	61	39	1
323−12	Screw − Cap Hex. Hd.	29	4	2
323−12	Screw − Cap Hex. Hd.	22	32	2
323−12	Screw − Cap Hex. Hd.	35	36	1
323−12	Screw − Cap Hex. Hd.	62	56	2
323−14	Screw − Cap Hex. Hd.	35	44	3
323−20	Screw − Cap Hex. Hd.	23	49	2
324−7	Screw − Cap Hex. Hd.	22	29	4
325−4	Screw − Cap Hex. Hd.	35	31	8
325−4	Screw − Cap Hex. Hd.	63	35	4
325−4	Screw − Cap Hex. Hd.	62	59	6
325−5	Screw − Cap Hex. Hd.	55	3	4
325−5	Screw − Cap Hex. Hd.	69	6	9
325−7	Screw − Cap Hex. Hd.	22	13	2
327−2	Screw − Cap Hex. Hd.	55	4	1
328−7	Screw − Cap Hex. Hd.	61	18	4
328−12	Screw − Cap Hex. Hd.	61	13	2
3210−8	Screw − Cap, Hex Hd.	24	19	8
3212−4	Bolt	7	48	2
3212−4	Screw − Cap Hex. Hd.	69	*	2
3217−6	Nut − Hex.	28	28	1
3217−6	Nut − Lock	8	32	1
3217−9	Nut − Lock	69	7	3
3218−1	Nut − Jam	23	50	1
3219−2	Nut	24	1	8
3220−3	Nut − Jam	5	1	2
3220−6	Nut	4	27	1
3220−6	Nut − Steering Wheel	3	8	1
3230−2	Bolt − Carriage	35	15	1
3230−3	Bolt − Carriage	60	1	3
3234−5	Screw − Whiz Lock	31	3	6
3234−7	Screw − Hex. Flange Hd.	2	42	1
3234−7	Screw − Hex. Flange Hd.	2	53	1
3234−14	Screw − Hex. Washer Hd.	2	33	14
3234−17	Screw − Cap Hex. Hd.	34	11	1
3245−35	Screw − Set	60	24	1
3250−29	Screw − Cap Hex. Hd.	6	7	4
3253−3	Washer − Lock	22	7	1
3253−3	Washer − Lock	60	16	6
3253−3	Washer − Lock	6	30	1
3253−3	Washer − Lock	11	32	3
3253−4	Washer − Lock	3	2	2
3253−4	Washer − Lock	6	13	4
3253−4	Washer − Lock	63	16	2
3253−4	Washer − Lock	28	17	2
3253−4	Washer − Lock	1	20	4
3253−4	Washer − Lock	15	29	4
3253−4	Washer − Lock	31	39	4
3253−4	Washer − Lock	36	60	4
3253−5	Washer − Lock	29	5	2
3253−6	Washer − Lock	69	*	2
3253−6	Washer − Lock	8	25	2
3253−6	Washer − Lock	7	47	2
3253−7	Washer − Lock	69	5	9
3253−7	Washer − Lock	35	32	8
3253−7	Washer − Lock	64	39	4
3253−7	Washer − Lock	62	58	6
3253−15	Washer − Lock	21	9	5
3253−21	Washer − Lock	52	16	1
3253−21	Washer − Lock	22	33	2
3253−21	Washer − Lock	35	35	1
3253−21	Washer − Lock	14	42	2
3253−33	Washer − Lock	8	31	1
3255−8	Washer − Lock	35	22	2
3255−8	Washer − Lock ETLW	3	31	1
3255−9	Washer − Lock E.T.L.W.	36	49	1
3256−1	Washer − Flat	11	13	5
3256−1	Washer − Flat	1	14	10
3256−1	Washer − Flat	3	29	2
3256−3	Washer − Flat	2	31	4
3256−3	Washer − Flat	11	34	3
3256−5	Washer − Flat	8	4	1
3256−6	Washer − Flat	64	40	4
3256−6	Washer − Flat	62	57	6
3256−22	Washer − Flat	33	3	8
3256−22	Washer − Flat	21	4	2
3256−22	Washer − Flat	5	6	2
3256−22	Washer − Flat	3	11	4
3256−22	Washer − Flat	31	22	4
3256−22	Washer − Flat	61	34	2
3256−23	Washer − Flat	63	7	10

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. No.	Ref. No.	Qty.
3256−23	Washer − Flat	6	12	8
3256−23	Washer − Flat	3	15	6
3256−23	Washer − Flat	35	17	6
3256−23	Washer − Flat	1	18	6
3256−23	Washer − Flat	52	25	2
3256−23	Washer − Flat	61	25	3
3256−23	Washer − Flat	31	38	4
3256−24	Washer	8	5	1
3256−24	Washer − Flat	55	2	2
3256−24	Washer − Flat	5	4	1
3256−24	Washer − Flat	52	17	1
3256−24	Washer − Flat	6	19	3
3256−24	Washer − Flat	61	24	3
3256−24	Washer − Flat	63	30	4
3256−24	Washer − Flat	14	41	2
3256−24	Washer − Flat	36	50	4
3256−26	Washer − Flat	28	2	1
3256−26	Washer − Flat	69	4	9
3256−26	Washer − Flat	3	22	1
3256−26	Washer − Flat	8	24	2
3256−40	Washer − Flat	36	66	2
3256−46	Washer − Flat	8	20	1
3256−69	Washer − Thrust	5	31	3
3256−70	Washer − Flat	34	12	2
3256−78	Washer − Flat	35	25	1
3258−19	Screw − Machine	53	6	2
3258−166	Screw − Phillips Hd.	11	12	5
3258−166	Screw − Phillips Hd.	3	28	2
3258−166	Screw − Phillips Hd.	2	46	3
3269−10	Washer − Back−up	31	30	7
3269−13	Rivet − Pop	31	32	17
3269−15	Rivet − Pop	31	5	8
3272−2	Pin − Cotter	5	5	2
3272−4	Pin − Cotter	1	11	2
3272−5	Pin − Cotter	3	17	3
3272−10	Pin − Cotter	28	1	1
3272−10	Pin − Cotter	63	4	2
3272−10	Pin − Cotter	61	17	3
3272−10	Pin − Cotter	3	21	1
3272−10	Pin − Cotter	6	21	2
3272−10	Pin − Cotter	5	40	4
3272−11	Pin − Cotter	55	10	1
3272−17	Pin − Cotter	58	31	2
3273−26	Screw − Hex. Socket Hd.	12	45	2
3274−8	Screw − Cap Hex. Hd.	60	17	6
3274−34	Screw − Socket Flat Hd.	60	30	1
3290−93	Screw − Cap Hex. Hd.	12	39	4
3290−271	Rivet − Pop	31	20	2
3290−336	Tie − Cable	63	1	1
3290−336	Tie − Cable	61	14	3
3290−354	Plate − Nut	11	36	2
3290−378	Tie − Cable	3	*	3
3290−378	Tie − Cable	31	17	1
3290−378	Tie − Cable	55	25	1
3290−378	Tie − Cable	52	28	1
3290−378	Tie − Cable	64	42	3
3290−378	Tie − Cable	62	68	5
3290−461	Washer − Belleville	5	21	1
3290−488	Boot − Lift Control	12	40	1
3290−489	Knob − Lift Control	11	3	1
3296−2	Nut − Lock	11	18	5
3296−3	Nut − Lock	6	27	3
3296−9	Nut − Hex.	28	24	2
3296−20	Nut − Lock	3	16	4
3296−23	Nut − Lock	55	7	4
3296−23	Nut − Lock	22	16	2
3296−29	Nut − Lock	60	6	7
3296−29	Nut − Lock	28	9	4
3296−29	Nut − Lock	63	9	8
3296−29	Nut − Lock	34	14	2
3296−29	Nut − Lock	5	23	8
3296−29	Nut − Lock	6	23	9
3296−29	Nut − Lock	52	27	4
3296−29	Nut − Lock	35	43	10
3296−29	Nut − Lock	62	45	3
3296−29	Nut − Lock	32	59	2
3296−39	Nut − Lock	55	8	2
3296−39	Nut − Lock	6	9	3
3296−39	Nut − Lock	63	31	6
3296−39	Nut − Lock	22	35	2
3296−39	Nut − Lock	35	38	4
3296−39	Nut − Lock	5	38	1
3296−39	Nut − Lock	55	45	2
3296−39	Nut − Lock	62	52	2
3296−42	Nut − Lock	21	3	2
3296−42	Nut − Lock	33	5	4
3296−42	Nut − Lock	1	13	7
3296−42	Nut − Lock	14	15	2
3296−42	Nut − Lock	17	21	4
3296−42	Nut − Lock	11	22	4
3296−42	Nut − Lock	31	25	7
3296−42	Nut − Lock	3	30	2
3296−42	Nut − Lock	61	37	2
3296−42	Nut − Lock	36	63	1
3296−44	Nut − Lock	8	22	1
3296−44	Nut − Lock	34	23	3
3296−44	Nut − Lock	61	23	4
3296−48	Nut − Lock	22	45	4
3296−51	Nut − Lock	61	19	6
3296−54	Nut − Lock	6	4	4
3296−56	Nut − Lock	22	4	2
3296−59	Nut − Lock	5	22	1
3296−59	Nut − Lock	6	35	2
3296−59	Nut − Lock	36	54	1
32104−76	Screw − Thread Forming	62	48	2
32105−1	Screw − Cap Hex. Hd.	12	43	1
32105−13	Screw − Cap Hex. Hd.	11	17	4
32105−21	Screw	28	4	2
32107−11	Nut−Square	53	5	2
32108−9	Screw − Machine	22	12	1
32120−74	Ring − Retaining	27	53	1
32120−93	Ring − Retaining	63	25	4
32120−93	Ring − Retaining	61	29	6
32121−2	Pin − Roll	35	4	2
32121−6	Pin − Roll	5	9	1
32121−16	Pin − Roll	5	32	1
32121−34	Pin − Roll	60	18	1
32121−38	Pin − Roll	6	22	1
32121−45	Pin − Roll	5	10	2
32121−50	Pin − Roll	5	41	1
32121−122	Pin − Roll	64	44	2
32121−122	Pin − Roll	62	55	3
32122−24	Screw − Round Hd.	21	10	5
32128−20	Nut − Flange Head	34	18	1
32128−20	Nut − Lock	52	19	3
32128−20	Nut − Whiz	31	8	6
32128−26	Nut − Flange	8	21	4
32128−33	Nut − Flange Head	2	45	3
32128−33	Nut − Lock	18	10	4
32128−33	Nut − Lock	52	20	2
32128−33	Nut − Lock, Flange	21	36	2
32128−33	Nut − Lock, Flange Hd.	12	55	3
32136−13	Nut − Slotted	55	16	2
32144−1	Screw − Cap Hex. Hd.	12	41	2
32144−4	Screw − Self Tapping	55	19	1
32144−10	Screw − Hex. Washer Hd.	14	33	2
32144−14	Screw − Self Tapping	62	66	3
32144−18	Screw − Cap Hex. Hd.	12	46	2
32144−21	Screw	3	6	1
32144−22	Screw − Cap Hex. Hd.	28	13	4

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. No.	Ref. No.	Qty.
32144−26	Screw − Self−Tapping	3	1	2
32144−49	Screw − Hex. Washer Hd.	64	56	2
32144−112	Screw − Cap Hex. Hd.	22	8	8
32144−112	Screw−Thread Forming	24	13	8
32148−7	Nut − Clinch	31	34	2
32149−1	Nut − Lock	36	59	1
32151−36	Ring − Retaining	64	47	4
32151−41	Ring − Retaining	20	13	1
32151−48	Ring − Retaining	63	5	2
32151−48	Ring − Retaining	61	20	3
32151−61	Ring − Retaining	63	18	4
32151−62	Ring − Retaining	22	38	1
32151−87	Ring − Retaining	60	21	1
32152−10	Nut	65	2	1
32152−10	Nut	66	2	1
32152−10	Nut	67	2	1
32152−10	Nut	68	2	1
33103−025	Screw − Hex. Flange Hd.	21	26	3
33105−025	Screw − Hex. Flange Hd.	14	36	3
33105−030	Screw − Hex. Flange Hd.	14	38	6
340−2	Fitting − Hydraulic Straight	17	15	2
340−3	Fitting − Hydraulic Straight	15	5	1
340−3	Fitting − Hydraulic Straight	29	16	1
340−3	Fitting − Hydraulic, Straight	22	19	2
340−4	Fitting − Hydraulic Straight	29	10	2
340−8	Fitting − Hydraulic Straight	14	11	2
340−13	Fitting − Hydraulic Straight	18	12	2
340−13	Fitting − Hydraulic Straight	15	19	2
340−13	Fitting − Straight	62	64	2
340−18	Fitting − Hydraulic 90˚	15	2	2
340−18	Fitting − Hydraulic 90˚	19	7	10
340−21	Fitting − Hydraulic Tee	19	13	1
340−77	Fitting − Hydraulic 90˚	14	22	1
340−77	Fitting − Hydraulic 90˚	17	27	1
340−82	Fitting − Hydraulic 90˚	14	47	2
340−87	Fitting − Hydraulic 45˚	14	27	1
340−92	Fitting − Hydraulic Straight	18	3	4
340−92	Fitting − Hydraulic Straight	15	17	2
340−92	Fitting − Hydraulic Straight	17	26	4
340−101	Fitting − Hydraulic 45˚	15	10	2
340−101	Fitting − Hydraulic 45˚	16	11	1
340−103	Fitting − Hydraulic 45˚	19	3	5
340−103	Fitting − Hydraulic 45˚	63	13	1
340−124	Fitting − Straight	32	48	2
340−132	Fitting − Hydraulic 90˚	17	3	3
340−132	Fitting − Hydraulic 90˚	61	4	5
340−132	Fitting − Hydraulic 90˚	18	8	1
340−132	Fitting − Hydraulic 90˚	55	21	2
340−132	Fitting − Hydraulic 90˚	63	22	3
340−139	Fitting − Hydraulic 90˚	15	23	1
340−139	Fitting − Hydraulic 90˚	14	35	1
340−143	Fitting − Hydraulic 90˚	18	11	1
340−143	Fitting − Hydraulic 90˚	16	18	1
340−143	Fitting − Hydraulic 90˚	15	32	1
340−143	Fitting − Hydraulic 90˚	62	70	1
351−78	Edging	6	1	1
353−512	Fitting − Hydraulic Plug	18	5	2
353−550	Fitting − Plug	14	44	1
353−599	Pin−Dowel	20	3	2
353−682	Fitting − Hydraulic Straight	14	20	1
353−781	Fitting − 90˚	21	30	2
353−989	Plug	16	6	2
353−990	Plug	16	2	11
353−991	Plug	16	17	2
354−20	Fitting − Fuel Tee	21	15	1
354−21	Fitting − Fuel Straight	21	17	1
354−22	Fitting − Fuel, Straight	21	14	2
354−46	Ring−Seal	20	8	1
354−50	Screw−Hex Socket Hd.	20	1	4
354−51	Washer	20	2	4
354−70	Plug	16	21	1
354−72	Fitting − Hydraulic 45˚	22	42	1
354−73	Fitting − Hydraulic Straight	14	24	2
354−74	Fitting − Hydraulic Plug	14	16	1
354−75	Fitting − Hydraulic 90˚	22	40	1
354−77	Fitting − Hydraulic Test Port	22	23	1
354−77	Fitting − Test Port	15	11	2
354−78	Fitting − Hydraulic	29	3	1
354−79	Cap − Test Port	15	12	2
354−79	Cap − Test Port	22	24	1

*Not Illustrated

TABLE OF CONTENTS

Description	Page
Frame & Body Assembly	1−2
Steering Tower Assembly	3
Steering Valve Assembly No. 75−0600	4
Traction & Brake Pedals Assembly	5
Seat & Throttle Assembly	6−7
Seat Suspension Assembly	8
Diagnostic−ACE Display Assembly	9
Electrical Schematic	10
Control Console Assembly	11−12
Hydraulic Schematic	13
Hydraulic Reservoir Assembly	14
Hydraulic Control Manifold Assembly	15
Control Manifold Assembly	16
Front Hydraulic Manifolds	17
Rear Hydraulic Manifolds	18
Cutting Unit Hydraulic Components	19
Reel Motor Assembly No. 93−1375	20
Fuel Tank Assembly	21
Front Axle & Transmission Assembly	22−23
Front Axle Assembly No. 93−0084	24−25
Brake Assembly	26
Transmission Assembly No. 75−0012	27
Traction Control Assembly	28
Gear Pump Installation Assembly	29
Hydraulic Pump Assembly No. 93−1376	30
Radiator Assembly	31−32
Fan Guard & Flywheel Shield Assembly (Europe)	33
Muffler & Pump Drive Assembly	34
Engine Installation Assembly	35−36
Timing Gear, Piston, Flywheel & Crankshaft	37

Description	Page
Cylinder Block And Bearing Assembly	38
Valve, Camshaft And Rocker Assembly	39
Oil Pan, Pump Relief Valve	40
Cylinder Head, Manifold & Cover Assembly	41
Timing Gear Case	42
Water Pump Assembly	43
Fuel Injection Pump Assembly	44
Thermostat And Alternator Mount Assembly	45
Fuel And Starter System Assembly	46
Governor	47
Starter Assembly	48
Alternator Assembly	49
Overhaul Gasket Kit	50−51
Engine Components Assembly	52
Air Cleaner Assembly	53
Fuel Filter Assembly	54
Rear Axle Installation Assembly	55
Rear Axle Assembly No. 68−6823	56−58
Hydraulic Cylinder No. 83−5030	59
Drive Shaft Assembly	60
Front Lift Arms Assembly	61−62
Rear Lift Arms Assembly	63−64
Hydraulic Cylinder Assembly No. 93−0079	65
Hydraulic Cylinder Assembly No. 85−9880	66
Hydraulic Cylinder Assembly No. 83−7480	67
Hydraulic Cylinder Assembly No. 83−7490	68
R.O.P.S. Assembly (Optional)	69
Special Tools	70
International Parts Reference	71−72
Part Number Index	73−85

European parts kit number 93−7184 contains all of the individual parts on the preceding pages designated as (Europe).

IDENTIFICATION AND ORDERING

MODEL AND SERIAL NUMBERS

The Reelmaster® 5300D has two identification numbers; a model number and a serial number. The two numbers are stamped on a decal which is located on the traction unit frame under the seat. In any correspondence concerning the Reelmaster 5300D, supply model and serial numbers to assure that correct information and replacement parts are obtained.

To order replacement parts from an Authorized TORO Service Dealer, supply the following information:

1. Model and serial number of the Reelmaster 5300D.
2. Part number, description, and the quantity of part(s) desired.

NOTE: Do not order by reference number if a parts catalog is being used; use the PART NUMBER.

COUNTRIES OTHER THAN THE UNITED STATES OR CANADA

Customers who have purchased TORO products exported from the United States or Canada should contact their Toro Distributor (Dealer) to obtain guarantee policies for your country, province or state.

MAINTENANCE RECORD

Date								

MAINTENANCE RECORD

Date								