
FORM NO. 3321–612

TORO®

MODEL NO. 30581–90001 & UP

PARTS CATALOG

GROUNDSMASTER® 580–D
Traction Unit



T–1278–2


SEAT ASM

Ref. No.	Part No.	Description	No. Used
1	92–6280	Asm–Seat (Incl. Ref. #2, 3 & 7)	1
2	92–6534	Shell–Seat	1
3	351–78	Edging	1
4	3296–29	Nut–Lock	4
5	3234–5	Screw–HH	4
6	98–3048	Plate–Seat	1
7	92–6533	Cushion–Seat	1
8	3256–24	Washer–Flat	2
9	69–0770	Bracket–Arm Rest RH	1
*	69–0760	Bracket–Arm Rest LH	1
10	92–7301	Spacer	2
11	69–1180	Armrest	2
12	32128–19	Nut–HHF	2
13	323–9	Screw–HH	2
14	3234–14	Screw–HH	6
15	92–6282	Switch–Seat	1
16	321–3	Screw–HH	2
*	98–7326	Harness–Wire, Seat Switch	1

* Not Illustrated

© The TORO Company – 1998
All Rights Reserved

TPS




T−1279−1

SEAT PIVOT AND BELLOWS ASM

Ref. No.	Part No.	Description	No. Used
1	74−0720	Tube−Manual	1
2	2412−133	Clamp	2
3	66−8530	Track−Adjustment	1
4	82−9060	Track & Latch−Adjustment	1
5	71−2410	Plate−Upper Suspension (Incl. Ref. #6)	1
6	71−2400	Asm−Bumper (Incl. Ref. #7 & 8)	2
7	71−2380	Washer	2
8	71−2390	Rivet−Pop	2
9	323−6	Screw−HH	2
10	3253−21	Washer−Lock	2
11	83−6660	Support−Seat	1

Ref. No.	Part No.	Description	No. Used
12	71−2420	Bellows−Rubber	1
13	39−5710	Plug	21
14	40−3890	Trim	2
15	48−7780	Screw−HH	2
16	3256−23	Washer−Flat	4
17	3296−29	Nut−Lock	4
18	32121−4	Pin−Roll	1
19	27−4720	Pin−Pivot, Seat	1
20	3230−22	Bolt−CARR	1
21	33104−025	Screw−HHF	2
22	33015−00	Nut	2
23	33004−00	Nut−HWH	2




T−0483−1

SEAT SUSPENSION ASM

Ref. No.	Part No.	Description	No. Used
1	40−4010	Roller	4
2	71−2180	Bearing	4
3	71−2190	Pin	1
4	71−2290	Bearing−Trible	1
5	40−4090	Rivet−Pop	2
6	40−4080	Track−U	1
7	40−4120	Plate−Rubber	1
8	71−2310	Plate−Lower Suspension (Incl. Ref. #5−7 & 9)	1
9	71−2300	Bumper	2
10	71−2280	Band−Weight Indicator	1
11	40−4150	Roller	1
12	40−4160	Guide−Sleeve	1
13	71−2210	Pin	1
14	71−2230	Ring−Snap	1
15	71−2240	Asm−Knob (Incl. Ref. #13, 14 & 16)	1
16	71−2220	Pin	1
17	40−4230	Plug	1
18	71−2250	Bracket−Spring	1
19	71−2330	Ring−Snap	2
20	71−2340	Absorber−Shock	1
21	71−2320	Pin	2
22	71−2170	Pin	1
23	71−2270	Nut−Special	1
24	40−4070	Washer	3
25	40−4310	Bearing−Thrust Needle	1
26	40−4060	Washer−Rubber	1
27	71−2260	Spring	2
28	40−4340	Spring−Extension	1
29	40−4350	Spring−Extension	2
30	40−4360	Plate	1
31	40−4370	Bolt	1
32	40−4380	Bracket−Release	2
33	71−2200	Bracket−Swing Arm (Incl. Ref. #1−3, 22 & 29−32)	1
*	71−0480	Asm−Suspension (Incl. Ref. #1−33, & 6−8, 12 & 13, from page 2)	1

* Not Illustrated




STEERING TOWER ASM

Ref. No.	Part No.	Description	No. Used
1	69−1560	Lever−Lock	1
2	69−9230	Shaft−Steering Pivot	1
3	233−17	Knob	1
4	69−9440	Panel−Steering Tower	1
5	44−2210	Body−Indicator Light (Incl. Ref. #6−7 & 23−24)	1
†6		Bulb−Indicator Light (#1891)	3
7	218−533	Lens−Indicator Light (Red)	1
8	98−7325	Cover−Steering Wheel	1
9	47−6990	Nut−Hex.	1
10	68−8080	Wheel−Steering	1
11	218−562	Lens−Indicator Light (Amber)	2
12	44−2212	Body−Indicator Light (Incl. Ref. #6, 11 & 23−24)	2
13	32144−64	Screw−HWH	4
14	20−9500	Spacer	2
15	31−0390	Washer−Friction	3
16	323−7	Screw−HH	4
17	3253−21	Washer−Lock	4
18	69−9540	Bracket−Steering Gear	1
19	69−7760	Link−Steering Gear	1
20	3296−49	Nut−Lock	1
21	69−7740	Support−Steering Gear	1
22	32128−20	Nut−HHF	2
23	218−536	Washer−Lock	3

Ref. No.	Part No.	Description	No. Used
24	218−535	Nut−Hex.	3
25	3234−14	Screw−HWH	8
26	46−1600	Spacer	4
27	71−0540	Column−Steering	1
28	92−9748	Valve−Power Steering	1
29	3256−26	Washer−Flat	3
30	325−5	Screw−HH	3
31	69−8160	Tower−Steering	1
32	340−133	Fitting−Hydraulic Straight (Incl. Ref. #37 & 39)	3
33	69−5500	Hose−Hydraulic	4
34	32128−23	Nut−HHF	3
35	28−0380	Spacer	3
36	3290−378	Tie−Cable	5
37	237−22	O−Ring	4
38	69−6980	Valve−Check (Incl. Ref. # 37 & 39)	1
39	237−79	O−Ring	4
40	71−4060	Rod−Brake Latch	1
41	69−8510	Cover−Steering Tower	1
43	3272−5	Pin−Cotter	1
44	3256−22	Washer−Flat	1
45	95−1821	Spring−Compression	1
46	95−0825	Panel−Control	1
47	62−5550	Decal	1
48	93−7252	Decal−CE	1
*	72−0130	Kit−Horn	1

† Obtain Locally



T−1007−2


POWER STEERING VALVE ASM NO. 92−9748

Ref. No.	Part No.	Description	No. Used
1	52−9260	Screw−Set	1
†2		Seal−1” ID	1
3	52−9230	Ring−Retaining	1
4	52−9240	Bushing−Gland Seal	1
†5		Seal−1.875” ID	1
†6		Seal−Quad Ring	1
7	59−6730	Race−Bearing	2
8	59−6740	Bearing−Needle Thrust	1
†9		Housing	1
†10		Sleeve−Control	1
11	59−6820	Kit−Centering Spring	1
†12		Spool−Control	1
†13		Seal	3
14	92−9732	Plate−Wear	1
15	52−9320	Drive	1

Ref. No.	Part No.	Description	No. Used
16	69−1860	Gerotor	1
17	69−1880	Spacer	1
18	92−9730	Cap−End	1
19	92−9735	Screw−Cap	7
20	59−6830	Kit−Centering Pin	1
21	52−9290	Retainer−Check Ball	1
22	52−9280	Ball−Check	1
†23		Seal	1
24	52−9270	Seat−Check Ball	1
†25		Seal	1
*	52−9250	Kit−Needle Bearing (Incl. Ref. #7−8)	1
*	92−9749	Kit−Seal (Incl. Ref. #2, 5−6,13, 23 & 25)	1

* Not Illustrated
† Not Serviceable Separately

3321−612




T−0339−1

STEERING BRAKE ASM

Ref. No.	Part No.	Description	No. Used
1	256−247	Bushing−Flange	4
2	69−7890	Arm−Brake RH (Incl. Ref. #1 & 3)	1
3	302−5	Fitting−Grease	2
4	69−9210	Lever−Brake Latch	1
5	321−4	Screw−HH	1
6	3272−5	Pin−Cotter	1
7	69−7720	Pawl−Brake	1
8	69−9200	Pin−Brake Pawl	1
9	3272−6	Pin−Cotter	2
10	321−2	Screw−HH	1
11	69−7790	Pin−Brake Arm	1
12	32152−1	Nut−Lock	4
13	29−6163	Switch−Micro	1
14	3296−9	Nut−Lock	2

Ref. No.	Part No.	Description	No. Used
15	32152−4	Nut−Lock	2
16	69−7840	Mount−Brake Arm	1
17	32128−20	Nut−HHF	3
18	3234−14	Screw−HH	3
19	49−6171	Pad−Brake Pedal LH	1
*	49−6172	Pad−Brake Pedal RH	1
20	69−7700	Pedal−Brake	2
21	323−4	Screw−HH	4
22	69−5670	Cable−Brake	2
23	69−7880	Arm−Brake LH (Incl. Ref. #1 & 3)	1
24	283−1	Pin−Clevis	2
25	3290−307	Pin−Cotter, Hair	2
26	3249−11	Screw−Machine	2
*	3290−378	Tie−Cable	3

* Not Illustrated




T−0341−1

SERVICE BRAKE ASM

Ref. No.	Part No.	Description	No. Used
1	69−8750	Arm−Brake	1
2	32152−1	Nut−Lock	2
3	69−7700	Pedal−Brake	1
4	49−6170	Pad−Brake	1
5	322−3	Screw−HH	2
6	3272−12	Pin−Cotter	1
7	323−7	Screw−HH	3
8	32128−21	Nut−HHF	3
9	69−2640	Asm−Master Cylinder	1
10	353−994	Adapter	1
11	74−2530	Tube−Hydraulic	1
12	218−243	Fitting−Tee	1
13	74−2510	Tube−Hydraulic LH	1
14	74−2520	Tube−Hydraulic RH	1

Ref. No.	Part No.	Description	No. Used
15	69−9340	Rod−Brake	1
16	3272−10	Pin−Cotter	1
17	3220−2	Nut−Jam	1
18	282−2	Clevis−Brake Rod	1
19	3234−13	Screw−HWH	2
20	32149−2	Nut−Keps	2
21	93−7039	Bracket−Service Brake	1
22	93−7037	Switch	1
23	21−1830	Spring−Extension	1
24	283−1	Pin−Clevis	1
25	218−242	Switch−Brake	1
26	32144−1	Screw−HH	2
27	32127−11	Nut−Flexlok	2
28	93−9337	Bracket−Switch	1




T−0384−1

BRAKE SYSTEM MASTER CYLINDER NO. 69−2640

Ref. No.	Part No.	Description	No. Used
1	69−2650	Boot−Rod	1
2	69−2660	Ring−Retaining	1
†3		Seal−Lip	1
†4		Piston	1
†5		Protector−Cup	1
†6		Cup−Pumping	1
†7		Retainer−Cup	1

Ref. No.	Part No.	Description	No. Used
†8		Spring−Piston Return	1
9	69−2750	Cover−Reservoir	1
10	69−2760	Gasket−Diaphragm	1
11	69−2770	Seat−Tube	1
12	69−2740	Bail−Cover	1
*	69−2730	Asm−Piston (Incl. Ref. #3−8)	1


* Not Illustrated
† Not Serviceable Separately



TRACTION PEDAL & CRUISE CONTROL ASM

Ref. No.	Part No.	Description	No. Used
1	3217−7	Nut−Lock	1
2	3253−21	Washer−Lock	2
3	92−9701	Shaft−Cruise Control	1
4	32149−2	Nut−Keps	4
5	42−1720	Asm−Field Core Coil	1
6	321−3	Screw−HH	4
9	99−5348	Plate−Clutch	1
10	43−6320	Collar−Locking	1
11	69−9390	Shaft−Pedal	1
12	3234−14	Screw−HH	1
13	32128−20	Nut−HHF	1
14	69−9030	Post−Neutral Device	1
15	23−2270	Bushing−Rubber	1
16	74−2700	Rod−Control	1


Ref. No.	Part No.	Description	No. Used
17	3256−6	Washer−Flat	1
18	3272−10	Pin−Cotter	1
19	3220−5	Nut−Jam	1
20	21−0141	Joint−Ball	1
21	3220−3	Nut−Jam	2
23	3272−7	Pin−Cotter	2
24	99−5347	Pedal−Traction	1
25	71−0440	Abrasive−Pedal Front	1
26	3245−32	Screw−Set	1
27	43−6200	Spring−Compression	1
28	256−273	Bushing−Flange	1
29	71−0450	Abrasive−Pedal Rear	1
30	256−156	Bushing−Flange	2
31	323−6	Screw−HH	1



T−0876−1

TOOL BOX ASM

Ref. No.	Part No.	Description	No. Used
1	3234−14	Screw−HFH	4
2	71−0410	Cover−Abrasive	1
3	69−8080	Cover−Tool Box	1
4	69−9430	Foam−Tool Box	1
5	69−8110	Box−Tool	1




T−0340−3

CONTROL BOX ASM

Ref. No.	Part No.	Description	No. Used
1	69−9560	Housing−Control	1
2	3234−7	Screw−HWH	11
3	80−9330	Alarm−Audio	1
4	323−4	Screw−HH	4
5	98−1487	Decal−Fuse	1
6	69−6260	Magnet	1
7	32105−12	Screw−HSH	2
8	32105−13	Screw−HH	4
11	3290−133	Screw−Round Hd.	4
12	3256−22	Washer−Flat	4
13	69−7040	Holder−Cup	1
14	321−3	Screw−HH	4
15	3253−3	Washer−Lock	4
16	71−2430	Plate−Rear	1
17	71−4130	Support−Control	1
18	3290−378	Tie−Cable	2
19	3253−21	Washer−Lock	4
21	3296−2	Nut−Lock	6
22	92−5720	Controller	1
23	32149−7	Nut−Keps	3

Ref. No.	Part No.	Description	No. Used
24	67−7160	Block−Fuse	4
25	3234−14	Screw−HH	2
26	69−8210	Support−Cover	1
27	32128−20	Nut−HHF	2
32	99−4416	Decal−Service	1
32	95−0832	Decal−Service (Europe)	1
33	218−581	Fuse−15A	6
34	92−8661	Tab	3
35	3229−8	Bolt−CARR	3
36	32149−2	Nut−Keps	3
37	85−4491	Holder−Indicator, Light (Incl. Ref. #38−40)	1
38	219−19	Bulb	1
39	3220−24	Nut−Hex.	1
40	3254−6	Washer−Lock, Int. Tooth	1
*	98−7309	Asm−Wire Harness (Incl. Ref. #24)	1
*	218−573	Fuse−5A	1
*	3290−378	Tie−Cable	25


* Not Illustrated



T−1458−1

DIAGNOSTIC DISPLAY ASM

Ref. No.	Part No.	Description	No. Used
1	95−0834	Decal−Diagnostic V2.0 GM 580D	1
2	85−4750	Display−Diagnostic	1




T−1448−1

UPPER CONTROL PANEL ASM

Ref. No.	Part No.	Description	No. Used
1	3290−133	Screw−Round Hd.	4
2	3256−23	Washer	4
3	95−0827	Panel	1
4	71−4210	Cluster−Warning Light	1
5	86−7410	Plate−Gage	1
6	71−4200	Cluster−Warning Light	1
7	32104−16	Screw−Tapping	4
8	63−7430	Gauge−Temperature	1
9	219−17	Bulb−Light	8
10	43−6280	Button	2

Ref. No.	Part No.	Description	No. Used
11	43−6420	Bezel	2
15	3296−2	Nut−Lock	2
16	92−1771	Board−Instrument	1
17	32105−1	Screw−HH	2
18	218−498	Nut	2
20	71−4250	Spacer	2
23	69−4780	Clamp−Gauge	2
24	32144−19	Screw−Round Hd.	4
25	66−2940	Gauge−Fuel	1
26	66−2950	Hourmeter	1




T−2814-1

LOWER CONTROL PANEL ASM


Ref. No.	Part No.	Description	No. Used
1	95−0815	Panel−Lever	1
2	3256−22	Washer−Flat	8
3	3290−133	Screw−Round Hd.	8
4	3296−42	Nut−Lock	4
5	98−3041	Plate−Control	1
6	98−3040	Panel−Control	1
7	218−498	Nut−Hex	10
8	218−447	Washer−Lock	1
9	218−446	Nut−Hex	1
10	233−66	Knob	1
11	63−8360	Key−Ignition	1
12	43−6280	Button	2
13	43−6420	Bezel	2
14	69−9740	Switch−Toggle (Incl. Ref. #7)	1
15	72−9760	Switch (Incl. Ref. #7, 12 & 13)	2

Ref. No.	Part No.	Description	No. Used
16	99−2319	Switch−Ignition (Incl. Ref. #8 & 9)	1
17	3290−392	Screw−HH	1
18	69−9730	Switch−Toggle (Incl. Ref. #7)	1
19	71−4170	Switch−Toggle (Incl. Ref. #7)	1
20	69−9310	Plate−Lever	1
21	3253−15	Washer−Lock	A/R
22	95−0831	Decal−Fuse	1
23	44−2210	Kit−Light (Incl. Ref. #24−27)	1
24	218−535	Nut−Hex.	1
25	218−536	Washer−Lock	1
26	218−533	Lens−Red	1
27	93−7480	Bulb−LED	1


ELECTRICAL SCHEMATIC




CONTROLLER ELECTRICAL SCHEMATIC



OPERATORS CONTROL PANEL ELECTRICAL SCHEMATIC



T–1655–1




T−0352−1

THROTTLE ASM

Ref. No.	Part No.	Description	No. Used
1	3296−42	Nut−Lock	3
2	3−2858	Disc−Friction	1
3	233−48	Knob	1
4	69−8040	Arm−Throttle	1
5	283−67	Pin−Clevis Arm End	1
*	69−0090	Pin−Clevis Engine End	1
6	282−28	Clevis−Adjustable	2
7	3219−14	Nut−Hex.	2

Ref. No.	Part No.	Description	No. Used
8	77−2990	Cable−Throttle	1
9	3272−1	Pin−Cotter	3
10	321−3	Screw−HH	3
11	69−9130	Bracket−Throttle	1
12	3−8596	Spring−Compression	1
13	3256−26	Washer−Flat	1
14	3296−23	Nut−Lock	1

* Not Illustrated




T−0355−1

LIFT VALVE INSTALLATION ASM

Ref. No.	Part No.	Description	No. Used
1	321−10	Screw−HH	2
2	69−1780	Asm−Lift Valve	1
3	233−42	Knob	3
4	3272−1	Pin−Cotter	6
5	69−7010	Lever−Valve LH	1
*	69−6990	Lever−Valve Mid.	1
*	69−7000	Lever−Valve RH	1
6	69−9140	Link−Valve Lever	3
7	32149−2	Nut−Keps	2
8	3234−14	Screw−HFH	6
9	69−9150	Shaft−Valve Lever	1
10	3272−6	Pin−Cotter	2
11	69−7810	Bracket−Valve	1
12	237−79	O−Ring	2
13	340−3	Fitting−Hydraulic Straight (Incl. Ref. #12 & 14)	2
14	237−22	O−Ring	9
15	340−86	Fitting−Hydraulic Tee (Incl. Ref. #14 & 24)	2
16	69−5860	Tube−Hydraulic	1
17	69−5720	Tube−Hydraulic	1
18	69−5700	Tube−Hydraulic	1
19	69−5740	Tube−Hydraulic	1
20	69−5680	Tube−Hydraulic	1
21	69−5890	Tube−Hydraulic	1
22	69−5870	Tube−Hydraulic	1
23	340−2	Fitting−Hydraulic Straight (Incl. Ref. #14 & 24)	3
24	237−42	O−Ring	5
25	3254−6	Washer−Lock	1
26	95−5907	Asm−Counterbalance Manifold	1

* Not Illustrated




T−0379−1

LIFT VALVE ASM NO. 69−1780

Ref. No.	Part No.	Description	No. Used
1	58−6780	Asm−Plug (Incl. Ref. #5)	3
2	60−6450	Disc	A/R
3	58−6760	Spring	3
4	58−6770	Plunger−Detent	3
5	58−6790	O−Ring	3
6	58−6710	Asm−Plug (Incl. Ref. #7)	1
7	58−6720	O−Ring	1
†8		Body	1
9	60−5720	O−Ring	6
10	58−6370	Washer−Back−Up	6
11	58−6350	Asm−Plug (Incl. Ref. #9−10)	3
12	58−6450	O−Ring	6
†13		Spool	3
14		Nut−Lock	1
15		Washer	1
16	69−1830	Asm−Plug (Incl. Ref. #14, 15 & 17)	1
17	58−6750	O−Ring	1
18	58−6470	Washer	A/R
19	58−6480	Washer	A/R

Ref. No.	Part No.	Description	No. Used
20	58−6490	Washer	A/R
21	69−1820	Spring−Black	1
22	58−6440	Poppet	1
†23		Seat	1
24	58−6320	Wiper−Seal	3
25	58−6400	Bushing	3
26	58−6700	Washer	3
27	58−6730	Spring	3
28	58−6310	Spacer	3
29	58−6460	Ring−Retaining	3
30	58−6420	Asm−Cap	3
31	69−1840	Plunger	1
32	69−1800	Asm−Plug (Incl. Ref. #9−10)	3
33	69−1810	Spring	3
34	58−6290	Asm−Poppet	3
35	58−6330	Asm−Seat (Incl. Ref. #36)	3
36	58−6340	O−Ring	3
37	69−1790	Plunger	2
*	60−3780	Kit−Seal (Incl. Ref. #5, 7, 9, 10, 12, 17, 24, 29, 34, & 36)	1

* Not Illustrated
† Not Serviceable Separately




T−0356−2

COUNTERBALANCE MANIFOLD ASM

Ref. No.	Part No.	Description	No. Used
1	95−5630	Valve−Hydraulic Cartridge (Incl. Ref. #2)	1
2	95−5645	Kit−Seal	2
3	353−990	Plug−Hose (Incl. Ref. #4)	2
4	237−78	O−Ring	2
5	69−5890	Tube−Hydraulic	1
6	237−21	O−Ring	2
7	340−92	Fitting−Hydraulic Straight (Incl. Ref. #6 & 8)	2
8	237−78	O−Ring	3
9	69−5680	Tube−Hydraulic	1
10	95−5634	Valve−Hydraulic Cartridge (Incl. Ref. #11)	1
11	95−5641	Kit−Seal	1
12	353−991	Plug−Hole (Incl. Ref. #13)	8
13	237−156	O−Ring	8
14	69−4070	Manifold−Counter Balance	1
15	95−5632	Valve−Hydraulic Cartridge (Incl. Ref. #2)	1
16	353−566	Tee−Hydraulic (Incl. Ref. #8)	1
17	92−4967	Tube−Hydraulic	1
18	69−5850	Tube−Hydraulic	1
19	69−5910	Tube−Hydraulic	1
20	69−5710	Tube−Hydraulic	1

Ref. No.	Part No.	Description	No. Used
21	237−22	O−Ring	7
22	237−30	O−Ring	2
23	340−4	Fitting−Hydraulic Straight (Incl. Ref. #22 & 24)	2
24	237−79	O−Ring	2
25	93−7192	Hose−Hydraulic Diagnostic	1
26	340−2	Fitting−Hydraulic Straight (Incl. Ref. #21 & 27)	5
27	237−42	O−Ring	6
28	69−5870	Tube−Hydraulic	1
29	95−5642	Kit−Seal	3
30	95−5633	Valve−Hydraulic Cartridge (Incl. Ref. #29)	2
31	69−5820	Tube−Hydraulic	1
32	69−5830	Tube−Hydraulic	1
33	69−5730	Tube−Hydraulic	1
34	69−5860	Tube−Hydraulic	1
35	340−94	Tee−Hydraulic (Incl. Ref. #21 & 27)	1
36	95−5631	Valve−Hydraulic Cartridge (Incl. Ref. #29)	1
37	69−5920	Tube−Hydraulic	1
*	95−5907	Counterbalance Manifold (Incl. Ref. #1−4, 10−15, 29, 30 & 36)	1
38	69−4140	Plug−Orifice .120mm	1
39	69−4130	Plug−Orifice .047mm	2


* Not Illustrated



FUEL TANK ASM

Ref. No.	Part No.	Description	No. Used
1	62−7650	Gasket−Level Sensing Unit	1
2	70−6990	Asm−Level Sensing Unit	1
3	32122−24	Screw−HH	5
4	5−3637	Spacer−Terminal	1
5	3253−21	Washer−Lock	1
6	323−39	Screw−HH	1
7	3256−5	Washer−Flat	2
8	3234−13	Screw−HWH	1
9	2412−89	Clamp−R	1
10	93−3102	Cap−Fuel	1
11	94−2865	Tank−Fuel	1
12	95−0822	Decal−Warning	1

Ref. No.	Part No.	Description	No. Used
15	2412−108	Clamp−Hose	3
16	353−536	Fitting−Fuel 90° Elbow	2
17	72−9550	Stud−Fuel Tank	1
18	68−7572	Strip−Sealing	1
19	3296−39	Nut−Lock	1
20	3253−15	Washer−Lock	5
21	46−6560	Bushing	1
22	94−3310	Tube−Vent	1
23	94−3311	Hose−Fuel	1
24	2412−138	Clamp−R	1
25	37−9560	Hose−Fuel	2




T−0354−3

HYDRAULIC TANK ASM

Ref. No.	Part No.	Description	No. Used
1	237−81	O−Ring	1
2	69−1170	Gauge−Sight (Incl. Ref. #1)	1
3	85−6260	Level Sensing Unit	1
4	94−1893	Tank−Hydraulic	1
5	323−10	Screw−HH	4
6	3253−21	Washer−Lock	4
7	5−3177	Washer−Flat	4
8	69−1610	Adapter−Suction Hose	1
9	3253−3	Washer−Lock	10
10	321−5	Screw−HH	10
11	2412−34	Clamp−Hose	1
12	69−5640	Hose−Suction	1
13	2412−42	Clamp−Hose	4
14	94−1892	Hose−Auxiliary Suction	1
15	2412−3	Clamp−Hose	1
16	237−157	O−Ring	1
17	69−1650	Screen−Suction	1
19	237−80	O−Ring	1
20	69−5800	Tube−Hydraulic	1

Ref. No.	Part No.	Description	No. Used
21	237−22	O−Ring	2
22	340−3	Fitting−Hydraulic Straight (Incl. Ref. #21 & 23)	1
23	237−79	O−Ring	1
24	68−7571	Strip−Sealing	1
26	321−2	Screw−HH	1
27	75−0540	Tether−Cap, Reservoir	1
31	71−2680	Hose−Vent	1
32	2412−108	Clamp−Hose	1
33	69−4280	Tube−Hydraulic Vent	1
34	61−2790	Filler−Screen	1
35	2410−73	Pin−Tether	1
36	93−3103	Cap−Hydraulic (Incl. Ref. #27 & 35)	1
37	92−4970	Hose−Hydraulic	1
38	340−22	Fitting−Tee (Incl. Ref. #19 & 41)	1
39	98−7067	Fitting−Reducer	1
40	340−150	Cap−Hydraulic	1
41	237−65	O−Ring	2

3321−612




HYDRAULIC FILTER ASM

Ref. No.	Part No.	Description	No. Used
1	237−80	O−Ring	1
2	340−17	Fitting−Hydraulic 90° (Incl. Ref. #1 & 3)	1
3	237−65	O−Ring	1
4	92−4807	Tube−Hydraulic	1
5	237−22	O−Ring	3
7	237−58	O−Ring	1
9	2412−92	Clamp−Hose	4
10	69−5410	Manifold−Return (Incl. Ref. #5, 13 & 24)	1
11	69−6000	Tube−Hydraulic (Incl. Ref. #5)	1
12	69−5990	Tube−Hydraulic (Incl. Ref. #5)	1
13	237−30	O−Ring	2
14	69−5460	Hose−Hydraulic	1
15	39−7593	Temperature Sending Unit	1
16	3253−2	Washer−Lock	1
17	3219−14	Nut−Hex.	1
18	69−5650	Hose−Hydraulic	1
19	69−1700	Asm−Hydraulic Filter (Incl. Ref. #20, 21 & 25−27)	1
20	237−155	O−Ring	1
21	69−1720	Element−Filter (Incl. Ref. #20)	1

Ref. No.	Part No.	Description	No. Used
22	340−65	O−Ring	1
23	340−79	Fitting−Hydraulic 90° (Incl. Ref. #22 & 24)	1
24	237−101	O−Ring	2
25	69−1710	Indicator−Filter (Incl. Ref. # 26 & 27)	1
†26		O−Ring	1
†27		O−Ring	1
28	323−4	Screw−HH	3
29	3253−21	Washer−Lock	3
30	69−5440	Hose−Hydraulic	1
31	69−8440	Hose−Hydraulic	1
32	69−5950	Tube−Hydraulic	1
34	74−2660	Hose−Hydraulic Return	1
35	92−2352	Hose−Hydraulic	1
36	92−2351	Fitting−Tank Return (Incl. Ref. #7 & 37)	1
37	340−136	O−Ring	1
39	2412−129	Clamp−Hose	1
40	92−1742	Tube−Hydraulic	1
41	32152−1	Nut−Lock	3
42	56−7978	Clamp Half−Hydraulic Line	6
43	69−9761	Plate−Cover	3
44	322−12	Screw−HH	3

† Not Serviceable Separately




T−0349−3

HYDRAULIC PUMP INSTALLATION ASM

Ref. No.	Part No.	Description	No. Used
1	98−0655	Asm−Hydraulic Hose	2
4	323−7	Screw−HH	8
5	3253−21	Washer−Lock	8
6	353−992	Flange−Fitting	4
7	340−135	O−Ring	2
8	69−2050	Asm−Hydraulic Pump	1
9	237−116	O−Ring	1
10	354−42	Flange−Half	2
11	2412−42	Clamp−Hose	8
12	69−5640	Hose−Hydraulic	2
13	99−4969	Tube−Suction	1
†14		Bolt−U	2

Ref. No.	Part No.	Description	No. Used
15	20−4840	Clamp−Tube (Incl. Ref. #14 & 19)	2
16	32152−2	Nut−Lock	4
17	69−9220	Support−Tube Clamp	2
18	323−6	Screw−HH	4
19	32128−25	Nut−Lock	4
20	325−6	Screw−HH	4
21	3253−7	Washer−Lock	8
22	3213−2	Screw−HH	4
23	74−2270	Fitting−Suction	1
24	99−4968	Tube−Suction	1

† Not Serviceable Separately




T–0382–1

DOUBLE GEAR PUMP NO. 69–2050

Ref. No.	Part No.	Description	No. Used
1	69–2110	Coupling	1
2	69–2170	Asm–Adapter Section	1
3	59–7990	Seal–Gland	4
4	59–8470	Retainer–Seal	4
5	69–2070	Plate–Flex	4
6	69–2200	O–Ring	2
7	69–2080	Asm–Center Section	2
8	69–2090	Gear/Shaft–Rear Drive	1
9	59–8600	Gear–Driven	2
10	69–2120	O–Ring	2
11	69–2100	Asm–Rear Cover	1
12	59–7590	Washer–Lock	16
13	69–2150	Screw–HH	4

Ref. No.	Part No.	Description	No. Used
14	69–2140	Screw–HH	4
15	69–2210	O–Ring	1
16	69–2160	Asm–Port Section	1
17	59–8500	Gear/Shaft–Front Drive	1
18	69–2060	Asm–Shaft End Cover	1
19	69–2130	Plug	1
20	59–8590	Seal–Shaft	1
21	59–8580	Ring–Retaining	1
22	59–8570	Seal–Shaft	1
23	59–7970	Stud–Threaded	8
24	59–7580	Nut–Hex.	8
*	59–8610	Kit–Repair (Incl. Ref. #3, 4, 20 & 22)	1


* Not Illustrated



FRAME ASM

Ref. No.	Part No.	Description	No. Used
1	85−6190	Link−Deck Tilt	1
2	3290−495	Pin−Lynch	2
3	340−126	Nut−Bulkhead	2
4	340−70	Nut−Bulkhead	6
5	69−8940	Washer	12
6	240−4	Grommet	6
7	340−71	Fitting−Hydraulic Bulkhead (Incl. Ref. #32)	1
8	237−30	O−Ring	3
9	92−4967	Tube−Hydraulic (Incl. Ref. #8)	1
10	3234−28	Screw−HFH	2
11	93−7422	Hose−Hydraulic	1
12	353−375	Fitting−Hydraulic 90° (Incl. Ref. #13)	2
13	237−78	O−Ring	5
14	237−58	O−Ring	4
15	3274−86	Screw−HSH	1
16	69−5470	Hose−Hydraulic	1
17	69−5480	Hose−Hydraulic	1
18	237−65	O−Ring	6
19	93−7177	Asm−Tube, Traction LH	1
20	83−8350	Fitting−Traction, LH (Incl. Ref. #14 & 18)	1
21	93−7178	Asm−Tube, Traction RH	1

Ref. No.	Part No.	Description	No. Used
22	69−6200	Tube−Hydraulic (Incl. Ref. #18)	1
23	69−6190	Tube−Hydraulic (Incl. Ref. #18	1
24	71−2450	Cover−Access	1
25	3234−14	Screw−HFH	4
26	69−8930	Washer	4
27	69−8960	Spacer	2
28	240−5	Grommet	2
29	340−127	Nut−Bulkhead	2
30	85−6150	Tube−Hydraulic	1
31	69−8970	Spacer	6
32	237−22	O−Ring	7
33	69−6050	Tube−Hydraulic (Incl. Ref. #32)	1
34	69−6040	Tube−Hydraulic (Incl. Ref. #32)	1
35	69−6030	Tube−Hydraulic (Incl. Ref. #32)	1
36	32152−1	Nut−Lock	1
37	69−5790	Tube−Hydraulic (Incl. Ref. #8)	1
38	69−6060	Tube−Hydraulic (Incl. Ref. #32)	1
39	93−7426	Tube−Hydraulic (Incl. Ref. #32)	1




FRAME ASM (Continued)

Ref. No.	Part No.	Description	No. Used
40	32108−103	Screw−Machine Flat Hd.	4
41	69−9300	Cushion−Rubber	2
42	32152−1	Nut−Lock	4
43	321−9	Screw−HH	2
44	56−7973	Clamp Half−Hydraulic Line	4
45	32152−4	Nut−Lock	2
46	256−247	Bushing−Flange	2
47	240−7	Grommet	4
48	302−5	Fitting−Grease	1
49	69−0100	Asm−Frame (Incl. Ref. #46 & 48)	1
50	69−6100	Tube−Hydraulic Pressure (Incl. Ref. #14)	1
*	69−5810	Tube−Hydraulic Return (Incl. Ref. #14)	1
51	69−8910	Washer	4
52	69−8900	Spacer	2
53	3220−4	Nut	1
54	92−3048	Kit−Solenoid Coil	3
55	32149−2	Nut−Keps	2
56	340−92	Fitting−Hydraulic (Incl. Ref. #13 & 58)	1
57	69−5950	Tube−Hydraulic	1
58	237−21	O−Ring	3
59	340−125	Fitting−Hydraulic (Incl. Ref. #13 & 58)	1

Ref. No.	Part No.	Description	No. Used
†60		Body−Valve	1
61	93−9988	Fitting−Hydraulic (Incl. Ref. #13)	1
62	95−5638	Valve−Solenoid (Incl. Ref. #53)	1
63	69−9470	Cover−Access	1
64	71−0430	Cover−Abrasive	1
65	321−11	Screw−HH	2
66	71−0420	Floor−Abrasive	1
67	3256−56	Washer−Flat	2
68	3256−23	Washer−Flat	2
69	93−7424	Hose−Diagnostic	1
70	93−7193	Hose−Diagnostic	1
71	72−4080	Decal−Danger	2
72	2410−10	Plug−Button	1
73	83−8360	Fitting−Traction, RH	1
74	83−8370	Plate−Clamp	1
77	93−7038	Switch	1
80	92−4970	Hose−Hydraulic	1
81	93−7192	Hose−Diagnostic	1
82	83−4330	Asm−Tube, Traction LH	1
83	83−4340	Asm−Tube, Traction RH	1
*	95−5917	Valve Seal Kit	1
*	95−5916	Asm−Solenoid Valve (Incl. Ref. #53, 54, 60, 62 & Valve Seal Kit #92−3049)	1

* Not Illustrated
†‡ Not Serviceable Separately




T−3077

HYDRAULIC SYSTEM DIAGNOSTIC PANEL ASM

Ref. No.	Part No.	Description	No. Used
1	3269−25	Rivet−Pop	4
2	354−79	Cap−Fitting	5
3	353−997	Fitting−Hydraulic Bulkhead (Incl. Ref. #12)	5
4	99−1900	Panel−Diagnostic	1

Ref. No.	Part No.	Description	No. Used
5	93−7422	Hose−Hyd. Diagnostic	1
6	69−5910	Tube−Hyd. Diagnostic	1
7	93−7193	Hose−Hyd. Diagnostic	1
8	69−5920	Tube−Diagnostic	1
9	3220−4	Nut−Bulkhead	5




HYDRAULIC LINE CLAMPS ASM


Ref. No.	Part No.	Description	No. Used
1	69−9330	Cover	1
2	3234−14	Screw−HFH	6
3	340−128	Nut−Bulkhead	2
4	69−8920	Washer	4
5	69−8950	Spacer	2
6	240−2	Grommet	2
7	237−164	Grommet	1
8	95−0821	Decal−Hydraulic Oil	1
9	322−12	Screw−HH	2
10	69−9760	Plate−Cover	3
11	3256−22	Washer−Flat	2
12	32152−4	Nut−Lock	6
13	32152−1	Nut−Lock	8
14	69−9761	Plate−Cover	5
15	99−4964	Tube−Hydraulic	1
16	99−4966	Tube−Hydraulic	1
17	56−7974	Clamp Half−Hydraulic Line	2
18	321−15	Screw−HH	2
19	56−7973	Clamp Half−Hydraulic Line	20
20	56−7972	Clamp Half−Hydraulic Line	4
21	3256−56	Washer−Flat	8
22	321−9	Screw−HH	6
23	322−21	Screw−HH	3

Ref. No.	Part No.	Description	No. Used
24	3256−23	Washer−Flat	1
25	56−7978	Clamp Half−Hydraulic Line	12
26	56−7971	Clamp Half−Hydraulic Line	2
27	93−7179	Tube−Hydraulic (Incl. Ref. #29)	1
28	69−5800	Tube−Hydraulic (Incl. Ref. #29)	1
29	237−21	O−Ring	4
30	69−8980	Washer	8
31	240−6	Grommet	4
32	240−7	Grommet	1
33	69−8990	Spacer	4
34	340−78	Nut−Bulkhead	4
35	69−6080	Tube−Hydraulic (Incl. Ref. #29)	1
36	69−6070	Tube−Hydraulic (Incl. Ref. #29)	1
37	32151−1	Nut−Lock	4
38	71−2560	Support−Bulkhead	2
39	69−0940	Decal−Caution	1
40	95−5616	Spacer	4
42	322−38	Screw−HH	2
43	3256−23	Washer−Flat	4

HYDRAULIC SCHEMATIC



T−1656−2




FRONT WHEEL ASM

Ref. No.	Part No.	Description	No. Used
1	237−42	O−Ring	2
2	69−5940	Tube−Hydraulic LH	1
*	69−5930	Tube−Hydraulic RH	1
3	237−21	O−Ring	2
4	340−82	Fitting−Hydraulic Elbow (Incl. Ref. #1 & 3)	2
5	237−146	O−Ring	4
6	340−91	Fitting−Hydraulic Straight (Incl. Ref. #5 & 7)	2
7	237−58	O−Ring	7
8	83−4330	Tube−Hydraulic LH	1
*	83−4340	Tube−Hydraulic RH	1
9	237−81	O−Ring	4
10	340−9	Fitting−Hydraulic St. LH (Incl. Ref. #7 & 9)	1
*	340−148	Fitting−Hydraulic Tee RH (Incl. Ref. #7 & 9)	1
12	92−1742	Tube−Hydraulic LH	1
*	92−4807	Tube−Hyd. RH Run	1
*	85−6150	Tube−Hyd. RH Branch	1
13	71−4010	Housing−Brake	2
14	3272−6	Pin−Cotter	2
15	71−3880	Clevis−Brake Cable	2
16	283−2	Pin−Clevis	2
17	3253−21	Washer−Lock	14
18	323−6	Screw−HH	14
19	71−0470	Disc−Middle	4
20	71−3990	Cap−Brake Housing	2

Ref. No.	Part No.	Description	No. Used
21	237−158	O−Ring	4
22	253−156	Seal−Oil	2
23	251−340	Bearing−Ball	2
24	32120−22	Ring−Retaining Internal	2
25	302−39	Vent	2
26	3253−8	Washer−Lock	16
27	327−22	Screw−HH	16
28	69−9800	Tire	2
*	58−5620	Tube−Inner	2
*	231−140	Tire−(Optional)	2
29	71−2470	Rim	2
30	3253−7	Washer−Lock	22
31	3219−5	Nut−Hex.	18
32	69−1730	Asm−Planetary Gear Drive	2
33	32120−84	Ring−Retaining External	2
34	71−3810	Coupling−Hydraulic Motor	2
35	69−9970	Stud	4
36	69−9960	Link	4
37	69−9950	Spring−Extension	4
38	69−9990	Disc−Actuating	4
39	69−9980	Ball	6
40	69−9940	Nut−Jam	4
41	253−157	Ring−Cup	6
42	92−1741	Tube−Hydraulic	1
43	340−142	Fitting−Hydraulic Elbow (Incl. Ref. #9 & 11)	2
44	69−3050	Motor−Hydraulic Wheel	2
45	3256−26	Washer−Flat	4


* Not Illustrated



FRONT WHEEL ASM (Continued)

Ref. No.	Part No.	Description	No. Used
46	325−7	Screw−HH	4
47	72−4070	Decal−Danger	2
48	93−7176	Fitting−45° ORFS	2
49	237−65	O−Ring	2
50	93−7177	Tube−Hydraulic, LH	1
*	93−7178	Tube−Hydraulic, RH	1

* Not Illustrated




WHEEL MOTOR NO. 69–3050

Ref. No.	Part No.	Description	No. Used
1	69–3150	Screw–HH	10
2	69–3070	Washer–Plain	10
†3		Ring–Retaining	1
†4		Washer	1
†5		Spring–Compression	1
†6		Washer	1
†7		Block–Cylinder	1
†8		Retainer	1
†9		Pin–Slipper Hold Down	3
†10		Guide–Retainer	1
†11		Guide–Slipper	1
†12		Asm–Piston	7
13	69–3500	Bearing–Sleeve	1
14	69–3510	Pin	1
15	76–4610	Cover–Front	1
16	76–4590	Screw	6
17	69–3200	Ring–Retaining	2
18	69–3190	Seal–Lip	1
19	69–3170	Ring–Retaining	2
20	69–3210	Bearing–Ball	1
21	69–3960	Screw	1
22	69–3970	Bearing–Journal	2
23	69–3520	Pin–Spring	2
24	69–3980	Swashplate–Variable	1

Ref. No.	Part No.	Description	No. Used
25	69–3950	Shaft–Motor	1
26	76–4600	Gasket–Front Cover	1
27	69–3910	Kit–Cylinder Block (Incl. Ref. #3–12	1
28	69–3990	Plate–Motor Valve	1
29	69–3940	Plug	1
30	69–3450	Pin	1
31	69–3370	Bearing–Needle	1
32	69–3230	Pin–Spring	1
33	69–3130	Plug–Hole	1
†36		Housing	1
37	69–4020	Piston–Servo	1
38	69–3560	O–Ring	2
39	69–3570	Ring–Piston	2
40	69–4030	Spring–Servo	1
41	69–3710	Gasket–Servo Cover	2
42	69–4040	Stop–Servo Piston	1
43	69–3720	Cover–Servo	2
44	95–4400	Washer–Backup	1
*	69–3920	Kit–Piston Ring & O–Ring (Incl. Ref. #38 & 39)	1

* Not Illustrated
† Not Serviceable Separately



T–0140–2


PLANETARY GEAR ASM NO. 69–1730

Ref. No.	Part No.	Description	No. Used
2	60–3810	Shaft–Input	1
3	69–1740	Spindle	1
4	60–3830	Seal–Oil	1
5	60–3840	Cone–Bearing	1
6	60–3850	Cup–Bearing	2
7	60–3860	Bolt–Wheel	9
8	60–3870	Hub	1
9	60–3880	Cone–Bearing	1
10	60–3890	Bolt–HH	6
11	60–3910	Washer–Flat	6
12	60–3980	Washer–Thrust	1
13	60–3970	Gear–Primary Sun	1
14	60–4070	Bolt–HH	2
15	60–3960	Asm–Primary Carrier	1

Ref. No.	Part No.	Description	No. Used
16	60–4040	Plug–Pipe	1
17	60–4030	Bolt–HH	8
18	60–4060	Cover–Disengage	1
19	60–4050	Cover–Large	1
20	60–4000	Asm–Secondary Carrier	1
21	60–4020	O–Ring	1
22	60–4010	Plunger–Disengage	1
23	60–3990	Washer–Thrust	1
24	60–3900	Gear–Ring	1
25	60–3930	Ring–Retaining	2
26	60–3940	Washer	2
27	60–3950	Spring–Disengage	1
†28	62–6450	Kit–Retaining Ring	1
*	62–6460	Sealant–RTV (Tube)	1

* Not Illustrated

† Includes 7 different thickness retaining rings for service adjustment of bearings.



T−1277−1


WHEEL BRAKE ASM

Ref. No.	Part No.	Description	No. Used
2	32151−100	Ring−Retaining	2
3	69−8910	Washer	2
4	82−7850	Spring−Compression	2
5	354−104	Ring−Backup	2
6	237−175	O−Ring	2
7	82−7840	Piston−Brake	2
8	21−2070	Yoke−End	2
9	237−174	O−Ring	2
10	354−105	Ring−Backup	2
11	82−7830	Screw−Bleed, Brake	2
12	92−8003	Housing−Actuator, RH	1
*	92−8004	Housing−Actuator, LH	1
13	82−7820	Seat−Brake, Tube	2
14	71−3870	Gasket	2
15	71−3850	Cover−Housing	2
16	3253−3	Washer−Lock	8
17	321−2	Screw−HH	8
18	3274−7	Screw−HSH	8
19	3253−21	Washer−Lock	8

Ref. No.	Part No.	Description	No. Used
20	32128−25	Nut−HHF	2
21	71−3830	Bellcrank−Brake	2
22	3272−6	Pin−Cotter	2
23	71−3880	Clevis−Brake Cable	2
24	283−2	Pin−Clevis	2
25	71−3900	Gasket	2
26	3272−10	Pin−Cotter	2
27	3256−24	Washer−Flat	4
28	71−3860	Clevis	2
29	3296−3	Nut−Lock	2
30	69−0030	Spring−Compression	2
31	283−15	Pin−Clevis	2
32	12−8900	Bolt−Shoulder	2
33	93−7417	Gasket	2
34	71−3910	Collar	2
35	3296−59	Nut−Lock	2
36	93−7418	Cap−Actuator	2
37	321−6	Screw−HH	8

* Not Illustrated

3321–612




T–0350–1

VARIABLE DISPLACEMENT PUMP INSTALLATION

Ref. No.	Part No.	Description	No. Used
1	93–9322	Variable Displacement Pump	1
2	32128–21	Nut–HHF	2
3	93–7189	Yoke–Pump End	1
4	98–0836	Tube–Slip Yoke	1
5	302–2	Fitting–Grease	1
6	93–7188	Shaft –Slip Yoke	1
7	93–7190	Kit–Universal Joint	2
8	98–0835	Yoke–Engine End	1
9	3253–6	Washer–Lock	6
10	99–6058	Screw–HH	6
11	3274–20	Screw–HSH	2
12	325–7	Screw–HH	2
13	3253–7	Washer–Lock	2
14	3217–9	Nut–Hex.	2
15	237–81	O–Ring	1
16	340–131	Fitting–Hydraulic Elbow (Incl. Ref. #15 & 17)	1
17	237–30	O–Ring	2
18	69–5460	Hose–Hydraulic	1
19	237–146	O–Ring	3
20	340–15	Fitting–Hydraulic Elbow (Incl. Ref. #19 & 21)	3
21	237–58	O–Ring	3
22	69–5650	Hose–Hydraulic	1
23	237–42	O–Ring	1
25	237–22	O–Ring	1
26	69–9020	Nut–Special	1

Ref. No.	Part No.	Description	No. Used
27	32152–4	Nut–Lock	2
28	69–9480	Bracket–Neutral Device	1
29	3219–2	Nut–Hex.	1
30	32144–1	Screw–HH	2
31	69–9040	Cam–Neutral Device	1
32	3253–21	Washer–Lock	3
33	3231–30	Bolt–CARR	1
34	3217–7	Nut–Hex.	1
35	93–9337	Bracket–Switch	1
36	3234–13	Screw–HFH	4
37	32127–11	Nut–Flexlok	2
38	29–6170	Asm–Leaf Spring	1
39	322–17	Screw–HH	1
40	3210–7	Screw–HH	1
41	251–307	Bearing–Neutral Detent	1
42	321–4	Screw–HH	2
43	29–6150	Spring–Leaf	1
44	32153–3	Nut–Lock	1
45	69–9050	Bar–Neutral Device	1
46	3253–3	Washer–Lock	2
47	321–10	Screw–HH	2
48	340–134	Fitting–Hydraulic Elbow (Incl. Ref. #23)	1
49	41–8760	Gasket–Pump	1
50	93–7424	Hose–Hydraulic	1
51	323–7	Screw–HH	2
52	69–2220	Pump/Valve	1




VARIABLE DISPLACEMENT PUMP INSTALLATION (Cont.)

Ref. No.	Part No.	Description	No. Used
53	327−80	O−Ring	2
54	340−130	Fitting−Hydraulic Elbow (Incl. Ref. #25 & 53)	1
55	340−105	Fitting−Hydraulic Elbow (Incl. Ref. #17 & 53)	1
56	69−5450	Hose−Hydraulic	1
57	69−5470	Hose−Hydraulic	1

Ref. No.	Part No.	Description	No. Used
58	69−5440	Hose−Hydraulic	1
59	69−5480	Hose−Hydraulic	1
60	51−3150	Shim−Spring	A/R
61	93−7037	Switch	1
*	98−0819	Asm−Pump Drive Shaft (Incl. Ref. #3−8)	1


* Not Illustrated



GEAR PUMP & FLOW DIVIDER NO. 69–2220

Ref. No.	Part No.	Description	No. Used
1	69–2410	Plug (Incl. Ref. #2)	2
2	69–2420	O–Ring	2
3	69–2450	Piston	1
4	69–2440	Orifice	1
5	69–2430	Spring–Compression	1
6	69–2460	Cap	1
7	69–2470	Gasket–Cap	1
8	69–2480	Screw–Set	1
9	69–2490	Spring–Compression	1
10	69–2500	Poppet	1
11	69–2510	Seat	1
12	69–2530	O–Ring	1
13	69–2540	Asm–Cover (Incl. Ref. #20)	1
14	69–2340	Pin–Dowel	2
15	69–2280	Shaft/Gear–Idler	1
16	69–2320	Plate–Wear	1
17	69–2260	Seal–Load	1
18	69–2270	Seal–Pre–Load	1
19	69–2350	Ring–Sealing	1
20	69–2250	Bearing–Sleeve	4
21	69–2330	Asm–Body (Incl. Ref. #20)	1
22	69–2370	Washer	4
23	69–2360	Screw	4
24	69–2380	Screw	4
25	69–2390	Washer	4
26	69–2300	Ring–Retaining	1
27	69–2310	Seal–Shaft	1
28	69–2290	Shaft/Gear–Drive	1
29	69–2400	O–Ring	1
30	69–2230	Asm–Flow Divider (Incl. Ref. #1–11 & 31)	1
31	69–2520	Plug–Pipe	1
32	69–2240	Screw	4
*	69–2550	Kit–Repair, Pump (Incl. Ref. #16–19, 22 & 25–27)	1
*	69–2560	Kit–Repair, Pump & Divider Incl. Ref. #2, 7, 9–10, 12, 16–19, 22, 25–27 & 29)	1

* Not Illustrated




T–0373–3

VARIABLE DISPLACEMENT PUMP NO. 93–9322

Ref. No.	Part No.	Description	No. Used
1	69–3620	Cover–Servo Adjustment	1
2	69–3630	Nut Special	1
3	69–3640	Cover–Servo	1
4	69–3710	Gasket–Servo	2
5	69–3610	Nut–Jam	1
6	69–3600	Nut–Hex.	1
7	69–3590	Ring–Retaining	1
8	69–3580	Guide–Spring	1
9	69–3130	Plug (Incl. Ref. #10)	1
†10		O–Ring	1
†11		Housing–Pump	1
12	69–3230	Pin–Spring	1
13	69–3370	Bearing–Needle	1
†14		Ring–Retaining	1
†15		Washer	1
†16		Spring–Compression	1
†17		Washer	1
†18		Block–Cylinder	1
†19		Retainer	1
†20		Pin–Slipper Hold Down	3
†21		Guide–Retainer	1
†22		Guide–Slipper	1
†23		Asm–Piston	7
24	69–3250	Swashplate–Variable	1
25	69–3240	Bearing–Journal	2
26	94–2878	Pin	2
27	76–4590	Screw	6

Ref. No.	Part No.	Description	No. Used
28	69–3220	Screw	1
29	69–3200	Ring–Retaining	2
30	69–3190	Seal–Lip	1
31	69–3170	Ring–Retaining	2
32	69–3210	Bearing–Ball	1
33	76–4610	Cover	1
34	69–3500	Sleeve–Bearing	1
35	69–3510	Pin	1
36	69–3470	Pin	1
37	69–3180	Shaft Pump	1
38	76–4600	Gasket–Cover	1
39	69–3910	Asm–Cylinder Block (Incl. Ref #14–23)	1
40	93–9320	Plate–Valve LH	1
41	69–3450	Pin	1
42	69–3820	Sleeve–Control Valve	1
43	28–3590	O–Ring	1
44	28–3580	Ring–Back Up	1
45	69–3880	Spring–Neutral Return	1
46	69–3830	Spool–Rotary Valve	1
47	25–2630	Ring Back Up	1
48	69–3890	Bracket–Neutral Return	1
49	69–3860	Screw–HFH	1
50	69–3870	Handle–Control Valve	1
51	69–3900	Washer	1
52	69–3840	O–Ring	1
53	69–3650	Piston–Servo	1

† Not Serviceable Separately




VARIABLE DISPLACEMENT PUMP NO. 93–9322 (Cont.)

Ref. No.	Part No.	Description	No. Used
54	69–3690	Bearing	2
55	69–3560	O–Ring	2
56	69–3570	Ring–Piston	2
57	69–3720	Cover Servo	1
58	69–3140	Bracket–Lifting	1
†59		O–Ring	4
60	69–3080	Plug (Incl. Ref. #59)	4
61	69–3150	Screw–HH	10
62	69–3070	Washer–Lock	10
63	25–2630	Ring–Back Up	1
64	237–22	O–Ring	1
65	69–3800	Valve	1
66	69–3810	Valve–By Pass	1
67	69–3780	Plug (Incl, Ref. #68)	1
68	237–80	O–Ring	1
69	69–3770	Shim	1
70	69–3790	Spring Compression	1
71	69–3760	Plug–Special (Incl. Ref. #77)	2
72	69–3740	Spring–Compression	2
73	94–9413	Screw	3
74	94–9412	Seal–Adapter	1
75	93–9321	Plug–Orifice	1

Ref. No.	Part No.	Description	No. Used
76	285–17	Plug–Pipe	2
77	69–3750	O–Ring	2
78	69–3730	Valve–Relief (Incl. Ref. #71, 72 & 77)	2
79	94–9414	Adapter–Suction	1
80	69–3460	Plug Expansion	1
81	69–3550	Pin	1
83	69–3400	Screw–HH	3
84	69–3430	Key–Woodruff	1
85	69–3410	Adapter–A Flange	1
86	69–3420	Ring–Temper Load	1
87	69–3440	O–Ring	1
88	69–3540	Cover–Gerotor	1
89	69–3390	Asm–Gerotor	1
90	69–3700	Guide–Spring	1
91	69–3660	Screw–Special	1
92	69–3680	Stop–Servo	1
93	69–3670	Spring–Compression	1
†94		O–Ring	1
95	69–3120	Plug (Incl, Ref. #94)	1
96	94–9415	Plug (Incl. Ref. #97)	1
†97		O–Ring	1
98	95–4400	Washer–Backup	1

† Not Serviceable Separately

3321−612




T−2813−1

COWL ASM

Ref. No.	Part No.	Description	No. Used
1	58−4250	Magnet	6
9	69−9650	Screen−Cowl	2
10	98−2365	Cowl−Radiator	1
12	3296−2	Nut−Lock	20
13	69−3030	Strike−Latch	8
14	3290−321	Screw−HWH	20
15	69−8690	Support−Grille	1
16	69−3020	Handle−Latch	2
18	69−9721	Strip−Sealing	3
19	75−9460	Bracket−Sealing LH	1
20	69−0040	Foam−Lower Grille	1

Ref. No.	Part No.	Description	No. Used
21	32144−11	Screw−HFH	8
22	75−9480	Bracket−Sealing Bottom	1
23	69−7150	Grille−Lower	1
24	32153−6	Nut Lock	2
25	75−9470	Bracket−Sealing RH	1
26	328−11	Screw−HH	2
27	69−7120	Grille−Upper	1
28	69−9720	Strip−Sealing	2
32	3269−15	Rivet−Pop	22
33	3269−6	Washer−Backup	22
35	69−9722	Trim−Sealing	1




T−0360−1

HOOD ASM

Ref. No.	Part No.	Description	No. Used
1	71−0270	Foam−Hood Side RH	1
2	71−0250	Foam−Hood Top	1
3	71−0260	Foam−Hood Side LH	1
4	92−1772	Asm−Hood (Incl. Ref.#1−4, 8, 15−17, 20, 26 & 29)	1
5	3290−321	Screw−HH	12
6	69−3010	Strap−Hold Down (Incl. Ref. #10)	4
7	3296−2	Nut−Lock	12
8	71−0060	Support−Foam	1
9	69−9520	Panel−Rear	1
†10		Latch−Hold−Down	4
11	3234−14	Screw−HH	6
12	69−1390	Panel−Side LH	1
*	69−1380	Panel−Side RH	1
13	3290−134	Screw−HH	4
14	71−0400	Foam−Side Panel	2

Ref. No.	Part No.	Description	No. Used
15	69−9723	Seal−Hood Bottom	2
16	32149−2	Nut−Keps	16
17	69−8230	Bracket−Trim LH	1
18	88−6770	Stud−Ball	2
19	88−6760	Spring−Gas	2
20	69−8250	Bracket−Trim R.H	1
21	69−8500	Shim−Hinge Bracket	6
22	3253−21	Washer−Lock	6
23	323−6	Screw−HH	4
24	3256−24	Washer−Flat	6
25	323−4	Screw−HH	2
26	69−0950	Decal−580D	2
27	66−6140	Decal−TORO	1
28	98−3026	Bracket−Hinge	2
29	69−9724	Seal−Hood Front	1
30	32149−7	Nut	4
31	32152−1	Nut	2

* Not Illustrated
† Not Serviceable Separately




T–2807–2

RADIATOR & OIL COOLER ASM

Ref. No.	Part No.	Description	No. Used
1	71–0350	Foam–Rad. Support RH	1
2	69–8590	Support–Radiator Upper	1
3	71–0360	Foam–Rad. Support Top	1
4	98–7320	Hose–Upper Radiator	1
5	66–3241	Cap–Radiator	1
6	2412–108	Clamp–Hose	2
7	23–2140	Hose–Radiator Vent	1
8	323–34	Screw–HH	7
9	98–7318	Shroud–Fan (Incl. Ref. #45 & 46)	1
10	95–6456	Hose–Lower Radiator	1
11	2412–92	Clamp–Hose	4
12	98–7311	Radiator	1
13	71–0210	Foam–Radiator Seal	1
14	304–46	Valve–Drain	1
15	98–7348	Foam–Seal	2
19	32128–20	Nut–HHF	5
20	69–3020	Latch	8
21	3253–2	Washer–Lock	16
22	3290–321	Screw–HH	16
23	46–3380	Bolt–Shoulder	2
24	69–7100	Support–Radiator Lower	1
25	3290–216	Washer–Bevel	4
26	32153–5	Nut–Lock	4
27	32152–2	Nut–Lock	7
28	340–65	O–Ring	3
29	69–5620	Hose–Hydraulic	1

Ref. No.	Part No.	Description	No. Used
30	69–8450	Hose–Hydraulic (Incl. Ref. #28)	1
31	69–5900	Tube–Hydraulic	1
32	69–1670	Cooler–Oil (Incl. Ref. #28)	1
33	32103–3	Nut–Wing	2
34	71–0370	Foam–Lower Rad. Support	2
35	3253–21	Washer–Lock	12
36	71–0340	Foam–Rad. Support LH	1
37	88–9450	Bracket–Hood Cylinder	2
38	2412–41	Clamp–R	2
39	322–5	Screw–HH	1
40	322–6	Screw–HH	4
41	323–7	Screw–HH	4
42	71–0380	Foam–Rad. Support Front	1
43	325–6	Screw–HH	4
44	71–0390	Foam–Rad. Support Rear	1
45	76–8750	Plate–Caution	2
46	3290–274	Rivet–Pop	4
47	3256–56	Washer–Flat	2
50	68–6150	Breather	1
51	354–95	Fitting	1
53	71–2680	Hose–Vent	1
54	32144–69	Screw–HWH	6
56	88–6770	Stud–Ball	2
57	32152–1	Nut–Lock	2




T−2835-3

ENGINE INSTALLATION ASM

Ref. No.	Part No.	Description	No. Used
1	95−6499	Asm−Engine	1
2	98−0826	Asm−Coupler	1
3	95−6481	Plate−Pump Adapter	1
4	98−0655	Asm−Hose	2
5	323−7	Screw−HH	8
6	3253−21	Washer−Lock	8
7	353−992	Flange−Split	4
8	69−2050	Pump−Gear, Double	1
9	354−42	Flange−Split, Half	2
10	2412−129	Clamp−Hose	12
11	69−5640	Hose−Suction	3
12	99−4969	Tube−Suction	1
13	20−4840	Clamp−Muffler	2
14	32152−2	Nut−Lock	4
15	323−6	Screw−HH	4
16	69−9220	Bracket−Suction Tube	2
17	3256−23	Washer−Flat	4
18	3253−4	Washer−Lock	4
19	3217−6	Nut−Hex.	4
20	325−6	Screw−HH	8
21	3253−7	Washer−Lock	12
22	3213−2	Screw−HH	4
23	33115−030	Screw−HH	18
24	3253−6	Washer−Lock	20
25	33115−025	Screw−HH	8
26	321−6	Screw−HH	2
27	95−6465	Asm−Mount, LH Rear	1
28	323−10	Screw−HH	8

Ref. No.	Part No.	Description	No. Used
29	32149−2	Nut−Lock	10
30	69−8490	Bracket−Throttle Cable	1
31	3253−3	Washer−Lock	2
32	33113−016	Screw−HH	2
33	32128−21	Nut−HFH	8
34	95−6489	Bracket−Throttle	1
35	321−4	Screw−HH	2
36	33116−050	Screw−HH	3
38	95−6470	Asm−Mount LH	1
39	32128−23	Nut−HHF	4
40	98−3023	Washer	4
41	95−6486	Spacer−Mount	8
42	98−0830	Retainer−Mount	4
43	98−3024	Mount−Engine	4
44	323−38	Screw−HH	4
45	325−9	Screw−HH	4
46	33116−030	Screw−HH	3
47	95−6467	Asm−Mount RH	1
48	95−6465	Asm−Mount Rear	1
49	282−28	Clevis−Adjustable	1
50	77−2990	Cable−Throttle	1
51	69−0090	Pin−Throttle	1
52	3272−1	Pin−Cotter	1
54	93−3526	Switch	1
55	67−4510	Gauge Unit	1
56	51−5070	Switch	1
57	69−1750	Asm−Fuel Filter	1
58	99−4968	Tube−Suction	1




T−2949

CYLINDER HEAD ASM

Ref. No.	Part No.	Description	No. Used
2	99−1812	Plug−Drain	1
3	99−1813	Gasket	1
4	99−1806	Bolt−Cylinder Head	17
5	99−1801	Cap−Sealing 20mm	12
6	99−1802	Cap−Sealing 25mm	7
7	99−1803	Guide−Valve	8
8	99−1811	Bolt−W/Washer	4
9	99−1808	Eye−Lifting, Rear	1
10	99−1809	Gasket−Head, Rear	1

Ref. No.	Part No.	Description	No. Used
11	99−1807	Gasket−Head, Cylinder	1
12	99−1804	Seat−Valve, Inlet	4
13	99−1805	Seat−Valve, Exhaust	4
14		Head−Cylinder	1
15		Plug	1
*	99−1800	Asm−Head, Cylinder (Incl. Ref. #2−3, 5−7 & 12−14)	1

* Not Illustrated




T−2950

VALVE MECHANISM ASM

Ref. No.	Part No.	Description	No. Used
1	99−1822	Ring−Snap	2
2		Bushing−Rocker	8
3		Rocker	8
4	93−3401	Screw−Rocker	8
5	51−5210	Nut−Jam	8
6	99−1824	Bolt−Rocker Bracket	4
7	99−1820	Spring−Rocker	3
8		Shaft−Rocker	1
9		Plug−Shaft, Rocker	2
10	99−1825	Bolt−W/Washer	4
11	51−5280	Cap	8
12	60−7420	Cotter−Valve	16
13	99−1816	Retainer−Upper	8
14	99−1817	Seal−Stem, Valve	8
15	51−5320	Spring−Valve	8
16	99−1815	Valve−Exhaust	4
17	99−1814	Valve−Inlet	4
18	99−1823	Bracket−Shaft, Rocker	4
*	99−1818	Asm−Rocker & Shaft (Incl. Ref. #1−9)	1
*	99−1819	Asm−Rocker (Incl. Ref. #2−5)	8
*	99−1821	Asm−Shaft, Rocker (Incl. Ref. #8−9)	1

* Not Illustrated




T−2951

ROCKER COVER & CAMSHAFT ASM

Ref. No.	Part No.	Description	No. Used
1	99−1827	Gasket−Rocker	1
2	99−1828	Bolt−W/Washer	5
3		Pipe	1
4		Cover−Rocker	1
5	42−7420	Cap−Filter, Oil	1
6	99−1833	Clip−Hose	1
7	99−1834	Hose−Breather	1
8	99−1835	Clip	1
9	99−1836	Bolt−W/Washer	1

Ref. No.	Part No.	Description	No. Used
10	99−1832	Rod−Push	8
11	99−1831	Tappet	8
12	99−1829	Camshaft	1
13	51−5470	Plate−Thrust	1
15	99−1830	Bolt−W/Washer	2
16	51−5460	Key−Woodruff	1
*	99−1826	Asm−Cover, Rocker (Incl. Ref. #3−4)	1

* Not Illustrated




T−2952

CRANKCASE ASM

Ref. No.	Part No.	Description	No. Used
1	93−3365	Pin−Dowel	2
2		Crankcase	1
3	99−1845	Plug−Taper	1
4	51−5600	Cap−Sealing	10
5	70−3370	Cap−Sealing	6
6	86−6240	Plug−Taper	5
7	56−0100	Plug−Taper	1
8		Cap−Bearing	4
9	99−1838	Bolt−Cap, Bearing	10
10	99−1842	Pin−Spring	6

Ref. No.	Part No.	Description	No. Used
11		Cap−Bearing	1
12	99−1840	Plug−Cam	1
13	70−3000	Pin−Dowel	2
14		Plug	3
15	99−1839	Valve−Check	4
16	99−1843	Bushing	1
17	99−1844	Shaft−Idler	1
18	99−1841	Pin−Dowel	1
*	99−1837	Asm−Crankcase (Incl. Ref. #1−18)	1

* Not Illustrated




T−2953

FLYWHEEL HOUSING & MAIN METAL ASM

Ref. No.	Part No.	Description	No. Used
1	51−5970	Nut−Lock	2
2	51−6390	Washer−Spring	2
3	99−1858	Stud	2
4	99−1813	Gasket	1
5	99−1812	Plug−Drain	1
6	60−7430	Seal−Oil	1
7	99−1854	Housing−Flywheel	1
8	42−7290	Gasket	1
9	67−2520	Plug−Drain	1
10	99−1856	Bolt−W/Washer	10
10	99−1857	Bolt−W/Washer	2
11	99−1855	Gasket−Rear	1
12	99−1850	Plate−Thrust Std.	3

Ref. No.	Part No.	Description	No. Used
12	99−1851	Plate−Thrust O.S. 0.15	1
12	99−1852	Plate−Thrust O.S. 0.30	1
13	99−1853	Seal−Side	2
14		Set−Metal, Main	5
15		Set−Metal, Main	5
*	99−1846	Set−Metal, Main Std. (Incl. Ref. #14−15)	1
*	99−1847	Set−Metal, Main U.S. 0.25 (Incl. Ref. #14−15)	1
*	99−1848	Set−Metal, Main U.S. 0.50 (Incl. Ref. #14−15)	1
*	99−1849	Set−Metal, Main U.S. 0.75 (Incl. Ref. #14−145	1

* Not Illustrated




T−2954

TIMING GEAR CASE & TIMING GEAR ASM

Ref. No.	Part No.	Description	No. Used
1	99−1864	Bolt−W/Washer	13
2	99−1861	Case−Gear, Timing	1
3	99−1862	Gasket−Gear	1
4	99−1859	Plate−Front	1
5	99−1860	Gasket−Front Plate	1
6	99−1868	Gear−Camshaft	1
7		Gear−Idler	1
8		Bushing	1
9	99−1869	Gear−Pump, Injection	1
10	99−1873	Gear−Pump, Oil	1

Ref. No.	Part No.	Description	No. Used
11	99−1871	Plate−Thrust	1
12	99−1872	Bolt−W/Washer	1
13	99−1810	Bolt−W/Washer	5
14	99−1865	O−Ring	1
15	99−1863	Cover−Gear, Case	1
16	99−1866	Bolt−W/Washer	5
17	99−1867	Seal−Oil	1
*	99−1870	Asm−Idler, Gear (Incl. Ref. #7−8)	1

* Not Illustrated




T−2955

OIL PAN & OIL LEVEL ASM

Ref. No.	Part No.	Description	No. Used
1	99−1877	Bracket−Gage Guide	1
2	99−1875	Gage−Oil Level	1
3	99−1811	Bolt−W/Washer	1
4	99−1876	Guide−Oil Level Gage	1
5	99−1878	O−Ring	1
6		Pan−Oil	1

Ref. No.	Part No.	Description	No. Used
7	99−1810	Bolt−W/Washer	26
8	68−6430	Gasket	1
9	68−6420	Plug−Drain	1
*	99−1874	Asm−Pan, Oil (Incl. Ref. #6, 8 & 9)	1

* Not Illustrated




T−2956

PISTON & CONNECTING ROD ASM

Ref. No.	Part No.	Description	No. Used
1		Ring No. 1	4
*	99−1884	Ring−Piston O.S. 0.25 (Incl. Ref. #1−3)	4
2		Ring No. 2	4
*	99−1885	Ring−Piston O.S. 0.50 (Incl. Ref. #1−3)	4
3		Ring−Oil	4
4	99−1887	Ring−Snap	8
5	99−1880	Piston−Std.	4
5	99−1881	Piston−O.S. 0.25	4
5	99−1882	Piston−O.S. 0.50	4
6		Rod−Connecting	4
7	99−1891	Set−Metal Std.	1
7	99−1892	Set−Metal O.S. 0.25	1
7	99−1893	Set−Metal O.S. 0.50	1
7	99−1894	Set−Metal O.S. 0.75	1
8		Cap−Connecting Rod	4
9	51−6230	Nut	8
10	99−1889	Bolt−Connecting	8
11	99−1890	Bushing−Rod, Connecting	8
12	99−1886	Pin−Piston	4
*	99−1888	Asm−Rod, Connecting (Incl. Ref. #6−11)	4
*	99−1883	Set−Ring, Piston Std (Incl. Ref. #1−3)	4

* Not Illustrated




T−2957

CRANKSHAFT & FLYWHEEL ASM

Ref. No.	Part No.	Description	No. Used
1	99−1897	Nut−Crankshaft	1
2	99−1896	Pulley−Crankshaft	1
3	99−1898	Gear−Crankshaft	1
4	51−5460	Key−Woodruff	2
5		Crankshaft	1
6	51−6300	Pin−Dowel	2
7	99−2100	Gear−Ring	1

Ref. No.	Part No.	Description	No. Used
8		Flywheel	1
9	70−2880	Bolt	4
10	51−8610	Washer−Spring	4
*	99−1895	Asm−Crankshaft (Incl. Ref. #1−6)	1
*	99−1899	Asm−Flywheel (Incl. Ref. #7−8)	1

* Not Illustrated




T−2958

INLET & EXHAUST MANIFOLD ASM

Ref. No.	Part No.	Description	No. Used
1	60−7290	Bolt	1
2	99−2125	Clamp	2
3	99−2119	Pipe−Oil	1
4	70−4980	Bolt−Eye	1
5	51−5060	Gasket	2
6	99−2126	Nut	1
7	51−7400	Washer−Spring	1
8	99−2120	Elbow	1
9	99−2124	Asm−Turbocharger	1
10	99−2115	Stud	3
11	99−2117	Clamp	1
12	99−2116	Hose−Air	1
13	70−3440	Clamp	1
14	99−2121	Gasket−Pipe, Drain	1
15	99−2118	Pipe−Drain, Oil	1
16	70−3090	Clamp−Hose	2
17	99−2123	Hose−Oil	1
18	70−5310	Elbow	1
19	99−2103	Elbow−Air Inlet	1

Ref. No.	Part No.	Description	No. Used
20	99−1811	Bolt−W/Washer	4
21	99−2104	Gasket−Heater, Air	1
22	99−1828	Bolt/W/Washer	16
23	99−2101	Asm−Inlet, Manifold	1
24	99−2102	Gasket−Manifold, Inlet	1
25	99−2122	Bolt−W/Washer	2
26	99−2109	Spacer	8
27	51−7250	Washer−Spring	8
28	99−2110	Washer	8
29	99−2111	Bolt/W/Washer	8
30	99−2106	Pipe−Exhaust	1
31	60−7120	Nut	8
32	99−2107	Gasket−Exhaust, Manifold	1
33	99−2108	Asm−Exhaust, Manifold	1
34	99−2105	Gasket−Exhaust	1
35	70−3480	Stud	4
36	99−2114	Gasket−Exhaust	1
37	99−2112	Stud	4
38	99−2113	Nut−Lock	8




T−2959

OIL SYSTEM ASM

Ref. No.	Part No.	Description	No. Used
1	99−2139	Gasket−Cover, Side	1
2	99−2136	Asm−Element	1
3	99−2141	O−Ring	2
4		Asm−Case	1
5	99−1811	Bolt−W/Washer	16
6	99−2138	Bolt−Cooler, Oil	4
7	99−2142	Gasket	4
8	99−2131	O−Ring	2
9	99−2140	Gasket	1
10	99−2144	Union−Filter, Oil	1
11	99−2143	Cartridge−Oil	1
12	93−3417	Gasket	1
13	99−2132	Valve	1
14	99−2134	Gasket	1
15	99−2133	Valve	1
16	99−2131	O−Ring	1
17	99−2130	Strainer−Oil	1

Ref. No.	Part No.	Description	No. Used
18	99−1830	Bolt/W/Washer	2
19		Rotor−Outer	1
20	99−1811	Bolt−W/Washer	4
21	99−2129	Nut−Jam	1
22	51−6390	Washer−Spring	1
23		Case−Oil Pump	1
24		Pin−Dowel	2
25		Shaft−Pump, Oil	1
26		Rotor−Inner	1
27		Pin	1
28	99−2128	O−Ring	1
*	99−2127	Asm−Pump, Oil (Incl. Ref. #19 & 23−27)	1
*	99−2137	Asm−Case	1
*	99−2135	Asm−Cooler, Oil (Incl. Ref. #2−4 & 6−7)	1

* Not Illustrated




T−2960

COOLING SYSTEM ASM

Ref. No.	Part No.	Description	No. Used
1	99−2150	Bolt−W/Washer	1
2	99−1813	Gasket	2
3	99−1812	Plug−Drain	2
4	99−2155	Thermostat	1
5	99−2154	Gasket−Thermostat	1
6	99−2153	Cover−Thermostat	1
7	92−2133	Bolt−Flange	2
8	51−7210	Gasket	1
9		Plug−Tapered	1
10	99−2146	Cover−Pump, Water	1
11	99−2148	Gasket−Pump, Water	1
12	99−2147	Gasket−Cover, Pump	1
13		Case−Pump, Water	1
14	99−2150	Bolt−W/Washer	5
15	99−2159	Belt−Raw Edge	1
16	51−5160	Washer	4
17	99−2160	Bolt−W/Washer	4

Ref. No.	Part No.	Description	No. Used
18	99−2149	Pulley−Pump, Water	1
19	99−2151	Bolt−Flange	1
20	92−2133	Bolt−Flange	2
21		Pipe−Water	1
22	93−4297	Clamp−Hose	2
23	99−2152	Hose−By−Pass	1
24		Pipe	1
25		Case	1
26	99−2158	Bolt−W/Washer	1
*	99−2157	Asm−Thermostat (Incl. Ref. #4−7 & 24−25)	1
*	99−2145	Asm−Pump, Water (Incl. Ref. #9−10, 12−13 & 19−21)	1
*	99−2156	Asm−Case, Thermostat (Incl. Ref. #24−25)	1


* Not Illustrated



FUEL INJECTION PUMP MOUNT ASM

Ref. No.	Part No.	Description	No. Used
1	98−7375	Gasket−Nozzle	4
2	99−2167	Cap	1
4	99−2169	Clip	7
*	99−2168	Asm−Hose, Oil (Incl. Ref. #4 & 5)	3
5		Hose−Fuel	3
6	99−2172	Pipe−Injection No. 1	1
7	99−2173	Pipe−Injection No. 2	1
8	99−2174	Pipe−Injection No. 3	1
9	99−2175	Pipe−Injection No. 4	1
10	99−2165	Support−Nozzle	4
11	99−2166	Bolt−W/Washer	4
12	99−2170	Bracket−Pump	1
13	51−7250	Washer−Spring	2
14	60−7120	Nut	1
15	60−7280	Bolt	1
16	99−2178	Asm−Hose, Fuel	1
17	99−2176	Pipe−Return, Fuel	1
18	99−2177	Joint−Eye	1
19	56−0750	Clamp (B)	3
20	56−0760	Clamp (A)	3
21	99−2179	Bolt−W/Washer	3

Ref. No.	Part No.	Description	No. Used
22	99−2185	Connector	1
23	99−2184	Pipe−Oil	1
24	99−2164	Bolt−W/Washer	1
25	70−6530	Bolt−W/Washer	6
26		Asm−Governor	1
27		Asm−Body, Injection	1
28	99−2163	Asm−Pump, Feed	1
29	70−6880	Key−Woodruff	1
30	70−6780	Nut−Hex.	1
31	70−6680	Washer−Spring	1
32	99−2162	Cover−Control	1
33	99−2186	Color	1
34	99−2183	Bolt−W/Washers	4
35	99−2182	O−Ring	1
36	99−1811	Bolt−W/Washer	1
37	99−2171	Flange−Pimp, Injection	1
38	99−1865	O−Ring	1
39	99−2181	Hose	1
40	99−2180	Hose	1
*	99−2161	Asm−Pump, Injection (Incl. Ref. #24−32)	1




T−2962

NOZZLE ASM

Ref. No.	Part No.	Description	No. Used
1	99−2779	Asm−Body	4
2	70−4860	Washer−1.000mm Thick	AR
2	70−4870	Washer−1.050mm Thick	AR
2	70−4880	Washer−1.100mm Thick	AR
2	99−2190	Washer−1.150mm Thick	AR
2	99−2191	Washer−1.200mm Thick	AR
2	99−2192	Washer−1.250mm Thick	AR
2	99−2193	Washer−1.300mm Thick	AR
2	99−2194	Washer−1.350mm Thick	AR
2	99−2195	Washer−1.400mm Thick	AR
2	99−2196	Washer−1.450mm Thick	AR
2	99−2197	Washer−1.500mm Thick	AR
2	99−2198	Washer−1.550mm Thick	AR
2	99−2199	Washer−1.600mm Thick	AR
2	99−2200	Washer−1.650mm Thick	AR
2	99−2201	Washer−1.700mm Thick	AR
2	99−2202	Washer−1.750mm Thick	AR
2	99−2203	Washer−1.800mm Thick	AR
2	70−4890	Washer−1.275mm Thick	AR
2	70−4900	Washer−1.325mm Thick	AR
2	99−2204	Washer−1.375mm Thick	AR
2	99−2205	Washer−1.425mm Thick	AR
2	99−2206	Washer−1.475mm Thick	AR

Ref. No.	Part No.	Description	No. Used
2	70−4920	Washer−0.950mm Thick	AR
2	99−2207	Washer−0.700mm Thick	AR
2	99−2217	Washer−0.750mm Thick	AR
2	99−2208	Washer−0.800mm Thick	AR
2	99−2209	Washer−0.850mm Thick	AR
2	99−2210	Washer−0.900mm Thick	AR
2	99−2211	Washer−0.975mm Thick	AR
2	99−2212	Washer−1.025mm Thick	AR
2	99−2213	Washer−1.075mm Thick	AR
2	99−2214	Washer−1.125mm Thick	AR
2	99−2215	Washer−1.175mm Thick	AR
2	99−2216	Washer−1.225mm Thick	AR
3	99−2281	Spring−Pressure	4
4	99−2280	Pin−Pressure	4
5	99−2218	Packing	4
6	70−6830	Pin−Straight	8
7	99−2189	Asm−Tip, Nozzle	4
8	70−4840	Nut−Retaining	4
*	99−2187	Asm−Nozzle (Incl. Ref. #1−8)	4
*	99−2188	Asm−Holder (Incl. Ref. #1−6 & 8)	4




T−2963

INJECTION PUMP ASM

Ref. No.	Part No.	Description	No. Used
1	70−6840	Bearing−Roller	1
2	70−3780	Shim−0.10mm Thick	AR
2	70−3790	Shim−0.15mm Thick	AR
2	70−3800	Shim−0.30mm Thick	AR
2	70−3810	Shim−0.50mm Thick	AR
2	99−2240	Shim−1.00mm Thick	AR
2	99−2241	Shim−1.50mm Thick	AR
2	99−2242	Shim−0.12mm Thick	AR
2	99−2243	Shim−0.14mm Thick	AR
2	99−2244	Shim−0.18mm Thick	AR
2	99−2245	Shim−0.03mm Thick	AR
3	70−3700	Ring−Adjust	1
4	70−6940	Screw−Hollow	1
5	70−3870	Washer−Union	2
6		Housing−Pump	1
7	99−2234	Screw−Guide, Rack	1
8	99−2224	Element−Pump	4
9	99−2223	Valve−Delivery	4
10	70−3530	Gasket−Valve	4
11	99−2222	Spring−Valve	4
12	99−2221	Stopper−Valve	4
13	70−6910	O−Ring	4
14	99−2220	Holder−Valve	4
15	70−3880	Plate−Set	2
16	70−3860	Washer−Union	2
17	99−2239	Asm−Valve	1

Ref. No.	Part No.	Description	No. Used
18	99−2233	Rack−Control	1
19	70−3930	Gasket−Plate, Cover	1
20	70−3710	Shim−0.10mm Thick	AR
20	70−3720	Shim−0.12mm Thick	AR
20	70−3730	Shim−0.14mm Thick	AR
20	70−3740	Shim−0.16mm Thick	AR
20	70−3750	Shim−0.18mm Thick	AR
20	70−3760	Shim−0.50mm Thick	AR
20	70−3770	Shim−0.30mm Thick	AR
20	99−2228	Shim−1.00mm Thick	AR
20	99−2229	Shim−1.50mm Thick	AR
20	99−2230	Shim−2.00mm Thick	AR
20	99−2231	Shim−0.03mm Thick	AR
21	70−6850	Bearing−Roller	1
22	70−3690	Ring−Adjusting	1
23	70−3900	Packing	2
24	70−3950	Screw	2
25	70−6930	Screw−Hollow	1
26	70−3910	Washer−Nipple	2
27	70−6720	Stud	3
28	70−6900	O−Ring	1
29	99−2238	Washer−Spring	3
30	99−2237	Nut−Hex.	3
31	70−3570	Screw−Clamp, Pinion	4
32	70−3970	Shim−0.60mm Thick	AR
32	70−3980	Shim−0.70mm Thick	AR




T−2963

INJECTION PUMP ASM (Continued)

Ref. No.	Part No.	Description	No. Used
32	70−3990	Shim−0.80mm Thick	AR
32	70−4000	Shim−0.90mm Thick	AR
32	70−4010	Shim−1.00mm Thick	AR
32	70−4020	Shim−1.10mm Thick	AR
32	70−4030	Shim−1.20mm Thick	AR
32	70−4040	Shim−1.30mm Thick	AR
32	70−4050	Shim−1.40mm Thick	AR
32	70−4060	Shim−0.10mm Thick	AR
32	70−4070	Shim−0.20mm Thick	AR
32	70−4080	Shim−0.30mm Thick	AR
32	70−4090	Shim−0.40mm Thick	AR
32	70−4100	Shim−0.50mm Thick	AR
32	70−4110	Shim−0.15mm Thick	AR
32	99−2236	Shim−0.13mm Thick	AR

Ref. No.	Part No.	Description	No. Used
33	70−3630	Tappet	4
34	70−3670	Plug−Screw	4
35	70−3610	Sheet−Spring, Lower	4
36	99−2227	Spring−Plunger	4
37	99−2226	Sheet−Spring, Upper	4
38	99−2225	Sleeve−Control	4
39	70−3560	Pinion−Control	4
40	70−3680	Camshaft	1
41	70−6540	Bolt−W/Washer	4
42	70−3820	Cover−Bearing	1
43	99−2232	Gasket−Cover, Bearing	1
44	70−3940	Cover−Plate	1
*	99−2235	Asm−Cover, Pump (Incl. Ref. #23−24 & 44)	1




T−2964

GOVERNOR ASM

Ref. No.	Part No.	Description	No. Used
1	70−4480	Shaft−Governor	1
2	70−4470	Lever−Support	1
3	70−4490	Cup−Spring	1
4	70−4510	Spring	1
5	70−4520	Spring	1
6	70−4500	Spring	1
7	70−4460	Plate−Cap	1
8	70−6510	O−Ring	2
9	70−4230	Bushing−Lever	2
10	70−4580	Cap−Lever	1
11	70−4360	Plug−Screw	2
12	70−4350	Shaft−Lever	1
13	70−4400	Cover−Governor	1
14	70−6740	Bolt−W/Washer	2
15	99−2251	Capsule	1
16	70−3890	Washer−Nipple	2
17	70−4310	Nut−Lock, Adapter	1
18	70−4440	Nut−Cap	1
19	70−6540	Bolt−W/Washer	2
20	99−2254	Plate−Cover	1
21	99−2248	Nut−Cap	1
22	70−6690	Washer−Plate	2
23	99−2260	Nut−Hex.	1
24	70−6500	O−Ring	1
25	70−4330	Bushing	1
26	99−2255	Bolt−W/Washer	2

Ref. No.	Part No.	Description	No. Used
27	70−4430	Screw−Adjusting	1
28	70−6560	Nut−W/Hole	1
29	70−6790	Packing−Rubber Plate	1
30	70−6750	Bolt−W/Washer	4
31	70−6920	Seal−Oil	1
32	99−2253	Lever−Adjusting	1
33	70−6730	Bolt−W/Washer	1
34	70−4530	Cover−Spring	1
35	70−4570	Lever−Stop	1
36	70−6520	Bolt−W/Washer	1
37	99−2249	Lever−Tension	1
38	70−4370	Spring−Control	1
39	70−4320	Asm−Control, Tension	1
40	70−4540	Slider−Supporting	1
41	70−6610	Washer−Plate 0.2mm Thick	AR
41	70−6620	Washer−Plate 0.3mm Thick	AR
41	70−6630	Washer−Plate 0.4mm Thick	AR
41	70−6640	Washer−Plate 0.1mm Thick	AR
41	70−6650	Washer−Plate 1.0mm Thick	AR
42	70−6490	Snap Ring	1
43	70−4200	Plate	1
44	70−4190	Sleeve−Governor (Incl. Ref. #42−43)	1
45	70−4180	Nut−Round	1
46	70−6670	Washer−Spring	1
47	70−4170	Asm−Flyweight	1




T−2964

GOVERNOR ASM (Continued)

Ref. No.	Part No.	Description	No. Used
48	99−2258	Gasket	1
49	99−2250	Nut−Hex.	1
50	99−2247	Screw−Adjust	1
51	99−2259	Gasket	1
52	70−6870	Key−Woodruff	1
53	99−2246	Housing−Governor	1
54	70−6710	Washer−Copper Plate	1
55	70−4590	Plug−Screw	1
56	70−4210	Plate	1
57	70−6810	Washer−Snap	2

Ref. No.	Part No.	Description	No. Used
58	99−2252	Lever−Swivelling	1
59	70−6860	Key−Woodruff	1
60	70−4380	Spring−Start	1
61	70−4340	Shackle	1
62	70−6480	Pin−Split	1
63	99−2257	Spring	1
64	70−6890	O−Ring	1
65	99−2256	Bushing−Bearing	1
66	70−4410	Pin−Stop	1
67	70−4390	Screw−Adjusting	1




T−2965

FEED PUMP ASM

Ref. No.	Part No.	Description	No. Used
1	70−4780	Plug−Chamber	1
2	70−6700	Washer	1
3	70−4770	Spring−Piston	1
4	99−2263	Piston	1
5	70−4610	Valve−Check	2
6	70−4620	Spring−Valve	2
7	70−4630	Gasket−Plug	2
8	70−4640	Support−Valve	1
9	99−2262	Washer−Union	4
10	70−6940	Screw−Hollow	1
11	70−4650	Pump−Priming	1
12	70−4760	Block−Sliding	2

Ref. No.	Part No.	Description	No. Used
13	70−4730	Tappet−Feed Pump	1
14	70−4740	Roller−Tappet	1
15	70−6820	Ring−Snap	1
16	70−4750	Pin−Roller	1
17	99−2282	Seal−Oil	1
18	70−4600	Asm−Housing (Incl. Ref. #17 & 20)	1
19	70−4790	Filter−Fuel	1
20	70−4800	Screw−Hollow	1
21	99−2261	Rod−Push	1
*	70−5700	Asm−Pump, Feed (Incl. Ref. #1−21)	1

* Not Illustrated




T−2966

FUEL FILTER ASM

Ref. No.	Part No.	Description	No. Used
1	70−3250	Bolt−Connector	2
2	51−5390	Packing−Connector	4
3	70−3240	Plug−Air	1
4	51−5840	Washer−Sealing	1
5	70−5720	Bracket	1
6	70−5730	Asm−Cartridge	1
*	70−5710	Asm−Filter, Fuel (Incl. Ref. #1−6)	1

* Not Illustrated




T−2967

ELECTRICAL COMPONENTS ASM

Ref. No.	Part No.	Description	No. Used
1	99−2265	Plate−Connection	1
2	99−2266	Plug−Glow	4
3	99−1811	Bolt−W/Washer	2
4	67−4660	Bolt−Flange	1
5	54−8660	Washer	1

Ref. No.	Part No.	Description	No. Used
6	99−1857	Bolt−W/Washer	2
7	99−2268	Bracket−Alternator	1
8	99−2267	Asm−Starter	1
9	99−2270	Plate−Adjusting	1




T−2968

ALTERNATOR ASM

Ref. No.	Part No.	Description	No. Used
1	93−3578	Nut	1
2	99−2271	Asm−Pulley	1
3	93−3582	Set−Screw	1
4	93−3580	Set−Bolt	1
5		Asm−Cover, Front	1
6	93−3583	Bearing−Front	1
7		Plate	1
8		Rotor	1
9		Washer	1
10	93−3585	Bearing−Rear	1
11	99−2275	Set−Nut	1
12		Asm−Cover, Rear	1
13	99−2274	Asm−Rectifier	1
14		Ring−Retaining	1

Ref. No.	Part No.	Description	No. Used
15	93−3589	Brush	2
16		Asm−Regulator	1
17	93−3586	Asm−Stator	1
*	99−2269	Asm−Alternator (Incl. Ref. #1−17)	1
*	99−2272	Asm−Bracket, Front (Incl. Ref. #3 & 5−7)	1
*	93−3584	Asm−Rotor (Incl. Ref. #8−10)	1
*	99−2273	Asm−Bracket, Rear (Incl. Ref. #11−16)	1
*	93−3588	Set−Regulator (Incl. Ref. #14−16)	1

* Not Illustrated




T−2969

OVERHAUL GASKET KIT ASM

Ref. No.	Part No.	Description	No. Used
1	51−5060	Gasket	2
2	99−2104	Gasket	1
3	99−1827	Gasket−Rocker	1
4	99−1809	Gasket−Head, Cylinder	1
5	99−1855	Gasket−Rear	1
6	99−1813	Gasket	2
7	51−5390	Washer−Sealing	10
8	51−5840	Washer−Sealing	1
9	99−2134	Gasket	1
10	99−2102	Gasket−Manifold, Inlet	1
11	99−2104	Gasket	1
12	99−2139	Gasket−Cover, Side	1
13	99−2141	O−Ring	2
14	99−2131	O−Ring	3

Ref. No.	Part No.	Description	No. Used
15	99−2140	Gasket	1
16	99−2142	Gasket	4
17	93−3417	Gasket	1
18	99−2128	O−Ring	1
19	99−1817	Seal−Stem, Valve	8
20	99−1807	Gasket−Head, Cylinder	1
21	99−1865	O−Ring	2
22	99−1862	Gasket−Rear	1
23	99−1837	Gasket−Plate, Front	1
24	99−2105	Gasket−Manifold, Exhaust	1
25	99−2107	Gasket−Exhaust	1
26	99−2114	Gasket−Exhaust	1
27	99−2277	Gasket	1




T−2970

OVERHAUL GASKET KIT ASM (Continued)

Ref. No.	Part No.	Description	No. Used
1	99−1865	O−Ring	2
2	99−2182	O−Ring	1
3	98−7375	Gasket−Nozzle	4
4	68−6430	Gasket	1
5	99−1878	O−Ring	1
6	99−1853	Seal−Side	2
7	51−7210	Gasket	1


Ref. No.	Part No.	Description	No. Used
8	99−2131	O−Ring	3
9	99−2148	Gasket−Water	1
10	99−2147	Gasket−Cover, Pump	1
11	99−1813	Gasket	2
12	99−2154	Gasket−Thermostat	1
13	93−3599	Gasket−Liquid	1



FAN DRIVE ASM

Ref. No.	Part No.	Description	No. Used
1	3253−21	Washer−Lock	14
2	323−4	Screw−HH	4
3	32128−25	Nut−HHF	6
4	96−1267	Pulley−Fan	1
5	98−3008	Hub−Fan	1
6	322−3	Screw−HH	6
7	33114−070	Screw−HH	1
8	3253−4	Washer−Lock	7
9	98−0831	Bearing−Fan	1
10	32120−11	Ring−Retaining, Internal	2
11	95−6495	Asm−Bearing Housing	1
12	98−7307	Asm−Fan Support	1
13	33104−020	Screw−HHF	2
14	5−0838	Washer−Flat	6
15	323−6	Screw−HH	2
16	95−6480	Bracket Asm−	1
17	323−7	Screw−HH	6
18	3296−39	Nut−Lock	2
19	33114−045	Screw−HH	4
20	98−3013	Support−Fan	1
21	33114−060	Screw−HH	2
22	99−5915	Asm−Idler Bracket	1

Ref. No.	Part No.	Description	No. Used
23	95−6497	Spacer	1
24	66−5310	Pulley−Idler	1
25	3231−6	Bolt−CARR	1
26	32128−21	Nut−HHF	1
27	95−6477	Pulley−Fan Drive	1
28	98−9008	V−Belt	1
29	98−0809	Fan	1
30	323−5	Screw−HH	4
31	98−7321	Clutch−Modulating Fan	1
32	70−5710	Filter−Fuel	1
33	99−1929	Asm−Solenoid	1
34	33013−00	Nut	2
35	3253−3	Washer−Lock	5
36	33093−00	Washer−Flat	3
37	99−1930	Rod−Connecting	1
38	33103−016	Screw	1
39	99−1931	Rod−Support	1
40	99−1928	Bracket−Mounting	1
41	33103−050	Screw	2
*	98−7327	Asm−Solenoid, Run (Incl. Ref. #33−41)	1




T−2837-2

MUFFLER & AIR CLEANER ASM

Ref. No.	Part No.	Description	No. Used
1	2412−110	Clamp−Hose	3
2	95−6459	Hose−Air Inlet	2
3	95−6474	Asm−Exhaust Tube	1
4	3256−24	Washer−Flat	3
5	3253−6	Washer−Lock	5
6	69−9710	Nut−Lock	3
7	69−9420	Muffler−Exhaust	7
8	20−4840	Clamp−Muffler	2
9	95−6463	Bracket−Muffler	9
10	323−6	Screw−HH	2
11	33115−025	Screw−HH	2
12	322−3	Screw−HH	2
13	98−0833	Band−Air Cleaner	1
14	3253−4	Washer−Lock	2
15	3256−23	Washer−Flat	4

Ref. No.	Part No.	Description	No. Used
16	33114−020	Screw−HH	4
17	95−6462	Bracket−Air Cleaner	1
18	32128−25	Nut−HHF	2
19	98−0800	Asm−Air Cleaner	1
20	95−6457	Hose−Air Outlet	1
21	95−6461	Tube−Intake	1
22	95−6458	Hose−Air Outlet	1
23	2412−42	Clamp−Hose	1
24	98−7347	Clamp−Hose	2
25	32128−21	Nut−HHF	2
26	95−6464	Bracket−Manifold	1
27	69−1940	Indicator−Electrical	1
28	94−1416	Adapter	1
29	99−2277	Gasket	1

3321−612




T−2252−1

AIR CLEANER ASM NO. 98−0800

Ref. No.	Part No.	Description	No. Used
†1		Plug	1
†2		Asm−Body	1
3	98−0801	Asm−Element	1

Ref. No.	Part No.	Description	No. Used
4	98−0802	Asm−Cover	1
5	98−0803	Valve	1

† Not Serviceable




T−0376−1

FUEL/WATER FILTER ASM

Ref. No.	Part No.	Description	No. Used
1	37−9560	Hose−Fuel	1
2	2412−108	Clamp−Hose	3
3	353−781	Fitting−Fuel Elbow	2
4	63−8280	Head−Fuel Filter (Incl. Ref. #5)	1
5	63−8290	Vent−Air	1
7	71−2690	Hose−Fuel	1

Ref. No.	Part No.	Description	No. Used
8	63−8310	Valve−Drain	1
9	69−1760	Sensor−Water	1
10	237−154	O−Ring	1
11	69−1770	Element−Spin−On (Incl. Ref. #6)	1
*	69−1750	Asm−Fuel Filter (Incl. Ref. #4, 5 & 8−11)	1

* Not Illustrated




T−0346−5

BATTERY FRAME ASM

Ref. No.	Part No.	Description	No. Used
1	95−5908	Asm−Manifold (Power Take Off)	1
2	69−9350	Bracket−Hood Prop Rod	1
3	321−3	Screw−HH	3
4	3272−6	Pin−Cotter	1
5	69−9120	Rod−Hood Prop	1
6	3234−17	Screw−HFH	4
7	2412−73	Clamp−R	3
8	32149−2	Nut−Keps	3
†9		Bolt−Clamp	4
†10		Nut−Clamp	4
11	95−1839	Cable−Negative	1
12	98−7308	Cable−Positive	1
13	323−9	Screw−HH	2
14	3253−21	Washer−Lock	2
15	3256−24	Washer−Flat	2
16	66−2490	Hold−Down−Battery	2
‡17		Battery (Type 24, LTV)	2
18	80−0160	Tray−Battery	1
19	66−8800	Relay	2
20	3290−321	Screw−HH	4
21	323−4	Screw−HH	4
22	32152−2	Nut−Lock	4

Ref. No.	Part No.	Description	No. Used
23	18−2770	Strap−Ground	1
24	3296−2	Nut−Lock	4
25	3254−2	Washer−Lock	1
26	32152−1	Nut−Lock	3
27	322−5	Screw−HH	1
28	33116−020	Screw−HH	1
29	48−8070	Washer−Lock	1
30	322−11	Screw−HH	1
31	56−7974	Clamp−Hydraulic Lines	2
32	323−6	Screw−HH	4
33	69−8290	Frame−Battery	1
34	237−37	Bumper−Rubber	4
35	23−7250	Spacer	1
36	69−9761	Plate−Clamp	1
37	72−4080	Decal−Danger	1
38	2412−41	Clamp	1
39	2412−39	Clamp	1
40	2412−104	Clamp−R	2
41	99−4965	Asm−Tube Front, Return	1
42	99−4967	Asm−Tube, Front, Deck Pressure	1
43	237−58	O−Ring	2

† Not Serviceable Separately
‡ Obtain Locally




T–0364–3

PTO MANIFOLD ASM

Ref. No.	Part No.	Description	No. Used
1	98–0655	Hose–Hydraulic	2
†2		O–Ring	6
†4		O–Ring	6
5	95–5640	Valve–Cartridge (600 lbs) (Incl. Ref. #2–4)	3
6	353–989	Plug (Incl. Ref. #7)	1
7	237–42	O–Ring	1
8	95–5635	Valve–Cartridge (3000 lbs) (Incl. Ref. #2–4)	3
9	69–5600	Hose–Hydraulic	1
10	237–58	O–Ring	8
11	69–6160	Tube–Hydraulic	1
12	340–65	O–Ring	2
13	340–129	Fitting–Hydraulic Elbow (Incl. Ref. #12 & 14)	1
14	237–146	O–Ring	1
15	340–142	Fitting–Hydraulic Elbow (Incl. Ref. #10 & 16)	1
17	69–5610	Hose–Hydraulic	1
18	340–9	Fitting–Hydraulic Straight (Incl. Ref. #10 & 19)	5
19	237–81	O–Ring	8
20	69–6180	Tube–Hydraulic	1
21	69–6170	Tube–Hydraulic	1
23	88–9190	Asm–Solenoid Coil	3
24	3219–10	Nut–Jam	3

Ref. No.	Part No.	Description	No. Used
25	95–5639	Spool–Solenoid Valve (Incl. Ref. #24, 26–28)	3
†26		O–Ring	3
†28		O–Ring	6
†29		Manifold–Power Take Off	1
30	237–156	O–Ring	30
31	353–991	Plug (Incl. Ref. #30)	30
32	237–79	O–Ring	4
33	237–78	O–Ring	1
34	353–990	Plug (Incl. Ref. #33)	1
†35		O–Ring	6
†36		O–Ring	6
†37		O–Ring	6
38	95–5637	Valve–Cartridge (75 lbs) (Incl. Ref. #35–37)	3
39	353–988	Plug (Incl. Ref. #32)	4
40	95–5636	Valve–Cartridge (20 lbs) (Incl. Ref. #35–37)	3
41	237–78	O–Ring	2
42	353–431	Fitting–Hydraulic 45° (Incl. Ref. #41 & 43)	2
44	93–7423	Hose–Diagnostic	2
45	69–6140	Tube–Hydraulic	1
46	69–6150	Tube–Hydraulic	1

† Not Serviceable Separately




T−0364−3

PTO MANIFOLD ASM (Continued)

Ref. No.	Part No.	Description	No. Used
47	69−4220	Plug−Orifice	1
48	98−0657	Fitting−Hydraulic (Incl. Ref. #)	2
*	95−5645	Kit−Cartridge Valve Seal (Incl. Ref. #2 & 4)	6
*	95−5644	Kit−Cartridge Valve Seal (Incl. Ref. #35−37)	6

Ref. No.	Part No.	Description	No. Used
*	95−5643	Kit−Solenoid Valve Seal (Incl. Ref. #26−28)	3
*	95−5908	Asm−Manifold (Power Take Off) (Incl. Ref. #2, 4−8, 22−40 & 47)	1

* Not Illustrated




REAR AXLE ASM

Ref. No.	Part No.	Description	No. Used
1	69−5510	Hose−Hydraulic	4
2	340−68	Fitting−Hydraulic Bulkhead Tee (Incl. Ref. #45)	2
3	323−6	Screw−HH	2
4	32121−110	Pin−Roll	1
5	71−2590	Shaft−Pivot	1
6	69−6470	Bushing−Flange	6
7	256−304	Washer−Thrust	6
8	32128−23	Nut−Lock	12
9	3290−216	Washer−Bevel	12
10	3234−12	Screw−HFH	2
11	3296−68	Nut−Lock	1
12	69−7960	Support−Axle	2
13	69−8890	Cap−Spindle	2
14	32151−10	Ring−Retaining	2
15	302−5	Fitting−Grease	3
16	69−7420	Axle−Rear (Incl. Ref. #6 & 15)	1
17	93−0311	Spindle−Wheel LH	1
*	93−0310	Spindle−Wheel RH	1
18	69−2990	Screw−Drive	10
19	69−2960	Hub−Rear Wheel (Incl. Ref. #18, 20 & 30)	2
20	254−72	Cup−Bearing Outer	2
21	254−92	Cone−Bearing Outer	2
22	69−9880	Tire	2
23	217−116	Rim	2

Ref. No.	Part No.	Description	No. Used
24	23−7270	Nut−Lug	10
25	93−0309	Washer	2
26	3272−13	Pin−Cotter	2
27	69−2970	Cap−Hub	2
28	3220−7	Nut−Jam	2
29	232−27	Stem−Valve	2
30	254−107	Cup−Bearing Inner	2
31	254−106	Cone−Bearing Inner	2
32	69−2980	Seal−Inner	2
33	32136−13	Nut−Castle	4
34	3272−12	Pin−Cotter	6
35	2116−4	Joint−Ball RH	1
*	2116−3	Joint−Ball LH	1
36	302−33	Fitting−Grease	2
†37		Nut−Lock	2
38	2412−7	Asm−Clamp (Incl. Ref. #37 & 40)	2
39	3−3710	Asm−Tie Rod (Incl. Ref. #35−41)	1
†40		Screw−HH	2
41	32136−2	Nut−Castle	2
42	98−0661	Asm−Hydraulic Cylinder	2
43	237−78	O−Ring	4
44	340−132	Fitting−Hydraulic Elbow (Incl. Ref. #43 & 52)	4
45	237−22	O−Ring	6
46	325−6	Screw−HH	12


* Not Illustrated
†‡ Not Serviceable Separately



REAR AXLE ASM (Continued)

Ref. No.	Part No.	Description	No. Used
47	32152−2	Nut−Lock	2
48	340−70	Nut−Bulkhead	2
49	95−6487	Bracket−Hose Support	1
50	69−6010	Tube−Hydraulic	1

Ref. No.	Part No.	Description	No. Used
51	69−6020	Tube−Hydraulic	1
52	237−21	O−Ring	4
53	93−0307	Nut−Retainer	2




T−0378−3

HYDRAULIC CYLINDER ASM NO. 98−0661

Ref. No.	Part No.	Description	No. Used
1	302−5	Fitting−Grease	2
2	69−9810	Joint−Ball	1
3		Ring−Retaining	1
4	98−0666	Rod−Piston	1
5		Wiper−Rod	1
6		Seal−U−Cup	1
7	98−0664	Ring−Head	1
8		Ring−Back−Up	1
9		O−Ring	1
10		O−Ring	1
11	98−0665	Piston	1
12		Ring−Piston	1

Ref. No.	Part No.	Description	No. Used
13		O−Ring	1
14	43−5130	Nut−Lock	1
15		Barrel−Cylinder	1
16	69−1980	Nut−Jam	1
17	82−5730	Joint−Ball	1
18	32121−34	Pin−Roll	1
*	98−0667	Kit−Repair (Incl. Ref. #3, 5, 6, 8−10 & 12−13)	1
*	98−0661	Steering Cylinder (Complete) (Incl. Ref. #3−18)	2


* Not Illustrated



FRONT LIFT ARM ASM

Ref. No.	Part No.	Description	No. Used
1	3296−68	Nut−Lock	2
2	302−2	Fitting−Grease	4
3	71−2570	Shaft−Pivot	1
4	69−7940	Support−Lift Arm RH	2
6	237−42	O−Ring	4
7	92−4971	Asm−Hydraulic Cylinder	2
8	237−22	O−Ring	9
9	69−8440	Hose−Hydraulic	1
11	72−4310	Switch−Ball	1
12	69−5440	Hose−Hydraulic	3
13	340−70	Nut−Bulkhead	1
14	340−68	Fitting−Hydraulic Bulk. Tee (Incl. Ref. #8)	1
15	98−7346	Tube−Cylinder Bushing	2
16	20−4360	Tube−Spacer	2
17	69−9180	Pin−Cylinder	2
18	3272−23	Pin−Cotter	4
19	340−77	Fitting−Hydraulic Elbow (Incl. Ref. #6 & 8)	4
20	32153−6	Nut−Lock	2
21	328−5	Screw−HH	2
22	325−6	Screw−HH	12
23	32121−110	Pin−Roll	2
24	71−2590	Shaft−Pivot	1
25	3253−7	Washer−Lock	16
26	3217−9	Nut−Hex.	16

Ref. No.	Part No.	Description	No. Used
27	69−7920	Support−Lift Arm LH	2
28	256−304	Washer−Thrust	2
29	69−6470	Bushing−Flange	4
30	92−4806	Pin−Latch	1
31	32120−47	Ring−Retaining	2
32	69−8470	Spring−Torsion	1
33	76−1670	Spring−Extension	1
34	69−1540	Pivot−Spring	1
35	3272−12	Pin−Cotter	2
36	32136−2	Nut−Slotted	2
37	86−8100	Joint−Ball (Incl. Ref. #2 & 36)	2
38	21−3000	Nut−Jam	2
39	69−9580	Asm−Front Lift Arm, LH (Incl. Ref. #29 & 40)	1
40	302−5	Fitting−Grease	2
41	3290−378	Tie−Cable	1
43	69−9570	Asm−Front Lift Arm, RH (Incl. Ref. #29 & 40)	1
44	93−7426	Tube−Hydraulic	1
45	340−57	Fitting−Hydraulic Straight (Incl. Ref. #8)	2
46	93−1397	Valve−Flow Control	1
47	93−7427	Tube−Hydraulic	1




HYDRAULIC CYLINDER ASM NO. 92–4971

Ref. No.	Part No.	Description	No. Used
1	69–2580	Shaft w/clevis	1
†2		Seal–Dust	1
3	61–4990	Ring–Retaining	1
4	69–2570	Head	1
†5		Ring–Back–Up	1
†6		O–Ring	1
†7		Ring–Back–Up	1
†8		O–Ring	1

Ref. No.	Part No.	Description	No. Used
†9		Uni–Ring	1
10	60–9770	Piston	1
11	60–9760	Nut–Lock	1
†12		Barrel	1
13	302–5	Fitting–Grease	3
14		Seal–Uni–Ring	1
*	86–7350	Kit–Seal Repair (Incl. Ref. #2 & 5–9)	1

* Not Illustrated
† Not Serviceable Separately

3321−612




T−0362−4

CENTER DECK MODEL NO. 30592
CARRIER FRAME ASM

Ref. No.	Part No.	Description	No. Used
1	3290−384	Pin−Lynch	2
2	69−1510	Spacer−Caster	12
3	32128−23	Nut−HHF	4
4	69−8790	Plate−Reinforcing	2
5	69−7290	Mount−Ball Joint	2
6	325−15	Screw−HH	4
7	69−8860	Arm−Castor RH (Incl. Ref. #26−27)	1
8	32151−48	Ring−Retaining	4
9	283−70	Pin−Hitch (Incl. Ref. #11)	2
10	98−3047	Arm−Pivot	2
11	3290−343	Pin−Cotter Hair	2
12	93−4240	10” Wheel−Pneumatic (Incl. Ref. #13−14, 28, 33−37, & 40)	2
13	93−4241	Spacer	2
14	93−4237	Bearing	8
15	327−24	Screw HH	2
16	3296−53	Nut−Lock	4
17	323−15	Screw−HH	16
18	5−0838	Washer−Flat	16
19	32128−43	Nut−HHF	16
20	327−25	Screw−HH	2

Ref. No.	Part No.	Description	No. Used
21	93−5630	Spacer−Bearing	2
22	98−7313	Tire−12”	2
23	98−7312	Wheel−Pneumatic, 12” (Incl. Ref. #14, 21−22 & 38)	2
24	98−7302	Fork−Castor	2
25	69−6860	Washer−Castor	8
26	69−6470	Bushing−Flange	4
27	302−5	Fitting−Grease	2
28	32128−16	Nut−HHF	8
29	69−9260	Pin−Clevis	2
30	95−0818	Decal−Torque	1
31	13−5069	Arm−Castor LH (Incl. Ref. #26−27, & 30)	1
32	30−8770	Washer−Flat	4
33	93−4242	Plate	2
34	93−4243	Tire−10”	2
35	93−4239	Rim−Wheel	4
36	93−5980	Hub	2
37	93−4244	Tube−w/Valve	2
38	93−5631	Rim−Wheel	2
40	95−2741	Rim−Wheel	2
41	93−7252	Decal−CE	1




T–0361–5

CENTER DECK MODEL NO. 30592

Ref. No.	Part No.	Description	No. Used
1	76–2760	Asm–Hydraulic Hose	1
2	76–2750	Asm–Hydraulic Hose	1
3	237–58	O–Ring	2
4	95–1692	Fitting–Hydraulic Elbow (Incl. Ref #3 & 5)	1
5	237–81	O–Ring	2
6	76–2770	Asm–Hydraulic Hose	1
7	237–22	O–Ring	1
8	69–4320	Fitting–Hydraulic 90° (Incl. Ref. #7 & 9)	1
9	237–42	O–Ring	1
10	32128–21	Nut–HHF	6
11	94–4907	Motor–Hydraulic	1
12	3231–28	Bolt–CARR	2
13	19–1470	Bolt–Shoulder	4
14	69–6960	Spacer–Idler	4
15	63–1540	Pulley–Idler	3
16	325–7	Screw–HH	1
17	69–9290	Pad–Bumper	2
18	32108–103	Screw–Flat Hd.	4
19	32128 –20	Nut–HHF	4
20	302–2	Fitting–Grease	1
21	32120–72	Ring–Retaining	1
22	256–188	Bushing–Sleeve	1
23	69–6610	Arm–Idler (Incl. Ref. #22)	1
24	325–8	Screw–HH	1
25	69–5430	Pulley–Idler	1

Ref. No.	Part No.	Description	No. Used
26	69–6970	Spacer–Idler	1
27	32105–1	Screw–Machine	8
28	92–3162	Bushing–Flange	4
29	3269–25	Rivet–Pop	8
30	69–6780	Cover–Center Left	1
31	69–6870	Plate–Magnet	4
32	69–6260	Magnet–Cover	4
33	302–5	Fitting–Grease	4
34	3296–2	Nut–Lock	8
35	32128–23	Nut–Flange Lock	4
36	76–1670	Spring–Extension	1
37	3217–9	Nut–Jam	2
38	69–6550	Arm–Tension	1
39	95–0833	Decal–Belt Routing	1
40	43–8480	Decal–Danger	1
41	13–4969	Deck–Center (Incl. Ref. #20, 28, 33, 39, 40 & 57)	1
42	3233–27	Bolt–CARR	1
43	98–0755	Plate–Tension	1
44	77–2830	Rod–Spring	1
45	3272–7	Pin–Cotter	1
48	86–7480	Spring–Compression	1
49		Screw–Set	2
50	23–1640	Bushing–Taper Lock (Incl. Ref. #49)	1
51	63–0660	Pulley–Drive	1

3321−612




T−0361−5

CENTER DECK MODEL NO. 30592 (Continued)

Ref. No.	Part No.	Description	No. Used
52	69−6390	Plate−Gearbox	1
53	3234−12	Screw−HFH	4
54	69−6790	Cover−Center Right	1
56	95−0845	Decal−Height of Cut	1
57	95−0817	Decal−Height of Cut	1
58	3−6498	Washer−Flat	1
59	3233−30	Bolt−CARR	1
60	66−1340	Decal−Danger	1
60	93−7824	Decal−Danger (Europe)	1
61	93−9324	Pivot−Idler	1
62	94−9820	Bar−Guard, Front RH & LH (Europe)	2

Ref. No.	Part No.	Description	No. Used
63	94−9819	Bar−Guard, Front Center (Europe)	1
64	32104−31	Screw−HW (Europe)	10
65	98−3038	Bushing−Idler	1
66	32149−1	Nut−Keps	1
67	322−6	Screw−HH	1
68	99−4444	Fitting	1
69	99−4443	Fitting	1
70	354−79	Cap−Dust	1
*	93−8457	Belt−Hex. Deck Drive	1
*	3290−378	Tie−Cable	2

* Not Illustrated




T−0366−3

CENTER DECK MODEL NO. 30592 LEFT WING ASM

Ref. No.	Part No.	Description	No. Used
1	3269−25	Rivet−Pop	4
2	3296−2	Nut−Lock	6
3	40−9520	Spacer−Split	2
4	40−0330	Cushion−Rubber	1
5	32122−28	Screw−Truss Hd.	2
6	323−6	Screw−HH	3
7	69−6730	Skid	1
8	32128−23	Nut−Flange Lock	3
9	3233−9	Bolt−CARR	3
10	32128−21	Nut−HHF	6
11	32105−1	Screw−Machine	4
12	13−4989	Deck−Left Wing (Incl. Ref. #23−25)	1
13	69−6640	Hinge−Left Front	1
14	69−6900	Shaft−Hinge	1
15	69−6260	Magnet−Cover	2
16	95−3297	Washer−Thrust	2
17	69−6670	Hinge−Left Rear	1
18	32121−6	Pin−Roll	2
19	94−6760	Bracket−Support	1
20	3231−25	Bolt−CARR	2

Ref. No.	Part No.	Description	No. Used
21	69−6870	Plate−Magnet	2
22	69−6850	Cover−Left Wing	1
23	66−1340	Decal−Danger	1
23	93−7824	Decal−Danger (Europe)	1
24	43−8480	Decal−Danger	1
24	93−7815	Decal−Danger (Europe)	1
25	67−5360	Decal−Danger	1
25	93−7273	Decal−Danger (Europe)	1
26	3256−69	Washer	2
27	82−4910	Roller	1
28	32121−4	Pin−Roll	2
29	88−9270	Bracket−Roller LH	1
30	5−0838	Washer−Flat	3
31	323−7	Screw−HH	3
32	94−9824	Bar− Guard, Front Wing LH (Europe)	1
33	32104−31	Screw−HH (Europe)	3
34	3296−29	Nut−Lock	2
35	3256−23	Washer−Flat	2
*	99−2318	V−Belt	1
*	42−6200	Shim−Cushion	A/R

* Not Illustrated




T−0365−4

CENTER DECK MODEL NO. 30592 RIGHT WING ASM

Ref. No.	Part No.	Description	No. Used
1	3269−25	Rivet−Pop	4
2	69−6840	Cover−Right Wing	1
3	69−6870	Plate−Magnet	2
4	302−2	Fitting−Grease	1
5	32120−72	Ring−Retaining	1
6	256−188	Bushing−Sleeve	1
7	69−5430	Pulley−Idler	1
8	325−8	Screw−HH	1
9	3231−25	Bolt−CARR	2
10	3296−2	Nut−Lock	6
11	94−6762	Bracket−Support	1
12	40−9520	Spacer−Split	2
13	40−0330	Cushion−Rubber	1
14	32122−28	Screw−Truss Hd.	2
15	69−6260	Magnet−Cover	2
16	32105−1	Screw−Machine	4
17	69−6970	Spacer−Idler	1
18	13−4979	Asm−Right Wing Deck (Incl. Ref. #4, 32 & 33)	1
19	323−6	Screw−HH	3
20	69−6900	Shaft−Hinge	1
21	32121−6	Pin−Roll	2
22	32128−21	Nut−HHF	6
23	69−6710	Hinge−Right Rear	1
24	95−3297	Washer−Thrust	2
25	76−1670	Spring−Extension	1
26	32128−23	Nut−HHF	4
27	69−6610	Asm−Idler Arm (Incl. Ref. #6)	1

Ref. No.	Part No.	Description	No. Used
28	69−6690	Hinge−Right Front	1
29	69−6730	Skid	1
30	3233−9	Bolt−CARR	3
31	67−5360	Decal−Danger	1
31	93−7273	Decal−Danger (Europe)	1
32	43−8480	Decal−Danger	1
32	93−7815	Decal−Danger (Europe)	1
33	66−1340	Decal−Danger	1
33	93−7824	Decal−Danger (Europe)	1
34	3−6498	Washer	1
35	3256−69	Washer	2
36	82−4910	Roller	1
37	32121−4	Pin−Roll	2
38	88−9260	Bracket−Roller RH	1
39	323−7	Screw−HH	3
40	5−0838	Washer−Flat	3
41	93−9324	Pivot−Idler	1
42	94−9821	Bar−Guard, Front Wing RH (Europe)	1
43	32104−31	Screw−HH (Europe)	3
44	3296−29	Nut−Lock	2
45	3256−23	Washer−Flat	2
46	98−3038	Bushing−Idler	1
47	32149−1	Nut−Keps	1
48	322−6	Screw−HH	1
*	99−2318	V−Belt	1
*	42−6200	Shim−Cushion	A/R

* Not Illustrated




T−0348−1

WING DECK LIFT ASM

Ref. No.	Part No.	Description	No. Used
1	322−11	Screw−HH	1
2	56−7974	Clamp Half−Hydraulic Line	2
3	32152−1	Nut−Lock	5
4	32153−6	Nut−Lock	22
5	32152−2	Nut−Lock	6
6	69−6170	Tube−Hydraulic LH (Incl. Ref. #20)	1
*	69−6140	Tube−Hydraulic RH (Incl. Ref. # 20)	1
7	69−9450	Bracket−Wing Hose LH	1
*	69−9460	Bracket−Wing Hose RH	1
8	240−3	Grommet	4
9	69−9000	Spacer	4
10	69−9010	Washer	8
11	340−74	Nut−Bulkhead	4
12	323−6	Screw−HH	4
13	69−9761	Plate−Cover	1
15	340−70	Nut−Bulkhead	10
16	69−8940	Washer	20
17	69−8970	Spacer	10
18	240−4	Grommet	10
19	237−22	O−Ring	14
20	237−65	O−Ring	4
21	69−5980	Tube−Hydraulic LH (Incl. Ref. #19)	1
*	69−5970	Tube−Hydraulic RH (Incl. Ref #19)	1

Ref. No.	Part No.	Description	No. Used
22	69−6180	Tube−Hydraulic LH (Incl. Ref. #20)	1
*	69−6150	Tube−Hydraulic RH (Incl. Ref. #20)	1
23	32152−4	Nut Lock	3
24	3272−33	Pin−Cotter	2
25	32108−103	Screw−Machine Flat Hd.	4
26	99−5917	Shaft−Lift Arm Pivot	2
27	32121−110	Pin−Roll	2
28	328−26	Screw−HH	12
29	256−304	Washer−Thrust	4
30	69−6470	Bushing−Flange	4
31	302−2	Fitting −Grease	4
32	72−4310	Switch−Lift	2
33	93−9926	Asm−Lift Arm LH (Incl. Ref. #30−31)	1
*	93−9925	Asm−Lift Arm RH (Incl. Ref. #30−31)	1
34	69−9300	Cushion−Rubber	2
35	3296−68	Nut Lock	2
36	328−8	Screw−HH	4
37	328−8	Screw−HH	2
38	69−9190	Bushing−Cylinder	2
39	69−5490	Hose−Cylinder	4
40	3256−56	Washer−Flat	3
41	340−77	Fitting−Hydraulic Elbow (Incl. Ref. #19 & 42)	4


* Not Illustrated



WING DECK LIFT ASM (Continued)

Ref. No.	Part No.	Description	No. Used
42	237−42	O−Ring	4
43	74−2170	Cylinder−Lift	2
44	323−15	Screw−HH	2
45	74−2680	Bracket−Bulkhead	1
46	69−6030	Tube−Hydraulic (Incl. Ref. #19)	1
47	69−6060	Tube−Hydraulic (Incl. Ref. #19)	1
48	69−6070	Tube−Hydraulic (Incl. Ref. #19)	1
49	69−6000	Tube−Hydraulic (Incl. Ref. #19)	1
50	69−6040	Tube−Hydraulic (Incl. Ref. #19)	1
51	69−6050	Tube−Hydraulic (Incl. Ref. #19)	1
52	69−6080	Tube−Hydraulic (Incl. Ref. #19)	1
53	69−5990	Tube−Hydraulic (Incl. Ref. #19)	1
54	69−4400	Carrier−Wing Deck	1
55	69−1580	Anchor−Latch LH	1
*	69−1600	Anchor−Latch RH	1
56	321−9	Screw−HH	3
57	56−7973	Clamp Half−Hydraulic Line	6
58	328−24	Screw−HH	4
59	39−7650	Plate−Cover	2
60	32144−11	Screw−Thread Forming	4
61	93−9922	Spacer	2
*	3290−378	Tie−Cable	3


* Not Illustrated



HYDRAULIC CYLINDER ASM NO. 74−2170

Ref. No.	Part No.	Description	No. Used
1	74−2230	Shaft/Clevis	1
2	74−2220	Collar	1
†3		Seal−Dust	1
4	74−2200	Head	1
†5		Ring−Back−Up	1
†6		O−Ring	1
†7		Seal−Uni−Ring	1
†8		Ring−Wear	1
9	74−2180	Ring−Steel	1
10	74−2190	Cushion	1
†11		Seal−Uni−Ring	1
12	74−2210	Piston	1
13	60−9760	Nut−Lock	1
†14		Ring−Wear	1
15	302−5	Fitting−Grease	2
†16		Barrel/Clevis	1
†17		Seal−Uni−Ring	1
18	95−1597	Bushing	1
*	86−7350	Kit−Seal Repair (Incl. Ref. #3, 5−8, 11, 14 & 17)	1


* Not Illustrated
†‡ Not Serviceable Separately



WING DECK LATCH ASM

Ref. No.	Part No.	Description	No. Used
1	32136–2	Nut–Castle	4
2	3272–12	Pin–Cotter	4
3	21–3001	Nut–Jam LH Thread	2
4	3220–22	Nut–Jam	4
5	69–7210	Tube–Latch	2
6	69–8480	Spring–Compression	2
7	69–9100	Washer–Latch	2
8	3296–41	Nut–Lock	2
9	71–2550	Washer–Latch Shaft	2
10	69–9680	Shaft–Latch	2
11	92–4804	Block–Latch Pivot	2
12	69–1630	Arm–Latch Pivot	4
13	92–4806	Pin–Latch	8

Ref. No.	Part No.	Description	No. Used
14	32120–47	Ring–Retaining	16
15	256–172	Bearing–Sleeve	8
16	92–4094	Roller–Latch	4
17	32121–49	Pin–Roll	2
18	302–5	Fitting–Grease	2
19	86–8100	Joint–Ball ((Incl. Ref. #1 & 18)	2
20	21–3000	Nut–Jam	2
21	92–4805	Cam–Spring Trip	2
22	86–8101	Joint–Ball (Incl. Ref. #1 & 23)	2
23	302–40	Fitting–Grease	2




T−0370−5

WING DECK LIFT ARM ASM

Ref. No.	Part No.	Description	No. Used
1	32128−32	Nut−HHF	4
2	74−2710	Clamp Half−Hydraulic Line	4
3	321−15	Screw−HH	4
4	302−2	Fitting−Grease	4
5	69−6470	Bushing−Flange	8
6	256−304	Washer−Thrust	8
7	32152−1	Nut−Lock	4
8	69−9300	Cushion−Rubber	2
9	32108−103	Screw−Machine Flat Hd.	4
10	93−9942	Arm−Outer Lift LH (Incl. Ref. #5)	1
*	93−9941	Arm−Outer Lift RH (Incl. Ref. #5)	1
11	71−2600	Tube−Anti−Sway	2
12	3220−7	Nut−Jam	4
13	2411−40	Joint−Ball	4
14	98−3311	Arm−Anti−Sway LH	1
*	98−3312	Arm−Anti−Sway RH	1
15	256−76	Bushing−Sleeve	4
16	69−9240	Roller−Cam	2

Ref. No.	Part No.	Description	No. Used
17	32121−34	Pin−Roll	2
18	69−9250	Shaft−Roller	2
19	3219−7	Nut−Lock	4
20	3253−9	Washer−Lock	4
21	32151−10	Ring−Retaining	2
22	302−5	Fitting−Grease	2
23	71−2620	Shaft−Lift Arm Elbow	2
24	32121−110	Pin Roll	4
25	93−9926	Asm−Lift Arm LH (Incl. Ref. #5)	1
*	93−9925	Asm−Lift Arm RH (Incl. Ref. #5)	1
26	3254−2	Washer	4
27	322−3	Screw−HH	4
28	93−9928	Clamp−Hose	2
30	93−9912	Grommet	2
31	74−2730	Tube−Clamp	4
32	94−6772	Retainer−Clamp	2
34	82−7900	Shaft−Arm	2
35	3256−22	Washer−Flat	4

* Not Illustrated




T−0335−5

WING DECK MODEL NO. 30591 LH & 30593 RH

Ref. No.	Part No.	Description	No. Used
1	98−7342	Arm−Inside Castor (Incl. Ref. #16 & 34)	2
2	3290−384	Pin−Lynch	8
3	325−20	Screw−HH	8
4	69−8790	Plate−Reinforcing	2
5	69−9700	Mount−Rubber (Incl. Ref. #6)	8
6		Spacer	8
7	32128−23	Nut−HHF	20
8	32128−45	Nut−HHF	8
9	30−8770	Washer−Flat	8
10	69−7170	Clevis−Deck	2
11	3233−29	Bolt−CARR	2
12	3233−28	Bolt−CARR	6
13	302−2	Fitting−Grease	2
14	3296−68	Nut−Lock	2
15	71−2610	Shaft−Deck Pivot	2
16	69−6470	Bushing−Flange	20
17	32121−110	Pin−Roll	2
18	98−1461	Asm−LH Lift Bar (Incl. Ref. #16)	1
*	98−1462	Asm−RH Lift Bar (Incl. Ref. #16)	1
19	98−7343	Arm−Outside Castor (Incl. Ref. #16, 34 & 38)	2
20	13−5009	Deck−Wing LH (Incl. Ref. #27, 36, 37 & 39)	1

Ref. No.	Part No.	Description	No. Used
*	13−4999	Deck−Wing RH (Incl. Ref. #27, 36, 37 & 39)	1
21	69−6730	Skid	4
22	3233−9	Bolt−CARR	12
23	323−15	Screw−HH	32
24	5−0838	Washer−Flat	32
25	32128−43	Nut−HHF	32
26	327−17	Screw HH	8
27	43−8480	Decal−Danger	2
27	93−7815	Decal−Danger (Europe)	2
28	93−4241	Spacer	8
29	93−4237	Bearing	16
30	93−4240	10” Wheel−Pneumatic (Incl. Ref. #28−29 & 42−47)	8
31	3296−53	Nut−Lock	8
32	98−7300	Fork−Castor	8
33	69−6860	Washer−Thrust	28
34	302−5	Fitting−Grease	8
35	69−1510	Spacer−Castor	48
36	95−0819	Decal−Belt Routing LH	1
*	95−0820	Decal−Belt Routing RH	1
37	66−1340	Decal−Danger	2
37	93−7824	Decal−Danger (Europe)	2
38	95−0818	Decal−Torque	2
39	67−5360	Decal−Danger	4
39	93−7273	Decal−Danger (Europe)	4
40	256−304	Washer−Thrust	4

* Not Illustrated




T−0335−5

WING DECK MODEL NO. 30591 LH & 30593 RH (Cont.)

Ref. No.	Part No.	Description	No. Used
42	93−4243	Tire−10”	8
43	93−5980	Hub	8
44	95−2741	Rim−Wheel	16
45	93−4244	Tube−w/Valve	8
46	93−4242	Plate	8
47	32128−16	Nut−HHF	32

Ref. No.	Part No.	Description	No. Used
48	93−7252	Decal−CE	2
49	32104−31	Screw−HH (Europe)	20
50	94−9822	Bar−Guard, Wing Inner (Europe)	2
51	94−9823	Bar−Guard, Wing RH & LH (Europe)	2




T−0346−4

WING DECK MODEL NO. 30591 LH & 30593 RH DRIVE ASM

Ref. No.	Part No.	Description	No. Used
1	69−6800	Cover−Inner LH	1
*	69−6820	Cover−Inner RH	1
2	3234−12	Screw−HWH	8
3	69−6360	Plate−Motor Mounting LH	1
*	69−6340	Plate−Motor Mounting RH	1
4	32128−21	Nut−HHF	12
5	237−81	O−Ring	4
6	340−8	Fitting−Hydraulic Straight (Incl. Ref. #5 & 7)	2
7	237−65	O−Ring	4
8	93−9918	Asm−Hose, Hydraulic	4
9	93−9917	Asm−Hose, Hydraulic	2
10	237−22	O−Ring	2
11	340−2	Fitting−Hydraulic Straight (Incl. Ref. # 10 & 12)	2
12	237−42	O−Ring	2
13	94−4907	Motor−Hydraulic	2
14	63−0660	Pulley−Wing Deck Drive	2
15	23−1640	Bushing−Taper Lock (Incl. Ref. #26)	2
16	69−6810	Cover−Outer LH	1

Ref. No.	Part No.	Description	No. Used
*	69−6830	Cover−Outer RH	1
17	3269−25	Rivet−Pop	16
18	69−6870	Plate−Magnet	8
19	3296−2	Nut−Lock	16
20	69−6260	Magnet−Cover	8
21	32105−1	Screw−PH	16
22	3233−30	Bolt−CARR	6
23	69−6960	Spacer−Idler	6
24	63−1540	Pulley−Idler	6
25	32128−23	Nut−HHF	6
26		Screw−Set	4
27	3231−28	Bolt−CARR	4
28	95−0845	Decal−Height of Cut	2
30	3296−29	Nut−Lock	4
31	3256−23	Washer−Flat	4
32	99−4442	Fitting	2
33	99−4443	Fitting	2
34	354−79	Cap−Dust	2
*	99−2318	V−Belt	6
*	3290−378	Tie−Cable	24

* Not Illustrated




T−2313−2

HYDRAULIC MOTOR ASM NO. 94−4907

Ref. No.	Part No.	Description	No. Used
1	33016−00	Nut−Hex.	4
2	33096−00	Washer−Flat	4
3	94−5391	Seal−Shaft	1
4	94−5390	Plate−Load	2
5		O−Ring	1
6		Ring−Retaining	1

Ref. No.	Part No.	Description	No. Used
7		Seal−Load	2
8	93−7637	Key−Square	1
9	99−5903	Stud	4
*	94−5392	Kit−Seal (Incl. Ref. #3 & 5−8)	1

* Not Illustrated




T−0337−2

SPINDLE ASM

Ref. No.	Part No.	Description	No. Used
1	302−2	Fitting−Grease Str.	1
*	302−10	Fitting−Grease 45° (Used only on wing deck center & inside spindles)	1
2	3296−49	Nut−Lock	1
3	3−8514	Washer	1
4	69−8390	Pulley−Spindle	1
5	253−154	Seal−Wave	2
6	71−2530	Asm−Bearing	1
7	3231−22	Bolt−CARR	6

Ref. No.	Part No.	Description	No. Used
8	69−1530	Housing−Spindle	1
9	32128−21	Nut−HHF	6
10	69−6760	Shaft−Spindle	1
11	92−9800	Spacer−Spindle	1
12	69−6920	Blade−20”	1
13	67−7561	Cup−Anti Scalp	1
14	3253−8	Washer−Lock	1
15	51−4060	Bolt−Blade	1
16	3256−24	Washer−Flat	A/R

* Not Illustrated



T−2441−2

10” & 13” FOAM FILLED TIRE ASSEMBLIES

Ref. No.	Part No.	Description	No. Used
†1		Plate	1
2	93−5973	Asm−10” Foam Filled Tire (Incl. Ref. #1, 3−7)	1
†3		Hub	1
4	93−4241	Spacer−Bearing, Inner	1
†5		Rim	2

Ref. No.	Part No.	Description	No. Used
†6		Nut−HHF	4
7	93−4237	Bearing	4
8	93−5630	Spacer−Bearing, Inner	1
†9		Rim	1
10	98−7329	Asm−12” Foam Filled Tire (Incl. Ref. #7−9)	1

† Not Serviceable Separately

TORO PART NUMBER INDEX

Part No.	Description	Pg. No.	Ref. No.	Qty.
3–2858	Disc–Friction	18	2	1
3–3710	Asm–Tie Rod	77	39	1
3–6498	Washer	86	34	1
3–6498	Washer–Flat	84	58	1
3–8514	Washer	96	3	1
3–8596	Spring–Compression	18	12	1
5–0838	Washer–Flat	70	14	6
5–0838	Washer–Flat	82	18	16
5–0838	Washer–Flat	92	24	32
5–0838	Washer–Flat	85	30	3
5–0838	Washer–Flat	86	40	3
5–3177	Washer–Flat	23	7	4
5–3637	Spacer–Terminal	22	4	1
12–8900	Bolt–Shoulder	36	32	2
13–4969	Deck–Center	83	41	1
13–4979	Asm–Right Wing Deck	86	18	1
13–4989	Deck–Left Wing	85	12	1
13–4999	Deck–Wing RH	92	*	1
13–5009	Deck–Wing LH	92	20	1
13–5069	Arm–Castor LH	82	31	1
18–2770	Strap–Ground	74	23	1
19–1470	Bolt–Shoulder	83	13	4
20–4360	Tube–Spacer	80	16	2
20–4840	Clamp–Muffler	71	8	2
20–4840	Clamp–Muffler	45	13	2
20–4840	Clamp–Tube	25	15	2
20–9500	Spacer	4	14	2
21–0141	Joint–Ball	9	20	1
21–1830	Spring–Extension	7	23	1
21–2070	Yoke–End	36	8	2
21–3000	Nut–Jam	90	20	2
21–3000	Nut–Jam	80	38	2
21–3001	Nut–Jam LH Thread	90	3	2
23–1640	Bushing–Taper Lock	94	15	2
23–1640	Bushing–Taper Lock	83	50	1
23–2140	Hose–Radiator Vent	44	7	1
23–2270	Bushing–Rubber	9	15	1
23–7250	Spacer	74	35	1
23–7270	Nut–Lug	77	24	10
25–2630	Ring Back Up	40	47	1
25–2630	Ring–Back Up	41	63	1
27–4720	Pin–Pivot, Seat	2	19	1
28–0380	Spacer	4	35	3
28–3580	Ring–Back Up	40	44	1
28–3590	O–Ring	40	43	1
29–6150	Spring–Leaf	37	43	1
29–6163	Switch–Micro	6	13	1
29–6170	Asm–Leaf Spring	37	38	1
30–8770	Washer–Flat	92	9	8
30–8770	Washer–Flat	82	32	4
31–0390	Washer–Friction	4	15	3
37–9560	Hose–Fuel	73	1	1
37–9560	Hose–Fuel	22	25	2
39–5710	Plug	2	13	21
39–7593	Temperature Sending Unit	24	15	1
39–7650	Plate–Cover	88	59	2
40–0330	Cushion–Rubber	85	4	1
40–0330	Cushion–Rubber	86	13	1
40–3890	Trim	2	14	2
40–4010	Roller	3	1	4
40–4060	Washer–Rubber	3	26	1
40–4070	Washer	3	24	3
40–4080	Track–U	3	6	1
40–4090	Rivet–Pop	3	5	2
40–4120	Plate–Rubber	3	7	1
40–4150	Roller	3	11	1
40–4160	Guide–Sleeve	3	12	1
40–4230	Plug	3	17	1
40–4310	Bearing–Thrust Needle	3	25	1
40–4340	Spring–Extension	3	28	1
40–4350	Spring–Extension	3	29	2
40–4360	Plate	3	30	1
40–4370	Bolt	3	31	1
40–4380	Bracket–Release	3	32	2
40–9520	Spacer–Split	85	3	2
40–9520	Spacer–Split	86	12	2
41–8760	Gasket–Pump	37	49	1
42–1720	Asm–Field Core Coil	9	5	1
42–6200	Shim–Cushion	85	*	A/R
42–6200	Shim–Cushion	86	*	A/R
42–7290	Gasket	50	8	1
42–7420	Cap–Filter, Oil	48	5	1
43–5130	Nut–Lock	79	14	1
43–6110	Plate–Clutch	9	9	1
43–6200	Spring–Compression	9	27	1
43–6280	Button	13	10	2
43–6280	Button	14	12	2
43–6320	Collar–Locking	9	10	1
43–6420	Bezel	13	11	2
43–6420	Bezel	14	13	2
43–8480	Decal–Danger	85	24	1
43–8480	Decal–Danger	92	27	2
43–8480	Decal–Danger	86	32	1
43–8480	Decal–Danger	83	40	1
44–2210	Body–Indicator Light	4	5	1
44–2210	Kit–Light	14	23	1
44–2212	Body–Indicator Light	4	12	2
46–1600	Spacer	4	26	4
46–3380	Bolt–Shoulder	44	23	2
46–6560	Bushing	22	21	1
47–6990	Nut–Hex.	4	9	1
48–7780	Screw–HH	2	15	2
48–8070	Washer–Lock	74	29	1
49–6170	Pad–Brake	7	4	1
49–6171	Pad–Brake Pedal LH	6	19	1
49–6172	Pad–Brake Pedal RH	6	*	1
51–3150	Shim–Spring	38	60	A/R
51–4060	Bolt–Blade	96	15	1
51–5060	Gasket	68	1	2
51–5060	Gasket	55	5	2
51–5070	Switch	45	56	1
51–5160	Washer	57	16	4
51–5210	Nut–Jam	47	5	8
51–5280	Cap	47	11	8
51–5320	Spring–Valve	47	15	8
51–5390	Packing–Connector	65	2	4
51–5390	Washer–Sealing	68	7	10
51–5460	Key–Woodruff	54	4	2
51–5460	Key–Woodruff	48	16	1
51–5470	Plate–Thrust	48	13	1
51–5840	Washer–Sealing	65	4	1
51–5840	Washer–Sealing	68	8	1
51–5970	Nut–Lock	50	1	2
51–5600	Cap–Sealing	49	4	10
51–8610	Washer–Spring	54	10	4
51–6230	Nut	53	9	8
51–6300	Pin–Dowel	54	6	2
51–6390	Washer–Spring	50	2	2
51–6390	Washer–Spring	56	22	1
51–7210	Gasket	69	7	1
51–7210	Gasket	57	8	1
51–7250	Washer–Spring	58	13	2
51–7250	Washer–Spring	55	27	8
51–7400	Washer–Spring	55	7	1
52–9230	Ring–Retaining	5	3	1
52–9240	Bushing–Gland Seal	5	4	1
52–9250	Kit–Needle Bearing	5	*	1
52–9260	Screw–Set	5	1	1
52–9270	Seat–Check Ball	5	24	1
52–9280	Ball–Check	5	22	1
52–9290	Retainer–Check Ball	5	21	1
52–9320	Drive	5	15	1
54–8660	Washer	66	5	1
56–0100	Plug–Taper	49	7	1
56–0750	Clamp (B)	58	19	3
56–0760	Clamp (A)	58	20	3
56–7971	Clamp Half–Hydraulic Line	30	26	2
56–7972	Clamp Half–Hydraulic Line	30	20	4

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. No.	Ref. No.	Qty.
56−7973	Clamp Half−Hydraulic Line	30	19	20
56−7973	Clamp Half−Hydraulic Line	28	44	4
56−7973	Clamp Half−Hydraulic Line	88	57	6
56−7974	Clamp Half−Hydraulic Line	87	2	2
56−7974	Clamp Half−Hydraulic Line	30	17	2
56−7974	Clamp−Hydraulic Lines	74	31	2
56−7978	Clamp Half−Hydraulic Line	30	25	12
56−7978	Clamp Half−Hydraulic Line	24	42	6
58−4250	Magnet	42	1	6
58−5620	Tube−Inner	32	*	2
58−6290	Asm−Poppet	20	34	3
58−6310	Spacer	20	28	3
58−6320	Wiper−Seal	20	24	3
58−6330	Asm−Seat	20	35	3
58−6340	O−Ring	20	36	3
58−6350	Asm−Plug	20	11	3
58−6370	Washer−Back−Up	20	10	6
58−6400	Bushing	20	25	3
58−6420	Asm−Cap	20	30	3
58−6440	Poppet	20	22	1
58−6450	O−Ring	20	12	6
58−6460	Ring−Retaining	20	29	3
58−6470	Washer	20	18	A/R
58−6480	Washer	20	19	A/R
58−6490	Washer	20	20	A/R
58−6700	Washer	20	26	3
58−6710	Asm−Plug	20	6	1
58−6720	O−Ring	20	7	1
58−6730	Spring	20	27	3
58−6750	O−Ring	20	17	1
58−6760	Spring	20	3	3
58−6770	Plunger−Detent	20	4	3
58−6780	Asm−Plug	20	1	3
58−6790	O−Ring	20	5	3
59−6730	Race−Bearing	5	7	2
59−6740	Bearing−Needle Thrust	5	8	1
59−6820	Kit−Centering Spring	5	11	1
59−6830	Kit−Centering Pin	5	20	1
59−7580	Nut−Hex.	26	24	8
59−7590	Washer−Lock	26	12	16
59−7970	Stud−Threaded	26	23	8
59−7990	Seal−Gland	26	3	4
59−8470	Retainer−Seal	26	4	4
59−8500	Gear/Shaft−Front Drive	26	17	1
59−8570	Seal−Shaft	26	22	1
59−8580	Ring−Retaining	26	21	1
59−8590	Seal−Shaft	26	20	1
59−8600	Gear−Driven	26	9	2
59−8610	Kit−Repair	26	*	1
60−3780	Kit−Seal	20	*	1
60−3810	Shaft−Input	35	2	1
60−3830	Seal−Oil	35	4	1
60−3840	Cone−Bearing	35	5	1
60−3850	Cup−Bearing	35	6	2
60−3860	Bolt−Wheel	35	7	9
60−3870	Hub	35	8	1
60−3880	Cone−Bearing	35	9	1
60−3890	Bolt−HH	35	10	6
60−3900	Gear−Ring	35	24	1
60−3910	Washer−Flat	35	11	6
60−3930	Ring−Retaining	35	25	2
60−3940	Washer	35	26	2
60−3950	Spring−Disengage	35	27	1
60−3960	Asm−Primary Carrier	35	15	1
60−3970	Gear−Primary Sun	35	13	1
60−3980	Washer−Thrust	35	12	1
60−3990	Washer−Thrust	35	23	1
60−4000	Asm−Secondary Carrier	35	20	1
60−4010	Plunger−Disengage	35	22	1
60−4020	O−Ring	35	21	1
60−4030	Bolt−HH	35	17	8
60−4040	Plug−Pipe	35	16	1
60−4050	Cover−Large	35	19	1
60−4060	Cover−Disengage	35	18	1
60−4070	Bolt−HH	35	14	2
60−5720	O−Ring	20	9	6
60−6450	Disc	20	2	A/R
60−7120	Nut	58	14	1
60−7120	Nut	55	31	8
60−7280	Bolt	58	15	1
60−7290	Bolt	5	51	1
60−7420	Cotter−Valve	47	12	16
60−7430	Seal−Oil	50	6	1
60−9760	Nut−Lock	81	11	1
60−9760	Nut−Lock	89	13	1
60−9770	Piston	81	10	1
61−2790	Filler−Screen	23	34	1
61−4990	Ring−Retaining	81	3	1
62−5550	Decal	4	47	1
62−6450	Kit−Retaining Ring	35	28	1
62−6460	Sealant−RTV (Tube)	35	*	1
62−7650	Gasket−Level Sensing Unit	22	1	1
63−0660	Pulley−Drive	83	51	1
63−0660	Pulley−Wing Deck Drive	94	14	2
63−1540	Pulley−Idler	83	15	3
63−1540	Pulley−Idler	94	24	6
63−7430	Gauge−Temperature	13	8	1
63−8280	Head−Fuel Filter	73	4	1
63−8290	Vent−Air	73	5	1
63−8310	Valve−Drain	73	8	1
63−8360	Key−Ignition	14	11	1
66−1340	Decal−Danger	85	23	1
66−1340	Decal−Danger	86	33	1
66−1340	Decal−Danger	92	37	2
66−1340	Decal−Danger	84	60	1
66−2490	Hold−Down−Battery	74	16	2
66−2940	Gauge−Fuel	13	25	1
66−2950	Hourmeter	13	26	1
66−3241	Cap−Radiator	44	5	1
66−5310	Pulley−Idler	70	24	1
66−6140	Decal−TORO	43	27	1
66−8530	Track−Adjustment	2	3	1
66−8800	Relay	74	19	2
67−2520	Plug−Drain	50	9	1
67−4510	Gauge Unit	45	55	1
67−4660	Bolt−Flange	66	4	1
67−5360	Decal−Danger	85	25	1
67−5360	Decal−Danger	86	31	1
67−5360	Decal−Danger	92	39	4
67−7160	Block−Fuse	11	24	4
67−7561	Cup−Anti Scalp	96	13	1
68−6150	Breather	44	50	1
68−6420	Plug−Drain	52	9	1
68−6430	Gasket	69	4	1
68−6430	Gasket	52	8	1
68−7571	Strip−Sealing	23	24	1
68−7572	Strip−Sealing	22	18	1
68−8080	Wheel−Steering	4	10	1
69−0030	Spring−Compression	36	30	2
69−0040	Foam−Lower Grille	42	20	1
69−0090	Pin−Clevis Engine End	18	*	1
69−0090	Pin−Throttle	45	51	1
69−0100	Asm−Frame	28	49	1
69−0760	Bracket−Arm Rest LH	1	*	1
69−0770	Bracket−Arm Rest RH	1	9	1
69−0940	Decal−Caution	30	39	1
69−0950	Decal−580D	43	26	2
69−1170	Gauge−Sight	23	2	1
69−1180	Armrest	1	11	2
69−1380	Panel−Side RH	43	*	1
69−1390	Panel−Side LH	43	12	1
69−1510	Spacer−Caster	82	2	12
69−1510	Spacer−Castor	92	35	48
69−1530	Housing−Spindle	96	8	1
69−1540	Pivot−Spring	80	34	1
69−1560	Lever−Lock	4	1	1
69−1580	Anchor−Latch LH	88	55	1
69−1600	Anchor−Latch RH	88	*	1

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. No.	Ref. No.	Qty.
69–1610	Adapter–Suction Hose	23	8	1
69–1630	Arm–Latch Pivot	90	12	4
69–1650	Screen–Suction	23	17	1
69–1670	Cooler–Oil	44	32	1
69–1700	Asm–Hydraulic Filter	24	19	1
69–1710	Indicator–Filter	24	25	1
69–1720	Element–Filter	24	21	1
69–1730	Asm–Planetary Gear Drive	32	32	2
69–1740	Spindle	35	3	1
69–1750	Asm–Fuel Filter	73	*	1
69–1760	Sensor–Water	73	9	1
69–1770	Element–Spin–On	73	11	1
69–1780	Asm–Lift Valve	19	2	1
69–1790	Plunger	20	37	2
69–1800	Asm–Plug	20	32	3
69–1810	Spring	20	33	3
69–1820	Spring–Black	20	21	1
69–1830	Asm–Plug	20	16	1
69–1840	Plunger	20	31	1
69–1860	Gerotor	5	16	1
69–1880	Spacer	5	17	1
69–1940	Indicator–Electrical	71	27	1
69–1980	Nut–Jam	79	16	1
69–2050	Asm–Hydraulic Pump	25	8	1
69–2050	Pump–Gear, Double	45	8	1
69–2060	Asm–Shaft End Cover	26	18	1
69–2070	Plate–Flex	26	5	4
69–2080	Asm–Center Section	26	7	2
69–2090	Gear/Shaft–Rear Drive	26	8	1
69–2100	Asm–Rear Cover	26	11	1
69–2110	Coupling	26	1	1
69–2120	O–Ring	26	10	2
69–2130	Plug	26	19	1
69–2140	Screw–HH	26	14	4
69–2150	Screw–HH	26	13	4
69–2160	Asm–Port Section	26	16	1
69–2170	Asm–Adapter Section	26	2	1
69–2200	O–Ring	26	6	2
69–2210	O–Ring	26	15	1
69–2220	Pump/Valve	37	52	1
69–2230	Asm–Flow Divider	39	30	1
69–2240	Screw	39	32	4
69–2250	Bearing–Sleeve	39	20	4
69–2260	Seal–Load	39	17	1
69–2270	Seal–Pre–Load	39	18	1
69–2280	Shaft/Gear–Idler	39	15	1
69–2290	Shaft/Gear–Drive	39	28	1
69–2300	Ring–Retaining	39	26	1
69–2310	Seal–Shaft	39	27	1
69–2320	Plate–Wear	39	16	1
69–2330	Asm–Body	39	21	1
69–2340	Pin–Dowel	39	14	2
69–2350	Ring–Sealing	39	19	1
69–2360	Screw	39	23	4
69–2370	Washer	39	22	4
69–2380	Screw	39	24	4
69–2390	Washer	39	25	4
69–2400	O–Ring	39	29	1
69–2410	Plug	39	1	2
69–2420	O–Ring	39	2	2
69–2430	Spring–Compression	39	5	1
69–2440	Orifice	39	4	1
69–2450	Piston	39	3	1
69–2460	Cap	39	6	1
69–2470	Gasket–Cap	39	7	1
69–2480	Screw–Set	39	8	1
69–2490	Spring–Compression	39	9	1
69–2500	Poppet	39	10	1
69–2510	Seat	39	11	1
69–2520	Plug–Pipe	39	31	1
69–2530	O–Ring	39	12	1
69–2540	Asm–Cover	39	13	1
69–2550	Kit–Repair, Pump	39	*	1
69–2560	Kit–Repair, Pump & Divider	39	*	1
69–2570	Head	81	4	1
69–2580	Shaft w/clevis	81	1	1
69–2640	Asm–Master Cylinder	7	9	1
69–2650	Boot–Rod	8	1	1
69–2660	Ring–Retaining	8	2	1
69–2730	Asm–Piston	8	*	1
69–2740	Bail–Cover	8	12	1
69–2750	Cover–Reservoir	8	9	1
69–2760	Gasket–Diaphragm	8	10	1
69–2770	Seat–Tube	8	11	1
69–2960	Hub–Rear Wheel	77	19	2
69–2970	Cap–Hub	77	27	2
69–2980	Seal–Inner	77	32	2
69–2990	Screw–Drive	77	18	10
69–3010	Strap–Hold Down	43	6	4
69–3020	Handle–Latch	42	16	2
69–3020	Latch	44	20	8
69–3030	Strike–Latch	42	13	8
69–3050	Motor–Hydraulic Wheel	32	44	2
69–3070	Washer–Lock	41	62	10
69–3070	Washer–Plain	34	2	10
69–3080	Plug	41	60	4
69–3120	Plug	41	95	1
69–3130	Plug	40	9	1
69–3130	Plug–Hole	34	33	1
69–3140	Bracket–Lifting	41	58	1
69–3150	Screw–HH	34	1	10
69–3150	Screw–HH	41	61	10
69–3170	Ring–Retaining	34	19	2
69–3170	Ring–Retaining	40	31	2
69–3180	Shaft Pump	40	37	1
69–3190	Seal–Lip	34	18	1
69–3190	Seal–Lip	40	30	1
69–3200	Ring–Retaining	34	17	2
69–3200	Ring–Retaining	40	29	2
69–3210	Bearing–Ball	34	20	1
69–3210	Bearing–Ball	40	32	1
69–3220	Screw	40	28	1
69–3230	Pin–Spring	40	12	1
69–3230	Pin–Spring	34	32	1
69–3240	Bearing–Journal	40	25	2
69–3250	Swashplate–Variable	40	24	1
69–3370	Bearing–Needle	40	13	1
69–3370	Bearing–Needle	34	31	1
69–3390	Asm–Gerotor	41	89	1
69–3400	Screw–HH	41	83	3
69–3410	Adapter–A Flange	41	85	1
69–3420	Ring–Temper Load	41	86	1
69–3430	Key–Woodruff	41	84	1
69–3440	O–Ring	41	87	1
69–3450	Pin	34	30	1
69–3450	Pin	40	41	1
69–3460	Plug Expansion	41	80	1
69–3470	Pin	40	36	1
69–3500	Bearing–Sleeve	34	13	1
69–3500	Sleeve–Bearing	40	34	1
69–3510	Pin	34	14	1
69–3510	Pin	40	35	1
69–3520	Pin–Spring	34	23	2
69–3540	Cover–Gerotor	41	88	1
69–3550	Pin	41	81	1
69–3560	O–Ring	34	38	2
69–3560	O–Ring	41	55	2
69–3570	Ring–Piston	34	39	2
69–3570	Ring–Piston	41	56	2
69–3580	Guide–Spring	40	8	1
69–3590	Ring–Retaining	40	7	1
69–3600	Nut–Hex.	40	6	1
69–3610	Nut–Jam	40	5	1
69–3620	Cover–Servo Adjustment	40	1	1
69–3630	Nut Special	40	2	1
69–3640	Cover–Servo	40	3	1
69–3650	Piston–Servo	40	53	1
69–3660	Screw–Special	41	91	1

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. No.	Ref. No.	Qty.
69–3670	Spring–Compression	41	93	1
69–3680	Stop–Servo	41	92	1
69–3690	Bearing	41	54	2
69–3700	Guide–Spring	41	90	1
69–3710	Gasket–Servo	40	4	2
69–3710	Gasket–Servo Cover	34	41	2
69–3720	Cover Servo	41	57	1
69–3720	Cover–Servo	34	43	2
69–3730	Valve–Relief	41	78	2
69–3740	Spring–Compression	41	72	2
69–3750	O–Ring	41	77	2
69–3760	Plug–Special	41	71	2
69–3770	Shim	41	69	1
69–3780	Plug	41	67	1
69–3790	Spring Compression	41	70	1
69–3800	Valve	41	65	1
69–3810	Valve–By Pass	41	66	1
69–3820	Sleeve–Control Valve	40	42	1
69–3830	Spool–Rotary Valve	40	46	1
69–3840	O–Ring	40	52	1
69–3860	Screw–HFH	40	49	1
69–3870	Handle–Control Valve	40	50	1
69–3880	Spring–Neutral Return	40	45	1
69–3890	Bracket–Neutral Return	40	48	1
69–3900	Washer	40	51	1
69–3910	Asm–Cylinder Block	40	39	1
69–3910	Kit–Cylinder Block	34	27	1
69–3920	Kit–Piston Ring & O–Ring	34	*	1
69–3940	Plug	34	29	1
69–3950	Shaft–Motor	34	25	1
69–3960	Screw	34	21	1
69–3970	Bearing–Journal	34	22	2
69–3980	Swashplate–Variable	34	24	1
69–3990	Plate–Motor Valve	34	28	1
69–4020	Piston–Servo	34	37	1
69–4030	Spring–Servo	34	40	1
69–4040	Stop–Servo Piston	34	42	1
69–4070	Manifold–Counter Balance	21	14	1
69–4130	Plug–Orifice .047mm	21	39	2
69–4140	Plug–Orifice .120mm	21	38	1
69–4220	Plug–Orifice	76	47	1
69–4280	Tube–Hydraulic Vent	23	33	1
69–4320	Fitting–Hydraulic 90°	83	8	1
69–4400	Carrier–Wing Deck	88	54	1
69–4780	Clamp–Gauge	13	23	2
69–5410	Manifold–Return	24	10	1
69–5430	Pulley–Idler	86	7	1
69–5430	Pulley–Idler	83	25	1
69–5440	Hose–Hydraulic	80	12	3
69–5440	Hose–Hydraulic	24	30	1
69–5440	Hose–Hydraulic	38	58	1
69–5450	Hose–Hydraulic	38	56	1
69–5460	Hose–Hydraulic	24	14	1
69–5460	Hose–Hydraulic	37	18	1
69–5470	Hose–Hydraulic	27	16	1
69–5470	Hose–Hydraulic	38	57	1
69–5480	Hose–Hydraulic	27	17	1
69–5480	Hose–Hydraulic	38	59	1
69–5490	Hose–Cylinder	87	39	4
69–5500	Hose–Hydraulic	4	33	4
69–5510	Hose–Hydraulic	77	1	4
69–5600	Hose–Hydraulic	75	9	1
69–5610	Hose–Hydraulic	75	17	1
69–5620	Hose–Hydraulic	44	29	1
69–5640	Hose–Hydraulic	25	12	2
69–5640	Hose–Suction	45	11	3
69–5640	Hose–Suction	23	12	1
69–5650	Hose–Hydraulic	24	18	1
69–5650	Hose–Hydraulic	37	22	1
69–5670	Cable–Brake	6	22	2
69–5680	Tube–Hydraulic	21	9	1
69–5680	Tube–Hydraulic	19	20	1
69–5700	Tube–Hydraulic	19	18	1
69–5710	Tube–Hydraulic	21	20	1
69–5720	Tube–Hydraulic	19	17	1
69–5730	Tube–Hydraulic	21	33	1
69–5740	Tube–Hydraulic	19	19	1
69–5790	Tube–Hydraulic	27	37	1
69–5800	Tube–Hydraulic	23	20	1
69–5800	Tube–Hydraulic	30	28	1
69–5810	Tube–Hydraulic Return	28	*	1
69–5820	Tube–Hydraulic	21	31	1
69–5830	Tube–Hydraulic	21	32	1
69–5850	Tube–Hydraulic	21	18	1
69–5860	Tube–Hydraulic	19	16	1
69–5860	Tube–Hydraulic	21	34	1
69–5870	Tube–Hydraulic	19	22	1
69–5870	Tube–Hydraulic	21	28	1
69–5890	Tube–Hydraulic	21	5	1
69–5890	Tube–Hydraulic	19	21	1
69–5900	Tube–Hydraulic	44	31	1
69–5910	Tube–Hyd. Diagnostic	29	6	1
69–5910	Tube–Hydraulic	21	19	1
69–5920	Tube–Diagnostic	29	8	1
69–5920	Tube–Hydraulic	21	37	1
69–5930	Tube–Hydraulic RH	32	*	1
69–5940	Tube–Hydraulic LH	32	2	1
69–5950	Tube–Hydraulic	24	32	1
69–5950	Tube–Hydraulic	28	57	1
69–5970	Tube–Hydraulic RH	87	*	1
69–5980	Tube–Hydraulic LH	87	21	1
69–5990	Tube–Hydraulic	24	12	1
69–5990	Tube–Hydraulic	88	53	1
69–6000	Tube–Hydraulic	24	11	1
69–6000	Tube–Hydraulic	88	49	1
69–6010	Tube–Hydraulic	78	50	1
69–6020	Tube–Hydraulic	78	51	1
69–6030	Tube–Hydraulic	27	35	1
69–6030	Tube–Hydraulic	88	46	1
69–6040	Tube–Hydraulic	27	34	1
69–6040	Tube–Hydraulic	88	50	1
69–6050	Tube–Hydraulic	27	33	1
69–6050	Tube–Hydraulic	88	51	1
69–6060	Tube–Hydraulic	27	38	1
69–6060	Tube–Hydraulic	88	47	1
69–6070	Tube–Hydraulic	30	36	1
69–6070	Tube–Hydraulic	88	48	1
69–6080	Tube–Hydraulic	30	35	1
69–6080	Tube–Hydraulic	88	52	1
69–6100	Tube–Hydraulic Pressure	28	50	1
69–6140	Tube–Hydraulic	75	45	1
69–6140	Tube–Hydraulic RH	87	*	1
69–6150	Tube–Hydraulic	75	46	1
69–6150	Tube–Hydraulic RH	87	*	1
69–6160	Tube–Hydraulic	75	11	1
69–6170	Tube–Hydraulic	75	21	1
69–6170	Tube–Hydraulic LH	87	6	1
69–6180	Tube–Hydraulic	75	20	1
69–6180	Tube–Hydraulic LH	87	22	1
69–6190	Tube–Hydraulic	27	23	1
69–6200	Tube–Hydraulic	27	22	1
69–6260	Magnet	11	6	1
69–6260	Magnet–Cover	85	15	2
69–6260	Magnet–Cover	86	15	2
69–6260	Magnet–Cover	94	20	8
69–6260	Magnet–Cover	83	32	4
69–6340	Plate–Motor Mounting RH	94	*	1
69–6360	Plate–Motor Mounting LH	94	3	1
69–6390	Plate–Gearbox	84	52	1
69–6470	Bushing–Flange	91	5	8
69–6470	Bushing–Flange	77	6	6
69–6470	Bushing–Flange	92	16	20
69–6470	Bushing–Flange	82	26	4
69–6470	Bushing–Flange	80	29	4
69–6470	Bushing–Flange	87	30	4
69–6550	Arm–Tension	83	38	1
69–6610	Arm–Idler	83	23	1
69–6610	Asm–Idler Arm	86	27	1

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. No.	Ref. No.	Qty.
69–6640	Hinge–Left Front	85	13	1
69–6670	Hinge–Left Rear	85	17	1
69–6690	Hinge–Right Front	86	28	1
69–6710	Hinge–Right Rear	86	23	1
69–6730	Skid	85	7	1
69–6730	Skid	92	21	4
69–6730	Skid	86	29	1
69–6760	Shaft–Spindle	96	10	1
69–6780	Cover–Center Left	83	30	1
69–6790	Cover–Center Right	84	54	1
69–6800	Cover–Inner LH	94	1	1
69–6810	Cover–Outer LH	94	16	1
69–6820	Cover–Inner RH	94	*	1
69–6830	Cover–Outer RH	94	*	1
69–6840	Cover–Right Wing	86	2	1
69–6850	Cover–Left Wing	85	22	1
69–6860	Washer–Castor	82	25	8
69–6860	Washer–Thrust	92	33	28
69–6870	Plate–Magnet	86	3	2
69–6870	Plate–Magnet	94	18	8
69–6870	Plate–Magnet	85	21	2
69–6870	Plate–Magnet	83	31	4
69–6900	Shaft–Hinge	85	14	1
69–6900	Shaft–Hinge	86	20	1
69–6920	Blade–20”	96	12	1
69–6960	Spacer–Idler	83	14	4
69–6960	Spacer–Idler	94	23	6
69–6970	Spacer–Idler	86	17	1
69–6970	Spacer–Idler	83	26	1
69–6980	Valve–Check	4	38	1
69–6990	Lever–Valve Mid.	19	*	1
69–7000	Lever–Valve RH	19	*	1
69–7010	Lever–Valve LH	19	5	1
69–7040	Holder–Cup	11	13	1
69–7100	Support–Radiator Lower	44	24	1
69–7120	Grille–Upper	42	27	1
69–7150	Grille–Lower	42	23	1
69–7170	Clevis–Deck	92	10	2
69–7210	Tube–Latch	90	5	2
69–7290	Mount–Ball Joint	82	5	2
69–7420	Axle–Rear	77	16	1
69–7650	Pedal–Traction	9	24	1
69–7700	Pedal–Brake	7	3	1
69–7700	Pedal–Brake	6	20	2
69–7720	Pawl–Brake	6	7	1
69–7740	Support–Steering Gear	4	21	1
69–7760	Link–Steering Gear	4	19	1
69–7790	Pin–Brake Arm	6	11	1
69–7810	Bracket–Valve	19	11	1
69–7840	Mount–Brake Arm	6	16	1
69–7880	Arm–Brake LH	6	23	1
69–7890	Arm–Brake RH	6	2	1
69–7920	Support–Lift Arm LH	80	27	2
69–7940	Support–Lift Arm RH	80	4	2
69–7960	Support–Axle	77	12	2
69–8040	Arm–Throttle	18	4	1
69–8080	Cover–Tool Box	10	3	1
69–8110	Box–Tool	10	5	1
69–8160	Tower–Steering	4	31	1
69–8210	Support–Cover	11	26	1
69–8230	Bracket–Trim LH	43	17	1
69–8250	Bracket–Trim R.H	43	20	1
69–8290	Frame–Battery	74	33	1
69–8390	Pulley–Spindle	96	4	1
69–8440	Hose–Hydraulic	80	9	1
69–8440	Hose–Hydraulic	24	31	1
69–8450	Hose–Hydraulic	44	30	1
69–8470	Spring–Torsion	80	32	1
69–8480	Spring–Compression	90	6	2
69–8490	Bracket–Throttle Cable	45	30	1
69–8500	Shim–Hinge Bracket	43	21	6
69–8510	Cover–Steering Tower	4	41	1
69–8590	Support–Radiator Upper	44	2	1
69–8690	Support–Grille	42	15	1
69–8750	Arm–Brake	7	1	1
69–8790	Plate–Reinforcing	82	4	2
69–8790	Plate–Reinforcing	92	4	2
69–8860	Arm–Castor RH	82	7	1
69–8890	Cap–Spindle	77	13	2
69–8900	Spacer	28	52	2
69–8910	Washer	36	3	2
69–8910	Washer	28	51	4
69–8920	Washer	30	4	4
69–8930	Washer	27	26	4
69–8940	Washer	27	5	12
69–8940	Washer	87	16	20
69–8950	Spacer	30	5	2
69–8960	Spacer	27	27	2
69–8970	Spacer	87	17	10
69–8970	Spacer	27	31	6
69–8980	Washer	30	30	8
69–8990	Spacer	30	33	4
69–9000	Spacer	87	9	4
69–9010	Washer	87	10	8
69–9020	Nut–Special	37	26	1
69–9030	Post–Neutral Device	9	14	1
69–9040	Cam–Neutral Device	37	31	1
69–9050	Bar–Neutral Device	37	45	1
69–9100	Washer–Latch	90	7	2
69–9120	Rod–Hood Prop	74	5	1
69–9130	Bracket–Throttle	18	11	1
69–9140	Link–Valve Lever	19	6	3
69–9150	Shaft–Valve Lever	19	9	1
69–9180	Pin–Cylinder	80	17	2
69–9190	Bushing–Cylinder	87	38	2
69–9200	Pin–Brake Pawl	6	8	1
69–9210	Lever–Brake Latch	6	4	1
69–9220	Bracket–Suction Tube	45	16	2
69–9220	Support–Tube Clamp	25	17	2
69–9230	Shaft–Steering Pivot	4	2	1
69–9240	Roller–Cam	91	16	2
69–9250	Shaft–Roller	91	18	2
69–9260	Pin–Clevis	82	29	2
69–9290	Pad–Bumper	83	17	2
69–9300	Cushion–Rubber	91	8	2
69–9300	Cushion–Rubber	87	34	2
69–9300	Cushion–Rubber	28	41	2
69–9310	Plate–Lever	14	20	1
69–9330	Cover	30	1	1
69–9340	Rod–Brake	7	15	1
69–9350	Bracket–Hood Prop Rod	74	2	1
69–9390	Shaft–Pedal	9	11	1
69–9420	Muffler–Exhaust	71	7	7
69–9430	Foam–Tool Box	10	4	1
69–9440	Panel–Steering Tower	4	4	1
69–9450	Bracket–Wing Hose LH	87	7	1
69–9460	Bracket–Wing Hose RH	87	*	1
69–9470	Cover–Access	28	63	1
69–9480	Bracket–Neutral Device	37	28	1
69–9520	Panel–Rear	43	9	1
69–9540	Bracket–Steering Gear	4	18	1
69–9560	Housing–Control	11	1	1
69–9570	Asm–Front Lift Arm, RH	80	43	1
69–9580	Asm–Front Lift Arm, LH	80	39	1
69–9650	Screen–Cowl	42	9	2
69–9680	Shaft–Latch	90	10	2
69–9700	Mount–Rubber	92	5	8
69–9710	Nut–Lock	71	6	3
69–9720	Strip–Sealing	42	28	2
69–9721	Strip–Sealing	42	18	3
69–9722	Trim–Sealing	42	35	1
69–9723	Seal–Hood Bottom	43	15	2
69–9724	Seal–Hood Front	43	29	1
69–9730	Switch–Toggle	14	18	1
69–9740	Switch–Toggle	14	14	1
69–9760	Plate–Cover	30	10	3
69–9761	Plate–Clamp	74	36	1
69–9761	Plate–Cover	87	13	1

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. No.	Ref. No.	Qty.
69−9761	Plate−Cover	30	14	5
69−9761	Plate−Cover	24	43	3
69−9800	Tire	32	28	2
69−9810	Joint−Ball	79	2	1
69−9880	Tire	77	22	2
69−9940	Nut−Jam	32	40	4
69−9950	Spring−Extension	32	37	4
69−9960	Link	32	36	4
69−9970	Stud	32	35	4
69−9980	Ball	32	39	6
69−9990	Disc−Actuating	32	38	4
70−2880	Bolt	54	9	4
70−3000	Pin−Dowel	49	13	2
70−3090	Clamp−Hose	55	16	2
70−3240	Plug−Air	65	3	1
70−3250	Bolt−Connector	65	1	2
70−3370	Cap−Sealing	49	5	6
70−3440	Clamp	55	13	1
70−3480	Stud	55	35	4
70−3530	Gasket−Valve	60	10	4
70−3560	Pinion−Control	61	39	4
70−3570	Screw−Clamp, Pinion	60	31	4
70−3610	Sheet−Spring, Lower	61	35	4
70−3630	Tappet	61	33	4
70−3670	Plug−Screw	61	34	4
70−3680	Camshaft	61	40	1
70−3690	Ring−Adjusting	60	22	1
70−3700	Ring−Adjust	60	3	1
70−3710	Shim−0.10mm Thick	60	20	AR
70−3720	Shim−0.12mm Thick	60	20	AR
70−3730	Shim−0.14mm Thick	60	20	AR
70−3740	Shim−0.16mm Thick	60	20	AR
70−3750	Shim−0.18mm Thick	60	20	AR
70−3760	Shim−0.50mm Thick	60	20	AR
70−3770	Shim−0.30mm Thick	60	20	AR
70−3780	Shim−0.10mm Thick	60	2	AR
70−3790	Shim−0.15mm Thick	60	2	AR
70−3800	Shim−0.30mm Thick	60	2	AR
70−3810	Shim−0.50mm Thick	60	2	AR
70−3820	Cover−Bearing	61	42	1
70−3860	Washer−Union	60	16	2
70−3870	Washer−Union	60	5	2
70−3880	Plate−Set	60	15	2
70−3890	Washer−Nipple	62	16	2
70−3900	Packing	60	23	2
70−3910	Washer−Nipple	60	26	2
70−3930	Gasket−Plate, Cover	60	19	1
70−3940	Cover−Plate	61	44	1
70−3950	Screw	60	24	2
70−3970	Shim−0.60mm Thick	60	32	AR
70−3980	Shim−0.70mm Thick	60	32	AR
70−3990	Shim−0.80mm Thick	61	32	AR
70−4000	Shim−0.90mm Thick	61	32	AR
70−4010	Shim−1.00mm Thick	61	32	AR
70−4020	Shim−1.10mm Thick	61	32	AR
70−4030	Shim−1.20mm Thick	61	32	AR
70−4040	Shim−1.30mm Thick	61	32	AR
70−4050	Shim−1.40mm Thick	61	32	AR
70−4060	Shim−0.10mm Thick	61	32	AR
70−4070	Shim−0.20mm Thick	61	32	AR
70−4080	Shim−0.30mm Thick	61	32	AR
70−4090	Shim−0.40mm Thick	61	32	AR
70−4100	Shim−0.50mm Thick	61	32	AR
70−4110	Shim−0.15mm Thick	61	32	AR
70−4170	Asm−Flyweight	62	47	1
70−4180	Nut−Round	62	45	1
70−4190	Sleeve−Governor	62	44	1
70−4200	Plate	62	43	1
70−4210	Plate	63	56	1
70−4230	Bushing−Lever	62	9	2
70−4310	Nut−Lock, Adapter	62	17	1
70−4320	Asm−Control, Tension	62	39	1
70−4330	Bushing	62	25	1
70−4340	Shackle	63	61	1
70−4350	Shaft−Lever	62	12	1
70−4360	Plug−Screw	62	11	2
70−4370	Spring−Control	62	38	1
70−4380	Spring−Start	63	60	1
70−4390	Screw−Adjusting	63	67	1
70−4400	Cover−Governor	62	13	1
70−4410	Pin−Stop	63	66	1
70−4430	Screw−Adjusting	62	27	1
70−4440	Nut−Cap	62	18	1
70−4460	Plate−Cap	62	7	1
70−4470	Lever−Support	62	2	1
70−4480	Shaft−Governor	62	1	1
70−4490	Cup−Spring	62	3	1
70−4500	Spring	62	6	1
70−4510	Spring	62	4	1
70−4520	Spring	62	5	1
70−4530	Cover−Spring	62	34	1
70−4540	Slider−Supporting	62	40	1
70−4570	Lever−Stop	62	35	1
70−4580	Cap−Lever	62	10	1
70−4590	Plug−Screw	63	55	1
70−4600	Asm−Housing	64	18	1
70−4610	Valve−Check	64	5	2
70−4620	Spring−Valve	64	6	2
70−4630	Gasket−Plug	64	7	2
70−4640	Support−Valve	64	8	1
70−4650	Pump−Priming	64	11	1
70−4730	Tappet−Feed Pump	64	13	1
70−4740	Roller−Tappet	64	14	1
70−4750	Pin−Roller	64	16	1
70−4760	Block−Sliding	64	12	2
70−4770	Spring−Piston	64	3	1
70−4780	Plug−Chamber	64	1	1
70−4790	Filter−Fuel	64	19	1
70−4800	Screw−Hollow	64	20	1
70−4840	Nut−Retaining	59	8	4
70−4860	Washer−1.000mm Thick	59	2	AR
70−4870	Washer−1.050mm Thick	59	2	AR
70−4880	Washer−1.100mm Thick	59	2	AR
70−4890	Washer−1.275mm Thick	59	2	AR
70−4900	Washer−1.325mm Thick	59	2	AR
70−4920	Washer−0.950mm Thick	59	2	AR
70−4980	Bolt−Eye	55	4	1
70−5310	Elbow	55	18	1
70−5700	Asm−Pump, Feed	64	*	1
70−5710	Asm−Filter, Fuel	65	*	1
70−5710	Asm−Filter, Fuel	70	32	1
70−5710	Filter−Fuel	70	32	1
70−5720	Bracket	65	5	1
70−5730	Asm−Cartridge	65	6	1
70−6480	Pin−Split	63	62	1
70−6490	Snap Ring	62	42	1
70−6500	O−Ring	62	24	1
70−6510	O−Ring	62	8	2
70−6520	Bolt−W/Washer	62	36	1
70−6530	Bolt−W/Washer	58	25	6
70−6540	Bolt−W/Washer	62	19	2
70−6540	Bolt−W/Washer	61	41	4
70−6560	Nut−W/Hole	62	28	1
70−6610	Washer−Plate 0.2mm Thick	62	41	AR
70−6620	Washer−Plate 0.3mm Thick	62	41	AR
70−6630	Washer−Plate 0.4mm Thick	62	41	AR
70−6640	Washer−Plate 0.1mm Thick	62	41	AR
70−6650	Washer−Plate 1.0mm Thick	62	41	AR
70−6670	Washer−Spring	62	46	1
70−6680	Washer−Spring	58	31	1
70−6690	Washer−Plate	62	22	2
70−6700	Washer	64	2	1
70−6710	Washer−Copper Plate	63	54	1
70−6720	Stud	60	27	3
70−6730	Bolt−W/Washer	62	33	1
70−6740	Bolt−W/Washer	62	14	2
70−6750	Bolt−W/Washer	62	30	4
70−6780	Nut−Hex.	58	30	1

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. No.	Ref. No.	Qty.
70–6790	Packing–Rubber Plate	62	29	1
70–6810	Washer–Snap	63	57	2
70–6820	Ring–Snap	64	15	1
70–6830	Pin–Straight	59	6	8
70–6840	Bearing–Roller	60	1	1
70–6850	Bearing–Roller	60	21	1
70–6860	Key–Woodruff	63	59	1
70–6870	Key–Woodruff	63	52	1
70–6880	Key–Woodruff	58	29	1
70–6890	O–Ring	63	64	1
70–6900	O–Ring	60	28	1
70–6910	O–Ring	60	13	4
70–6920	Seal–Oil	62	31	1
70–6930	Screw–Hollow	60	25	1
70–6940	Screw–Hollow	60	4	1
70–6940	Screw–Hollow	64	10	1
70–6990	Asm–Level Sensing Unit	22	2	1
71–0060	Support–Foam	43	8	1
71–0210	Foam–Radiator Seal	44	13	1
71–0250	Foam–Hood Top	43	2	1
71–0260	Foam–Hood Side LH	43	3	1
71–0270	Foam–Hood Side RH	43	1	1
71–0340	Foam–Rad. Support LH	44	36	1
71–0350	Foam–Rad. Support RH	44	1	1
71–0360	Foam–Rad. Support Top	44	3	1
71–0370	Foam–Lower Rad. Support	44	34	2
71–0380	Foam–Rad. Support Front	44	42	1
71–0390	Foam–Rad. Support Rear	44	44	1
71–0400	Foam–Side Panel	43	14	2
71–0410	Cover–Abrasive	10	2	1
71–0420	Floor–Abrasive	28	66	1
71–0430	Cover–Abrasive	28	64	1
71–0440	Abrasive–Pedal Front	9	25	1
71–0450	Abrasive–Pedal Rear	9	29	1
71–0470	Disc–Middle	32	19	4
71–0480	Asm–Suspension	3	*	1
71–0540	Column–Steering	4	27	1
71–2170	Pin	3	22	1
71–2180	Bearing	3	2	4
71–2190	Pin	3	3	1
71–2200	Bracket–Swing Arm	3	33	1
71–2210	Pin	3	13	1
71–2220	Pin	3	16	1
71–2230	Ring–Snap	3	14	1
71–2240	Asm–Knob	3	15	1
71–2250	Bracket–Spring	3	18	1
71–2260	Spring	3	27	2
71–2270	Nut–Special	3	23	1
71–2280	Band–Weight Indicator	3	10	1
71–2290	Bearing–Trible	3	4	1
71–2300	Bumper	3	9	2
71–2310	Plate–Lower Suspension	3	8	1
71–2320	Pin	3	21	2
71–2330	Ring–Snap	3	19	2
71–2340	Absorber–Shock	3	20	1
71–2380	Washer	2	7	2
71–2390	Rivet–Pop	2	8	2
71–2400	Asm–Bumper	2	6	2
71–2410	Plate–Upper Suspension	2	5	1
71–2420	Bellows–Rubber	2	12	1
71–2430	Plate–Rear	11	16	1
71–2450	Cover–Access	27	24	1
71–2470	Rim	32	29	2
71–2530	Asm–Bearing	96	6	1
71–2550	Washer–Latch Shaft	90	9	2
71–2560	Support–Bulkhead	30	38	2
71–2570	Shaft–Pivot	80	3	1
71–2590	Shaft–Pivot	77	5	1
71–2590	Shaft–Pivot	80	24	1
71–2600	Tube–Anti–Sway	91	11	2
71–2610	Shaft–Deck Pivot	92	15	2
71–2620	Shaft–Lift Arm Elbow	91	23	2
71–2680	Hose–Vent	23	31	1
71–2680	Hose–Vent	44	53	1
71–2690	Hose–Fuel	73	7	1
71–3810	Coupling–Hydraulic Motor	32	34	2
71–3830	Bellcrank–Brake	36	21	2
71–3850	Cover–Housing	36	15	2
71–3860	Clevis	36	28	2
71–3870	Gasket	36	14	2
71–3880	Clevis–Brake Cable	32	15	2
71–3880	Clevis–Brake Cable	36	23	2
71–3900	Gasket	36	25	2
71–3910	Collar	36	34	2
71–3990	Cap–Brake Housing	32	20	2
71–4010	Housing–Brake	32	13	2
71–4060	Rod–Brake Latch	4	40	1
71–4130	Support–Control	11	17	1
71–4170	Switch–Toggle	14	19	1
71–4200	Cluster–Warning Light	13	6	1
71–4210	Cluster–Warning Light	13	4	1
71–4250	Spacer	13	20	2
72–0130	Kit–Horn	4	*	1
72–4070	Decal–Danger	33	47	2
72–4080	Decal–Danger	74	37	1
72–4080	Decal–Danger	28	71	2
72–4310	Switch–Ball	80	11	1
72–4310	Switch–Lift	87	32	2
72–9550	Stud–Fuel Tank	22	17	1
72–9760	Switch	14	15	2
74–0720	Tube–Manual	2	1	1
74–2170	Cylinder–Lift	88	43	2
74–2180	Ring–Steel	89	9	1
74–2190	Cushion	89	10	1
74–2200	Head	89	4	1
74–2210	Piston	89	12	1
74–2220	Collar	89	2	1
74–2230	Shaft/Clevis	89	1	1
74–2270	Fitting–Suction	25	23	1
74–2510	Tube–Hydraulic LH	7	13	1
74–2520	Tube–Hydraulic RH	7	14	1
74–2530	Tube–Hydraulic	7	11	1
74–2660	Hose–Hydraulic Return	24	34	1
74–2680	Bracket–Bulkhead	88	45	1
74–2700	Rod–Control	9	16	1
74–2710	Clamp Half–Hydraulic Line	91	2	4
74–2730	Tube–Clamp	91	31	4
75–0540	Tether–Cap, Reservoir	23	27	1
75–9460	Bracket–Sealing LH	42	19	1
75–9470	Bracket–Sealing RH	42	25	1
75–9480	Bracket–Sealing Bottom	42	22	1
76–1670	Spring–Extension	86	25	1
76–1670	Spring–Extension	80	33	1
76–1670	Spring–Extension	83	36	1
76–2750	Asm–Hydraulic Hose	83	2	1
76–2760	Asm–Hydraulic Hose	83	1	1
76–2770	Asm–Hydraulic Hose	83	6	1
76–4590	Screw	34	16	6
76–4590	Screw	40	27	6
76–4600	Gasket–Cover	40	38	1
76–4600	Gasket–Front Cover	34	26	1
76–4610	Cover	40	33	1
76–4610	Cover–Front	34	15	1
76–8750	Plate–Caution	44	45	2
77–2830	Rod–Spring	83	44	1
77–2990	Cable–Throttle	18	8	1
77–2990	Cable–Throttle	45	50	1
80–0160	Tray–Battery	74	18	1
80–4890	Decal–Service	11	32	1
80–9330	Alarm–Audio	11	3	1
82–4910	Roller	85	27	1
82–4910	Roller	86	36	1
82–5730	Joint–Ball	79	17	1
82–7820	Seat–Brake, Tube	36	13	2
82–7830	Screw–Bleed, Brake	36	11	2
82–7840	Piston–Brake	36	7	2
82–7850	Spring–Compression	36	4	2
82–7900	Shaft–Arm	91	34	2

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. No.	Ref. No.	Qty.
82–9060	Track & Latch–Adjustment	2	4	1
83–4330	Asm–Tube, Traction LH	28	82	1
83–4330	Tube–Hydraulic LH	32	8	1
83–4340	Asm–Tube, Traction RH	28	83	1
83–4340	Tube–Hydraulic RH	32	*	1
83–6660	Support–Seat	2	11	1
83–8350	Fitting–Traction, LH	27	20	1
83–8360	Fitting–Traction, RH	28	73	1
83–8370	Plate–Clamp	28	74	1
85–4491	Holder–Indicator, Light	11	37	1
85–4750	Display–Diagnostic	12	2	1
85–6150	Tube–Hyd. RH Branch	32	*	1
85–6150	Tube–Hydraulic	27	30	1
85–6190	Link–Deck Tilt	27	1	1
85–6260	Level Sensing Unit	23	3	1
86–6240	Plug–Taper	49	6	5
86–7350	Kit–Seal Repair	89	*	1
86–7350	Kit–Seal Repair	81	*	1
86–7410	Plate–Gage	13	5	1
86–7480	Spring–Compression	83	48	1
86–8100	Joint–Ball	90	19	2
86–8100	Joint–Ball	80	37	2
86–8101	Joint–Ball	90	22	2
88–6760	Spring–Gas	43	19	2
88–6770	Stud–Ball	43	18	2
88–6770	Stud–Ball	44	56	2
88–9190	Asm–Solenoid Coil	75	23	3
88–9260	Bracket–Roller RH	86	38	1
88–9270	Bracket–Roller LH	85	29	1
88–9450	Bracket–Hood Cylinder	44	37	2
92–1741	Tube–Hydraulic	32	42	1
92–1742	Tube–Hydraulic	24	40	1
92–1742	Tube–Hydraulic LH	32	12	1
92–1771	Board–Instrument	13	16	1
92–1772	Asm–Hood	43	4	1
92–2133	Bolt–Flange	57	7	2
92–2133	Bolt–Flange	57	20	2
92–2351	Fitting–Tank Return	24	36	1
92–2352	Hose–Hydraulic	24	35	1
92–3048	Kit–Solenoid Coil	28	54	3
92–3162	Bushing–Flange	83	28	4
92–4094	Roller–Latch	90	16	4
92–4804	Block–Latch Pivot	90	11	2
92–4805	Cam–Spring Trip	90	21	2
92–4806	Pin–Latch	90	13	8
92–4806	Pin–Latch	80	30	1
92–4807	Tube–Hyd. RH Run	32	*	1
92–4807	Tube–Hydraulic	24	4	1
92–4967	Tube–Hydraulic	27	9	1
92–4967	Tube–Hydraulic	21	17	1
92–4970	Hose–Hydraulic	23	37	1
92–4970	Hose–Hydraulic	28	80	1
92–4971	Asm–Hydraulic Cylinder	80	7	2
92–5720	Controller	11	22	1
92–6280	Asm–Seat	1	1	1
92–6282	Switch–Seat	1	15	1
92–6533	Cushion–Seat	1	7	1
92–6534	Shell–Seat	1	2	1
92–7301	Spacer	1	10	2
92–8003	Housing–Actuator, RH	36	12	1
92–8004	Housing–Actuator, LH	36	*	1
92–8661	Tab	11	34	3
92–9701	Shaft–Cruise Control	9	3	1
92–9730	Cap–End	5	18	1
92–9732	Plate–Wear	5	14	1
92–9735	Screw–Cap	5	19	7
92–9748	Valve–Power Steering	4	28	1
92–9749	Kit–Seal	5	*	1
92–9800	Spacer–Spindle	96	11	1
93–0307	Nut–Retainer	78	53	2
93–0309	Washer	77	25	2
93–0310	Spindle–Wheel RH	77	*	1
93–0311	Spindle–Wheel LH	77	17	1
93–1397	Valve–Flow Control	80	46	1
93–3102	Cap–Fuel	22	10	1
93–3103	Cap–Hydraulic	23	36	1
93–3365	Pin–Dowel	49	1	2
93–3401	Screw–Rocker	47	4	8
93–3417	Gasket	56	12	1
93–3417	Gasket	68	17	1
93–3526	Switch	45	54	1
93–3578	Nut	67	1	1
93–3580	Set–Bolt	67	4	1
93–3582	Set–Screw	67	3	1
93–3583	Bearing–Front	67	6	1
93–3584	Asm–Rotor	67	*	1
93–3585	Bearing–Rear	67	10	1
93–3586	Asm–Stator	67	17	1
93–3588	Set–Regulator	67	*	1
93–3589	Brush	67	15	2
93–3599	Gasket–Liquid	69	13	1
93–4237	Bearing	97	7	4
93–4237	Bearing	82	14	8
93–4237	Bearing	92	29	16
93–4239	Rim–Wheel	82	35	4
93–4240	10” Wheel–Pneumatic	92	30	8
93–4240	10” Wheel–Pneumatic	82	12	2
93–4241	Spacer	82	13	2
93–4241	Spacer	92	28	8
93–4241	Spacer–Bearing, Inner	97	4	1
93–4242	Plate	82	33	2
93–4242	Plate	93	46	8
93–4243	Tire–10”	82	34	2
93–4243	Tire–10”	93	42	8
93–4244	Tube–w/Valve	82	37	2
93–4244	Tube–w/Valve	93	45	8
93–4297	Clamp–Hose	57	22	2
93–5630	Spacer–Bearing	82	21	2
93–5630	Spacer–Bearing, Inner	97	8	1
93–5631	Rim–Wheel	82	38	2
93–5973	Asm–10” Foam Filled Tire	97	2	1
93–5980	Hub	82	36	2
93–5980	Hub	93	43	8
93–7037	Switch	7	22	1
93–7037	Switch	38	61	1
93–7038	Switch	28	77	1
93–7039	Bracket–Service Brake	7	21	1
93–7176	Fitting–45˚ ORFS	33	48	2
93–7177	Asm–Tube, Traction LH	27	19	1
93–7177	Tube–Hydraulic, LH	33	50	1
93–7178	Asm–Tube, Traction RH	27	21	1
93–7178	Tube–Hydraulic, RH	33	*	1
93–7179	Tube–Hydraulic	30	27	1
93–7188	Shaft –Slip Yoke	37	6	1
93–7189	Yoke–Pump End	37	3	1
93–7190	Kit–Universal Joint	37	7	2
93–7192	Hose–Diagnostic	28	81	1
93–7192	Hose–Hydraulic Diagnostic	21	25	1
93–7193	Hose–Diagnostic	28	70	1
93–7193	Hose–Hyd. Diagnostic	29	7	1
93–7252	Decal–CE	82	41	1
93–7252	Decal–CE	4	48	1
93–7252	Decal–CE	93	48	2
93–7273	Decal–Danger (Europe)	85	25	1
93–7273	Decal–Danger (Europe)	86	31	1
93–7273	Decal–Danger (Europe)	92	39	4
93–7417	Gasket	36	33	2
93–7418	Cap–Actuator	36	36	2
93–7422	Hose–Hyd. Diagnostic	29	5	1
93–7422	Hose–Hydraulic	27	11	1
93–7423	Hose–Diagnostic	75	44	2
93–7424	Hose–Diagnostic	28	69	1
93–7424	Hose–Hydraulic	37	50	1
93–7426	Tube–Hydraulic	27	39	1
93–7426	Tube–Hydraulic	80	44	1
93–7427	Tube–Hydraulic	80	47	1
93–7480	Bulb–LED	14	27	1
93–7637	Key–Square	95	8	1

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. No.	Ref. No.	Qty.
93–7815	Decal–Danger (Europe)	85	24	1
93–7815	Decal–Danger (Europe)	92	27	2
93–7815	Decal–Danger (Europe)	86	32	1
93–7824	Decal–Danger (Europe)	85	23	1
93–7824	Decal–Danger (Europe)	86	33	1
93–7824	Decal–Danger (Europe)	92	37	2
93–7824	Decal–Danger (Europe)	84	60	1
93–8457	Belt–Hex. Deck Drive	84	*	1
93–9320	Plate–Valve LH	40	40	1
93–9321	Plug–Orifice	41	75	1
93–9322	Variable Displacement Pump	37	1	1
93–9324	Pivot–Idler	86	41	1
93–9324	Pivot–Idler	84	61	1
93–9337	Bracket–Switch	7	28	1
93–9337	Bracket–Switch	37	35	1
93–9912	Grommet	91	30	2
93–9917	Asm–Hose, Hydraulic	94	9	2
93–9918	Asm–Hose, Hydraulic	94	8	4
93–9922	Spacer	88	61	2
93–9925	Asm–Lift Arm RH	87	*	1
93–9925	Asm–Lift Arm RH	91	*	1
93–9926	Asm–Lift Arm LH	91	25	1
93–9926	Asm–Lift Arm LH	87	33	1
93–9928	Clamp–Hose	91	28	2
93–9941	Arm–Outer Lift RH	91	*	1
93–9942	Arm–Outer Lift LH	91	10	1
93–9988	Fitting–Hydraulic	28	61	1
94–1416	Adapter	71	28	1
94–1892	Hose–Auxiliary Suction	23	14	1
94–1893	Tank–Hydraulic	23	4	1
94–2865	Tank–Fuel	22	11	1
94–2878	Pin	40	26	2
94–3310	Tube–Vent	22	22	1
94–3311	Hose–Fuel	22	23	1
94–4907	Motor–Hydraulic	83	11	1
94–4907	Motor–Hydraulic	94	13	2
94–5390	Plate–Load	95	4	2
94–5391	Seal–Shaft	95	3	1
94–5392	Kit–Seal	95	*	1
94–6760	Bracket–Support	85	19	1
94–6762	Bracket–Support	86	11	1
94–6772	Retainer–Clamp	91	32	2
94–9412	Seal–Adapter	41	74	1
94–9413	Screw	41	73	3
94–9414	Adapter–Suction	41	79	1
94–9415	Plug	41	96	1
94–9819	Bar–Guard, Front Center	84	63	1
94–9820	Bar–Guard, Front RH & LH	84	62	2
94–9821	Bar–Guard, Front Wing RH	86	42	1
94–9822	Bar–Guard, Wing Inner	93	50	2
94–9823	Bar–Guard, Wing RH & LH	93	51	2
94–9824	Bar– Guard, Front Wing LH	85	32	1
95–0815	Panel–Lever	14	1	1
95–0817	Decal–Height of Cut	84	57	1
95–0818	Decal–Torque	82	30	1
95–0818	Decal–Torque	92	38	2
95–0819	Decal–Belt Routing LH	92	36	1
95–0820	Decal–Belt Routing RH	92	*	1
95–0821	Decal–Hydraulic Oil	30	8	1
95–0822	Decal–Warning	22	12	1
95–0825	Panel–Control	4	46	1
95–0827	Panel	13	3	1
95–0831	Decal–Fuse	14	22	1
95–0832	Decal–Service (Europe)	11	32	1
95–0833	Decal–Belt Routing	83	39	1
95–0834	Decal–Diagnostic V2.0	12	1	1
95–0845	Decal–Height of Cut	94	28	2
95–0845	Decal–Height of Cut	84	56	1
95–1597	Bushing	89	18	1
95–1692	Fitting–Hydraulic Elbow	83	4	1
95–1821	Spring–Compression	4	45	1
95–1839	Cable–Negative	74	11	1
95–2741	Rim–Wheel	82	40	2
95–2741	Rim–Wheel	93	44	16
95–3297	Washer–Thrust	85	16	2
95–3297	Washer–Thrust	86	24	2
95–4400	Washer–Backup	34	44	1
95–4400	Washer–Backup	41	98	1
95–5616	Spacer	30	40	4
95–5630	Valve–Hydraulic Cartridge	21	1	1
95–5631	Valve–Hydraulic Cartridge	21	36	1
95–5632	Valve–Hydraulic Cartridge	21	15	1
95–5633	Valve–Hydraulic Cartridge	21	30	2
95–5634	Valve–Hydraulic Cartridge	21	10	1
95–5635	Valve–Cartridge (3000 lbs)	75	8	3
95–5636	Valve–Cartridge (20 lbs)	75	40	3
95–5637	Valve–Cartridge (75 lbs)	75	38	3
95–5638	Valve–Solenoid	28	62	1
95–5639	Spool–Solenoid Valve	75	25	3
95–5640	Valve–Cartridge (600 lbs)	75	5	3
95–5641	Kit–Seal	21	11	1
95–5642	Kit–Seal	21	29	3
95–5643	Kit–Solenoid Valve Seal	76	*	3
95–5644	Kit–Cartridge Valve Seal	76	*	6
95–5645	Kit–Cartridge Valve Seal	76	*	6
95–5645	Kit–Seal	21	2	2
95–5907	Asm–Counterbalance	19	26	1
95–5907	Counterbalance Manifold	21	*	1
95–5908	Asm–Manifold	76	*	1
95–5908	Asm–Manifold	74	1	1
95–5916	Asm–Solenoid Valve	28	*	1
95–5917	Valve Seal Kit	28	*	1
95–6456	Hose–Lower Radiator	44	10	1
95–6457	Hose–Air Outlet	71	20	1
95–6458	Hose–Air Outlet	71	22	1
95–6459	Hose–Air Inlet	71	2	2
95–6461	Tube–Intake	71	21	1
95–6462	Bracket–Air Cleaner	71	17	1
95–6463	Bracket–Muffler	71	9	9
95–6464	Bracket–Manifold	71	26	1
95–6465	Asm–Mount Rear	45	48	1
95–6465	Asm–Mount, LH Rear	45	27	1
95–6467	Asm–Mount RH	45	47	1
95–6470	Asm–Mount LH	45	38	1
95–6474	Asm–Exhaust Tube	71	3	1
95–6477	Pulley–Fan Drive	70	27	1
95–6480	Bracket Asm–	70	16	1
95–6481	Plate–Pump Adapter	45	3	1
95–6486	Spacer–Mount	45	41	8
95–6487	Bracket–Hose Support	78	49	1
95–6489	Bracket–Throttle	45	34	1
95–6495	Asm–Bearing Housing	70	11	1
95–6497	Spacer	70	23	1
95–6499	Asm–Engine	45	1	1
96–1267	Pulley–Fan	70	4	1
98–0655	Asm–Hose	45	4	2
98–0655	Asm–Hydraulic Hose	25	1	2
98–0655	Hose–Hydraulic	75	1	2
98–0657	Fitting–Hydraulic	76	48	2
98–0661	Asm–Hydraulic Cylinder	77	42	2
98–0661	Steering Cylinder (Complete)	79	*	2
98–0664	Ring–Head	79	7	1
98–0665	Piston	79	11	1
98–0666	Rod–Piston	79	4	1
98–0667	Kit–Repair	79	*	1
98–0755	Plate–Tension	83	43	1
98–0800	Asm–Air Cleaner	71	19	1
98–0801	Asm–Element	72	3	1
98–0802	Asm–Cover	72	4	1
98–0803	Valve	72	5	1
98–0809	Fan	70	29	1
98–0819	Asm–Pump Drive Shaft	38	*	1
98–0826	Asm–Coupler	45	2	1
98–0830	Retainer–Mount	45	42	4
98–0831	Bearing–Fan	70	9	1
98–0833	Band–Air Cleaner	71	13	1
98–0835	Yoke–Engine End	37	8	1
98–0836	Tube–Slip Yoke	37	4	1

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. No.	Ref. No.	Qty.
98–1461	Asm–LH Lift Bar	92	18	1
98–1462	Asm–RH Lift Bar	92	*	1
98–1487	Decal–Fuse	11	5	1
98–2365	Cowl–Radiator	42	10	1
98–3008	Hub–Fan	70	5	1
98–3013	Support–Fan	70	20	1
98–3023	Washer	45	40	4
98–3024	Mount–Engine	45	43	4
98–3026	Bracket–Hinge	43	28	2
98–3038	Bushing–Idler	86	46	1
98–3038	Bushing–Idler	84	65	1
98–3040	Panel–Control	14	6	1
98–3041	Plate–Control	14	5	1
98–3047	Arm–Pivot	82	10	2
98–3048	Plate–Seat	1	6	1
98–3311	Arm–Anti–Sway LH	91	14	1
98–3312	Arm–Anti–Sway RH	91	*	1
98–7067	Fitting–Reducer	23	39	1
98–7300	Fork–Castor	92	32	8
98–7302	Fork–Castor	82	24	2
98–7307	Asm–Fan Support	70	12	1
98–7308	Cable–Positive	74	12	1
98–7309	Asm–Wire Harness	11	*	1
98–7311	Radiator	44	12	1
98–7312	Wheel–Pneumatic, 12”	82	23	2
98–7313	Tire–12”	82	22	2
98–7318	Shroud–Fan	44	9	1
98–7320	Hose–Upper Radiator	44	4	1
98–7321	Clutch–Modulating Fan	70	31	1
98–7325	Cover–Steering Wheel	4	8	1
98–7326	Harness–Wire, Seat Switch	1	15	1
98–7327	Solenoid–Run	70	*	1
98–7329	Asm–12” Foam Filled Tire	97	10	1
98–7342	Arm–Inside Castor	92	1	2
98–7343	Arm–Outside Castor	92	19	2
98–7346	Tube–Cylinder Bushing	80	15	2
98–7347	Clamp–Hose	71	24	2
98–7348	Foam–Seal	44	15	2
98–7375	Gasket–Nozzle	58	1	4
98–7375	Gasket–Nozzle	69	3	4
98–9008	V–Belt	70	28	1
99–1800	Asm–Head, Cylinder	46	*	1
99–1801	Cap–Sealing 20mm	46	5	12
99–1802	Cap–Sealing 25mm	46	6	7
99–1803	Guide–Valve	46	7	8
99–1804	Seat–Valve, Inlet	46	12	4
99–1805	Seat–Valve, Exhaust	46	13	4
99–1806	Bolt–Cylinder Head	46	4	17
99–1807	Gasket–Head, Cylinder	46	11	1
99–1807	Gasket–Head, Cylinder	68	20	1
99–1808	Eye–Lifting, Rear	46	9	1
99–1809	Gasket–Head, Cylinder	68	4	1
99–1809	Gasket–Head, Rear	46	10	1
99–1810	Bolt–W/Washer	46	16	2
99–1810	Bolt–W/Washer	52	7	26
99–1810	Bolt–W/Washer	51	13	5
99–1811	Bolt–W/Washer	46	8	4
99–1811	Bolt–W/Washer	52	3	1
99–1811	Bolt–W/Washer	66	3	2
99–1811	Bolt–W/Washer	56	5	16
99–1811	Bolt–W/Washer	55	20	4
99–1811	Bolt–W/Washer	58	36	1
99–1811	Bolt–W/Washer	56	20	4
99–1812	Plug–Drain	57	3	2
99–1812	Plug–Drain	46	2	1
99–1812	Plug–Drain	50	5	1
99–1813	Gasket	57	2	2
99–1813	Gasket	46	3	1
99–1813	Gasket	50	4	1
99–1813	Gasket	68	6	2
99–1813	Gasket	69	11	2
99–1814	Valve–Inlet	47	17	4
99–1815	Valve–Exhaust	47	16	4
99–1816	Retainer–Upper	47	13	8
99–1817	Seal–Stem, Valve	47	14	8
99–1817	Seal–Stem, Valve	68	19	8
99–1818	Asm–Rocker & Shaft	47	*	1
99–1819	Asm–Rocker	47	*	8
99–1820	Spring–Rocker	47	7	3
99–1821	Asm–Shaft, Rocker	47	*	1
99–1822	Ring–Snap	47	1	2
99–1823	Bracket–Shaft, Rocker	47	18	4
99–1824	Bolt–Rocker Bracket	47	6	4
99–1825	Bolt–W/Washer	47	10	4
99–1826	Asm–Cover, Rocker	48	*	1
99–1827	Gasket–Rocker	48	1	1
99–1827	Gasket–Rocker	68	3	1
99–1828	Bolt–W/Washer	48	2	5
99–1828	Bolt/W/Washer	55	22	16
99–1829	Camshaft	48	12	1
99–1830	Bolt/W/Washer	56	18	2
99–1830	Bolt/W/Washer	48	15	1
99–1831	Tappet	48	11	8
99–1832	Rod–Push	48	10	8
99–1833	Clip–Hose	48	6	1
99–1834	Hose–Breather	48	7	1
99–1835	Clip	48	8	1
99–1836	Bolt–W/Washer	48	9	1
99–1837	Asm–Crankcase	49	*	1
99–1837	Gasket–Plate, Front	68	23	1
99–1838	Bolt–Cap, Bearing	49	9	10
99–1839	Valve–Check	49	15	4
99–1840	Plug–Cam	49	12	1
99–1841	Pin–Dowel	49	18	1
99–1842	Pin–Spring	49	10	6
99–1843	Bushing	49	16	1
99–1844	Shaft–Idler	49	17	1
99–1845	Plug–Taper	49	3	1
99–1846	Set–Metal, Main Std.	50	*	1
99–1847	Set–Metal, Main U.S. 0.25	50	*	1
99–1848	Set–Metal, Main U.S. 0.50	50	*	1
99–1849	Set–Metal, Main U.S. 0.75	50	*	1
99–1850	Plate–Thrust Std.	50	12	3
99–1851	Plate–Thrust O.S. 0.15	50	12	1
99–1852	Plate–Thrust O.S. 0.30	50	12	1
99–1853	Seal–Side	69	6	2
99–1853	Seal–Side	50	13	2
99–1854	Housing–Flywheel	50	7	1
99–1855	Gasket–Rear	68	5	1
99–1855	Gasket–Rear	50	11	1
99–1856	Bolt–W/Washer	50	10	10
99–1857	Bolt–W/Washer	66	6	2
99–1857	Bolt–W/Washer	50	10	2
99–1858	Stud	50	3	2
99–1859	Plate–Front	51	4	1
99–1860	Gasket–Front Plate	51	5	1
99–1861	Case–Gear, Timing	51	2	1
99–1862	Gasket–Gear	51	3	1
99–1862	Gasket–Rear	68	22	1
99–1863	Cover–Gear, Case	51	15	1
99–1864	Bolt–W/Washer	51	1	13
99–1865	O–Ring	69	1	2
99–1865	O–Ring	51	14	1
99–1865	O–Ring	68	21	2
99–1865	O–Ring	58	38	1
99–1866	Bolt–W/Washer	51	16	5
99–1867	Seal–Oil	51	17	1
99–1868	Gear–Camshaft	51	6	1
99–1869	Gear–Pump, Injection	51	9	1
99–1870	Asm–Idler, Gear	51	*	1
99–1871	Plate–Thrust	51	11	1
99–1872	Bolt–W/Washer	51	12	1
99–1873	Gear–Pump, Oil	51	10	1
99–1874	Asm–Pan, Oil	52	*	1
99–1875	Gage–Oil Level	52	2	1
99–1876	Guide–Oil Level Gage	52	4	1
99–1877	Bracket–Gage Guide	52	1	1
99–1878	O–Ring	52	5	1

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. No.	Ref. No.	Qty.
99−1878	O−Ring	69	5	1
99−1880	Piston−Std.	53	5	4
99−1881	Piston−O.S. 0.25	53	5	4
99−1882	Piston−O.S. 0.50	53	5	4
99−1883	Set−Ring, Piston Std.	53	*	4
99−1884	Ring−Piston O.S. 0.25	53	*	4
99−1885	Ring−Piston O.S. 0.50	53	*	4
99−1886	Pin−Piston	53	12	4
99−1887	Ring−Snap	53	4	8
99−1888	Asm−Rod, Connecting	53	*	4
99−1889	Bolt−Connecting	53	10	8
99−1890	Bushing−Rod, Connecting	53	11	8
99−1891	Set−Metal Std.	53	7	1
99−1892	Set−Metal O.S. 0.25	53	7	1
99−1893	Set−Metal O.S. 0.50	53	7	1
99−1894	Set−Metal O.S. 0.75	53	7	1
99−1895	Asm−Crankshaft	54	*	1
99−1896	Pulley−Crankshaft	54	2	1
99−1897	Nut−Crankshaft	54	1	1
99−1898	Gear−Crankshaft	54	3	1
99−1899	Asm−Flywheel	54	*	1
99−1900	Panel−Diagnostic	29	4	1
99−1928	Bracket−Mounting	70	40	1
99−1929	Asm−Solenoid	70	33	1
99−1930	Rod−Connecting	70	37	1
99−1931	Rod−Support	70	39	1
99−2100	Gear−Ring	54	7	1
99−2101	Asm−Inlet, Manifold	55	23	1
99−2102	Gasket−Manifold, Inlet	68	10	1
99−2102	Gasket−Manifold, Inlet	55	24	1
99−2103	Elbow−Air Inlet	55	19	1
99−2104	Gasket	68	2	1
99−2104	Gasket	68	11	1
99−2104	Gasket−Heater, Air	55	21	1
99−2105	Gasket−Exhaust	55	34	1
99−2105	Gasket−Manifold, Exhaust	68	24	1
99−2106	Pipe−Exhaust	55	30	1
99−2107	Gasket−Exhaust	68	25	1
99−2107	Gasket−Exhaust, Manifold	55	32	1
99−2108	Asm−Exhaust, Manifold	55	33	1
99−2109	Spacer	55	26	8
99−2110	Washer	55	28	8
99−2111	Bolt/W/Washer	55	29	8
99−2112	Stud	55	37	4
99−2113	Nut−Lock	55	38	8
99−2114	Gasket−Exhaust	68	26	1
99−2114	Gasket−Exhaust	55	36	1
99−2115	Stud	55	10	3
99−2116	Hose−Air	55	12	1
99−2117	Clamp	55	11	1
99−2118	Pipe−Drain, Oil	55	15	1
99−2119	Pipe−Oil	55	3	1
99−2120	Elbow	55	8	1
99−2121	Gasket−Pipe, Drain	55	14	1
99−2122	Bolt−W/Washer	55	25	2
99−2123	Hose−Oil	55	17	1
99−2124	Asm−Turbocharger	55	9	1
99−2125	Clamp	55	2	2
99−2126	Nut	55	6	1
99−2127	Asm−Pump, Oil	56	*	1
99−2128	O−Ring	68	18	1
99−2128	O−Ring	56	28	1
99−2129	Nut−Jam	56	21	1
99−2130	Strainer−Oil	56	17	1
99−2131	O−Ring	56	8	2
99−2131	O−Ring	69	8	3
99−2131	O−Ring	68	14	3
99−2131	O−Ring	56	16	1
99−2132	Valve	56	13	1
99−2133	Valve	56	15	1
99−2134	Gasket	68	9	1
99−2134	Gasket	56	14	1
99−2135	Asm−Cooler, Oil	56	*	1
99−2136	Asm−Element	56	2	1
99−2137	Asm−Case	56	*	1
99−2138	Bolt−Cooler, Oil	56	6	4
99−2139	Gasket−Cover, Side	56	1	1
99−2139	Gasket−Cover, Side	68	12	1
99−2140	Gasket	56	9	1
99−2140	Gasket	68	15	1
99−2141	O−Ring	56	3	2
99−2141	O−Ring	68	13	2
99−2142	Gasket	56	7	4
99−2142	Gasket	68	16	4
99−2143	Cartridge−Oil	56	11	1
99−2144	Union−Filter, Oil	56	10	1
99−2145	Asm−Pump, Water	57	*	1
99−2146	Cover−Pump, Water	57	10	1
99−2147	Gasket−Cover, Pump	69	10	1
99−2147	Gasket−Cover, Pump	57	12	1
99−2148	Gasket−Pump, Water	57	11	1
99−2148	Gasket−Water	69	9	1
99−2149	Pulley−Pump, Water	57	18	1
99−2150	Bolt−W/Washer	57	1	1
99−2150	Bolt−W/Washer	57	14	5
99−2151	Bolt−Flange	57	19	1
99−2152	Hose−By−Pass	57	23	1
99−2153	Cover−Thermostat	57	6	1
99−2154	Gasket−Thermostat	57	5	1
99−2154	Gasket−Thermostat	69	12	1
99−2155	Thermostat	57	4	1
99−2156	Asm−Case, Thermostat	57	*	1
99−2157	Asm−Thermostat	57	*	1
99−2158	Bolt−W/Washer	57	26	1
99−2159	Belt−Raw Edge	57	15	1
99−2160	Bolt−W/Washer	57	17	4
99−2161	Asm−Pump, Injection	58	*	1
99−2162	Cover−Control	58	32	1
99−2163	Asm−Pump, Feed	58	28	1
99−2164	Bolt−W/Washer	58	24	1
99−2165	Support−Nozzle	58	10	4
99−2166	Bolt−W/Washer	58	11	4
99−2167	Cap	58	2	1
99−2168	Asm−Hose, Oil	58	*	3
99−2169	Clip	58	4	7
99−2170	Bracket−Pump	58	12	1
99−2171	Flange−Pimp, Injection	58	37	1
99−2172	Pipe−Injection No. 1	58	6	1
99−2173	Pipe−Injection No. 2	58	7	1
99−2174	Pipe−Injection No. 3	58	8	1
99−2175	Pipe−Injection No. 4	58	9	1
99−2176	Pipe−Return, Fuel	58	17	1
99−2177	Joint−Eye	58	18	1
99−2178	Asm−Hose, Fuel	58	16	1
99−2179	Bolt−W/Washer	58	21	3
99−2180	Hose	58	40	1
99−2181	Hose	58	39	1
99−2182	O−Ring	69	2	1
99−2182	O−Ring	58	35	1
99−2183	Bolt−W/Washers	58	34	4
99−2184	Pipe−Oil	58	23	1
99−2185	Connector	58	22	1
99−2186	Color	58	33	1
99−2187	Asm−Nozzle	59	*	4
99−2188	Asm−Holder	59	*	4
99−2189	Asm−Tip, Nozzle	59	7	4
99−2190	Washer−1.150mm Thick	59	2	AR
99−2191	Washer−1.200mm Thick	59	2	AR
99−2192	Washer−1.250mm Thick	59	2	AR
99−2193	Washer−1.300mm Thick	59	2	AR
99−2194	Washer−1.350mm Thick	59	2	AR
99−2195	Washer−1.400mm Thick	59	2	AR
99−2196	Washer−1.450mm Thick	59	2	AR
99−2197	Washer−1.500mm Thick	59	2	AR
99−2198	Washer−1.550mm Thick	59	2	AR
99−2199	Washer−1.600mm Thick	59	2	AR
99−2200	Washer−1.650mm Thick	59	2	AR
99−2201	Washer−1.700mm Thick	59	2	AR

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. No.	Ref. No.	Qty.
99–2202	Washer–1.750mm Thick	59	2	AR
99–2203	Washer–1.800mm Thick	59	2	AR
99–2204	Washer–1.375mm Thick	59	2	AR
99–2205	Washer–1.425mm Thick	59	2	AR
99–2206	Washer–1.475mm Thick	59	2	AR
99–2207	Washer–0.700mm Thick	59	2	AR
99–2208	Washer–0.800mm Thick	59	2	AR
99–2209	Washer–0.850mm Thick	59	2	AR
99–2210	Washer–0.900mm Thick	59	2	AR
99–2211	Washer–0.975mm Thick	59	2	AR
99–2212	Washer–1.025mm Thick	59	2	AR
99–2213	Washer–1.075mm Thick	59	2	AR
99–2214	Washer–1.125mm Thick	59	2	AR
99–2215	Washer–1.175mm Thick	59	2	AR
99–2216	Washer–1.225mm Thick	59	2	AR
99–2217	Washer–0.750mm Thick	59	2	AR
99–2218	Packing	59	5	4
99–2220	Holder–Valve	60	14	4
99–2221	Stopper–Valve	60	12	4
99–2222	Spring–Valve	60	11	4
99–2223	Valve–Delivery	60	9	4
99–2224	Element–Pump	60	8	4
99–2225	Sleeve–Control	61	38	4
99–2226	Sheet–Spring, Upper	61	37	4
99–2227	Spring–Plunger	61	36	4
99–2228	Shim–1.00mm Thick	60	20	AR
99–2229	Shim–1.50mm Thick	60	20	AR
99–2230	Shim–2.00mm Thick	60	20	AR
99–2231	Shim–0.03mm Thick	60	20	AR
99–2232	Gasket–Cover, Bearing	61	43	1
99–2233	Rack–Control	60	18	1
99–2234	Screw–Guide, Rack	60	7	1
99–2235	Asm–Cover, Pump	61	*	1
99–2236	Shim–0.13mm Thick	61	32	AR
99–2237	Nut–Hex.	60	30	3
99–2238	Washer–Spring	60	29	3
99–2239	Asm–Valve	60	17	1
99–2240	Shim–1.00mm Thick	60	2	AR
99–2241	Shim–1.50mm Thick	60	2	AR
99–2242	Shim–0.12mm Thick	60	2	AR
99–2243	Shim–0.14mm Thick	60	2	AR
99–2244	Shim–0.18mm Thick	60	2	AR
99–2245	Shim–0.03mm Thick	60	2	AR
99–2246	Housing–Governor	63	53	1
99–2247	Screw–Adjust	63	50	1
99–2248	Nut–Cap	62	21	1
99–2249	Lever–Tension	62	37	1
99–2250	Nut–Hex.	63	49	1
99–2251	Capsule	62	15	1
99–2252	Lever–Swivelling	63	58	1
99–2253	Lever–Adjusting	62	32	1
99–2254	Plate–Cover	62	20	1
99–2255	Bolt–W/Washer	62	26	2
99–2256	Bushing–Bearing	63	65	1
99–2257	Spring	63	63	1
99–2258	Gasket	63	48	1
99–2259	Gasket	63	51	1
99–2260	Nut–Hex.	62	23	1
99–2261	Rod–Push	64	21	1
99–2262	Washer–Union	64	9	4
99–2263	Piston	64	4	1
99–2265	Plate–Connection	66	1	1
99–2266	Plug–Glow	66	2	4
99–2267	Asm–Starter	66	8	1
99–2268	Bracket–Alternator	66	7	1
99–2269	Asm–Alternator	67	*	1
99–2270	Plate–Adjusting	66	9	1
99–2271	Asm–Pulley	67	2	1
99–2272	Asm–Bracket, Front	67	*	1
99–2273	Asm–Bracket, Rear	67	*	1
99–2274	Asm–Rectifier	67	13	1
99–2275	Set–Nut	67	11	1
99–2277	Gasket	68	27	1
99–2277	Gasket	71	29	1
99–2280	Pin–Pressure	59	4	4
99–2281	Spring–Pressure	59	3	4
99–2282	Seal–Oil	64	17	1
99–2779	Asm–Body	59	1	4
99–2318	V–Belt	85	*	1
93–2318	V–Belt	86	*	1
99–2318	V–Belt	94	*	6
99–2319	Switch–Ignition	14	16	1
99–4443	Fitting	84	69	1
99–4443	Fitting	94	33	2
99–4444	Fitting	84	68	1
99–4444	Fitting	94	32	2
99–4964	Tube–Hydraulic	30	15	1
99–4965	Asm–Tube Front, Return	74	41	1
99–4966	Tube–Hydraulic	30	16	1
99–4967	Asm–Tube Front, Deck	74	42	1
99–4968	Tube–Suction	25	24	1
99–4968	Tube–Suction	45	58	1
99–4969	Tube–Suction	25	13	1
99–5903	Stud	95	9	4
99–4969	Tube–Suction	45	12	1
99–5915	Asm–Idler Bracket	70	22	1
99–5917	Shaft–Lift Arm Pivot	87	26	2
99–6058	Screw–HH	37	10	6
217–116	Rim	77	23	2
218–242	Switch–Brake	7	25	1
218–243	Fitting–Tee	7	12	1
218–446	Nut–Hex	14	9	1
218–447	Washer–Lock	14	8	1
218–498	Nut	13	18	2
218–498	Nut–Hex	14	7	10
218–533	Lens–Indicator Light (Red)	4	7	1
218–533	Lens–Red	14	26	1
218–535	Nut–Hex.	14	24	1
218–535	Nut–Hex.	4	24	3
218–536	Washer–Lock	4	23	3
218–536	Washer–Lock	14	25	1
218–562	Lens–Indicator Light	4	11	2
218–573	Fuse–5A	11	*	1
218–581	Fuse–15A	11	33	6
219–17	Bulb–Light	13	9	8
219–19	Bulb	11	38	1
2116–3	Joint–Ball LH	77	*	1
2116–4	Joint–Ball RH	77	35	1
231–140	Tire–(Optional)	32	*	2
232–27	Stem–Valve	77	29	2
233–17	Knob	4	3	1
233–42	Knob	19	3	3
233–48	Knob	18	3	1
233–66	Knob	14	10	1
237–21	O–Ring	32	3	2
237–21	O–Ring	21	6	2
237–21	O–Ring	30	29	4
237–21	O–Ring	78	52	4
237–21	O–Ring	28	58	3
237–22	O–Ring	24	5	3
237–22	O–Ring	83	7	1
237–22	O–Ring	80	8	9
237–22	O–Ring	94	10	2
237–22	O–Ring	19	14	9
237–22	O–Ring	87	19	14
237–22	O–Ring	21	21	7
237–22	O–Ring	23	21	2
237–22	O–Ring	37	25	1
237–22	O–Ring	27	32	7
237–22	O–Ring	4	37	4
237–22	O–Ring	77	45	6
237–22	O–Ring	41	64	1
237–30	O–Ring	27	8	3
237–30	O–Ring	24	13	2
237–30	O–Ring	37	17	2
237–30	O–Ring	21	22	2
237–37	Bumper–Rubber	74	34	4
237–42	O–Ring	32	1	2

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. No.	Ref. No.	Qty.
237−42	O−Ring	80	6	4
237−42	O−Ring	75	7	1
237−42	O−Ring	83	9	1
237−42	O−Ring	94	12	2
237−42	O−Ring	37	23	1
237−42	O−Ring	19	24	5
237−42	O−Ring	21	27	6
237−42	O−Ring	88	42	4
237−58	O−Ring	83	3	2
237−58	O−Ring	24	7	1
237−58	O−Ring	32	7	7
237−58	O−Ring	74	43	2
237−58	O−Ring	75	10	8
237−58	O−Ring	27	14	4
237−58	O−Ring	37	21	3
237−65	O−Ring	23	41	2
237−65	O−Ring	24	3	2
237−65	O−Ring	94	7	4
237−65	O−Ring	27	18	6
237−65	O−Ring	87	20	4
237−65	O−Ring	33	49	2
237−78	O−Ring	21	4	2
237−78	O−Ring	21	8	3
237−78	O−Ring	27	13	5
237−78	O−Ring	75	33	1
237−78	O−Ring	75	41	2
237−78	O−Ring	77	43	4
237−79	O−Ring	19	12	2
237−79	O−Ring	23	23	1
237−79	O−Ring	21	24	2
237−79	O−Ring	75	32	4
237−79	O−Ring	4	39	4
237−80	O−Ring	24	1	1
237−80	O−Ring	23	19	3
237−80	O−Ring	41	68	1
237−81	O−Ring	23	1	1
237−81	O−Ring	83	5	2
237−81	O−Ring	94	5	4
237−81	O−Ring	32	9	4
237−81	O−Ring	37	15	1
237−81	O−Ring	75	19	8
237−101	O−Ring	24	24	2
237−116	O−Ring	25	9	1
237−146	O−Ring	32	5	4
237−146	O−Ring	75	14	1
237−146	O−Ring	37	19	3
237−154	O−Ring	73	10	1
237−155	O−Ring	24	20	1
237−156	O−Ring	21	13	8
237−156	O−Ring	75	30	30
237−157	O−Ring	23	16	1
237−158	O−Ring	32	21	4
237−164	Grommet	30	7	1
237−174	O−Ring	36	9	2
237−175	O−Ring	36	6	2
240−2	Grommet	30	6	2
240−3	Grommet	87	8	4
240−4	Grommet	27	6	6
240−4	Grommet	87	18	10
240−5	Grommet	27	28	2
240−6	Grommet	30	31	4
240−7	Grommet	30	32	1
240−7	Grommet	28	47	4
2410−10	Plug−Button	28	72	1
2410−73	Pin−Tether	23	35	1
2411−40	Joint−Ball	91	13	4
2412−3	Clamp−Hose	23	15	1
2412−7	Asm−Clamp	77	38	2
2412−34	Clamp−Hose	23	11	1
2412−39	Clamp	74	39	1
2412−41	Clamp	74	38	1
2412−41	Clamp−R	44	38	2
2412−42	Clamp−Hose	25	11	8
2412−42	Clamp−Hose	23	13	4
2412−42	Clamp−Hose	71	23	1
2412−73	Clamp−R	74	7	3
2412−89	Clamp−R	22	9	1
2412−92	Clamp−Hose	24	9	4
2412−92	Clamp−Hose	44	11	4
2412−104	Clamp−R	74	40	2
2412−108	Clamp−Hose	73	2	3
2412−108	Clamp−Hose	44	6	2
2412−108	Clamp−Hose	22	15	3
2412−108	Clamp−Hose	23	32	1
2412−110	Clamp−Hose	71	1	3
2412−129	Clamp−Hose	45	10	12
2412−129	Clamp−Hose	24	39	1
2412−133	Clamp	2	2	2
2412−138	Clamp−R	22	24	1
251−307	Bearing−Neutral Detent	37	41	1
251−340	Bearing−Ball	32	23	2
253−154	Seal−Wave	96	5	2
253−156	Seal−Oil	32	22	2
253−157	Ring−Cup	32	41	6
254−72	Cup−Bearing Outer	77	20	2
254−92	Cone−Bearing Outer	77	21	2
254−106	Cone−Bearing Inner	77	31	2
254−107	Cup−Bearing Inner	77	30	2
256−76	Bushing−Sleeve	91	15	4
256−156	Bushing−Flange	9	30	2
256−172	Bearing−Sleeve	90	15	8
256−188	Bushing−Sleeve	86	6	1
256−188	Bushing−Sleeve	83	22	1
256−247	Bushing−Flange	6	1	4
256−247	Bushing−Flange	28	46	2
256−273	Bushing−Flange	9	28	1
256−304	Washer−Thrust	91	6	8
256−304	Washer−Thrust	77	7	6
256−304	Washer−Thrust	80	28	2
256−304	Washer−Thrust	87	29	4
256−304	Washer−Thrust	92	40	4
282−2	Clevis−Brake Rod	7	18	1
282−28	Clevis−Adjustable	18	6	2
282−28	Clevis−Adjustable	45	49	1
283−1	Pin−Clevis	6	24	2
283−1	Pin−Clevis	7	24	1
283−2	Pin−Clevis	32	16	2
283−2	Pin−Clevis	36	24	2
283−15	Pin−Clevis	36	31	2
283−67	Pin−Clevis Arm End	18	5	1
283−70	Pin−Hitch	82	9	2
285−17	Plug−Pipe	41	76	2
302−2	Fitting −Grease	87	31	4
302−2	Fitting−Grease	80	2	4
302−2	Fitting−Grease	86	4	1
302−2	Fitting−Grease	91	4	4
302−2	Fitting−Grease	37	5	1
302−2	Fitting−Grease	92	13	2
302−2	Fitting−Grease	83	20	1
302−2	Fitting−Grease Str.	96	1	1
302−5	Fitting−Grease	79	1	2
302−5	Fitting−Grease	6	3	2
302−5	Fitting−Grease	81	13	3
302−5	Fitting−Grease	77	15	3
302−5	Fitting−Grease	89	15	2
302−5	Fitting−Grease	90	18	2
302−5	Fitting−Grease	91	22	2
302−5	Fitting−Grease	82	27	2
302−5	Fitting−Grease	83	33	4
302−5	Fitting−Grease	92	34	8
302−5	Fitting−Grease	80	40	2
302−5	Fitting−Grease	28	48	1
302−10	Fitting−Grease 45°	96	*	1
302−33	Fitting−Grease	77	36	2
302−39	Vent	32	25	2
302−40	Fitting−Grease	90	23	2
304−46	Valve−Drain	44	14	1
321−2	Screw−HH	6	10	1

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. No.	Ref. No.	Qty.
321−2	Screw−HH	36	17	8
321−2	Screw−HH	23	26	1
321−3	Screw−HH	1	16	2
321−3	Screw−HH	74	3	3
321−3	Screw−HH	9	6	4
321−3	Screw−HH	18	10	3
321−3	Screw−HH	11	14	4
321−4	Screw−HH	6	5	1
321−4	Screw−HH	45	35	2
321−4	Screw−HH	37	42	2
321−5	Screw−HH	23	10	10
321−6	Screw−HH	45	26	2
321−6	Screw−HH	36	37	8
321−9	Screw−HH	30	22	6
321−9	Screw−HH	28	43	2
321−9	Screw−HH	88	56	3
321−10	Screw−HH	19	1	2
321−10	Screw−HH	37	47	2
321−11	Screw−HH	28	65	2
321−15	Screw−HH	91	3	4
321−15	Screw−HH	30	18	2
322−3	Screw−HH	7	5	2
322−3	Screw−HH	70	6	6
322−3	Screw−HH	71	12	2
322−3	Screw−HH	91	27	4
322−5	Screw−HH	74	27	1
322−5	Screw−HH	44	39	1
322−6	Screw−HH	44	40	4
322−6	Screw−HH	86	48	1
322−6	Screw−HH	84	67	1
322−11	Screw−HH	87	1	1
322−11	Screw−HH	74	30	1
322−12	Screw−HH	30	9	2
322−12	Screw−HH	24	44	3
322−17	Screw−HH	37	39	1
322−21	Screw−HH	30	23	3
322−38	Screw−HH	30	42	2
323−4	Screw−HH	70	2	4
323−4	Screw−HH	11	4	4
323−4	Screw−HH	6	21	4
323−4	Screw−HH	74	21	4
323−4	Screw−HH	43	25	2
323−4	Screw−HH	24	28	3
323−5	Screw−HH	70	30	4
323−6	Screw−HH	77	3	2
323−6	Screw−HH	85	6	3
323−6	Screw−HH	2	9	2
323−6	Screw−HH	71	10	2
323−6	Screw−HH	87	12	4
323−6	Screw−HH	45	15	4
323−6	Screw−HH	70	15	2
323−6	Screw−HH	25	18	4
323−6	Screw−HH	32	18	14
323−6	Screw−HH	86	19	3
323−6	Screw−HH	43	23	4
323−6	Screw−HH	9	31	1
323−6	Screw−HH	74	32	4
323−7	Screw−HH	25	4	8
323−7	Screw−HH	45	5	8
323−7	Screw−HH	7	7	3
323−7	Screw−HH	4	16	4
323−7	Screw−HH	70	17	6
323−7	Screw−HH	85	31	3
323−7	Screw−HH	86	39	3
323−7	Screw−HH	44	41	4
323−7	Screw−HH	37	51	2
323−9	Screw−HH	1	13	2
323−9	Screw−HH	74	13	2
323−10	Screw−HH	23	5	4
323−10	Screw−HH	45	28	8
323−15	Screw−HH	82	17	16
323−15	Screw−HH	92	23	32
323−15	Screw−HH	88	44	2
323−34	Screw−HH	44	8	7
323−38	Screw−HH	45	44	4
323−39	Screw−HH	22	6	1
325−5	Screw−HH	4	30	3
325−6	Screw−HH	25	20	4
325−6	Screw−HH	45	20	8
325−6	Screw−HH	80	22	12
325−6	Screw−HH	44	43	4
325−6	Screw−HH	77	46	12
325−7	Screw−HH	37	12	2
325−7	Screw−HH	83	16	1
325−7	Screw−HH	33	46	4
325−8	Screw−HH	86	8	1
325−8	Screw−HH	83	24	1
325−9	Screw−HH	45	45	4
325−15	Screw−HH	82	6	4
325−20	Screw−HH	92	3	8
327−17	Screw HH	92	26	8
327−22	Screw−HH	32	27	16
327−24	Screw HH	82	15	2
327−25	Screw−HH	82	20	2
327−80	O−Ring	38	53	2
328−5	Screw−HH	80	21	2
328−8	Screw−HH	87	36	4
328−8	Screw−HH	87	37	2
328−11	Screw−HH	42	26	2
328−24	Screw−HH	88	58	4
328−26	Screw−HH	87	28	12
3210−7	Screw−HH	37	40	1
3213−2	Screw−HH	25	22	4
3213−2	Screw−HH	45	22	4
3217−6	Nut−Hex.	45	19	4
3217−7	Nut−Hex.	37	34	1
3217−7	Nut−Lock	9	1	1
3217−9	Nut−Hex.	37	14	2
3217−9	Nut−Hex.	80	26	16
3217−9	Nut−Jam	83	37	2
3217−26	Nut−Lock	9	7	1
3219−2	Nut−Hex.	37	29	1
3219−5	Nut−Hex.	32	31	18
3219−7	Nut−Lock	91	19	4
3219−10	Nut−Jam	75	24	3
3219−14	Nut−Hex.	18	7	2
3219−14	Nut−Hex.	24	17	1
3220−2	Nut−Jam	7	17	1
3220−3	Nut−Jam	9	21	2
3220−4	Nut	28	53	1
3220−4	Nut−Bulkhead	29	9	5
3220−5	Nut−Jam	9	19	1
3220−7	Nut−Jam	91	12	4
3220−7	Nut−Jam	77	28	2
3220−22	Nut−Jam	90	4	4
3220−24	Nut−Hex.	11	39	1
3229−8	Bolt−CARR	11	35	3
3230−22	Bolt−CARR	2	20	1
3231−6	Bolt−CARR	70	25	1
3231−22	Bolt−CARR	96	7	6
3231−25	Bolt−CARR	86	9	2
3231−25	Bolt−CARR	85	20	2
3231−28	Bolt−CARR	83	12	2
3231−28	Bolt−CARR	94	27	4
3231−30	Bolt−CARR	37	33	1
3233−9	Bolt−CARR	85	9	3
3233−9	Bolt−CARR	92	22	12
3233−9	Bolt−CARR	86	30	3
3233−27	Bolt−CARR	83	42	1
3233−28	Bolt−CARR	92	12	6
3233−29	Bolt−CARR	92	11	2
3233−30	Bolt−CARR	94	22	6
3233−30	Bolt−CARR	84	59	1
3234−5	Screw−HH	1	5	4
3234−7	Screw−HWH	11	2	11
3234−12	Screw−HFH	77	10	2
3234−12	Screw−HFH	84	53	4
3234−12	Screw−HWH	94	2	8

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. No.	Ref. No.	Qty.
3234−13	Screw−HFH	37	36	4
3234−13	Screw−HWH	22	8	1
3234−13	Screw−HWH	7	19	2
3234−14	Screw−HFH	10	1	4
3234−14	Screw−HFH	30	2	6
3234−14	Screw−HFH	19	8	6
3234−14	Screw−HFH	27	25	4
3234−14	Screw−HH	43	11	6
3234−14	Screw−HH	9	12	1
3234−14	Screw−HH	1	14	6
3234−14	Screw−HH	6	18	3
3234−14	Screw−HH	11	25	2
3234−14	Screw−HWH	4	25	8
3234−17	Screw−HFH	74	6	4
3234−28	Screw−HFH	27	10	2
3245−31	Screw−Set	9	8	1
3245−32	Screw−Set	9	26	1
3249−11	Screw−Machine	6	26	2
3253−2	Washer−Lock	24	16	1
3253−2	Washer−Lock	44	21	16
3253−3	Washer−Lock	23	9	10
3253−3	Washer−Lock	11	15	4
3253−3	Washer−Lock	36	16	8
3253−3	Washer−Lock	45	31	2
3253−3	Washer−Lock	37	46	2
3253−4	Washer−Lock	70	8	7
3253−4	Washer−Lock	71	14	2
3253−4	Washer−Lock	45	18	4
3253−6	Washer−Lock	71	5	5
3253−6	Washer−Lock	37	9	6
3253−6	Washer−Lock	45	24	20
3253−7	Washer−Lock	37	13	2
3253−7	Washer−Lock	25	21	8
3253−7	Washer−Lock	45	21	18
3253−7	Washer−Lock	80	25	16
3253−7	Washer−Lock	32	30	22
3253−8	Washer−Lock	96	14	1
3253−8	Washer−Lock	32	26	16
3253−9	Washer−Lock	91	20	4
3253−15	Washer−Lock	22	20	5
3253−15	Washer−Lock	14	21	A/R
3253−21	Washer−Lock	70	1	14
3253−21	Washer−Lock	9	2	2
3253−21	Washer−Lock	22	5	1
3253−21	Washer−Lock	25	5	8
3253−21	Washer−Lock	23	6	4
3253−21	Washer−Lock	45	6	8
3253−21	Washer−Lock	2	10	2
3253−21	Washer−Lock	74	14	2
3253−21	Washer−Lock	32	17	14
3253−21	Washer−Lock	4	17	4
3253−21	Washer−Lock	11	19	4
3253−21	Washer−Lock	36	19	8
3253−21	Washer−Lock	43	22	6
3253−21	Washer−Lock	24	29	3
3253−21	Washer−Lock	37	32	3
3253−21	Washer−Lock	44	35	12
3254−2	Washer	91	26	4
3254−2	Washer−Lock	74	25	1
3254−6	Washer−Lock	19	25	1
3254−6	Washer−Lock, Int. Tooth	11	40	1
3256−5	Washer−Flat	22	7	2
3256−6	Washer−Flat	9	17	1
3256−22	Washer−Flat	14	2	8
3256−22	Washer−Flat	30	11	2
3256−22	Washer−Flat	11	12	4
3256−22	Washer−Flat	91	35	4
3256−22	Washer−Flat	4	44	1
3256−23	Washer	13	2	4
3256−23	Washer−Flat	71	15	4
3256−23	Washer−Flat	2	16	4
3256−23	Washer−Flat	45	17	4
3256−23	Washer−Flat	30	24	1
3256−23	Washer−Flat	94	31	4
3256−23	Washer−Flat	85	35	2
3256−23	Washer−Flat	30	43	4
3256−23	Washer−Flat	86	45	2
3256−23	Washer−Flat	28	68	2
3256−24	Washer−Flat	71	4	3
3256−24	Washer−Flat	1	8	2
3256−24	Washer−Flat	74	15	2
3256−24	Washer−Flat	96	16	A/R
3256−24	Washer−Flat	43	24	6
3256−24	Washer−Flat	36	27	4
3256−26	Washer−Flat	18	13	1
3256−26	Washer−Flat	4	29	3
3256−26	Washer−Flat	32	45	4
3256−56	Washer−Flat	30	21	8
3256−56	Washer−Flat	87	40	3
3256−56	Washer−Flat	44	47	2
3256−56	Washer−Flat	28	67	2
3256−69	Washer	85	26	2
3256−69	Washer	86	35	2
3269−6	Washer−Backup	42	33	22
3269−15	Rivet−Pop	42	32	22
3269−25	Rivet−Pop	29	1	4
3269−25	Rivet−Pop	85	1	4
3269−25	Rivet−Pop	86	1	4
3269−25	Rivet−Pop	94	17	16
3269−25	Rivet−Pop	83	29	8
3272−1	Pin−Cotter	19	4	6
3272−1	Pin−Cotter	18	9	3
3272−1	Pin−Cotter	45	52	1
3272−5	Pin−Cotter	6	6	1
3272−5	Pin−Cotter	4	43	1
3272−6	Pin−Cotter	74	4	1
3272−6	Pin−Cotter	6	9	2
3272−6	Pin−Cotter	19	10	2
3272−6	Pin−Cotter	32	14	2
3272−6	Pin−Cotter	36	22	2
3272−7	Pin−Cotter	9	23	2
3272−7	Pin−Cotter	83	45	1
3272−10	Pin−Cotter	7	16	1
3272−10	Pin−Cotter	9	18	1
3272−10	Pin−Cotter	36	26	2
3272−12	Pin−Cotter	90	2	4
3272−12	Pin−Cotter	7	6	1
3272−12	Pin−Cotter	77	34	6
3272−12	Pin−Cotter	80	35	2
3272−13	Pin−Cotter	77	26	2
3272−23	Pin−Cotter	80	18	4
3272−33	Pin−Cotter	87	24	2
3274−7	Screw−HSH	36	18	8
3274−20	Screw−HSH	37	11	2
3274−86	Screw−HSH	27	15	1
3290−133	Screw−Round Hd.	13	1	4
3290−133	Screw−Round Hd.	14	3	8
3290−133	Screw−Round Hd.	11	11	4
3290−134	Screw−HH	43	13	4
3290−216	Washer−Bevel	77	9	12
3290−216	Washer−Bevel	44	25	4
3290−274	Rivet−Pop	44	46	4
3290−307	Pin−Cotter, Hair	6	25	2
3290−321	Screw−HH	43	5	12
3290−321	Screw−HH	74	20	4
3290−321	Screw−HH	44	22	16
3290−321	Screw−HWH	42	14	20
3290−343	Pin−Cotter Hair	82	11	2
3290−378	Tie−Cable	11	*	25
3290−378	Tie−Cable	6	*	3
3290−378	Tie−Cable	84	*	2
3290−378	Tie−Cable	88	*	3
3290−378	Tie−Cable	94	*	24
3290−378	Tie−Cable	11	18	2
3290−378	Tie−Cable	4	36	5
3290−378	Tie−Cable	80	41	1
3290−384	Pin−Lynch	82	1	2
3290−384	Pin−Lynch	92	2	8

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. No.	Ref. No.	Qty.
3290−392	Screw−HH	14	17	1
3290−495	Pin−Lynch	27	2	2
3296−2	Nut−Lock	85	2	6
3296−2	Nut−Lock	43	7	12
3296−2	Nut−Lock	86	10	6
3296−2	Nut−Lock	42	12	20
3296−2	Nut−Lock	13	15	2
3296−2	Nut−Lock	94	19	16
3296−2	Nut−Lock	11	21	6
3296−2	Nut−Lock	74	24	4
3296−2	Nut−Lock	83	34	8
3296−3	Nut−Lock	36	29	2
3296−9	Nut−Lock	6	14	2
3296−23	Nut−Lock	18	14	1
3296−29	Nut−Lock	1	4	4
3296−29	Nut−Lock	2	17	4
3296−29	Nut−Lock	94	30	4
3296−29	Nut−Lock	85	34	2
3296−29	Nut−Lock	86	44	2
3296−39	Nut−Lock	70	18	2
3296−39	Nut−Lock	22	19	1
3296−41	Nut−Lock	90	8	2
3296−42	Nut−Lock	18	1	3
3296−42	Nut−Lock	14	4	4
3296−49	Nut−Lock	96	2	1
3296−49	Nut−Lock	4	20	1
3296−53	Nut−Lock	82	16	4
3296−53	Nut−Lock	92	31	8
3296−59	Nut−Lock	36	35	2
3296−68	Nut Lock	87	35	2
3296−68	Nut−Lock	80	1	2
3296−68	Nut−Lock	77	11	1
3296−68	Nut−Lock	92	14	2
32103−3	Nut−Wing	44	33	2
32104−16	Screw−Tapping	13	7	4
32104−31	Screw−HH (Europe)	85	33	3
32104−31	Screw−HH (Europe)	86	43	3
32104−31	Screw−HH (Europe)	93	49	20
32104−31	Screw−HW (Europe)	84	64	10
32105−1	Screw−HH	13	17	2
32105−1	Screw−Machine	85	11	4
32105−1	Screw−Machine	86	16	4
32105−1	Screw−Machine	83	27	8
32105−1	Screw−PH	94	21	16
32105−12	Screw−HSH	11	7	2
32105−13	Screw−HH	11	8	4
32108−103	Screw−Flat Hd.	83	18	4
32108−103	Screw−Machine Flat Hd.	91	9	4
32108−103	Screw−Machine Flat Hd.	87	25	4
32108−103	Screw−Machine Flat Hd.	28	40	4
32120−11	Ring−Retaining, Internal	70	10	2
32120−22	Ring−Retaining Internal	32	24	2
32120−47	Ring−Retaining	90	14	16
32120−47	Ring−Retaining	80	31	2
32120−72	Ring−Retaining	86	5	1
32120−72	Ring−Retaining	83	21	1
32120−84	Ring−Retaining External	32	33	2
32121−4	Pin−Roll	2	18	1
32121−4	Pin−Roll	85	28	2
32121−4	Pin−Roll	86	37	2
32121−6	Pin−Roll	85	18	2
32121−6	Pin−Roll	86	21	2
32121−34	Pin−Roll	91	17	2
32121−34	Pin−Roll	79	18	1
32121−49	Pin−Roll	90	17	2
32121−110	Pin Roll	91	24	4
32121−110	Pin−Roll	77	4	1
32121−110	Pin−Roll	92	17	2
32121−110	Pin−Roll	80	23	2
32121−110	Pin−Roll	87	27	2
32122−24	Screw−HH	22	3	5
32122−28	Screw−Truss Hd.	85	5	2
32122−28	Screw−Truss Hd.	86	14	2
32127−11	Nut−Flexlok	7	27	2
32127−11	Nut−Flexlok	37	37	2
32128−16	Nut−HHF	82	28	8
32128−16	Nut−HHF	93	47	32
32128−19	Nut−HHF	1	12	2
32128−20	Nut−HHF	9	13	1
32128−20	Nut−HHF	6	17	3
32128−20	Nut−HHF	44	19	5
32128 −20	Nut−HHF	83	19	4
32128−20	Nut−HHF	4	22	2
32128−20	Nut−HHF	11	27	2
32128−21	Nut−HFH	45	33	8
32128−21	Nut−HHF	37	2	2
32128−21	Nut−HHF	94	4	12
32128−21	Nut−HHF	7	8	3
32128−21	Nut−HHF	96	9	6
32128−21	Nut−HHF	83	10	6
32128−21	Nut−HHF	85	10	6
32128−21	Nut−HHF	86	22	6
32128−21	Nut−HHF	71	25	2
32128−21	Nut−HHF	70	26	1
32128−23	Nut−Flange Lock	85	8	3
32128−23	Nut−Flange Lock	83	35	4
32128−23	Nut−HHF	82	3	4
32128−23	Nut−HHF	92	7	20
32128−23	Nut−HHF	94	25	6
32128−23	Nut−HHF	86	26	4
32128−23	Nut−HHF	4	34	3
32128−23	Nut−HHF	45	39	4
32128−23	Nut−Lock	77	8	12
32128−25	Nut−HHF	70	3	6
32128−25	Nut−HHF	71	18	2
32128−25	Nut−HHF	36	20	2
32128−25	Nut−Lock	25	19	4
32128−32	Nut−HHF	91	1	4
32128−43	Nut−HHF	82	19	16
32128−43	Nut−HHF	92	25	32
32128−45	Nut−HHF	92	8	8
32136−2	Nut−Castle	90	1	4
32136−2	Nut−Castle	77	41	2
32136−2	Nut−Slotted	80	36	2
32136−13	Nut−Castle	77	33	4
32144−1	Screw−HH	7	26	2
32144−1	Screw−HH	37	30	2
32144−11	Screw−HFH	42	21	8
32144−11	Screw−Thread Forming	88	60	4
32144−19	Screw−Round Hd.	13	24	4
32144−64	Screw−HWH	4	13	4
32144−69	Screw−HWH	44	54	6
32149−1	Nut−Keps	86	47	1
32149−1	Nut−Keps	84	66	1
32149−2	Nut−Keps	9	4	4
32149−2	Nut−Keps	19	7	2
32149−2	Nut−Keps	74	8	3
32149−2	Nut−Keps	43	16	16
32149−2	Nut−Keps	7	20	2
32149−2	Nut−Keps	11	36	3
32149−2	Nut−Keps	28	55	2
32149−2	Nut−Lock	45	29	10
32149−7	Nut	43	30	4
32149−7	Nut−Keps	11	23	3
32151−1	Nut−Lock	30	37	4
32151−10	Ring−Retaining	77	14	2
32151−10	Ring−Retaining	91	21	2
32151−48	Ring−Retaining	82	8	4
32151−100	Ring−Retaining	36	2	2
32152−1	Nut	43	31	2
32152−1	Nut−Lock	7	2	2
32152−1	Nut−Lock	87	3	5
32152−1	Nut−Lock	91	7	4
32152−1	Nut−Lock	6	12	4
32152−1	Nut−Lock	30	13	8
32152−1	Nut−Lock	74	26	3
32152−1	Nut−Lock	27	36	1
32152−1	Nut−Lock	24	41	3

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. No.	Ref. No.	Qty.
32152−1	Nut−Lock	28	42	4
32152−1	Nut−Lock	44	57	2
32152−2	Nut−Lock	87	5	6
32152−2	Nut−Lock	45	14	4
32152−2	Nut−Lock	25	16	4
32152−2	Nut−Lock	74	22	4
32152−2	Nut−Lock	44	27	7
32152−2	Nut−Lock	78	47	2
32152−4	Nut Lock	87	23	3
32152−4	Nut−Lock	30	12	6
32152−4	Nut−Lock	6	15	2
32152−4	Nut−Lock	37	27	2
32152−4	Nut−Lock	28	45	2
32153−3	Nut−Lock	37	44	1
32153−5	Nut−Lock	44	26	4
32153−6	Nut Lock	42	24	2
32153−6	Nut−Lock	87	4	22
32153−6	Nut−Lock	80	20	2
33004−00	Nut−HWH	2	23	2
33013−00	Nut	70	34	2
33015−00	Nut	2	22	2
33016−00	Nut−Hex.	95	1	4
33093−00	Washer−Flat	70	36	3
33096−00	Washer−Flat	95	2	4
33103−016	Screw	70	38	1
33103−050	Screw	70	41	2
33104−020	Screw−HHF	70	13	2
33104−025	Screw−HHF	2	21	2
33113−016	Screw−HH	45	32	2
33114−020	Screw−HH	71	16	4
33114−045	Screw−HH	70	19	4
33114−060	Screw−HH	70	21	2
33114−070	Screw−HH	70	7	1
33115−025	Screw−HH	71	11	2
33115−025	Screw−HH	45	25	8
33115−030	Screw−HH	45	23	12
33116−020	Screw−HH	74	28	1
33116−030	Screw−HH	45	46	3
33116−050	Screw−HH	45	36	3
340−2	Fitting−Hydraulic Straight	19	23	3
340−2	Fitting−Hydraulic Straight	21	26	5
340−2	Fitting−Hydraulic Straight	94	11	2
340−3	Fitting−Hydraulic Straight	19	13	2
340−3	Fitting−Hydraulic Straight	23	22	1
340−4	Fitting−Hydraulic Straight	21	23	2
340−8	Fitting−Hydraulic Straight	94	6	2
340−9	Fitting−Hydraulic St. LH	32	10	1
340−9	Fitting−Hydraulic Straight	75	18	5
340−15	Fitting−Hydraulic Elbow	37	20	3
340−17	Fitting−Hydraulic 90°	24	2	1
340−22	Fitting−Hydraulic Tee	23	38	1
340−57	Fitting−Hydraulic Straight	80	45	2
340−65	O−Ring	75	12	2
340−65	O−Ring	24	22	1
340−65	O−Ring	44	28	3
340−68	Fitting−Hydraulic Bulk. Tee	80	14	1
340−68	Fitting−Hydraulic Bulkhead	77	2	2
340−70	Nut−Bulkhead	27	4	6
340−70	Nut−Bulkhead	80	13	1
340−70	Nut−Bulkhead	87	15	10
340−70	Nut−Bulkhead	78	48	2
340−71	Fitting−Hydraulic Bulkhead	27	7	1
340−74	Nut−Bulkhead	87	11	4
340−77	Fitting−Hydraulic Elbow	80	19	4
340−77	Fitting−Hydraulic Elbow	87	41	4
340−78	Nut−Bulkhead	30	34	4
340−79	Fitting−Hydraulic 90°	24	23	1
340−82	Fitting−Hydraulic Elbow	32	4	2
340−86	Fitting−Hydraulic Tee	19	15	2
340−91	Fitting−Hydraulic Straight	32	6	2
340−92	Fitting−Hydraulic	28	56	1
340−92	Fitting−Hydraulic Straight	21	7	2
340−94	Tee−Hydraulic	21	35	1
340−105	Fitting−Hydraulic Elbow	38	55	1
340−125	Fitting−Hydraulic	28	59	1
340−126	Nut−Bulkhead	27	3	2
340−127	Nut−Bulkhead	27	29	2
340−128	Nut−Bulkhead	30	3	2
340−129	Fitting−Hydraulic Elbow	75	13	1
340−130	Fitting−Hydraulic Elbow	38	54	1
340−131	Fitting−Hydraulic Elbow	37	16	1
340−132	Fitting−Hydraulic Elbow	77	44	4
340−133	Fitting−Hydraulic Straight	4	32	3
340−134	Fitting−Hydraulic Elbow	37	48	1
340−135	O−Ring	25	7	2
340−136	O−Ring	24	37	1
340−142	Fitting−Hydraulic Elbow	75	15	1
340−142	Fitting−Hydraulic Elbow	32	43	2
340−148	Fitting−Hydraulic Tee RH	32	*	1
340−150	Cap−Hydraulic	24	38	1
351−78	Edging	1	3	1
353−375	Fitting−Hydraulic 90°	27	12	2
353−431	Fitting−Hydraulic 45°	75	42	2
353−536	Fitting−Fuel 90° Elbow	22	16	2
353−566	Tee−Hydraulic	21	16	1
353−781	Fitting−Fuel Elbow	73	3	2
353−988	Plug	75	39	4
353−989	Plug	75	6	1
353−990	Plug	75	34	1
353−990	Plug−Hose	21	3	2
353−991	Plug	75	31	30
353−991	Plug−Hole	21	12	8
353−992	Flange−Fitting	25	6	4
353−992	Flange−Split	45	7	4
353−994	Adapter	7	10	1
353−997	Fitting−Hydraulic Bulkhead	29	3	5
354−42	Flange−Half	25	10	2
354−42	Flange−Split, Half	45	9	2
354−79	Cap−Fitting	29	2	5
354−79	Cap−Fitting	84	70	1
354−79	Cap−Fitting	94	34	2
354−95	Fitting	44	51	1
354−104	Ring−Backup	36	5	2
354−105	Ring−Backup	36	10	2

*Not Illustrated

TABLE OF CONTENTS

Description	Page
Seat Asm	1
Seat Pivot & Bellows Asm	2
Seat Suspension Asm	3
Steering Tower Asm	4
Power Steering Valve Asm No. 92−9748	5
Steering Brake Asm	6
Service Brake Asm	7
Brake System Master Cylinder No. 69−2640	8
Traction Pedal & Cruise Control Asm	9
Tool Box Asm	10
Control Box Asm	11
Diagnostic Display Asm	12
Upper Control Panel Asm	13
Lower Control Panel Asm	14
Electrical Schematic	15
Controller Electrical Schematic	16
Operators Control Panel Electrical Schematic	17
Throttle Asm	18
Lift Valve Installation Asm	19
Lift Valve Asm No. 69−1780	20
Counterbalance Manifold Asm	21
Fuel Tank Asm	22
Hydraulic Tank Asm	23
Hydraulic Filter Asm	24
Hydraulic Pump Installation Asm	25
Double Gear Pump No. 69−2050	26
Frame Asm	27−28
Hydraulic System Diagnostic Panel Asm	29
Hydraulic Line Clamps Asm	30
Hydraulic Schematic	31
Front Wheel Asm	32−33
Wheel Motor No. 69−3050	34
Planetary Gear Drive Asm No. 69−1730	35
Wheel Brake Asm	36
Variable Displacement Pump Installation	37−38
Gear Pump & Flow Divider No. 69−2220	39
Variable Displacement Pump No. 93−9322	40−41
Cowl Asm	42
Hood Asm	43
Radiator & Oil Cooler Asm	44
Engine Installation Asm	45
Cylinder Head Asm	46
Valve Mechanism Asm	47
Rocker Cover & Camshaft Asm	48
Crankcase Asm	49
Flywheel Housing & Main Metal Asm	50
Timing Gear Case & Timing Gear Asm	51
Oil Pan & Oil Level Asm	52
Piston & Connecting Rod Asm	53
Crankshaft & Flywheel Asm	54
Inlet & Exhaust Manifold Asm	55
Oil System Asm	56
Cooling System Asm	57
Fuel Injection Pump Mount Asm	58
Nozzle Asm	59
Injection Pump Asm	60−61
Governor Asm	62−63
Feed Pump Asm	64
Fuel Filter Asm	65
Electrical Components Asm	66
Alternator Asm	67
Overhaul Gasket Kit Asm	68−69
Fan Drive Asm	70
Muffler & Air Cleaner Asm	71
Air Cleaner Asm No. 98−0800	72
Fuel/Water Filter Asm	73
Battery Frame Asm	74
PTO Manifold Asm	75−76
Rear Axle Asm	77−78
Hydraulic Cylinder Asm No. 98−0661	79
Front Lift Arm Asm	80
Hydraulic Cylinder Asm No. 92−4971	81
Center Deck Model No. 30592 Carrier Frame Asm	82
Center Deck Model No. 30592	83−84
Center Deck Model No. 30592 Left Wing Asm	85
Center Deck Model No. 30592 Ring Wing Asm	86
Wing Deck Lift Asm	87−88
Hydraulic Cylinder Asm No. 74−2170	89
Wing Deck Latch Asm	90
Wing Deck Lift Arm Asm	91
Wing Deck Model No. 30591 L.H. & 30593 R.H.	92−93
Wing Deck Model No. 30591 L.H. & 30593 R.H. Drive Asm	94
Hydraulic Motor Asm No. 94−4907	95
Spindle Asm	96
10” & 13” Foam Filled Tire Assemblies (Optional)	97
TORO Part Number Index	98−114

Compliance with Radio Interference Regulations Certified.
Certifie Conforme au Reglement sur le Brouillage Radioelectrique.

Litho in U.S.A.

MAINTENANCE RECORD

Date								