Form No. 3400-840 Rev B

TORO®

Count on it.

Parts Catalog

TimeCutter® SW 5425

Riding Mower

Model No. 74793—Serial No. 316000001 and Up

Register at www.Toro.com.
Original Instructions (EN)

3400-840 B

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1,6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.


Contents

Frame, Front Axle and Caster Wheel Assembly 4
Deck Lift Assembly 6
Steering Column Assembly 8
Speed Control Assembly 10
Neutral Return Assembly 12
Steering Gear Assembly 14
Steering Cable Assembly 16
Steering Assembly 18
Motion Control Assembly 20
Brake Assembly 22
Seat Assembly 24
Seat Assembly No. 131-4147 26
Belt and Idler Assembly 28
Hydro Transaxle Drive and Rear Wheel Assembly 30
2 Ply Wheel and Tire Assembly No. 131-3673 32
RH Transaxle Assembly No. 131-3641 34
LH Transaxle Assembly No. 131-3640 36
Clutch Assembly 38
Engine and Muffler Assembly 40
Fuel System Assembly with Non-Canister Style Air Filter 42
Carburetor Assembly No. 127-9289 with Non-Canister Style Air Filter 44
Air Intake and Filtration Assembly with Non-Canister Style Air Filter 46
Ignition and Electrical Assembly 48
Crankcase and Crankshaft Assembly 50
Governor Control Assembly 52
Piston and Cylinder Head Assembly 54
Blower Housing Assembly 56
Gasket and Seal Kit Assembly 58
Body Styling and Fuel Tank Assembly 60
Fuel Delivery Assembly 62
Wire Harness Assembly 64
Battery and Electrical Assembly 66
54 Inch Deck Assembly 68
54 Inch Deck Decal Assembly No. 130-7004 70
54 Inch Deck, Belt and Blade Assembly 72
Attachments and Accessories 74

© 2018—The Toro® Company
8111 Lyndale Avenue South
Bloomington, MN 55420

Contact us at www.Toro.com.
Printed in the USA.
All Rights Reserved

Frame, Front Axle and Caster Wheel Assembly




Frame, Front Axle and Caster Wheel Assembly (continued)

Ref.	Part Number	Qty.	Description
1	130-0805-01	1	Frame ASM (Wide)
2	132-9346-05	1	Pan-Steer, Front
3	130-0748-05	1	Housing-Spindle, LH
4	130-0746-05	1	Housing-Spindle, RH
5	119-3473	2	13 Inch Wheel And Tire ASM
5:1	119-3471	1	Tire-13 Inch
5:3	114-1640	2	Bushing-Flange
5:4	232-27	1	Stem-Valve
5:5	302-5	1	Fitting-Grease
5:99	232-46	1	Tube-Inner ●
6	119-3475	2	Spanner
7	325-37	2	Screw-HH
8	3296-45	2	Nut-Lock, NI
9	130-0670-03	2	Caster Fork ASM
10	117-7394	2	Washer-Thrust
11	109-3678	2	Bearing-Ball
12	131-1032	2	Washer-Flat
13	3234-47	2	Screw-HHF
14	130-6979-03	1	Plate-Bridge, Wide
15	130-7015	2	Cap-Caster
16	126-1963	2	Bushing-Pivot
17	115-7660	6	Screw-HHF
18	130-0689	2	Gear-Wheel, 15 Tooth
19	104-8300	6	Nut-HF, NI
20	114-4681	4	Screw-HHF
21	104-8301	4	Nut-HF, NI
22	321-4	4	Screw-HH
23	130-0829-03	1	Tube-Front, Wide
24	3274-55	10	Screw-HSBH
25	109-6658	6	Nut-Flange, NI
26	132-0941-03	1	Bracket-Upstop
27	132-0868-03	1	Guard-Front

● Not illustrated


Deck Lift Assembly



Deck Lift Assembly (continued)

Ref.	Part Number	Qty.	Description
1	1-806005	1	Pin-Cotter
2	120-5499	2	Screw-HSBH
4	119-3427-03	1	Lever-Lift
5	132-6878-03	1	Lift-Deck, Wide
6	117-7337-03	1	Brace-Seat, Rear
7	119-8875	2	Bracket-Lift
8	131-0914-03	1	Bracket-Battery
9	3296-29	2	Nut-Lock, NI
10	108-7840	2	Link-Lift
11	119-3347	1	Arm-Lift, Rear (Wide)
12	108-7845	2	Block-Pivot
14	1-633268	1	Grip-Lever
15	3272-11	2	Pin-Cotter
16	3256-26	3	Washer-Flat
17	104-8300	14	Nut-HF, NI
18	131-0901-01	1	Mount-Hydro, Front (RH)
19	131-0902-01	1	Mount-Hydro, Front (LH)
20	3234-29	6	Screw-HHF
21	3296-19	1	Nut-Hex
22	32144-70	16	Screw-HWH
24	131-3945	1	Rod-Mount, Deck
25	119-8810	1	Pin-Pivot
35	121-2989	2	Decal-Bypass
36	130-0701-03	1	Guard-Engine, Wide
37	130-6946-01	1	Crossmember-Rear, Wide
38	3234-47	8	Screw-HHF
39	117-1232-03	1	Bracket-Hitch
40	131-4036	1	Decal
43	99-4693	1	Decal


Steering Column Assembly



Steering Column Assembly (continued)

Ref.	Part Number	Qty.	Description
1	131-1052-03	1	Bracket-Pivot, Column (LH)
2	131-1053-03	1	Bracket-Pivot, Column (RH)
3	131-1054-01	1	Column-Front
4	132-9315-01	1	Column-Back
5	133-1160	1	Bearing-Spherical
6	125-5507	1	Shaft-Steering, Upper
7	131-1056	2	Spacer-Pivot, Column
8	131-1050	1	Rod-Plunger
9	131-8729	2	Washer-Shaft, Tilt
10	131-1030	1	U-Joint ASM
11	132-6868	1	Release Pedal ASM
12	701197	4	E-Ring
13	131-1049	2	Plate-Plunger
14	322-3	2	Screw-HH
15	32144-70	8	Screw-HWH
16	130-6998	2	Spring-Extension
17	3256-23	4	Washer-Plain
19	132-0921	6	Stud-Push-In
20	104-8301	7	Nut-HF, NI
21	131-1043	2	Plate-Retainer
22	5-4460	2	Washer-Pivot
23	99-4243	2	Bushing-Flange
24	322-6	2	Screw-HH
25	131-4096	1	Pad-Tilt Pedal
26	32112-6	2	Nut-Push
28	256-257	2	Bushing-Nyliner
29	131-3697	1	Spacer
30	323-23	1	Screw-HH
31	121-1759	2	Spacer


Speed Control Assembly



Speed Control Assembly (continued)

Ref.	Part Number	Qty.	Description
1	131-0904	1	Speed Control ASM
1:10	131-8667	12	Washer-Thrust
1:11	32120-18	8	E-Ring
2	127-0115	1	Rod-Hydro, RH
3	127-0116	1	Rod-Hydro, LH
4	2411-33	3	Balljoint-RH (W/Grommet)
5	3220-2	4	Nut-Jam
6	130-6887	1	Mount-Pedal Pivot
7	132-6907	1	Pivot Lever ASM
8	127-3397	1	Roller
9	56-6590	1	Bolt-Wheel
10	104-8301	1	Nut-HF, NI
11	3296-42	4	Nut-Lock, NI
12	1-543017	1	Balljoint-RH
13	130-6906	1	Rod-Threaded
14	133-1171	1	Damper-Non Cavitating
15	3234-47	4	Screw-HHF
16	32151-48	1	E-Ring
17	132-6865-01	1	Pedal-Traction
18	99-6810	2	Screw-HHF
19	131-0903	1	Neutral Return ASM
20	131-1034	1	Spacer
21	104-8300	3	Nut-HF, NI
22	322-10	1	Screw-HH
23	70-1160	2	Washer
24	324-4	1	Screw-HH
25	84-1560	1	Washer-Thrust
26	98-9040	1	Pad-Toe, Hydro Pedal
27	98-9039	1	Pad-Heel, Hydro Pedal
28	32112-6	6	Nut-Push
29	132-6917	2	Ball Stud
30	3296-4	3	Nut-Lock
31	130-6910-03	1	Bracket-Damper
32	131-1041	2	Cover-End Rod
33	32144-44	2	Screw-HWH, Thread Roll
34	32144-70	2	Screw-HWH
35	131-8736	1	Spacer-Bearing
36	132-6863	1	Decal-Release, Break


Neutral Return Assembly



Neutral Return Assembly (continued)

Ref.	Part Number	Qty.	Description
1	132-0909-03	1	Bracket-Switch
2	110-6765	2	Switch
3	130-0782	2	Arm-Switch
4	119-2309	2	Bolt-Shoulder
5	104-7201	3	Nut-HF
6	132-6915	2	Spring-Extension
7	131-3976	1	Spacer
8	321-14	1	Screw-HH


Steering Gear Assembly



Steering Gear Assembly (continued)

Ref.	Part Number	Qty.	Description
1	103-4398	4	Bearing-Flange, Iglide
2	131-1031	2	Bolt-Shoulder
3	130-0830	2	Gear-Wheel, 30 Tooth
4	83-1050	3	Spacer
5	103-0608	4	Joint-Ball, End
7	84-1560	1	Washer-Thrust
8	324-4	1	Screw-HH
9	131-8731	1	Sector Gear ASM
9:2	109-3678	1	Bearing-Ball
10	131-8733	1	Flange Bearing ASM
10:2	115-7019	1	Bushing-Straight
11	119-7640	1	Washer-Thrust
12	125-5508	1	Lower Steering Shaft ASM
13	32151-48	1	E-Ring
14	323-9	1	Screw-HH
15	323-11	1	Screw-HH
16	130-6986	1	Rod-Cross, Wide
17	104-8301	3	Nut-HF, NI
18	3256-26	1	Washer-Flat
19	99-5107	3	Nut-Lock
20	32144-70	2	Screw-HWH
21	323-8	1	Screw-HH
22	131-1037	1	Rod-Steering, Wide
23	3220-3	4	Nut-HJ
24	130-6878	1	Lever-Cable
25	131-3951	2	Bushing
26	131-3950	1	Strap-Roller
27	32144-86	1	Screw-HWHTF
28	325-11	1	Screw-HH
29	3218-5	1	Nut-Jam
30	32144-14	1	Screw-HWHTF
31	131-8736	1	Spacer-Bearing
32	131-8737	1	Pivot-Bearing
33	70-1160	1	Washer


Steering Cable Assembly



Steering Cable Assembly (continued)

Ref.	Part Number	Qty.	Description
2	3234-47	4	Screw-HHF
3	132-6943	1	Cable Bracket ASM
4	132-6944	1	Cable Bracket ASM
5	131-3623	1	Arm-Cable, RH
6	131-3647	1	Arm-Cable, LH
7	104-8300	4	Nut-HF, NI
8	7896	2	Washer-Bowed
9	32151-48	2	E-Ring
10	37-8080	2	Washer-Thrust
11	32151-47	2	Ring-Retaining
12	105-1853	2	Clamp-Hose
14	105-7699	1	Strip-Seal
15	127-0118	2	Cable-Steering


Steering Assembly



Steering Assembly (continued)

Ref.	Part Number	Qty.	Description
1	133-1152	1	Shroud-Styling, Front
2	131-1028	1	Cover-Pivot, Column
3	131-1066	1	Cap-Column
4	131-4099	1	Rear Cover And Decal ASM
4:2	132-0870	1	Decal-Danger
5	107069	2	Clip
7	120-7950	9	Screw-Shoulder
8	131-1029-03	1	Support-Footrest
9	32144-4	3	Screw-HWH
10	1-513658	1	Bumper
12	131-3630	1	Cap-Wheel, Steering
13	99-5107	1	Nut-Lock
14	131-0957	1	Wheel-Steering


Motion Control Assembly



Motion Control Assembly (continued)

Ref.	Part Number	Qty.	Description
1	125-5458-03	1	Box-Control, Wide
2	132-6880	1	Bellcrank-LH
3	132-6886	1	Bellcrank-RH
4	127-0146	4	Bearing-Flange
5	32105-12	2	Screw
6	3290-126	4	Screw-HWH
7	3296-2	6	Nut-Lock, NI
8	125-1812	1	Rod-Hydro, LH
9	127-3378	1	Rod-Hydro, RH
10	1-303105	2	Yoke-Adjustable
11	1-808280	2	Pin-Clevis
12	104-8300	8	Nut-HF, NI
13	3220-2	2	Nut-Jam
14	119-8842	2	Mount-Rod, Hydro
15	1-603807	2	Spring-Return, Neutral
16	3256-23	2	Washer-Plain
17	3234-47	4	Screw-HHF
20	1-806003	2	Pin-Cotter
22	119-8870	1	Decal-HOC
23	32144-70	2	Screw-HWH


Brake Assembly



Brake Assembly (continued)

Ref.	Part Number	Qty.	Description
1	130-0795	1	Brake Box ASM
2	121-2976	1	Rod-Brake, Wide (RH)
3	121-2977	1	Rod-Brake, Wide (LH)
4	117-1169	4	Spring-Compression
5	3290-307	2	Pin-Cotter
6	32144-36	4	Screw-PPH
7	130-6974	1	Cover-Connector
8	32144-4	2	Screw-HWH
10	3296-42	2	Nut-Lock, NI
11	119-8952	6	Washer
12	130-0790-03	1	Bracket-Mount, Brake
13	94-4496	2	Screw-PPH


Seat Assembly



Seat Assembly (continued)

Ref.	Part Number	Qty.	Description
1	132-0919-03	1	Pan-Seat
2	131-4147	1	Seat ASM
3	115-4966	1	Rod-Stop
5	3290-250	2	Pin-Cotter
6	92-7054	3	Spring-Compression
7	104-8300	5	Nut-HF, NI
10	131-1038	1	Bracket-Stop, Seat
11	107069	1	Clip
13	119-3431-03	2	Support-Tank, Rear
14	132-0888	1	Decal
17	99-6810	1	Screw-HHF
18	106-8717	1	Decal-Service, CE
19	131-1039-03	1	Support-Pod, Wide
20	32144-70	4	Screw-HWH
21	3234-29	3	Screw-HHF
24	1-413088	2	Bushing-Lever, Lift
25	131-4008-03	1	Bracket-Latch, Seat
26	3274-55	2	Screw-HSBH


Seat Assembly No. 131-4147



Seat Assembly No. 131-4147 (continued)

Ref.	Part Number	Qty.	Description
2	131-4149	1	Cushion-Seat, Back
3	131-4151	1	Cushion-Seat, Bottom
4	131-4153	1	Track ASM
5	131-4154	1	Bushing ASM
6	131-4155	1	Armrest Kit
7	131-4156	1	Shell
8	82-2190	1	Switch-Bail
9	110-4163	2	Cushion-Rest, Arm


Belt and Idler Assembly



Belt and Idler Assembly (continued)

Ref.	Part Number	Qty.	Description
3	3230-8	1	Screw-CARR
6	104-8300	2	Nut-HF, NI
7	322-7	1	Screw-HH
8	104-6415	1	Spring-Return, Pedal
9	5-4460	1	Washer-Pivot
10	130-6976	1	V-Belt
11	119-8822	1	Pulley-Idler
12	106-2176	1	Pulley-Idler
13	119-3326	1	Arm-Idler
14	119-3353	1	Spacer
15	119-3327	1	Spacer-Arm, Idler
25	3256-3	1	Washer-Flat


Hydro Transaxle Drive and Rear Wheel Assembly



Hydro Transaxle Drive and Rear Wheel Assembly (continued)

Ref.	Part Number	Qty.	Description
1	131-3641	1	RH Hydro Transmission ASM
2	131-3640	1	LH Hydro Transmission ASM
4	322-11	4	Screw-HH
5	322-13	4	Screw-HH
6	104-8300	12	Nut-HF, NI
16	131-3673	2	2 Ply Tire And Wheel ASM
17	242-50	8	Nut-Lug
18	117-7264-03	2	Mount-Hydro
19	131-0900	1	Rod-Bypass, LH
20	324-10	4	Screw-HH
21	119-3342-03	1	Plate-Cross, Hydro
22	3234-29	4	Screw-HHF
23	3290-307	2	Pin-Cotter
24	130-7049	1	Rod-Bypass, RH
26	3296-48	6	Nut-Lock, NI
27	3256-25	6	Washer-Flat
28	324-8	2	Screw-HH
29	119-8952	2	Washer
30	3256-23	6	Washer-Plain

2 Ply Wheel and Tire Assembly No. 131-3673




2 Ply Wheel and Tire Assembly No. 131-3673 (continued)

Ref.	*Part Number*	*Qty.*	*Description*
2	131-3680	1	Tire-2 Ply
3	232-27	1	Stem-Valve
4	93-3893	1	Tube-Inner ●

● Not illustrated


RH Transaxle Assembly No. 131-3641



RH Transaxle Assembly No. 131-3641 (continued)

Ref.	Part Number	Qty.	Description
1	106-8674	1	Main Housing ASM
2	106-8675	1	Side ASM
3	110-8561	1	Pump Block ASM
4	103-2666	1	Cylinder Block Kit
5	104-2189	1	Plug-Thread, Straight
6	117-5359	16	Screw-HHF
7	106-8677	2	Ring-Retaining, External
8	106-8678	1	Rod-Bypass
9	106-8679	1	Ring-Retaining, Internal
10	104-5304	1	Swashplate-Trunnion
11	104-2116	1	Stud
12	112-9853	1	Puck-Friction
13	94-1936	1	Spring-Block
14	94-1937	1	Washer-Thrust
15	104-5306	1	Shaft-Input
16	104-5311	1	Bearing-Ball
17	104-5307	1	Ring-Retaining
18	104-5308	1	Spacer
19	104-5310	1	Seal-Lip
20	104-5309	2	Ring-Retaining
21	94-6922	2	Bearing-Thrust
22	104-5339	1	Washer-Flat
23	104-5340	1	Ring-Retaining
24	132-0912	1	Gear-12T
25	106-8683	1	Shaft-Motor
26	104-5360	1	Washer
27	94-1933	2	Washer
28	132-0911	1	Gear-49T
29	104-5318	1	Gear-Jackshaft, 10T
30	104-5329	1	Pin-Jackshaft
31	112-9854	1	Ring-Spiral, Retaining
32	112-9855	1	Gear-52T, Bull
33	112-9856	1	Washer
34	112-9857	1	Bearing-Sleeve
35	120-7104	1	Shaft-Axle
36	112-9859	1	Bushing-Axle
37	112-9860	1	Seal-Lip
38	106-8686	1	Seal Kit
39	106-8687	1	Expansion Plate Kit
40	121-5746	1	Fan Pulley Kit
41	106-8688	1	Brake Arm Kit
42	112-9862	1	Center Section Filter Kit
44	107-2489	1	Bypass Arm Kit
45	114-1634	1	Filter Kit
46	120-7109	1	Tube-Axle
47	106-8694	1	Disc-Brake, Cog
48	115-5057	1	Cover-Nut, Axle
49	109-5939	1	Hub Kit
50	112-9866	1	Breather Kit
51	114-1635	1	Breather ASM
52	117-5362	1	Control Arm Kit
53	114-8467	1	Puller-Hub, 4 Bolt


LH Transaxle Assembly No. 131-3640



LH Transaxle Assembly No. 131-3640 (continued)

Ref.	Part Number	Qty.	Description
1	106-8695	1	Main Housing ASM
2	106-8696	1	Side ASM
3	110-8561	1	Pump Block ASM
4	103-2666	1	Cylinder Block Kit
5	104-2189	1	Plug-Thread, Straight
6	117-5359	16	Screw-HHF
7	106-8677	2	Ring-Retaining, External
8	106-8678	1	Rod-Bypass
9	106-8679	1	Ring-Retaining, Internal
10	104-5304	1	Swashplate-Trunnion
11	104-2116	1	Stud
12	112-9853	1	Puck-Friction
13	94-1936	1	Spring-Block
14	94-1937	1	Washer-Thrust
15	104-5306	1	Shaft-Input
16	104-5311	1	Bearing-Ball
17	104-5307	1	Ring-Retaining
18	104-5308	1	Spacer
19	104-5310	1	Seal-Lip
20	104-5309	2	Ring-Retaining
21	94-6922	2	Bearing-Thrust
22	104-5339	1	Washer-Flat
23	104-5340	1	Ring-Retaining
24	132-0912	1	Gear-12T
25	106-8683	1	Shaft-Motor
26	104-5360	1	Washer
27	94-1933	2	Washer
28	132-0911	1	Gear-49T
29	104-5318	1	Gear-Jackshaft, 10T
30	104-5329	1	Pin-Jackshaft
31	112-9854	1	Ring-Spiral, Retaining
32	112-9855	1	Gear-52T, Bull
33	112-9856	1	Washer
34	112-9857	1	Bearing-Sleeve
35	120-7104	1	Shaft-Axle
36	112-9859	1	Bushing-Axle
37	112-9860	1	Seal-Lip
38	106-8686	1	Seal Kit
39	106-8697	1	Expansion Plate Kit
40	121-5746	1	Fan Pulley Kit
41	106-8688	1	Brake Arm Kit
42	112-9861	1	Center Section Filter Kit
44	120-5549	1	Bypass Kit
45	114-1634	1	Filter Kit
46	120-7109	1	Tube-Axle
47	106-8694	1	Disc-Brake, Cog
48	115-5057	1	Cover-Nut, Axle
49	109-5939	1	Hub Kit
50	112-9866	1	Breather Kit
51	114-1635	1	Breather ASM
52	117-5362	1	Control Arm Kit
53	114-8467	1	Puller-Hub, 4 Bolt


Clutch Assembly



Clutch Assembly (continued)

Ref.	Part Number	Qty.	Description
5	3234-42	1	Screw-HHF
6	130-6854	1	Pulley-Engine
7	120-2217	1	Isolator-Clutch
8	119-8885	1	Stop-Clutch
10	104-8301	1	Nut-HF, NI
11	127-3410	1	Clutch-PTO
13	3212-19	1	Screw-HH
20	112843	1	Washer


Engine and Muffler Assembly




Engine and Muffler Assembly (continued)

Ref.	Part Number	Qty.	Description
1	127-9041	1	Engine-2P77F
2	131-4157	1	Decal
4	130-6851	1	Muffler
5	132-0902	1	Decal-Engine
7	32144-109	4	Screw-Taptite
8	3256-24	3	Washer-Flat
9	131-1071-03	1	Shield-Heat
10	46-8560	2	Screw-HHFTF
11	131-1097	1	Decal-Drain, Oil
12	127-9076	1	Placard-Intake


Fuel System Assembly
with Non-Canister Style Air Filter






If equipped with canister type air filter refer to kit model 136-7860 for carburetor assembly and internal carburetor parts.


96



97



98




Fuel System Assembly with Non-Canister Style Air Filter (continued)

Ref.	Part Number	Qty.	Description
1	133-1563	1	Filter-Fuel
2	120-4251	6	Clamp-Fuel Line
3	120-4371	1	Line-Fuel
4	127-9206	1	Pump-Fuel
5	120-4225	2	Screw-HHF
6	127-9205	1	Hose-Fuel
7	127-9207	1	Hose-Fuel
8	127-9230	2	Gasket-Intake
9	120-4284	4	Screw-HHF
10	127-9244	1	Manifold-Intake
11	127-9245	4	Stud
12	127-9246	2	Gasket-Carburetor
13	127-9247	1	Insulator-Carburetor
14	127-9248	1	Linkage-Throttle
96	127-9289	1	Carburetor Replacement Kit
97	127-9290	1	Carburetor Repair Kit
98	127-9292	1	Solenoid Kit
99	127-9303	1	High Altitude Kit ●

● Not illustrated

Carburetor Assembly No. 127-9289
with Non-Canister Style Air Filter




If equpped with canister type
air filter refer to kit model 136-7860
to look up parts.

Carburetor Assembly No. 127-9289 with Non-Canister Style Air Filter (continued)

Ref.	Part Number	Qty.	Description
1	127-9249	1	Carburetor
1	127-9251	1	Gasket-Carburetor
3	127-9246	2	Gasket-Carburetor
14	127-9319	1	Spring
20	127-9325	1	Cover-Shaft, Choke
23	127-9328	1	Spring
25	127-9330	1	Spring
28	127-9333	1	Clamp-Lock
30	127-9335	1	Spring

Ref.	Part Number	Qty.	Description
90	127-9290	1	Carburetor Repair Kit
91	127-9292	1	Solenoid Kit
92	127-9340	1	Float Kit
93	127-9341	1	Bowl Kit
94	127-9342	1	Throttle Shaft Kit
95	127-9343	1	Nozzle And Jet Kit
96	127-9344	1	Air Jet Kit
97	127-9345	1	Choke Shaft Kit
98	127-9347	1	Idlestop Kit


Air Intake and Filtration Assembly with Non-Canister Style Air Filter



Air Intake and Filtration Assembly with Non-Canister Style Air Filter (continued)

Ref.	Part Number	Qty.	Description
1	127-9235	1	Tube-Breather
2	127-9234	2	Clamp-Hose
3	127-9252	1	Filter-Air, Complete
3:1	127-9288	1	Filter-Pre, Foam
4	127-9253	1	Hose-Fuel
5	127-9187	1	Clamp-Hose
6	120-4236	4	Nut-Flange
7	127-9047	1	Manifold-Filter, Air
8	127-9251	1	Gasket-Carburetor


Ignition and Electrical Assembly




Ignition and Electrical Assembly (continued)

Ref.	Part Number	Qty.	Description
1	127-9197	4	Screw-HWH
2	127-9198	1	Screen-Rotating
3	127-9199	4	Screw-HWH
4	127-9200	1	Fan-Cooling
5	127-9201	1	Screw-HWH
6	127-9202	1	Washer-Flat
7	127-9306	1	Flywheel
8	127-9210	4	Screw-HSH
9	127-9211	1	Alternator
10	133-1564	1	Motor-Starter
11	127-9208	1	Bracket-Lift
12	120-4231	2	Screw-HHF
13	121-0007	4	Bolt-Flange
14	127-9216	2	Ignition Coil ASM
15	81-3250	2	Spark Plug
16	127-9220	4	Tie-Zip
17	127-9219	1	Regulator-Voltage W/Harness
18	120-4216	1	Screw-HHF
19	120-4232	2	Screw-HHF
20	133-1562	1	Pinion-Starter

Crankcase and Crankshaft Assembly






Crankcase and Crankshaft Assembly (continued)

Ref.	Part Number	Qty.	Description
1	120-4232	14	Screw-HHF
2	127-9212	1	Baffle
3	127-9213	1	Cover-Breather
4	127-9214	1	Gasket-Breather
5	127-9215	1	Filter-Breather
6	120-4216	1	Screw-HHF
7	127-9217	1	Valve-Breather
8	120-4267	1	Seal-Oil
9	127-9223	1	Crankcase
10	127-9221	1	Fitting-Threaded, Oil Filter
11	120-4276	1	Filter-Oil
12	127-9218	1	Oil Tube ASM
12:1	127-9283	1	Dipstick
12:2	127-9284	1	O-Ring
12:4	127-9286	1	O-Ring
13	127-9255	1	Crankshaft
14	127-9261	1	Cover-Screen, Oil
15	127-9262	1	Screen-Oil
16	127-9263	1	Retainer-Screen
17	120-4274	2	Pin-Dowel
18	127-9264	1	Plate-Retainer
19	127-9265	1	Spring
20	127-9266	1	Valve-Ball
21	120-4262	2	O-Ring
22	127-9267	1	Gasket-Cover, Crankcase
23	120-4285	1	Plug-Drain
24	127-9268	1	Cover-Crankcase
25	127-9293	1	Oil Drain Hose ASM
26	127-9275	1	Fitting-Hose
27	127-9276	1	Clamp-Hose
28	127-9271	1	Seal
29	121-0473	10	Screw-HHF
30	127-9274	1	Cover-Oil Pump
31	127-9273	1	O-Ring
32	127-9272	1	Oil Pump ASM
33	120-4275	1	Deflector-Oil, Rubber
34	133-1568	1	Camshaft
35	133-1569	1	Governor ASM
36	127-9238	1	Rod-Governor
37	120-4258	2	Washer-Plain
38	120-4257	1	Seal-Oil
39	120-4256	1	Pin-Hair
40	120-4232	2	Screw-HHF


Governor Control Assembly



Governor Control Assembly (continued)

Ref.	Part Number	Qty.	Description
1	127-9250	1	Clip-Linkage
2	127-9242	1	Linkage-Choke
3	127-9241	1	Spring-Governor
4	120-4238	1	Bolt-Arm, Governor
5	120-4236	1	Nut-Flange
6	127-9239	1	Arm-Governor
7	127-9240	1	Spring-Governor
8	133-1570	1	Control Plate ASM
9	120-4232	2	Screw-HHF


Piston and Cylinder Head Assembly



Piston and Cylinder Head Assembly (continued)

Ref.	Part Number	Qty.	Description
1	127-9256	2	Connecting Rod ASM
2	127-9258	4	Clip-Pin, Piston
3	127-9257	2	Pin-Piston
4	127-9259	2	Piston
5	127-9260	2	Piston Ring Set
6	127-9224	4	Lifter-Valve
7	127-9225	4	Rod-Push
8	127-9226	2	Gasket-Head, Cylinder
9	127-9227	4	Pin-Dowel
10	127-9228	2	Valve Set
11	127-9229	1	Head-Cylinder
12	127-9254	1	Head-Cylinder
13	127-9236	4	Stud
14	120-4317	2	Gasket-Exhaust
15	127-9279	4	Washer-Lock, Split
16	121-0199	4	Nut-HH
17	81-3250	2	Spark Plug
18	127-9231	6	Screw-HWH
19	127-9232	4	Screw-HWH
20	120-4303	4	Seat-Spring, Valve
21	120-4304	4	Seal-Stem, Valve
22	120-4305	4	Spring-Valve
23	120-4306	4	Retainer-Spring, Valve
24	120-4307	4	Keeper-Valve
25	127-9233	2	Plate-Guide, Push Rod
26	127-9294	4	Rocker Arm ASM
27	127-9295	2	Gasket-Valve Cover
28	127-9050	2	Cover-Valve
29	120-4225	8	Screw-HHF
30	120-4214	1	Screw-Shoulder, HH


Blower Housing Assembly



Blower Housing Assembly (continued)

Ref.	Part Number	Qty.	Description
1	133-1571	4	Screw-PPH, Plastic
2	127-9045	1	Cover-Fan
3	127-9196	6	Screw-Shoulder, HWH
4	133-1572	1	Shroud-Engine
5	127-9046	1	Door-Filter, Air
6	127-9280	2	Pin-Hair
7	127-9282	2	Pin
8	127-9281	1	Plate-Spring
9	127-9049	1	Baffle-Air, Left
10	120-4210	2	Screw-Shoulder, HHF
11	127-9048	1	Baffle-Air, Right
12	127-9287	1	Cleat-Hose
13	120-4232	2	Screw-HHF


Gasket and Seal Kit Assembly



Gasket and Seal Kit Assembly (continued)

Ref.	Part Number	Qty.	Description
1	127-9296	1	Gasket And Seal Kit
1:1	127-9214	1	Gasket-Breather
1:2	120-4267	1	Seal-Oil
1:3	127-9226	2	Gasket-Head, Cylinder
1:4	127-9230	2	Gasket-Intake
1:5	127-9295	2	Gasket-Valve Cover
1:6	120-4317	2	Gasket-Exhaust
1:7	120-4257	1	Seal-Oil
1:8	127-9246	2	Gasket-Carburetor
1:9	127-9251	1	Gasket-Carburetor
1:10	120-4262	2	O-Ring
1:11	127-9267	1	Gasket-Cover, Crankcase
1:12	127-9271	1	Seal
1:13	127-9273	1	O-Ring
1:14	127-9284	1	O-Ring
1:15	127-9286	1	O-Ring


Body Styling and Fuel Tank Assembly



Body Styling and Fuel Tank Assembly (continued)

Ref.	Part Number	Qty.	Description
1	119-3338	1	Pod-RH
2	119-3337	1	Pod-LH
3	121-0773	1	Decal-Panel, Control
4	121-0769	1	Cable-Throttle
5	3258-166	3	Screw-PRH
6	107069	3	Clip
7	120-5461	1	Cap-Fuel, Ratcheting
8	119-3377-03	1	Plate-Control
9	119-3324	1	Fuel Tank ASM
9:1	121-0793	1	Connector-Elbow, 90 DEG
9:2	46-6560	2	Bushing
9:4	117-7400	1	Fitting-Plastic
10	120-7950	8	Screw-Shoulder
11	609830	2	Spring
12	112-9753	1	Cable-Choke
13	3253-21	1	Washer-Lock
14	3220-3	1	Nut-HJ
15	130-7039	1	Cover-RH
16	130-7040	1	Cover-LH
17	119-3395-03	1	Support-Tank, Front
18	32144-70	2	Screw-HWH
19	131-3621	1	Decal-Nmir
20	131-3620	1	Decal-Control, Pedal
22	131-3664	1	Decal-Keychoice
23	131-3954	1	Decal-Brake, Parking
24	132-0904	1	Decal-Shutdown

Fuel Delivery Assembly



Fuel Delivery Assembly (continued)

Ref.	Part Number	Qty.	Description
3	109-0281	1	Hose-Fuel
8	2412-98	3	Clamp-Hose
9	614249	1	Tie-Cable
10	117-5399	1	Adaptor-Orifice
11	110-1876	1	Hose-Fuel


Wire Harness Assembly



Wire Harness Assembly (continued)

Ref.	Part Number	Qty.	Description
1	131-3639	1	Key-Toro
2	132-9361	1	Harness-Wire
2:1	109103	1	Fuse-Blade, 30 Amp
2:2	109102	1	Fuse-Blade, 25 Amp
3	130-6874	1	Switch-Rocker, (On)-Off-(On)
4	119-3068	1	Switch-Momentary, N.O.
5	131-4136	1	Light-Indicator


Battery and Electrical Assembly



Battery and Electrical Assembly (continued)

Ref.	Part Number	Qty.	Description
1	105-1692	1	Battery
2	117-2221	1	Switch-Ignition
3	63-8360	1	Key-Ignition
4	114-0279	1	Switch-PTO, On-On-(On)
5	32103-22	1	Nut-Wing
8	117-1197	1	Solenoid
9	121-0711	1	Cable-Battery, Positive
10	3229-1	1	Bolt-CARR
11	119-8899	1	Cable-Battery, Black
12	104-2466	1	Holddown-Battery
13	321-3	1	Screw-HH
15	3256-22	2	Washer-Flat
17	119-8897	1	Cable-Battery, Red
18	32128-33	1	Nut-HF
19	33003-00	1	Nut-HF
20	32144-4	2	Screw-HWH
21	3220-2	2	Nut-Jam
22	3234-14	1	Screw-HHF


54 Inch Deck Assembly



54 Inch Deck Assembly (continued)

Ref.	Part Number	Qty.	Description
1	130-7004	1	54 Inch Deck ASM
2	131-4138	1	Bracket-Hanger, RH
3	131-3935	1	Bracket-Hanger, LH
4	104-8301	5	Nut-HF, NI
5	3231-2	2	Bolt-CARR
6	104-8300	4	Nut-HF, NI
7	95-2747	2	Fitting-Washout
8	46-6290	2	O-Ring
9	46-8560	4	Screw-HHFTF
10	131-0961	1	Decal-Deck
11	322-3	2	Screw-HH
12	95-3270	1	Connector-Hose
13	112-3983-03	1	Baffle-Cutoff
14	108-7890	2	Cover-Belt
15	32144-1	6	Screw-Taptite
16	112-3977	3	Bolt-Shoulder
17	1-603299	3	Roller-Scalp, Anti
18	112-3950	1	Rod-Pivot
19	108-7895	1	Deflector
20	110-6694	1	Spring-Torsion
22	3296-59	1	Nut-Lock, NI
23	3230-23	1	Screw-CARR
24	120-7024	1	Screw-Shoulder, HHF
25	110-0618	1	Pin-Clevis
26	3256-23	1	Washer-Plain
27	1-806003	1	Pin-Cotter
29	131-0955	1	Rod-Level, Deck


54 Inch Deck Decal Assembly No. 130-7004



54 Inch Deck Decal Assembly No. 130-7004 (continued)

Ref.	Part Number	Qty.	Description
2	93-7009	1	Decal-Danger
3	132-0872	2	Decal-Danger, Deck
4	99-3943	1	Decal-Routing, Belt
5	112-9840	1	Decal-Scalp, Anti
6	322-2	1	Screw-HH
7	104-8300	2	Nut-HF, NI
8	3230-23	1	Screw-CARR

54 Inch Deck, Belt and Blade Assembly



54 Inch Deck, Belt and Blade Assembly (continued)

Ref.	Part Number	Qty.	Description
1	130-0843	1	Belt-V
2	323-9	3	Screw-HH
3	3256-24	2	Washer-Flat
4	106-2175	3	Pulley-Idler, Flat
5	104-8301	2	Nut-HF, NI
6	114-8540	1	Arm-Idler
7	120-2229	2	Washer
8	114-0463	2	Washer-Friction, Composite
9	115-4986	1	Spacer
10	323-7	1	Screw-HH
11	3219-6	3	Nut-Hex
12	130-0656	3	Pulley ASM
13	32144-41	12	Screw-Taptite
14	26-0671	3	Screw-HH
15	3290-465	3	Washer-Belleville
16	121-0751	3	Spindle ASM
16:1	117-7267	1	Spindle
16:2	120-7935	2	Spacer
16:3	38-7820	2	Bearing-Ball
17	115-2454-03	3	Blade-Hi Lift, 18.75 Inch
18	1-603414	1	Spring-Extension
19	112-3973	1	Hook-Return, Spring
20	117-7268	3	Shaft-Spindle
21	63-7400	1	Washer-Rebound

Attachments and Accessories

For 74793 TimeCutter SW 5425 Riding Mower

Product Name	Model/Part
Hourmeter Kit	116-5461
All Season Synthetic Oil	117-0066
Fuel Stabilizer (4oz)	117-0089
Fuel Stabilizer (16oz)	117-0090
Seat Cover w/Arm Rest	117-0097
Jack Mount Kit	126-5251
Jack Kit	127-6666
Attachment Mount Kit	131-3966
54in Striping Kit	131-4165
54in Bagging Enhancement Kit	131-4166
54in Recycler Kit	131-4185
Floor Mat Kit	132-6920
HD Air Cleaner Kit	136-7860
10w30 4-cycle Engine Oil (32oz Bottle)	38280
Toro 4-cycle SAE 30 Oil (32oz Bottle)	38903
Storage Cover	490-7516
Sunshade Kit	79011
Cargo Carrier	79040
50in and 54in Bagger	79392

Notes:



Count on it.