Form No. 3425-911 Rev A

TORO®

Count on it.

Parts Catalog

Super Recycler®

Lawn Mower

Model No. 21383—Serial No. 400000000 and Up

Register at www.Toro.com.
Original Instructions (EN)

3425-911 A

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1,6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.


Contents

Housing Assembly 4
Mulch Plug Assembly 6
Bag Assembly 8
Engine and Blade Assembly 10
Fuel System Assembly 12
Air Intake and Filtration Assembly 14
Ignition and Electrical Assembly 16
Crankcase Assembly 18
Governor Assembly 20
Piston and Cylinder Head Assembly 22
Blower Housing Assembly 24
Front Wheel and Height-of-Cut Assembly 26
Transmission and Rear Wheel Height-of-Cut Assembly 28
Brake Control Assembly 30
Handle Assembly 32
Attachments and Accessories 34

© 2019—The Toro® Company
8111 Lyndale Avenue South
Bloomington, MN 55420

Contact us at www.Toro.com.
Printed in the USA.
All Rights Reserved


Housing Assembly



Housing Assembly (continued)

Ref.	Part Number	Qty.	Description
1	140-3768	1	Housing ASM
1:2	140-3770	2	Kicker-Housing
1:3	32144-111	4	Screw-PPH
1:4	94-8072	1	Decal-Danger
1:7	125-5092	1	Decal-Placement, Foot
1:8	137-9196	1	Decal-Quick Wash
4	107-7494	1	Cover-Belt
5	49-2040	3	Screw-HWHTF
6	112-6416	1	Bracket-Cover
7	137-4795	2	Screw
8	99-5291	1	Rod-Cover
9	99-5293	1	Spring-Torsion
10	107-3717	1	Discharge Door ASM
10:2	138-3221	1	Latch-Door
10:3	138-3242	1	Cap-Door
10:4	137-9137	1	Screw-PPH
11	108-3753	1	Chute-Discharge, Side
12	138-3224	1	Bracket-Cable, Traction
13	62-3720	1	Clamp-Cable
14	112-6401	1	Coupling-Hose, Washout Port
15	112-6400	1	Port-Washout
17	112-6438	1	Washer-Seal, Washout Port
18	3254-5	1	Washer-Lock
19	3218-6	1	Nut-Jam


Mulch Plug Assembly



Mulch Plug Assembly (continued)

Ref.	Part Number	Qty.	Description
1	107-7495	1	Tunnel-Discharge
2	49-2040	5	Screw-HWHTF
3	114-2668	1	Chute
4	115-8413	1	Mulch Plug ASM
5	137-9139	1	Rear Door ASM
5:2	131-4514	1	Decal-Warning
8	115-2859	1	Spring-Torsion
9	114-7924	1	Spring-Torsion
10	94-8196	2	Washer-Nylon
12	105-1316-01	1	Lip-Housing
13	63-8590	3	Screw
16	32144-70	2	Screw-HWHTF
18	120-7011	1	Shield-Trailing
19	117-1092	2	Screw-PTH
20	137-9108	1	Plate-Handle, LH
21	137-9107	1	Plate-Handle, RH


Bag Assembly



Bag Assembly (continued)

Ref.	*Part Number*	*Qty.*	*Description*
1	132-4529-03	1	Bag Frame ASM
2	114-2664	1	Grass Bag ASM


Engine and Blade Assembly



Engine and Blade Assembly (continued)

Ref.	Part Number	Qty.	Description
1	136-7858	1	Engine-1P65F-2
2	133-8189	1	Plate-Anchor
3	107-0759	1	Bolt-Shoulder
4	107-0797	1	Bushing
5	3256-16	1	Washer-Flat
6	3296-73	1	Nut-Lock, NI
7	125-1063	1	Plate-Brake
8	603773	2	Locknut
9	107-0758	1	Spacer-Bearing
10	38-7820	3	Bearing-Ball
11	138-3217	1	Retainer-Belt
12	605256	1	Spacer
13	138-3222	1	Plate-Guide
14	3231-25	1	Bolt-CARR
15	108-3792	1	Spring-Tension, Brake
16	32144-102	3	Screw-HWH
17	117-5970	1	Pulley
18	110-1790	1	Belt
19	108-9342	1	Nut-Hex
20	126-8108	1	Drum
21	3211-42	2	Screw-HH
22	107-7488	1	Cover
23	49-2040	3	Screw-HWHTF
24	138-3225	1	Disk
25	107-7487	1	Support-Blade
26	133-8183-03	1	Blade-Recycling, 21In
27	108-3766-01	1	Support-Blade
28	127-6852	2	Nut-Flange, Lock
29	98-2256	1	Clamp
30	32144-32	1	Screw
32	140-3823	1	Decal-Shroud
33	136-5863	1	Decal
34	133-8062	1	Decal-Arrestor, Spark
35	2210-316	1	Stop-Rope

Fuel System Assembly




Fuel System Assembly (continued)

Ref.	Part Number	Qty.	Description
1	136-7875	1	Cap-Fuel, Sealed
2	139-0718	1	Tank-Fuel
3	121-4167	1	Fuel Line Kit
4	133-9874	1	Canister-Carbon, 19 Cc
5	120-4451	1	Lock-Throttle
6	133-9909	1	Linkage-Choke, Thermal
7	133-9908	2	Screw-HWHTF
8	133-9907	1	Control-Thermal
9	121-4183	1	Gasket-Intake
10	133-9902	1	Spacer-Carburetor
11	133-9901	1	Insulator-Carburetor
12	121-4184	2	Gasket-Carburetor
13	133-9900	1	Carburetor
14	133-9899	1	Gasket-Carburetor
15	127-9395	1	Internal Carb Service Kit
16	121-0016	1	Bolt-Stud
17	120-4236	1	Nut-Flange
99	133-9943	1	High Altitude Kit ●

● Not illustrated


Air Intake and Filtration Assembly



Air Intake and Filtration Assembly (continued)

Ref.	Part Number	Qty.	Description
1	121-0010	2	Nut-Flange
2	133-9906	1	Shield-Muffler
3	121-0166	1	Muffler ASM
4	121-0034	1	Gasket-Exhaust
5	133-9928	1	Air Cleaner Base
6	120-4236	2	Nut-Flange
7	119-1909	1	Air Filter And Prefilter Kit
8	121-0364	1	Cover-Cleaner, Air


Ignition and Electrical Assembly



Ignition and Electrical Assembly (continued)

Ref.	Part Number	Qty.	Description
1	121-0047	1	Nut-Flange
2	133-9912	1	Cup-Starter
3	133-9913	1	Flywheel
4	120-4209	2	Screw-Shoulder, HHF
5	133-9914	1	Guard-Flywheel
6	136-7871	1	Coil-Ignition
7	133-9881	1	Guard-Flywheel
8	120-4225	1	Screw-HHF


Crankcase Assembly



Crankcase Assembly (continued)

Ref.	Part Number	Qty.	Description
1	120-4216	1	Screw-HHF
2	133-9882	1	Cover-Breather
3	133-9883	1	Gasket-Cover, Breather
4	133-9884	1	Valve-Breather
5	121-0019	1	Seal-Oil
7	133-9911	1	Tube-Breather
8	133-9915	1	Crankshaft ASM
9	121-4174	1	Camshaft ASM
10	121-0051	1	Washer-Flat
11	133-9895	1	Gasket-Cover, Case
12	133-9897	1	Cover-Crankcase
13	121-0048	1	Washer-Plain
14	121-0030	1	Screw-HHF
15	120-4223	7	Screw-HHF
16	121-0022	1	Seal-Oil
17	121-0054	2	Pin-Dowel
18	136-7863	1	Washer-Flat
19	133-9886	1	Dipstick And Fill Tube Kit
20	121-0007	1	Bolt-Flange
21	121-0369	1	Screw-HWH, Thd Form
22	136-7864	1	Governor Gear ASM


Governor Assembly



Governor Assembly (continued)

Ref.	Part Number	Qty.	Description
1	133-9880	1	Linkage-Choke
2	136-7866	2	Washer-Flat
3	133-9879	1	Air Vane-Autochoke
4	127-9196	1	Screw-Shoulder, HWH
5	121-0017	1	Clip-Harness, Wire
6	133-9891	1	Plate-Control, Throttle
7	136-7865	1	Arm-Governor
8	120-4256	1	Pin-Hair
10	121-0023	1	Spring-Return, Throttle
11	133-9892	1	Rod-Governor
12	121-0028	1	Arm-Governor
13	120-4236	1	Nut-Flange
14	120-4238	1	Bolt-Arm, Governor
15	133-9893	1	Spring-Governor
16	121-0021	1	Seal-Oil
17	120-4216	1	Screw-HHF


Piston and Cylinder Head Assembly



Piston and Cylinder Head Assembly (continued)

Ref.	Part Number	Qty.	Description
1	120-4232	5	Screw-HHF
2	133-9905	1	Cover-Valve
3	133-9904	1	Gasket-Cover, Valve
4	136-7868	1	Exhaust Rocker Arm ASM
5	136-7869	1	Intake Rocker Arm ASM
6	120-4474	2	Retainer-Valve, Spring
7	121-0187	1	Spark Plug
8	120-4473	2	Spring-Valve
9	121-0043	4	Bolt-Flange
10	121-4202	1	Seal-Stem, Valve
11	121-0045	4	Stud-Exhaust
12	121-4192	1	Valve Set
13	121-4193	2	Rod-Push
14	133-9910	1	Gasket-Head
15	121-4171	1	Piston Ring Set
16	120-4467	1	Pin-Piston
17	120-4469	1	Connecting Rod ASM
18	120-4477	2	Tappet-Valve
19	121-4173	1	Piston
20	121-0052	2	Clip-Pin, Wrist
21	121-0053	2	Pin-Dowel
22	136-7890	1	Complete Head ASM


Blower Housing Assembly



Blower Housing Assembly (continued)

Ref.	Part Number	Qty.	Description
1	127-9115	3	Nut-Acorn
2	133-9857	1	Recoil Shroud ASM
2	133-9922	1	Recoil Shroud ASM
3	136-7867	1	Shroud-Fan
4	133-9877	2	Stud-Shroud
5	133-9878	1	Stud-Shroud
6	136-7770	1	Spring-Compression, Recoil


Front Wheel and Height-of-Cut Assembly



Front Wheel and Height-of-Cut Assembly (continued)

Ref.	Part Number	Qty.	Description
1	114-3467	2	Screw-Shoulder
2	107-7492	2	Arm-Pivot
3	52-2480	2	Spacer-Wheel
4	107-7491	2	Arm-Spring
5	105-3042	2	Knob-Lever, HOC
6	49-2040	6	Screw-HWHTF
7	3256-24	2	Washer-Flat
8	603773	4	Locknut
9	92-1057	2	Bolt-Shoulder
10	140-1294	2	Wheel ASM
10:1	27-6250	2	Bushing
11	40-1940	2	Washer
12	139-1669-01	2	Plate-HOC

Transmission and Rear Wheel Height-of-Cut Assembly




Transmission and Rear Wheel Height-of-Cut Assembly (continued)

Ref.	Part Number	Qty.	Description
1	121-9184	1	Transmission ASM
2	115-4669	1	Belt-V
3	114-7977-03	1	Bracket-Transmission
4	108-7476	3	Screw-Plastite
5	138-3235	2	Cap-End
6	107-7491	2	Arm-Spring
7	105-3042	2	Knob-Lever, HOC
8	49-2040	6	Screw-HWHTF
9	100-8774	2	Pivot Arm ASM
9:2	47-2900	1	Bushing
9:3	70-9760	1	Bushing
9:4	302-56	1	Fitting-Grease
10	65-4730	2	Washer-Arm, Pivot
11	65-4740	4	Washer-Thrust, Keyed
12	65-2720	4	Ring-Retaining, Clip
13	65-4710	2	Ring-Friction
14	65-4760	2	Washer-Clutch
15	139-6644	1	Key-Rocking, L.H.
16	139-6643	1	Key-Rocking, R.H.
17	65-4750	2	Gear-Pinion
18	65-4720	2	Spring-Compression
19	92-1057	2	Bolt-Shoulder
20	140-1295	2	Wheel Gear ASM
20:3		1	Wheel ASM ●
20:3:1	27-6250	2	Bushing
21	74-1671	2	Spacer-Cover, Wheel
22	74-1660	2	Cover-Wheel
23	603773	2	Locknut
26	139-1669-01	2	Plate-HOC

● Not serviced separately


Brake Control Assembly



Brake Control Assembly (continued)

Ref.	Part Number	Qty.	Description
1	121-2347	1	Harness
2	321-50	1	Screw-HH
3	108-3788-03	1	Bail-Brake
4	3290-337	1	Nut-Speed
5	106-9169	1	Screw-HWH
6	107-7462	1	Spring-Torsion
7	107-7463	1	Spacer
8	138-3220	1	Lever
9	32128-17	1	Nut-Lock, Flange
10	112-8884	1	Knob
11	108-8155	1	Cable ASM
12	104-9368	1	Plug-Dome

Handle Assembly



Handle Assembly (continued)

Ref.	Part Number	Qty.	Description
1	137-4845-03	1	Bracket-Float, LH
2	137-4846-03	1	Bracket-Float, RH
3	137-4844	2	Knob-Handle
4	137-4793-05	1	Handle-Upper
5	130-2344	2	Bolt-Shoulder
6	3296-47	4	Nut-Lock, NI
7	138-3249	2	Quick Release ASM
7:1	32112-11	1	Nut-Push
7:2	138-3248	1	Lever-Release
7:3	138-3253	1	Anchor-Spring
7:4	115-2858	1	Spring-Compression
7:5	138-3243	1	Rod-Release
8	86-9671	1	Guide-Rope
9	3296-73	2	Nut-Lock, NI
10	114-7988	1	Guide-Cable
11	105-6842	1	Guide-LH
12	105-6841	1	Guide-RH
15	104-8678	1	Handle-Control
16	140-3821	1	Decal
17	136-7150	1	Bar-Control, Traction
18	3256-23	1	Washer-Plain
19	99-1589	1	Lever-Traction
20	136-7166	1	Spring-Torsion
23	136-5864	1	Anchor-Cable
24	117-9389	1	Cable-Traction
26	614249	3	Tie-Cable
29	131-4551	1	Cover-Handle
30	137-4803	2	Bumper-Rubber
31	137-9100	2	Cover-Bumper
32	140-3827	2	Decal-Flex
33	3256-1	1	Washer-Flat

Attachments and Accessories

For 21383 Super Recycler Lawn Mower

Product Name	Model/Part
Bagging Blade	108-3759-03
Fuel Stabilizer .05 oz	130-2393
4-Cycle Fuel, Snow And Lawn 32oz Can	131-3823
Traction Assist Handle Kit	131-4590
Toro Premium Fuel Treatment 12 Oz Bottle	131-6572
High Altitude Kit	133-9943
Oil-30/10W-30 Synthetic (Quart)	138-6053
Engine Maintenance Kit	20240
Lawn Striping Kit with 22in Roller	20601
Toro 4-Cycle SAE 30 Oil (32oz Bottle)	38903
Summer Oil-Case of 24 (20oz Bottles)	38916
Bag-Walk Behind (Toro)	490-7318
Lawnmower Cover	490-7462
Bagger Kit	59165

Notes:



Count on it.