Form No. 3323–135 REV A

48cm Recycler®/ Rear Bagging Mower

Model No. 20827–200000001 and Up

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form **a:b.** The **a** represents the reference number of the entire service assembly and the **b** represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number **6**, the tire by **6:1**, the valve by **6:2**, and the wheel by **6:3**. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually.

Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form **nX y.** The **n** represents the quantity of the part, the **X** is the multiplication symbol, and the **y** represents the reference number.

For example, in an illustration, the reference number **2X 37** means that two of the parts identified by reference number 37 are indicated.

© The TORO Company — 2000
All Rights Reserved


Contents

Description	Page
Deck, Kickers And Recycler Plug Assembly	3
Engine And Blade Assembly	4
HOC And Wheel Assembly	5
Self Propelled Handle And Controls Assembly	6
Electric Start Componants Assembly	7
Rear Bagger Assembly	8
Drive Assembly	9
Gear Case Assembly No. 99–6466	10
Engine, Briggs & Stratton	11–21

Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

Abbreviation	Meaning
AR	as required
ASM	assembly
CARR	carriage
DEG	degrees
FH	flat head
GA	gauge
HF	hex flange
HH	hex head
HHF	hex head flange
HLH	hex lag head
HJ	hex jam
HOC	height-of-cut
HS	hex socket
HSBH	hex socket button head
HSFH	hex socket flat head
HSH	hex socket head
HWH	hex washer head
HWHTF	hex washer head thread forming
INC	incorporated
LH	left hand
NI	nylon insert
PPH	Phillips pan head
PTH	Phillips truss head
PTO	power take off
RH	right hand
SFH	slotted fillister head
SHH	slotted hex head
SQH	square head
SHWH	slotted hex washer head
SPH	slotted pan head
SRH	slotted round head
STD	standard
TAP	self tapping
TTH	Torx truss head
WH	wing head




Sheet No.:2

Deck, Kickers And Recycler Plug Assembly

Ref. No.	Part No.	Qty.	Description
1	100–9115	1	Door–Decal ASM
1:2	93–4105	1	Decal – Danger
3	100–1509	1	Rod–Pivot, Door
4	100–1505	1	Recycler–Plug, Kicker
5	100–1522	1	Fitting–Washout
6	46–6290	1	O–Ring
7	32144–1	11	Screw–Taptite
9	2412–87	2	Clamp–Cable
10	100–4367	1	Shield–Trailing
11	49–2040	2	Screw–Taptite
12	99–6486	1	Kicker–Cover, Rear
13	100–1506	1	Ramp–Discharge
14	100–4352	2	Screw–HWH
15	99–6485	1	Kicker–Front
16	99–6457–01	1	Deck
17	100–4354	1	Decal–Recycler
18	100–3932	1	Boot–HOC
19	99–6479	1	Belt Cover
20	99–5293	1	Spring–Torsion
21	98–2256	2	Clamp
22	100–9123–03	1	Bracket – Deck
24	3256–22	4	Washer–Flat

Ref. No.	Part No.	Qty.	Description

3323–135A




Sheet No.:3

Engine And Blade Assembly

Ref. No.	Part No.	Qty.	Description
3		1	Engine–B & S (123607–0153–E1)
6	100–1523–03	1	Guide–Belt, Engine
7	93–0232	1	V–Belt
8	32144–4	2	Screw–HH
9	80–0510–03	1	Blade Stiffener
10	3253–22	1	Washer–Lock/Sp
11	100–4368	1	Bolt–Blade
12	71–9260–03	1	Blade
13	99–6467	1	Blade Driver ASM
14	100–1102	1	Pulley ASM
15	613227	1	Screw–Set
16	32144–102	3	Screw–HWH
17	92–2289	1	Plate–Logo
18	100–5951	1	Decal–Engine
19	2210–316	1	Stop–Rope
20	93–7198	1	Gas Cap ASM

Ref. No.	Part No.	Qty.	Description




Sheet No.:4

HOC And Wheel Assembly

Ref. No.	Part No.	Qty.	Description
1	100–4352	4	Screw–HWH
2	99–6487	1	Handle–Deck
3	99–6480	1	Button–HOC
4	88–7540	1	Washer – Backup
5	99–6481	1	Spring–Compression, HOC
6	99–6483	1	Bushing–HOC
7	100–1525	1	Bracket–Traction Cable
8	32144–1	6	Screw–Taptite
9	92–9698	1	Screw–Shoulder
10	99–6458	1	Pipe – HOC
11	3296–73	1	Nut–Lock, NI
12	100–4384	1	Spring–Extension, HOC
13	99–6459	1	Bolt–Shoulder
14	99–6460	1	Plate–Support, HOC
15	99–6478	1	Axle–Rear ASM
16	99–6471	2	Wheel ASM
17	100–4370	4	Nut–Lock, Flanged
18	100–4366	2	Cover–Smart Wheel
19	100–9114	2	Decal–Smart Wheel
20	95–6543	2	Cover – Wheel
21	99–6470	2	Wheel ASM
22	100–1500	4	Mount–Axle, Front
23	99–6464	1	Axle–Front ASM

Ref. No.	Part No.	Qty.	Description
24	100–9116	1	Rod–Decal ASM
24:2	100–4355	1	Decal–HOC
25	100–3939	2	Palnut
27	100–4383–03	1	Cover–Handle




Sheet No.:5

Self Propelled Handle And Controls Assembly

Ref. No.	Part No.	Qty.	Description
1	99–1593–03	1	Bail–Brake
2	99–1595	1	Retainer–Cable, Brake
3	46–8091	1	Screw–HWH
4	99–6008	1	Retainer–Control Rod, Traction
5	94–4496	10	Screw–PPH
7	99–1589	1	Lever–Traction
8	99–1590	2	Guide–Handle, Control
9	95–4453	1	Screw–Handle
10	99–5239	1	Anchor–Cable
11	100–3936	1	Cable–Traction
12	98–7134	2	Knob–Handle
13	92–2260	2	Screw–Handle
14	3290–378	2	Tie–Cable
15	100–4360–05	1	Handle–Lower
17	100–4396	2	Adjusting Knob–Handle
18	100–1510	2	Disk Adjusting–Handle
19	100–1517	2	Disk Holding–Handle
20	60–6690	2	Capscrew
21	99–1596–05	1	Handle–Upper
22	86–9671	1	Guide–Rope
23	3296–73	2	Nut–Lock, NI
24	3256–1	1	Washer–Flat
25	100–3937	1	Cable–Brake
26	100–5970	1	Cover–Handle

Ref. No.	Part No.	Qty.	Description
27	99–1592	1	Spring–Torsion, RH
28	99–1588	1	Bar–Control, Traction
29	100–5950	1	Decal–Automatic
30	99–1582	1	Handle–Control




Electric Start Componants Assembly

Ref. No.	Part No.	Qty.	Description
1	32144–97	1	Screw–Plastite
2	63–8360	1	Key–Ignition
3	218–461	1	Nut–HH
4	99–6006	1	Switch–Holder
5	46–5780	1	Switch–Starter
6	100–4356	1	Wire–Harness
9	100–9117	1	Box–Decal ASM
9:2	100–4369	1	Decal–Box, Battery
10	99–5299	2	Rod–Battery
11	99–5296	1	Battery
12	99–5298	1	Cover–Battery
13	94–4496	4	Screw–PPH
*20	98–2391	1	Euporean Charger,12 Vdc

Ref. No.	Part No.	Qty.	Description

* Not illustrated




Sheet No.:8

Rear Bagger Assembly

Ref. No.	Part No.	Qty.	Description
1	100–1530	1	Grass Bag ASM
2	100–1518–03	1	Bag Frame ASM

Ref. No.	Part No.	Qty.	Description




Sheet No.:9

Drive Assembly

Ref. No.	Part No.	Qty.	Description
1	65–4730	2	Washer–Arm, Pivot
2	65–4740	4	Washer–Thrust, Keyed
3	65–2720	4	Ring–Klip
4	65–4710	2	Ring–Friction
5	65–4760	2	Washer
6	66–6040	1	Key–Rocking, RH
7	66–6050	1	Key–Rocking, LH
8	65–4750	2	Gear–Pinion
9	65–4720	2	Spring–Compression
10	100–1513	2	Cover–Gear
12	100–9118	2	Bushing–Zerk ASM
12:2	302–56	1	Fitting–Zerk
13	99–6466	1	Transmission ASM
15	614673	1	Bushing–Plate, Actuator
16	100–1524–03	1	Guide–Transmission
17	49–2040	1	Screw–Taptite
18	92–1616	1	Screw–HWHTF
19	100–1511	2	Retainer–Ring
20	100–1515	2	Washer–Wave
21	32144–1	4	Screw–Taptite

Ref. No.	Part No.	Qty.	Description




Sheet No.:A1

Gear Case Assembly No. 99–6466

Ref. No.	Part No.	Qty.	Description
1	100–1514	1	Shaft–Output
2	614668–03	1	Cover–Gear Case
3	92–7727	1	Gearcase
4	60–8850	2	Bushing–Output
5	3285–19	2	Pin–Groove
6	614596	1	Gear
7	36–4780	2	Washer
8	614696	1	Shaft–Intermediate
9	49–2040	4	Screw–Taptite
10	55–3760	1	Gear–Bevel
11	36–4791	2	Washer–Thrust
12	60–8750	2	Bushing
13	38–7820	1	Bearing–Ball
14	3256–24	1	Washer–Flat
15	60–8890	1	Gear–Bevel, Pinion
16	3296–5	1	Nut–Lock, NI
17	100–1176	2	Half–Pulley
18	62–6660	1	Spacer

Ref. No.	Part No.	Qty.	Description

★ REQUIRES SPECIAL TOOLS TO INSTALL. SEE REPAIR INSTRUCTION MANUAL.



Assemblies include all parts shown in frames.

Sheet No.:2

Engine Briggs & Stratton Model 123607–0153–E1

Ref. No.	Part No.	Qty.	Description
1	99–0900	1	Cylinder ASM
2	99–0911	1	Bushing
⋆3	77–9060	1	Seal – Oil
8	77–9260	1	Breather ASM
⋆9	99–0913	1	Gasket–Breather
10	99–0914	1	Screw–HH
11	99–0915	1	Tube–Breather
523	100–9146	1	Dipstick
306	99–0917	1	Lever ASM–Governor
⋆842	77–7270	1	O–Ring
⋆524	77–7300	1	O–Ring
307	99–0920	1	Screw–HH
⋆585	77–7410	1	Gasket–Breather
525	99–0906	1	Tube–Oil Filter
718	77–7600	1	Dowel – Sleeve
584	99–0922	1	Baffle–Cylinder
847	98–9209	1	Dipstick Tube ASM
684	99–0920	1	Screw–HH
287	99–0927	1	Screw–HH


Ref. No.	Part No.	Qty.	Description

⋆ Included in Engine Gasket Set–See Ref. 358

◆ Included in Carburetor Gasket Set–See Ref. 977

● Included in Carburetor Overhaul Kit–See Ref. 121

Δ Included in Valve Gasket Set–See Ref. 1095



Assemblies include all parts shown in frames.

Sheet No.:3

Engine Briggs & Stratton Model 123607–0153–E1

Ref. No.	Part No.	Qty.	Description
5	99–0929	1	Cylinder Head
★Δ7	99–0930	1	Gasket–Cylinder Head
13	99–0931	1	Screw–HH
33	99–0932	1	Valve–Exhaust
34	99–0933	1	Valve–Intake
35	99–0934	1	Spring–Valve
40	99–0935	1	Retainer–Spring, Valve
45	99–0936	1	Tappet–Valve
155	99–0938	1	Plate–Cylinder Head
189	99–0939	1	Ball–Rocker Arm
238	99–0940	1	Cap–Valve
914	100–9147	1	Screw – Rocker Cover
337	77–7330	1	Spark Plug
383	99–0944	1	Wrench–Spark Plug
635	77–9190	1	Elbow–Sparkplug
830	99–0945	1	Stud–Rocker Arm
619	99–0941	1	Screw–HH
★Δ868	99–0946	1	Seal–Valve
★Δ883	99–0947	1	Gasket–Exhaust
36	99–0934	1	Spring–Valve
★Δ1022	99–0907	1	Gasket–Cover, Rocker
1023	98–9211	1	Cover–Rocker & Gasket
1026	99–0949	1	Rod–Push
1029	99–0950	1	Arm–Rocker
1034	99–0951	1	Guide–Push, Rod


Ref. No.	Part No.	Qty.	Description
★Δ993	99–6264	1	Gasket–Plate
51	99–0968	1	Gasket–Intake
★◆●△122	99–0978	1	Gasket–Intake

★ Included in Engine Gasket Set–See Ref. 358

◆ Included in Carburetor Gasket Set–See Ref. 977

● Included in Carburetor Overhaul Kit–See Ref. 121

Δ Included in Valve Gasket Set–See Ref. 1095



Assemblies include all parts shown in frames.

Sheet No.:4

Engine Briggs & Stratton Model 123607–0153–E1

Ref. No.	Part No.	Qty.	Description
4	99–0952	1	Sump–Engine
⋆12	99–0953	1	Gasket–Crankcase
15	99–0954	1	Plug–Drain, Oil
16	98–9214	1	Crankshaft
24	77–8340	1	Key – Flywheel
⋆20	99–0955	1	Seal–Oil
22	99–0957	1	Key–Flywheel
25	99–0958	1	Piston ASM
26	99–0959	1	Ring Set
27	99–0960	1	Lock–Pin, Piston
28	99–0961	1	Pin–Piston
29	99–0962	1	Rod–Connecting
32	99–0963	1	Screw–Rod, Connecting
43	99–0964	1	Slinger–Oil, Governor
46	99–0965	1	Gear–Cam
146	99–0966	1	Key–Timing
741	99–0967	1	Gear–Timing


Ref. No.	Part No.	Qty.	Description

⋆ Included in Engine Gasket Set–See Ref. 358

◆ Included in Carburetor Gasket Set–See Ref. 977

● Included in Carburetor Overhaul Kit–See Ref. 121

Δ Included in Valve Gasket Set–See Ref. 1095



Assemblies include all parts shown in frames.

Sheet No.:5

Engine Briggs & Stratton Model 123607–0153–E1

Ref. No.	Part No.	Qty.	Description
95	99–0969	1	Screw–SPH
●104	99–0970	1	Pin–Hinge, Float
117	99–0971	1	Jet–Main
●◆708	100–5037	1	Seal–Dust
125	99–0973	1	Carburetor
130	99–0974	1	Valve–Throttle
131	99–0975	1	Shaft–Throttle
●◆276	100–5038	1	Washer–Sealing
●134	77–8110	1	Valve – Float
⋆◆●163	99–0976	1	Gasket–Air Cleaner
975	99–0977	1	Bowl–Float
133	77–8170	1	Float–Carburetor
⋆◆●∆51	99–0968	1	Gasket–Intake
365	99–0972	1	Shoulder Screw
⋆◆●∆122	99–0978	1	Gasket–Intake
●127	100–9107	1	Plug–Welch
●◆137	104–7550	1	Gasket–Float Bowl


Ref. No.	Part No.	Qty.	Description

⋆ Included in Engine Gasket Set–See Ref. 358

◆ Included in Carburetor Gasket Set–See Ref. 977

● Included in Carburetor Overhaul Kit–See Ref. 121

∆ Included in Valve Gasket Set–See Ref. 1095



Assemblies include all parts shown in frames.

Sheet No.:6

Engine Briggs & Stratton Model 123607–0153–E1

Ref. No.	Part No.	Qty.	Description
⋆◆●△51	99–0968	1	Gasket–Intake
⋆◆●△122	99–0978	1	Gasket–Intake
222	100–2891	1	Bracket–Control
910	99–1014	1	Stud–Mounting, Starter
202	99–0981	1	Link–Governor
188	100–5031	1	Screw–Control Bracket
745	99–0983	1	Screw–HH
474	99–1011	1	Alternator
356	99–1007	1	Wire–Stop
334	99–1006	1	Screw–HH
935	100–9109	1	Switch–Interlock
851	77–9450	1	Terminal – Spark Plug
333	99–1005	1	Armature–Magneto
922	99–0987	1	Spring–Brake
923	99–0988	1	Brake Assembly
621	99–0986	1	Switch–Stop
1160	77–9520	1	Screw–HH
227	99–0917	1	Lever ASM–Governor
404	99–0918	1	Washer–Crank, Governor
562	99–0921	1	Screw–HH
505	99–0924	1	Nut–Hex
615	99–0925	1	Fastener
616	99–0926	1	Crank–Governor


Ref. No.	Part No.	Qty.	Description
209	99–0982	1	Spring–Governor
1119	104–7551	1	Screw–Alternator

⋆ Included in Engine Gasket Set–See Ref. 358

◆ Included in Carburetor Gasket Set–See Ref. 977

● Included in Carburetor Overhaul Kit–See Ref. 121

△ Included in Valve Gasket Set–See Ref. 1095



Assemblies include all parts shown in frames.

Sheet No.:7

Engine Briggs & Stratton Model 123607–0153–E1

Ref. No.	Part No.	Qty.	Description
467	100–9108	1	Knob–Air Cleaner
677	100–9148	1	Screw
836	94–1674	1	Screw–HH
968	98–9207	1	Cover–Air Cleaner
445	98–9212	1	Element – Air Filter
★Δ883	99–0947	1	Gasket–Exhaust
★◆●163	99–0976	1	Gasket–Air Cleaner
966	99–0979	1	Base–Air Cleaner
613	99–1047	1	Screw–HH
836A	99–0999	1	Screw–HH
300	99–0995	1	Muffler–Exhaust
259	99–0984	1	Grommet
967	99–0989	1	Foam Pre–Filter Wrap
676	99–1044	1	Deflector–Muffler
832	98–9206	1	Guard–Muffler
613A	99–0941	1	Screw–HH
443	99–0990	1	Hex Screw
976	99–0991	1	Primer


Ref. No.	Part No.	Qty.	Description

★ Included in Engine Gasket Set–See Ref. 358

◆ Included in Carburetor Gasket Set–See Ref. 977

● Included in Carburetor Overhaul Kit–See Ref. 121

Δ Included in Valve Gasket Set–See Ref. 1095



1036 EMISSIONS LABEL

Assemblies include all parts shown in frames.

Engine Briggs & Stratton Model 123607–0153–E1

Ref. No.	Part No.	Qty.	Description
23	99–1001	1	Flywheel
332	94–1673	1	Nut – Flywheel
65	99–1002	1	Screw–HH
304	99–1003	1	Housing–Blower
930	98–9203	1	Guard, Rewind
1036	99–1016	1	Kit–Label, Emissions
1005	99–1015	1	Fan–Flywheel
326	98–9204	1	Screw–Shroud
363	99–1008	1	Puller–Flywheel
592	99–1009	1	Nut–Hex
455	99–1010	1	Cup–Flywheel
305	99–0941	1	Screw–HH


Ref. No.	Part No.	Qty.	Description

★ Included in Engine Gasket Set–See Ref. 358

● Included in Carburetor Overhaul Kit–See Ref. 121

◆ Included in Carburetor Gasket Set–See Ref. 977

Δ Included in Valve Gasket Set–See Ref. 1095



Assemblies include all parts shown in frames.

Sheet No.:9

Engine Briggs & Stratton Model 123607–0153–E1

Ref. No.	Part No.	Qty.	Description
55	99–1048	1	Housing–Starter
65	99–1002	1	Screw–HH
58	94–1668	1	Rope – Starter
592	100–9149	1	Nut (Rewind Starter)
60	77–8510	1	Handle – Rewind Starter
1210	94–1657	1	Pulley – Rewind Starter
1211	94–1657	1	Pulley – Rewind Starter
456	94–1659	1	Retainer–Rewind Starter
459	94–1654	1	Pawl – Starter
597	94–1660	1	Screw – Shoulder
689	94–1655	1	Spring – Torsion
608	98–9215	1	Assembly – Rewind


Ref. No.	Part No.	Qty.	Description


★ Included in Engine Gasket Set–See Ref. 358


◆ Included in Carburetor Gasket Set–See Ref. 977


● Included in Carburetor Overhaul Kit–See Ref. 121

Δ Included in Valve Gasket Set–See Ref. 1095









Sheet No.:10

Engine Briggs & Stratton Model 123607–0153–E1

Ref. No.	Part No.	Qty.	Description
★3	99–0912	1	Oil Seal
★Δ7	99–0930	1	Gasket–Cylinder Head
★9	99–0913	1	Gasket–Breather
★12	99–0953	1	Gasket–Crankcase
1095	100–5033	1	Valve Overhaul Gasket Set
●104	99–0970	1	Pin–Hinge, Float
977	100–5034	1	Gasket Set–Carburetor
358	100–5035	1	Engine Overhaul Gasket Set
●134	77–8110	1	Valve – Float
121	100–5036	1	Carburetor Kit
●◆708	100–5037	1	Seal–Dust
●◆276	100–5038	1	Washer–Sealing
★Δ868	99–0946	1	Seal–Valve
★Δ883	99–0947	1	Gasket–Exhaust
★842	77–7270	1	O–Ring
★524	77–7300	1	O–Ring
★Δ1022	99–0907	1	Gasket–Cover, Rocker
★◆●Δ122	99–0978	1	Gasket–Intake
★585	99–0925	1	Fastener
★Δ993	99–0948	1	Plate Gasket
★20	99–0955	1	Seal–Oil
★◆●Δ51	99–0968	1	Gasket–Intake
◆●Δ163	99–0976	1	Gasket–Air Cleaner


Ref. No.	Part No.	Qty.	Description
●127	100–9107	1	Plug–Welch
●◆137	104–7550	1	Gasket–Float Bowl

★ Included in Engine Gasket Set–See Ref. 358

◆ Included in Carburetor Gasket Set–See Ref. 977

● Included in Carburetor Overhaul Kit–See Ref. 121

Δ Included in Valve Gasket Set–See Ref. 1095



Assemblies include all parts shown in frames.

Sheet No.:11

Engine Briggs & Stratton Model 123607–0153–E1

Ref. No.	Part No.	Qty.	Description
309	77–8670	1	Motor – Starter
310	99–1019	1	Screw
510	77–8910	1	Drive Set
513	99–1021	1	Clutch–Drive
544	99–1022	1	Armature–Starter
545	77–8740	1	Washer Assembly
651	99–1017	1	Screw
697	99–1018	1	Screw
742	77–8830	1	Retainer – Lock
783	99–1023	1	Gear–Starter
783A	99–1024	1	Gear–Starter
784	99–1025	1	Cover–Gear
785	99–1026	1	Gasket–Cover
801	99–1027	1	Cap–Drive
802	99–1028	1	Cap–End
803	99–1029	1	Housing–Starter
937	99–1030	1	Spline–Starter


Ref. No.	Part No.	Qty.	Description

★ Included in Engine Gasket Set–See Ref. 358

● Included in Carburetor Overhaul Kit–See Ref. 121

◆ Included in Carburetor Gasket Set–See Ref. 977

Δ Included in Valve Gasket Set–See Ref. 1095



Assemblies include all parts shown in frames.

Sheet No.:12

Engine Briggs & Stratton Model 123607–0153–E1

Ref. No.	Part No.	Qty.	Description
601	78–4690	1	Clamp–Hose
674	98–9202	1	Screw–Tank Bracket
182	98–9205	1	Bracket–Fuel Tank
187	99–0992	1	Fuel Line
1059	99–0993	1	Screw–Shoulder
190	99–0994	1	Screw–HH
670	99–0997	1	Spacer–Fuel Tank
972	99–1000	1	Tank–fuel

Ref. No.	Part No.	Qty.	Description

★ Included in Engine Gasket Set–See Ref. 358

◆ Included in Carburetor Gasket Set–See Ref. 977

● Included in Carburetor Overhaul Kit–See Ref. 121

Δ Included in Valve Gasket Set–See Ref. 1095

Maintenance Record

Date								

Maintenance Record

Date								


TORO®