Form No. 3425-804 Rev C

TORO®

Count on it.

Parts Catalog

Groundsmaster® 1200 Series

Pull Behind Rotary Mower

Model No. 31905—Serial No. 403390001 and Up

Register at www.Toro.com.
Original Instructions (EN)

CE

3425-804 C

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1,6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Frame Assembly 4
Lift Arm Assembly No. 2 6
Lift Arm Assembly No. 3 8
Lift Arm Assembly No. 1 10
Tire and Axle Assembly 12
LH Torsion Axle Assembly No. 137-3572 14
RH Torsion Axle Assembly No. 137-3573 16
Gearbox and Driveshaft Assembly 18
Main Driveshaft Assembly No. 138-9039 20
Rear Driveshaft Assembly No. 138-9040 22
Side Driveshaft Assembly No. 138-9041 24
Deck Assembly 26
Blade, Pulley and Spindle Assembly 28
Deck Assembly No. 138-9026 30
Deck Mount and Deck Cover Assembly 32
Double Spindle Assembly No. 137-3541 34
High Spindle Assembly No. 137-3542 36
Low Spindle Assembly No. 137-3543 38
Hydraulic Assembly 40
Attachments and Accessories 42

© 2020—The Toro® Company
8111 Lyndale Avenue South
Bloomington, MN 55420

Contact us at www.Toro.com.
Printed in the USA.
All Rights Reserved

Frame Assembly



Frame Assembly (continued)

Ref.	Part Number	Qty.	Description
1	137-3501-01	1	Frame ASM
2	137-3578-01	1	Hitch ASM
3	T0000-3423	1	Jack-Sidewind
4	119-3920	2	Guide-Hose, RH
6	325-18	4	Screw-HH
7	3256-26	4	Washer-Flat
8	104-8301	4	Nut-HF, NI
10	137-3594-01	1	Clevis ASM
11	137-3591	1	Bushing-Flange
12	3290-343	1	Pin-Hair
13	137-3606	1	Hitch Pin ASM
16	99-5107	4	Nut-Lock
18	5-0652	4	Spacer
20	110-4668	1	Decal-Warning, PTO
22	133-8061	1	Decal-Warning
23	120-0625	4	Decal-Warning

Lift Arm Assembly No. 2



Lift Arm Assembly No. 2 (continued)

Ref.	Part Number	Qty.	Description
1	105-2806	1	End-Rod
2	3220-7	1	Nut-Jam
3	114-5677-03	1	Housing
4	323-7	4	Screw-HH
5	117-9404	1	Shaft-Spring
6	114-5986	3	Washer-Plain
7	114-5993	1	Spring-Compression
8	114-5992	1	Bearing-Plastic
9	3256-62	1	Washer-Flat
10	3220-9	2	Nut-Jam
11	285-17	1	Plug-Pipe
12	104-8301	5	Nut-HF, NI
13	137-3599-01	1	Arm-Impact
14	327-23	1	Screw-HH
15	3256-7	2	Washer-Flat
16	3296-53	1	Nut-Lock, NI
17	115-5468	1	Pivot Hub ASM
17:1	115-5469	2	Bushing-Flange
17:2	114-5680	2	Bushing-Flange
17:3	302-60	1	Fitting-Grease
18	94-6604	1	Tube-Spacer
19	137-3562	1	#2 Lift Arm ASM
19:2	302-5	1	Fitting-Grease
19:3	69-6470	2	Bushing-Caster
19:4	114-5596	2	Bushing-Straight
20	32151-36	2	Ring-Retaining
21	10-8110	2	Washer-Thrust
22	138-5272	1	Pin-Cylinder
23	137-3604	1	Pin-Arm, Lift
24	32144-41	2	Screw-Taptite
25	138-3050	2	Cylinder Pin ASM
26	138-3068	1	LH Wing Latch ASM
27	1-633131	1	Yoke-Linkage, Brake
28	103-2399	1	Pin-Spring, Clevis
29	323-8	1	Screw-HH
30	3253-21	1	Washer-Lock
31	3219-3	1	Nut-Hex
32	103-1167	1	Joint-Ball End, LH
33	137-3692	1	Rod-Adjuster, Wing
34	3219-20	1	Nut-Hex, LH
35	302-5	3	Fitting-Grease
36	114-5989	1	Bushing-Plain
37	99-5105	1	Screw-Shoulder

Lift Arm Assembly No. 3



Lift Arm Assembly No. 3 (continued)

Ref.	Part Number	Qty.	Description
1	105-2806	1	End-Rod
2	3220-7	1	Nut-Jam
3	114-5677-03	1	Housing
4	323-7	4	Screw-HH
5	117-9404	1	Shaft-Spring
6	114-5986	3	Washer-Plain
7	114-5993	1	Spring-Compression
8	114-5992	1	Bearing-Plastic
9	3256-62	1	Washer-Flat
10	3220-9	2	Nut-Jam
11	285-17	1	Plug-Pipe
12	104-8301	5	Nut-HF, NI
13	137-3599-01	1	Arm-Impact
14	327-23	1	Screw-HH
15	3256-7	2	Washer-Flat
16	3296-53	1	Nut-Lock, NI
17	115-5468	1	Pivot Hub ASM
17:1	115-5469	2	Bushing-Flange
17:2	114-5680	2	Bushing-Flange
17:3	302-60	1	Fitting-Grease
18	94-6604	1	Tube-Spacer
19	137-3563	1	#3 Lift Arm ASM
19:2	302-5	1	Fitting-Grease
19:3	69-6470	2	Bushing-Caster
19:4	114-5596	2	Bushing-Straight
20	32151-36	2	Ring-Retaining
21	10-8110	2	Washer-Thrust
22	138-5272	1	Pin-Cylinder
23	137-3604	1	Pin-Arm, Lift
24	32144-41	2	Screw-Taptite
25	138-3050	2	Cylinder Pin ASM
26	138-3069	1	RH Wing Latch ASM
27	1-633131	1	Yoke-Linkage, Brake
28	103-2399	1	Pin-Spring, Clevis
29	323-8	1	Screw-HH
30	3253-21	1	Washer-Lock
31	3219-3	1	Nut-Hex
32	103-1167	1	Joint-Ball End, LH
33	137-3692	1	Rod-Adjuster, Wing
34	3219-20	1	Nut-Hex, LH
35	302-5	3	Fitting-Grease
36	114-5989	1	Bushing-Plain
37	99-5105	1	Screw-Shoulder

Lift Arm Assembly No. 1



Lift Arm Assembly No. 1 (continued)

Ref.	Part Number	Qty.	Description
1	323-8	2	Screw-HH
2	103-1167	2	Joint-Ball End, LH
3	3253-21	2	Washer-Lock
4	3219-20	2	Nut-Hex, LH
5	104-8301	6	Nut-HF, NI
6	137-3688-03	1	Latch Shaft ASM
7	256-236	2	Bearing-Mount, Flange
8	323-20	4	Screw-HH
9	137-3691	2	Rod-Adjuster, Rear
10	3219-3	2	Nut-Hex
11	1-633131	2	Yoke-Linkage, Brake
12	103-2399	2	Pin-Spring, Clevis
13	3256-62	2	Washer-Flat
14	10-8110	6	Washer-Thrust
15	32151-36	6	Ring-Retaining
16	138-3076	1	Latch-Rear-LH
17	138-3077	1	Latch-Rear-RH
18	32144-41	2	Screw-Taptite
19	138-3051	2	Rear Cylinder Pin ASM
20	138-3071	2	Lift Arm Pin ASM
21	3296-45	2	Nut-Hex
22	325-15	2	Screw-HH
23	115-2144	2	Tube-Spacer
24	115-3366	2	Roller
25	137-3561	1	#1 Lift Arm LH ASM
25:2	302-5	1	Fitting-Grease
25:3	105-7441	1	Bearing-Spherical
25:4	32151-34	1	Ring-Retaining
25:5	105-7468	1	Stud-Tapered
25:6	32128-42	1	Nut-HF
25:7	69-6470	2	Bushing-Caster
26	137-3584	1	#1 Lift Arm RH ASM
26:2	302-5	1	Fitting-Grease
26:3	105-7441	1	Bearing-Spherical
26:4	32151-34	1	Ring-Retaining
26:5	105-7468	1	Stud-Tapered
26:6	32128-42	1	Nut-HF
26:7	69-6470	2	Bushing-Caster
27	137-3617	2	Pin-Cylinder
28	3296-41	2	Nut-Lock NI
29	137-3581-01	2	Hub Support ASM
30	86-1440	2	Washer-Flat
31	105-5723	2	Spacer-Tube
32	20-9580	1	Rope-Latch
33	5-2942	4	Shackle
34	283-42	4	Pin-Clevis
35	119-1415	4	Pin-Cotter, Locking
36	138-5274	2	Chain-6 Link
37	75-5270	2	Spacer-Knob, Seat
38	99-5105	2	Screw-Shoulder
39	302-5	4	Fitting-Grease

Tire and Axle Assembly



Tire and Axle Assembly (continued)

Ref.	Part Number	Qty.	Description
1	137-3571	2	Tire ASM
1:1	115-1573	1	Rim
1:2	232-27	1	Stem-Valve
1:3	120-8910	1	Tire-Off Road
2	137-3572	1	LH Torsion Axle ASM
3	3234-24	20	Screw-HHF
4	104-8301	20	Nut-HF, NI
5	137-3573	1	RH Torsion Axle ASM
6	242-35	10	Nut-Wheel
7	138-9006-03	2	Bracket-Flap
8	138-9007	2	Flap-Rubber

LH Torsion Axle Assembly No. 137-3572



LH Torsion Axle Assembly No. 137-3572 (continued)

Ref.	Part Number	Qty.	Description
1	254-62	2	Bearing-Roller, Cone
2	137-3596	1	Washer-Spindle
3	3272-18	1	Pin-Cotter
4	119-6001	1	Hub ASM
4:1		1	Hub ●
4:2	115-9471	2	Bearing-Cup
4:3	69-2990	5	Stud-Wheel
5		1	Grease ●
6	137-3595	1	Seal
7		1	Tube And Bracket ASM ●
8		4	Cord-Rubber ●
9		1	Sticker-Rubber, Torsion ●
10		1	Sticker-Axle, Serial Tag ●
11		1	Idler ●
12	242-35	5	Nut-Wheel
13	119-6005	1	Nut-Slotted, Hex
14	119-6004	1	Cap-Dust

● Not serviced separately

RH Torsion Axle Assembly No. 137-3573



RH Torsion Axle Assembly No. 137-3573 (continued)

Ref.	Part Number	Qty.	Description
1	119-6001	1	Hub ASM
1:1		1	Hub ●
1:2	115-9471	2	Bearing-Cup
1:3	69-2990	5	Stud-Wheel
2		1	Grease ●
3		1	Sticker-Axle, Serial Tag ●
4		1	Tube And Bracket ASM ●
5		4	Cord-Rubber ●
6		1	Sticker-Rubber, Torsion ●
7	119-6004	1	Cap-Dust
8	137-3596	1	Washer-Spindle
9	254-62	2	Bearing-Roller, Cone
10	242-35	5	Nut-Wheel
11		1	Idler ●
12	3272-18	1	Pin-Cotter
13	119-6005	1	Nut-Slotted, Hex
14	137-3595	1	Seal

● Not serviced separately

Gearbox and Driveshaft Assembly



Gearbox and Driveshaft Assembly (continued)

Ref.	Part Number	Qty.	Description
1	139-3154	1	Gearbox-Center
2	139-3153	3	Gearbox-Deck
3	138-9039	1	Driveshaft-Main
4	138-9040	1	Driveshaft-Rear
5	138-9041	1	Driveshaft-Side
6	138-9005	7	Clamp-Hose
7	3256-69	4	Washer-Flat
8	327-11	4	Screw-HH
9	33106-025	12	Screw-HHF
99	138-9038	4	Decal-Danger, Entanglement ●

● Not illustrated

Main Driveshaft Assembly No. 138-9039



Main Driveshaft Assembly No. 138-9039 (continued)

Ref.	Part Number	Qty.	Description
1	138-9045	1	Yoke-Cv
2	138-9043	2	Cv Cross Kit
3	138-9046	1	Body-Cv
4	138-9047	1	Yoke
5	138-9044	1	Cross Kit
6	138-9042	1	Shield-Shaft, Main
99	138-9048	2	Chain-Shield ●

● Not illustrated

Rear Driveshaft Assembly No. 138-9040



Rear Driveshaft Assembly No. 138-9040 (continued)

Ref.	Part Number	Qty.	Description
1	139-3150	2	Yoke
2	138-9049	2	Cross Kit
3	139-3151	1	Shield-Shaft, Rear
99	138-9048	2	Chain-Shield ●

● Not illustrated

Side Driveshaft Assembly No. 138-9041



Side Driveshaft Assembly No. 138-9041 (continued)

Ref.	Part Number	Qty.	Description
1	139-3150	2	Yoke
2	138-9049	2	Cross Kit
3	139-3152	1	Shield-Shaft, Side
99	138-9048	2	Chain-Shield ●

● Not illustrated

Deck Assembly



Deck Assembly (continued)

Ref.	Part Number	Qty.	Description
1		3	Deck ASM ●
2	114-5640-03	2	Joint Yoke ASM
2:1		1	Yoke-Joint ●
2:1:1	104-4299	1	Cross And Bearing Kit
3	104-0720	2	Spacer
4	104-0719	2	Washer-Hardened
5	99-3139	2	Nut-Slotted
6	3272-25	2	Pin-Cotter
7	104-0721	4	Washer-Thrust
8	137-3699-03	4	Mount-Base
9	104-0731	4	Shim
10	139-3161	6	Plate-Spacer
11	323-43	20	Screw-HH
12	100-4852	20	Washer-Hardened
13	137-3675-03	1	Mount-Deck
14	3234-42	8	Screw-HHF
15	115-2144	4	Tube-Spacer
16	115-3366	4	Roller
17	325-15	4	Screw-HH
18	3296-45	4	Nut-Hex
19	137-3680-01	2	Roller-Kicker
20	137-3696-01	2	Plate-Kicker
21	74-3730	4	Spacer-Spindle, Rear
22	328-5	2	Screw-HH
23	3296-51	2	Nut-Lock, NI
24	325-6	4	Screw-HH
25	3256-26	4	Washer-Flat
26	99-5107	4	Nut-Lock
27	323-6	16	Screw-HH
28	104-8301	16	Nut-HF, NI
29	127-1653	3	Decal
30	114-5641	2	Washer-Thrust
31	138-9000-03	2	Stop-Deck
32	69-9290	2	Pad-Bumper
33	32108-103	4	Screw-FH
34	104-8300	4	Nut-HF, NI
35	138-3085	2	Decal
36	125-6110	4	Decal-Danger

● Not serviced separately

Blade, Pulley and Spindle Assembly



Blade, Pulley and Spindle Assembly (continued)

Ref.	Part Number	Qty.	Description
1	138-9026	1	Deck Shell ASM
2	137-3541	1	Double Spindle ASM
3	137-3542	1	High Spindle ASM
4	137-3543	1	Low Spindle ASM
5	114-0997	2	Pivot-Idler
6	108-1926	2	Washer
7	137-3676-03	2	Roller ASM
8	137-3659-03	3	Blade-Lift, Medium
9	72-9361	3	Cup-Scalp, Anti
10	104-2444	3	Bolt-Blade, LH Thread
11	138-3083-01	1	Skid-LH
12	138-3084-01	1	Skid-RH
13	138-5271	4	Shim-Bearing
14	138-3087	4	Decal-HOC
15	138-3098	4	Indicator-HOC
16	138-5270	4	Bearing-Flange, 2 Bolt
17	137-3635-01	1	Plate-Doubler, LH
18	137-3636-01	1	Plate-Doubler, Center
19	137-3637-01	1	Plate-Doubler, RH
20	138-5283	1	Pulley-Drive
21	138-3086	4	Block-HOC
22	3256-28	4	Washer-Flat
23	137-3648	4	Screw-HHCS
24	HDW17555	4	Bolt-Carriage
25	138-3092	4	Nut-Hex
26	137-3644	1	Belt-V
27	137-3645	1	Belt-V
28	137-3649	2	Idler Arm ASM
28:2	93-4510	2	Bushing-Caster
29	112-7395	2	Spring-Torsion
30	92-2651	1	Washer
31	121-5274	1	Spacer-Idler
32	1-613098	1	Pulley-Idler
33	69-6970	1	Spacer-Idler, Flat
34	100-3102	1	Washer-Flat
35	108-1993	1	Screw-HSBH
36	32120-84	2	Ring-Snap, External
37	302-5	2	Fitting-Grease
38	3296-45	2	Nut-Hex
39	324-5	8	Screw-HH
40	126-9780	8	Nut-Lock
41	3231-22	4	Screw-CARR
42	3231-25	2	Bolt-CARR
43	104-8301	43	Nut-HF, NI
44	3231-27	13	Screw-CARR
45	115-9830	8	Screw-HSBH
46	302-33	4	Fitting-Grease
47	137-3660	1	Bushing-Taperlock
48	325-8	1	Screw-HH
49	132-9421	1	Pulley-Idler, Flat

Deck Assembly No. 138-9026



Deck Assembly No. 138-9026 (continued)

Ref.	Part Number	Qty.	Description
2	138-3078	1	Decal-Routing, Belt
3	117-4979	2	Decal-Warning
4	120-6604	2	Decal-Danger
5	125-6110	4	Decal-Danger
6	138-3085	2	Decal

Deck Mount and Deck Cover Assembly



Deck Mount and Deck Cover Assembly (continued)

Ref.	Part Number	Qty.	Description
1	137-3556-03	1	Deck Mount ASM
2	3233-26	4	Screw-CARR, Short Neck
3	99-5107	6	Nut-Lock
5	137-3646	1	Flap-Rear
6	137-3647-01	1	Plate-Flap
7	3230-10	7	Bolt-CARR
8	104-8300	23	Nut-HF, NI
9	74-5950	6	Latch-Swell
10	137-3519-03	1	Cover-Deck, LH
11	137-3520-03	1	Cover-Deck, RH
12	3230-23	16	Screw-CARR
13	3234-47	2	Screw-HHF
14	117-2749	2	Nut-Push
15	325-39	2	Screw-HH
16	137-3549-01	1	LH Chamber ASM
17	137-3550-01	1	Center Chamber ASM
18	137-3551-01	1	RH Chamber ASM
19	137-3665-01	1	Baffle-Inner
20	138-3078	1	Decal-Routing, Belt
21	115-8827	2	Foam-Strip
25	117-4979	2	Decal-Warning
26	120-6604	2	Decal-Danger
27	119-6807	2	Decal-Warning
28	138-9027-03	2	Shim-Mount, Deck
29	3256-26	2	Washer-Flat
30	139-3156-01	1	Stiffener-Deck
31	3231-27	7	Screw-CARR
32	104-8301	7	Nut-HF, NI

Double Spindle Assembly No. 137-3541



Double Spindle Assembly No. 137-3541 (continued)

Ref.	Part Number	Qty.	Description
1	119-4777	1	Spindle ASM
1:1		1	Spindle ASM ●
1:1:2	114-8195	8	Bolt-Neck, Ribbed
1:2	108-1954	1	Bearing Spacer Set
1:3	110-8297	1	Bearing ASM
1:4	253-154	2	Seal-Oil
1:5	302-60	1	Fitting-Grease
2	69-6950	1	Spacer-Shaft, Spindle
3	137-3622	1	Double Pulley ASM
4	120-5576	1	Washer-Hardened
5	3296-60	1	Nut-Lock, NI
6	137-3545	1	Shaft-Spindle
7	106-7159	1	O-Ring

● Not serviced separately

High Spindle Assembly No. 137-3542



High Spindle Assembly No. 137-3542 (continued)

Ref.	Part Number	Qty.	Description
1	119-4777	1	Spindle ASM
1:1		1	Spindle ASM ●
1:1:2	114-8195	8	Bolt-Neck, Ribbed
1:2	108-1954	1	Bearing Spacer Set
1:3	110-8297	1	Bearing ASM
1:4	253-154	2	Seal-Oil
1:5	302-60	1	Fitting-Grease
2	69-6950	1	Spacer-Shaft, Spindle
3	137-3627	1	Single Pulley ASM
4	120-5576	1	Washer-Hardened
5	3296-60	1	Nut-Lock, NI
6	137-3545	1	Shaft-Spindle
7	106-7159	1	O-Ring

● Not serviced separately

Low Spindle Assembly No. 137-3543



Low Spindle Assembly No. 137-3543 (continued)

Ref.	Part Number	Qty.	Description
1	119-4777	1	Spindle ASM
1:1		1	Spindle ASM ●
1:1:2	114-8195	8	Bolt-Neck, Ribbed
1:2	108-1954	1	Bearing Spacer Set
1:3	110-8297	1	Bearing ASM
1:4	253-154	2	Seal-Oil
1:5	302-60	1	Fitting-Grease
2	69-6950	1	Spacer-Shaft, Spindle
3	137-3629	1	Pulley-Driven, Low
4	120-5576	1	Washer-Hardened
5	3296-60	1	Nut-Lock, NI
6	137-3545	1	Shaft-Spindle
7	106-7159	1	O-Ring

● Not serviced separately

Hydraulic Assembly



Hydraulic Assembly (continued)

Ref.	Part Number	Qty.	Description
1	137-3570	2	Cylinder ASM
1:6	137-3608	1	Kit-Seal
1:10	302-5	1	Fitting-Grease
2	137-3598	2	Cylinder ASM
2:6	137-3609	1	Kit-Seal
2:10	302-5	1	Fitting-Grease
3	138-3094	1	Manifold
3:1		1	Manifold Block ■
3:2	110-8881	1	Valve-Check
3:2:1	105-9159	1	Seal Kit ●
4	340-2	11	Fitting-Straight
4:1	237-22	1	O-Ring
4:2	237-42	1	O-Ring
5	340-87	1	Fitting-Elbow, 45 DEG
5:1	237-22	1	O-Ring
5:2	237-42	1	O-Ring
7	105-9817	4	Hose-HYD
8	99-3576	2	Hose-HYD
9	138-5296	2	Hose ASM
9:1		1	Fitting-Straight, Rgd ■
9:1:1	237-79	1	O-Ring
10	138-5297	2	Hose ASM
11	138-3064	1	Tube ASM
12	138-3065	1	Tube ASM
13	340-166	2	Fitting-Tee
13:1	237-22	2	O-Ring
14	56-7973	2	Clamp-Tube
15	3234-34	2	Screw-HHF
16	115-1794	1	Screw-HHF
17	104-8300	1	Nut-HF, NI
18	138-3096-01	1	Bracket-Hardline
19	120-4654	2	Screw-HHF
20	104-7201	2	Nut-HF
21	133-7828	2	Coupler-Connect, Quick
22	138-3066	1	Cap-Dust, Red
23	T56152152	1	Cap-Connect, Quick

● Not illustrated

■ Not serviced separately

Attachments and Accessories

For 31905 Groundsmaster 1200 Series Pull Behind Rotary Mower

Product Name	Model/Part
High Lift Blades MVP Kit	138-9028
Standard Lift MVP Kit	138-9029

Notes:

Count on it.