Form No. 3439-464 Rev C

TORO®

Count on it.

Parts Catalog

# Power TRX Commercial 1432

## OHXE Snowthrower

**Model No. 38875—Serial No. 400000000 and Up**

Register at www.Toro.com.
Original Instructions (EN)

CE

*3439-464* C

# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

**Understanding Reference Numbers**

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

**Service Assembly Reference Numbers**

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1,6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

**Reference Numbers Indicating Quantity**

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# Contents


Main Frame Assembly . . . . . 4
Traction Frame Assembly . . . . . 6
Auger Drive Assembly . . . . . 8
Belt Drive Assembly . . . . . 10
Gear Case Assembly . . . . . 12
Engine Assembly . . . . . 14
Fuel Systems and Carburetor Assembly . . . . . 16
Intake and Exhaust Assembly . . . . . 18
Ignition and Electrical Assembly . . . . . 20
Crankcase Assembly . . . . . 22
Governor Assembly . . . . . 24
Piston and Head Assembly . . . . . 26
Blower Housing and Shrouds Assembly . . . . . 28
Engine Decal Assembly . . . . . 30
Chute Assembly . . . . . 32
Chute Control Assembly . . . . . 34
Traction Control Assembly . . . . . 36
Handle Assembly . . . . . 38
Hydrostatic Drive Assembly . . . . . 40
Track Drive Assembly . . . . . 42
Attachments and Accessories . . . . . 44

**© 2020—The Toro® Company**
**8111 Lyndale Avenue South**
**Bloomington, MN 55420**



**Contact us at www.Toro.com.**
**Printed in the USA.**
**All Rights Reserved**


# Main Frame Assembly



# Main Frame Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 2 | 107069 | 8 | Clip |
| 3 | 139-1563 | 1 | Auger Housing ASM |
| 3:2 | 121-6817 | 1 | Decal-Danger, Auger |
| 4 | 136-6571 | 1 | Bearing-Ball |
| 5 | 136-6573 | 1 | Retainer-Bearing |
| 6 | 32144-14 | 6 | Screw-HWHTF |
| 7 | 136-6602-01 | 1 | Blade-Scraper |
| 8 | 137-3061 | 11 | Bolt-CARR |
| 9 | 119-4041 | 11 | Nut-HF |
| 10 | 110-3144 | 4 | Bolt-CARR |
| 12 | 120-3098-03 | 2 | Skid-Cast |
| 13 | 119-4150 | 4 | Washer-Flat |
| 14 | 136-6650-01 | 1 | Cover-Bottom |
| 16 | 32144-85 | 11 | Screw-HWH |
| 17 | 121-1228-03 | 2 | Breaker-Drift, Side |


# Traction Frame Assembly



# Traction Frame Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 140-7904-01 | 1 | Frame-Traction |
| 2 | 140-7916-01 | 1 | Cover-Rear |
| 3 | 140-7915-01 | 1 | Brace-Frame, Lower |
| 4 | 139-2598 | 8 | Screw-HHF |
| 5 | 119-4041 | 8 | Nut-HF |
| 6 | 140-7934-03 | 1 | Cover-Lock, Neutral |
| 7 | 32144-85 | 2 | Screw-HWH |


# Auger Drive Assembly



# Auger Drive Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 2 | 136-6691 | 1 | Pulley-Spacer |
| 3 | 136-6690 | 1 | Pulley-Impeller, Double Sheave |
| 5 | 138-3662 | 1 | Support-Pulley |
| 6 | 125-2466 | 1 | Bolt-Blade |
| 7 | 136-6504 | 1 | Belt-V |
| 9 | 136-8654-03 | 1 | Bracket-Clutch, Impeller |
| 10 | 136-6557 | 1 | Pulley-Impeller, Double Sheave |
| 11 | 136-6558 | 1 | Hub-Pulley |
| 12 | 32144-70 | 4 | Screw-HWHTF |
| 13 | 136-8671-03 | 1 | Bracket-Brake, Clutch |
| 15 | 66-8060 | 1 | Pad-Brake |
| 16 | 136-7199 | 1 | Bolt-Shoulder |
| 17 | 121-4600 | 2 | Nut-Hex |
| 18 | 137-6234-03 | 1 | Arm-Clutch, Impeller |
| 19 | 136-6531 | 1 | Pulley, Idler |
| 20 | 138-0722 | 1 | Screw-HH |
| 21 | 137-3111 | 1 | Screw-HHF |
| 22 | 137-3005 | 1 | Nut-HF |
| 23 | 32144-85 | 9 | Screw-HWH |
| 24 | 136-7116 | 1 | Bolt-Shoulder |
| 25 | 137-3095 | 1 | Nut-Hex |
| 27 | 136-7186 | 1 | Arm-Idler, Traction |
| 28 | 3-4244 | 1 | Pulley-Idler |
| 29 | 137-3065 | 1 | Screw-HH |
| 33 | 107-1045 | 1 | Spring-Extension |
| 41 | 115-1166 | 2 | Washer-Flat |
| 47 | 137-3121 | 1 | Washer-Plain |
| 48 | 115-5142 | 1 | Screw-HHF |
| 49 | 137-3089 | 1 | Nut-Hex |
| 50 | 137-3016 | 1 | Nut-HF |
| 51 | 104-0858 | 1 | Bolt-Shoulder |


# Belt Drive Assembly



# Belt Drive Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 140-7944 | 2 | Sheave-Traction |
| 2 | 140-7940 | 1 | Belt-Traction (A, 41.00) |
| 3 | 136-7186 | 1 | Arm-Idler, Traction |
| 4 | 3-4244 | 1 | Pulley-Idler |
| 5 | 140-7895-03 | 1 | Bracket-Cable |
| 6 | 140-7894-03 | 1 | Anchor-Cable |
| 7 | 32144-85 | 4 | Screw-HWH |
| 8 | 139-3565 | 2 | Guide-Cable |
| 9 | 139-3564 | 2 | Cap-Guide, Cable |
| 10 | 140-7924 | 1 | Cable-Traction |
| 11 | 360-0272 | 2 | Screw |
| 12 | 520-0006 | 2 | Nut-Hex, Nylock |
| 13 | 80-4600 | 1 | Spring-Extension |
| 14 | 140-7941 | 1 | Key-Square |
| 15 | 49-2040 | 1 | Screw-HWHTF |


# Gear Case Assembly



# Gear Case Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 136-6620 | 1 | Auger Gearcase ASM |
| 1:20 | 138-3629 | 1 | Plug-Oil |
| 2 | 136-6570-03 | 1 | Impeller |
| 5 | 136-6597-03 | 1 | Auger-LH, 32 Inch |
| 6 | 136-6598-03 | 1 | Auger-RH, 32 Inch |
| 7 | 106-4570 | 2 | Bearing-Auger |
| 8 | 3-0750 | 2 | Washer |
| 9 | 137-3066 | 2 | Screw-HH |
| 10 | 120-9738 | 2 | Screw-HH |
| 11 | 136-7148 | 2 | Spacer-Grommet |
| 13 | 119-4038 | 2 | Nut-Hex |
| 14 | 32144-70 | 4 | Screw-HWHTF |
| 15 | 137-3032 | 2 | Screw-HH |
| 16 | 137-3088 | 2 | Nut-Hex |


# Engine Assembly



# Engine Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 139-0732 | 1 | Engine-Lc190Fds-1 |
| 2 | 137-6165 | 1 | Engine Plate ASM |
| 3 | 32144-70 | 4 | Screw-HWHTF |
| 5 | 136-6607 | 1 | Belt Guide |
| 6 | 138-0690 | 2 | Screw-HH |
| 8 | 138-0670 | 1 | LED Light ASM |
| 9 | 138-0683-03 | 1 | Bracket-Light |
| 10 | 32144-85 | 2 | Screw-HWH |
| 11 | 121-4604 | 1 | Screw-HH |
| 12 | 136-6606 | 1 | Cover-Belt |
| 13 | 3230-19 | 1 | Bolt-CARR |
| 14 | 137-3089 | 1 | Nut-Hex |
| 15 | 137-3099 | 1 | Screw-Plastite, HWH |

# Fuel Systems and Carburetor Assembly




# Fuel Systems and Carburetor Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 133-9823 | 1 | Cap-Fuel |
| 2 | 121-0324 | 1 | Insert-Cover, Tank |
| 3 | 121-0296 | 4 | Screw-HHF |
| 4 | 139-0574 | 1 | Cover-Tank, Fuel |
| 5 | 139-0567 | 1 | Fuel Tank And Filter ASM |
| 5:2 | 127-9065 | 1 | Filter-Fuel |
| 6 | 139-0569 | 4 | Screw-HHF |
| 7 | 139-0571 | 1 | Bracket-Tank, Right |
| 8 | 139-0570 | 1 | Bracket-Tank, Left |
| 9 | 127-9120 | 1 | Clamp-Hose |
| 10 | 139-0566 | 1 | Sleeve-Abrasion |
| 11 | 127-9064 | 1 | Hose-Fuel |
| 12 | 121-0087 | 3 | Clamp-Hose |
| 13 | 121-0258 | 1 | Valve-Fuel |
| 14 | 139-0583 | 1 | Hose-Fuel |
| 15 | 139-0579 | 1 | Gasket-Carburetor |
| 16 | 139-0580 | 1 | Insulator-Carburetor |
| 17 | 139-0581 | 1 | Gasket-Carburetor |
| 18 | 144-0964 | 1 | Carburetor ASM |
| 18:1 | 139-0638 | 1 | Lever-Choke |
| 19 | 121-0254 | 1 | Gasket-Coated, Rubber |
| 20 | 127-9372 | 1 | Primer Kit |
| 21 | 139-0625 | 1 | Internal Carb Service Kit |
| 22 | 121-0010 | 3 | Nut-Flange |
| 99 | 144-0970 | 1 | High Altitude Kit ● |

● Not illustrated


# Intake and Exhaust Assembly



# Intake and Exhaust Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 121-0297 | 2 | Screw-HHF |
| 2 | 139-0577 | 1 | Shield-Muffler |
| 3 | 121-0199 | 2 | Nut-HH |
| 4 | 139-0578 | 1 | Muffler ASM |
| 5 | 121-0272 | 1 | Gasket-Exhaust |
| 6 | 121-0304 | 2 | Stud-Mount, Muffler |
| 7 | 121-0294 | 4 | Screw-HHF |
| 8 | 121-0303 | 2 | Stud-Mount, Carburetor |
| 9 | 144-0962 | 1 | Box-Heater |
| 10 | 121-0308 | 2 | Nut-Flange |


# Ignition and Electrical Assembly



# Ignition and Electrical Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 121-0306 | 2 | Screw-Bhp |
| 2 | 121-0312 | 2 | Washer-Plain |
| 3 | 139-0589 | 1 | Motor-Starter |
| 4 | 121-0294 | 2 | Screw-HHF |
| 5 | 121-0296 | 1 | Screw-HHF |
| 6 | 121-0017 | 1 | Clip-Harness, Wire |
| 7 | 139-0572 | 1 | Bracket-Box, Switch |
| 8 | 120-4461 | 1 | Screw-PPH |
| 9 | 139-0563 | 1 | Switch-Stop, Engine |
| 10 | 121-0298 | 2 | Screw-HHF |
| 11 | 121-4108 | 1 | Stator Coil ASM |
| 12 | 120-4223 | 2 | Screw-HHF |
| 13 | 139-0555 | 1 | Clamp-Wire, Charge |
| 14 | 121-0118 | 1 | Screw-HHF |
| 15 | 139-0558 | 1 | Flywheel ASM |
| 16 | 139-0559 | 1 | Fan-Cooling |
| 17 | 139-0560 | 1 | Cup-Starter |
| 18 | 121-0309 | 1 | Nut-Flange |
| 19 | 121-0097 | 2 | Screw-HHF |
| 20 | 139-0557 | 1 | Ignition Coil ASM |
| 21 | 121-0326 | 1 | Clip |
| 22 | 121-0283 | 1 | Switch-Key |
| 23 | 117-7728 | 1 | Key |


# Crankcase Assembly



# Crankcase Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 136-7941 | 1 | Oil Fill ASM |
| 2 | 127-9123 | 1 | Screw-HHF |
| 3 | 121-0298 | 8 | Screw-HHF |
| 4 | 136-7942 | 1 | Seal-Oil |
| 5 | 133-9805 | 1 | Plug-Drain |
| 6 | 139-0611 | 1 | Crankcase Cover ASM |
| 6:2 | 120-4261 | 1 | Bearing-Ball |
| 6:3 | 136-7949 | 1 | Bearing-Ball |
| 7 | 136-7945 | 1 | Gasket-Cover, Case |
| 8 | 121-0314 | 2 | Pin-Dowel |
| 9 | 139-0550 | 1 | Shaft-Balance |
| 10 | 136-7939 | 1 | Camshaft ASM |
| 11 | 139-0586 | 1 | Crankshaft ASM |
| 11:1 | 120-4320 | 1 | Key-Woodruff |
| 11:2 | 120-4261 | 1 | Bearing-Ball |
| 13 | 136-7949 | 1 | Bearing-Ball |
| 16 | 121-0030 | 1 | Screw-HHF |
| 17 | 121-0048 | 1 | Washer-Plain |
| 18 | 121-0229 | 1 | Tube-Drain, Oil |
| 19 | 139-0556 | 1 | Seal-Oil |
| 20 | 121-0222 | 1 | Screw-HHF |
| 21 | 121-0310 | 2 | Washer-Plain |


# Governor Assembly



# Governor Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 139-0564 | 1 | Spring-Governor |
| 2 | 139-0552 | 1 | Nut-Flange |
| 3 | 139-0551 | 1 | Arm-Governor |
| 4 | 120-4238 | 1 | Bolt-Arm, Governor |
| 5 | 120-4257 | 1 | Seal-Oil |
| 6 | 120-4256 | 1 | Pin-Hair |
| 7 | 121-0311 | 1 | Washer-Plain |
| 8 | 139-0553 | 1 | Shaft-Governor |
| 9 | 136-7944 | 1 | Governor Gear ASM |
| 10 | 121-0261 | 1 | Spring-Return, Throttle |
| 11 | 139-0584 | 1 | Rod-Governor |
| 12 | 121-0118 | 2 | Screw-HHF |
| 13 | 139-0562 | 1 | Throttle Control ASM |
| 14 | 121-0269 | 1 | Knob-Control, Throttle |


# Piston and Head Assembly



# Piston and Head Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 121-0044 | 4 | Screw-HHF |
| 2 | 121-0233 | 1 | Valve Cover ASM |
| 3 | 127-9408 | 1 | Clamp-Hose |
| 4 | 144-0963 | 1 | Tube-Breather |
| 5 | 121-0234 | 1 | Gasket-Cover, Valve |
| 6 | 121-0302 | 4 | Screw-HHF |
| 7 | 139-0595 | 1 | Complete Head ASM |
| 7:1 | 136-7932 | 1 | Head-Cylinder |
| 7:2 | 81-3250 | 1 | Spark Plug |
| 7:5 | 121-0245 | 2 | Rocker Arm ASM |
| 7:6 | 121-0247 | 1 | Plate-Guide, Push Rod |
| 7:7 | 121-0244 | 2 | Rotator-Valve |
| 7:8 | 120-4307 | 4 | Keeper-Valve |
| 7:9 | 120-4306 | 2 | Retainer-Spring, Valve |
| 7:10 | 120-4305 | 2 | Spring-Valve |
| 7:11 | 120-4304 | 1 | Seal-Stem, Valve |
| 7:12 | 120-4303 | 1 | Seat-Spring, Valve |
| 7:13 | 136-7940 | 1 | Valve Set |
| 8 | 139-0590 | 1 | Gasket-Head, Cylinder |
| 9 | 120-4200 | 2 | Pin-Dowel |
| 10 | 136-7938 | 2 | Rod-Push |
| 11 | 120-4298 | 2 | Lifter-Valve |
| 12 | 136-7946 | 1 | Connecting Rod ASM |
| 13 | 144-0961 | 1 | Ring Set, Piston |
| 14 | 120-4288 | 2 | Ring-Retaining, Piston Pin |
| 15 | 144-0960 | 1 | Piston |
| 16 | 120-4291 | 1 | Pin-Piston |


# Blower Housing and Shrouds Assembly



# Blower Housing and Shrouds Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 139-0575 | 1 | Screw-HHF |
| 2 | 139-0576 | 1 | Panel-Rear |
| 3 | 121-0294 | 8 | Screw-HHF |
| 4 | 121-0296 | 2 | Screw-HHF |
| 5 | 136-7937 | 1 | Shroud-Head, Upper |
| 6 | 136-7933 | 1 | Shroud-Head, Lower |
| 7 | 121-0307 | 1 | Shroud-Recoil |
| 8 | 121-0325 | 1 | Grommet-Rubber |
| 9 | 121-0118 | 2 | Screw-HHF |
| 10 | 139-0565 | 1 | Panel-Control, Front |
| 11 | 121-0268 | 1 | Knob-Valve, Fuel |
| 12 | 121-0305 | 1 | Screw-Bhp |
| 13 | 139-0561 | 1 | Recoil ASM |
| 13:1 | 121-0287 | 1 | Handle-Recoil |
| 14 | 127-9380 | 4 | Washer-Plain |
| 15 | 127-9031 | 4 | Screw-HHF |


# Engine Decal Assembly



# Engine Decal Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 131-6487 | 1 | Decal-Throttle |
| 2 | 120-9805 | 1 | Decal-Control, Engine |
| 3 | 136-7825 | 1 | Decal-Valve, Fuel |
| 4 | 138-3622 | 1 | Decal-Recoil |


# Chute Assembly



# Chute Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 136-6515 | 1 | Guide-Chute |
| 2 | 136-6580-01 | 1 | Lower Chute ASM |
| 3 | 138-3671 | 2 | Gasket-Deflector |
| 4 | 136-6582-01 | 1 | Middle Deflector ASM |
| 5 | 135-1929 | 6 | Bolt-CARR |
| 6 | 138-0719 | 6 | Nut-HF |
| 7 | 139-1564 | 1 | Deflector ASM |
| 7:2 | 121-6847 | 1 | Decal-Danger |
| 8 | 106-4422 | 1 | Spacer-Chute |
| 9 | 137-6245-03 | 1 | Chute Post ASM |
| 10 | 106-4472 | 1 | Gear-Chute |
| 11 | 46-6810 | 2 | Screw And Washer ASM |
| 12 | 136-7199 | 1 | Bolt-Shoulder |
| 13 | 137-3088 | 3 | Nut-Hex |
| 14 | 137-3063 | 2 | Bolt-Car |
| 15 | 119-4041 | 2 | Nut-HF |
| 16 | 136-6517 | 1 | Mount-Gear, Face |
| 17 | 106-4471 | 1 | Gear-Face |
| 18 | 136-6676 | 1 | Anchor-Cable |
| 19 | 136-7197 | 3 | Screw-Shoulder |
| 20 | 136-6525 | 1 | Latch-Chute |
| 21 | 137-3103 | 1 | Screw-Shoulder, HH |
| 22 | 137-3089 | 2 | Nut-Hex |
| 23 | 108-7315 | 1 | Spring-Torsion |
| 24 | 138-0689 | 2 | Screw-PH |
| 25 | 138-0687 | 2 | Bushing-Pivot |
| 26 | 136-6522 | 1 | Link-Deflector |
| 27 | 137-3094 | 2 | Nut-Hex |
| 28 | 32144-85 | 1 | Screw-HWH |
| 29 | 136-6586 | 2 | Grommet-Screw |
| 30 | 94-4496 | 2 | Screw-PPH |
| 31 | 136-7191 | 1 | Clamp-Cable |
| 32 | 137-3110 | 1 | Screw-Plastite, HWH |
| 33 | 136-6672 | 1 | Cover-Gear, Face |
| 35 | 132-6915 | 1 | Spring-Extension |
| 36 | 138-3651 | 1 | Plug-Plastic |


# Chute Control Assembly



# Chute Control Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 138-0662 | 1 | Rod-Control, Chute |
| 2 | 138-0659 | 1 | Screw-Shoulder, HWH |
| 3 | 139-1552 | 1 | Chute Control Lever ASM |
| 5 | 105-9988 | 1 | Lever-Cable, Deflector |
| 6 | 106-7310 | 1 | Pawl-Latch |
| 7 | 137-3087 | 1 | Nut-Hex |
| 8 | 137-6238 | 1 | Trigger-Latch |
| 9 | 138-0730 | 1 | Cable-Control, Deflector |
| 10 | 105-9982 | 1 | Spring-Torsion |
| 11 | 138-0688 | 1 | Link-Latch |
| 12 | 137-6239 | 1 | Cap-Lever |
| 13 | 136-6578 | 1 | Rod-Chute, Rotation |
| 14 | 94-4496 | 8 | Screw-PPH |
| 15 | 136-6677 | 1 | Globe-Quickstick, RH |
| 16 | 136-6632-03 | 1 | Plate-Stiffner |
| 17 | 136-6678 | 1 | Globe-Quickstick, LH |
| 18 | 137-3056 | 3 | Bolt-CARR |
| 19 | 137-3094 | 3 | Nut-Hex |
| 20 | 139-9903 | 1 | Cable-Release, Chute |
| 21 | 138-0744 | 1 | Washer-Friction, Composite |


# Traction Control Assembly



# Traction Control Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 2 | 137-3052 | 4 | Screw-HH |
| 8 | 144-1601 | 1 | Panel-Control, Assembly |
| 8:2 | 138-0650 | 1 | Decal-Safety |
| 9 | 137-6178 | 1 | Cover-Quickstick |
| 10 | 105-9987 | 2 | Support-Rod |
| 11 | 137-3099 | 9 | Screw-Plastite, HWH |
| 12 | 137-6197-01 | 1 | Brace-Console |
| 14 | 137-6187-03 | 1 | Gate-Shift |
| 15 | 137-6188-03 | 1 | Bracket-Shift |
| 16 | 137-6231-03 | 1 | Selector-Speed |
| 22 | 105-9999 | 1 | Knob-Shift, LH |
| 23 | 106-4423 | 1 | Knob-Shift, RH |
| 24 | 94-4496 | 1 | Screw-PPH |
| 30 | 105-9980 | 2 | Mount-Lever, Clutch |
| 31 | 106-4505 | 2 | Lever-Clutch |
| 32 | 1-808265 | 2 | Pin-Clevis |
| 33 | 138-3661 | 1 | Cable-Auger |
| 34 | 108-2992 | 2 | Pin-Hair |
| 35 | 136-7161 | 1 | Spring-Lockout, Handle |
| 36 | 137-6182 | 1 | Rod-Lockout |
| 37 | 138-0678 | 1 | Spring-Torsion, Handle Return |
| 38 | 139-3694 | 3 | Screw-HSH |
| 39 | 98-3499 | 1 | Washer-Flat |
| 40 | 138-0681 | 1 | Screw-Shoulder |
| 41 | 137-6227 | 1 | Lock-Handle |
| 42 | 137-9137 | 1 | Screw-PPH |
| 43 | 137-6229 | 1 | Latch-Lockout |
| 44 | 138-8466 | 1 | Cam-Lockout |
| 45 | 138-3652 | 1 | Link-Lockout |
| 46 | 137-6171 | 2 | Lever-Control |
| 50 | 138-3644 | 1 | Harness-Wire, LED And Hand Warmers |
| 51 | 614249 | 2 | Tie-Cable |
| 53 | 32180-030 | 1 | Clip-Tie |
| 54 | 110-3408 | 1 | Stick-Cleanout |
| 55 | 122-1124 | 1 | Switch-Rocker, On-None-Off (Heater) |
| 57 | 3290-271 | 4 | Rivet-Pop |
| 58 | 138-8467 | 1 | Collar-Cam |
| 60 | 127-5951 | 2 | Grip-Heated |
| 61 | 144-0329 | 1 | Decal-Console, Powermax Trx HD 1432 |
| 62 | 137-3093 | 1 | Nut-Hex |
| 63 | 140-3749 | 3 | Nut-Lock Rohs |


# Handle Assembly



# Handle Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 137-6221-03 | 2 | Bracket-Handle, Lower |
| 2 | 138-8402 | 1 | Bolt-CARR |
| 3 | 138-8401 | 12 | Nut-HF |
| 4 | 137-6224-03 | 1 | HD Handle ASM |
| 5 | 120-9686 | 4 | Screw-HH |
| 6 | 137-6233-01 | 1 | Trim-Metal, HD |
| 7 | 138-3653 | 2 | Screw-HHF |
| 8 | 108-2301 | 1 | Spacer |
| 9 | 115-1151 | 1 | Washer-Flat |
| 10 | 138-0741 | 1 | Screw-CARR |
| 12 | 138-0724-03 | 1 | Bracket-Stick, Cleanout |
| 13 | 106-4509 | 2 | Clamp-Cable |
| 14 | 137-3094 | 2 | Nut-Hex |
| 15 | 140-7917-03 | 1 | Bracket-Lever |
| 16 | 140-7932-03 | 1 | Lever-Adjustment, Track |
| 17 | 140-7931-03 | 1 | Bracket-Cable, Speed |
| 18 | 136-7120 | 1 | Clamp-Light |
| 19 | 139-1699 | 2 | Washer-Flat |
| 20 | 140-7927 | 1 | Cable - Traction Upper |
| 21 | 140-7926 | 2 | Cable-Clutch |
| 23 | 137-3043 | 1 | Screw-HWH |
| 24 | 136-7191 | 1 | Clamp-Cable |
| 25 | 140-7925-03 | 1 | Gate-Shift, Speed |
| 26 | 104-0858 | 1 | Bolt-Shoulder |
| 27 | 99-6808 | 1 | Washer-Stepped |
| 28 | 119-4040 | 2 | Nut-Flange, NI |
| 29 | 126-4424 | 1 | Screw-Shoulder |
| 30 | 142-2432 | 1 | Washer, Wave |
| 31 | 119-4041 | 1 | Nut-HF |
| 32 | 140-7863 | 1 | Cable-Hydro, Push Pull |
| 33 | 42-3560 | 1 | Bolt-Shoulder |


# Hydrostatic Drive Assembly



# Hydrostatic Drive Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 140-7930 | 1 | Hydro - Sst |
| 2 | 140-7936-03 | 1 | Bracket-Hydro, Cable |
| 3 | 119-4036 | 2 | Screw-HHF |
| 4 | 119-4041 | 2 | Nut-HF |
| 5 | 32144-85 | 8 | Screw-HWH |
| 6 | 140-7899-03 | 1 | Bracket-Hydro, Rear |
| 7 | 107069 | 5 | Clip |
| 8 | 138-3326 | 4 | Screw-HHF |
| 9 | 137-3005 | 4 | Nut-HF |
| 11 | 144-1226 | 1 | Screw-HHF Spcl |
| 12 | 3296-59 | 1 | Nut-Lock, NI |
| 13 | 140-7937-03 | 1 | Bracket-Hydro, Upper |
| 14 | 119-4150 | 1 | Washer-Flat |
| 15 | 3290-307 | 1 | Pin-Cotter |

# Track Drive Assembly



# Track Drive Assembly (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 140-7865-03 | 1 | Support-Track, ASM LH |
| 2 | 140-7870-03 | 1 | Support-Track, ASM RH ● |
| 3 | 120-7162 | 2 | Bushing-Axle |
| 4 | 32144-85 | 4 | Screw-HWH |
| 5 | 140-7886-03 | 2 | Hub-Drive, Weld ASM |
| 6 | 140-7889-01 | 2 | Wheel-Drive, Weld ASM |
| 7 | 140-7864 | 12 | Tube-Support |
| 8 | 135-5779 | 12 | Screw-HHF |
| 9 | 119-4041 | 18 | Nut-HF |
| 10 | 107-3039 | 2 | Pin-Lynch |
| 11 | 140-7914-03 | 1 | Bar-Pivot |
| 12 | 139-2598 | 2 | Screw-HHF |
| 13 | 140-7905-03 | 1 | Bracket-Height, Adjuster |
| 14 | 140-7910-03 | 1 | Pivot-Link, Weld ASM |
| 15 | 136-7199 | 1 | Bolt-Shoulder |
| 17 | 140-7909-03 | 1 | Latch ASM, Welded |
| 18 | 109-8054 | 2 | Bushing-Flange |
| 19 | 3290-343 | 2 | Pin-Hair |
| 22 | 140-7876 | 6 | Bushing-Tensioner |
| 23 | 140-7921 | 4 | Wheel-Bogey |
| 24 | 140-7890-03 | 2 | Tensioner, Welded |
| 25 | 140-7879-03 | 2 | Yoke-Bogey |
| 26 | 139-1723 | 2 | Washer-Flat |
| 27 | 109-6868 | 6 | Bolt-Carriage |
| 28 | 119-4042 | 6 | Nut-HF, NI |
| 29 | 140-7923 | 2 | Screw-HH |
| 30 | 115-1166 | 2 | Washer-Flat |
| 31 | 140-7878 | 2 | Skid-Track, ASM |
| 32 | 137-3061 | 6 | Bolt-CARR |
| 33 | 140-7862 | 2 | Track-Snow |
| 34 | 283-52 | 1 | Pin-Clevis |
| 35 | 131-8667 | 2 | Washer-Thrust |
| 36 | 3290-467 | 1 | Pin-Hair |
| 37 | 3-8664 | 2 | Washer-Thrust |
| 41 | 140-7929-01 | 1 | Brace-Front |
| 42 | 140-7928 | 1 | Cable-Adjust, Height |
| 43 | 42-3560 | 1 | Bolt-Shoulder |
| 44 | 119-4040 | 1 | Nut-Flange, NI |
| 45 | 107-1045 | 1 | Spring-Extension |
| 46 | 137-3089 | 1 | Nut-Hex |
| 47 | 140-7943-03 | 2 | Support-Bushing, Axle |

● Not illustrated

# Attachments and Accessories

## For 38875 Power TRX Commercial 1432 OHXE Snowthrower

| Product Name | Model/Part |
|---|---|
| Heated Grip Kit | 131-6460 |
| Kit-Cab | 139-1640 |
| Toro Snow Oil 0W30 Synthetic 20-Ounce Bottle | 38913 |
| Power Max HD Covers (2019) | 490-7415 |

## Notes:

## Notes:

## Notes:




**Count on it.**