Form No. 3397-429 Rev F

TORO®

Count on it.

Parts Catalog

GrandStand® Mower

With 48in TURBO FORCE® Cutting Unit

Model No. 74518—Serial No. 316000001 and Up

Register at www.Toro.com.
Original Instructions (EN)

3397-429 F

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1,6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.


Contents

48 Inch Deck Assembly 4
Deck Decal Assembly No. 127-1931 6
Spindle Assembly No. 127-0560 8
Deflector Assembly No. 120-2451 10
Ground Drive Assembly 12
LH Transaxle Assembly No. 136-4101 14
RH Transaxle Assembly No. 136-4102 16
Motion Control Assembly 18
LH Control Handle Assembly No. 132-5157 20
RH Control Handle Assembly No. 132-5158 22
Parking Brake Assembly 24
Deck Lift Assembly 26
HOC Lever Assembly No. 130-1755 28
Frame Assembly 30
Wheel, Tire and Bearing Assembly No. 130-4558 32
Platform Assembly 34
Engine Assembly 36
Fuel Tank Assembly 38
Wire Harness Assembly 40
Attachments and Accessories 42

© 2020—The Toro® Company
8111 Lyndale Avenue South
Bloomington, MN 55420

Contact us at www.Toro.com.
Printed in the USA.
All Rights Reserved


48 Inch Deck Assembly



48 Inch Deck Assembly (continued)

Ref.	Part Number	Qty.	Description
1	127-1931	1	Deck ASM
2	127-0560	3	Spindle ASM
3	120-6433	3	Pulley
4	109-6982	2	Wireform-Cover
5	109-6936	1	Cover-Belt, LH
6	109-6935	1	Cover-Belt, RH
7	117-0410-01	1	48 Inch Baffle ASM
8	121-1790-01	1	Baffle
9	107-8541-01	1	Baffle-Discharge
10	117-5758-03	4	Bracket-Cover
11	120-2451	1	Deflector ASM
12	104-8301	48	Nut-HF, NI
13	107-3192-03	3	Blade-16.5 Inch (High Flow)
14	3231-2	9	Bolt-CARR
15	131-1121	1	Belt-V
16	32144-70	4	Screw-HWHTF
17	109-6658	2	Nut-Flange, NI
18	92-1624	3	Screw-HWH
19	105-4622	1	Spacer
20	322-50	1	Screw-HH
21	104-8300	1	Nut-HF, NI
22	108-4052	1	Spring-Torsion
23	103-0865	3	Washer-Blade Bolt, Heavy
24	51-4060	3	Screw-Blade
25	130-1812	1	Torsion Idler ASM
26	127-1971	1	Pulley-Idler
27	323-14	1	Screw-HH
28	114-1908-01	1	Skid
29	130-6649-01	1	Bracket-Skid
30	109-2872	1	Spacer-Pulley
31	132-7543	1	Idler-Pulley, Flat
32	3231-44	1	Screw-CARR
33	132-5154	1	Shield-Dust


Deck Decal Assembly No. 127-1931



Deck Decal Assembly No. 127-1931 (continued)

Ref.	Part Number	Qty.	Description
2	133-4604	2	Decal-Danger
4	107-1690	1	Decal
5	93-7818	1	Decal-Torque, Blade Bolt
6	131-3507	1	Decal-Belt, Tension (CE)
7	131-1180	1	Decal-Adjustment, Baffle

Spindle Assembly No. 127-0560




Spindle Assembly No. 127-0560 (continued)

Ref.	Part Number	Qty.	Description
1		1	Spindle Housing ASM W/Studs ●
1:2	114-8195	6	Bolt-Neck, Ribbed
2	116-0720	2	Bearing-Ball
3	127-0554	1	Spacer-Bearing
4	127-0556	1	Shaft-Spindle, Ball Bearing
5	127-0557	1	Hub-Spindle (W/Studs)
6	92-5836	1	Washer
7	3296-67	1	Nut-Lock, NI

● Not serviced separately


Deflector Assembly No. 120-2451



Deflector Assembly No. 120-2451 (continued)

Ref.	Part Number	Qty.	Description
1	3231-4	4	Screw-CARR
2	106-3246-01	1	Deflector
3	106-3248-03	1	Strap-Discharge
4	110-0759	1	Deflector-Rubber
5	108-4059-01	1	Plate-Hinge, Rear
6	106-3253-01	1	Plate-Hinge, Front
7	104-8301	4	Nut-HF, NI


Ground Drive Assembly



Ground Drive Assembly (continued)

Ref.	Part Number	Qty.	Description
1	136-4101	1	LH Transmission ASM
2	136-4102	1	RH Transmission ASM
3	131-1131-03	1	Support-Transaxle
4	93-2569	4	Screw-HHF
5	116-4701	16	Screw-HHF
6	104-8301	18	Nut-HF, NI
7	131-7405-03	1	Plate-Skid, Transmission (RH)
8	131-7404-03	1	Plate-Skid, Transmission (LH)
9	117-5351	1	Spacer
10	1-413088	1	Bushing-Lever, Lift
11	131-1175	1	Arm-Idler
12	114-0463	2	Washer-Friction, Composite
13	110-9981	1	Washer-Plain
14	3234-39	1	Screw-HHF
15	93-1622	1	Pulley-Idler
16	3231-4	1	Screw-CARR
17	132-1184	1	Spring-Extension
18	131-1124	1	Belt-V
19	132-1135	1	Tank-HYD
20	3229-25	3	Screw-CARR
21	104-7201	3	Nut-HF
22	131-7427	1	HYD Hose ASM
23	109-0309	1	Hose-Fuel
24	92-2379	1	Clamp-Hose
25	131-7469	1	Rod-Bypass, RH
26	131-7470	1	Rod-Bypass, LH
27	108-2992	2	Pin-Hair
28	32180-030	1	Clip-Tie
29	132-7574	2	Wheel And Tire ASM
29:1	133-1414	1	Rim-8 Inch, Gray
29:2	133-1417	1	Tire
29:3	232-27	1	Stem-Valve
30	242-50	8	Nut-Lug
31	132-7584	2	Spacer-Hex
32	104-8300	2	Nut-HF, NI
33	3290-250	2	Pin-Cotter
34	2412-141	2	Clamp-Drive, Worm
35	3290-378	1	Tie-Cable

LH Transaxle Assembly No. 136-4101



4 = Items Included in Seal Kit


8 = Items Included in RH Brake Kit

LH Transaxle Assembly No. 136-4101 (continued)

Ref.	Part Number	Qty.	Description
1	132-4737	1	Nut-Lock
2	132-4738	1	Fan
3	132-4739	1	Pulley
4	136-5402	1	Seal Kit
4:1	100-6926	1	Cap-Sealing
4:2	132-4736	1	O-Ring
4:3		1	Cap-Seal ●
4:4		2	Seal-Washer ●
4:5		1	Packing ●
4:6	132-4744	1	Seal-Shaft
4:7		2	O-Ring ●
4:8		1	Seal-Oil ●
4:9	121-0959	1	Sealant
4:10	132-4745	1	Seal-Axle
4:11		1	Packing ●
5	104-3265	1	Pin
6	132-4700	1	Lever-Bypass
7	133-1461	1	Expansion Fitting Kit
7:1	136-4051	2	Seal-Fitting, Expansion
7:2		1	Fitting ●
7:3		1	Bolt-Flange ●
8	133-1468	1	Brake Kit,Left
8:1		1	O-Ring ●
8:2		1	Arm-Brake ●
8:3		1	Pin-Roll ●
8:4		1	Shaft-Brake ●
8:5		1	Actuator-Brake ●
8:6		1	Disc-Brake ●
8:7		1	Shoe-Brake ●
8:8		1	Shim Kit ●
9	132-4735	1	Cap-Oil
10	132-4746	1	Drain Bolt Kit
10:1		1	Seal-Washer ●
11	136-5401	1	Lever-Control, RH
12	132-4747	1	Sleeve
13	132-4748	1	Washer
14	136-5406	1	Axle Flange Kit
14:1		1	Flange ●
14:2		1	Key-Woodruff ●
14:3		1	Washer ●
14:4		1	Nut-Lock ●
14:5		1	Nut-Cap ●
15	132-4743	1	Hydro Filter Kit
15:1	136-5409	2	Filter
15:2	136-5410	2	O-Ring

● Not serviced separately

RH Transaxle Assembly No. 136-4102



4 = Items Included in Seal Kit


8 = Items Included in RH Brake Kit

RH Transaxle Assembly No. 136-4102 (continued)

Ref.	Part Number	Qty.	Description
1	132-4737	1	Nut-Lock
2	132-4738	1	Fan
3	132-4739	1	Pulley
4	136-5402	1	Seal Kit
4:1	100-6926	1	Cap-Sealing
4:2	132-4736	1	O-Ring
4:3		1	Cap-Seal ●
4:4		2	Seal-Washer ●
4:5		1	Packing ●
4:6	132-4744	1	Seal-Shaft
4:7		2	O-Ring ●
4:8		1	Seal-Oil ●
4:9	121-0959	1	Sealant
4:10	132-4745	1	Seal-Axle
4:11		1	Packing ●
5	104-3265	1	Pin
6	132-4700	1	Lever-Bypass
7	133-1461	1	Expansion Fitting Kit
7:1	136-4051	2	Seal-Fitting, Expansion
7:2		1	Fitting ●
7:3		1	Bolt-Flange ●
8	133-1462	1	RH Brake Kit
8:1		1	O-Ring ●
8:2		1	Arm-Brake ●
8:3		1	Pin-Roll ●
8:4		1	Shaft-Brake ●
8:5		1	Actuator-Brake ●
8:6		1	Disc-Brake ●
8:7		1	Shoe-Brake ●
8:8		1	Shim Kit ●
9	132-4735	1	Cap-Oil
10	132-4746	1	Drain Bolt Kit
10:1		1	Seal-Washer ●
11	136-5401	1	Lever-Control, RH
12	132-4747	1	Sleeve
13	132-4748	1	Washer
14	136-5406	1	Axle Flange Kit
14:1		1	Flange ●
14:2		1	Key-Woodruff ●
14:3		1	Washer ●
14:4		1	Nut-Lock ●
14:5		1	Nut-Cap ●
15	132-4743	1	Hydro Filter Kit
15:1	136-5409	2	Filter
15:2	136-5410	2	O-Ring

● Not serviced separately


Motion Control Assembly



Motion Control Assembly (continued)

Ref.	Part Number	Qty.	Description
1	132-5157	1	LH Control Handle ASM
2	132-5158	1	RH Control Handle ASM
3	119-0222	2	Grip
4	103-9928	2	Bearing
5	120-3288	1	Tab-Pivot, LH
6	3229-1	4	Screw-CARR
7	104-7201	6	Nut-HF
8	120-3287	1	Tab-Pivot, RH
9	130-1803	1	LH Control Rod ASM
9:1	1-603807	1	Spring-Return, Neutral
9:2	92-7008	1	End-Rod, Female
9:3	103-1167	1	Joint-Ball End, LH
9:4	132-7515	1	Rod-Control
9:5	3256-45	2	Washer-Flat
10	130-1807	1	RH Control Rod ASM
10:1	92-7008	1	End-Rod, Female
10:2	103-1167	1	Joint-Ball End, LH
10:3	132-7515	1	Rod-Control
11	3231-28	2	Screw-CARR
12	104-8301	4	Nut-HF, NI
13	3256-24	2	Washer-Flat
14	132-7538	1	Bracket-Adjustment, Speed
15	126-1499	2	Cam


LH Control Handle Assembly No. 132-5157




LH Control Handle Assembly No. 132-5157 (continued)

Ref.	Part Number	Qty.	Description
1	132-5115	1	Pivot-Control, Motion (LH)
2	131-3562	1	Bearing-Sleeve
3	132-5114-03	1	Lever-LH
4	323-10	1	Screw-HH
5	104-8301	1	Nut-HF, NI
6	110-7191	2	Washer-Thrust
7	116-2670	1	Screw-Shoulder
8	104-8300	1	Nut-HF, NI
9	132-5146	1	Spring-Extension

RH Control Handle Assembly No. 132-5158






RH Control Handle Assembly No. 132-5158 (continued)

Ref.	Part Number	Qty.	Description
1	120-8490	1	Pivot-Control, Motion (RH)
2	130-1825-03	1	Lever-RH
3	104-8301	1	Nut-HF, NI
4	323-10	1	Screw-HH
5	110-7191	2	Washer-Thrust
6	116-2670	1	Screw-Shoulder
7	104-8300	1	Nut-HF, NI
8	131-3562	1	Bearing-Sleeve
9	132-5146	1	Spring-Extension


Parking Brake Assembly



Parking Brake Assembly (continued)

Ref.	Part Number	Qty.	Description
1	132-5170	1	Brake Handle ASM
2	3230-23	5	Bolt-CARR
3	104-8300	6	Nut-HF, NI
4	132-5168	1	RH Brake Caliper ASM
5	132-5169	1	LH Brake Caliper ASM
6	104-8301	2	Nut-HF, NI
7	32144-4	2	Screw-HWH
8	132-1187	1	Clamp-Cable
9	132-7582	1	Mount-Cable, Brake
10	1-633268	1	Grip-Lever
11	131-1195	2	Cable-Brake


Deck Lift Assembly



Deck Lift Assembly (continued)

Ref.	Part Number	Qty.	Description
1	120-8405-01	1	Shaft-Cross, Front
2	109-9409	2	Support-Bearing, Cross Shaft (Front)
3	109-9410	2	Bearing-Cross Shaft, Front
4	116-1700	4	Bolt-CARR
5	99-5107	8	Nut-Lock
6	127-0369	6	Bushing
7	10-8110	3	Washer-Thrust
8	3256-62	3	Washer-Flat
9	120-8411-01	1	Arm-Lift, RH
10	32151-29	3	Ring-Retaining
11	120-8410-01	1	Arm-Lift, LH
12	130-1755	1	HOC Lever ASM
13	119-6223	2	Washer
14	3296-53	3	Nut-Lock, NI
15	327-7	3	Screw-HH
16	130-6615	1	HOC Link ASM
17	3218-6	1	Nut-Jam
18	98-5975	1	Washer-Belleville
19	323-58	1	Bolt-TAP, HH
20	116-0886	1	Spring-Extension
21	116-0780	4	Screw-Shoulder, HHF
22	3256-28	4	Washer-Flat
23	127-1948-03	2	Link-Lift
24	136-5675	1	Deck Strut ASM
24:2	126-8360	4	Bushing-Rubber, Suspension
24:3	108-6544	4	Spacer
25	3231-7	4	Screw-CARR
26	104-8301	7	Nut-HF, NI
27	32128-19	4	Nut-HF Lock,Large Flg
28	109-9066	4	Yoke-Adjust, Deck
29	322-47	4	Screw-HH
30	3218-2	8	Nut-Jam
31	130-6589	2	Link-Lift
32	109-9840	2	Screw-Shoulder, HHF
33	109-9065	2	Screw-HH
34	116-2428	2	Bushing-Flanged
35	3256-4	2	Washer-Flat
36	114-8417	4	Nut-HF, NI
37	104-0151	2	Spacer
38	84-2350	1	Spacer-Long
39	132-7581	1	HOC Plate And Decal ASM
40	131-1103-01	1	Plate-HOC, Inner
41	116-4701	3	Screw-HHF
42	80-7590	2	Spacer
43	116-5584	1	Pin-HOC
44	116-0756	2	Deck Lift Chain ASM
44:1	1-633447	1	Chain-Lift, Deck
44:2	109-9065	1	Screw-HH
44:3	32128-37	1	Nut-HF
45	130-0742	2	Bolt-Shoulder
46	43-0940	2	Spacer
47	133-1431	1	Spacer-Split


HOC Lever Assembly No. 130-1755



HOC Lever Assembly No. 130-1755 (continued)

Ref.	Part Number	Qty.	Description
1	130-1775-01	1	Lever-Lift
2	119-2331	1	Rod-Latch
3	114-8187	1	Spring-Compression
4	114-1207	1	Washer-Special
5	115-2750	1	Knob
6	115-3592	1	Grip
7	119-2309	1	Bolt-Shoulder
8	103-1363	4	Rivet
9	614672	1	Screw-Shoulder, HWH
10	98-1629	1	Washer
11	104-7201	1	Nut-HF
12	104-8301	1	Nut-HF, NI
13	131-7452	1	Latch-HOC


Frame Assembly



Frame Assembly (continued)

Ref.	Part Number	Qty.	Description
2	131-7423-01	1	Frame
8	132-7537	1	Tower Decal ASM
8:2	131-3524	1	Decal-Level, Oil
8:3	131-3529	1	Decal-Service Aid
8:4	116-8775	1	Decal-Fill, Fuel
8:5	131-3527	1	Decal-Caution
8:6	131-3526	1	Decal-Controls
8:7	131-3528	1	Decal-Fuse
9	3234-42	4	Screw-HHF
10	104-8301	8	Nut-HF, NI
11	131-7455	1	Plate-Striker
12	3229-11	1	Screw-CARR
13	104-7201	1	Nut-HF
14	105-4886	4	Nut-Tinnerman
15	3230-5	3	Bolt-CARR
16	104-8300	9	Nut-HF, NI
17	107-3844	3	Washer
18	130-4558	2	Wheel/Tire And Bearing ASM
19	132-5161-01	1	Tube-Mount, Fuel Tank
20	132-1145-03	1	Bracket-Cross
21	117-3591	2	Decal-Commercial
22	114-1925	2	Bumper-Rubber
23	114-1926	2	Bumper-Rubber
24	121-7988-01	2	Fork-Caster
25	1-811010	2	Plug
26	1-543509	4	Bearing-Roller, Tapered
27	116-5647	2	Seal-Grease
28	1-633508	6	Washer-Bellville
29	103-4882	2	Cap-Grease
30	132-5150-03	1	Guard-Engine
31	1-513658	4	Bumper
33	3230-10	2	Bolt-CARR
34	3296-51	2	Nut-Lock, NI
35	3290-271	2	Rivet-Pop
38	130-1790	1	Decal-Panel, Control
48	107-3002	2	Washer-Nylon
49	105-8278	1	Decal
52	132-7578-01	1	Guard-Fan, RH
53	132-7598-01	1	Guard-Fan, LH
63	133-4641	2	Decal-Warning, No Riders

Wheel, Tire and Bearing Assembly No. 130-4558




Wheel, Tire and Bearing Assembly No. 130-4558 (continued)

Ref.	Part Number	Qty.	Description
1		1	Wheel And Bearing ASM ●
1:1	1-633585	2	Bearing-Cone, Taper
1:2	103-0063	2	Seal-Caster
1:3	103-3051	2	Spacer-Nut ■
1:4	103-3157	1	Axle-Caster
1:5	130-4563	1	Wheel And Tire ASM
2	103-2768	2	Guard-Seal
3	3296-45	1	Nut-Hex
4	325-20	1	Screw-HH

● Not serviced separately
■ Use Pro-Lock, Nut Type (P/N 1-840022, .5ml tube) on spacer nut


Platform Assembly



Platform Assembly (continued)

Ref.	Part Number	Qty.	Description
1	120-8499-03	1	Hinge-Pad
2	117-9739	1	Pad-Cushion
3	3256-23	4	Washer-Plain
4	121-7999	4	Screw-HH
5	114-0463	4	Washer-Friction, Composite
6	133-1426	2	Knob
7	116-2886	2	Slide-Bushing
8	3253-4	2	Washer-Lock
9	131-4535	2	Nut-Acorn
10	111044	4	Spacer
11	114-1915-01	2	Link-Pad
12	3256-4	6	Washer-Flat
13	3296-59	4	Nut-Lock, NI
14	3231-2	2	Bolt-CARR
15	3231-27	2	Screw-CARR
16	120-8475-01	1	Platform
17	114-5349	1	Mat-Foot
18	114-1920-03	1	Clamp-Shield
19	32144-70	2	Screw-HWHTF
20	119-8650	1	Pin-Latch
21	114-5348	1	Spring
22	1-603175	1	Knob-Ball
23	132-7583	2	Bushing-Flanged
24	104-8301	2	Nut-HF, NI
25	323-11	2	Screw-HH


Engine Assembly



Engine Assembly (continued)

Ref.	Part Number	Qty.	Description
1	130-6637	1	Engine-Kohler, Evc730
2	98-5975	4	Washer-Belleville
3	126-0983	4	Screw-BHTF
5	132-1168	1	Bracket-Muffler
6	3234-42	2	Screw-HHF
8	104-8301	2	Nut-HF, NI
9	133-4634	1	Muffler-Kohler
12	3234-17	4	Screw-HHF
13	32128-25	4	Nut-HF
14	1-807259	1	Key
15	120-8498	1	Pulley
16	131-1100	1	Clutch
17	107-4136	1	Washer
18	1-603610	1	Washer-Spring
19	3212-6	1	Screw-HH
20	131-3586-03	1	Stop-Clutch
21	32144-70	4	Screw-HWHTF
22	132-5152	1	Throttle ASM
23	1-807533	2	Bolt-CARR
24	32128-17	2	Nut-Lock, Flange
25	1-603175	1	Knob-Ball
26	131-3550	1	Muffler Guard ASM
29	94-2579	1	Decal
30	131-3530-03	1	Bracket-Mounting, Guard
31	106-9758	1	Screw-CARR
32	3230-23	4	Bolt-CARR
33	104-8300	5	Nut-HF, NI
34	3290-378	1	Tie-Cable
35	116-5108	1	Oil Drain Hose ASM
35:2	353-508	1	Plug-HH
35:2:1	237-42	1	O-Ring


Fuel Tank Assembly



Fuel Tank Assembly (continued)

Ref.	Part Number	Qty.	Description
1	132-7560	1	Fuel Tank ASM
1:2	46-6560	2	Bushing
1:3	115-7788	1	Cap-Fuel
1:4	104-5228	1	Fitting-Elbow, 90 DEG
1:5	132-7559	1	Fuel Tube ASM
2	110-8255	1	Hose-Fuel
3	98-2952	1	Fitting-Straight
4	132-7576	1	Hose-Fuel
5	132-7545	1	Fuel Line ASM

Wire Harness Assembly



Wire Harness Assembly (continued)

Ref.	Part Number	Qty.	Description
1	130-1800	1	Harness-Wire
1:1	109355	2	Fuse-Blade, 15 Amp
1:2	218-578	1	Fuse-Blade, 10 Amp
1:3	116-0053	1	Cap-Plug
1:4	114241	1	Fuse-Blade, 7.5 Amp
2	82-2190	3	Switch-Bail
3	104-8162	1	Battery
4	130-6635-01	1	Bracket-Hold Down, Battery
5	104-7201	2	Nut-HF
6	1-633651	2	Bolt-Holddown
7	112-7063	1	Cable-Battery, Black
8	130-6570	1	Module-Meter, Hour
9	3256-23	2	Washer-Plain
10	322-3	2	Screw-HH
11	115-3864	1	Cable-Battery, Positive
12	109-5715	2	Nut-HHF, Smooth
13	114-0279	1	Switch-PTO, On-On
14	117-2222	1	Switch-Ignition
15	63-8360	1	Key-Ignition
16	3253-3	1	Washer-Lock
17	3217-5	1	Nut-Hex
18	3290-500	1	Screw-PPH
19	3256-14	1	Washer-Flat
20	3296-2	1	Nut-Lock, NI
21	1-643275	1	Relay
22	67-1300	1	Decal
23	1-643267	1	Indicator-LED, Red
99	3290-378	4	Tie-Cable

Attachments and Accessories

For 74518 GrandStand Mower With 48in TURBO FORCE Cutting Unit

Product Name	Model/Part
Quick Attach-Male	132-5193
MVP Pack	133-1447
Snow Tires	133-4603
E-Z Vac Bagger	78570
48in Ez Vac Blower Drive K	78574
Recycler Kit	115-7466
Brake Hub Puller	116-6518
Speed Setting Tool	132-7595
Light Kit	133-1437
Electric Accessory Port	133-1438
Hydraulic Cap Lock Kit	136-5420
Twin Bagger Kit	78524
Trash Bag Assembly	133-1435
HOC Set Blocks	133-1439
Strobe Light Kit	133-1495
Blower Drive 48In	78525
15-Pound Cast Weight	112-7059-01
Harness Wire Splitter	121-5988
Trimmer Rack	133-1441
5 Gallon Bucket	133-2533
Filter-Oil	98020
Spark Plug	130-8380
Stand-On Weight Kit	133-1428
Chute Gate Kit W/ Bag	133-1434
Bucket Mount Kit	136-5681
Pneumatic Castor Wheel Kit	137-4136
Roller Striper Kit	133-1436
Starter Fuse Kit, GrandStand Mower	139-5555
18x8.5n10 X-Tweel Turf	139-7890
Soft Bag (3 Bushel)	30104
Air Cleaner Filter	100-4556
Filter Air Safety	103-1326
Bagging Enhancement Kit	108-4091
Bagger Enhancement Kit	139-1529
6in Hose Kit, E-Z Vac Twin Bagger, 2016 and After Grandstand Mower	139-7930
Blower Upgrade Kit, Twin Bagger, 2016 and After Grandstand Mower	139-7940
Fuel Filter	130-8381
Blade-Lo Flow, 16.5in (6 Pack)	110-0415
Blade-Low Flow, 16.5in	107-3193-03
Blade-Mid Flow, 16.5in (6 Pack)	110-0418
Blade-Mid Flow, 16.5in	107-3194-03
Blade-Hi Flow, 16.5in (6 Pack)	110-0414
Blade-Hi Flow, 16.5in	107-3192-03
Blade-Recycler, 16.5in (6 Pack)	110-0416
Blade-Recycling, 16.5in	107-3196-03
Blade-Atomic, 16.5in (6 Pack)	110-0417

Attachments and Accessories (continued)

Blade-Atomic, 16.5in 107-3195-03
Blade And Belt Kit-48 In 132-4740
Anti-Scalp Kit, 48/52 Grandstand Deck..... 133-1440
Hypr-Oil 500 (quart) 114-4713
Hypr-Oil 500 (gallon).....114-4714
Hypr-Oil 500-5 (5 gallon).....114-4715
Toro Premium Fuel Treatment 12 Oz Bottle 131-6572
Hydro Filter Kit 132-4743
Hydro Oil Change Kit 133-1457
10w30 4-Cycle Engine Oil (32oz Bottle)..... 38280
Toro 4-Cycle SAE 30 Oil (32oz Bottle) 38903
Spark Arrestor 98-9099



Count on it.