Form No. 3328–139

Groundsmaster® 455–D with 126in Quadfloat® Cutting Unit

Traction Unit

Model No. 30450—220000301 and Up

Model No. 30455—220000301 and Up

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form **a:b.** The **a** represents the reference number of the entire service assembly and the **b** represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number **6**, the tire by **6:1**, the valve by **6:2**, and the wheel by **6:3**. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually.

Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form **nX y.** The **n** represents the quantity of the part, the **X** is the multiplication symbol, and the **y** represents the reference number.

For example, in an illustration, the reference number **2X 37** means that two of the parts identified by reference number 37 are indicated.

© The TORO Company — 2002
All Rights Reserved

Contents


Description	Page
Frame and Body Assembly	4
Front Transaxle Installation Assembly	6
Transaxle Assembly No. 99–7566	8
Hydraulic Motor Assembly No. 92–2556–01	9
Front Axle Assembly	10
Brake Linkage Assembly	11
Traction and Brake Pedal Assembly	12
Steering Tower Assembly	13
Power Steering Valve Assembly No. 92–9729	15
Seat Plate Assembly	16
Seat and Roll–Over–Protection–System Assembly	17
Mini Suspension Assembly No. 76–1970	18
Control Console Assembly	19
Gage Panel Assembly	20
Lift Valve Installation Assembly	21
Lift Valve Assembly No. 92–7762	23
Cylinder and Lift Arm Assembly	24
Hydraulic Cylinder Assembly No. 86–5580	25
Fuel Tank Assembly	26
Fuel Filter Assembly No. 76–5300	27
Hydraulic Reservoir Assembly	28
Hydraulic Pump Installation Assembly	30
Gear Pump Assembly No. 94–8297	32
Traction Pump Assembly No. 86–5590	33
Deck Drive Component Assembly	34
Clutch Assembly No. 98–7250	35
Electrical Schematic Main Wire Harness Assembly No. 104–7414	36
Hydraulic Pump Fitting Assembly	37
Solenoid Valve Assembly No. 76–9970 (only on: 30455)	39
Engine Fasteners Installation Assembly	40
Air Filter Assemby No. 100–2597	43
Radiator Assembly	44
Rear Axle Assembly–2WD (only on: 30450)	45
Hydraulic Cylinder Assembly No. 94–8142 (only on: 30450)	47
Rear Axle Assembly–4WD (only on: 30455)	48
Bi–Directional Clutch Assembly No. 99–7500 (only on: 30455)	50
Hydraulic Motor Assembly No. 99–7502 (only on: 30455)	51
Hydraulic Cylinder Assembly No. 98–3806 (only on: 30455)	52
Hydraulic Schematic (only on: 30450)	53
Hydraulic Schematic (only on: 30455)	54

Description	Page
Rear Axle Assembly No. 100–3784 Bevel Pinion Shaft Assembly	55
Rear Axle Assembly No. 100–3784 (Continued) Differential Assembly	56
Rear Axle Assembly No. 100–3784 (Continued) Axle Support Assembly	57
Rear Axle Assembly No. 100–3784 (Continued) Bevel Gear Case Assembly	58
Rear Axle Assembly No. 100–3784 (Continued) Bevel Gear Shaft Assembly	59
Rear Axle Assembly No. 100–3784 (Continued) Axle Case Assembly	60
Rear Axle Assembly No. 100–3784 (Continued) Axle Assembly	61
Right Hand Deck Assembly	62
Left Hand Deck Assembly	63
Center Deck Assembly	64
Hydraulic Cylinder Assembly No. 86–2190	66
Deck Breakaway Assembly	67
Trap Door Assembly	68
Drive Assembly	69
Driveshaft Assembly No. 86–1730	70
Gearbox Assembly No. 100–2585	71
Rear Castor Assembly	72
Pulley Assembly	73
Front Castor Assembly	74
Belt Tensioner Assembly	75
Hydraulic Assembly	76
Cover Assembly	77
Clutch Spindle Assembly	78
Electric Clutch Brake Assembly No. 100–2559	79
Center Spindle Assembly	80
Wing Spindle Assembly	81
Crankcase Assembly	82
Crankshaft Assembly	83
Cylinder Head Assembly	84
Camshaft and Fan Support Assembly	88
Timing Cover Assembly	89
Intake and Exhaust Manifold Assembly	90
Oil Pump Assembly	91
Collector Assembly	92
Water Pump Assembly	93
Fuel Injection Pump Assembly	94
Fuel Injector Assembly	95
Alternator Assembly	96
Starter Assembly	97
Glow Plug and Glow Relay Assembly	98

Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

Abbreviation	Meaning
AR	as required
ASM	assembly
CARR	carriage
DEG	degrees
FH	flat head
GA	gauge
HF	hex flange
HH	hex head
HHF	hex head flange
HLH	hex lag head
HJ	hex jam
HOC	height-of-cut
HS	hex socket
HSBH	hex socket button head
HSFH	hex socket flat head
HSH	hex socket head
HWH	hex washer head
HWHTF	hex washer head thread forming
HYD	hydraulic
INC	incorporated
LH	left hand
NI	nylon insert
PPH	Phillips pan head
PTH	Phillips truss head
PTO	power take off
RH	right hand
SFH	slotted fillister head
SHH	slotted hex head
SQH	square head
SHWH	slotted hex washer head
SPH	slotted pan head
SRH	slotted round head
STD	standard
TAP	self tapping
TTH	Torx truss head
WH	wing head




Sheet No.:2

Frame and Body Assembly

Ref. No.	Part No.	Qty.	Description
1	62–7400	1	Decal–Logo, Toro
2	46–6810	9	Screw And Washer ASM
3	76–9700–01	1	Cover–Tower
4	84–1080	1	Frame (only on: 30450)
4	98–7826	1	Frame (only on: 30455)
4:61	256–237	1	Bushing
4:63	256–10	2	Bushing–Flange
4:64	32148–9	10	Insert–Nut
5	70–2560	2	Decal–Oil
6	68–7573	2	Strip–Sealing
7	94–5601–03	1	Support–Tank, Lower
8	76–6360	2	Strip–Sealing
9	93–7236–03	1	Support–Cleaner, Air
10	32144–11	17	Screw–TAP
11	3256–78	2	Washer–Flat
12	93–9426	1	Decal–Danger
14	65–5100	1	Handle–Door
15	46–8091	2	Screw–HWH
16	83–1470	2	Washer–Neoprene
17	323–6	1	Screw–HH
18	93–7798	1	Hood ASM
18:3	84–1460	2	Decal–Gm455d
18:5	94–5617	2	Strip–Sealing, Hood

Ref. No.	Part No.	Qty.	Description
18:6	94–5618	1	Trim–Firewall
19	3290–467	2	Pin–Hair
20	94–5613	2	Stop–Rubber
21	84–1490–01	2	Latch–Lockup
22	325–5	2	Screw–HH
23	48–7081	2	Grip–Plastic
25	32151–72	2	Ring–Retaining
27	32121–11	2	Pin–Roll
28	3290–359	3	Screw–HWH
29	94–5626	1	Latch–Draw, Flexible
29:1	100–5806	1	Handle–Latch
29:2	100–5807	1	Keeper–Latch
30	3290–357	2	Nut–HHF
31	3290–483	2	Washer
32	3296–25	2	Nut–Lock, NI
33	80–7730	1	Spacer
34	76–6361	1	Strip–Sealing
35	3256–3	2	Washer–Flat
36	3234–12	7	Screw–HHF
37	94–5609–03	1	Cover–Hood, Lower
38	323–4	1	Screw–HH
39	3253–21	2	Washer–Lock
40	3256–24	2	Washer–Flat
41	76–9300–01	1	Fender–LH
42	76–9340–01	1	Fender–RH
43	88–1310	1	Strip–Foam, Cover




Sheet No.:2

Frame and Body Assembly (Continued)

Ref. No.	Part No.	Qty.	Description
44	74–4090	1	Tread–Rest, Foot
45	3231–22	2	Screw–CARR
46	3250–36	2	Screw–PPH
47	100–2596–03	1	Cover–Seat, Front
48	76–6380	1	Seal–Cover, Front

Ref. No.	Part No.	Qty.	Description


3328–139



Front Transaxle Installation Assembly

Ref. No.	Part No.	Qty.	Description
1	323–9	1	Screw–HH
2	2411–36	1	Bearing–End, Rod
3	3220–3	1	Nut–Jam
4	84–0690	1	Rod–Shift
5	76–9100	2	Spacer–Speed, Reel
6	77–4260	1	Link–Shift
7	3296–59	1	Nut–Lock, NI
8	84–1610–03	1	Support–Rod, Shift
9	84–0700	1	Rod–Shift
10	32121–24	1	Pin–Spring
11	302–14	1	Fitting–Vent
12	2812–11	1	Bushing–Reducer
13	289–44	1	Nipple–Pipe
14	2813–14	1	Pipe–Elbow, 90
15	27–3710	1	Dipstick
16	99–7566	1	Transaxle–2 Speed
17	72–4320	1	Switch
18	32151–62	1	Ring–Retaining
19	237–167	1	O–Ring
20	84–1600	1	Arm–Lever, Front Axle
21	3234–12	2	Screw–HHF
22	3290–357	1	Nut–HHF
23	323–7	2	Screw–HH
24	92–5830	1	Traction Hose ASM
25	353–947	2	Cap–Dust, Rubber
26	3256–24	2	Washer–Flat

Ref. No.	Part No.	Qty.	Description
27	92–2556–01	1	Motor–Hydraulic
28	340–101	1	Fitting–HYD, 90°
28:1	237–30	1	O–Ring
28:2	237–79	1	O–Ring
29	86–5750	1	Motor Drain Tube ASM
30	3234–4	2	Screw–HHF
31	325–2	1	Screw–HH
32	86–5420	1	Spacer–Rod, Shift
33	32121–6	1	Pin–Roll
34	289–50	1	Nipple–Pipe
35	43–8610	1	Guide
36	3–1506	2	Bushing
37	86–5860	2	Nipple
38	92–1366	1	Spring–Compression
39	340–155	2	Fitting–HYD
39:1	237–79	1	O–Ring
39:2	237–151	1	O–Ring
40	92–7765	1	Traction Tube ASM (only on: 30455)
40	92–5841	1	Traction Hose ASM (only on: 30450)
41	340–167	2	Fitting–HYD, Tee
41:1	237–65	2	O–Ring
42	82–5380	1	Shim–Pinion, .045
43	82–5390	1	Shim–Pinion, .038
44	82–5400	1	Shim–Pinion, .052




Sheet No.:3

Front Transaxle Installation Assembly (Continued)

Ref. No.	Part No.	Qty.	Description
46	92–1364	1	Guide–Pin, Switch
47	92–1365	1	Plunger–Switch
48	237–30	1	O–Ring
49	2412–150	1	J–Clip


Ref. No.	Part No.	Qty.	Description



Transaxle Assembly No. 99–7566

Ref. No.	Part No.	Qty.	Description
1	76–5610	1	Pinion–Output
3	76–5630	1	Gear–Spur
4	76–5640	1	Gasket–Case & Cover
5	76–5650	3	Washer–Thrust
6	76–5660	2	Pin–Dowel
7	76–5670	2	Seal–Oil
9	76–5690	2	Washer–Thrust
10	76–5700	1	Bearing–Thrust
11	76–5710	1	Plug–Drain, Magnetic
12	76–5720	13	Screw–HWHTF
14	76–5680	1	Washer–Thrust
15	92–0639	1	Transaxle Case ASM
15:1	76–5860	2	Bearing–Needle
15:2	76–5870	3	Bearing–Needle
15:3	92–0640	1	Bearing–Needle
16	76–5760	1	Transaxle Cover ASM
16:1	76–5860	2	Bearing–Needle
16:2	76–5870	3	Bearing–Needle
17	92–0642	1	Gear–Output
18	76–5780	1	Gear–Spur
19	92–0644	1	Gear–Cluster
20	92–0641	1	Shaft–Counter
21	92–0645	1	Shifter–Gear & Shaft
22	76–5820	1	Screw–HHF
23	76–5830	1	Ball–Steel
24	76–5840	1	Spring–Fork, Shifter

Ref. No.	Part No.	Qty.	Description
25	76–5850	1	Seal–Oil
29	76–5890	2	Ring–Retaining
30	76–5900	1	Fork–Shift
31	92–0647	1	Rod–Shift, Hi–Low
32	99–7567	1	Differential ASM
36	76–5960	1	Carrier–Differential
37	104–0195	2	Bearing–Ball, Hi–Cap
38	76–5980	6	Screw–HHF
39	98–3801	6	Washer
40	76–5990	1	Carrier–Differential
42	76–6010	2	Spacer
44	76–6030	1	Seal–Oil
45	76–6040	2	Plug–Pipe
46	84–0080	1	Set–Gear, Matched Spiral
47	76–5680	1	Washer–Thrust
48	76–5740	1	Washer–Thrust
49	84–0090	1	Washer–Thrust
50	84–0130	1	Washer–Thrust
51	84–0140	1	Washer–Thrust




Sheet No.:A2
T–3626

Hydraulic Motor Assembly No. 92–2556–01

Ref. No.	Part No.	Qty.	Description
1	237–65	4	O–Ring
2	25–2380	1	Plate–Thrust
3	25–2430	1	Pin–Dowel
4	28–3380	1	Plate–Valve, Motor
5	48–1800	1	Cylinder Block Kit
☆5:1		1	Retainer–Slipper
☆5:2		9	Piston ASM
6	74–9480	1	Seal–Lip
7	74–9500	4	Screw–HH
8	74–9510	1	Washer–Plain
9	82–4970	1	Ring–Retaining
10	82–4990	1	Housing–Fixed
11	92–0636	1	Shaft ASM
☆11:1		1	Bearing
☆11:2		1	Sleeve
12	92–2571	1	Plug–Steel
13	92–2572	1	Motor Endcap ASM
13:1	77–3640	1	Bearing–Ball
14	67–9100	1	Gasket

Ref. No.	Part No.	Qty.	Description

☆ Not serviced separately




Front Axle Assembly

Ref. No.	Part No.	Qty.	Description
1	76–4240–03	2	Plate–Adapter
2	3274–87	12	Screw–HSFH
3	74–3640	4	Disc–Middle
4	106–1021	2	Disc–Actuating
4:1	92–7774	2	Stud
4:2	92–7775	2	Link
4:3	92–7776	2	Spring–Extension
4:4	92–7777	2	Disc–Actuating
4:5	92–7773	3	Ball
4:6	69–9940	2	Nut–HJ
5	92–9714	2	Flanged Axle ASM
5:1	242–34	5	Stud–Drive
5:2	32151–76	1	Ring–Retaining
5:4	92–9706	1	Spacer–Axle, Flanged
5:5	92–9708	1	Collar–Bearing
5:6	92–9709	1	Spacer–Bearing
5:7	92–9710	1	Bearing
5:8	92–9712	1	Seal–V–Ring
6	3234–30	6	Screw–HHF
7	325–4	1	Screw–HH
8	76–8300–03	2	Cover–Housing, Axle
9	32128–50	4	Nut–Flange
10	86–5430–03	1	Plate–Skid
11	325–15	10	Screw–HH
12	92–9704–03	2	Housing–Axle
13	84–1590	2	U–Bolt, Front Axle

Ref. No.	Part No.	Qty.	Description
☆14		2	Tire & Wheel ASM
14:1	99–5434	1	Tire
14:2	104–0161	1	Rim
14:3	232–27	1	Stem–Valve
15	84–1620–03	2	Plate–Support, Axle
16	23–7270	10	Nut–Wheel
17	76–6010	2	Spacer

☆ Not serviced separately




Sheet No.:5

Brake Linkage Assembly

Ref. No.	Part No.	Qty.	Description
1	84–0940	1	Fork–Brake, RH
1:2	302–5	1	Fitting–Grease
2	86–5840	2	Plate–Spring
3	3220–3	2	Nut–Jam
4	3296–59	2	Nut–Lock, NI
5	2411–36	2	Bearing–End, Rod
6	323–7	2	Screw–HH
7	76–9690–03	2	Rod–Brake
8	84–0990	2	Pin–Pivot
9	86–5830	2	Spring–Compression
10	66–6480	2	Washer
11	84–0970	1	Fork–Brake, LH
11:2	302–5	1	Fitting–Grease
12	32120–19	4	E–Ring
13	3296–39	2	Nut–Lock, NI
14	76–8270	2	Pin–Brake
15	76–4180	2	Boot–Rod, Brake
16	283–2	2	Pin–Clevis
17	76–6610	2	Clevis
18	3272–6	2	Pin–Cotter
19	3256–69	2	Washer–Flat

Ref. No.	Part No.	Qty.	Description




Sheet No.:6

Traction and Brake Pedal Assembly

Ref. No.	Part No.	Qty.	Description
1	3296–59	3	Nut–Lock, NI
2	2411–36	3	Bearing–End, Rod
3	3220–3	3	Nut–Jam
4	3256–3	1	Washer–Flat
7	74–9100	1	Pad–Pedal, Forward
8	82–5190–03	1	Pedal–Traction
9	74–9110	1	Pad–Pedal, Reverse
10	63–9751	1	Mount
11	3218–2	2	Nut–Jam
12	322–4	2	Screw–HH
13	3274–19	1	Screw–HSH
14	88–1160–03	1	Rod–Control
15	92–1367	1	Lever–Traction
16	32128–20	2	Nut–HF
17	323–9	1	Screw–HH
18	82–4960	2	Pad–Foot, Brake
19	63–7880	1	Pin–Latch, Brake
20	32121–50	1	Pin–Spring
21	3234–14	2	Screw–HHF
22	76–9680	1	Hub–Brake
22:2	256–90	1	Bushing–Flange
23	302–2	1	Fitting–Grease
24	92–5804–01	1	Pedal–Brake, LH
25	3296–42	1	Nut–Lock, NI
26	63–8410	1	Washer
27	92–5805	1	Pedal–Brake, RH

Ref. No.	Part No.	Qty.	Description
27:2	256–10	2	Bushing–Flange
27:3	302–5	1	Fitting–Grease
28	92–2586–01	2	Lever–Brake
29	32121–25	2	Pin–Roll
30	66–1140	3	Hub–Adjustment
31	92–5806–01	1	Shaft–Brake
32	302–5	3	Fitting–Grease
33	322–21	3	Screw–HH
34	76–9030	1	Brake Support ASM
34:2	256–10	2	Bushing–Flange
34:3	302–5	1	Fitting–Grease
35	32144–11	4	Screw–TAP
36	323–12	2	Screw–HH
38	84–1470	1	Decal–Safety
42	92–1370	1	Decal–Warning
45	32152–1	3	Nut–Lock, NI




Sheet No.:7
T–3628

Steering Tower Assembly

Ref. No.	Part No.	Qty.	Description
1	32121–10	1	Pin–Roll
2	74–5790	1	Shaft–Pivot
3	32121–123	2	Pin–Roll
4	10–8110	1	Washer–Thrust
5	3296–49	2	Nut–Lock, NI
6	2411–36	1	Bearing–End, Rod
7	3220–3	1	Nut–Jam
8	233–17	1	Knob
9	72–0130	1	Horn Kit
10	47–6990	1	Nut
11	68–8080	1	Wheel–Steering
12	32144–4	4	Screw–HWH
13	93–9415	1	Panel–Control, Tower
14	76–9450	1	Boot–Column, Steering
15	32144–11	6	Screw–TAP
16	323–8	1	Screw–HH
17	3296–59	1	Nut–Lock, NI
18	95–1821–03	1	Spring–Compression
19	3256–22	1	Washer–Flat
20	69–1560–03	1	Lever–Lock
21	3272–5	2	Pin–Cotter
22	76–9050	1	Rod–Brake, Park
23	84–0680	1	Link–Shift
24	32121–6	1	Pin–Roll
25	3272–10	1	Pin–Cotter


Ref. No.	Part No.	Qty.	Description
26	63–7900–03	1	Rack ASM
27	3256–26	4	Washer–Flat
28	20–9500	2	Washer
29	83–0740	2	Disc–Friction
30	76–8340	1	Shaft–Pivot, Steering
31	2410–64	2	Plug–Button
32	76–8150–03	1	Support–Shaft, Steering
33	92–9729	1	Steering Control ASM
34	340–138	3	Fitting–HYD, 45°
34:1	237–79	1	O–Ring
34:2	237–22	1	O–Ring
35	86–3210	1	Hose ASM
36	3290–378	2	Tie–Cable
37	59–6430	1	Valve–Check
37:1	237–22	1	O–Ring
37:2	237–79	1	O–Ring
38	86–5570	1	Hose ASM
39	86–3220	2	Hose ASM
40	76–8140–03	1	Bracket–Gear, Steering
41	76–8160–03	1	Support–Gear, Steering
42	323–6	4	Screw–HH
43	3253–21	4	Washer–Lock
44	74–3670	1	Steering Column ASM



Steering Tower Assembly (Continued)

Ref. No.	Part No.	Qty.	Description
45	76–9100	1	Spacer–Speed, Reel
46	82–4950	1	Plunger–Spring
47	74–5770–03	1	Lever–Shift
48	104–7415	1	Harness–Wire, Front
49	21–9260	1	Cover–Dust
50	340–70	3	Nut–Lock
51	340–71	1	Fitting–Straight, Bulkhead
51:1	237–22	2	O–Ring
52	2412–74	1	R–Clamp
53	340–159	3	Fitting–HYD, 90°
53:1	237–22	2	O–Ring
54	32144–57	2	Screw
55	3256–71	2	Washer–Flat
56	56–7973	4	Clamp–Tube
57	94–8299	1	Steering Tube ASM
58	86–5730	1	RH Front Tube ASM
59	86–5740	1	LH Front Tube ASM
60	2412–104	1	R–Clamp
61	2412–147	1	Clamp (only on: 30450)
62	29–6163	1	Switch–Micro
63	3249–11	2	Screw
64	3296–9	2	Nut–Lock, NI

Ref. No.	Part No.	Qty.	Description




Sheet No.:A3
T–3629

Power Steering Valve Assembly No. 92–9729

Ref. No.	Part No.	Qty.	Description
1	52–9260	1	Screw–Set
3	52–9230	1	Ring–Retaining
4	52–9240	1	Bushing
☆9		1	Housing
☆10		1	Sleeve–Control
11	59–6820	1	Centering Spring Kit
☆12		1	Spool–Control
15	52–9320	1	Drive
16	76–6300	1	Gerotor ASM
17	76–6320	1	Spacer
20	59–6830	1	Centering Pin Kit
21	52–9290	1	Retainer–Checkball
22	52–9280	1	Checkball
24	52–9270	1	Seat–Checkball
26	52–9250	1	Bearing Kit
26:1	59–6730	2	Race
26:2	59–6740	1	Bearing
27	92–9749	1	Seal Kit
☆27:1		1	Seal–Dust
☆27:2		1	O–Ring
☆27:3		1	O–Ring
☆27:4		3	O–Ring
☆27:5		1	O–Ring
☆27:6		1	O–Ring
28	92–9745	1	End Cap Kit
28:1	92–9732	1	Plate–Wear
28:2	92–9730	1	Cap–End
28:3	92–9736	7	Screw–Cap

☆ Not serviced separately




Sheet No.:8

Seat Plate Assembly

Ref. No.	Part No.	Qty.	Description
1	32104–82	1	Screw–HHF
2	2412–133	2	R–Clamp
3	74–0720	1	Tube–Manual
4	76–9460–03	1	Plate–Seat
5	77–3780	1	Pin ASM
5:10	28–8070	1	Lanyard
6	3290–282	1	Rivet–Pop, Steel
7	3256–49	1	Washer–Flat
8	76–9930	1	Foam–Center
9	3256–24	1	Washer–Flat
10	86–2860–03	1	Cover–Belt, Upper
11	82–4900	1	Foam–Seat, Rear
12	76–9440	1	Rod–Prop, Seat
16	3290–307	1	Pin–Hair
17	240–5	1	Grommet
18	321–5	1	Screw–HH
19	32144–11	3	Screw–TAP
20	32128–33	2	Nut–HF
21	70–1480	1	Relay
22	2412–74	1	R–Clamp
23	37–2690	1	Capacitor
23:1	3252–18	2	Screw
23:2	3254–1	2	Washer–Lock, Internal
25	237–136	2	Grommet
26	76–9480	2	Sleeve–Pivot, Seat
28	325–9	2	Screw–HH


Ref. No.	Part No.	Qty.	Description
29	48–4590	1	Disc–Horn
30	74–8910	1	Bracket–Horn
31	3256–23	2	Washer–Flat
32	322–2	2	Screw–HH



Sheet No.:9
T–3630

Seat and Roll–Over–Protection–System Assembly

Ref. No.	Part No.	Qty.	Description
1	76–9370–03	1	Rops–2 Post (only on: 30455)
2	325–33	2	Screw–HH (only on: 30455)
3	3256–26	4	Washer–Flat (only on: 30455)
4	325–2	4	Screw–HH (only on: 30455)
5	3253–7	4	Washer–Lock (only on: 30455)
6	82–5370	2	Foam–Rops (only on: 30455)
7	3296–25	2	Nut–Lock, NI (only on: 30455)
8	3212–5	2	Screw–HH (only on: 30455)
9	3253–6	2	Washer–Lock (only on: 30455)
10	3256–5	2	Washer–Flat (only on: 30455)
11	3256–28	2	Washer–Flat (only on: 30455)
12	21–4191	1	Seat Belt ASM (only on: 30455)
13	76–1970	1	Suspension–Seat
14	3256–2	8	Washer–Flat
15	3296–29	4	Nut–Lock, NI
16	322–3	4	Screw–HH
17	3253–4	4	Washer–Lock
18	104–4620	1	Seat–Olympic, Toro
19	92–7307	1	LH Armrest ASM
19:1	69–0760	1	Bracket–Arm, LH
19:2	92–7301	1	Spacer
19:3	69–1180	1	Armrest
19:4	323–9	1	Screw–HH
19:5	32128–19	1	Nut–HF
19:7	3256–24	1	Washer–Flat
20	92–7306	1	RH Armrest ASM
20:1	69–0770	1	Bracket–Arm, RH
20:2	92–7301	1	Spacer
20:3	69–1180	1	Armrest
20:4	323–9	1	Screw–HH
20:5	32128–19	1	Nut–HF
20:7	3256–24	1	Washer–Flat
21	3234–14	6	Screw–HHF
22	66–9290	4	Spacer–Suspension
23	3218–2	4	Nut–Jam
30	92–6282	1	Switch–Seat
31	3234–33	2	Screw–HHF




Sheet No.:A4
T–3631

Mini Suspension Assembly No. 76–1970

Ref. No.	Part No.	Qty.	Description
1	32153–2	1	Nut–Lock
2	3217–6	1	Nut–Hex
3	322–6	1	Screw–HH
4	3253–33	1	Washer–Lock
5	3256–24	1	Washer–Flat
6	66–8510	1	Adjuster W/Handle
7	66–8530	1	Adjuster
8	66–8560	4	Nut–Push
9	66–8600	1	Frame–Upper
10	66–8610	1	Frame–Lower
11	66–9290	4	Spacer–Suspension
12	76–1910	2	Shaft–Pivot
13	76–1920	4	Sleeve–Bearing
14	76–1930	1	Knob–Adjuster, Tension
15	76–1940	2	Spring–Extension
16	76–2940	2	Bumper
17	77–2870	1	Hanger–Spring
18	93–3163	2	Spring
19	93–3164	2	Cap
20	93–3165	1	Bracket

Ref. No.	Part No.	Qty.	Description




Sheet No.:10

Control Console Assembly

Ref. No.	Part No.	Qty.	Description
1	233–39	1	Knob–Control
2	76–4300	1	Lever–Throttle
3	3290–126	2	Screw
4	3296–44	1	Nut–Lock, NI
6	52–2900	2	Washer
7	94–5627	1	Plug
8	32128–33	1	Nut–HF
9	76–8450	1	Boot–Lever, Lift
10	76–5260	1	Relay–Plug,Glow
11	76–8440	1	Boot–Throttle
12	86–5410	1	Panel–Console
13	83–2280	1	Timer–Delay
☆13:1		1	Timer–Delay
13:1:1	98–4604	1	R–Clamp
14	70–1480	3	Relay
15	32144–86	1	Screw–HH
16	218–573	2	Fuse–5 Amp
17	218–581	1	Fuse–15 Amp, 32 Volt
18	218–593	1	Fuse–30 Amps
19	3296–12	2	Nut–Lock
20	74–5480	1	Cable–Throttle
21	2412–31	1	Clamp–Boden
22	32144–4	10	Screw–HWH
23	321–2	1	Screw–HH
24	3256–78	1	Washer–Flat (only on: 30455)

Ref. No.	Part No.	Qty.	Description
24	3256–78	2	Washer–Flat (only on: 30450)
25	77–3970	1	Spacer–Relay
26	3255–8	1	Washer–Lock
27	3296–47	1	Nut–Lock, NI
28	3296–42	1	Nut–Lock, NI
29	3255–7	1	Washer–Lock/Ext
30	48–7880	1	Nut–Hex
31	48–7890	1	Nut
32	3256–35	1	Washer–Flat

☆ Not serviced separately




Sheet No.:11
T–3632

Gage Panel Assembly

Ref. No.	Part No.	Qty.	Description
1	92–6564	1	Decal–4 Matic (only on: 30455)
2	84–1450	1	Panel–Gauges, Console
3	32151–72	2	Ring–Retaining
4	93–7483	1	Lamp–Cluster
4:1	3217–26	1	Nut–Hex
4:2	3254–1	1	Washer–Lock, Internal
☆4:3		1	Clamp
4:4	87–6270	4	Socket–Light
4:5	219–17	4	Bulb
5	76–9060	1	Gauge–Temperature
5:1	3219–14	6	Nut–Hex
5:2	3253–2	5	Washer–Lock/Sp
5:3	3256–14	2	Washer–Flat
6	66–2940	1	Gauge–Fuel
6:2	3254–1	2	Washer–Lock, Internal
6:3	3217–27	2	Nut–Hex
6:4	3255–24	3	Washer–Lock/Ext
6:5	3217–16	3	Nut–Hex
7	93–7484	1	Cluster–Lamp
7:1	3217–26	1	Nut–Hex
7:2	3254–1	1	Washer–Lock, Internal
☆7:3		1	Clamp
7:4	87–6270	4	Socket–Light
7:5	219–17	4	Bulb

Ref. No.	Part No.	Qty.	Description
8	32144–4	6	Screw–HWH
9	3256–24	2	Washer–Flat
10	3250–36	2	Screw–PPH
11	63–8360	1	Key–Ignition
12	82–3750–03	1	Cover–Console
13	27–2360	1	Switch–Key
13:1	218–446	1	Nut–Hex
13:2	218–447	1	Washer–Lock
14	85–4980	1	Switch–PTO
14:1	3218–19	2	Nut–HJ
14:2	3254–20	1	Washer–Lock,Internal
15	32128–33	4	Nut–HF
16	3274–31	4	Screw–HSBH

☆ Not serviced separately




Sheet No.:12

Lift Valve Installation Assembly

Ref. No.	Part No.	Qty.	Description
1	46–6810	4	Screw And Washer ASM
2	76–7090–03	1	Cover–Control, Front
3	76–6270	1	Strip–Foam, Panel
4	82–5300–03	1	Heel–Support
5	32144–11	2	Screw–TAP
6	340–99	1	Fitting–HYD, 90°
6:1	237–30	1	O–Ring
6:2	237–42	1	O–Ring
7	321–10	2	Screw–HH
8	3272–1	6	Pin–Cotter
9	323–17	1	Screw–HH
10	3256–24	2	Washer–Flat
11	233–42	3	Knob
12	74–6060	1	Lever–Valve, RH
13	74–6050	1	Lever–Valve, Center
14	69–7010	1	Lever–Valve, LH
15	3296–39	1	Nut–Lock, NI
16	69–9140	3	Link–Lever, Valve
17	92–7762	1	Control Valve ASM
18	74–5910	1	Bulkhead–Special
18:1	237–79	2	O–Ring
19	95–4354	1	Hose ASM
20	340–1	3	Adapter
20:1	237–35	1	O–Ring
20:2	237–42	1	O–Ring

Ref. No.	Part No.	Qty.	Description
21	84–6402	1	Disc–Orifice
22	3290–379	1	Tie–Cable
23	86–5440	1	Dual Wing Relief ASM
23:1	88–1520	1	Cartridge–Relief
23:2	88–1530	1	Cartridge–Relief, Differential
24	86–3190	2	Hose ASM
25	63–4090	1	Fitting
25:1	237–30	1	O–Ring
25:2	237–79	1	O–Ring
26	86–3180	1	Hose ASM
27	353–947	1	Cap–Dust, Rubber
28	86–3230	1	Hose ASM
29	86–5770	1	Reilief Valve Tube ASM
30	340–2	1	Fitting–HYD, Straight
30:1	237–22	1	O–Ring
30:2	237–42	1	O–Ring
31	93–7243	1	Decal–Service, 2wd (only on: 30450)
31	93–7242	1	Decal–Service, 4wd (only on: 30455)
32	86–5760	1	Deck Return Tube ASM
33	354–77	1	Fitting–Quick
33:1	237–78	1	O–Ring




Sheet No.:12

Lift Valve Installation Assembly (Continued)

Ref. No.	Part No.	Qty.	Description
34	76–7040	1	Pad–Foot
35	86–2501	2	Plate–Orifice

Ref. No.	Part No.	Qty.	Description



Sheet No.:A5
T–3633


Lift Valve Assembly No. 92–7762

Ref. No.	Part No.	Qty.	Description
1	58–6780	3	Plug
1:1	58–6790	1	O–Ring
2	60–6450	1	Disc
3	58–6760	3	Spring
4	58–6770	3	Plunger
6	353–508	3	Plug
6:1	237–42	1	O–Ring
☆8		1	Body
11	58–6350	3	Plug
11:1	60–5720	1	O–Ring
11:2	58–6370	1	Washer
☆13		3	Spool
16	69–1830	1	Plug ASM
☆16:1		1	Washer
16:2	58–6750	1	O–Ring
☆16:3		1	Nut–Lock
18	58–6470	1	Washer
19	58–6480	1	Washer
20	58–6490	1	Washer
21	92–2567	1	Spring
22	92–2568	1	Poppet
☆23		1	Seat
25	58–6400	3	Bushing
26	58–6700	3	Washer
27	58–6730	3	Spring
30	58–6420	3	Cap

Ref. No.	Part No.	Qty.	Description
31	84–6430	1	Plunger
32	92–7780	3	Plug ASM
32:1	60–5720	1	O–Ring
32:2	58–6370	1	Washer
33	92–7778	3	Spring
35	58–6330	3	Seat
35:1	58–6340	1	O–Ring
37	84–6420	2	Plunger
38	92–7779	3	Eyelet
39	60–3780	1	Seal Kit
39:1	58–6790	3	O–Ring
39:2	58–6720	3	O–Ring
39:3	60–5720	6	O–Ring
39:4	58–6310	6	Spacer
39:5	58–6750	1	O–Ring
39:6	58–6450	6	O–Ring
39:7	58–6460	3	Ring
39:8	58–6290	3	Poppet
39:9	58–6340	3	O–Ring
39:10	58–6320	3	Wiper
39:11	58–6370	1	Washer

☆ Not serviced separately

3328–139




Sheet No.:13
T–3634

Cylinder and Lift Arm Assembly

Ref. No.	Part No.	Qty.	Description
1	340–132	2	Fitting–HYD, 90°
1:1	237–78	1	O–Ring
1:2	237–21	1	O–Ring
2	86–5580	2	HYD Cylinder ASM
3	340–140	1	Adapter–Tee
3:1	237–21	2	O–Ring
3:2	237–78	1	O–Ring
4	322–2	5	Screw–HH
5	3253–4	5	Washer–Lock
6	84–1350	2	Pin–Pivot
7	86–3160	1	Hose ASM
8	86–3200	1	Hose ASM
9	3247–4	2	Screw–Set
10	2412–137	1	Clamp–Tube
11	70–1380	1	Sleeve–Protective
12	340–125	1	Adapter
12:1	237–21	2	O–Ring
12:2	237–78	1	O–Ring
13	86–3170	1	Hose ASM
14	88–1190	2	Pin–Pivot
15	86–2790–03	1	Pin–Pivot, LH
16	88–1200–03	1	Pin–Pivot, RH
17	3220–7	3	Nut–Jam
18	86–5450	3	Coupler
19	68–6480	4	Bushing–Flange
20	302–5	6	Fitting–Grease

Ref. No.	Part No.	Qty.	Description
21	84–0730–03	1	Arm–Lift, LH
22	86–5890–03	1	Arm–Lift, RH
23	32108–58	4	Screw–FH
24	69–9300	2	Pad–Bumper




Parts not listed in part list are not serviced separately

Sheet No.:A6
T–3635

Hydraulic Cylinder Assembly No. 86–5580

Ref. No.	Part No.	Qty.	Description
10	88–3590	1	Nut–Lock
11	88–3600	1	Piston
12	88–3610	1	Barrel ASM
13	88–3620	1	Rod ASM
14	88–3630	1	Head–Ring, Snap
15	88–3640	1	Kit–Seal

Ref. No.	Part No.	Qty.	Description




Sheet No.:14

Fuel Tank Assembly

Ref. No.	Part No.	Qty.	Description
1	3234–12	2	Screw–HHF
2	76–9790	1	Foam–Tank, Fuel
3	74–5580	1	Tank–Fuel
3:10	285–22	1	Plug–Pipe
3:20	2812–1	1	Bushing–Pipe
4	93–3102	1	Cap–Fuel
5	76–6600	1	Pipe–Stand
6	2412–108	6	Clamp–Worm
7	46–6550	2	Fitting–HYD, 90°
8	46–6560	2	Bushing
9	106–1018	1	Bracket–Cover
10	63–7627	1	Hose–Fuel
11	68–6150	2	Breather–Air
12	2412–36	1	Clamp–Hose
13	76–8780	1	Decal–Caution, Fuel
14	323–4	7	Screw–HH
15	354–95	1	Fitting–Female, Barbed
16	354–94	1	Hose–Female, Barbed
17	74–9122	1	Hose–Overflow, Radiator
18	240–6	3	Grommet–Rubber
19	3256–24	9	Washer–Flat
20	3253–21	9	Washer–Lock
21	323–7	2	Screw–HH
22	63–7622	2	Hose–Fuel

Ref. No.	Part No.	Qty.	Description
23	32144–18	2	Screw–HH
24	94–5614–03	1	Bracket–Meter, Hour
25	76–6590–03	1	Plate–Tank, Fuel
26	63–7626	1	Hose–Fuel
27	32148–9	3	Insert–Nut
28	62–7650	1	Gasket
29	74–5860	1	Sender–Fuel
30	3253–15	5	Washer–Lock/Sp
31	32122–24	5	Screw–Pth
32	321–3	2	Screw–HH
33	3296–42	2	Nut–Lock, NI
34	70–1480	1	Relay
35	75–6820	1	Hourmeter
36	76–5300	1	Fuel Filter ASM
37	76–5190	2	Fitting–Adjustable



Parts not listed in part list are not serviced separately


Sheet No.:B2
T–3486

Fuel Filter Assembly No. 76–5300

Ref. No.	Part No.	Qty.	Description
1	76–5180	4	Washer–Copper
2	76–5190	2	Fitting–Adjustable
5	76–5220	1	Element–Filter
☆5:1		1	O–Ring
☆5:2		1	Seal–Gasket
☆5:3		1	Seal–Gasket
9	76–5320	1	Probe–Sensor, Water
9:1	94–8025	1	O–Ring
12	94–8026	1	Screw–Vent
12:1	94–8027	1	O–Ring
12:2	94–8028	1	O–Ring

Ref. No.	Part No.	Qty.	Description

☆ Not serviced separately




Sheet No.:15

Hydraulic Reservoir Assembly

Ref. No.	Part No.	Qty.	Description
1	104–0157	1	Hose–Suction
2	2412–34	1	Clamp–Hose
3	104–7546	1	Strainer–Tank
3:1	340–136	1	O–Ring
4	340–141	1	Fitting
4:1	237–22	1	O–Ring
4:2	237–80	1	O–Ring
5	340–6	1	Fitting–HYD, Straight
5:1	237–30	1	O–Ring
5:2	237–80	1	O–Ring
7	340–4	1	Adapter
7:1	237–30	1	O–Ring
7:2	237–79	1	O–Ring
8	353–551	2	Plug–HH
8:1	237–80	1	O–Ring
9	340–17	1	Fitting–HYD, 90°
9:1	237–65	1	O–Ring
9:2	237–80	1	O–Ring
10	86–3150	1	Hose ASM
11	86–5500	1	Hose ASM
13	340–147	1	Fitting–HYD, Tee
13:1	237–65	2	O–Ring
14	74–6230	1	Tube ASM (only on: 30455)
15	353–947	1	Cap–Dust, Rubber
16	74–4080	1	Orifice

Ref. No.	Part No.	Qty.	Description
17	340–109	1	Fitting–HYD, Tee (only on: 30455)
17:1	237–79	1	O–Ring (only on: 30455)
17:2	237–30	2	O–Ring (only on: 30455)
18	249–49	4	D–Ring
19	3234–13	2	Screw–HHF
20	76–9950	4	Bracket–Ring
21	354–103	1	Hose–Male, Barbed
22	2412–36	1	Clamp–Hose
23	94–8298	1	Oil Cooler Tube ASM
23:1	237–30	1	O–Ring
24	57–5420	1	Screw–Shoulder
25	32144–4	4	Screw–HWH
26	86–5860	1	Nipple
27	93–7160	1	Cap–Oil, HYD
28	61–2790	1	Filter–Screen
29	104–0164	1	Reservoir–Hydraulic
30	69–1170	1	Glass–Sight
30:1	237–81	1	O–Ring
31	32144–11	2	Screw–TAP
32	92–5840–03	1	Bracket–Mounting, Filter
33	240–11	3	Grommet–Mount, Tank




Sheet No.:15

Hydraulic Reservoir Assembly (Continued)

Ref. No.	Part No.	Qty.	Description
34	74–6400	1	Filter Line Tube ASM
35	340–8	1	Adapter
35:1	237–65	1	O–Ring
35:2	237–81	1	O–Ring
36	92–5821	1	Filter Head ASM
37	86–3010	1	Filter–Oil, Transmission
38	340–139	1	Fitting–HYD, 90°
38:1	237–81	1	O–Ring
38:2	237–65	1	O–Ring
39	86–5810	1	Velocity Tube ASM (only on: 30455)
40	323–5	3	Screw–HH
41	63–8410	3	Washer
42	353–550	1	Plug–HYD (only on: 30450)
42:1	237–79	1	O–Ring (only on: 30450)

Ref. No.	Part No.	Qty.	Description




Sheet No.:16

Hydraulic Pump Installation Assembly

Ref. No.	Part No.	Qty.	Description
1	94–8297	1	Pump–Gear
2	237–161	1	O–Ring
3	86–5590	1	Pump ASM
4	84–1380–03	1	Anchor–Spring
5	3256–24	6	Washer–Flat
6	63–9751	4	Mount
7	95–4352–03	1	Bracket–Neutral
8	63–8410	4	Washer
9	3296–59	3	Nut–Lock, NI
10	3296–29	5	Nut–Lock, NI
11	322–10	1	Screw–HH
12	3213–2	2	Screw–HH
13	76–8640	1	Stud–Traction
14	251–307	2	Bearing–Ball
15	75–5470	5	Spacer–Bearing
16	3–6498	2	Washer–Thrust
17	92–2581	1	Neutral Switch Arm ASM
17:1	256–113	2	Bushing–Flange
17:2	302–5	1	Fitting–Grease
18	322–7	1	Screw–HH
19	322–5	2	Screw–HH
20	324–4	2	Screw–HH
21	3253–6	2	Washer–Lock
22	76–9430–03	1	Spring–Extention
23	84–1480	1	Hose–Dampener

Ref. No.	Part No.	Qty.	Description
24	86–3040	2	Coupler–Line, Drive
25	323–29	3	Screw–HH
26	82–5180–03	1	Control–Pump
27	86–3020	1	Wire–Switch, Neutral
28	29–6163	1	Switch–Micro
29	3249–11	2	Screw
30	3296–9	2	Nut–Lock, NI
31	82–5280	1	Shaft–Pivot
32	2411–36	1	Bearing–End, Rod
33	3220–3	1	Nut–Jam
34	88–1470–03	1	Plate–Control, Pump
35	3290–357	1	Nut–HHF
36	3290–477	2	Washer–Curved
37	3256–71	3	Washer–Flat
38	32144–26	2	Screw–Flow
39	95–4351–03	1	Plate–Pivot
40	76–9760	1	Damper–Pivot
41	76–8870	1	Lever Damper ASM
42	32151–73	1	Ring–Clip
43	323–7	2	Screw–HH
44	322–6	2	Screw–HH
45	3296–47	2	Nut–Lock, NI
46	253–43	1	Seal–Oil
47	84–1330–03	1	Hub–Splined
48	84–1030–03	1	Shaft–Drive
49	84–0170–03	1	Pulley–PTO




Sheet No.:16

Hydraulic Pump Installation Assembly (Continued)

Ref. No.	Part No.	Qty.	Description
50	251–314	2	Bearing–Ball
51	86–5940	1	Spacer–Bearing, Upper
52	84–0750–03	1	Housing–Bearing, PTO
53	88–1430	1	Locknut–Bearing
54	3234–1	4	Screw–HHF
55	86–2830–03	1	Plate–Adapter, Main
56	100–2592	6	Screw–HHF
57	302–5	2	Fitting–Grease
58	3296–39	6	Nut–Lock, NI
59	3256–26	2	Washer–Flat
60	3256–3	1	Washer–Flat
61	323–45	6	Screw–HH
62	88–1440	1	Washer–Lock
63	80–7730	3	Spacer
64	92–1351	1	Plug–Pulley
65	32120–74	1	Snap–Ring

Ref. No.	Part No.	Qty.	Description




Parts not listed in part list are not serviced separately

Sheet No.:B3
T–3636

Gear Pump Assembly No. 94–8297

Ref. No.	Part No.	Qty.	Description
1	49–2640	1	Seal–Shaft
2	56–6710	4	O–Ring
3	60–5890	1	Washer
4	94–3011	1	Plug
5	94–8160	4	Washer
6	95–4362	1	Plate–Front
7	95–4363	1	Backplate
8	95–4364	2	Body
9	95–4365	1	Gear–Drive
10	95–4366	2	Gear–Idler
11	95–4367	2	Gasket
12	95–4368	2	Plate–Wear
13	95–4369	2	Seal
14	95–4370	8	Screw–Cap
15	95–4371	1	Plate–Adaptor
16	95–4372	1	Key
17	95–4373	1	Gear–Fit, Slip
18	95–4374	1	Valve–Relief

Ref. No.	Part No.	Qty.	Description




Sheet No.:B4
T–3637

Traction Pump Assembly No. 86–5590

Ref. No.	Part No.	Qty.	Description
1	92–1354	1	Cap–End
2	92–1355	2	Plug–Special
4	75–0240	2	O–Ring
5	75–0140	2	Spring–Conical
6	84–0550	2	Ring–Retaining
7	92–1356	2	Valve–Screw
8	84–0480	1	Poppet–Relief, Charge
9	84–0490	1	Spring–Compression
10	92–1353	1	Kit–Shim
11	28–3570	1	O–Ring
12	84–0500	1	Charge Relief Plug ASM
13	75–0500	1	Bearing–Needle
14	84–0210	1	Gasket–Cap, End
15	75–0480	2	Pin
16	84–0460	8	Screw–HWHTF
17	84–0440	2	Cover–Trunnion
18	84–0430	4	O–Ring
19	84–0270	4	Spacer–Trunnion
20	84–0570	4	Shim–Trunnion, Composite
21	84–0260	4	Bearing–Roller, Tapered
22	353–551	3	Plug–HH
22:1	237–80	1	O–Ring
24	84–0360	8	Washer

Ref. No.	Part No.	Qty.	Description
25	84–0330	8	Screw–HH
26	84–0300	1	Shaft–Pump
27	84–0310	1	Bearing–Ball
28	84–0320	1	Ring–Retaining
29	84–0400	1	Seal–Lip
30	84–0410	1	Carrier–Seal
31	28–3520	1	O–Ring
32	84–0380	2	Ring–Retaining, Internal
33	84–0240	1	Housing–Pump
34	84–0470	2	Seal–Lip
35	84–0450	1	Cover–Trunnion
36	84–0250	1	Swashplate–Variable
37	75–0400	1	Plate–Thrust
38	75–0470	1	Cylinder Block Kit
39	84–0280	1	Plate–Valve, RH
40	75–0510	1	Pin
41	92–1358	1	Coupling–9 Tooth
42	92–1352	3	Plug
43	92–1357	1	Pin




Sheet No.:17

Deck Drive Component Assembly

Ref. No.	Part No.	Qty.	Description
1	100–2592	3	Screw–HHF
2	84–1320–03	1	Shaft–PTO
3	33115–030	3	Screw–HH
4	104–2350–03	1	Adapter–Clutch
5	325–14	1	Screw–HH
6	84–1570	1	Spacer–Plate
7	84–1550	5	Mount–Rubber
8	98–7250	1	Clutch–PTO
9	3234–22	3	Screw–HHF
10	84–1560	4	Washer–Thrust
11	3296–25	5	Nut–Lock, NI
12	32128–49	3	Nut–HHF
13	3256–24	3	Washer–Flat
14	325–9	2	Screw–HH
15	88–1450	1	Locknut–Bearing
16	251–310	2	Bearing–Ball
17	92–5818–03	1	Housing
18	88–1140	1	Spacer–Bearing, Lower
19	84–1540	1	Key–Clutch
20	88–1170	1	V–Belt (Matched Set)
21	84–0180–03	1	Pulley–Lower
22	88–1510	1	Screw–Special
23	106–1004	1	Spacer–Clutch
24	92–5817	1	Pin–Stop, Clutch
25	88–8950	1	Decal–Warning

Ref. No.	Part No.	Qty.	Description
26	84–1580	1	Washer–Clutch
27	3234–19	1	Screw–HHF
28	86–3040	1	Coupler–Line, Drive
29	3296–39	3	Nut–Lock, NI
30	86–1990	4	Washer
31	302–60	1	Fitting–Grease
32	86–5620	1	Bearing–Ball, 2 Bolt Flange
33	104–7414	1	Harness–Wire, Main
34	32144–11	5	Screw–TAP
35	88–1280	1	Cover–Belt, Lower
36	3256–70	3	Washer–Flat
37	2412–109	2	Clip–J
38	3274–71	2	Screw–HSH
39	3296–47	1	Nut–Lock, NI
40	88–1460	1	Washer–Lock
43	323–45	3	Screw–HH




Sheet No.:B5
T–3638

Clutch Assembly No. 98–7250

Ref. No.	Part No.	Qty.	Description
1	88–1610	1	Field & Rotor ASM
2	88–1370	1	Plate–Brake
3	98–7253	1	Armature ASM
4	44–8320	3	Spring
5	3296–6	3	Nut–Lock, NI

Ref. No.	Part No.	Qty.	Description




Sheet No.:B6

T–3639

Electrical Schematic
Main Wire Harness Assembly No. 104–7414

Ref. No.	Part No.	Qty.	Description
1	94–8002	1	Fuse–Blade
2	94–8001	1	Fuse–80 Amp
3	86–7470	2	Diode ASM
4	67–7160	1	Block–Fuse

Ref. No.	Part No.	Qty.	Description




Sheet No.:18

Hydraulic Pump Fitting Assembly

Ref. No.	Part No.	Qty.	Description
1	2412–34	1	Clamp–Hose
2	95–4356	1	Fitting
2:1	237–71	1	O–Ring
3	80–7730	1	Spacer
4	340–18	2	Fitting–HYD, 90°
4:1	237–79	1	O–Ring
4:2	237–22	1	O–Ring
5	86–5480	2	Nipple–Test
6	340–115	2	Fitting–Tee
6:1	237–22	2	O–Ring
7	354–79	2	Cap–Dust, Yellow
8	340–17	2	Fitting–HYD, 90°
8:1	237–65	1	O–Ring
8:2	237–80	1	O–Ring
9	2412–104	1	R–Clamp
10	32128–20	1	Nut–HF
11	322–5	1	Screw–HH
12	88–1290–03	1	Bracket–Rod, Seat
13	324–4	2	Screw–HH
14	3253–6	2	Washer–Lock
15	340–155	2	Fitting–HYD (only on: 30455)
15:1	237–79	1	O–Ring (only on: 30455)
15:2	237–151	1	O–Ring (only on: 30455)

Ref. No.	Part No.	Qty.	Description
16	322–6	1	Screw–HH
17	3256–71	1	Washer–Flat
18	3296–47	1	Nut–Lock, NI
19	56–7973	2	Clamp–Tube
20	76–9970	1	Valve–4wd (only on: 30455)
21	340–55	1	Fitting–HYD, 45° (only on: 30455)
21:1	237–79	1	O–Ring (only on: 30455)
21:2	237–65	1	O–Ring (only on: 30455)
22	92–5828	1	Hose ASM (only on: 30455)
23	86–2770	1	4wd Tube ASM (only on: 30455)
24	321–15	2	Screw–HH (only on: 30455)
25	86–2710	1	Hose ASM (only on: 30455)
26	340–157	1	Fitting–HYD (only on: 30455)
26:1	237–79	1	O–Ring (only on: 30455)
26:2	237–30	2	O–Ring (only on: 30455)




Sheet No.:18

Hydraulic Pump Fitting Assembly (Continued)

Ref. No.	Part No.	Qty.	Description
27	340–4	1	Adapter (only on: 30455)
27:1	237–30	1	O–Ring (only on: 30455)
27:2	237–79	1	O–Ring (only on: 30455)
28	84–0720	1	Valve–Fuse, Velocity (only on: 30455)
29	340–165	1	Fitting–HYD, Elbow (only on: 30455)
29:1	237–30	1	O–Ring (only on: 30455)
29:2	237–79	1	O–Ring (only on: 30455)
30	340–7	2	Adapter
30:1	237–65	1	O–Ring
30:2	237–80	1	O–Ring
31	340–159	2	Fitting–HYD, 90°
31:1	237–22	2	O–Ring

Ref. No.	Part No.	Qty.	Description



Sheet No.:B9


T–3640

Solenoid Valve Assembly No. 76–9970 (only on: 30455)

Ref. No.	Part No.	Qty.	Description
1	237–80	2	O–Ring
2	218–591	1	Coil ASM
3	218–592	1	Nut–Coil
☆4		1	Adapter ASM
☆5		1	Valve–Directional
☆6		1	Spool
☆7		1	Tube ASM

Ref. No.	Part No.	Qty.	Description

☆ Not serviced separately




Sheet No.:19

Engine Fasteners Installation Assembly

Ref. No.	Part No.	Qty.	Description
1	3290–357	9	Nut–HHF
2	323–5	2	Screw–HH
3	3253–21	3	Washer–Lock
4	3256–24	4	Washer–Flat
5	3255–8	2	Washer–Lock
6	32144–11	2	Screw–TAP
7	323–4	1	Screw–HH
8	324–12	3	Screw–HH
9	33115–030	1	Screw–HH
10	33115–100	1	Screw–HH
11	32128–37	3	Nut–HF
12	87–5100	4	Washer–Snubbing
13	3234–11	6	Screw–HHF
14	323–9	1	Screw–HH
15	33114–016	8	Screw–HH
16	33114–025	1	Screw–HH
17	2412–3	4	Clamp–Hose
18	86–2990	2	Mount–Cable, Throttle
19	2412–36	5	Clamp–Hose
20	48–7570	3	Screw–HH
21	33104–016	2	Screw–HHF
22	2412–108	4	Clamp–Worm
23	2412–125	3	Clamp–Hose
24	32152–1	1	Nut–Lock, NI
25	33103–020	1	Screw–HHF
26	33093–00	1	Washer–Flat

Ref. No.	Part No.	Qty.	Description
27	3290–378	2	Tie–Cable
28	33023–00	1	Nut–Lock
29	33104–020	2	Screw–HHF
30	33004–00	2	Nut–HF
31	2412–129	6	Clamp–Hose
32	323–20	2	Screw–HH
33	3253–4	4	Washer–Lock
34	322–3	4	Screw–HH
35	32128–19	2	Nut–HF
36	32128–20	2	Nut–HF
37	33114–016	2	Screw–HH
38	3234–11	3	Screw–HHF
39	56–7971	2	Clamp–Tube
40	69–9760	1	Coverplate
41	322–9	1	Screw–HH
42	48–7810	3	Screw
43	33115–025	3	Screw–HH
44	33113–012	3	Screw–HH
45	94–2814	1	Kit–Coupler, Exhaust
46	62–9510	1	Washer–Lever, Brake
47	32148–9	3	Insert–Nut
48	33114–030	1	Screw–HH
49	48–7880	3	Nut–Hex
50	33014–00	2	Nut–Hex




Sheet No.:20

Engine Parts Installation Assembly

Ref. No.	Part No.	Qty.	Description
1	76–4310–03	1	Support–Base, Battery
2	74–5470–03	1	Mount–Engine, LH
3	76–6500–03	1	Base–Battery
4	66–2490	1	Retainer–Battery
5	53–9681	2	Mount–Engine
6	76–4120–03	1	Mount–Engine, RH
7	93–3220	1	Battery
8	74–9080	1	Cable–Battery, Positive
9	74–9090	1	Cable–Battery, Negative
10	94–1418	1	Hose–Radiator, Upper
11	84–0760–03	1	Adapter–Pump
12	100–3794	1	Engine ASM
13	53–9682	1	Rubber–Support, Engine
14	3290–378	2	Tie–Cable
15	93–7594	1	Spacer
16	93–4207	1	Fitting–Tee, Hose
17	93–7229–03	1	Support–Degassing
18	55–4130	1	Hose–Fuel
19	94–8003–03	1	Wireform–Hose
20	93–7788	1	Hose–Return
21	94–5625	1	Hose–Overflow, Radiator
22	93–7223	1	Hose–Intake

Ref. No.	Part No.	Qty.	Description
23	94–5604	1	Hose–Overflow
24	93–7224	1	Hose–Cleaner, Air
25	74–5520	1	Clutch–Fan
26	74–3650	1	Fan
27	93–7221	1	Hose–Radiator,Upper Rear
28	93–7245–03	1	Bracket–Support
29	63–7622	1	Hose–Fuel
30	93–9175	1	Dipstick
31	94–2812	1	Grommet
32	74–6020	1	Hose–Radiator, Lower
33	94–1416	1	Indicator Adapter ASM
34	94–5608	1	Mount–Rubber
35	100–2597	1	Air Filter ASM
36	92–7382–03	1	Cover
37	94–5615	1	Bracket–Hose, Return
38	94–8012	1	Muffler ASM
39	94–2630	1	Hose–Return
40	93–9164	1	Indicator–Mini
41	77–3700	1	Gasket–Muffler, Exhaust
42	83–9150	1	Decal–Fluid, Starting
43	92–7381	1	Tube–Return, Water
44	74–6490	2	Hose–Line, Water
45	76–4220–03	1	Mount–Engine, LH
46	84–1440–03	1	Plate–Adapter




Sheet No.:20

Engine Parts Installation Assembly (Continued)

Ref. No.	Part No.	Qty.	Description
47	77–3600	1	Shield–Adapter
48	94–2800	1	Cap–Pressure
52	94–2801	2	Grommet–Rubber
53	98–1805	1	Box–Degassing
54	94–9984	1	Sensor–Level, Water

Ref. No.	Part No.	Qty.	Description



Parts not listed in part list are not serviced separately


Sheet No.:B7

T–2076

Air Filter Assemby No. 100–2597

Ref. No.	Part No.	Qty.	Description
1	93–9162	1	Filter–Primary
2	93–9163	1	Filter–Secondary
3	94–1414	1	Valve–Vacuator

Ref. No.	Part No.	Qty.	Description




Sheet No.:21

Radiator Assembly

Ref. No.	Part No.	Qty.	Description
1	74–4980	1	Shroud–Top
2	3296–23	2	Nut–Lock, NI
3	93–6681	1	Decal–Warning, Fan
4	74–3410	1	Radiator ASM
5	93–7239–03	1	Mount–Radiator
6	3234–30	10	Screw–HHF
7	94–5621–01	1	Bracket–Screen
8	94–5622	1	Seal–Strip, Screen
9	82–3740	1	Cooler–Oil
10	3234–14	2	Screw–HHF
11	94–2638	4	Nut–Tinnerman
12	27–4570	4	Knob–Seat
13	94–5612–03	1	Screen
14	93–6028	1	Plate–Logo, Toro
15	3256–3	2	Washer–Flat
16	2410–64	3	Plug–Button
17	93–7244–03	1	Bracket–Support
18	322–4	5	Screw–HH
19	94–8010	2	Hose ASM
20	37–8771	2	Bolt–Shoulder
21	3296–47	5	Nut–Lock, NI
22	3234–11	3	Screw–HHF
23	340–72	2	Fitting–HYD, Bulkhead, 90°
23:1	237–65	2	O–Ring
24	340–74	2	Locknut–Bulkhead

Ref. No.	Part No.	Qty.	Description
25	237–65	2	O–Ring
26	32128–20	2	Nut–HF
27	76–6381	2	Strip–Sealing, Radiator
28	76–6382	2	Strip–Sealing, Fan Shroud
29	304–46	1	Draincock
30	2811–1	1	Elbow–Street, 45°
31	74–5460–03	1	Angle–Support, Radiator
32	325–35	2	Screw–HH
33	74–4990	1	Shroud–Bottom
34	2412–3	2	Clamp–Hose
35	32151–72	2	Ring–Retaining
36	3256–26	2	Washer–Flat
38	3256–23	7	Washer–Flat
39	32148–9	4	Insert–Nut
40	2412–36	1	Clamp–Hose
41	32128–49	2	Nut–HHF
42	94–5616	1	Seal–Hood
43	325–34	2	Screw–HH
44	88–1360	2	Washer–Weight, Rear
45	92–9711–03	1	Weight–Rear
46	98–7070	1	Weight ASM




Sheet No.:22

Rear Axle Assembly–2WD (only on: 30450)

Ref. No.	Part No.	Qty.	Description
1	105–7843	1	Rod End ASM
1:2	105–7942	1	Spacer
1:3	32136–2	1	Nut–SHH
1:4	105–7835	1	Seal
1:5	302–5	1	Fitting–Grease
2	3220–11	1	Nut–Jam
3	32144–11	1	Screw–TAP
4	74–6450	1	Bracket–Bulkhead, Steering
5	340–70	2	Nut–Lock
6	86–3130	1	Hose ASM
7	86–3120	1	Hose ASM
8	93–7247	2	Washer–Thrust
9	93–7240–03	1	Plate–Axle Pivot, Rear
10	325–20	2	Screw–HH
11	3296–45	2	Nut–Lock, NI
12	3256–29	1	Washer–Flat
13	94–8000	1	Nut–Hex
14	325–35	2	Screw–HH
15	3234–12	2	Screw–HHF
16	69–8890	2	Cap–Spindle
17	32151–10	2	Ring–Snap
18	62–2170	4	Washer–Thrust
19	94–5607	1	Axle ASM
19:1	69–6470	4	Bushing–Castor
19:2	94–5603	2	Bushing–Metric

Ref. No.	Part No.	Qty.	Description
19:3	302–11	2	Fitting–Lube, 45°
20	92–9725–03	1	Spindle–LH
21	92–9724–03	1	Spindle–RH
☆22		2	Wheel & Tire ASM
22:1	94–5236	1	Tire
22:2	100–2582	1	Rim
22:3	232–27	1	Stem–Valve
23	32128–49	4	Nut–HHF
24	3220–7	2	Nut–Jam
25	93–0307	2	Nut–Lock, Retainer
26	3272–13	2	Pin–Cotter
27	242–50	10	Nut–Lug
28	80–8660	1	Spacer–Coupler
29	32144–41	1	Screw–Taptite
30	92–9651	2	Hub Sub ASM
30:1	254–107	1	Cup–Bearing, Tapered
30:2	254–72	1	Bearing–Cup, Tapered
30:3	92–9652	5	Stud–Bolt
31	93–0309	2	Washer–Tab
32	3272–12	4	Pin–Cotter
33	92–5833	1	Spacer–Joint, Ball
34	105–7815–03	1	Tie Rod ASM
34:1	105–7812	1	Rod & Clamp ASM
34:2	71–4740	2	End–Rod, Tie
34:2:1	105–7941	1	Nut–Hex, Slotted
34:2:2	105–7835	1	Seal


☆ Not serviced separately



Sheet No.:22

Rear Axle Assembly–2WD (only on: 30450) (Continued)

Ref. No.	Part No.	Qty.	Description
34:2:3	302–5	1	Fitting–Grease
34:3	323–9	2	Screw–HH
34:4	3296–39	2	Nut–Lock, NI
35	340–97	2	Fitting–HYD, 90°
35:1	237–22	1	O–Ring
35:2	237–78	1	O–Ring
36	94–8142	1	HYD Cylinder ASM
37	92–5839	1	Joint–Ball
38	325–12	2	Screw–HH
40	302–2	2	Fitting–Grease
41	93–7249	1	Pin–Pivot, Axle
43	76–4880	1	Connector
44	56–7973	2	Clamp–Tube
45	32104–37	1	Screw–HWH
47	3256–71	1	Washer–Flat
48	76–8350	2	Stop–Axle
49	86–5780	1	RH Rear Steering Tube ASM
50	86–5790	1	LH Rear Steering Tube ASM
50:1	237–22	1	O–Ring
51	32151–104	1	Ring–Retaining, Ext
52	100–3769	2	Buddy–Bearing
53	100–3809	2	Cap–Protector, Bearing
54	254–92	2	Cone–Bearing, Outer
55	69–2980	2	Seal
56	254–106	2	Cone–Bearing, Tapered




Sheet No.:B8
T–3497

Hydraulic Cylinder Assembly No. 94–8142 (only on: 30450)

Ref. No.	Part No.	Qty.	Description
1	94–9959	1	Barrel ASM
2	94–9960	1	Piston Rod ASM
3	94–9961	1	Piston
4	94–9962	1	Gland–Cylinder
5	32152–10	1	Locknut
6	94–9963	1	Ring–Retaining
7	94–9964	1	Kit–Repair, Seal
☆7:1		1	Uniring
☆7:2		1	O–Ring
☆7:3		1	Seal–Rod
☆7:4		1	O–Ring
☆7:5		1	Backup
☆7:6		1	O–Ring

Ref. No.	Part No.	Qty.	Description

☆ Not serviced separately




Sheet No.:23
T–3642

Rear Axle Assembly–4WD (only on: 30455)

Ref. No.	Part No.	Qty.	Description
2	86–5780	1	RH Rear Steering Tube ASM
3	86–5790	1	LH Rear Steering Tube ASM
3:1	237–22	1	O–Ring
4	32144–11	2	Screw–TAP
6	100–3784	1	Drive Axle ASM
7	74–6450	1	Bracket–Bulkhead, Steering
8	76–9290	1	Bracket–Drain, Case
9	3234–4	1	Screw–HHF
10	32128–33	1	Nut–HF
11	340–70	3	Nut–Lock
12	86–3140	1	Hose ASM
13	76–9590	2	Hose ASM
14	302–5	2	Fitting–Grease
15	98–7076	2	Stop–Axle
16	56–7973	2	Clamp–Tube
18	98–3867	2	Washer–Thrust
19	74–5700	1	Bearing–Needle, Roller
20	340–74	1	Locknut–Bulkhead
21	86–2730	1	Hose ASM
22	2412–74	1	R–Clamp
23	325–36	2	Screw–HH
24	32104–37	1	Screw–HWH

Ref. No.	Part No.	Qty.	Description
25	3296–68	1	Nut–Lock, NI
26	92–1765	1	Washer–Thrust
27	99–7500	1	Clutch–Bi–Directional
28	33114–025	6	Screw–HH
29	3253–4	6	Washer–Lock
30	95–4393	1	Gear–Driven
31	340–156	1	Fitting–HYD
31:1	237–65	1	O–Ring
31:2	237–81	1	O–Ring
32	237–166	1	O–Ring
33	99–7502	1	Piston Motor ASM
34	340–139	1	Fitting–HYD, 90°
34:1	237–81	1	O–Ring
34:2	237–65	1	O–Ring
35	325–6	2	Screw–HH
36	32120–15	2	Ring–Snap, Ext
37	340–18	1	Fitting–HYD, 90°
37:1	237–79	1	O–Ring
37:2	237–22	1	O–Ring
38	80–8660	1	Spacer–Coupler
39	3256–71	1	Washer–Flat
40	325–35	2	Screw–HH
☆41		2	Wheel & Tire ASM
41:1	94–5236	1	Tire
41:2	100–2582	1	Rim
41:3	232–27	1	Stem–Valve

☆ Not serviced separately




Sheet No.:23
T–3642

Rear Axle Assembly–4WD (Continued) (only on: 30455)

Ref. No.	Part No.	Qty.	Description
42	32128–49	4	Nut–HHF
43	32151–104	2	Ring–Retaining, Ext
44	93–5268	10	Nut–Lug
46	353–508	2	Plug
46:1	237–42	1	O–Ring
47	100–3795	1	Joint–Ball
48	100–3796	1	Spacer–Joint, Ball
49	340–97	1	Fitting–HYD, 90°
49:1	237–22	1	O–Ring
49:2	237–78	1	O–Ring
50	98–3806	1	Hydraulic Cylinder ASM
51	92–5833	2	Spacer–Joint, Ball
52	94–8246–03	1	Pivot–Rear
53	325–12	2	Screw–HH
54	98–7077	1	Pin–Axle, Rear
55	302–2	1	Fitting–Grease
56	3296–23	2	Nut–Lock, NI
57	32136–14	2	Nut–SHH
59	92–5836	1	Washer
60	92–5838–01	1	Joint–Ball
62	302–33	1	Fitting–Grease
63	32144–41	1	Screw–Taptite
65	88–7200	1	Washer–Flat
66	33114–025	1	Screw–HH
67	3272–12	2	Pin–Cotter

Ref. No.	Part No.	Qty.	Description
68	104–2353	2	Pin–Dowel
69	340–54	1	Elbow–45°
69:1	237–22	1	O–Ring
69:2	237–78	1	O–Ring




Sheet No.:C1
T–3643

Bi–Directional Clutch Assembly No. 99–7500 (only on: 30455)

Ref. No.	Part No.	Qty.	Description
1	93–8923	1	Spring–Wave
2	93–8929	1	Washer–Thrust
3	93–8919	1	Bearing–Needle, Thrust
4	93–8925	6	Roller
5	32151–96	1	Ring–Retaining
6	100–2572	1	Bearing
7	100–2571	1	Spring–Form, Wire
8	100–2570	1	Hub ASM
9	100–2569	1	Housing ASM
10	100–2568	1	Roll Cage ASM

Ref. No.	Part No.	Qty.	Description




Sheet No.:C2

Hydraulic Motor Assembly No. 99–7502 (only on: 30455)

Ref. No.	Part No.	Qty.	Description
1	76–6910	1	Rotating Kit
2	76–6970	1	Insert–Plate, Cam
3	76–7010	1	Ring–Retaining
4	76–7000	2	Ring–Retaining
5	76–6950	2	Race–Thrust
6	76–6980	1	O–Ring
7	76–6960	1	Bearing–Thrust
8	100–2550	6	Screw, Cap
9	100–2551	1	Backplate
☆9:1		3	Pin–Dowel
☆9:2		1	Pin–Dowel
☆9:3		1	Bearing–Needle
10	100–2552	1	Housing
11	105–3331	1	Seal–Shaft
12	100–2554	1	Shaft, Drive

Ref. No.	Part No.	Qty.	Description

☆ Not serviced separately




Sheet No.:C3
T–3527

Hydraulic Cylinder Assembly No. 98–3806 (only on: 30455)

Ref. No.	Part No.	Qty.	Description
1	92–6593	1	Kit–Seal
☆1:1		1	Seal
☆1:2		1	O–Ring
☆1:3		1	O–Ring
☆1:4		1	O–Ring
☆1:5		1	U–Cup
☆1:6		1	Wiper
☆2		1	Locknut
☆3		1	Piston
☆4		1	Gland
☆5		1	Rod ASM


Ref. No.	Part No.	Qty.	Description


Hydraulic Schematic (only on: 30450)



T–1495–2

Hydraulic Schematic (only on: 30455)






Sheet No.:83
T–3202–1

Rear Axle Assembly No. 100–3784
Bevel Pinion Shaft Assembly

Ref. No.	Part No.	Qty.	Description
1	100–2555	1	Ring And Pinion Matched Set
2	99–7570	2	Bearing–Taper Roller
3	95–7534	1	Case–Bearing
4	99–7571	2	O–Ring
5	99–7572	1	Collar–Oil Seal
6	99–7573	1	O–Ring
7	99–7574	1	Seal–Oil
8	99–7559	1	Washer–Lock
9	99–7560	1	Nut–Lock
10	99–7550	2	Shim 0.1
10	99–7551	2	Shim 0.2
11	95–7533	1	Case–Gear
12	99–7575	2	Bolt
13	100–2556	2	Stud
14	99–7527	2	Washer–Spring
15	99–7526	2	Nut
16	95–7541	1	Plate–Cover
17	95–7540	1	Gasket
18	104–2353	2	Pin–Dowel

Ref. No.	Part No.	Qty.	Description




Sheet No.:84
T–3203–1

Rear Axle Assembly No. 100–3784 (Continued)
Differential Assembly

Ref. No.	Part No.	Qty.	Description
1	95–7503	1	Differential ASM
2	100–2555	1	Ring And Pinion Matched Set
3	95–7502	1	Case–Differential
4	99–7576	8	Bolt
5	99–7577	8	Washer–Spring
6	99–7578	1	Shaft–Differential
7	99–7579	2	Pinion–Differential
8	99–7580	2	Washer–Differential
9	99–7581	2	Gear–Differential
10	99–7582	2	Washer–Differential
10	99–7583	2	Washer–Differential
10	99–7584	2	Washer–Differential
11	99–7588	1	Pin–Spring
12	99–7562	2	Bearing–Ball
13	99–7585	2	Shim 0.1
13	99–7586	2	Shim 0.2
13	99–7587	2	Shim 0.4

Ref. No.	Part No.	Qty.	Description




Sheet No.:85

T–3204–1

Rear Axle Assembly No. 100–3784 (Continued)
Axle Support Assembly

Ref. No.	Part No.	Qty.	Description
1	95–7508	1	Support–Axle
2	95–7506	1	Support–Axle
3	95–7507	1	O–Ring
4	95–7537	2	Bushing–Flanged
5	99–7590	2	Washer–Seal
6	99–7589	2	Plug
7	99–7591	1	Oil Plug ASM
8	99–7592	8	Bolt
9	99–7593	2	O–Ring
10	104–2377	1	Extension, Vent
11	104–8643	1	Plug
12	104–8644	1	O–Ring

Ref. No.	Part No.	Qty.	Description




Rear Axle Assembly No. 100–3784 (Continued)
Bevel Gear Case Assembly

Ref. No.	Part No.	Qty.	Description
1	95–7538	2	Case–Bevel Gear
2	100–2557	2	Seal–Oil
2	104–2378	2	Bushing
5	104–2376	2	Knuckle ASM
5:1	104–2373	1	Knuckle
5:2	104–2372	1	O–Ring
6	104–2374	8	Bolt
7	100–3768	1	LH Steering Arm ASM
8	100–3766	1	RH Steering Arm ASM
10	95–7547	2	Shim 0.1
10	95–7548	2	Shim 0.2
10	95–7549	2	Shim 0.4
11	99–7597	4	Pin–Dowel
12	104–2375	4	Bolt
13	99–7599	8	Bolt
14	99–7525	4	Stud
15	99–7526	4	Nut
16	99–7527	4	Washer–Spring
18	100–3762	1	Tie Rod ASM
*18:1	100–3851	1	LH Tie Rod End ASM
*18:1:1	100–3853	1	Cover–Dust
*18:1:2	100–3854	1	Nut–Castle
18:2	100–3852	1	RH Tie Rod End ASM
18:2:1	100–3853	1	Cover–Dust

Ref. No.	Part No.	Qty.	Description
18:2:2	100–3854	1	Nut–Castle
18:3	100–3855	2	Bolt
18:4	99–7527	2	Washer–Spring
18:5	99–7526	2	Nut


* Not illustrated



Rear Axle Assembly No. 100–3784 (Continued)
Bevel Gear Shaft Assembly

Ref. No.	Part No.	Qty.	Description
1	95–7509	1	Shaft–Gear, Differential
2	95–7512	1	Shaft–Gear, Differential
3	95–7517	2	Gear–15 Tooth Bevel
4	99–7530	4	Bearing–Ball
5	99–7552	2	Shim 0.1
5	99–7553	2	Shim 0.2
5	99–7554	2	Shim 0.5
6	99–7531	2	Clip
7	95–7529	2	Shaft–Bevel Gear
8	95–7519	2	Gear–17 Tooth Bevel
9	99–7532	2	Bearing–Taper Roller
10	99–7558	2	Collar

Ref. No.	Part No.	Qty.	Description




Sheet No.:88
T–3207–1

Rear Axle Assembly No. 100–3784 (Continued)
Axle Case Assembly

Ref. No.	Part No.	Qty.	Description
1	95–7531	2	Case–Axle
2	99–7535	2	Plug
3	99–7536	2	Washer–Seal
4	95–7527	2	Gear–17 Tooth Bevel
5	99–7532	2	Bearing–Taper Roller
6	100–2560	2	Cover
7	100–2561	2	O–Ring
8	99–7589	2	Plug
9	99–7590	2	Washer–Seal
10	100–2562	8	Bolt

Ref. No.	Part No.	Qty.	Description




Sheet No.:89
T–3108–1

Rear Axle Assembly No. 100–3784 (Continued)
Axle Assembly

Ref. No.	Part No.	Qty.	Description
1	95–7522	2	Axle
2	99–7564	2	Seal–Oil
3	95–7544	4	Clip
4	95–7523	2	Spacer
5	99–7555	2	Shim 0.3
5	99–7556	2	Shim 0.2
5	99–7557	2	Shim 0.5
6	95–7524	2	Gear–29 Tooth Bevel
7	99–7534	2	Bearing–Ball
8	95–7521	2	Cover–Axle
9	99–7538	2	O–Ring
10	99–7561	2	Bearing–Ball
11	99–7539	2	Clip
12	99–7596	12	Bolt
13	99–7563	10	Stud

Ref. No.	Part No.	Qty.	Description




Sheet No.:2

Right Hand Deck Assembly

Ref. No.	Part No.	Qty.	Description
1	3216–6	1	Screw–HH
3	323–13	3	Screw–HH
4	86–2010	1	Pin–HOC
5	3290–256	1	Pin–Hair
6	3296–15	1	Nut–Lock NI
8	100–2588	1	V–Belt, B–Section
9	92–7758	1	RH Wing Deck ASM
9:1	32148–10	1	Insert–Threaded
9:2	43–8480	2	Decal–Danger
9:3	66–1340	1	Decal–Danger
9:4	69–6470	2	Bushing–Castor
9:5	85–6410	1	Decal–Danger
9:6	86–0700	1	Decal–HOC, RH Wing
9:7	86–0760	1	Decal–Belt, RH
10	92–9727	1	HOC Cap ASM
10:1	92–5581	1	Ring–Retaining
10:2	92–5583	1	Washer–Cap
10:3	92–9726	1	Spring–Compression
10:4	92–8861	1	Cap–HOC
11	86–2600–01	4	Washer–Guide, Belt
12	69–1510	5	Spacer–Castor
13	302–5	1	Fitting–Grease
15	32128–54	1	Nut–Flange
16	32128–29	1	Locknut–Flange
21	86–1440	2	Washer–Flat
22	3256–35	1	Washer–Flat

Ref. No.	Part No.	Qty.	Description




Sheet No.:3

Left Hand Deck Assembly

Ref. No.	Part No.	Qty.	Description
1	323–13	2	Screw–HH
2	32128–19	2	Nut–HF
3	100–2588	1	V–Belt, B–Section
4	3296–15	1	Nut–Lock NI
5	3290–256	1	Pin–Hair
6	86–2010	1	Pin–HOC
8	3216–6	1	Screw–HH
11	69–1510	5	Spacer–Castor
12	32128–54	1	Nut–Flange
14	302–5	1	Fitting–Grease
15	92–7756	1	LH Wing Deck ASM
15:1	32148–10	1	Insert–Threaded
15:2	43–8480	2	Decal–Danger
15:3	66–1340	1	Decal–Danger
15:4	69–6470	2	Bushing–Castor
15:5	85–6410	1	Decal–Danger
15:6	86–0710	1	Decal–HOC, LH Wing
15:7	86–0750	1	Decal–Belt, LH
16	86–2600–01	3	Washer–Guide, Belt
17	32128–29	1	Locknut–Flange
21	86–1440	2	Washer–Flat
22	92–9727	1	HOC Cap ASM
22:1	92–5581	1	Ring–Retaining
22:2	92–5583	1	Washer–Cap
22:3	92–9726	1	Spring–Compression
22:4	92–8861	1	Cap–HOC

Ref. No.	Part No.	Qty.	Description




Sheet No.:4

Center Deck Assembly

Ref. No.	Part No.	Qty.	Description
1	32128–19	2	Nut–HF
2	325–35	4	Screw–HH
3	3256–26	4	Washer–Flat
4	86–2230–01	1	Guide–Cover, RH
5	86–2260–01	1	Guide–Cover, LH
6	86–2190	2	Cylinder–Lift, Wing
7	32121–51	2	Pin–Roll
8	3272–12	2	Pin–Cotter
9	94–8008	2	Plate–Wear
10	86–8100–01	2	Joint–Ball
10:1	302–5	1	Fitting–Grease
10:2	32136–2	1	Nut–SHH
10:3	105–7835	1	Seal
11	21–3000–01	2	Nut–Jam, Push Arm
12	325–11	2	Screw–HH
13	86–2280–01	1	Tube–Carrier, RH
14	3290–256	2	Pin–Hair
15	94–8009–01	2	Strap–Deck, HOC
16	86–2320–01	1	Tube–Carrier, LH
17	32128–54	2	Nut–Flange
18	86–2390	2	Pin
19	86–1890–03	4	Hinge
20	32144–26	12	Screw–Flow
21	57–0690	2	Pin–Special
22	57–0680	2	Shaft–Roller
23	29–4820	2	Roller

Ref. No.	Part No.	Qty.	Description
24	3272–11	2	Pin–Cotter
25	92–7757	1	Center Deck ASM
25:1	32148–10	1	Insert–Threaded
25:2	43–8480	1	Decal–Danger
25:3	55–4300	2	Decal–Warning
25:4	68–8340	1	Decal–Torque
25:5	69–6470	4	Bushing–Castor
25:6	85–6410	1	Decal–Danger
25:7	86–0720	1	Decal–HOC, LH Center
25:8	86–0730	1	Decal–HOC, RH Center
25:9	86–0740	1	Decal–Belt, Center
26	3234–1	1	Screw–HHF
27	68–6840	1	Shaft–Roller
28	32128–21	1	Nut–HF
29	68–6710	1	Roller
30	92–9727	2	HOC Cap ASM
30:1	92–5581	1	Ring–Retaining
30:2	92–5583	1	Washer–Cap
30:3	92–9726	1	Spring–Compression
30:4	92–8861	1	Cap–HOC
31	69–7290–01	2	Mount–Joint, Ball
32	32128–23	4	Nut–HF
33	77–0950	2	Washer–Castor
35	69–1510	10	Spacer–Castor



Sheet No.:4


Center Deck Assembly (Continued)

Ref. No.	Part No.	Qty.	Description
36	302–5	2	Fitting–Grease
38	84–5300	4	Nut–Jam
39	92–5810–03	2	Female Rod End ASM
*39:1	32136–2	1	Nut–SHH
*39:2	105–7835	1	Seal
*39:3	302–5	1	Fitting–Grease
40	92–5811–03	2	Male Rod End ASM
*40:1	32136–2	1	Nut–SHH
*40:2	105–7835	1	Seal
*40:3	302–5	1	Fitting–Grease
41	3296–23	2	Nut–Lock, NI
46	86–2510–01	2	Spring–Comp, Lift
47	86–1440	4	Washer–Flat
48	3296–29	4	Nut–Lock, NI
49	322–21	4	Screw–HH
50	106–1017–03	1	Shield–Wire Harness, LH
*53	106–1022–03	1	Shield–Wire Harness, RH

Ref. No.	Part No.	Qty.	Description

* Not illustrated

3328–139




Sheet No.:A1

T–1464

Hydraulic Cylinder Assembly No. 86–2190

Ref. No.	Part No.	Qty.	Description
1	92–0603	1	Rod/Piston
2	92–0604	1	Head–Ring, Snap
3	92–0602	1	Barrel ASM
4	92–0600	1	Kit–Seal


Ref. No.	Part No.	Qty.	Description



Deck Breakaway Assembly

Ref. No.	Part No.	Qty.	Description
1	3296–29	4	Nut–Lock, NI
2	84–1350	4	Pin–Pivot
3	3218–18	2	Nut–Jam
4	60–9870	2	Screw
5	53–6380	4	Washer
6	323–4	4	Screw–HH
7	92–4036	2	Cap–Rod
8	92–4037	2	Capscrew–HSH
9	106–1006–01	4	Arm–Pivot
10	302–5	4	Fitting–Grease
12	86–2080–01	4	Joint–Ball
12:1	32136–2	1	Nut–SHH
12:2	105–7835	1	Seal
12:3	302–5	1	Fitting–Grease
13	86–1440	8	Washer–Flat
14	32128–54	4	Nut–Flange
15	86–2560–01	2	Spring–Compression
16	86–2650	2	Spring–Support
17	3272–5	6	Pin–Cotter
18	86–2090	6	Bushing–Pm
19	86–2150	2	Lock
20	283–61	6	Pin–Yoke
21	86–2130	2	Pin–Clevis
22	3272–9	2	Pin–Cotter
23	86–2180	4	Bushing–Flange
24	86–2120	4	Roller–Lock

Ref. No.	Part No.	Qty.	Description
25	94–8031	2	Boot–Switch
26	94–8029	2	Nut–Special
27	237–7	2	O–Ring
28	94–8023	2	Guide–Pin, Switch
29	94–8024	2	Plunger–Switch
30	43–8600	2	Spring–Compression
31	55–4300	2	Decal–Warning
32	43–8610	2	Guide
33	237–42	2	O–Ring
34	72–4320	2	Switch




Sheet No.:6

Trap Door Assembly

Ref. No.	Part No.	Qty.	Description
1	32128–19	2	Nut–HF
2	323–13	4	Screw–HH
3	86–1820–01	1	Bracket–Pulley
4	32144–70	2	Screw–HH
5	3296–25	2	Nut–Lock, NI
6	32121–11	2	Pin–Roll
7	86–2400–01	2	Latch–Arm
8	325–5	2	Screw–HH
9	86–1560	2	Spacer–Cylinder, Lift
10	86–1490	2	End–Rod, LH Thread
11	3220–12	2	Nut–HJ,LH Thread
12	86–1570	2	Rod–Threaded
13	3220–5–01	2	Nut–HJ
14	86–1550	2	End–Rod, RH Thread
15	3296–25	2	Nut–Lock, NI
16	3256–26	4	Washer–Flat
17	92–7766–01	1	Bracket–Pulley
18	92–4033–01	2	Trap–Door
19	256–243	2	Bearing–Flange
20	325–7	2	Screw–HH
23	3290–467	2	Pin–Hair
24	86–2590	2	Rod–Clutch
25	237–141	4	Grommet–Rubber
26	48–7081	2	Grip–Plastic
27	86–2600–01	4	Washer–Guide, Belt

Ref. No.	Part No.	Qty.	Description
28	3290–378	2	Tie–Cable
29	3290–483	2	Washer




Sheet No.:7

Drive Assembly

Ref. No.	Part No.	Qty.	Description
1	86–1730	1	Driveshaft
2	86–1830	1	Cover–Driveshaft
3	32144–70	3	Screw–HH
4	325–7	2	Screw–HH
5	3234–1	4	Screw–HHF
6	95–4375	1	Harness–Wire, Deck
7	323–14	2	Screw–HH
11	32128–23	2	Nut–HF
12	86–3100–03	1	Pulley–Gearbox, High Speed
*12	86–1410–03	1	Pulley–Gearbox
13	3296–39	2	Nut–Lock, NI
15	86–1970	1	V–Belt
16	86–1990	6	Washer
17	84–1550	4	Mount–Rubber
18	325–9	2	Screw–HH
19	86–2020–01	1	Support–Gearbox
20	100–2585	1	Gearbox
21	2412–138	1	R–Clamp
22	70–2560	1	Decal–Oil
23	86–0780	1	Decal–HOC
26	2412–150	1	J–Clip
27	3234–1	2	Screw–HHF
29	100–2591	1	Shield ASM
29:2	32148–9	2	Insert–Nut

Ref. No.	Part No.	Qty.	Description

* Not illustrated




Sheet No.:A2
T–1465

Driveshaft Assembly No. 86–1730

Ref. No.	Part No.	Qty.	Description
1	86–1150	2	Yoke–End
2	86–1160	2	Kit–Joint, Universal
3	86–1170	1	Shaft–Yoke, Slip
4	86–1180	1	Tube–Yoke, Slip
5	3273–17	4	Screw–HSH


Ref. No.	Part No.	Qty.	Description



Sheet No.:A3
T–3570

Gearbox Assembly No. 100–2585


Ref. No.	Part No.	Qty.	Description
1	100–4571	1	Bearing–Cup
2	100–4572	1	Bearing–Cone
3	104–2359	2	Bearing–Cup
4	104–2360	2	Bearing–Cone
5	100–5817	1	Bearing–Cup
6	104–2358	1	Bearing–Cone
7	100–5818	8	Screw–HH
8	100–5812	3	Plug
9	100–4580	2	Key–Woodruff
10	100–1391	2	Nut–Lock
11	104–2361	1	Seal
12	104–2367	1	Gear–RH
13	104–2368	1	Gear–LH
14	104–2362	1	Shaft–Input
15	100–9984	1	Cap–End, Closed
16	104–2357	1	Cap–End, Open
17	100–5826	1	Case
18	104–2363	1	Shaft–Output
19	104–2364	1	Seal
20	100–5824	2	Washer
23	100–5847	1	O–Ring
24	104–2365	1	Housing–Pinion
25	100–5848	2	O–Ring
26	100–1394	3	Shim–Green (.003in)
27	100–7758	3	Shim–Blue (.005in)
28	100–1396	3	Shim–Brown (.010in)
29	100–7760	3	Shim–Yellow (.020in)
30	104–2366	4	Screw



Rear Castor Assembly

Ref. No.	Part No.	Qty.	Description
1	75–9790–01	2	Arm–Pivot
2	93–9938	2	8 Inch Wheel ASM
2:1	93–9939	1	Tire
2:2	68–8950	1	Tube–Inner (W/Valve)
2:3	93–4241	1	Spacer–Bearing, Inner
2:4	93–4237	2	Bearing
2:6	32128–16	4	Nut–HHF
2:7	93–4242	1	Plate
2:8	93–4239	1	Rim–Wheel, Half
2:9	93–5980	1	Hub
2:10	95–2741	1	Rim–Wheel, Half
3	327–24	2	Screw–HH
4	3296–53	2	Nut–Lock, NI
5	93–5974	2	8 Inch Foam Filled Wheel ASM
5:1	93–9939	1	Tire
5:3	93–4241	1	Spacer–Bearing, Inner
5:4	93–4237	2	Bearing
5:6	32128–16	4	Nut–HHF
5:7	93–4242	1	Plate
5:8	93–4239	2	Rim–Wheel, Half
5:9	93–5980	1	Hub

Ref. No.	Part No.	Qty.	Description




Sheet No.:9

Pulley Assembly

Ref. No.	Part No.	Qty.	Description
1	92–0625	6	Flat Pulley ASM
1:1	100–2587	2	Spacer–Bearing
1:2	38–7820	2	Bearing–Ball
1:3	84–0920	1	Pulley–Flat
2	92–9722	4	V–Pulley ASM
2:1	92–9719	1	Pulley–V
2:2	38–7820	2	Bearing–Ball
2:3	100–2587	2	Spacer–Bearing
3	104–2355	2	Idler Pulley ASM
3:1	104–2356	1	Pulley–Idler
3:2	38–7820	2	Bearing–Ball
3:3	100–2587	2	Spacer–Bearing

Ref. No.	Part No.	Qty.	Description




Sheet No.:10

Front Castor Assembly

Ref. No.	Part No.	Qty.	Description
1	3296–53	4	Nut–Lock, NI
2	92–7750–01	2	Fork–Castor
3	92–7752–01	2	Fork–Castor
4	327–24	4	Screw–HH
5	93–9938	2	8 Inch Wheel ASM
5:1	93–9939	1	Tire
5:2	68–8950	1	Tube–Inner (W/Valve)
5:3	93–4241	1	Spacer–Bearing, Inner
5:4	93–4237	2	Bearing
5:6	32128–16	4	Nut–HHF
5:7	93–4242	1	Plate
5:8	93–4239	1	Rim–Wheel, Half
5:9	93–5980	1	Hub
5:10	95–2741	1	Rim–Wheel, Half
6	93–4240	2	10 Inch Wheel ASM
6:1	93–4243	1	Tire
6:2	93–4244	1	Tube–Inner (W/Valve)
6:3	93–4241	1	Spacer–Bearing, Inner
6:4	93–4237	2	Bearing
6:5	32128–16	4	Nut–HHF
6:7	93–4242	1	Plate
6:8	93–4239	1	Rim–Wheel, Half
6:9	93–5980	1	Hub
6:10	95–2741	1	Rim–Wheel, Half
7	93–5974	2	8 Inch Foam Filled Wheel ASM

Ref. No.	Part No.	Qty.	Description
8	93–5973	2	10 Inch Foam Filled Wheel ASM




Sheet No.:11

Belt Tensioner Assembly

Ref. No.	Part No.	Qty.	Description
1	32128–43	3	Nut–Flange
2	95–4383	3	Pulley Yoke ASM
2:1	55–4300	1	Decal–Warning
3	86–0060	6	Sleeve–Tube
4	86–0050	3	Screw
5	3217–9	3	Nut–HH
6	92–0626	3	Tube ASM
6:1	106–1005	1	Decal–Adjustment, Gm
7	92–7767	2	Spring–Compression
8	92–7768	1	Spring–Compression
9	86–2000	3	Screw
10	322–5	3	Screw–HH

Ref. No.	Part No.	Qty.	Description




Sheet No.:12

Hydraulic Assembly

Ref. No.	Part No.	Qty.	Description
1	340–70	6	Nut–Lock
2	86–2480	1	RH Cylinder Tube ASM
3	86–2490	1	LH Cylinder Tube ASM
4	86–2470	1	Cylinder Drain Tube ASM
5	86–2460	2	Hose ASM
6	340–87	3	Fitting–HYD, 45°
6:1	237–22	1	O–Ring
6:2	237–42	1	O–Ring
7	86–5460	3	Nipple–Coupler
8	86–2630	2	Spring–Compression
9	84–6403	2	Disc–Orifice
10	86–2450	2	Hose ASM
11	340–77	2	Fitting–HYD, 90°
11:1	237–22	1	O–Ring
11:2	237–42	1	O–Ring
12	86–2440	2	Hose ASM
13	340–166	1	Fitting–Tee, HYD
13:1	237–22	1	O–Ring
14	86–2640	2	Deck Cylinder Tube ASM
15	340–86	2	Fitting–Tee, HYD
15:1	237–22	2	O–Ring
15:2	237–42	1	O–Ring
16	340–2	2	Fitting–HYD, Straight
16:1	237–22	1	O–Ring

Ref. No.	Part No.	Qty.	Description
16:2	237–42	1	O–Ring
17	86–0690	3	Spacer
18	92–5807	2	Retainer–Hardlines
19	86–1420	1	LH Lift Hose ASM




Sheet No.:13

Cover Assembly

Ref. No.	Part No.	Qty.	Description
1	3250–20	8	Screw–PPH
2	3256–67	8	Washer–Flat
3	86–1840	1	Cover–Deck, RH
4	3234–29	8	Screw–HHF
5	86–1900–03	4	Plate–Hinge
6	86–1870	1	Cover–Center, RH
7	86–1860	1	Cover–Center
8	86–1880	1	Cover–Center, LH
9	86–1850	1	Cover–Deck, LH
10	3296–59	4	Nut–Lock, NI
11	86–1920	2	Spring–Torsion
12	32128–20	8	Nut–HF
13	323–15	4	Screw–HH
14	86–1890–03	4	Hinge
15	86–0790	8	Insert–Cover
16	86–0770	1	Decal–Quadfloat
17	32144–70	2	Screw–HH
18	86–2660–01	1	Stop–Cover
19	2412–138	1	R–Clamp

Ref. No.	Part No.	Qty.	Description




Sheet No.:14

Clutch Spindle Assembly

Ref. No.	Part No.	Qty.	Description
1	302–33	2	Fitting–Grease
2	3296–49	2	Nut–Lock, NI
3	100–2559	2	Clutch–Brake, Electric
4	68–3220	2	Stock–Key
5	86–1740	2	Spacer
6	84–0780–01	2	Pulley–Spindle
7	253–154	4	Seal–Oil
8	3234–42	12	Screw–HHF
9	69–1530	2	Housing–Spindle
10	3290–357	12	Nut–HHF
11	86–2360	2	Shaft–Spindle, Clutch
12	69–6950	2	Spacer–Shaft, Spindle
13	86–0010–03	2	Blade
14	72–9361	2	Cup–Scalp, Anti
15	94–8013	2	Washer–Thrust
16	92–5816	2	Bolt–Blade
17	86–1480	2	Washer
19	71–2530	2	Bearing/Spacer Kit

Ref. No.	Part No.	Qty.	Description




Sheet No.:A4
T–3581

Electric Clutch Brake Assembly No. 100–2559

Ref. No.	Part No.	Qty.	Description
1	67–7050	1	Field And Rotor ASM
5	104–2370	1	Armature ASM
5:1	67–7080	1	Sleeve–Bearing, Armature
5:2	67–7090	1	Bearing–Armature
5:3	67–7060	1	Ring–Retaining
9	3296–6	3	Nut–Lock, NI
10	44–8320	3	Spring

Ref. No.	Part No.	Qty.	Description




Sheet No.:15

Center Spindle Assembly

Ref. No.	Part No.	Qty.	Description
1	302–2	1	Fitting–Grease
2	3296–49	1	Nut–Lock, NI
3	86–1480	1	Washer
4	84–0780–01	1	Pulley–Spindle
5	253–154	2	Seal–Oil
6	3234–42	6	Screw–HHF
7	69–1530	1	Housing–Spindle
8	3290–357	6	Nut–HHF
9	86–2340	1	Shaft–Spindle, Center
10	69–6950	1	Spacer–Shaft, Spindle
11	86–0010–03	1	Blade
12	72–9361	1	Cup–Scalp, Anti
13	92–5816	1	Bolt–Blade
14	71–2530	1	Bearing/Spacer Kit

Ref. No.	Part No.	Qty.	Description




Sheet No.:16

Wing Spindle Assembly

Ref. No.	Part No.	Qty.	Description
1	302–2	4	Fitting–Grease
2	3296–49	4	Nut–Lock, NI
3	86–1480	4	Washer
4	104–2354–03	4	Pulley–Spindle
5	253–154	8	Seal–Oil
6	3234–42	24	Screw–HHF
7	69–1530	4	Housing–Spindle
8	3290–357	24	Nut–HHF
9	86–2340	4	Shaft–Spindle, Center
10	69–6950	4	Spacer–Shaft, Spindle
11	86–0010–03	4	Blade
12	72–9361	4	Cup–Scalp, Anti
13	92–5816	4	Bolt–Blade
14	71–2530	4	Bearing/Spacer Kit

Ref. No.	Part No.	Qty.	Description




Sheet No.:3
T–2142

Crankcase Assembly

Ref. No.	Part No.	Qty.	Description
1	94–3181	1	Oil Filler
2	94–3182	1	Plug
4	94–3184	1	Hose–Crankcase
8	2412–129	8	Clamp–Hose
11	74–7770	1	Hose – Crank Case
12	74–7780	1	Gasket
13	74–7790	1	Screw
14	74–7800	2	Spring Pin
15	74–7810	1	Gasket–Plate
16	74–7820	1	Plate
17	94–3112	2	Screw
18	74–7840	8	Plug
18	94–3108	8	Plug–27.5mm
18	94–3109	9	Plug–28.5mm
19	74–7320	1	Gasket–Oil Drain Plug
20	74–7310	1	Oil Drain Plug
21	74–7380	1	Oil Sump Gasket
22	94–3111	2	Pin
23	74–7300	1	Oil Sump Assy
24	74–7850	2	Gasket
25	74–7330	23	Screw–HH
26	77–3790	1	Drain Plug
27	74–7930	10	Capscrew–Bearing
28	74–7940	1	Spring Bushing
29	74–7950	6	Plate Screw
30	74–7960	1	Filter Stud

Ref. No.	Part No.	Qty.	Description
31	74–7970	1	Oil Filter
32	94–3180	1	Pressure Switch
33	74–7990	4	Spring Pin
34	74–8000	2	Plug
35	74–8010	1	Tube
36	94–3100	1	Cylinder Block
37	74–8030	1	Spring Pin
38	74–8040	1	Plug
39	94–3183	1	Gasket
40	94–3186	1	O–Ring
42	94–3106	2	Gasket
43	94–3104	2	Plug–Threaded
44	94–3103	1	Plug–Threaded
45	94–3110	1	Stud
46	74–5760	1	Valve Pvc F/W
47	94–3192	1	Hose–Manifold
48	94–3191	1	Hose–Pcv Valve
*52	94–3101	1	Gasket Set
*53	77–3600	1	Shield–Adapter

* Not illustrated




Sheet No.:4

Crankshaft Assembly

Ref. No.	Part No.	Qty.	Description
1	94–3145	1	Screw–Pulley
2	74–8080	1	Washer
3	94–3144	1	Pulley–Crankshaft
4	74–8100	1	Pinion Gear
5	74–8110	1	Oil Pump Sprocket
6	74–8120	2	Key – Woodruff
7	94–3150	4	Screw–HH
8	94–3151	6	Washer–Spring
9	74–8140	1	Cover
10	74–8150	1	Cover Gasket
11	94–3148	1	Gasket
12	74–8170	5	Bearing Set (STD)
12	74–8180	2	Bearing Set (.30mm Os)
13	74–8200	2	Thrust Bearing Set
13	74–8210	2	Thrust Bearing Set
13	74–8220	2	Thrust Bearing Set
13	94–3141	2	Flange Set
14	74–8230	1	Crank Shaft
15	74–8240	1	Seal
16	74–7990	1	Spring Pin
17	94–3149	1	Gear–Flywheel
18	74–8270	3	Pin
19	74–8280	8	Screw Hex Hd
20	74–8290	2	Cap–Bearing
21	74–8300	8	Piston Pin Clip

Ref. No.	Part No.	Qty.	Description
22	74–8310	4	Piston Pin
23	74–8320	4	Piston Ring Set
23	74–8330	4	Piston Ring Set
23	74–8340	4	Piston Ring Set
23	94–3158	4	Piston Ring Set
24	94–3154	4	Bushing
25	94–3153	4	Connecting Rod Set
27	74–8380	4	Bearing–Connecting Rod
27	94–3155	1	Bearing Set–1st Repair
28	74–8400	8	Bolt – Connecting Rod
29	74–8420	1	Piston Set
29	74–8430	1	Piston Set
29	74–8440	1	Piston Set
29	94–3157	1	Piston Set
33	94–3152	2	Screw–HH
34	74–8260	1	Flywheel




Sheet No.:5

T–3504

Cylinder Head Assembly

Ref. No.	Part No.	Qty.	Description
1	94–3123	2	Capscrew
2	94–3117	1	Plate
3	94–3116	1	Gasket
4	74–7600	4	Plug
5	94–3113	1	Cylinder Head
5	94–9965	1	Cylinder Head ASM
6	76–5130	6	Stud
7	74–8900	6	Washer – Flat
8	94–3115	6	Nut
9	74–6570	8	Cup–Lower Valve Spring
10	74–6560	8	Valve Spring
11	74–6550	8	Cup
12	74–7240	16	Split Collar
13	74–6580	8	Insert – Valve (1.65mm)
13	74–6590	8	Insert –Valve (1.725mm)
13	74–6600	8	Insert –Valve (1.800mm)
13	74–6610	8	Insert –Valve (1.900mm)
13	74–6620	8	Insert –Valve (1.975mm)
13	74–6630	8	Insert –Valve (2.050mm)

Ref. No.	Part No.	Qty.	Description
13	74–6640	8	Insert –Valve (2.125mm)
13	74–6650	8	Insert –Valve (2.225mm)
13	74–6660	8	Insert –Valve (2.250mm)
13	74–6670	8	Insert –Valve (2.275mm)
13	74–6680	8	Insert –Valve (2.300mm)
13	74–6690	8	Insert –Valve (2.325mm)
13	74–6700	8	Insert –Valve (2.350mm)
13	74–6710	8	Insert –Valve (2.375mm)
13	74–6720	8	Insert –Valve (2.400mm)
13	74–6730	8	Insert –Valve (2.425mm)
13	74–6740	8	Insert –Valve (2.450mm)
13	74–6750	8	Insert –Valve (2.475mm)
13	74–6760	8	Insert –Valve (2.500mm)




Sheet No.:5

T–3504

Cylinder Head Assembly (Continued)

Ref. No.	Part No.	Qty.	Description
13	74–6770	8	Insert –Valve (2.525mm)
13	74–6780	8	Insert –Valve (2.550mm)
13	74–6790	8	Insert –Valve (2.575mm)
13	74–6800	8	Insert –Valve (2.600mm)
13	74–6810	8	Insert –Valve (2.625mm)
13	74–6820	8	Insert –Valve (2.650mm)
13	74–6830	8	Insert –Valve (2.675mm)
13	74–6840	8	Insert –Valve (2.700mm)
13	74–6850	8	Insert –Valve (2.725mm)
13	74–6860	8	Insert –Valve (2.750mm)
13	74–6870	8	Insert –Valve (2.775mm)
13	74–6880	8	Insert –Valve (2.800mm)
13	74–6890	8	Insert –Valve (2.825mm)

Ref. No.	Part No.	Qty.	Description
13	74–6900	8	Insert –Valve (2.850mm)
13	74–6910	8	Insert –Valve (2.875mm)
13	74–6920	8	Insert –Valve (2.900mm)
13	74–6930	8	Insert –Valve (2.925mm)
13	74–6940	8	Insert –Valve (2.950mm)
13	74–6950	8	Insert –Valve (2.975mm)
13	74–6960	8	Insert –Valve (3.000mm)
13	74–6970	8	Insert –Valve (3.025mm)
13	74–6980	8	Insert –Valve (3.050mm)
13	74–6990	8	Insert –Valve (3.075mm)
13	74–7000	8	Insert –Valve (3.100mm)
13	74–7010	8	Insert –Valve (3.125mm)
13	74–7020	8	Insert –Valve (3.150mm)




Sheet No.:5

T–3504

Cylinder Head Assembly (Continued)

Ref. No.	Part No.	Qty.	Description
13	74–7030	8	Insert –Valve (3.175mm)
13	74–7040	8	Insert –Valve (3.200mm)
13	74–7050	8	Insert –Valve (3.225mm)
13	74–7060	8	Insert –Valve (3.250mm)
13	74–7070	8	Insert –Valve (3.275mm)
13	74–7080	8	Insert –Valve (3.300mm)
13	74–7090	8	Insert –Valve (3.325mm)
13	74–7100	8	Insert –Valve (3.350mm)
13	74–7110	8	Insert –Valve (3.375mm)
13	74–7120	8	Insert –Valve (3.400mm)
13	74–7130	8	Insert –Valve (3.425mm)
13	74–7140	8	Insert –Valve (3.450mm)
13	74–7150	8	Insert –Valve (3.475mm)

Ref. No.	Part No.	Qty.	Description
13	74–7160	8	Insert –Valve (3.500mm)
13	74–7170	8	Insert –Valve (3.550mm)
13	74–7180	8	Insert –Valve (3.625mm)
13	74–7190	8	Insert –Valve (3.700mm)
13	74–7200	8	Insert –Valve (3.775mm)
13	74–7210	8	Insert –Valve (3.850mm)
13	74–7220	8	Insert –Valve (3.925mm)
13	74–7230	8	Insert –Valve (4.000mm)
14	74–6540	8	Tappet – Valve
15	94–3155	1	Bearing Set–1st Repair
16	74–7560	3	Lockwasher
17	76–5470	2	Capscrew – Hex Head
18	74–7630	1	Gasket – Valve Cover
19	74–7640	1	Valve Cover
20	74–7650	3	Washer – Flat
21	94–3125	3	Washer–Plate
22	94–3124	3	Screw–HH



Sheet No.:5


T–3504

Cylinder Head Assembly (Continued)

Ref. No.	Part No.	Qty.	Description
23	94–3136	1	Bracket–Lifting
24	94–3138	1	Screw–HH
25	94–3137	1	Bracket–Lifting
26	94–3139	1	Screw
27	94–3174	8	Washer–Repair
28	74–7270	10	Washer–Flat
29	74–7260	10	Head Bolt
30	94–3197	1	O–Ring
31	94–3196	1	Water–Inlet
32	94–3118	1	Plug
33	74–7840	2	Plug
33	94–3108	2	Plug–27.5mm
33	94–3109	2	Plug–28.5mm
34	68–9420	5	Washer–Lock
35	48–9460	2	Capscrew–Hex
36	2412–129	4	Clamp–Hose
37	94–3200	1	Hose–By Pass
38	48–7700	3	Screw
39	94–3199	1	Pipe–By Pass
40	94–3201	1	Hose–By Pass
41	74–7400	1	Tube
42	74–7840	2	Plug
43	94–3122	1	Gasket
44	94–3121	1	Plug
45	74–7420	4	Ball
46	74–7430	4	Chamber–Turbulence

Ref. No.	Part No.	Qty.	Description
46	74–7440	4	Chamber – Turbulence
47	92–7792	8	Valve Guide (14.29 Mm)
47	92–7793	8	Valve Guide (14.59 Mm)
48	74–7450	4	Exhaust Valve Seat
48	74–7460	4	Seat–Intake Valve (39.5)
49	74–7480	4	Intake Valve
50	92–7794	4	Valve – Exhaust
51	92–7795	4	Valve Seat
52	92–7791	8	Valve – Stem Seal
53	94–8132	1	Gasket – Head, 1.48
53	94–8133	1	Gasket – Head, 1.52
53	94–8134	1	Gasket – Head, 1.58
53	94–8135	1	Gasket – Head, 1.62
54	94–3120	1	Bracket
*55	74–7670	1	Head Bolt & Washer Set
*56	94–3119	1	Gasket Set

* Not illustrated




Sheet No.:6
T–2141

Camshaft and Fan Support Assembly

Ref. No.	Part No.	Qty.	Description
1	98–9968	2	Screw
2	77–3450	2	Washer
3	77–3420	1	Gasket
4	98–9967	1	Key
5	77–3400	1	Cam Shaft
6	94–3163	1	Screw–HH
7	94–3166	1	Washer–Plate
8	94–9994	1	Gasket – Camshaft
9	94–3162	1	Stud
10	94–3164	4	Washer–Spring
11	94–3159	1	Tensioner
12	94–3165	1	Nut–Hex
13	77–3520	1	Cup
14	77–3510	1	Spring
15	94–3160	1	Roller
16	94–3161	2	Screw–HH
17	94–3170	1	Screw
18	74–8830	1	Belt – Timing
19	94–3172	3	Washer
20	94–3171	2	Screw–HH
21	94–3168	1	Pulley–Fan
22	94–3173	3	Capscrew
23	76–5010	3	Washer–Spring
24	94–3167	1	Bracket–Fan
25	94–3169	1	Screw
26	98–9966	1	Gear – Camshaft

Ref. No.	Part No.	Qty.	Description




Sheet No.:7
T–2140

Timing Cover Assembly

Ref. No.	Part No.	Qty.	Description
1	94–3132	2	Screw–HHF
2	94–3130	1	Screw–HH
3	94–3125	1	Washer–Plate
4	94–3129	1	Plug
5	94–3126	1	Protector–Lower
6	94–3133	1	Nut–w/Washer
7	94–3127	1	Timing Case–Left
8	94–3134	1	Nut
9	94–3128	1	Timing Case Right
10	94–3131	1	Screw–HH

Ref. No.	Part No.	Qty.	Description




Sheet No.:8
T–2149

Intake and Exhaust Manifold Assembly

Ref. No.	Part No.	Qty.	Description
1	77–3300	6	Stud
2	77–3310	2	Gasket
3	77–3340	1	Manifold – Exhaust
4	68–9420	6	Washer–Lock
5	77–3320	6	Nut – Hex
6	94–3215	1	Manifold–Intake
7	94–3164	7	Washer–Spring
8	94–3216	5	Capscrew
9	94–3217	4	Capscrew
9	94–3218	1	Screw
*11	94–2815	1	Sleeve – Exhaust Flange
*12	94–2814	1	Kit – Exhaust Coupler

Ref. No.	Part No.	Qty.	Description

* Not illustrated




Sheet No.:9
T–0964

Oil Pump Assembly

Ref. No.	Part No.	Qty.	Description
1	76–5070	1	Oil Pump ASM
2	94–3176	1	Valve–Relief
3	76–5090	1	Piston Spring
4	94–3179	3	Washer–Spring
5	76–5100	1	Bolt–Shoulder
6	76–5010	5	Washer–Spring
7	94–3124	2	Screw–HH
9	94–3178	1	Strainer
10	77–3470	1	Screw
11	77–3490	1	Screw
12	94–3177	2	Plug
13	76–5170	1	Chain–Drive, Pump

Ref. No.	Part No.	Qty.	Description




Sheet No.:10
T–2143

Collector Assembly

Ref. No.	Part No.	Qty.	Description
1	94–3131	3	Screw–HH
2	94–3208	1	Outlet Stub
3	94–3205	1	Outlet Box
4	94–3207	1	Ring
5	94–3214	1	Capscrew
6	76–5380	1	Temp Sending Unit
7	94–3212	1	Plug
8	94–3213	1	Capscrew
9	94–3206	1	Gasket
10	94–3210	1	Gasket
11	94–3209	1	Thermostat
12	76–5400	1	Switch – Temp 105 DEG C

Ref. No.	Part No.	Qty.	Description




Sheet No.:11
T–2144

Water Pump Assembly

Ref. No.	Part No.	Qty.	Description
3	94–3197	1	O–Ring
4	94–3195	1	Gasket–Water Pump
5	94–3194	1	Cover–Water Pump
6	76–5500	5	Capscrew Hex Hd
7	94–3196	1	Water–Inlet
8	94–3198	2	Screw–HHF

Ref. No.	Part No.	Qty.	Description

* Not illustrated




Sheet No.:12 T–2146

Fuel Injection Pump Assembly

Ref. No.	Part No.	Qty.	Description
1	76–4950	1	Flange Nut
2	76–4940	1	Pump Pulley
3	94–3220	1	Bracket
4	94–3225	2	Screw–HH
5	76–4930	3	Washer
6	94–3165	4	Nut–Hex
7	74–8610	2	Spring Pin
8	74–8630	1	Flange Bushing
9	94–3224	2	Washer–Plate
10	94–3164	6	Washer–Spring
11	94–3221	1	Screw–HH
12	74–8650	1	Pacer
13	74–8670	1	Fuel Inlet ASM
14	74–8680	2	Gasket
15	94–3251	1	Nut–Lock
16	74–8710	1	Washer
17	93–5856	1	Solenoid Valve
18	94–3274	1	O–Ring
19	94–3219	1	Pump–Injection
20	94–3222	1	Key
21	74–8870	2	Gasket
22	94–3249	1	Outlet Tube
23	94–3250	1	Screw
24	94–3161	1	Screw–HH
25	94–3223	1	Screw–HH
26	76–4910	3	Stud

Ref. No.	Part No.	Qty.	Description
27	94–9969	1	Screw – Connection
28	94–9970	1	Screw – Purge



Sheet No.:13


T–2145

Fuel Injector Assembly

Ref. No.	Part No.	Qty.	Description
1	94–3230	1	Hose – Injection
2	76–5540	4	Injector Bushing
3	76–5530	4	Washer
4	94–3226	4	Gasket–Injector
5	76–5520	4	Fuel Injector Holder
6	94–3232	4	Washer–Calibration (.79)
6	94–3233	4	Washer–Calibration (.82)
6	94–3234	4	Washer–Calibration (.85)
6	94–3235	4	Washer–Calibration (.88)
6	94–3236	4	Washer–Calibration (.91)
6	94–3237	4	Washer–Calibration (.94)
6	94–3238	4	Washer–Calibration (.97)
6	94–3239	4	Washer–Calibration (1.0)
6	94–3240	4	Washer–Calibration (1.03)
6	94–3241	4	Washer–Calibration (1.06)

Ref. No.	Part No.	Qty.	Description
6	94–3242	4	Washer–Calibration (1.30)
6	94–3243	4	Washer–Calibration (1.33)
6	94–3244	4	Washer–Calibration (1.36)
6	94–3245	4	Washer–Calibration (1.39)
6	94–3246	4	Washer–Calibration (1.42)
6	94–3247	4	Washer–Calibration (1.45)
6	94–3248	4	Washer–Calibration (1.48)
7	94–3228	4	Spring
8	94–3227	4	Spacer
9	94–8147	4	Nozzle – Injector
10	74–8770	1	Plug
11	94–3229	3	Hose – Injector
12	74–8750	1	Injection Tube Set
13	94–3231	2	Bracket
*14	76–5600	4	Fuel Injector ASM

* Not illustrated




Sheet No.:14
T–2147

Alternator Assembly

Ref. No.	Part No.	Qty.	Description
1	76–5060	1	Screw–HH
2	76–5010	1	Washer–Spring
3	94–3260	1	Washer–Flat
4	94–3255	1	Slide
5	94–3256	1	Belt
6	94–3254	1	Screw
7	94–3253	1	Bracket–Alternator
8	74–8610	2	Spring Pin
9	76–5000	1	Adj Bolt
10	94–3262	1	Nut–HHF
11	94–3261	1	Nut–HHF
12	94–3252	1	Alternator
13	94–3257	1	Washer–Spring
14	94–3258	1	Capscrew
15	76–4990	1	Bolt–Slide

Ref. No.	Part No.	Qty.	Description




Sheet No.:15
T–0968

Starter Assembly

Ref. No.	Part No.	Qty.	Description
1	46–0330	2	Nut–Lock
2	76–5570	2	Lockwasher
3	94–3263	1	Starter
4	76–5590	1	Sleeve–Spring
5	48–7810	3	Screw

Ref. No.	Part No.	Qty.	Description

3328–139



Sheet No.:16
T–0972

Glow Plug and Glow Relay Assembly

Ref. No.	Part No.	Qty.	Description
1	76–5260	1	Relay–Glow Plug
2	94–3265	4	Glow Plug Cable ASM
3	94–3264	4	Plug–Glow
4	76–5290	4	Spring Washer
5	94–3266	4	Nut
6	94–3267	1	Nut–Lock
7	76–5310	1	Washer
8	94–3251	1	Nut–Lock
9	74–8710	1	Washer

Ref. No.	Part No.	Qty.	Description

Maintenance Record

Date								


TORO®